

INSTALLATION, OPERATING and SERVICE MANUAL

**NEWMAC COMBINATION FURNACE
CL 86-96C, CL 86-96G, CL 115-170C, CL 115-170G**

The installation of the unit shall be in accordance with the regulations of the authorities having jurisdiction.


**HEAD OFFICE
MARKETING / PRODUCTION
Newmac Mfg. Inc.**

DEBERT AIR INDUSTRIAL PARK,
208 LANCASTER CRESCENT
P.O. BOX 9, DEBERT
NOVA SCOTIA, B0M 1G0
PHONE: 902-662-3840
FAX: 902-662-2581

**WAREHOUSE
Newmac Mfg. Inc.**

430 SPRINGBANK AVE., SOUTH
P.O. BOX 545
WOODSTOCK, ONTARIO
N4S 7Y5
PHONE: 519-539-6147
FAX: 519-539-0048

EMAIL: newmac@ca.inter.net
HOMEPAGE: newmacfurnaces.com



**NOTICE TO HOMEOWNER:
READ THESE INSTRUCTIONS
SAVE THESE INSTRUCTIONS**

2210040 Revised November 2008



COMBINATION FURNACES
MODELS CL 86-96C, CL 86-96G, CL115-170C, CL 115-170G

It is the responsibility of the consignee of the unit to examine the packages for damages, and if found, to note the same on the Carrier' Bill of Lading.

PACKAGE # 1 – Heat exchanger with end panels and side panel installed, filters, draft regulator, accessory carton, brick rack, if brick liner, in firebox. CL 115-170G have 5 grates, 9 liner pieces and 1 shaker handle in firebox. CL 86-96G have 3 grates, 6 split brick and shaker handle in firebox, CL 86-96C have 8 split brick in firebox.

PACKAGE # 2 – Blower section with blower installed, blower belt attached.

PACKAGE # 3 – Oil Burner box with oil burner, primary relay, cell and nozzle.

PACKAGE # 4 – Firebrick CL 86-96C – 20 full brick
 CL 86-96G – 20 full brick
 CL 115-170C – 30 full brick

Accessory Carton – Wire harness, fan limit control, solid fuel and oil burner thermostats, junction box with relay transformer mounted, blower motor and pulley, draft fan package, Instruction Manual.

FIG. 1 - GENERAL INSTRUCTIONS

MODEL	AERO	BTUH INPUT	BTUH OUTPUT	NOZZLE	PUMP (p.s.i.)	INSERTION
CL86	F-AFC-2-8	105,000	86,000	.75 (80 R)	100	7-7/8"
CL96	F-AFC-2-8	119,000	96,000	.85 (80 R)	100	7-7/8"
CL115	F-AFC-3-8	140,000	111,000-109,000	1.00 (80 R)	100	7-7/8"
CL140	F-AFC-3-8	175,000	140,000-138,000	1.25 (80 R)	100	7-7/8"
CL155	F-AFC-3-8	189,000	152,000-150,000	1.35 (80 R)	100	7-7/8"
CL170	F-AFC-3-8	210,000	169,000-168,000	1.50 (80 R)	100	7-7/8"
MODEL	BECKETT	BTUH INPUT	BTUH OUTPUT	NOZZLE	PUMP (p.s.i.)	INSERTION
CL86	SR81RD (NM201)	105,000	86,000	.75 (80 R)	100	7-7/8"
CL96	SR81RD (NM201)	119,000	96,000	.85 (80 R)	100	7-7/8"
CL115	SR81RF (NM202)	140,000	111,000-109,000	1.00 (80 R)	100	7-7/8"
CL140	SR81RF (NM202)	175,000	140,000-138,000	1.25 (80 R)	100	7-7/8"
CL155	SR81RF (NM202)	189,000	152,000-150,000	1.35 (80 R)	100	7-7/8"
CL170	SR81RF (NM202)	210,000	169,000-168,000	1.50 (80 R)	100	7-7/8"
CL86	AFG (NM502)	105,000	86,000	.75 (70 A)	100	7-7/8"
CL96	AFG (NM502)	119,000	96,000	.85 (70 A)	100	7-7/8"
CL115	AFG (NM503)	140,000	111,000-109,000	1.00 (70 A)	100	7-7/8"
CL140	AFG (NM503)	175,000	140,000-138,000	1.25 (70 A)	100	7-7/8"
CL155	AFG (NM503)	189,000	152,000-150,000	1.35 (70 A)	100	7-7/8"
CL170	AFG (NM503)	210,000	169,000-168,000	1.50 (70 A)	100	7-7/8"
MODEL	RIELLO	BTUH INPUT	BTUH OUTPUT	NOZZLE	PUMP (p.s.i.)	INSERTION
CL96	40 F3 (10" BT)	111,000	94,000	0.65 (60W)	150	7-1/2"
CL96	40 F3 (10" BT)	111,000	94,000	0.65 (AB)	150	7-1/2"
CL96	40 F3 (10" BT)	119,000	101,000	0.75 (60W)	130	7-1/2"
CL115	40 F5 (10" BT)	140,000	111,000-109,000	0.85 (60 W)	150	7-1/2"
CL140	40 F5 (10" BT)	175,000	140,000-138,000	1.00 (60 W)	150	7-1/2"
CL155	40 F5 (10" BT)	189,000	152,000-150,000	1.10 (60 W)	150	7-1/2"

Minimum Clearance From Combustible Surfaces: See FIG. 6

Oil burner end	24"	Flue Pipe	18"
Wood door end	48"	Top of Supply Plenum	6"
One side	6"	Supply Plenum and takeoff ducts to 6' from furnace	6"
Other side (walkway)	24"	Duct beyond 6' from furnace	1/2"
		In USA next 3'	3", balance 1"
		Return Air is "otherwise certified" to be installed as per CSA B139 Clearances (Unlined Joist Space may be used for the Return Air as there is no radiation in the Return Air section)	

Effective August 2008 Refer to Canadian Building Code

COMBINATION FURNACE INSTALLATION


Check with provincial, state or local codes concerning clearances, chimney requirements and other installation procedures before installation. Some codes may vary from the requirements set forth in this manual.

To ensure the furnace is on a level foundation and above any possible dampness, a cement pad is recommended. It is important that the top be level. Install as close to the chimney as possible so that a minimum of pipes and elbows may be used.


If unit is installed in an enclosed area (furnace room), ventilation must be provided for the burner – minimum of one square inch for every 1,000 BTU.

1. The NEWMAC COMBINATION FURNACE may be installed with the supply or return air on either side. The units leave the factory with the return or cold air on the right when viewed looking at the oil burner end. If it simplifies the duct installation to have the supply air on the opposite side, remove the installed panel and install it on the other side.
2. After placing the heat exchanger on the proper side of the pad, assemble the blower section to the heat exchanger section by lining up the prepunched holes and metal screwing together.
3. Install the oil nozzle in the burner firing assembly, and check to make sure adjustments are according to Fig. 15. Install the oil burner by mounting it on the burner mounting plate. Check to make sure the oil burner tube is aligned with the hole in the combustion chamber.
4. Install junction box, fan/limit control, draft fan and thermostat as in Fig. 7. Note recommended setting.

FIG. 2 - THERMOSTAT HEAT ANTICIPATORS



HONEYWELL T822




WHITE ROGERS IF30

In order to prevent short cycling, the heat anticipator in the thermostats must be set at .4 amps as indicated in the diagrams below.

WARNING: The heat anticipator will **BURN OUT** IF 25 volts are applied directly to thermostat by shorting out primary control during testing or incorrect wiring. If this happens the warranty on the thermostat is void.

FIG. 3 - FAN AND LIMIT CONTROLS

Settings: Fan off – 95 F, Fan on – 130 F. High limit – 210 F for CL-115-170C&G, 180 F for CL-86-96C&G



NOTE: For constant fan operation, push the MANUAL-AUTO switch on button to MAN position.

5. Connect wiring as in Fig. 12 (All models).
6. Install the oil storage tank or tanks according to the instructions supplied by the manufacturer of the pump.
7. Install brick in firebox according to Fig. 9A for CL-86-96 G, Fig. 8B for CL-86-96C, and Fig. 8A for CL-115-170C. For grate installation in CL-86-96G refer to Fig. 9A and for grate and cast liner installation in CL-115-170G refer to Fig. 9B.
8. Do not use a manual flue pipe damper with this furnace.
9. **Caution:** If this furnace is used as a replacement for an existing furnace make sure there is a minimum of 6" clearance above the warm air plenum as far as 6 feet out from the furnace. Beyond 6 feet there must be a minimum of 1/2" clearance.

This furnace must be connected to a chimney approved for wood burning appliances, ie. ULC S629 (Canada) and UL103 (US). Newmac recommends an 8" round or 8" square chimney flue (inside dimension), however, this may be reduced to a 7" providing there is enough draft at the appliance to operate as designed. It is the responsibility of the installer to ensure there is sufficient draft in all cases. Draft should be between -0.03 and -0.05 ins wc. No other appliance should be connected to this chimney flue, unless the installation conforms to clause 5 of B365 and providing there is sufficient draft.

amended April 2003

The installation must conform with the regulations of the local authorities having jurisdiction with the applicable Electrical Code, and C.S.A. Standard B139 "The Installation Code for Oil Burning Appliances and Equipment" and with the regulations in C.S.A. Standard B365 "The Installation Code for Solid Fuel Burning Appliances and Equipment" when pertaining to supply air plenum clearances and flue pipe installation. The flue pipe must be black 24 ga pipe minimum.

The flue collar is sized so that a trade size flue pipe fits snugly inside it. Joints in flue pipes, including the connection at the appliance and the chimney, shall have at least 30mm (1 3/16") overlap. Flue pipe connections must be secured with at least 3 metal screws or an equivalent mechanical means; and be made tight in accordance with good practice.

The flue products may contain carbon monoxide particularly when the wood fire is being starved for air (made to burn at slow rate). Therefore, the flue pipe must seal tight and must not be inserted into the return air stream of the circulating blower.

Wood storage should conform to local bylaws, and should not be within minimum clearances for combustible surfaces as shown above. This furnace must be installed by a qualified furnace serviceman.

COMBUSTION AIR: Where fans are used in the fuel storage area, they should be installed so as not to create negative pressure in the room where the solid fuel burning appliance is located.

OUTSIDE COMBUSTION AIR: Provision for outside combustion air may be necessary to ensure that fuel-burning appliances do not discharge products of combustion into the house. Guidelines to determine the need for additional combustion air may not be adequate for every situation. If in doubt, it is advisable to provide additional air.

Outside combustion air may be required if:

1. the solid-fuel-fired appliance does not draw steadily, experiences smoke roll-out, burns poorly, or back-drafts whether or not there is combustion present;
2. existing fuel-fired equipment in the house, such as fireplaces or other heating appliances, smell, do not operate properly, suffer smoke roll-out when operated, or back-draft whether or not there is combustion present;
3. any of the above symptoms are alleviated by opening a window slightly on a calm (windless) day;
4. the house is equipped with a well-sealed vapor barrier and tight lifting windows and/or has any powered devices which exhaust house air;
5. there is excessive condensation on windows in the winter; or
6. a ventilation system is installed in the house.

If these or other indications that infiltration air is inadequate, additional combustion air should be provided from the outdoors.

BELT TENSION: When adjusting the proper pulley setting make certain that the belt is able to flex at least one inch without movement of the motor pulley.

DUCT INSTALLATION: To prevent excessive noise and temperature rise, limit the minimum return air duct size to at least 250 square inches (in²). Because the unit may be used as a gravity furnace when the power is off, the following is recommended:

1. Locate the furnace as centrally as possible in the home so the best warm air distribution may be enjoyed.
2. Use an extended plenum (central duct) at least one size larger than called for in National Warm Air Standards.
3. Use a minimum pipe size of six inches in diameter in runs and in no case smaller than five inch diameter.
4. Slope extended plenums and runs as much as possible to facilitate gravity flow of warm air.

IMPORTANT:

FIG. 4 - MINIMUM DUCT SIZES

Model	Return Air	Supply Air	Static Pressure
CL86/96	250 sq. in.	180 sq. in.	.20" W.C.
CL115	250 sq. in.	220 sq. in.	.20" W.C.
CL140	250 sq. in.	220 sq. in.	.20" W.C.
CL155	280 sq. in.	240 sq. in.	.20" W.C.
CL170	300 sq. in.	260 sq. in.	.25" W.C.

The above chart gives the MINIMUM free area duct size. The supply air extended plenum should be 8 – 10 feet out from the furnace with the sizes shown in the chart, then gradually transitioned to the end of duct system. If the plenum is lower than 24 inches high, increase the duct size proportionately. The Supply Air free area for CL-115 C&G is the same as CL-140 C&G because the wood burning portion of the furnace can produce 140,000 BTU.

HUMIDIFIER: Install humidifier in the return air plenum. This prevents possible damage due to excessive temperatures when there is a power failure.

Metal connecting ducting from the warm air plenum should be used.

OIL FIRED BLOCKED VENT SWITCH - MODEL WMO-1

Refer to the Newmac and Field Controls Instructions enclosed in the WMO-1 package.

Do not use the WMO-1 Blocked Vent Switch with the Newmac SVS Sealed Vent System

When installed on the chimney vent or on the appliance burner plate according to these instructions, the manually reset WMO-1 blocked vent switch is designed to shut off power to the oil burner if the hot flue gases in the chimney vent connector pipe back up sufficiently to activate it. The WMO-1 switch is required on new Newmac oil-fired and combination furnaces or boilers installed in Canada. It must be installed by a qualified installer in accordance with the manufacturer's installation instructions. Electrical wiring must be in accordance with applicable codes and the Canadian Electrical Code. Before leaving the appliance check that the WMO-1 switch and its cover are tightly secured.

Installation on the Burner Plate - combinations - Figs. 5A and 5B

1. See Fig. 5A. Remove the 5/8" diameter plug in the burner plate. Cut or file a hole in the rigid fiberglass insulation, behind the 5/8" hole in the burner plate, large enough that the WMO-1 securing nut will seat against the back of the burner plate. Remove one of the securing nuts from the tube of the WMO-1 assembly. Tighten the remaining nut onto the tube as far as possible.
2. See Fig 5B. With the WMO-1 assembly outside the burner plate, insert the threaded tube end into the 5/8" diameter hole in the burner plate, re-install the first securing nut onto the tube on the inside of the burner plate. Tighten securely.

CAUTION: Disconnect the electrical power supply before wiring the WMO-1 assembly.

3. See Fig. 5C. Using suitable AC90 flexible (BX) conduit or equivalent, wire the WMO-1 switch in series with the appliance limit circuit. Connect at the burner junction box.
4. Check the operation of the WMO-1 switch before leaving the appliance. The WMO-1 switch is reset by pushing the square red button.

WMO-1 Blocked Vent Switch Check

Note: take appropriate precautions - this test can produce soot, smoke and fumes. The appliance should not be left unattended during the test.

1. With the appliance shut down, block the vent pipe at the downstream (chimney) side of the barometric damper.
2. Start the appliance.
3. The WMO-1 switch should stop the oil burner in less than 10 minutes.
4. After the test, turn off the appliance and let it cool.
5. Remove the blockage from the vent pipe.
6. Reset the WMO-1 switch by pushing in the square red button until it clicks.
7. Ensure that the appliance is in a safe condition.

Maintenance and Cleaning

The WMO-1 switch assembly should be checked and cleaned at least once a year and after any time the switch has shut off the burner.

Cleaning procedure

1. Switch off the electrical power to the appliance.
2. Remove the WMO-1 cover.
3. Remove the two mounting screws for the thermodisc temperature sensor.
4. Carefully pull the sensor to one side.
5. Using a suitable soft brush or cloth carefully clean any soot from the surface of the sensor and the inside of the 5/8" diameter tube.
6. Replace the sensor and secure with its mounting screws.
7. Check that the wiring is in good condition and secure.
8. Check that the 5/8" diameter tube and its securing nuts are tight.
9. Replace the cover and tighten the mounting screws.
10. Check the operation of the WMO-1 switch as described above.

Troubleshooting

If for any reason the WMO-1 switch shuts the appliance down during operation, the cause of the shut down should be investigated and corrected before resetting the switch and restarting the appliance. The blockage switch is reset by pushing the square red button until it clicks.

FIG. 5A




FIG. 5B




FIG. 5C




FIG. 6 - FLUE PIPE CONNECTION & MINIMUM INSTALLATION CLEARANCES






FIG. 7 - CONTROL LOCATIONS

Mount Limit Control Bracket
flush with outside edge of
plenum for CL115-170C & G

Mount Limit Control flush
with inside edge of plenum
for CL86-96C & G



*Flexible conduit should be clamped at 18" intervals, within 4" of a junction box, and routed away from warm air plenum







FIG. 8A
COMBINATION MODELS CL 115C-170C
FIREBOX INSTALLATION PROCEDURE
WITH STAINLESS STEEL FRONT





FIG. 8B
COMBINATION MODELS CL86C-96C
FIREBOX INSTALLATION PROCEDURE
WITH STAINLESS STEEL FRONT



GRATES:

SHIPPING RETAINER should be removed to allow grates to turn and shake freely.

To remove a grate:

1. Remove front casting
2. Slide grate as far forward as possible
3. Lift rear end of grate approximately 6 inches
4. Slide grate back toward rear of firebox and up

To install a grate:

1. With rear end of grate higher than front end slide grate forward so shaft is through grate retaining hole at front of firebox.
2. Lower rear end of grate and slide rear shaft of grate into rear retaining hole.
3. Replace front casting if coal is to be burned.

FRONT CASTING:

Use for coal burning only.

Installation in CL86-96G

1. Remove top brick lock
2. Put casting through firedoor and hold tight to inside front of firebox above the brick. Square pattern on casting should be facing into the firebox.
3. Lower casting so it rests on round shaft of grates.

FRONT CASTING:

Use for coal burning only.




Installation in CL115-170G

1. Put casting through firedoor and hold tight to inside front of firebox above top of liners. Square pattern on casting should be facing into the firebox.
2. Lower casting so it rests on round shaft of grate.

CAST LINERS:**In CL115-170G**

Hook liner pieces in retainers as shown. Install on sequence shown by numbers 1 to 6. The other 3 pieces are installed on opposite side from 4, 5, 6 beginning at back corner.

NOTE: This front casting is not required when burning wood. However, this casting or provided grate plate should be placed on top of the grates for more efficient wood burning and to prevent wood coals from falling through and warping grates.

FIG. 9A - CL86G-96G FIREBOX**FIG. 9B - CL115G-170G FIREBOX**

GRATE COVER.PRT

FIG. - 9C - GRATE PLATE

COMBINATION OPERATING INSTRUCTIONS

1. When the installation is complete set both burner and solid fuel thermostats to the bottom of the scale.
2. Close the supply switch and turn the solid fuel thermostat above room temperature. The draft fan should operate.

If this fails to happen, check (a) power supply, (b) voltage on secondary side of control relay – transformer, (c) correct wiring hook up, (d) correct voltage at fan motor. If (a) to (d) check OK, the fan is defective.

3. Open the line switch, turn the solid fuel thermostat to its lowest setting and the oil burner thermostat above room temperature. Remove the air bleed plug from the pump (refer to Diagram attached to pump) (a) open oil supply valve, (b) place a container in position to catch foam, (c) close the line switch and after pure oil is emitted, open the line switch and replace bleed plug, (d) close the line switch and the oil burner should run normally after a few seconds.
4. Adjust oil burner air control so that a # 1 or less smoke is arrived at by means of a smoke test. The damper in the wood firedoor must be closed during this procedure. If a smoke tester is not available, slowly close the air adjustment until the fire becomes smokey. Slowly open the air adjustment until there is a small amount of smoke on the flame tips.
5. By means of the barometric draft regulator – adjust to a - .03 draft at the chimney. This must be done by means of a draft meter. The maximum draft is not to be more than - .05 as damage can result to the furnace when used as a gravity unit. The test must be made between the flue collar on the furnace and the draft regulator. A flue gas analysis should be made and the unit adjusted so that between a 8 % and 10 % CO² is registered.
6. The combination fan & limit switch is thermally operated. The limit side is connected in series to the power supply to the oil burner. Because of blower failure, dirty filters or some other cause, the present limit will interrupt the power supply to the burner. If the limit switch shuts the unit down it may be because of a common fault, not enough return air supply or a supply air grill being covered by a rug.

The load side of a limit also supplies power to the transformer – relay. If the unit goes off on limit, the draft fan will shut off.

7. The fan side of the combination control is adjustable with fan on and off fingers. If the furnace fan has been adjusted to deliver a 75° F temperature rise (difference between return air and supply air) a setting of fan on 130° F and off at 90° - 100° F is comfortable. The temperature rise is accomplished by speeding up or slowing down the fan by means of the adjustable pulley on the fan motor. Maximum temperature rise is 85° F on models CL 115-170, and 75° F on CL 86-96.

The fan speed is adjusted at the factory to give a 75° F temperature rise at a .20" W.C. or .25" W.C. static pressure (air resistance in duct work). Since most home duct work does not have resistance of the value the fan speed must be adjusted by means of the following:

With the oil burner operating, place a thermometer in the warm air supply (place thermometer so that it cannot see the heat exchanger) and measure the temperature after the unit has been operating for at least 5 minutes. (Be sure the blower door is closed) measure the return air (at return air grill). If the difference is less than 75° F slow the fan speed by opening the motor pulley or if it is greater than 75° F close the pulley. In the majority of cases the fan must be slowed.


By means of the motor adjustment bracket, adjust the motor so that the belt may be deflected approximately one inch. This adjustment is important as a tight belt causes excessive fan bearing wear, it uses more electricity and it is noisy.

If the above instructions are followed, continuous air circulation can be comfortably accomplished without the added expense of a two speed motor, simply by using the manual fan switch on the face of the combination control.

8. Before loading the solid fuel firebox, turn the thermostat up to insure that the draft fan is on: after the fire is established set thermostat to desired temperature. IMPORTANT: Learn how to load your solid fuel box with wood (or coal (G model)) so as to maintain a comfortable home temperature. The amount of fuel required depends upon your home's heating requirements.
9. The oil burner thermostat on combination furnaces is generally set about 5° lower than the solid fuel side. When the solid fuel thermostat is calling for heat, the draft fan is on. If the fuel has been depleted and cannot keep the temperature up, the oil burner thermostat brings the oil burner on. The NEWMAC COMBINATION FURNACE has a relay that stops the draft fan when the oil burner comes on, making the oil fuel side efficient, and making the furnace operate safely.
10. (a) By means of a slide Draft Control above the firedoor, you can control the amount of combustion air allowed into the fire box. Move this slide plate to the open position that allows sufficient combustion air in for the type of solid fuel you are

burning. For coal it must be maximum; for wood it will vary with size and type. For added efficiency, when heating with oil only, close the slide plate and adjust your solid fuel thermostat to its lowest temperature setting.

(b) FURNACE LABEL ILLUSTRATION



11. For safe operating procedures for solid fuel burning, refer to the notice label on the furnace.

- The furnace room must have adequate air for combustion. If the unit is in a confined space, one square inch of free air access for every 1,000 BTU must be provided.
- Use a chimney suitable for solid fuel, which must be kept free of accumulations of soot and ash.
- Accumulations of soot and ash not only create a fire hazard but cause poor efficiency.
- In case of a soot fire, move all thermostats to their lowest setting, close the barometric draft regulator and call the fire department.

POWER FAILURE

In case of a prolonged power failure, remove the blower access doors to allow freer air movements. The draft fan will be off. If more combustion air is needed, open the damper in the furnace door.

When the electrical power is restored make sure panels are installed in original position and slide plate damper is closed.

DURING POWER FAILURE OPERATION: DO NOT CHARGE the solid fuel side higher than half way up the liner because overheating may result at the warm air outlets.

OIL BURNER OPERATING INSTRUCTIONS

GENERAL CARE

This burner is fully automatic in operation. All adjustments have been carefully set and should not be changed. Keep burner free from excess dirt and moisture. Any oil leaks, however small, should receive immediate attention. The oil filters should be cleaned once a year by the service man. The motor should be given a few drops of light oil two or three times a year. No other parts require lubrication.

FUEL

The supply tank should be kept at least one quarter full. Outside underground storage tanks if not equipped with a special gauge, are gauged by stick. Recommended grade of fuel: No. 2 Furnace Oil.

CAUTION

1. **DO NOT USE GASOLINE CRANKCASE OR ANY OIL CONTAINING GASOLINE.**
2. **DO NOT TAMPER WITH THE UNIT OR CONTROLS, CALL THE SERVICEMAN.**
3. Do not attempt to start burner when excess oil has accumulated, when the heating unit is full of vapour, or when the combustion chamber is very hot.
4. Do not start the burner unless the blower access door is secured in place.
5. **DO NOT BURN GARBAGE OR PAPER IN THE HEATING SYSTEM, AND NEVER LEAVE PAPER OR RAGS AROUND THE UNIT.**

HEATING PLANT

Give your Heating unit the proper care and attention. The use of the furnace as an incinerator is not recommended. Heating unit flues should be kept clean for economical operation. Dampers are set by installation men and should not be changed. Free ventilation must be permanently provided in the room where the burner installation is made.

CONTROLS

The operation of the burner is normally controlled by room thermostat, which may be set for any temperature desired, usually 70 °F. If a higher or lower temperature is desired, the indicator should be moved to the proper point on the scale. To shut down burner at any time, turn main switch to off position.

SUMMER SHUT DOWN

When burner is not to be used during the summer months turn off burner main switch. If the heating unit room is damp, protect burner against dirt and moisture with light cover.

SAFETY SHUT-OFF

An emergency oil shut-off valve should be installed as required by local ordinance. Always keep the valve shut-off if the burner is shut down for an extended period of time.

SERVICE:

If burner fails to run when the thermostat or other operating control is calling for heat see that the main switch is turned on and that fuses are not blown. Be sure there is oil in the supply tank and that the electric service to the building has not been temporarily interrupted. Press button on burner control box and if burner still fails to start call the service man. A periodic inspection of the burner is recommended.

BURNING WOOD OPERATING INSTRUCTIONS

When installation is complete, close the supply switch and turn the thermostat above room temperature.

Check to make sure the forced draft fan above the fire door is operating when the thermostat is set above room temperature.

The draft fan should be off when thermostat is set below room temperature.

The maximum draft is not to be more than - .05 as damage may result to the furnace when operated as a gravity unit.

The circulating air blower speed is adjusted at the factory to give an adequate temperature rise under most conditions. However, because of various temperatures that can result from burning wood, the blower speed can be adjusted by the motor pulley. Under no circumstances should the temperature rise be more than 80°F (27°F).

NOTE:

Before loading the fire box, turn the thermostat up to insure that the draft fan is on. This provides an air curtain to avoid smoke roll out during loading and fans the coals to assist the ignition process of your new fuel. It also helps to promote draft when there is inadequate draft. After the fire is established, set the thermostat to desired temperature.

To start the fire, turn up the thermostat to **Maximum** setting to turn **ON** Forced Draft Fan. Place some newspaper crumpled up in the bottom of the firebox on top of the minimum requirement of 2" of sand, ash or firebrick. Add some small kindling and light the fire. When the fire starts add some larger pieces of kindling or wood until you have a good fire. The idea is to ultimately end up with a good bed of ash and coals which helps to maintain a good controllable fire.

When reloading the firebox there will be a build up of ash and coals from the previous fire. Rake the coals mixed with ash to the front of the firebox which places the coals at the front. Throw in your wood and the fire should light in a few minutes.

When the firebox gets full of ash (within one inch of door level), some morning, before loading the firebox, push or rake the coals to the rear of the firebox. Remove the ash from the front of the firebox using only the shovel supplied for this purpose.

When the ashes only are removed from the front, rake the coals from the back to the front. Throw in your wood and the fire will again be burning in a few minutes. The fire burns best when the ashes are 3" to 4" below the fire door level.

Return wood thermostat in main living space to regular setting.

For safe operating procedure, refer to the "Notice" label on the furnace.

COMBUSTION AIR CONTROL

The amount of combustion air allowed to enter into the firebox can be controlled by means of the Draft Control slide on the draft fan mounting plate. Set this slide plate to the position that allows sufficient combustion air in for the type of solid fuel being burned. Normally the setting is in the center between maximum and minimum, then if additional control is needed it can be adjusted accordingly. When burning coal it must be set at maximum, for burning wood it will vary with size and type. **DO NOT LET THE COALS/ASHES BUILD UP ANY HIGHER THAN HALF WAY UP THE FIRE BOX LINER.**

POWER FAILURE

In case of prolonged power failure, remove the blower access door and air filters. The draft fan will be off, so if more combustion air is needed for the wood fire, open the slide plate damper in the fire door. This damper must be closed when power is returned to normal.

DO NOT CHARGE the fire box higher than half way up the liner as overheating may result.

COAL BURNING TIPS

Burn ONLY anthracite (hard) coal of the “chestnut” size. Bituminous (soft) coal is not recommended because it has a high ash and sulphur content which means more cleaning and greater pollution. Also bituminous coal produces excessive smoke and an excessive amount of dirt and ash, which will plug the heating unit and the flue pipe possibly causing smoke damage or danger of carbon monoxide poisoning.

Coal is not as easy to burn as wood. It requires patience and a very specific and regular procedure of loading, shaking, adjusting, etc. If you do not follow the correct procedure, the coal fire will go out. This can happen in a very short space of time and once the process of extinction has started, it is almost impossible to reverse.

After a coal fire goes out, all the coal must be emptied from the furnace and the complete starting process must be repeated. The coal burning learning process is often long and frustrating, but once the proper procedure is established and followed, coal burning becomes a reasonably simple process, with the benefits of long burn times and evenness of output over the entire length of burn.

STARTING UP A NEW FIRE

The flue draft must be .05” W.C. to allow combustion gases to flow freely out the chimney. Turn the solid fuel thermostat up to a setting well above the room temperature to start the draft fan. Use paper and dry kindling to start the fire.

Add small compact pieces of hardwood when the kindling is burning hot. Keep the draft slide plate in the ash door fully open to establish a hot fire. The ash door may be opened for start-up. However, close the ash door before opening the fire door to prevent smoke from emitting out the fire door opening.

When a substantial bed of red coals is built up start adding coal, small amounts at a time. Continue adding small amounts of coal until there is a solid bed of burning coal. Do not add too much at one time. Allow sufficient time between each small loading (at least 10 to 15 minutes) so that each loading has time to thoroughly ignite before the next load is put in. For maximum burning efficiency, always fill the furnace to the highest level possible. A deep bed of coal always will burn more satisfactorily than a shallow bed.

Keep the draft fan running until you are sure the fire is continuing to burn hot, then turn the thermostat to the desired room temperature setting. If the ash door has been opened, close it to prevent over firing, which can severely damage the furnace.

LOADING

Coal should be added to the fire at least every twelve hours. Coal never should be added unless there is a reasonably hot fire. If the fire is burning hot and there is a deep bed of coals, full loads of coal can be added at any time. However, if there is not a deep bed of coals, it is best to add small amounts of coal at first.

SHAKING

Shaking should only be done only with a hot fire.

Shaking should be done at least once a day, but not more than twice a day.

Best results from shaking will occur if short “chopping” strokes are used rather than long even strokes.

The amount of shaking is critical. Too little or too much can extinguish a fire due to blocked air flow. The proper amount normally occurs when red coals first start to drop through onto the bed of ashes. **Be sure that a small amount of ash is left on the grates to protect them from the direct heat of the burning coal. Grates must be kept level or they will warp.**

MAINTENANCE

Ashes never should be allowed to accumulate in the ash pit so they in any way impede the flow of combustion air to the fire. Excess ash accumulation can cause the fire to go out, and also can cause severe damage to the grates because they cannot cool from a flow of air beneath them. Ashes MUST be removed daily and put in a metal container with a lid.

Clinkers can occur in any coal furnace. They are pieces of fused ash that are hard. They can become large, and therefore cannot be shaken through the grates in a coal furnace. When there is an appreciable accumulation, the fire will go out because insufficient air is allowed to pass through the clinkers to the burning coal. Once clinkers have formed, they can be removed only from above the grates. This usually means the fire must be allowed to die out before they can be removed.

Clinker formation can occur from a number of different causes or a combination of causes. Some of these are as follows:

- Too hot a fire (too much draft)
- Too shallow a bed of coals
- Too deep a bed of coals
- Excess shaking
- Poking the fire from the top
- Poor quality coal – excess ash content
- Too little air (draft) after a long hot fire

SAFETY

Whenever a loading door is opened, it always should be **cracked slightly before fully opening** to allow oxygen to enter and burn any combustible gases that are present. Failure to do this could result in sudden ignition of the unburned gases when the door is opened.

A furnace never should be filled with excess coal so that the flue gas exit is in anyway blocked or impeded. Burning coal generates carbon monoxide. If the flue gas exit is blocked, the carbon monoxide can be forced out of the furnace into the room with possible fatal consequences. Never burn coal in any furnace that does not have an airtight, unified chimney system. The furnace should be used only with chimney systems that provide a strong, reliable draft. With the exception of the start up period, an ash pit door **never** should be left open.

Do not use an automatic stoker with this furnace.

MAINTENANCE

Failure to follow these instructions may result in poor efficiency, excessive corrosion of the heat exchanger and the possibility of a creosote fire.

DAILY: Furnace model with grates must have the ashes removed daily. This is to prevent warping of the grates and prevent any interruption in the combustion air flow. Ashes must be put in a metal container with a lid on it before moving the ashes to the outdoors.

MONTHLY: Furnace heat exchanger and fluepipe – Furnaces without grates must have ashes removed on a minimum of a monthly basis depending on the ash build up. The complete heat exchanger and flue pipe should be thoroughly inspected for creosote deposits, ash buildup, etc. Creosote or ash deposits must be removed by scraping and/or brushing the deposits from the heat exchanger surfaces. An industrial vacuum cleaner may be used to assist in the removal of such deposits. A complete cleaning must be done immediately at the end of each heating season. If this is not done, condensation from the summer, or any other source, will mix with the ash or creosote and cause corrosion of the heat exchanger. Corrosion is not covered under warranty.

NOTE: Establish a routine for the storage of fuel, care of the appliance, and firing techniques. Check daily for creosote buildup until experience shows how often cleaning is necessary. Be aware that the hotter the fire, the less creosote is deposited and weekly cleaning may be necessary in mild weather even though monthly cleaning may be enough in the coldest months. Have a clearly understood plan to handle a chimney fire.

Chimney: Chemical chimney cleaners are not recommended as they could damage the furnace heat exchanger and flue pipe. One of the most efficient methods to clean a chimney is to lower a stiff brush (chimney brush) tied to a heavy weight down the chimney on a rope. Work the brush up and down the chimney to scrape the accumulated creosote and soot off the chimney walls. Remove the residue from the cleanout at the base of the chimney.

SEMI-ANNUALLY: Draft Fan – oil motor with #20 non-detergent oil.

ANNUALLY: Burner Motor and Blower Motor – oil with #20 non-detergent oil. In the spring, after the furnace is shut down for the summer, clean the heat exchanger of all soot, ash and creosote accumulation, remove all ashes, clean the flue pipe and clean the chimney.

NOTICE

IMPORTANT:

- This furnace must be installed according to CSA Standard B139 "Installation Code for Oil Burning Equipment". Furnace must be installed as per Newmac clearances. Venting must be installed according to CSA Standard B365 "Installation Code for Solid Fuel Burning Appliances and Equipment".
- The solid fuel side of this furnace is designed to burn wood only, unless equipped with grates thus allowing the burning of coal. Burn anthracite coal only.
- Proper flue draft must be maintained to allow combustion gases to flow freely out the chimney.
- ONLY chimney approved for wood burning may be used, ie. ULC S629-650 C, UL 103 or masonry chimney is acceptable.

FOR SAFE OPERATION:

- Load fuel carefully or damage may result.
- Do not load solid fuel higher than the fire box liner.
- Do not use chemical or fluid fire starters.
- Do not attempt to light a fire when there is oil vapour present.
- Minimum flue draft - - .03" W.C.
- Maximum flue draft - - .05"W.C.
- Do not burn garbage, manufactured fire logs, gasoline, naptha or crankcase oil.
- Keep the furnace doors tightly closed except for refueling and cleaning.

- Maintain all door seals in good condition.
- To maintain furnace efficiency and prevent soot fires, clean the heat exchanger, flue pipes, and chimney at the end of each heating season and as frequently as required during the heating season to prevent soot accumulation. The furnace and flue must be in good condition. Turn off power to the furnace when cleaning the furnace and flue.
- Do not store fuel or combustible material within the furnace clearances.
- Do not use salt wood (driftwood gathered from the seashore).

TO PREVENT DAMAGE:

- Do not set the flue draft above -- .05" W.C. as the fire could burn out of control.
- Do not open the furnace door slide plate damper during normal operation.
- Furnaces with grates must have ashes removed daily.
- Furnaces without grates require a minimum of 2" of sand or ash in the bottom of the fire box.

SPECIAL PROCEDURES

POWER FAILURE:

- (1) Remove the blower access door and air filters for better air circulation. If the furnace is in an enclosed area (furnace room) open the door to the room.
- (2) To control the fire open the slide plate damper in the furnace door. **THIS DAMPER SHOULD BE CLOSED FOR NORMAL OPERATION.**
- (3) Do not load the fire box higher than half way up the fire box liner.

SOOT FIRE

Close all sources of air that can reach the fire through the furnace and draft regulator. Insure the draft fan above the fire door is turned off. Do not attempt to take the flue pipes down until the fire has been completely extinguished.

RUNAWAY FIRE

This can be caused by too high a flue draft or excessive fueling.

- (1) Close all sources of air to the furnace. Insure draft fan is turned off.
- (2) Set the barometric draft regulator wide open to reduce draft. The excessive heat caused by a runaway fire may damage the furnace safety controls. Their operation should be checked before the furnace is returned to service. After a soot or runaway fire inspect chimney connection and chimney.

AIR CONDITIONING

The following thin-line boxed sections are excerpts from **NFPA 90B, Standard for Installation of Warm Air Heating and Air Conditioning Systems**:

4-1.4 Air Cooling Equipment. Mechanical refrigeration used with air duct systems shall be installed in accordance with ANSI/ASHRAE 15, *Safety Code for Mechanical Refrigeration*.

4-1.5 Furnaces Used with Cooling Units.

4-1.5.1 Combination units in which a refrigeration coil is provided shall have the refrigeration coil located downstream from the heating furnace, or the coil shall be located parallel to the heating furnace.

Exception: Where the heating furnace is specifically approved for installation downstream from the coil.

4-1.5.1.1 When the heating furnace is located upstream from the coil, the coil shall be designed or equipped so as not to develop excessive temperatures and pressures. In those cases where the coil is located parallel to the heating furnace, dampers or other means to control flow of air shall be adequate to prevent chilled air from entering the furnace section. If the dampers are manually operated, means shall be provided to prevent operation of either unit unless the damper is in the full heat or cool position. Adequate means shall be provided for the disposal of condensate and to prevent dripping of condensate on the heating element.

4-1.5.2 Furnaces (including duct furnaces) may be installed downstream from the evaporative coolers or air washers provided that condensate will not fall into any portion of burners, pilots, or burner carry-over arms and provided that the heating element is made of corrosion-resistant material, such as stainless steel, ceramic-coated steel, or an aluminum coated steel in which the bond between the steel and the aluminum is an iron-aluminum alloy. Air washers operating with chilled water which delivers air below the dew point of the ambient air at the appliance are considered as refrigeration systems.

4-1.5.3 The capacity of the blower shall be adequate to overcome the external static pressure imposed by the combined heating and cooling units at the air throughput required for heating or cooling, whichever is greater.

4-3.6 Accessory Equipment. Material used in the construction of accessory equipment attached to or installed in a supply or return system shall comply with the requirements for the materials of that portion of the system to which it is attached. This shall not preclude the attachment to a plenum or duct of small devices, such as humidifiers, specifically listed for such use. Motors and electrical wiring and equipment shall comply with section 4-2.

CONVERSION OF CL115/170 C & G TO 5 TONS A/C

- ¾ HP Motor Recommended.
- 7" X ¾ Blower Pulley Recommended (Standard is 8").
- 41" Blower Belt required for 7" pulley.
- See A/C wiring diagram with Honeywell 8405A Relay (or equivalent).
- Install a By-Pass damper or blast as per sketch "Typical A/C Coil Installation".
- For CL115, 140, 155, 170, a minimum supply duct free area of 220, 220, 240, 260 sq. in. respectively, must be maintained at all times during heating the cycle.
- For CL115, 140, 155, 170, a minimum return duct free area of 250, 250, 280, 300, sq. in. respectively, must be maintained at all times during heating the cycle.
- A/C coils installed above heat exchanger should be located over oil section.
- A/C coils installed above heat exchanger should be located as high as possible and no less than 12 inches above the top of the heat exchanger.
- A/C coils must not be located on return air side.
- Ensure condensate from coil does not drip onto heat exchanger surfaces.
- Condensate drip trays must be metal.
- Ensure duct sizes are as specified in Installation, Operating and Service Manual.
- Increased air flows may require more frequent air filter maintenance.

Emerson ¾ h.p. Single Speed Belt Drive Motor: p/n 2020020

3-1/2" X 5/8" VS motor pulley: p/n 2240008.

Blower pulley, 7" X ¾": p/n 2240002.

41" Blower Belt: p/n 2240041.

Honeywell 8405A fan center transformer relay: p/n 2010015.

Honeywell 8285A fan center transformer relay: p/n 2010041.

Honeywell 8239B fan center transformer relay: p/n 2010059.

The unit must be installed in accordance with the National Warm Air Heating and Air Conditioning Association Standards or generally accepted equivalent standards. Consult appropriate provincial, state, or local codes. Regulations governing installation requirements may vary from the ones presented here

CONVERSION OF CL86 C & G TO 4 TONS A/C

- 1/2 HP Motor Recommended.
- Use existing motor pulley.
- 7" X ¾ Blower Pulley Recommended (Standard is 8").
- 39" X 1/2" Blower Belt required for 7" pulley.
- See A/C wiring diagram with Honeywell 8405A Relay (or equivalent).
- Install a By-Pass damper or blast as per sketch "Typical A/C Coil Installation".
- A minimum supply duct free area of 180 square inches must be maintained at all times during heating the cycle.
- A minimum return duct free area of 250 square inches must be maintained at all times during heating the cycle.
- A/C coils installed above heat exchanger should be located over oil section.
- A/C coils installed above heat exchanger should be located as high as possible and no less than 12 inches above the top of the heat exchanger.
- A/C coils must not be located on return air side.
- Ensure condensate from coil does not drip onto heat exchanger surfaces.
- Condensate drip trays must be metal.
- Ensure duct sizes are as specified in Installation, Operating and Service Manual.
- Increased air flows may require more frequent air filter maintenance.

Emerson 1/2 h.p. Single Speed Belt Drive Motor: p/n 2020003

Blower pulley, 7" X ¾": p/n 2240002.

39" X 1/2" Blower Belt: p/n 2240039.


Honeywell 8405A fan center transformer relay: p/n 2010015.

Honeywell 8285A fan center transformer relay: p/n 2010041.

Honeywell 8239B fan center transformer relay: p/n 2010059.

The unit must be installed in accordance with the National Warm Air Heating and Air Conditioning Association Standards or generally accepted equivalent standards. Consult appropriate provincial, state, or local codes. Regulations governing installation requirements may vary from the ones presented here

FIG. 10 - TYPICAL A/C COIL INSTALLATION



ACOIL-14072006.PRT

FIG. 11 – WIRING DIAGRAM WITH AIR CONDITIONING

NEWMAC CL SERIES WIRING DIAGRAM WITH AIR CONDITIONING




FIG. 12 - CL SERIES WIRING DIAGRAM




FIG. 13 – COMBINATION AIR FLOW




FIG. 14 - AIR CONDITIONING INSTALLATION




FIG. 15A
ELECTRODE SETTING FOR AERO AND BECKETT




FIG. 15B
ELECTRODE SETTING FOR RIELLO




FIG. 15C
BURNER INSERTION




FIG. 15D
RIELLO SLEEVE POSITION




FIG. 15E
DIMENSIONAL RELATIONSHIPS (FIG. 15A-15D)

	AERO & BECKETT	RIELLO
A	1/8"	5/32"
B	7/16"	13/64"
C	1/16"	5/64" to 7/64"
Z	1-3/8"	-
E	7 7/8"	7 1/2"

BURNER SPECIFICATIONS FOR NEWMAC FURNACES ***

Furnace Model No.	B.T.U.H. Output	Aero Oil Burner Model No.	Nozzle Oil - gph	Input Oil B.T.U.H.	Aero* Gas Burner Model No.	Gas Orifice		Input Gas B.T.U.H.	Adams** Gas Burner Model No.	Gas Orifice	
						L. P.	Nat.			L. P.	Nat.
CL 86C-86G	86,000	F-AFC-2-8	.75 (80°)R	105,000	PGB-220	#23	#7	105,000	HP 225B-PS	#33	ADJ.
CL 96C-96G	96,000	F-AFC-2-8	.85 (80°)R	119,000	PGB-220	#20	7/32"	120,000	HP 225B-PS	1/8"	ADJ.
CL 115C-115G	111,000	F-AFC-3-8	1.00 (80°)R	140,000	PGB-220	#15	15/64"	145,000	HP 225B-PS	#29	ADJ.
CL 140C-140G	140,000	F-AFC-3-8	1.25 (80°)R	175,000	PGB-220	#7	1/4"	170,000	HP 225B-PS	#25	ADJ.
CL 155C-155G	152,000	F-AFC-3-8	1.35 (80°)R	189,000	PGB-220	#5	17/64"	185,000	HP 225B-PS	#24	ADJ.
CL 170C-170G	169,000	F-AFC-3-8	1.50 (80°)R	210,000	PGB-220	#2	9/32"	200,000	HP 225B-PS	5/32"	ADJ.

- * Aero Gas Burner Model #PGB-220 must operate at 3.0" W.C. for natural gas and 3.5" W.C. for propane gas.
- ** Adams Gas Burner Model #HP 2258-PS must operate at 3.5" W.C. for natural gas and 11.0" W.C. for propane gas. LP burners are designated by "LP". Example HP 2258-LP-PS.
- *** Newmac furnaces are not certified in Canada with gas burners installed. Check with local authorities and obtain their approval before installing a power gas burner. Refer to gas burner manual for proper installation and service.

GAS BURNER INSTALLATION

GAS PIPING

All piping must comply with local codes and ordinances. Refer to the gas burner manual for further recommendations.

BURNER MOUNTING

Install burner on the burner mounting plate with blast tube flush with the outside wall of the combustion chamber. Connect the gas line to the burner by means of a union.

WIRING OF BURNER

Connect wiring according to Fig. 16-1A for the Adams burner and Fig. 16-1B for the Aero burner.

FIG. 16-1A
WIRING DIAGRAM FOR INSTALLATION
OF ADAMS GAS BURNER






FIG. 16-1B
WIRING DIAGRAM FOR INSTALLATION
OF AERO GAS BURNER



STARTING GAS BURNER

1. Be sure cock on combination valve is in "OFF" position for 5 minutes.
2. Open gas cock on combination valve to "ON" position.
3. Turn to electric switch.
4. Set room thermostat above room temperature.
5. Burner will light.
6. Set room thermostat to temperature desired.

**FIG. 16-1C – ADAMS GAS BURNER EXPLODED ASSLY-
HP225 BPS**



**FIG. 16-1D ADAMS GAS BURNER PARTS LIST
HP225 BPS**

Ref.	DESCRIPTION	HP-225 BPS
1	Top Housing	7582-GN
2	Thermocouple	-----
2	Sensor Probe	12003
3	Pilot Burner	J 124 DDA
4	Pilot Orifice (Nat.)	5221 (.021)
4	Pilot Orifice (Prop.)	3215 (.015)
5	Ignition System	EPI-100 or EPI
6	Transformer (20 V.A.)	AT 20 A
7	Relay	R 8222 A 1002
8	Terminal Block	7586-3
9	Air Door	7582 A
10	Bottom Access Door	7587 B
11	Slide Tray Assembly	7586 D
12	Manifold	7015 D-6
13	Pedestal (Not Shown)	7584
14	Burner Casting	7583-1
15	Insulating Boot	846
16	Pilot Shield	12005
17	Electrode (3 inch)	7583-5A
18	Combination Valve (Nat.)	SX 242 NS
18	Combination Valve (Prop.)	SX 242 LS
19	Pipe Nipple	50001-6-3 1/2
20	Main Orifice (Specify Size)	172
21	Adjustable Orifice Assembly	6481
22	Bottom Housing Assembly	7581 B
23	Mounting Flange (Optional)	7585
24	Motor/Blower Assembly	7586-2A
25	APR Module (Optional)	-----
26	Extension Sleeve (Not Shown)	7581-1A-BL
27	Ignition Wire (30 inch)	7803
28	Sensor Wire (30 inch)	7852-2




FIG. 16-1E
AERO PGB 220-370 GAS BURNER EXPLODED ASSLY





FIG. 16-1F
AERO PGB 220-370 GAS BURNER PARTS LIST

ITEM #	PART NAME & DESCRIPTION	AERO #
1	F Housing	9035222400
2	Airtube (5"-8"-11')	
3	Mounting Flange (Standard)	2735161000
4	Micro Switch (V3101-D8)	9035061441
5	Sail & Leaf (JV-26)	2735121091
6	"J" Box	2735121091
7	"J" Box Hardware	2735121091
8	Motor (1/7/3450/60/1)	2735251414
9	Fan 524-202 (PGB 220)	2735151200
9a	Fan 524-316 (PGB 370)	2735152016
10	Raceway	2726202550
11	Air Band Assembly	2726200100
12	Ignition Control	9035061311
13	Wiring Harness (not shown)	9035061321
14	High Voltage Cable	9035061301
15	Fan Center	9035061210
16	Fuse Assembly	9026121400
17	Manifold Assembly - 1/2" PGB 220	
17a	Manifold Assembly - 3/4" PGB 370	
18	Electrode Assembly (S.S.B.)	9026121300
19	Centering Bolt	9035202205
20	Orifice (Input Required)	7235515220
21,22,23	Replaced by Gas Valves	
24	Combination Gas Valve (220)	9035061225
24a	Combination Gas Valve (370)	9035061227
24b	Comb. Propane Valve (220/370)	9035061226
	Adjustable Flange	2735162000
	Base assembly	2735032000
	Carton - complete	9035401000

FIG. 16-1G – THERMO-DISC MOUNTING ON BURNER PLATE



Note: Limit is located on centre line of burner plate
& in line with plate mounting screws as shown

FIG. 16-2A - AERO BURNER EXPLODED ASSEMBLY




FIG. 16-2B - PARTS LIST
Model F-AFC AERO OIL BURNER

ITEM #	DESCRIPTION	AERO PART #	NEWMAC PART #
1	F housing	2735222100	
2	Blast Tube 8"		2090006
3	Mounting flange - Standard	2735161000	
4	Air band assembly	2726200100	
5	Motor 1/6 HP, 1725 RPM	2735251415	2020010
6	Fan, 524-316	2735152016	
7	Flexible metal-end coupling	2433804813	
8	Fuel Pump A1VA-7112 Suntec	2735171201	
9	Transformer, Ignitor 2275-456	2735382730	2090066
	Transformer, Iron Core 2721-456	2735382740	2090002
	Transformer, 421-456		
10	End Cone:		
	AFC-2	2735141200	2110002
	AFC-3	2735141300	2110003
11	Nozzle Adapter	2735261100	
	Oil pipe, aluminum (specify blast tube length)		
12	Electrode Holder	2725131100	
13	Electrode (with porcelains)	2725132100	2090004
14	Electrode (with porcelains)	2725132100	2090004

ITEM #	DESCRIPTION	AERO PART #	NEWMAC PART #
14A	Bus bars (specify length)		
15	Turbo static disc F-AFC, 3"	2725353000	
16	Jam hex nut	9935193401	
17	Knurled lock nut		
100	Complete electrode assly (11 to 17)		2090001
18	AFC end cone screws	9935203901	2090020
19	Blast tube screw (specify length)	9935202202	
20	Raceway	2726202250	
21	Motor screws	9935203202	
22	Raceway screw	9935203901	
23	Transformer lock down screw	9935203201	
24	Transformer hinge screws	9935203901	
25	Slide plate	2726200400	
26	Slide plate pop rivet	9935203901	
27	Air band locking screw	9935203202	
27	Air band locking nut	9935193201	
28	Oil line assembly	2726202800	
29	Compression elbow, 90 degree		
30	Fuel pump screws	9935203202	
33	Oil burner mounting gasket, 1/8" - (not shown)	2735182400	

When ordering parts, always give: (1) Model, (2) Part Name, (3) Part Number, (4) Size and (5) Quantity Required.

FIG. 16-3A - BECKETT BURNER EXPLODED ASSEMBLY





FIG. 16-3B - BECKETT BURNER PARTS LIST

ITEM NO.	PART NUMBER		NM50 2	NM50 3	DESCRIPTION
	BECKETT	NEWMAC			
1	5877	2090024	X	X	Burner Housing Assembly
2	3709		X	X	Air Shutter
3	3492		X	X	Air Band
4	3493		X	X	Escutcheon Plate
8	21844U	2060012	X	X	Pump Clean Cut A2EA - 6520
	51843U		X	X	Strainer & Gasket
10	21755U	2090065	X	X	Valve Coil (Suntec Part No. 3713824)
7	21877U	2090072	X	X	Valve Stem
	51573	2090058			Suntec Pump c/w Solenoid Valve
	51843U				Strainer & Gasket
	21755U				Valve Coil (Suntec Part No. 3713824)
					Valve Stem (Includes 2 O Rings) (Suntec Part No. 3773578)
					Solenoid Valve Repair Kit (Suntec Part No. 991375)
9	21807		X	X	Valve cordset
11	2256				Pump Nozzle Port Fitting
12	5394				Connector Tube Assembly
13	21805U	2020012	X	X	PSC Drive Motor, 3450 RPM
14	2999U	2090056	X	X	Blower Wheel
16A	7456U	2090069	X	X	Primary Relay, Honeywell R7184B
16B	7457U	2090067			Primary Relay, Honeywell R7184P
17	5770		X	X	Junction Box Kit
18	51771U	2090064	X	X	Electronic Ignitor (14,000 Volt)
20	7006U	2010006	X	X	Cad Cell C554A1455B Honeywell
21	3384		X	X	3-3/8U Static Plate
22	5153633BK	2090039	X	X	Blast Tube c/w Welded Flange AFG (7 7/8")
		2110007	X		Endcone, F4
		2110009		X	Endcone, F6
24		2090022	X	X	Electrode Assembly 8"
	31517	2110015	X	X	Ceramic Heat Shield
		2110016	X	X	Ceramic Heat Shield Holder
	3416	2080051	X	X	Flange Gasket
	51770	2090061			Field Controls AirBoot
	5880	2090044	X	X	Low Firing Rate Baffle
	5941		X	X	Adjusting Plate Assy
		2100131	X		Nozzle, Delavan 0.75 X 70°A
		2100128	X		Nozzle, Delavan 0.85 X 70°A
		2100132	X	X	Nozzle, Delavan 1.00 X 70°A
		2100129		X	Nozzle, Delavan 1.25 X 70°A
		2100133		X	Nozzle, Delavan 1.35 X 70°A
		2100134		X	Nozzle, Delavan 1.50 X 70°A

Note: Also approved with SR Burner – See General Instructions & Certification Label

FIG. 16-4A - RIELLO F3 & F5 EXPLODED ASSEMBLY



See FIG. 15D for location of Riello End Cone Protector (No. 49)

FIG. 16-4B - RIELLO BURNER PARTS LIST

ITEM F3 & F5	PART NUMBER		BURNER MODEL		DESCRIPTION
	RIELLO	NEWMAC	F3	F5	
10	C7010002	2090043	X	X	O-ring - pump cover
20	3002279		X	X	Solenoid Coil
21	3007802	2060007	X	X	Pump
23	3005843		X	X	Motor
25	3002280	2010045	X	X	Photo cell
26	C7001029	2010048	X	X	Primary control 530 SE/C
28	3005855		X	X	Universal mounting flange
29	3005856	2080058	X	X	Mounting gasket
33	3007204		X	X	Manual Air Shutter
35	3005844	2090041	X	X	Capacitor 12.5 Uf
36	3005708		X	X	Fan
40	C3948874	2090051	X		Blast Tube Assembly
	C3948974	2090046		X	Blast Tube Assembly
49	C7001033	2030016	X	X	Blast Tube Protector
	3007568		X	X	Bleeder
	3006925		X	X	Valve Stem
	C7001013		X	X	Parts Bag
		2010034	X	X	24V Relay, Switching (for Riello)

FIG. 17-1A - CL115-170C WOOD/OIL COMBINATION FURNACE ASSEMBLY




FIG. 17-1B - PARTS LIST – CL115-170C

ITEM NO	PART NO	DESCRIPTION
1	4120202	Blower Section Side Panel
2	4120312	Fan Partition Panel
3	4120305	Blower Section Small Panel
4	2040001	50 CFM Draft Fan
5	5300012	Slide Plate Assembly
6	2180003	Filter 20" X 25" X 1"
7	5300007	Firedoor Gasket Set
8	5300009	Firedoor Handle Complete
9	5300002	Firedoor Set Complete
10	2240003	Blower Pulley 8" X ¾"
11	2040104	10" Air Circulating Twin Blower
12	4120322	Blower Section Access Panel
13	4120402	Blower Section Base Panel
14	4120409	Furnace Section Base Panel
15	2030001	Corbel Combustion Chamber

ITEM NO	PART NO	DESCRIPTION
16	5110003	Straight Brick 2 ½" X 4 ½" X 9" (Box of 10)
17	5400047	Aero Burner
17	2110128	Beckett Burner
18	4060101	Brick Loc
19	4060114	Firedoor Air Chute
20	2080009	Front Gasket
21	4120116	Furnace Section Front Panel
22	4120213	Furnace Section Side Panel
23	4120103	Furnace Section Back Panel
24	4060134	Heat Exchanger

FIG. 17-2A - CL86-96C WOOD/OIL COMBINATION FURNACE ASSEMBLY




FIG. 17-2B - PARTS LIST – CL86-96C

ITEM NO	PART NO	DESCRIPTION
1	4120203	Blower Section Side Panel
2	4120314	Fan Partition Panel
3	4120315	Blower Section Small Panel
4	2040001	50 CFM Draft Fan
5	5300012	Slide Plate Assembly
6	2180002	Filter 16" X 25" X 1"
7	5300005	Firedoor Gasket Set
8	5300009	Firedoor Handle Complete
9	5300001	Firedoor Set Complete
10	2240003	Blower Pulley 8" X ¾"
11	2040105	9" Air Circulating Twin Blower
12	4120323	Blower Section Access Panel
13	4120403	Blower Section Base Panel
14	4120414	Furnace Section Base Panel
15	2030004	Corbel Combustion Chamber

ITEM NO	PART NO	DESCRIPTION
16	5110003	Straight Brick 2 ½" X 4 ½" X 9" (Box of 10)
17	5400048	Aero Burner
17	2110126	Beckett Burner
18	4060106	Brick Loc
19	4060171	Firedoor Air Chute
20	5110006	Split Brick 1 ¼" X 4 ½" X 9" (Box of 6)
21	2080001	Front Gasket
22	4120120	Furnace Section Front Panel
23	4120218	Furnace Section Side Panel
24	4120104	Furnace Section Back Panel
25	4060143	Heat Exchanger

FIG. 17-3A - CL115-170G WOOD/OIL COMBINATION FURNACE ASSEMBLY




FIG. 17-3B - PARTS LIST – CL115-170G

ITEM NO	PART NO	DESCRIPTION
1	4120202	Blower Section Side Panel
2	4120305	Blower Section Small Panel
3	4120312	Fan Partition Panel
4	2040002	100 CFM Draft Fan
5	5300012	Slide Plate Assembly
6	2180003	Filter 20" X 25" X 1"
7	5300003	Firedoor/Ashdoor Set Complete
8	5300007	Firedoor Gasket Set Complete
9	4120322	Blower Section Access Panel
10	2040104	10" Air Circulating Twin Blower
11	2240003	Blower Pulley 8" X ¾"
12	4120402	Blower Section Base Panel
13	5300009	Firedoor Handle Complete
14	4120409	Furnace Section Base Panel
15	5300008	Ashdoor Gasket Set Complete

ITEM NO	PART NO	DESCRIPTION
16	2170007	Cast Grate
17	5400047	Aero Burner
17	2110128	Beckett Burner
18	4060116	Firedoor Air Chute
19	2170009	Cast Liner
20	2030001	Corbel Combustion Chamber
21	2080020	Front Gasket
22	4120117	Furnace Section Front Panel
23	4120213	Furnace Section Side Panel
24	4120103	Furnace Section Back Panel
25	4060138	Heat Exchanger
	4060128	Ash Pan
	3090183	Grate Plate

FIG. 17-4A - CL86-96G WOOD/OIL COMBINATION FURNACE ASSEMBLY




FIG. 17-4B - PARTS LIST – CL86-96G

ITEM NO	PART NO	DESCRIPTION	ITEM NO	PART NO	DESCRIPTION
1	4120203	Blower Section Side Panel	16	2170007	Cast Grate
2	4120315	Blower Section Small Panel	17	5400048	Aero Burner
3	4120314	Fan Partition Panel	17	2110126	Beckett Burner
4	2040001	50 CFM Draft Fan	18	4060118	Firedoor Air Chute
5	5300012	Slide Plate Assembly	19	5110006	Split Brick 1 ¼" X 4 ½" X 9" (Box of 6)
6	2180002	Filter 16" X 25" X 1"	20	2030004	Corbel Combustion Chamber
7	5300004	Firedoor/Ashdoor Set Complete	21	4060106	Brick Loc
8	5300005	Firedoor Gasket Set Complete	22	2080016	Front Gasket
9	4120323	Blower Section Access Panel	23	4120119	Furnace Section Front Panel
10	2040105	9" Air Circulating Twin Blower	24	4120218	Furnace Section Side Panel
11	2240003	Blower Pulley 8" X ¾"	25	4120104	Furnace Section Back Panel
12	4120403	Blower Section Base Panel	26	4060142	Heat Exchanger
13	5300009	Firedoor Handle Complete		4060127	Ash Pan
14	4120414	Furnace Section Base Panel		5110003	Straight Brick 2 ½" X 4 ½" X 9" (Box of 10)
15	5300006	Ashdoor Gasket Set Complete		3090182	Grate Plate

FIG. 18 - REPLACEMENT PARTS

Description	CL86-96C	CL86-96G	CL115-170C	CL115-170G	Newmac Part Number
Delhi Twin G9 Blower	X	X			2040105
Delhi Twin G10 Blower			X	X	2040104
Torin Twin BC916-916-1	X	X			**Replacement Shaft & Bearings Available
Torin Twin BC1020-1020-1			X	X	**Replacement Shaft & Bearings Available
Honeywell R8405C Transformer/Relay (Obsolete)					
Honeywell R8225B1007B Relay	X	X	X	X	2010020
Honeywell L4064R Fan & Limit (8" Insertion)	X	X			2010017
Honeywell L4064R Fan & Limit (8" Insertion)			X	X	2010019
Honeywell Thermostat T822D2063	X	X	X	X	
White Rodgers 8A05A-4 Transformer/Relay	X	X	X	X	2010050
White Rodgers Thermostat 1E30W-451S1	X	X	X	X	2010008
Emerson 1/3 HP Motor	X	X	X	X	2020002
GE 1/3 HP Motor	X	X	X	X	2020002
AO Smith 1/3 HP Motor	X	X	X	X	2020002
Airdex 50 CFM Draft Fan (7017011)	X	X	X		2040001
Airdex 100 CFM Draft Fan (7817001)				X	2040002
Fasco 50 CFM Draft Fan (7073-0655)					
Fasco 100 CFM Draft Fan (7021-1001-4)					
Ontor Field Draft Regulator B34C07GA	X	X	X	X	2040022

PREPARATION OF WOOD

Once I have my wood at home, how do I prepare it for burning?

The wood must be cut to length to suit the firebox of the stove, furnace, or fireplace in which it is to be burned. An 8' log may be cut into four, six or eight pieces, depending on the desired length. Splitting the wood greatly facilitates drying and reduces the wood to a more manageable size.

How much moisture is contained in wood?

Many softwoods have a moisture content in the vicinity of 55 percent when they are freshly cut. The popular hardwoods have moisture contents of about 45 percent. Air dried wood has a moisture content of about 15 percent and kiln dried wood may have a moisture content of less than 10 percent when it is fresh from the kiln.

What causes wood to rot?

When wood is cut, it is very susceptible to the growth of fungi, which converts the wood to water, carbon dioxide, and heat, just as does a fire. This rotting decreases the wood's energy. The fungi are most productive when three conditions are met: the temperature is between 60° F and 90° F, the wood's moisture content is above 30 percent, and ample oxygen is available. Thus, wood does not rot appreciably when it is dry, in the winter, or when it is submerged in the water, but it should not be allowed to lie on the ground during the summer.

How can rotting be prevented?

When the wood has been cut into stovewood lengths, and split, it should be piled outside during the months of June, July, and August. Two poles should be placed on the ground to serve as rails to keep the firewood off the moist ground and the wood should be piled up in such a way that it is well exposed to the sun and the wind. The moisture content of the wood will drop until it reaches equilibrium with the ambient weather conditions. When the relative humidity is 60 percent, the equilibrium moisture content is about 11 percent. When the wood has reached this equilibrium moisture content, it is said to be "air dried." Around mid August, it should be placed under cover so that it will not reabsorb moisture from the rain and snow before it is used.

Why this concern about allowing the wood to dry?

Green or wet wood is undesirable for several reasons. Green or wet wood tends to mildew and rot which causes a significant reduction in the thermal value. When green or wet wood is burned, it may take 20 to 25 percent of the thermal value of the wood heat to evaporate and drive off the moisture which is contained. Green wood does not burn easily and, in order to keep the fire burning, it is often necessary to add a lot of fuel and provide excessive draft, thereby decreasing the efficiency of the unit. The excess air needed for combustion must be heated and it escapes up the chimney wasting heat that should be used to heat the house.

What is creosote?

Wood smoke almost always contains some unburned gases and a fog of unburned tar-like liquids. Some of these materials will condense on the inside of the chimney, just as steam condenses on any cold surface. This condensation is a black, tacky, fluid when first formed. When it dries, it is flaky and shiny. Creosote has approximately the same thermal value as fuel oil. Not only does it reduce the effective size of the chimney, but an accumulation of this material constitutes a serious fire hazard.

Does green wood cause creosote?

Yes. Indirectly, green wood does cause creosote. The exhaust gases cool as they rise up the chimney. If the temperature falls below the dew point, any moisture contained in these gases will condense on the inside of the chimney, absorb the various products of incomplete combustion and form creosote. When green wood is burned, the exhaust gases carry a high moisture content in addition, because of the heat required for evaporation, these gases are cooler and more likely to condense than would be the case with dry wood.

Charcoal may be formed more readily if the unit is overcharge particularly, in milder weather. With overcharging (too much wood in unit) the draft fan will be off a greater percentage of time, coals will be formed which will become covered with ash in turn will smother the coals to form charcoal. Any coals in the furnace should be stirred before more wood is added to it.

The preceding is an excerpt from a document prepared by the Nova Scotia Energy Council and the Nova Scotia Research Foundation Corporation.

CREOSOTE AND CHIMNEY FIRES

Wood combustion is never perfectly complete. Wood smoke almost always contains some unburned gases and a fog of unburned tar-like liquids. Some of these materials will condense out of the flue gases onto any surface which is not too hot. The condensation is usually dark brown or black, and has an unpleasant acrid odor. It is called creosote. If condensed on a relatively cool surface (such as an exterior stovepipe chimney), the creosote will contain a large amount of water along with the organic compounds, and will thus be very fluid. Water is usually absent if the condensation occurs on surfaces hotter than 150°F. The condensation may then be thick and sticky, like tacky paint or tar. Creosote may be found almost anywhere in a wood-heating system, from the top of the chimney to the insides of the cover itself.

Creosote which remains in a chimney after its initial formation may later be significantly modified both in physical form and chemical content. The water and the more volatile organic compounds tend to evaporate, leaving the more tar-like substances behind. If these are subsequently heated by the flue gases from a hotter fire (this usually happens), they themselves are further pyrolyzed to the same final solid product that wood is carbon. The physical form is usually flaky, and often shiny on one side. Partially pyrolyzed deposits can have a bubbly appearance. The flakes do not adhere strongly to a stove pipe and thus are easy to brush off; some of the other forms will not budge even under the action of a stiff wire brush.

The amount of creosote deposited depends mostly on two factors – the density of the smoke and fumes from the fire, and the temperature of the surface on which it is condensing. Highest smoke densities occur when a large amount of wood in relatively small pieces is added to a hot bed of coals and the air inlet damper is closed. Here, there is considerable pyrolysis of wood, but little combustion, and little air to dilute the smoke. In practice, creosote generation is higher during low-power, overnight, smoldering burns. Smoke densities are least when combustion is relatively complete, which tends to be the case when the amount of excess air admitted to the wood-burner is high. Leaky stoves, open stoves and fireplaces typically have the least creosote problems.

One way to lower the average smoke density in an airtight stove is to use less wood each time fuel is added, and/or to use larger pieces of wood. In either case, the air supply need not be turned down so much in order to limit the heat output and combustion is likely to be more complete. Of course, if less wood is added, stoking must be more frequent. A related procedure to limit creosote is to leave the air inlet moderately open after adding wood until the wood is mostly reduced to charcoal, and then close the inlet as much as desired. This will promote complete combustion during pyrolysis, when the creosote compounds are being formed, but there will be a significant heat surge while the gases are burning.

Extra air can also be added to the flue gases in the stove pipe; this is what the Ashley creosote inhibitor does. But the net effect of adding dilution air is not obvious or necessarily beneficial. Dilution air will decrease the smoke density, but it will also decrease its temperature. These effects have opposing influences on creosote formation. The National Fire Prevention Association states that dilution air increases chimney deposits. In any case, the cooling effect of dilution air does decrease the heat transfer through the stovepipe and chimney, thus decreasing the system's energy efficiency.

Creosote formation may also depend on the type of wood burned and on its moisture content. Dry hardwoods have a reputation for generating the least creosote, but the quantity can still be very large. No kind of wood eliminates creosote formation.

For a given smoke density near a surface, the cooler the surface, the more creosote will condense on it. The phenomenon is very similar to water vapor condensing on the outside of a glass of ice water on a humid day, except for an inversion – condensation occurs on the inside of a chimney, especially when cold air outside makes the inner chimney surface relatively cool. A stovepipe chimney outside a house on a cold day will be wet on the inside with creosote (including a lot of water) virtually all the time. A well insulated, pre-fabricated metal chimney has the least serious creosote problems; its insulation helps maintain higher temperatures on its inner surface, and its low heat capacity allows it to warm up very quickly after a fire is started. Masonry chimneys frequently accumulate deposits at the beginnings of fires and their interior surfaces take a longer time to warm because the construction is so massive. Any type of chimney which runs up the outside of a house is more susceptible to creosote problems than the same type of chimney rising in the houses' interior, due to the cooling effect of the colder outdoor air on the exterior chimney.

Average flue gas temperatures can be increased by minimizing the length of stovepipe connecting the stove to the chimney. This, of course, will also decrease the energy efficiency of the system, and it is often true that measures which decrease creosote formation also decrease heating efficiency. For instance, stoves which have energy efficiencies due to their relatively good heat transfer (e.g. the Sevca, range 6303 and double barrel stoves) are more likely to have chimney creosote problems precisely because they do such a good job extracting heat from the flue gases.

Generally creosote is inevitable and must be lived with. Any kind of chimney deposit decreases the system's heating efficiency. Soot and dried creosote accumulations have a significant insulating effect; less of the heat in the flue gases transferred into a house through dirty stovepipes and chimneys. The most annoying problem can be creosote dripping from a stovepipe or chimney, and the most dangerous problem is chimney fires, during which the creosote, or its pyrolyzed residue, burns.

Creosote dripping can usually be eliminated. Joints in vertical segments of stovepipe will not leak if, at the joints, the smaller, crimped ends always stick down into the receiving end. (Smoke will not leak out of the joints due to this direction of overlay.) Since this is not the usual orientation for stovepipe, a double male fitting may be necessary at some point to connect the stovepipe to the stove, a prefabricated chimney, or a rain cap. Special drip proof adapters are available for connecting some sizes of stovepipe to Metalbestos brand prefabricated chimneys. Common types of stovepipe elbows can leak creosote due to their swivel joints; rigid and accordion type leak proof elbows are available. Horizontal or gently sloping joints between horizontal pipes and/or fillings are the most difficult to seal against dripping. A good high temperature sealant can sometimes help, but is no guarantee. The joint must also be snug, and well secured with sheet metal screws. If all joints are made leak proof, then the creosote will generally drip into the stove, where, when the fire is hot, it will be burned.

Chimney fires occur when the combustible deposits on the inside of a chimney burn. The deposits may be 'raw' creosote, pyrolyzed creosote, or soot. Ignition requires adequate oxygen, which is usually available, and sufficiently high temperatures - the same conditions as for the ignition and combustion of any fuel. Chimney fires are most likely to occur during a very hot fire, as when cardboard or Christmas tree branches are burned, or even when a stove burns normal wood, but at a higher than normal rate. A crackling sound can often be heard at the beginning of a chimney fire. As the intensity of the fire rises, the stovepipe will sometimes shake violently, air will be very forcefully drawn in through the stove, and the stovepipe may glow red hot. A tall plume of flame and sparks can be seen rising from the top of uncapped chimneys.

The most effective way to suppress a chimney fire is to limit its air supply although both water and salt are sometimes suggested if a relatively airtight stove is the connected appliance. This is easily done by closing the stove's air-inlet dampers, if all the stovepipe and/or chimney joints are tight, and if no other appliance is connected to the same flue.

In a properly designed and maintained chimney, the only potential hazard related to chimney fires is ignition of the building's roof or surroundings due to sparks and burning embers coming out of the top of the chimney. A spark arresting screen can decrease, but not eliminate this possibility, but spark screens themselves are often not suitable for use with wood fuel because they can become clogged. The chimney itself and the stovepipe, when properly installed, are intended to withstand an occasional chimney fire without danger of ignition of their surroundings. During a chimney fire, one ought to check the roof and surroundings, and possibly wet down critical areas. If the chimney may not be up to safety standards, one should also keep a close watch on all surfaces near the chimney.

Some people start chimney fires fairly frequently, as a means of chimney cleaning. This deters very intense chimney fires and the small ones which do happen are always under a watchful eye. Under some circumstances, this practice may be reasonable, but generally it is a risky method to keep a chimney clean. There is always some danger of a house fire, but in addition, any chimney fire is wearing on a chimney; the high temperatures increase the corrosion rate of metals and the thermal expansion of masonry materials encourage crack formation and growth.

Chemical chimney cleaners are available. Opinions on their effectiveness vary, but apparently when used regularly, and as directed, they work, and do not damage chimneys. The usual chimney cleaning method is the oldest human energy and some kind of mechanical tool. A stiff wire brush, a heavy chain (perhaps in a bag) hung with a rope and worked up and down from the top of the chimney, and very small brushes have all been used. Professional chimney sweeps are also reappearing.

Some people clean yearly, other after every few cords of wood burned, but there are so many factors influencing creosote build up that such generalizations are not appropriate in most particular cases. In new installations, or when changes occur (such as

a different stove) the chimney should be checked frequently (after 2 weeks, then after a month, then after another 2 months, etc.) until it is clear how frequently cleaning is usually needed.

The preceding is an excerpt from “THE WOODBURNERS ENCYCLOPEDIA” published by Vermont Crossroads Press, Inc. – Dec., 1976.

WOOD IS A SAFE CLEAN AND ECONOMICAL FUEL

Species	Approx. Wt. Per Cord	BTU Per Air Dried Cord	Equivalent Value #2 Heating Oil Litre	Cost at 70.0 cents	Cost at 75.0 cents	Cost at 80.0 cents
Hickory	3595	30,600,000	827.4	\$579.18	\$620.55	\$661.92
Hard Maple	3075	29,000,000	784.6	\$549.22	\$588.45	\$627.68
Beech	3240	27,800,000	752.4	\$526.68	\$564.30	\$601.92
Red Oak	3240	27,300,000	738.7	\$517.09	\$554.03	\$590.96
Yellow Birch	3000	26,200,000	709.2	\$496.44	\$531.90	\$567.36
Elm	2750	24,500,000	662.8	\$463.96	\$497.10	\$530.24
Soft Maple	2500	24,000,000	649.2	\$454.44	\$486.90	\$519.36
Tamarack	2500	24,000,000	649.2	\$454.44	\$486.90	\$519.36
Cherry	2550	23,500,000	635.5	\$444.85	\$476.63	\$508.40
Ash	2950	22,600,000	611.4	\$427.98	\$458.55	\$489.12
Spruce	2100	18,100,000	490.1	\$343.07	\$367.58	\$392.08
Hemlock	2100	17,900,000	484.1	\$338.87	\$363.08	\$387.28
Aspen	1900	17,700,000	483.2	\$338.24	\$362.40	\$386.56
White Pine	1800	17,700,000	462.8	\$323.96	\$347.10	\$370.24
Basswood	1900	17,000,000	459.6	\$321.72	\$344.70	\$367.68

Note: To change litres to US gal. multiply by 0.264

For the least amount of wood handling, the wood with the highest heat content is most desirable.

An open fireplace can actually refrigerate a house because it sucks in so much cold air, which is only partially used for combustion. A carefully designed fireplace makes use of perhaps 10 – 15 % of the heat available; most still going up the flue. The well-constructed potbellies get perhaps 20 – 25 % and the automatic, draft regulated, tightly sealed wood heaters get perhaps 50 %.

Notice that the percentage efficiency goes up as the combustion process becomes more and more controlled. The roaring fire is a complete waste of fuel. The best situation is one where the combustion chamber is gas-tight. This allows a controlled fire that toasts the wood and puts the right quantity of wood gas in the right place and at the right temperature for optimal combustion and heat transfer.

The NEWMAC COMBINATION OIL AND WOOD FURNACE toasts the wood to charcoal and the charcoal and the charcoal burns to dust leaving a minute amount of residue. From the above heat values, it can be seen that a cord of Hickory wood is equivalent to \$ 248.22 (@ 30.0 cents litre) worth of oil, over twice as much as you would pay for a cord of wood.

Without taking into account all the free wood that is available, EFFICIENT WOOD HEATING cuts your heating costs in half.

MAINTENANCE AND OPERATING BULLETIN

Regarding Multifuel and Solid Fuel Burning Heating Units

The following are some suggestions with reference to the above:

1. MAINTENANCE:

In addition to periodic cleaning, it is most important that the unit be cleaned thoroughly at the end of each heating season. Both the primary and the secondary heat exchangers should be given extra attention with a steel scraper or brush. This will help to prevent rust and corrosion during the high humidity summer months. Also, if the firedoor is left open, it will allow for air to circulate through the units.

2. OPERATION

- a) When burning with wood, the minimum setting for the manual draft slide should be in the center. (This is the slide knob beside the combustion fan above the firedoor). The closed position is for when burning with oil for a prolonged period (to obtain maximum efficiency) and the open setting is for initially starting a wood fire.
- b) Do not attempt to burn the solid fuel in the spring or fall when temperatures are mild. This will cause the unit to be shut down for extended periods at a time and will form creosote and soot.
- c) In the Multifuel units – two or three times a week, burn the oil fuel for an hour or so. This will help to keep the unit clean of creosote build up.
- d) In the Solid Fuel units – burn the fuel at maximum draft with good dry wood for an hour or so (once or twice a week). This will help to prevent creosote build up.
- e) During the off season, in order to dry out the humidity in the unit, fire the furnace once a month for at least 30 minutes.
The multifuel unit – use the oil side.
The solid fuel furnace – build a fire with dry wood.

The above details, if adhered to, will extend the longevity of your furnace and provide many years of warm, comfortable heat.

IMPORTANT HOMEOWNER INSTRUCTIONS

1. AN EMERGENCY POWER SWITCH IS REQUIRED TO BE INSTALLED IN A CONVENIENT LOCATION AT A SAFE DISTANCE FROM THE BURNER. THIS SWITCH INTERRUPTS THE ELECTRICAL SUPPLY CIRCUIT TO THE APPLIANCE. MAKE SURE YOU ARE AWARE OF ITS LOCATION AND THE OFF POSITION IS CLEARLY MARKED.
2. KEEP THE SPACE CLEAR AROUND THE APPLIANCE WITHIN THE SPECIFIED CLEARANCES TO COMBUSTIBLES.
3. ENSURE THE SUPPLY OF COMBUSTION AIR TO THE APPLIANCE IS NOT OBSTRUCTED OR CUT-OFF.
4. MAINTAIN PROPER VENTILATION OF THE APPLIANCE AREA.
5. MAINTAIN FREE AIR FLOW THROUGH THE RETURN AIR REGISTERS. *
6. CONTACT SERVICE PERSONNEL BEFORE REMODELLING.
7. CONTACT SERVICE PERSONNEL FOR ANNUAL SERVICE AND MAINTENANCE.
8. CONTACT SERVICE PERSONNEL FOR AIR FILTER REPLACEMENT. *
9. CONTACT SERVICE PERSONNEL BEFORE AND AFTER EXTENDED PERIODS OF APPLIANCE INOPERATION.
10. THE BURNER IS FULLY AUTOMATIC IN OPERATION. ALL ADJUSTMENTS SHOULD BE MADE BY A QUALIFIED TECHNICIAN. DO NOT PUSH THE RESET BUTTON MORE THAN ONCE.

CAUTION : DO NOT ATTEMPT TO START THE BURNER WHEN EXCESS OIL HAS ACCUMULATED, WHEN THE APPLIANCE IS FULL OF VAPOUR, OR WHEN THE COMBUSTION CHAMBER IS VERY HOT.

11. **CAUTION : DO NOT TAMPER WITH THE APPLIANCE OR CONTROLS—CALL YOUR SERVICE PERSONNEL.**
12. **DO NOT USE GASOLINE, CRANKCASE OIL, OR ANY OIL CONTAINING GASOLINE**
13. ALWAYS KEEP THE OIL SUPPLY VALVE SHUT OFF IF THE BURNER IS SHUT DOWN FOR AN EXTENDED PERIOD OF TIME.
14. DO NOT START THE BURNER UNLESS THE BLOWER ACCESS DOOR IS SECURED IN PLACE.
15. NEVER BURN GARBAGE OR PAPER IN THE HEATING SYSTEM, AND NEVER LEAVE PAPER OR RAGS AROUND THE APPLIANCE.

* FURNACES ONLY

INSTALLER INFORMATION

NAME : _____ **COMPANY** _____

The homeowner should telephone (____) _____ for a service call or for additional information.

APPLIANCE INITIAL TEST AND SERVICE INFORMATION

MODEL : _____ **INSTALLATION DATE :** _____

		DATE		
1	FUEL INPUT (GPH)			
2	FUEL PRESSURE (PSIG)			
3	DRAFT @ BREECH			
4	DRAFT @ OVERFIRE			
5	NOZZLE ANGLE/PATTERN			
6	CO ₂ PERCENT			
7	BURNER MODEL			
8	FLUE GAS TEMP °F			
9	ROOM TEMP °F			
10	SMOKE DENSITY N°.			
11	FUEL GRADE N°.			
12	STATIC PRESSURE IN WC (BONNET)			
13	AIR TEMP. INLET °F			
14	AIR TEMP. OUTLET °F			
15	AIR TEMP RISE °F			
16	LIMIT CONTROLS FUNCTIONING PROPERLY			
17	PRIMARY CONTROL			
A	SHUT OFF TIME (FLAME FAILURE)			
B	SHUT OFF TIME (IGNITION FAILURE)			
18	PULLEY TURNS OPEN			

NEWMAC MULTI FUEL AND SOLID FUEL HEATING UNIT "LIMITED" WARRANTY

Subject to the following provisions Newmac Mfg. Inc. (Newmac) warrants the heating unit, to the original owner, under normal use and repair, against defects in workmanship and materials, for a period of one calendar year from the date of original installation. Blower, motor, controls and/or any other electrical or mechanical components, not manufactured by Newmac, are not warranted by Newmac, but are warranted for a period of one year from date of original installation, by their respective manufacturer. In addition to this comprehensive, unconditional one year, new product warranty, Newmac further warrants the heat exchanger for an additional nine calendar years from date of original installation and in accordance with the declining table as set out below.

THE NEWMAC EXTENDED CONDITIONAL HEAT EXCHANGER WARRANTY PROGRAM

(Warranty protection calculated from date of original installation)

	Owner Warranty Protection	Owner Replacement Charge
First full year	100%	0%
From year one through year two	80%	20%
From year two through year four	60%	40%
From year four through year six	50%	50%
From year six through year eight	40%	60%
From year eight through year ten	20%	80%
From year ten and over	0%	100%

NOTES:

1. Owner Replacement Charges are expressed as a percentage of the replacement retail price prevailing at the time of replacement purchase.
2. Newmac is NOT responsible for:
 - A. Labour charges generated by removal of malfunctioning component and re-installation of replacement component.
 - B. Freight charges generated by any form of transportation of replacement component.
 - C. Any applicable sales tax generated by the purchase of replacement component.
 - D. Corrosion is not covered under warranty regardless of cause.

General Conditions and Limitations

1. The heating unit must be installed by a qualified licensed installer with the Newmac installation instructions. The heating unit must also be installed in accordance with all applicable codes and the National Warm Air Heating and Air Conditioning Association Standards or generally accepted equivalent standards.
2. The heating unit is NOT designed, or intended for use in a corrosive atmosphere (such as a concentration of acids or halogenated hydrocarbons). The installation, and operation of the unit in such an environment, will be considered as gross misuse, and all warranties will be automatically invalidated.
3. The heating unit must not be modified away from its published design and/or specifications without prior written authorization, for such modification, from Newmac.
4. The heating unit must be correctly sized to operate at its designed capability.
5. The heating unit must be correctly fueled to operate within its designed function.
6. The heating unit must be maintained and cleaned at regular intervals, and in accordance with instructions contained in the Newmac owner's manual.
7. Failure to comply with all the above stated qualifying conditions, will render the Newmac Warranty null, and void in its entirety.
8. This warranty is the only warranty made by Newmac, and furthermore, Newmac does not authorize any person or company to change, or alter, the conditions under which this warranty is provided. Newmac does not authorize any person, or company, to provide any other warranty on its behalf.
9. For routine service requirements, contact the dealer who installed the equipment originally or an alternate qualified and registered heating dealer or electrician.
10. As previously stated herein, Newmac does not assume responsibility for costs of delivery or labour charges involved in the replacement of defective component parts.
11. Newmac shall not be responsible for any consequential damage however caused whether by a defect in the heating unit or any part thereof warranted hereunder or by the negligence of any person.
12. This warranty is not effective unless the warranty registration card is properly filled out with all of the required information and received at Newmac's factory at the address below within (30) days from the installation date.

NOTE: Keep this warranty certificate and the instruction manual for future reference.

-----To register your warranty, please complete form below, detach and mail to Newmac Mfg. Inc., P.O. Box 9, Lancaster, Cr., Debert, N.S. B0M 1G0-----
LIMITED LIFETIME WARRANTY REGISTRATION

Owner's Name

Date of Installation

Address of Installation

Dealer's Name

Dealer's Address

Furnace Serial Number

Furnace Model Number