

SAFETY.CAT.COM™

C11, C13 and C15 ON-HIGHWAY ENGINES

Maintenance Intervals

Excerpted from Operation & Maintenance Manual (SEBU7695-13)

Maintenance Recommendations

System Pressure Release

i02909163

SMCS Code: 1250; 1300; 1350; 5050

Coolant System

WARNING

Pressurized system: Hot coolant can cause serious burn. To open cap, stop engine, wait until radiator is cool. Then loosen cap slowly to relieve the pressure.

To relieve the pressure from the coolant system, turn off the engine. Allow the cooling system pressure cap to cool. Remove the cooling system pressure cap slowly in order to relieve pressure.

Fuel System

To relieve the pressure from the fuel system, turn off the engine.

High Pressure Fuel Lines (If Equipped)

WARNING

Contact with high pressure fuel may cause fluid penetration and burn hazards. High pressure fuel spray may cause a fire hazard. Failure to follow these inspection, maintenance and service instructions may cause personal injury or death.

The high pressure fuel lines are the fuel lines that are between the high pressure fuel pump and the high pressure fuel manifold and the fuel lines that are between the fuel manifold and cylinder head. These fuel lines are different from fuel lines on other fuel systems.

This is because of the following differences:

- The high pressure fuel lines are constantly charged with high pressure.
- The internal pressures of the high pressure fuel lines are higher than other types of fuel system.

Before any service or repair is performed on the engine fuel lines, perform the following tasks:

1. Stop the engine.
2. Wait for ten minutes.

Do not loosen the high pressure fuel lines in order to remove air pressure from the fuel system.

Engine Oil

To relieve pressure from the lubricating system, turn off the engine.

i03091592

Welding on Engines with Electronic Controls

SMCS Code: 1000

NOTICE

Because the strength of the frame may decrease, some manufacturers do not recommend welding onto a chassis frame or rail. Consult the OEM of the equipment or your Caterpillar dealer regarding welding on a chassis frame or rail.

Proper welding procedures are necessary in order to avoid damage to the engine's ECM, sensors, and associated components. When possible, remove the component from the unit and then weld the component. If removal of the component is not possible, the following procedure must be followed when you weld on a unit that is equipped with a Caterpillar Electronic Engine. The following procedure is considered to be the safest procedure to weld on a component. This procedure should provide a minimum risk of damage to electronic components.

NOTICE

Do not ground the welder to electrical components such as the ECM or sensors. Improper grounding can cause damage to the drive train bearings, hydraulic components, electrical components, and other components.

Clamp the ground cable from the welder to the component that will be welded. Place the clamp as close as possible to the weld. This will help reduce the possibility of damage.

Note: Perform the welding in areas that are free from explosive hazards.

1. Stop the engine. Turn the switched power to the OFF position.

2. Disconnect the negative battery cable from the battery. If a battery disconnect switch is provided, open the switch.
3. Disconnect the J1/P1 and J2/P2 connectors from the ECM. Move the harness to a position that will not allow the harness to accidentally move back and make contact with any of the ECM pins.

Note: If electrical/electronic components are used as a ground for the welder, or electrical/electronic components are located between the welder ground and the weld, current flow from the welder could severely damage the component.

5. Protect the wiring harness from welding debris and spatter.
6. Use standard welding practices to weld the materials.




Illustration 43

g01075639

Use the example above. The current flow from the welder to the ground clamp of the welder will not cause damage to any associated components.

- (1) Engine
- (2) Welding electrode
- (3) Keyswitch in the OFF position
- (4) Battery disconnect switch in the open position
- (5) Disconnected battery cables
- (6) Battery
- (7) Electrical/Electronic component
- (8) Minimum distance between the component that is being welded and any electrical/electronic component
- (9) The component that is being welded
- (10) Current path of the welder
- (11) Ground clamp for the welder

4. Connect the welding ground cable directly to the part that will be welded. Place the ground cable as close as possible to the weld in order to reduce the possibility of welding current damage to bearings, hydraulic components, electrical components, and ground straps.

i03635998

Maintenance Interval Schedule (C11 and C13 Engines with 500 HP Field Up-Rates and 525 HP RV Ratings with Optional Shallow Oil Sumps)

SMCS Code: 1000; 7500

S/N: KCA1-Up

S/N: KCB1-Up

S/N: JAM1-Up

Ensure that all safety information, warnings, and instructions are read and understood before any operation or any maintenance procedures are performed. The user is responsible for the performance of maintenance, including all adjustments, the use of proper lubricants, fluids, filters, and the installation of new components due to normal wear and aging. The performance of this product may be diminished if proper maintenance intervals and procedures are not followed. Components may experience accelerated wear if proper maintenance intervals and procedures are not followed.

Note: Use whichever of the following that occurs first in order to determine the maintenance intervals: fuel consumption, service hours, and calendar time. Before each consecutive interval is performed, all maintenance from the previous intervals must be performed.

Products that operate in severe operating conditions may require more frequent maintenance.

When Required

Battery - Replace	76
Battery or Battery Cable - Disconnect	77
Cooling System Coolant Sample (Level 1) - Obtain	84
Cooling System Coolant Sample (Level 2) - Obtain	85
Crankshaft End Play - Test	86
Engine Air Cleaner Element - Clean/Replace	90
Engine Oil Level Gauge - Calibrate	92
Fuel System - Prime	100
Severe Service Application - Check	106

Daily

Cooling System Coolant Level - Check	84
Engine Air Cleaner Service Indicator - Inspect	90
Engine Oil Level - Check	92
Fuel System Water Separator - Inspect/Drain	103
Walk-Around Inspection	108

Every 24 140 km (15 000 miles) or 7950 L (2100 US gal) of Fuel or 230 Service Hours

Engine Oil Sample - Obtain	94
Engine Oil and Filter - Change	95

PM Level 1 - Every 48 000 km (30 000 miles) or 15 520 L (4100 US gal) of Fuel or 500 Service Hours

Air Compressor Filter - Clean/Replace	75
Air Shutoff - Test	75
Alternator - Inspect	76
Battery Electrolyte Level - Check	77
Belt - Inspect	77
Belt Tensioner - Inspect	78
Cooling System Supplemental Coolant Additive (SCA) - Test/Add	85
Cylinder Head Grounding Stud - Inspect/Clean/Tighten	88
Engine Crankcase Breather - Clean	91
Fuel System Primary Filter - Replace	102
Fuel System Secondary Filter - Replace	102
Fuel Tank Water and Sediment - Drain	104
Hoses and Clamps - Inspect/Replace	105

Between 24 000 and 96 000 km (15 000 and 60 000 miles)

Electronic Unit Injector - Inspect/Adjust	89
Engine Valve Lash - Inspect/Adjust	99
Valve Actuators - Inspect/Adjust	107

PM Level 2 - Every 320 000 km (200 000 miles) or 125 000 L (33 000 US gal) of Fuel or 4000 Service Hours or 2 Years

Aftercooler Core - Clean/Test	75
Cooling System Coolant (DEAC) - Change	80
Cooling System Water Temperature Regulator - Replace	86
Fan Drive Bearing - Lubricate	100
Radiator - Clean	106

PM Level 3 - Every 483 000 km (300 000 miles) or 190 000 L (50 000 US gal) of Fuel or 6000 Service Hours or 3 Years

Air Compressor - Inspect	75
Cooling System Coolant Extender (ELC) - Add	83
Crankshaft Vibration Damper - Inspect	87
Electronic Unit Injector - Inspect/Adjust	89
Engine - Clean	89
Engine Valve Lash - Inspect/Adjust	99
Turbocharger - Inspect	107
Valve Actuators - Inspect/Adjust	107

PM Level 4 - Every 966 000 km (600 000 miles) or 380 000 L (100 000 US gal) of Fuel or 12 000 Service Hours or 6 Years

Cooling System Coolant (ELC) - Change	82
---	----

i03635992

Maintenance Interval Schedule (C11 , C13 , and C15 Engines with Standard (Deep) Oil Sumps)

SMCS Code: 1000; 7500

Ensure that all safety information, warnings, and instructions are read and understood before any operation or any maintenance procedures are performed. The user is responsible for the performance of maintenance, including all adjustments, the use of proper lubricants, fluids, filters, and the installation of new components due to normal wear and aging. The performance of this product may be diminished if proper maintenance intervals and procedures are not followed. Components may experience accelerated wear if proper maintenance intervals and procedures are not followed.

Note: Use whichever of the following that occurs first in order to determine the maintenance intervals: fuel consumption, service hours, and calendar time . Before each consecutive interval is performed, all maintenance from the previous intervals must be performed.

Products that operate in severe operating conditions may require more frequent maintenance.

When Required

Battery - Replace	76
Battery or Battery Cable - Disconnect	77
Cooling System Coolant Sample (Level 1) - Obtain	84
Cooling System Coolant Sample (Level 2) - Obtain	85
Crankshaft End Play - Test	86
Engine Air Cleaner Element - Clean/Replace	90
Engine Oil Level Gauge - Calibrate	92
Fuel System - Prime	100
Severe Service Application - Check	106

Daily

Cooling System Coolant Level - Check	84
Engine Air Cleaner Service Indicator - Inspect	90
Engine Oil Level - Check	92
Fuel System Water Separator - Inspect/Drain	103
Walk-Around Inspection	108

PM Level 1 - Every 48 000 km (30 000 miles) or 15 520 L (4100 US gal) of Fuel or 500 Service Hours

Air Compressor Filter - Clean/Replace	75
---	----

Air Shutoff - Test	75
Alternator - Inspect	76
Battery Electrolyte Level - Check	77
Belt - Inspect	77
Belt Tensioner - Inspect	78
Cooling System Supplemental Coolant Additive (SCA) - Test/Add	85
Cylinder Head Grounding Stud - Inspect/Clean/Tighten	88
Engine Crankcase Breather - Clean	91
Engine Oil Sample - Obtain	94
Engine Oil and Filter - Change	95
Fuel System Primary Filter - Replace	102
Fuel System Secondary Filter - Replace	102
Fuel Tank Water and Sediment - Drain	104
Hoses and Clamps - Inspect/Replace	105

Between 24 000 and 96 000 km (15 000 and 60 000 miles)

Electronic Unit Injector - Inspect/Adjust	89
Engine Valve Lash - Inspect/Adjust	99
Valve Actuators - Inspect/Adjust	107

PM Level 2 - Every 320 000 km (200 000 miles) or 125 000 L (33 000 US gal) of Fuel or 4000 Service Hours or 2 Years

Aftercooler Core - Clean/Test	75
Cooling System Coolant (DEAC) - Change	80
Cooling System Water Temperature Regulator - Replace	86
Fan Drive Bearing - Lubricate	100
Radiator - Clean	106

PM Level 3 - Every 483 000 km (300 000 miles) or 190 000 L (50 000 US gal) of Fuel or 6000 Service Hours or 3 Years

Air Compressor - Inspect	75
Compression Brake - Inspect/Adjust/Replace	78
Cooling System Coolant Extender (ELC) - Add	83
Crankshaft Vibration Damper - Inspect	87
Electronic Unit Injector - Inspect/Adjust	89
Engine - Clean	89
Engine Valve Lash - Inspect/Adjust	99
Turbocharger - Inspect	107
Valve Actuators - Inspect/Adjust	107

PM Level 4 - Every 966 000 km (600 000 miles) or 380 000 L (100 000 US gal) of Fuel or 12 000 Service Hours or 6 Years

Compression Brake - Inspect/Adjust/Replace	78
Cooling System Coolant (ELC) - Change	82

i03636093

Maintenance Interval Schedule (C11 and C13 Engines with 500 HP Field Up-Rates and 525 HP RV Ratings with Standard (Deep) Oil Sumps)

SMCS Code: 1000; 7500

S/N: KCA1-Up

S/N: KCB1-Up

S/N: JAM1-Up

Ensure that all safety information, warnings, and instructions are read and understood before any operation or any maintenance procedures are performed. The user is responsible for the performance of maintenance, including all adjustments, the use of proper lubricants, fluids, filters, and the installation of new components due to normal wear and aging. The performance of this product may be diminished if proper maintenance intervals and procedures are not followed. Components may experience accelerated wear if proper maintenance intervals and procedures are not followed.

Note: Use whichever of the following that occurs first in order to determine the maintenance intervals: fuel consumption, service hours, and calendar time . Before each consecutive interval is performed, all maintenance from the previous intervals must be performed.

Products that operate in severe operating conditions may require more frequent maintenance.

When Required

Battery - Replace	76
Battery or Battery Cable - Disconnect	77
Cooling System Coolant Sample (Level 1) - Obtain	84
Cooling System Coolant Sample (Level 2) - Obtain	85
Crankshaft End Play - Test	86
Engine Air Cleaner Element - Clean/Replace	90
Engine Oil Level Gauge - Calibrate	92
Fuel System - Prime	100
Severe Service Application - Check	106

Daily

Cooling System Coolant Level - Check	84
Engine Air Cleaner Service Indicator - Inspect	90
Engine Oil Level - Check	92
Fuel System Water Separator - Inspect/Drain	103
Walk-Around Inspection	108

Every 32 000 km (20 000 miles) or 9464 L (2500 US gal) of Fuel or 300 Service Hours

Engine Oil Sample - Obtain	94
Engine Oil and Filter - Change	95

PM Level 1 - Every 48 000 km (30 000 miles) or 15 520 L (4100 US gal) of Fuel or 500 Service Hours

Air Compressor Filter - Clean/Replace	75
Air Shutoff - Test	75
Alternator - Inspect	76
Battery Electrolyte Level - Check	77
Belt - Inspect	77
Belt Tensioner - Inspect	78
Cooling System Supplemental Coolant Additive (SCA) - Test/Add	85
Cylinder Head Grounding Stud - Inspect/Clean/Tighten	88
Engine Crankcase Breather - Clean	91
Fuel System Primary Filter - Replace	102
Fuel System Secondary Filter - Replace	102
Fuel Tank Water and Sediment - Drain	104
Hoses and Clamps - Inspect/Replace	105

Between 24 000 and 96 000 km (15 000 and 60 000 miles)

Electronic Unit Injector - Inspect/Adjust	89
Engine Valve Lash - Inspect/Adjust	99
Valve Actuators - Inspect/Adjust	107

PM Level 2 - Every 320 000 km (200 000 miles) or 125 000 L (33 000 US gal) of Fuel or 4000 Service Hours or 2 Years

Aftercooler Core - Clean/Test	75
Cooling System Coolant (DEAC) - Change	80
Cooling System Water Temperature Regulator - Replace	86
Fan Drive Bearing - Lubricate	100
Radiator - Clean	106

PM Level 3 - Every 483 000 km (300 000 miles) or 190 000 L (50 000 US gal) of Fuel or 6000 Service Hours or 3 Years

Air Compressor - Inspect	75
Cooling System Coolant Extender (ELC) - Add	83
Crankshaft Vibration Damper - Inspect	87
Electronic Unit Injector - Inspect/Adjust	89
Engine - Clean	89
Engine Valve Lash - Inspect/Adjust	99
Turbocharger - Inspect	107
Valve Actuators - Inspect/Adjust	107

PM Level 4 - Every 966 000 km (600 000 miles) or 380 000 L (100 000 US gal) of Fuel or 12 000 Service Hours or 6 Years

Cooling System Coolant (ELC) - Change	82
---	----

i03636084

Maintenance Interval Schedule (C11 and C13 Engines with Optional Shallow Oil Sumps)

SMCS Code: 1000; 7500

S/N: KCA1-Up

S/N: KCB1-Up

S/N: JAM1-Up

Ensure that all safety information, warnings, and instructions are read and understood before any operation or any maintenance procedures are performed. The user is responsible for the performance of maintenance, including all adjustments, the use of proper lubricants, fluids, filters, and the installation of new components due to normal wear and aging. The performance of this product may be diminished if proper maintenance intervals and procedures are not followed. Components may experience accelerated wear if proper maintenance intervals and procedures are not followed.

Note: Use whichever of the following that occurs first in order to determine the maintenance intervals: fuel consumption, service hours, and calendar time. Before each consecutive interval is performed, all maintenance from the previous intervals must be performed.

Products that operate in severe operating conditions may require more frequent maintenance.

When Required

Battery - Replace	76
Battery or Battery Cable - Disconnect	77
Cooling System Coolant Sample (Level 1) - Obtain	84
Cooling System Coolant Sample (Level 2) - Obtain	85
Crankshaft End Play - Test	86
Engine Air Cleaner Element - Clean/Replace	90
Engine Oil Level Gauge - Calibrate	92
Fuel System - Prime	100
Severe Service Application - Check	106

Daily

Cooling System Coolant Level - Check	84
Engine Air Cleaner Service Indicator - Inspect	90
Engine Oil Level - Check	92
Fuel System Water Separator - Inspect/Drain	103
Walk-Around Inspection	108

Every 32 000 km (20 000 miles) or 9464 L (2500 US gal) of Fuel or 300 Service Hours

Engine Oil Sample - Obtain	94
Engine Oil and Filter - Change	95

PM Level 1 - Every 48 000 km (30 000 miles) or 15 520 L (4100 US gal) of Fuel or 500 Service Hours

Air Compressor Filter - Clean/Replace	75
Air Shutoff - Test	75
Alternator - Inspect	76
Battery Electrolyte Level - Check	77
Belt - Inspect	77
Belt Tensioner - Inspect	78
Cooling System Supplemental Coolant Additive (SCA) - Test/Add	85
Cylinder Head Grounding Stud - Inspect/Clean/Tighten	88
Engine Crankcase Breather - Clean	91
Fuel System Primary Filter - Replace	102
Fuel System Secondary Filter - Replace	102
Fuel Tank Water and Sediment - Drain	104
Hoses and Clamps - Inspect/Replace	105

PM Level 1 - Every 48 000 km (30 000 miles) or 17 400 L (4600 US gal) of Fuel or 600 Service Hours

Fuel System Primary Filter - Replace	102
--	-----

Between 24 000 and 96 000 km (15 000 and 60 000 miles)

Electronic Unit Injector - Inspect/Adjust	89
Engine Valve Lash - Inspect/Adjust	99
Valve Actuators - Inspect/Adjust	107

PM Level 2 - Every 320 000 km (200 000 miles) or 125 000 L (33 000 US gal) of Fuel or 4000 Service Hours or 2 Years

Aftercooler Core - Clean/Test	75
Cooling System Coolant (DEAC) - Change	80
Cooling System Water Temperature Regulator - Replace	86
Fan Drive Bearing - Lubricate	100
Radiator - Clean	106

PM Level 3 - Every 483 000 km (300 000 miles) or 190 000 L (50 000 US gal) of Fuel or 6000 Service Hours or 3 Years

Air Compressor - Inspect	75
Cooling System Coolant Extender (ELC) - Add	83
Crankshaft Vibration Damper - Inspect	87
Electronic Unit Injector - Inspect/Adjust	89
Engine - Clean	89
Engine Valve Lash - Inspect/Adjust	99
Turbocharger - Inspect	107
Valve Actuators - Inspect/Adjust	107

**PM Level 4 - Every 966 000 km (600 000 miles)
or 380 000 L (100 000 US gal) of Fuel or 12
000 Service Hours or 6 Years**

Cooling System Coolant (ELC) - Change 82

i01807350

Aftercooler Core - Clean/Test (Air-To-Air Aftercooler)

SMCS Code: 1064-070; 1064-081

The air-to-air aftercooler is OEM installed in many applications. Please refer to the OEM specifications for information that is related to the aftercooler.

i02413116

Air Compressor - Inspect

SMCS Code: 1803-040

WARNING

Do not disconnect the air line from the air compressor governor without purging the air brake and the auxiliary air systems. Failure to purge the air brake and the auxiliary air systems before removing the air compressor and/or the air lines could cause personal injury.




Illustration 44

g01206109

Typical example

(1) Pressure relief valve

WARNING

If the air compressor pressure relief valve that is mounted in the air compressor cylinder head is bypassing compressed air, there is a malfunction in the air system, possibly ice blockage. Under these conditions, your engine may have insufficient air for normal brake operation.

Do not operate the engine until the reason for the air bypass is identified and corrected. Failure to heed this warning could lead to property damage, personal injury, or death to the operator or bystanders.

The function of the pressure relief valve is to bypass air when there is a malfunction in the system for the air compressor.

The pressure relief valve for the air compressor releases air at 1723 kPa (250 psi). If the pressure relief valve for the air compressor exhausts, all personnel should be at a safe distance away from the air compressor. All personnel should also stay clear of the air compressor when the engine is operating and the air compressor is exposed.

Refer to the Service Manual or refer to the OEM specifications in order to find information concerning the air compressor. Consult your Caterpillar dealer for assistance.

i01544231

Air Compressor Filter - Clean/Replace (If Equipped)

SMCS Code: 1803-070-FQ; 1803-510-FQ

One of the single most important aspects of preventive maintenance for the air compressor is the induction of clean air. The type of maintenance that is required for the air compressor and the maintenance interval depends on the type of air induction system that is used. Operating conditions (dust, dirt and debris) may require more frequent service.

Refer to the Service Manual for the type of air compressor that is installed on the engine. Follow the maintenance recommendations that are provided by the OEM of the air compressor. Some engines use boost air pressure so the engine air cleaner will require servicing.

i02811865

Air Shutoff - Test (Engines that are Equipped with Optional Air Shutoff Systems)

SMCS Code: 1078-081

The air inlet shutoff switch can be used to manually activate the air inlet shutoff. When the switch is depressed, a one second pulse is sent to the air inlet shutoff relay.

In order to test the air shutoff system, perform the following steps:

- Start the engine.

- Place the transmission in the NEUTRAL position.
- Push the "AIR SHUTOFF" switch.

The engine should shut down.




Illustration 45

g01402506

Typical air shutoff

The air shutoff must be manually reset before further engine operation. The "OPEN/CLOSED" switch will be open during engine operation. Move the indicator from the CLOSED position to the OPEN position.

If the engine does not shut down, further testing of the air shutoffs may be accomplished through the use of Cat ET. Refer to the Troubleshooting Guide, "Air Inlet Shutoff Circuit - Test" information for your engine.

i02676048

Alternator - Inspect

SMCS Code: 1405-040

Caterpillar recommends a scheduled inspection of the alternator. Inspect the alternator for loose connections and proper battery charging. Inspect the ammeter (if equipped) during engine operation in order to ensure proper battery performance and/or proper performance of the electrical system. Make repairs, as required.

Check the alternator and the battery charger for proper operation. If the batteries are properly charged, the ammeter reading should be very near zero. All batteries should be kept charged. The batteries should be kept warm because temperature affects the cranking power. If the battery is too cold, the battery will not crank the engine. The battery will not crank the engine, even if the engine is warm. When the engine is not run for long periods of time or if the engine is run for short periods, the batteries may not fully charge. A battery with a low charge will freeze more easily than a battery with a full charge.

i02153996

Battery - Replace

SMCS Code: 1401-510

WARNING

Batteries give off combustible gases which can explode. A spark can cause the combustible gases to ignite. This can result in severe personal injury or death.

Ensure proper ventilation for batteries that are in an enclosure. Follow the proper procedures in order to help prevent electrical arcs and/or sparks near batteries. Do not smoke when batteries are serviced.

WARNING

The battery cables or the batteries should not be removed with the battery cover in place. The battery cover should be removed before any servicing is attempted.

Removing the battery cables or the batteries with the cover in place may cause a battery explosion resulting in personal injury.

1. Turn the key start switch to the OFF position. Remove the key and all electrical loads.
2. Turn OFF the battery charger. Disconnect the charger.
3. The NEGATIVE "-" cable connects the NEGATIVE "-" battery terminal to the ground plane. Disconnect the cable from the NEGATIVE "-" battery terminal.
4. The POSITIVE "+" cable connects the POSITIVE "+" battery terminal to the starting motor. Disconnect the cable from the POSITIVE "+" battery terminal.

Note: Always recycle a battery. Never discard a battery. Return used batteries to an appropriate recycling facility.

5. Remove the used battery.
6. Install the new battery.

Note: Before the cables are connected, ensure that the key start switch is OFF.

7. Connect the cable from the starting motor to the POSITIVE "+" battery terminal.

8. Connect the cable from the ground plane to the NEGATIVE “-” battery terminal.

i02601752

Battery Electrolyte Level - Check

SMCS Code: 1401-535

When the engine is not run for long periods of time or when the engine is run for short periods, the batteries may not fully recharge. Ensure a full charge in order to help prevent the battery from freezing.

WARNING

All lead-acid batteries contain sulfuric acid which can burn the skin and clothing. Always wear a face shield and protective clothing when working on or near batteries.

1. Remove the filler caps. Maintain the electrolyte level to the “FULL” mark on the battery.

If the addition of water is necessary, use distilled water. If distilled water is not available use clean water that is low in minerals. Do not use artificially softened water.

2. Check the condition of the electrolyte with the 245-5829 Coolant Battery Tester Refractometer.
3. Keep the batteries clean.

Clean the battery case with one of the following cleaning solutions:

- A mixture of 0.1 kg (0.2 lb) of baking soda and 1 L (1 qt) of clean water
- A mixture of 0.1 L (0.11 qt) of ammonia and 1 L (1 qt) of clean water

Thoroughly rinse the battery case with clean water.

Use a fine grade of sandpaper to clean the terminals and the cable clamps. Clean the items until the surfaces are bright or shiny. DO NOT remove material excessively. Excessive removal of material can cause the clamps to not fit properly. Coat the clamps and the terminals with 5N-5561 Silicone Lubricant, petroleum jelly or MPGM.

i01492654

Battery or Battery Cable - Disconnect

SMCS Code: 1402-029

WARNING

The battery cables or the batteries should not be removed with the battery cover in place. The battery cover should be removed before any servicing is attempted.

Removing the battery cables or the batteries with the cover in place may cause a battery explosion resulting in personal injury.

1. Turn the start switch to the OFF position. Turn the ignition switch (if equipped) to the OFF position and remove the key and all electrical loads.
2. Disconnect the negative battery terminal at the battery that goes to the start switch. Ensure that the cable cannot contact the terminal. When four 12 volt batteries are involved, the negative side of two batteries must be disconnected.
3. Tape the leads in order to help prevent accidental starting.
4. Proceed with necessary system repairs. Reverse the steps in order to reconnect all of the cables.

i02126625

Belt - Inspect

SMCS Code: 1357-040; 1357; 1397-040; 1397

Inspection

Belt tension should be checked initially between the first 20 to 40 hours of engine operation.

After the initial check, the belt tension should be checked at Every PM Level 1 or Three Months.

To maximize the engine performance, inspect the belts for wear and for cracking. Replace belts that are worn or damaged.

For applications that require multiple drive belts, replace the belts in matched sets. Replacing only one belt of a matched set will cause the new belt to carry more load because the older belt is stretched. The additional load on the new belt could cause the new belt to break.

If the belts are too loose, vibration causes unnecessary wear on the belts and pulleys. Loose belts may slip enough to cause overheating.

If the belts are too tight, unnecessary stresses are placed on the pulley bearings and on the belts. This may shorten the service life of the components.

Remove the belt guard. Inspect the condition and adjustment of the alternator belts and accessory drive belts (if equipped).

To check the belt tension, apply 110 N (25 lb ft) of force midway between the pulleys. A correctly adjusted belt will deflect 9 mm (0.35 inch) to 15 mm (0.59 inch).

If the belt does not require replacement or adjustment, install the belt guard. If the belt requires adjustment or replacement, perform the following procedure to adjust the belt tension.

- If the engine is equipped with a refrigerant compressor (air conditioner), the belt for the fan drive, the alternator, and the accessories will have an automatic belt tensioner.
- If the engine is not equipped with a refrigerant compressor, the alternator is used to adjust the belt tension.

Adjustment

Alternator Belt




Illustration 46

g00485289

Typical alternator mounting

- (1) Adjusting nuts
(2) Mounting bolts

1. Slightly loosen mounting bolt (2) and adjusting nut (1).
2. Move the pulley in order to adjust the belt tension.

3. Tighten adjusting nuts (1) and mounting bolts (2). Refer to the Specifications, SENR3130 in order to locate the proper torques.

4. Install the belt guard.

If new belts are installed, check the belt tension again after 30 minutes of engine operation at the rated rpm.

i03019073

Belt Tensioner - Inspect

SMCS Code: 1358-040

It is essential to check the position of the belt tightener in order to maintain the proper belt tension. A film (decals) is located on the side of the belt tightener. The decal indicates when the belts have stretched beyond the belt tightener's ability.




Illustration 47

g01526739

Side view of the belt tensioner

If the pointer (1) is in green zone (3), the belt tension is correct. If the pointer (1) is in the upper red zone (2), the belt has stretched. The tension must be adjusted or the belt must be replaced. If the pointer (1) is in the lower red zone (4), the belt is too short. The belt must be replaced.

i01426993

Compression Brake - Inspect/Adjust/Replace

SMCS Code: 1119-025; 1119-040; 1119-510

S/N: BXS1-Up

S/N: RKS1-Up

The maintenance of the compression brake should be performed in conjunction with scheduled engine maintenance. The correct tune-up kit is required when parts are replaced on the compression brake. Refer to the Parts Manual for additional information.

Note: The slave piston lash adjustment must be performed after the engine valve lash adjustment is performed. Make the slave piston adjustment while the engine is stopped. Refer to the Systems Operation, Testing and Adjusting Module for additional information.

Refer to the Disassembly and Assembly Module for instructions on replacing the components.

Table 30

Component	Required Maintenance (300,000 miles)	Required Maintenance (600,000 miles)
Wiring and Terminal Connections	Inspect	Inspect
Clutch/Throttle/Buffer Screw	Adjust/Replace	Adjust/Replace
Slave Piston Lash Adjusting Screw	Adjust/Inspect	Adjust/Replace
Solenoid Valves	Inspect	Replace
Crosshead Bridges/ Valve Stem Caps	Inspect	Inspect
Injector/Exhaust Rocker Arm Screws	Inspect	Inspect
Master Piston/Fork Assembly	Inspect	Inspect
Slave pistons	Inspect	Inspect
External Hose Assembly	Inspect	Inspect
Housings	Inspect	Inspect
Fuel Pipes	Inspect	Inspect
Hold Down Bolts	Inspect	Replace
Accumulator Springs ⁽¹⁾	Replace	Inspect
Solenoid Harness ⁽¹⁾	Replace	Inspect
Solenoid Seal Rings ⁽¹⁾	Replace	Inspect
Control Valve Springs ⁽¹⁾	Replace	Inspect
Control Valves ⁽¹⁾	Replace	Inspect
Oil Seal Rings ⁽¹⁾	Replace	Inspect
Master Piston Return Springs ⁽¹⁾	Replace	Inspect
Terminal Lead Out ⁽¹⁾	Replace	Inspect
Crosshead Pin Assembly ⁽¹⁾	Replace	Inspect

⁽¹⁾ Contained in tune-up kits

i02126636

Cooling System Coolant (DEAC) - Change

SMCS Code: 1350-070; 1395-044

Clean the cooling system and flush the cooling system before the recommended maintenance interval if the following conditions exist:

- The engine overheats frequently.
- Foaming is observed.
- The oil has entered the cooling system and the coolant is contaminated.
- The fuel has entered the cooling system and the coolant is contaminated.

NOTICE

Use of commercially available cooling system cleaners may cause damage to cooling system components. Use only cooling system cleaners that are approved for Caterpillar engines.

Note: Inspect the water pump and the water temperature regulator after the cooling system has been drained. This is a good opportunity to replace the water pump, the water temperature regulator and the hoses, if necessary.

Drain

WARNING

Pressurized System: Hot coolant can cause serious burns. To open the cooling system filler cap, stop the engine and wait until the cooling system components are cool. Loosen the cooling system pressure cap slowly in order to relieve the pressure.

1. Stop the engine and allow the engine to cool. Loosen the cooling system filler cap slowly in order to relieve any pressure. Remove the cooling system filler cap.
2. Open the cooling system drain valve (if equipped). If the cooling system is not equipped with a drain valve, remove one of the drain plugs.

Note: If equipped, be sure to drain the heater and any related supply and return lines.

Allow the coolant to drain.

NOTICE

Dispose of used engine coolant properly or recycle. Various methods have been proposed to reclaim used coolant for reuse in engine cooling systems. The full distillation procedure is the only method acceptable by Caterpillar to reclaim the used coolant.

For information regarding the disposal and the recycling of used coolant, consult your Caterpillar dealer or consult Caterpillar Dealer Service Tools Group:

Outside Illinois: 1-800-542-TOOL
Inside Illinois: 1-800-541-TOOL
Canada: 1-800-523-TOOL

Flush

1. Flush the cooling system with clean water in order to remove any debris.
2. Close the drain valve (if equipped). Clean the drain plugs. Install the drain plugs. Refer to the Specifications Manual, SENR3130, "Torque Specifications" for more information on the proper torques.

NOTICE

Fill the cooling system no faster than 19 L (5 US gal) per minute to avoid air locks.

3. Fill the cooling system with a mixture of clean water and Caterpillar Fast Acting Cooling System Cleaner. Add 0.5 L (1 pint) of cleaner per 15 L (4 US gal) of the cooling system capacity. Install the cooling system filler cap.
4. Start and run the engine at low idle for a minimum of 30 minutes. The coolant temperature should be at least 82 °C (180 °F).

NOTICE

Improper or incomplete rinsing of the cooling system can result in damage to copper and other metal components.

To avoid damage to the cooling system, make sure to completely flush the cooling system with clear water. Continue to flush the system until all signs of the cleaning agent are gone.

5. Stop the engine and allow the engine to cool. Loosen the cooling system filler cap slowly in order to relieve any pressure. Remove the cooling system filler cap. Open the drain valve (if equipped) or remove the cooling system drain plugs. Allow the water to drain. Flush the cooling system with clean water. If equipped, be sure to flush the heater and any related supply and return lines. Close the drain valve (if equipped). Clean the drain plugs. Install the drain plugs. Refer to the Specifications Manual, SENR3130, "Torque Specifications" for more information on the proper torques.

Cooling Systems with Heavy Deposits or Plugging

Note: For the following procedure to be effective, there must be some active flow through the cooling system components.

1. Flush the cooling system with clean water in order to remove any debris.

Note: If equipped, be sure to flush the heater and any related supply and return lines.

2. Close the drain valve (if equipped). Clean the drain plugs. Install the drain plugs. Refer to the Specifications Manual, SENR3130, "Torque Specifications" for more information on the proper torques.

NOTICE

Fill the cooling system no faster than 19 L (5 US gal) per minute to avoid air locks.

3. Fill the cooling system with a mixture of clean water and Caterpillar Fast Acting Cooling System Cleaner. Add 0.5 L (1 pint) of cleaner per 3.8 to 7.6 L (1 to 2 US gal) of the cooling system capacity. Install the cooling system filler cap.
4. Start and run the engine at low idle for a minimum of 90 minutes. The coolant temperature should be at least 82 °C (180 °F).

NOTICE

Improper or incomplete rinsing of the cooling system can result in damage to copper and other metal components.

To avoid damage to the cooling system, make sure to completely flush the cooling system with clear water. Continue to flush the system until all signs of the cleaning agent are gone.

5. Stop the engine and allow the engine to cool. Loosen the cooling system filler cap slowly in order to relieve any pressure. Remove the cooling system filler cap. Open the drain valve (if equipped) or remove the cooling system drain plugs. Allow the water to drain. Flush the cooling system with clean water. Close the drain valve (if equipped). Clean the drain plugs. Install the drain plugs. Refer to the Specifications Manual, SENR3130, "Torque Specifications" for more information on the proper torques.

Fill

NOTICE

Fill the cooling system no faster than 19 L (5 US gal) per minute to avoid air locks.

1. Fill the cooling system with coolant/antifreeze. Refer to the Operation and Maintenance Manual, "Refill Capacities and Recommendations" topic (Maintenance Section) for more information on cooling system specifications. Do not install the cooling system filler cap.
2. Start and run the engine at low idle. Increase the engine rpm to 1500 rpm. Run the engine at high idle for one minute in order to purge the air from the cavities of the engine block. Stop the engine.
3. Check the coolant level. Maintain the coolant level within 13 mm (0.5 inch) below the bottom of the pipe for filling. Maintain the coolant level within 13 mm (0.5 inch) to the proper level on the sight glass (if equipped).
4. Clean the cooling system filler cap. Inspect the gasket that is on the cooling system filler cap. If the gasket that is on the cooling system filler cap is damaged, discard the old cooling system filler cap and install a new cooling system filler cap. If the gasket that is on the cooling system filler cap is not damaged, perform a pressure test. A 9S-8140 Pressurizing Pump is used to perform the pressure test. The correct pressure for the cooling system filler cap is stamped on the face of the cooling system filler cap. If the cooling system filler cap does not retain the correct pressure, install a new cooling system filler cap.
5. Start the engine. Inspect the cooling system for leaks and for proper operating temperature.

i02126647

Cooling System Coolant (ELC) - Change

SMCS Code: 1350-070; 1395-044

Clean the cooling system and flush the cooling system before the recommended maintenance interval if the following conditions exist:

- The engine overheats frequently.
- Foaming is observed.
- The oil has entered the cooling system and the coolant is contaminated.
- The fuel has entered the cooling system and the coolant is contaminated.

Note: When the cooling system is cleaned, only clean water is needed when the ELC is drained and replaced.

Note: Inspect the water pump and the water temperature regulator after the cooling system has been drained. This is a good opportunity to replace the water pump, the water temperature regulator and the hoses, if necessary.

Drain

WARNING

Pressurized System: Hot coolant can cause serious burns. To open the cooling system filler cap, stop the engine and wait until the cooling system components are cool. Loosen the cooling system pressure cap slowly in order to relieve the pressure.

1. Stop the engine and allow the engine to cool. Loosen the cooling system filler cap slowly in order to relieve any pressure. Remove the cooling system filler cap.
2. Open the cooling system drain valve (if equipped). If the cooling system is not equipped with a drain valve, remove the cooling system drain plugs.

Allow the coolant to drain.

NOTICE

Dispose of used engine coolant properly or recycle. Various methods have been proposed to reclaim used coolant for reuse in engine cooling systems. The full distillation procedure is the only method acceptable by Caterpillar to reclaim the used coolant.

For information regarding the disposal and the recycling of used coolant, consult your Caterpillar dealer or consult Caterpillar Dealer Service Tools Group:

Outside Illinois: 1-800-542-TOOL

Inside Illinois: 1-800-541-TOOL

Canada: 1-800-523-TOOL

Flush

1. Flush the cooling system with clean water in order to remove any debris.

Note: If equipped, be sure to flush the heater and any related supply and return lines.

2. Close the drain valve (if equipped). Clean the drain plugs. Install the drain plugs. Refer to the Specifications Manual, SENR3130, "Torque Specifications" for more information on the proper torques.

NOTICE

Fill the cooling system no faster than 19 L (5 US gal) per minute to avoid air locks.

3. Fill the cooling system with clean water. Install the cooling system filler cap.
4. Start and run the engine at low idle until the temperature reaches 49 to 66 °C (120 to 150 °F).
5. Stop the engine and allow the engine to cool. Loosen the cooling system filler cap slowly in order to relieve any pressure. Remove the cooling system filler cap. Open the drain valve (if equipped) or remove the cooling system drain plugs. Allow the water to drain. Flush the cooling system with clean water. Close the drain valve (if equipped). Clean the drain plugs. Install the drain plugs. Refer to the Specifications Manual, SENR3130, "Torque Specifications" for more information on the proper torques.

Fill

NOTICE

Fill the cooling system no faster than 19 L (5 US gal) per minute to avoid air locks.

1. Fill the cooling system with Extended Life Coolant (ELC). Refer to the Operation and Maintenance Manual, "Refill Capacities and Recommendations" topic (Maintenance Section) for more information on cooling system specifications. Do not install the cooling system filler cap.

2. Start and run the engine at low idle. Increase the engine rpm to high idle. Run the engine at high idle for one minute in order to purge the air from the cavities of the engine block. Stop the engine.
3. Check the coolant level. Maintain the coolant level within 13 mm (0.5 inch) below the bottom of the pipe for filling. Maintain the coolant level within 13 mm (0.5 inch) to the proper level on the sight glass (if equipped).
4. Clean the cooling system filler cap. Inspect the gasket that is on the cooling system filler cap. If the gasket that is on the cooling system filler cap is damaged, discard the old cooling system filler cap and install a new cooling system filler cap. If the gasket that is on the cooling system filler cap is not damaged, use a 9S-8140 Pressurizing Pump in order to pressure test the cooling system filler cap. The correct pressure for the cooling system filler cap is stamped on the face of the cooling system filler cap. If the cooling system filler cap does not retain the correct pressure, install a new cooling system filler cap.
5. Start the engine. Inspect the cooling system for leaks and for proper operating temperature.

i03085827

Cooling System Coolant Extender (ELC) - Add

SMCS Code: 1352-045; 1395-081

WARNING

Personal injury can result from hot coolant, steam and alkali.

At operating temperature, engine coolant is hot and under pressure. The radiator and all lines to heaters or the engine contain hot coolant or steam. Any contact can cause severe burns.

Remove cooling system pressure cap slowly to relieve pressure only when engine is stopped and cooling system pressure cap is cool enough to touch with your bare hand.

Do not attempt to tighten hose connections when the coolant is hot, the hose can come off causing burns.

Cooling System Coolant Additive contains alkali. Avoid contact with skin and eyes.

NOTICE

Care must be taken to ensure that fluids are contained during performance of inspection, maintenance, testing, adjusting and repair of the product. Be prepared to collect the fluid with suitable containers before opening any compartment or disassembling any component containing fluids.

Refer to Special Publication, NENG2500, "Caterpillar Dealer Service Tool Catalog" for tools and supplies suitable to collect and contain fluids on Caterpillar products.

Dispose of all fluids according to local regulations and mandates.

1. Check the cooling system only when the engine is stopped and cool.
2. Loosen the cooling system filler cap slowly in order to relieve pressure. Remove the cooling system filler cap.
3. It may be necessary to drain enough coolant from the cooling system in order to add Cat ELC Extender .
4. Refer to the schedule that is found in Operation and Maintenance Manual , "Maintenance Interval Schedule". This schedule lists the interval for adding Cat ELC Extender to this engine.
5. Use the formula in Table 31 to determine the proper amount of Cat ELC Extender for your cooling system. The total cooling capacity will vary depending on the radiator that is provided by the vehicle manufacturer.

Table 31

Formula For Adding Cat ELC Extender To Cat ELC
$V \times 0.02 = X$
V is the total capacity of the cooling system.
X is the amount of Cat ELC Extender that is required.

6. Clean the cooling system filler cap. Inspect the filler cap gaskets. Replace the filler cap if the filler cap gaskets are damaged. Install the cooling system filler cap.

For more information about Cat ELC Extender, refer to Special Publication, SEBU6385, "Caterpillar On-highway Diesel Engine Fluid Recommendations".

i01197583

Cooling System Coolant Level - Check

SMCS Code: 1395-082

Check the coolant level when the engine is stopped and cool.




Illustration 48

g00285520

Cooling system filler cap

WARNING

Pressurized System: Hot coolant can cause serious burns. To open the cooling system filler cap, stop the engine and wait until the cooling system components are cool. Loosen the cooling system pressure cap slowly in order to relieve the pressure.

1. Remove the cooling system filler cap slowly in order to relieve pressure.
2. Maintain the coolant level within 13 mm (0.5 inch) of the bottom of the filler pipe. If the engine is equipped with a sight glass, maintain the coolant level to the proper level in the sight glass.




Illustration 49

g00103639

Typical filler cap gaskets

3. Clean the cooling system filler cap and check the condition of the filler cap gaskets. Replace the cooling system filler cap if the filler cap gaskets are damaged. Reinstall the cooling system filler cap.

4. Inspect the cooling system for leaks.

i03085830

Cooling System Coolant Sample (Level 1) - Obtain

SMCS Code: 1350-008; 1395-008; 1395-554; 7542

Note: Refer to this Operation and Maintenance Manual, "Refill Capacities and Recommendations" for the proper maintenance interval for your application.

NOTICE

Always use a designated pump for oil sampling, and use a separate designated pump for coolant sampling. Using the same pump for both types of samples may contaminate the samples that are being drawn. This contaminate may cause a false analysis and an incorrect interpretation that could lead to concerns by both dealers and customers.

Note: Level 1 results may indicate a need for Level 2 Analysis.

Obtain the sample of the coolant as close as possible to the recommended sampling interval. In order to receive the full effect of S-O-S analysis, you must establish a consistent trend of data. In order to establish a pertinent history of data, perform consistent samplings that are evenly spaced. Supplies for collecting samples can be obtained from your Caterpillar dealer.

Use the following guidelines for proper sampling of the coolant:

- Complete the information on the label for the sampling bottle before you begin to take the samples.
- Keep the unused sampling bottles stored in plastic bags.
- Obtain coolant samples directly from the coolant sample port. You should not obtain the samples from any other location.
- Keep the lids on empty sampling bottles until you are ready to collect the sample.
- Place the sample in the mailing tube immediately after obtaining the sample in order to avoid contamination.

- Never collect samples from expansion bottles.
- Never collect samples from the drain for a system.

Submit the sample for Level 1 analysis.

For additional information about coolant analysis, see Special Publication, SEBU6385, "Caterpillar On-highway Diesel Engine Fluids Recommendations" or consult your Caterpillar dealer.

i03085829

Cooling System Coolant Sample (Level 2) - Obtain

SMCS Code: 1350-008; 1395-008; 1395-554; 7542

Note: Refer to this Operation and Maintenance Manual, "Refill Capacities and Recommendations" for the proper maintenance interval for your application.

NOTICE

Always use a designated pump for oil sampling, and use a separate designated pump for coolant sampling. Using the same pump for both types of samples may contaminate the samples that are being drawn. This contaminate may cause a false analysis and an incorrect interpretation that could lead to concerns by both dealers and customers.

Refer to this Operation and Maintenance Manual, "Cooling System Coolant Sample (Level 1) - Obtain" for the guidelines for proper sampling of the coolant.

Submit the sample for Level 2 analysis.

For additional information about coolant analysis, see Special Publication, SEBU6385, "Caterpillar On-highway Diesel Engines Fluids Recommendations" or consult your Caterpillar dealer.

i03085828

Cooling System Supplemental Coolant Additive (SCA) - Test/Add

SMCS Code: 1352-045; 1395-081

Note: This procedure is NOT required for applications that use Cat Extended Life Coolant (ELC).

NOTICE

Cooling system coolant additive contains alkali. To help prevent personal injury, avoid contact with the skin and the eyes. Do not drink cooling system coolant additive.

Note: Test the Supplemental Coolant Additive (SCA) or test the SCA concentration as part of an S-O-S Coolant Analysis.

Test the SCA Concentration

Coolant, Antifreeze and SCA

NOTICE

Do not exceed the recommended six percent supplemental coolant additive concentration.

WARNING

Cooling system coolant additive contains alkali. To help prevent personal injury, avoid contact with the skin and the eyes. Do not drink cooling system coolant additive.

Use the 4C-9301 Coolant Conditioner Test Kit in order to check the concentration of the SCA. Refer to the Special Publication, SEBU6385, "Caterpillar On-highway Diesel Engine Fluid Recommendations" for more information.

Add the SCA, If Necessary

NOTICE

Do not exceed the recommended amount of supplemental coolant additive concentration. Excessive supplemental coolant additive concentration can form deposits on the higher temperature surfaces of the cooling system, reducing the engine's heat transfer characteristics. Reduced heat transfer could cause cracking of the cylinder head and other high temperature components. Excessive supplemental coolant additive concentration could also result in radiator tube blockage, overheating, and/or accelerated water pump seal wear. Never use both liquid supplemental coolant additive and the spin-on element (if equipped) at the same time. The use of those additives together could result in supplemental coolant additive concentration exceeding the recommended maximum.

 **WARNING**

Pressurized System: Hot coolant can cause serious burns. To open the cooling system filler cap, stop the engine and wait until the cooling system components are cool. Loosen the cooling system pressure cap slowly in order to relieve the pressure.

Follow the instructions that are provided by the OEM or follow the instructions that are provided by the manufacturer of the coolant conditioner element on engines that are equipped with a coolant conditioner element.

1. Slowly loosen the cooling system filler cap in order to relieve the pressure. Remove the cooling system filler cap.

Note: Always discard drained fluids according to local regulations.

2. If necessary, drain some coolant from the cooling system into a suitable container in order to allow space for the extra SCA.
3. Add the proper amount of SCA. Refer to Special Publication, SEBU6385, "Caterpillar On-highway Diesel Truck Engine Fluid Recommendations" for more information on SCA requirements.
4. Clean the cooling system filler cap. Inspect the gaskets of the cooling system filler cap. If the gaskets are damaged, replace the old cooling system filler cap with a new cooling system filler cap. Install the cooling system filler cap.

i02623972

Cooling System Water Temperature Regulator - Replace

SMCS Code: 1355-510

Replace the water temperature regulator before the water temperature regulator fails. This is a recommended preventive maintenance practice. Replacing the water temperature regulator reduces the chances for unscheduled downtime.

A water temperature regulator that fails in a partially opened position can cause overheating or overcooling of the engine.

A water temperature regulator that fails in the closed position can cause excessive overheating. Excessive overheating could result in cracking of the cylinder head or piston seizure problems.

A water temperature regulator that fails in the open position will cause the engine operating temperature to be too low during partial load operation. Low engine operating temperatures during partial loads could cause an excessive carbon buildup inside the cylinders. This excessive carbon buildup could result in an accelerated wear of the piston rings and wear of the cylinder liner.

NOTICE

Failure to replace your water temperature regulator on a regularly scheduled basis could cause severe engine damage.

Caterpillar engines incorporate a shunt design cooling system and require operating the engine with a water temperature regulator installed.

If the water temperature regulator is installed incorrectly, the engine may overheat, causing cylinder head damage. Ensure that the new water temperature regulator is installed in the original position. Ensure that the water temperature regulator vent hole is open.

Do not use liquid gasket material on the gasket or cylinder head surface.

Refer to two articles in the Disassembly and Assembly Manual, "Water Temperature Regulators - Remove and Water Temperature Regulators - Install" for the replacement procedure of the water temperature regulator, or consult your Caterpillar dealer.

Note: If only the water temperature regulators are replaced, drain the coolant from the cooling system to a level that is below the water temperature regulator housing.

i03604133

Crankshaft End Play - Test

SMCS Code: 1202-081-EP

S/N: KCA1-Up

S/N: KCB1-Up

S/N: JAM1-Up

Note: This maintenance is for an engine that is coupled to a transmission which uses a single plate clutch.

Note: Refer to this Operation and Maintenance Manual, "Severe Service Application - Check" in order to determine the operating conditions for the engine. This maintenance procedure should be completed at the following intervals:

- Every oil change for an engine which operates in a severe service application
- Alternate oil changes (every other oil change) for an engine which operates in normal conditions

Do not perform this maintenance and do not order any parts until the entire instruction has been read and understood.

Follow the procedure that is listed below in order to check the end play of the crankshaft without removing the engine. The current specification for crankshaft end play is 0.1 mm (0.00394 inch) to 0.5 mm (0.01969 inch).

1. Bleed the system pressure from the transmission. This is necessary for an accurate reading of the crankshaft's end play.

Note: Refer to the transmission manufacturer's instruction manual for more information on this procedure.

2. Place a dial gauge on the end of the crankshaft pulley in order to check the end play. Zero the dial gauge in order to get an accurate reading.
3. Use a prybar and use a wood block to move the crankshaft. The block of wood should be placed between the prybar and the vibration damper. The block of wood is used to protect the vibration damper from getting punctured. Move the crankshaft and observe the dial gauge.
4. Inspect the thrust bearing if the end play is greater than 0.5 mm (0.01969 inch).
5. If the end play is greater than the maximum specification, the 246-3144 Thrust Plate should be replaced.

Reference: Disassembly and Assembly, "Crankshaft Main Bearings Remove" Disassembly and Assembly, "Crankshaft Main Bearings Install"

6. Use a surface finish comparator in order to determine the reusability. Measure the surface finish. If the surface finish is less than 0.40 RA the crankshaft can be reused.
7. If a comparator is not available, visually inspect the crankshaft's bearing surfaces. Check the bearing's surface for scuffing or check the bearing's surface for the transfer of material.
8. Replace the crankshaft if any obvious signs of scuffing or transfer of material is found.

Reference: Disassembly and Assembly, "Crankshaft Removal" Disassembly and Assembly, "Crankshaft Installation"

Whenever questions arise about this maintenance, consult the local Caterpillar dealer for the latest available information.

i02933380

Crankshaft Vibration Damper - Inspect

SMCS Code: 1205-040

Damage to the crankshaft vibration damper or failure of the crankshaft vibration damper can increase torsional vibrations. This can result in damage to the crankshaft and to other engine components. A damper that is damaged can cause excessive gear train noise at variable points in the speed range.

The damper is mounted to the crankshaft which is located behind the belt guard on the front of the engine.

Visconic Damper

The visconic damper has a weight that is located inside a fluid filled case. The weight moves in the case in order to limit torsional vibration.

Inspect the damper for evidence of fluid leaks. If a fluid leak is found, determine the type of fluid. The fluid in the damper is silicone. Silicone has the following characteristics: transparent, viscous, smooth, and adhering.

If the fluid leak is oil, inspect the crankshaft seals for leaks. If a leak is observed, replace the crankshaft seals.

Inspect the damper and repair or replace the damper for any of the following reasons:

- The damper is dented, cracked, or leaking.
- The paint on the damper is discolored from heat.
- The engine has had a failure because of a broken crankshaft.
- Analysis of the oil has revealed that the front main bearing is badly worn.
- There is a large amount of gear train wear that is not caused by a lack of oil.

Refer to the Disassembly and Assembly Manual,
"Vibration Damper and Pulley - Remove and Install"
or consult your Caterpillar dealer for information
about damper replacement.

i01823226

Cylinder Head Grounding Stud - Inspect/Clean/Tighten

SMCS Code: 7423-040; 7423-070; 7423-079




Illustration 50

g00931100

C11 and C13 engines

(1) Cylinder head grounding stud




Illustration 51

g00931103

C15 Engine

(2) Cylinder head grounding stud

Inspect the OEM vehicle wiring harness for the following conditions:

- Connections that are loose or disconnected
- Mounting hardware that is missing
- Insulation that is chafed or cut
- Wires that are bare

The cylinder head grounding stud must have a wire ground to the battery. Tighten the cylinder head grounding stud at every oil change. Ground wires and straps should be combined at engine grounds. All grounds should be tight and free of corrosion.

1. Clean the cylinder head grounding stud and the terminals for the cylinder head ground strap with a clean cloth.
2. If the connections are corroded, clean the connections with a solution of baking soda and water.
3. Keep the cylinder head grounding stud and the strap clean and coated with MPGM grease or petroleum jelly.

i02070777

Electronic Unit Injector - Inspect/Adjust

SMCS Code: 1251-025; 1251-040; 1290-025; 1290-040

WARNING

Be sure the engine cannot be started while this maintenance is being performed. To prevent possible injury, do not use the starting motor to turn the flywheel.

Hot engine components can cause burns. Allow additional time for the engine to cool before measuring/adjusting the unit injectors.

The electronic unit injectors use high voltage. Disconnect the unit injector enable circuit connector in order to prevent personal injury. Do not come in contact with the injector terminals while the engine is running.

The operation of Caterpillar engines with improper adjustments of the electronic unit injector can reduce engine efficiency. This reduced efficiency could result in excessive fuel usage and/or shortened engine component life.

Only qualified service personnel should perform this maintenance. Refer to the following topics for your engine for the correct procedure: Refer to the Systems Operation, Testing and Adjusting, "Electronic Unit Injector - Test" for the test procedure, and Systems Operation, Testing and Adjusting, "Electronic Unit Injector - Adjust" for the correct procedure for adjusting the injectors.

NOTICE

The camshafts must be correctly timed with the crankshaft before an adjustment of the lash for the fuel injector is made. The timing pins must be removed from the camshafts before the crankshaft is turned or damage to the cylinder block will be the result.

i01646701

Engine - Clean

SMCS Code: 1000-070

WARNING

Personal injury or death can result from high voltage.

Moisture can create paths of electrical conductivity.

Make sure that the electrical system is OFF. Lock out the starting controls and tag the controls "DO NOT OPERATE".

NOTICE

Accumulated grease and oil on an engine is a fire hazard. Keep the engine clean. Remove debris and fluid spills whenever a significant quantity accumulates on the engine.

Periodic cleaning of the engine is recommended. Steam cleaning the engine will remove accumulated oil and grease. A clean engine provides the following benefits:

- Easy detection of fluid leaks
- Maximum heat transfer characteristics
- Ease of maintenance

Note: Caution must be used in order to prevent electrical components from being damaged by excessive water when you clean the engine. Avoid electrical components such as the alternator, the starter, and the ECM.

i00857000

Engine Air Cleaner Element - Clean/Replace

SMCS Code: 1054-070; 1054-510

NOTICE

Never service the air cleaner element with the engine running since this will allow dirt to enter the engine.

If the air cleaner element becomes plugged, the air can split the material of the air cleaner element. Unfiltered air will drastically accelerate internal engine wear.

- Operating conditions (dust, dirt and debris) may require more frequent service of the air cleaner element.
- The air cleaner element should be replaced at least one time per year. This replacement should be performed regardless of the number of cleanings.

Replace the dirty paper air cleaner elements with clean air cleaner elements. Before installation, the air cleaner elements should be thoroughly checked for tears and/or holes in the filter material. Inspect the gasket or the seal of the air cleaner element for damage. Maintain a supply of suitable air cleaner elements for replacement purposes.

Your Caterpillar dealer has the proper air cleaner elements for your application. Consult your Caterpillar dealer for the correct air cleaner element or follow the instructions that are provided by the OEM.

i01900118

Engine Air Cleaner Service Indicator - Inspect (If Equipped)

SMCS Code: 7452-040

Some engines may be equipped with a different service indicator.

Some engines are equipped with a differential gauge for inlet air pressure. The differential gauge for inlet air pressure displays the difference in the pressure that is measured before the air cleaner element and the pressure that is measured after the air cleaner element. As the air cleaner element becomes dirty, the pressure differential rises. If your engine is equipped with a different type of service indicator, follow the OEM recommendations in order to service the air cleaner service indicator.

The service indicator may be mounted on the air cleaner housing or in a remote location.




Illustration 52

g00103777

Typical service indicator

Observe the service indicator. The air cleaner element should be cleaned or the air cleaner element should be replaced when one of the following conditions occur:

- The yellow diaphragm enters the red zone.
- The red piston locks in the visible position.

Test the Service Indicator

Service indicators are important instruments.

- Check for ease of resetting. The service indicator should reset in less than three pushes.
- Check the movement of the yellow core when the engine is accelerated to the engine rated speed. The yellow core should latch approximately at the greatest vacuum that is attained.

If the service indicator does not reset easily, or if the yellow core does not latch at the greatest vacuum, the service indicator should be replaced. If the new service indicator will not reset, the hole for the service indicator may be plugged.

The service indicator may need to be replaced frequently in environments that are severely dusty, if necessary. Replace the service indicator annually regardless of the operating conditions. Replace the service indicator when the engine is overhauled, and whenever major engine components are replaced.

Note: When a new service indicator is installed, excessive force may crack the top of the service indicator. Tighten the service indicator to a torque of 2 N·m (18 lb in).

i03018600

Engine Crankcase Breather - Clean

SMCS Code: 1317-070

NOTICE

Perform this maintenance with the engine stopped.

If the crankcase breather is not maintained on a regular basis, the crankcase breather will become plugged. A plugged crankcase breather will cause excessive crankcase pressure that may cause crankshaft seal leakage.

Your engine will have one of the following engine crankcase breathers.

Type 1




Illustration 53

g01136454

Typical example

1. Loosen hose clamp (1) and remove the hose from breather assembly (2).
2. Loosen retaining clamp (3). Remove the breather assembly and seal (4).
3. Wash the breather element in solvent that is clean and nonflammable. Allow the breather element to dry before installation.
4. Install a breather element that is clean and dry. Install the seal, the breather assembly, and the clamp. Refer to the Specifications, SENR3130 in order to locate the proper torques.
5. Install the hose. Install the hose clamp. Refer to Specifications, SENR3130 in order to locate the proper torques.

Type 2




Illustration 54

g01445780

1. Loosen hose clamp (5) and remove hose (6) from valve cover (7).
2. Remove valve cover (7). Refer to the Disassembly and Assembly Manual for instructions on removing the valve cover..




Illustration 55

g01445781

3. Wash breather (8) in solvent that is clean and nonflammable. Allow the breather to dry before installation.
4. Install a breather element that is clean and dry.
5. Install valve cover (7). Refer to the Disassembly and Assembly Manual for instructions on installing the valve cover. Refer to Specifications, SENR3130 in order to locate the proper torques.
6. Install hose (6) on valve cover (7). Install hose clamp (5). Refer to Specifications, SENR3130 in order to locate the proper torques.

i02126741

Engine Oil Level - Check

SMCS Code: 1348-535-FLV

WARNING

Hot oil and hot components can cause personal injury. Do not allow hot oil or hot components to contact the skin.

Note: The location of the oil level gauge and the oil filler cap will vary with the truck model.




Illustration 56

g00110310

(Y) "ADD" mark
(X) "FULL" mark

NOTICE

Perform this maintenance with the engine stopped.

1. Maintain the oil level between "ADD" mark (Y) and "FULL" mark (X) on the oil level gauge. Do not fill the crankcase above "FULL" mark (X).

NOTICE

Engine damage can occur if the crankcase is filled above the "FULL" mark on the oil level gauge (dipstick).

An overfull crankcase can cause the crankshaft to dip into the oil. This will reduce the power that is developed and also force air bubbles into the oil. These bubbles (foam) can cause the following problems: reduction of the oil's ability to lubricate, reduction of oil pressure, inadequate cooling, oil blowing out of the crankcase breathers, and excessive oil consumption.

Excessive oil consumption will cause deposits to form on the pistons and in the combustion chamber. Deposits in the combustion chamber lead to the following problems: guttering of the valves, packing of carbon under the piston rings, and wear of the cylinder liner.

If the oil level is above the "FULL" mark on the oil level gauge, drain some of the oil immediately.

2. Remove the oil filler cap and add oil, if necessary. For the correct oil to use, see this Operation and Maintenance Manual, "Refill Capacities and Recommendations" topic (Maintenance Section). Do not fill the crankcase above "FULL" mark (X) on the oil level gauge. Clean the oil filler cap. Install the oil filler cap.
3. Record the amount of oil that is added. For the next oil sample and analysis, include the total amount of oil that has been added since the previous sample. This will help to provide the most accurate oil analysis.

i02921153

Engine Oil Level Gauge - Calibrate

SMCS Code: 1326-524

Check the Calibration at the First Oil Change

Note: For Caterpillar C11 and for C13 On-highway Engines, determine whether the oil pan is shallow or deep by referring to this Operation and Maintenance Manual, "Refill Recommendations and Capacities". Caterpillar C15 On-highway Engines use standard (deep) oil pans.

The engine oil level will vary depending on the angle and the slant of the engine installation. The angle is the front to back tilt. The slant is the sideways tilt.

The oil level gauge markings must be verified in order to ensure that it is correct. Verify the oil level gauge markings at the first oil change.

Use the following procedure in order to verify the "ADD" mark and verify the "FULL" mark that is on the oil level gauge.

NOTICE

The vehicle must be parked on a level surface in order to perform this maintenance procedure.

NOTICE

Care must be taken to ensure that fluids are contained during performance of inspection, maintenance, testing, adjusting and repair of the product. Be prepared to collect the fluid with suitable containers before opening any compartment or disassembling any component containing fluids.

Refer to Special Publication, NENG2500, "Caterpillar Dealer Service Tool Catalog" or refer to Special Publication, PECJ0003, "Caterpillar Shop Supplies and Tools Catalog" for tools and supplies suitable to collect and contain fluids on Caterpillar products.

Dispose of all fluids according to local regulations and mandates.

1. Operate the engine until normal operating temperature is achieved. Stop the engine. Remove the crankcase oil drain plugs. The oil drain plug from the deep portion of the oil pan should be removed. The oil drain plug from the shallow portion of the oil pan should be removed. This will allow all of the oil to drain. Drain the oil from the crankcase for 20 minutes.
2. Remove the used oil filter(s). Install the new oil filter(s). Install the oil drain plugs and tighten to $70 \pm 15 \text{ N}\cdot\text{m}$ ($50 \pm 11 \text{ lb ft}$).

Your engine may be equipped with auxiliary oil filters. The auxiliary oil filters require a different volume of oil. Refer to the OEM specifications for the auxiliary oil filter.

3. Refer to table 32 in order to determine the correct amount of oil that should be poured into the crankcase. Pour the correct amount of oil into the crankcase.

Table 32

Engine	C11 or C13		C15
Oil pan	Shallow	Deep	Deep (Standard)
Quantity of oil	22.5 L (23.8 qt)	28.5 L (30.1 qt)	26.5 L (28 qt)

1. Allow enough time for the oil to drain into the crankcase. Approximately 20 minutes should be allowed. Check the oil level. Wait for several minutes and check the oil level again. Proceed after the oil level stops changing.
2. Check the oil level on the oil level gauge. The oil level should be at the "ADD" mark. If the oil level is not at the existing "ADD" mark, grind off the "ADD" mark and engrave the new "ADD" level.
3. Pour 5.7 L (6 qt) of oil into the crankcase. Allow enough time for the oil to drain into the crankcase.
4. Check the oil level on the oil level gauge. The oil level should be at the "FULL" mark. If the oil level is not at the existing "FULL" mark, grind off the "FULL" mark and engrave the new "FULL" mark.
5. Refer to table 33 in order to determine the correct amount of oil that should be poured into the crankcase. Pour the correct amount of oil into the crankcase.

Table 33

Engine	C11 or C13		C15
Oil Pan	Shallow	Deep	Deep (Standard)
Quantity of oil	3.5 L (3.7 qt)	3.5 L (3.7 qt)	5.5 L (5.8qt)

1. Start the engine and run the engine enough to ensure that the lubrication system is filled. Inspect the engine for oil leaks.
2. Stop the engine and allow enough time for the oil to drain into the crankcase.
3. Check the oil level on the oil level gauge. If the oil level is not at the calibrated "FULL" mark, fill the crankcase to the calibrated "FULL" mark. Include the oil that was added in order to raise the level of oil to the "FULL" mark and record the oil capacity of the lubrication system for future oil changes.

i03542996

Engine Oil Sample - Obtain

SMCS Code: 1000-008; 1348-554-SM;
7542-554-OC, SM

In addition to a good preventive maintenance program, Caterpillar recommends using S·O·S oil analysis at regularly scheduled intervals in order to monitor the condition of the engine and the maintenance requirements of the engine. S·O·S oil analysis provides infrared analysis, which is required for determining nitration and oxidation levels.

Obtain the Sample and the Analysis

WARNING

Hot oil and hot components can cause personal injury. Do not allow hot oil or hot components to contact the skin.

Before you take the oil sample, complete the Label, PEEP5031 for identification of the sample. In order to help obtain the most accurate analysis, provide the following information:

- Engine model
- Service hours on the engine
- The number of hours that have accumulated since the last oil change
- The amount of oil that has been added since the last oil change

To ensure that the sample is representative of the oil in the crankcase, obtain a warm, well mixed oil sample.

To avoid contamination of the oil samples, the tools and the supplies that are used for obtaining oil samples must be clean.

Caterpillar recommends using the sampling valve in order to obtain oil samples. The quality and the consistency of the samples are better when the sampling valve is used. The location of the sampling valve allows oil that is flowing under pressure to be obtained during normal engine operation.

The 169-8373 Fluid Sampling Bottle is recommended for use with the sampling valve. The fluid sampling bottle includes the parts that are needed for obtaining oil samples. Instructions are also provided.

NOTICE

Always use a designated pump for oil sampling, and use a separate designated pump for coolant sampling. Using the same pump for both types of samples may contaminate the samples that are being drawn. This contaminate may cause a false analysis and an incorrect interpretation that could lead to concerns by both dealers and customers.

If the engine is not equipped with a sampling valve, use the 1U-5718 Vacuum Pump. The pump is designed to accept sampling bottles. Disposable tubing must be attached to the pump for insertion into the sump.

For instructions, see Special Publication, PEGj0047, "How To Take A Good S·O·S Oil Sample". Consult your Caterpillar dealer for complete information and assistance in establishing an S·O·S program for your engine.

i02812032

Engine Oil and Filter - Change

SMCS Code: 1318-510; 1348-044

WARNING

Hot oil and hot components can cause personal injury. Do not allow hot oil or hot components to contact the skin.

NOTICE

The vehicle must be parked on a level surface for this maintenance procedure.

Do not drain the engine oil when the engine is cold. As the engine oil cools, suspended waste particles settle on the bottom of the engine oil pan. The waste particles are not removed with the draining cold engine oil. Drain the crankcase while the engine is stopped. Drain the crankcase while the engine oil is warm. This draining method allows the waste particles that are suspended in the engine oil to be drained properly.

Failure to follow this recommended procedure will cause the waste particles to be recirculated through the engine lubrication system with the new engine oil.

NOTICE

Care must be taken to ensure that fluids are contained during performance of inspection, maintenance, testing, adjusting and repair of the product. Be prepared to collect the fluid with suitable containers before opening any compartment or disassembling any component containing fluids.

Refer to Special Publication, NENG2500, "Caterpillar Dealer Service Tool Catalog" or refer to Special Publication, PECJ0003, "Caterpillar Shop Supplies and Tools Catalog" for tools and supplies suitable to collect and contain fluids on Caterpillar products.

Dispose of all fluids according to local regulations and mandates.

Drain the Engine Oil

After the engine has been run at the normal operating temperature, stop the engine. Attach a "DO NOT OPERATE" or a similar warning tag to the ignition keyswitch before the engine is serviced. Use one of the following methods to drain the engine crankcase oil:

- If the engine is equipped with a drain valve, turn the drain valve knob counterclockwise in order to drain the engine oil. After the engine oil has drained, turn the drain valve knob clockwise in order to close the drain valve.
- If the engine is not equipped with a drain valve, remove the oil drain plug in order to allow the engine oil to drain. If the engine is equipped with a shallow sump, remove the bottom oil drain plugs from both ends of the engine oil pan.

After the engine oil has drained, the oil drain plugs should be cleaned and installed. Tighten the oil drain plugs to the proper torque. Refer to the Specifications Module, "Engine Oil Pan" topic for additional information.

Replace the Oil Filter

NOTICE

Caterpillar oil filters are built to Caterpillar specifications. Use of an oil filter not recommended by Caterpillar could result in severe engine damage to the engine bearings, crankshaft, etc., as a result of the larger waste particles from unfiltered oil entering the engine lubricating system. Only use oil filters recommended by Caterpillar.

1. Remove the oil filter with a 185-3630 Chain Wrench.
2. Cut the oil filter open with a 175-7546 Oil Filter Cutter. Break apart the pleats and inspect the oil filter for metal debris. An excessive amount of metal debris in the oil filter may indicate early wear or a pending failure.

Use a magnet to differentiate between the ferrous metals and the nonferrous metals that are found in the oil filter element. Ferrous metals may indicate wear on the steel and cast iron parts of the engine.

Nonferrous metals may indicate wear on the aluminum parts, brass parts or bronze parts of the engine. Parts that may be affected include the following items: main bearings, rod bearings, turbocharger bearings, and cylinder heads.

Due to normal wear and friction, it is not uncommon to find small amounts of debris in the oil filter. Consult your Caterpillar dealer in order to arrange for a further analysis if an excessive amount of debris is found in the oil filter.




Illustration 57

g00103713

3. Clean the sealing surface of the filter mounting base. Ensure that all of the old oil filter gasket is removed.
4. Apply clean engine oil to the new oil filter gasket.

NOTICE

Do not fill the oil filters with oil before installing them. This oil would not be filtered and could be contaminated. Contaminated oil can cause accelerated wear to engine components.

5. Install the new oil filter. Tighten the oil filter until the oil filter gasket contacts the base. Tighten the oil filter by hand according to the instructions that are shown on the oil filter. Do not overtighten the oil filter.

Fill the Engine Crankcase

1. Remove the oil filler cap. Refer to the Operation and Maintenance Manual, "Refill Capacities and Recommendations" topic for more information about: selecting the correct engine oil and finding the correct refill capacity for your engine. Fill the crankcase with the proper amount of engine oil.

NOTICE

If equipped with an auxiliary oil filter or system, extra oil must be added when filling the crankcase. Follow the OEM or filter manufacturer's recommendations. If the extra oil is not added, the engine may starve for oil.

NOTICE

To help prevent crankshaft or bearing damage, crank engine to fill all filters before starting. Do not crank engine for more than 30 seconds.

2. Start the engine and run the engine at "LOW IDLE" for two minutes. Perform this procedure in order to ensure that the lubrication system has oil and that the oil filters are filled. Inspect the oil filter for oil leaks.
3. Stop the engine and allow the oil to drain back to the sump for a minimum of ten minutes.
4. Remove the oil level gauge in order to check the oil level. Maintain the oil level between the "ADD" and "FULL" marks on the oil level gauge.
5. Remove the "DO NOT OPERATE" tag from the ignition keyswitch.

Adjustments to the Oil Change Intervals

Many conditions affect the selection of an oil change interval. Proper oil change intervals are important for maintaining engine service life and engine performance and fully utilizing the lubricant. The engine oil must be able to control the following items: corrosion, oxidation, soot, and wear metals. The engine oil must be able to control the conditions during the time between oil changes.

In some severe service applications, reducing the oil change interval may be necessary in order to maintain the integrity of the engine lubricant. Refer to this Operation and Maintenance Manual, "Severe Service Operation - Check" or consult with your Cat dealer in order to determine whether your engine is operating under severe service conditions.

Fuel consumption and oil consumption are the most important factors that are used in order to calculate an oil change interval. All engines do not consume fuel and oil at the same rate due to several factors: manufacturing tolerances, maintenance variations, and engine application.

Extended Oil Change Intervals

Requirements for Use of Extended Oil Change Intervals

The following requirements must be met in order to use Tables 34, 35, and 36:

- Cat DEO-ULS is used or an oil that meets the requirements of the Caterpillar ECF-3 (Engine Crankcase Fluid specification-3) specification is used.

- S·O·S Services oil analysis is performed at 16,100 km (10,000 mile) intervals and all oil change intervals. The S·O·S Services lab must be notified of the extended oil change interval. The use of an extended oil change interval makes a difference in the interpretation of the data.
- A Cat High Efficiency Fuel Filter is used.
- Fuel with 0.05% (500 ppm) or less sulfur is used.

NOTICE

Contact your Caterpillar dealer for more information about extended oil change intervals.

Note: Caterpillar cannot guarantee the performance of lubricants or filters that are not sold by Caterpillar. The performance guarantee of any commercially available lubricant is the responsibility of that oil company. The performance guarantee of any commercially available filter is the responsibility of the filter manufacturer.

Tables for Extended Oil Change Intervals

In order to understand the tables for maximum permissible oil change intervals, use the following procedures.

1. Determine the average fuel consumption of the vehicle.
2. Determine the gross vehicle weight (GVW) of the vehicle.
3. Determine the percent of idle time for the vehicle. A download of the histogram data from the ECM can provide a more accurate "percent idle time" measurement. Contact your nearest Caterpillar dealer for information on obtaining data from the ECM.
4. The intersection of the column and the row lists the maximum number of kilometers or miles between oil change intervals.

For example, a C13 Engine with an average fuel consumption of 3 km/L (7 mpg) in a light-duty application will have a maximum permissible oil change interval of 40,250 kilometers (25,000 miles) with a shallow oil sump. The maximum permissible oil change interval for the same situation with a Deep oil sump would be 64,350 km (40,000 miles).

Table 34

Maximum Permissible Oil Change Intervals for C11 and C13 On-highway Engines with Shallow Sumps and 500 HP Field Up-rates and 525 HP RV Ratings			
	Severe Duty	Normal Duty	Light Duty
Fuel Consumption Kilometers Per Liter (Miles Per Gallon)	Less than 2.6 km/L (6 MPG)	2.6 km/L (6 MPG) to 3 km/L (7 MPG)	Greater than 3 km/L (7 MPG)
Gross Vehicle Weight	More than 36287 kg (80000 lb)	36287 kg (80000 lb) or less	36287 kg (80000 lb) or less
Minimum Oil Sump Capacity⁽¹⁾	31.7 L (33.5 qt)	31.7 L (33.5 qt)	31.7 L (33.5 qt)
Idle Time	More than 40%	20% to 40%	Less than 20%
Oil Classification	Cat DEO-ULS or an oil that meets the requirements of the Caterpillar ECF-3 specification		
Kilometers (Miles)	24,150 kilometers (15,000 miles)	32,200 kilometers (20,000 miles)	40,250 kilometers (25,000 miles)

(1) If the oil sump capacity is greater than the oil sump capacity that is listed in Table 35, the oil change interval can be extended 1600 kilometers (1000 miles) for every 2 L (2 qt) increase in oil sump capacity.

Table 35

Maximum Permissible Oil Change Intervals for C11 and C13 On-highway Engines with Deep Sumps (Standard)			
	Severe Duty	Normal Duty	Light Duty
Fuel Consumption Kilometers Per Liter (Miles Per Gallon)	Less than 2.6 km/L (6 MPG)	2.6 km/L (6 MPG) to 3 km/L (7 MPG)	Greater than 3 km/L (7 MPG)
Gross Vehicle Weight	More than 36287 kg (80000 lb)	36287 kg (80000 lb) or less	36287 kg (80000 lb) or less
Minimum Oil Sump Capacity⁽¹⁾	37.7 L (39.8 qt)	37.7 L (39.8 qt)	37.7 L (39.8 qt)
Idle Time	More than 40%	20% to 40%	Less than 20%
Oil Classification	Cat DEO-ULS or an oil that meets the requirements of the Caterpillar ECF-3 specification		
Kilometers (Miles)	32,200 kilometers (20,000 miles)	48,300 kilometers (30,000 miles)	64,350 kilometers (40,000 miles)

(1) If the oil sump capacity is greater than the oil sump capacity that is listed in Table 35, the oil change interval can be extended 1600 kilometers (1000 miles) for every 2 L (2 qt) increase in oil sump capacity.

Table 36

Maximum Permissible Oil Change Intervals for C15 On-highway Engines with Deep Sumps (Standard)			
	Severe Duty	Normal Duty	Light Duty
Fuel Consumption Kilometers Per Liter (Miles Per Gallon)	Less than 2.3 km/L (5.5 MPG)	2.3 km/L (5.5 MPG) to 2.8 km/L (6.5 MPG)	Greater than 2.8 km/L (6.5 MPG)
Gross Vehicle Weight	More than 36287 kg (80000 lb)	36287 kg (80000 lb) or less	36287 kg (80000 lb) or less
Minimum Oil Sump Capacity⁽¹⁾	37.7 L (39.8 qt)	37.7 L (39.8 qt)	37.7 L (39.8 qt)
Idle Time	More than 40%	20% to 40%	Less than 20%
Oil Classification	Cat DEO-ULS or an oil that meets the requirements of the Caterpillar ECF-3 specification		
Kilometers (Miles)	32,200 kilometers (20,000 miles)	48,300 kilometers (30,000 miles)	64,350 kilometers (40,000 miles)

(1) If the oil sump capacity is greater than the oil sump capacity that is listed in Table 35, the oil change interval can be extended 1600 kilometers (1000 miles) for every 2 L (2 qt) increase in oil sump capacity.

i03011879

Engine Valve Lash - Inspect/Adjust

SMCS Code: 1102-025

The initial valve lash adjustment on new engines, rebuilt engines, or remanufactured engines is recommended at the first scheduled oil change. The adjustment is necessary due to the initial wear of the valve train components and to the seating of the valve train components.

This maintenance is recommended by Caterpillar as part of a lubrication and preventive maintenance schedule in order to help provide maximum engine life.

NOTICE

Only qualified service personnel should perform this maintenance. Refer to the Systems Operation/Testing and Adjusting Manual, "Valve Lash and Valve Bridge Adjustment" article or consult your Caterpillar dealer for the complete valve lash adjustment procedure.

Operation of Caterpillar engines with improper valve adjustments can reduce engine efficiency. This reduced efficiency could result in excessive fuel usage and/or shortened engine component life.

WARNING

Ensure that the engine can not be started while this maintenance is being performed. To help prevent possible injury, do not use the starting motor to turn the flywheel.

Hot engine components can cause burns. Allow additional time for the engine to cool before measuring/adjusting valve lash clearance.

Ensure that the engine is stopped before measuring the valve lash. To obtain an accurate measurement, allow the valves to cool before this maintenance is performed.

The following components should be inspected and adjusted when the valves are inspected and adjusted.

- Valve actuators
- Injectors
- Compression brakes

Refer to Systems Operations Testing and Adjusting, "Engine Valve Lash - Inspect/Adjust" for more information.

i01771215

Fan Drive Bearing - Lubricate

SMCS Code: 1359-086-BD




Illustration 58

g00746166

Typical location of the grease fitting that is for the fan drive bearing
The belt guards have been removed in this illustration.

Note: In some applications, the fan drives are supplied by the OEM. Refer to the OEM specifications if the fan drive is not supplied by Caterpillar.

Lubricate the grease fitting that is on the fan drive bearing with Bearing Lubricant or the equivalent.

Inspect the fan drive pulley assembly for wear or for damage. If the shaft is loose, an inspection of the internal components should be performed. Refer to the Service Manual for additional information.

i03086300

Fuel System - Prime

SMCS Code: 1258-548

WARNING

Fuel leaked or spilled onto hot surfaces or electrical components can cause a fire. To help prevent possible injury, turn the start switch off when changing fuel filters or water separator elements. Clean up fuel spills immediately.

NOTICE

Care must be taken to ensure that fluids are contained during performance of inspection, maintenance, testing, adjusting and repair of the product. Be prepared to collect the fluid with suitable containers before opening any compartment or disassembling any component containing fluids.

Refer to Special Publication, NENG2500, "Caterpillar Dealer Service Tool Catalog" or refer to Special Publication, PECJ0003, "Caterpillar Shop Supplies and Tools Catalog" for tools and supplies suitable to collect and contain fluids on Caterpillar products.

Dispose of all fluids according to local regulations and mandates.

NOTICE

Do not allow dirt to enter the fuel system. Thoroughly clean the area around a fuel system component that will be disconnected. Fit a suitable cover over disconnected fuel system component.

NOTICE

Do not crank the engine for more than 30 seconds. Allow the starting motor to cool for two minutes before cranking again.




Illustration 59

g01568053

C11 and C13 On-highway Engines

- (1) Fuel priming pump
- (2) Air purge screw
- (3) Priming valve (If equipped)




Illustration 60

g01568054

C15 On-highway Engines

- (1) Fuel priming pump
- (2) Air purge screw
- (3) Priming valve (If equipped)

The engine may need to be primed in the following circumstances:

- The engine runs out of fuel.
- The secondary fuel filter is replaced.

If the engine runs out of fuel, take the following steps before you prime the engine:

1. Turn the ignition to the OFF position.
2. Fill the fuel tank with clean diesel fuel.

Note: Refer to Operation and Maintenance Manual, "Fuel System Secondary Filter - Replace" for information on replacing the filter.

Using the Engine to Prime the Fuel System

1. Turn the ignition switch to the OFF position.
2. Unlock the fuel priming pump (if equipped) by turning the cap counterclockwise.
3. Purging air from the fuel system requires the air purge screw to be opened. Turn the air purge screw counterclockwise by three full turns. Do not remove the screw.
4. Turn the ignition switch to the ON position.
5. Crank the engine for 30 seconds. Use a suitable container to catch the fuel while you crank the engine. Allow the starting motor to cool for two minutes.

Note: Most of the air should be purged from the system after four or five cranking cycles.

6. Repeat Step 5 until the engine starts and runs. If the engine runs rough, continue to operate the engine at low idle until the engine runs smoothly.
7. Observe the air purge screw. When a small drop of fuel appears at the threads of the air purge screw, close the air purge screw. After the air purge screw is closed, tighten the air purge screw. Refer to Specifications, SENR3130 for the correct torque.

Note: Failure to tighten the screw could result in serious fuel leaks.

8. After the engine has operated smoothly for 30 seconds, turn the priming valve to the LOCK position.

Note: The life of the injectors may be shortened if the priming valve is left in the unlocked position.

9. Clean any residual fuel from the engine components.
10. Once the engine runs smoothly, stop the engine. Turn the ignition switch to the OFF position.

Using the Fuel Priming Pump (If Equipped) to Prime the Fuel System

1. Turn the ignition to the OFF position.
2. Unlock the priming pump by turning the cap counterclockwise.
3. Purging air from the fuel system requires the air purge screw to be opened three full turns. Open the air purge screw. Do not remove the screw.
4. Continue to operate the fuel priming pump until a strong resistance is felt. Listen for an audible click from the fuel manifold. The click will indicate that the valve has opened and the fuel system is pressurized. Lock the fuel priming pump.

Note: The life of the injectors may be shortened if the priming valve is left in the unlocked position.

5. Turn the ignition to the ON position.
6. Crank the engine. If the engine starts but the engine runs rough, continue to operate the engine at low idle until the engine runs smoothly.

Note: If the engine will not start, further priming is necessary. If the engine starts but the engine continues to misfire, further priming is necessary.

7. Observe the air purge screw. When a small drop of fuel appears at the threads of the air purge screw, close the air purge screw. After the air purge screw is closed, tighten the air purge screw. Refer to Specifications, SENR3130 for the correct torque.

Note: Failure to tighten the screw could result in serious fuel leaks.

8. Clean any residual fuel from the engine components.
9. Once the engine runs smoothly, stop the engine. Turn the ignition switch to the OFF position.

i03017559

Fuel System Primary Filter - Replace

SMCS Code: 1260-510

WARNING

Fuel leaked or spilled onto hot surfaces or electrical components can cause a fire. To help prevent possible injury, turn the start switch off when changing fuel filters or water separator elements. Clean up fuel spills immediately.

NOTICE

Do not allow dirt to enter the fuel system. Thoroughly clean the area around a fuel system component that will be disconnected. Fit a suitable cover over any disconnected fuel system components.

NOTICE

Care must be taken to ensure that fluids are contained during performance of inspection, maintenance, testing, adjusting and repair of the product. Be prepared to collect the fluid with suitable containers before opening any compartment or disassembling any component containing fluids.

Refer to Special Publication, NENG2500, "Caterpillar Dealer Service Tool Catalog" or refer to Special Publication, PECJ0003, "Caterpillar Shop Supplies and Tools Catalog" for tools and supplies suitable to collect and contain fluids on Caterpillar products.

Dispose of all fluids according to local regulations and mandates.

Note: Caterpillar requires the filtration of all fuels through a primary fuel filter that has a rating of no less than ten microns(c) absolute and no more than 15 microns(c) absolute.

For information on the maintenance of the primary fuel filter, refer to the literature that is provided by the OEM of the vehicle.

i03017560

Fuel System Secondary Filter - Replace

SMCS Code: 1261-510-SE

WARNING

Fuel leaked or spilled onto hot surfaces or electrical components can cause a fire. To help prevent possible injury, turn the start switch off when changing fuel filters or water separator elements. Clean up fuel spills immediately.

NOTICE

Do not allow dirt to enter the fuel system. Thoroughly clean the area around a fuel system component that will be disconnected. Fit a suitable cover over any disconnected fuel system components.

NOTICE

Care must be taken to ensure that fluids are contained during performance of inspection, maintenance, testing, adjusting and repair of the product. Be prepared to collect the fluid with suitable containers before opening any compartment or disassembling any component containing fluids.

Refer to Special Publication, NENG2500, "Caterpillar Dealer Service Tool Catalog" or refer to Special Publication, PECJ0003, "Caterpillar Shop Supplies and Tools Catalog" for tools and supplies suitable to collect and contain fluids on Caterpillar products.

Dispose of all fluids according to local regulations and mandates.

1. Stop the engine. Turn the ignition switch to the OFF position or disconnect the battery. Refer to the Operation and Maintenance Manual, "Battery or Battery Cable - Disconnect" topic (Maintenance Section) for more information. Shut off the fuel supply valve (if equipped).




Illustration 61

g01269066

(1) Air purge fitting

2. In order to relieve fuel pressure, turn the air purge fitting counterclockwise by three full turns. Do not remove the fitting.
3. Remove the used fuel filter and discard the used fuel filter.
4. Close the air purge fitting. Refer to Special Publication, SENR3130, "Torque Specifications" for the proper torque.
5. Clean the gasket sealing surface of the fuel filter base. Ensure that all of the old gasket is removed. Apply clean diesel fuel to the new fuel filter gasket.

NOTICE

Caterpillar requires the use of a 4 micron(c) absolute high efficiency secondary fuel filter.

NOTICE

Do not fill the secondary fuel filter with fuel before installing. The fuel would not be filtered and could be contaminated. Contaminated fuel will cause accelerated wear to fuel system parts.

6. Install the new fuel filter. Spin the fuel filter onto the fuel filter base until the gasket contacts the base. Instructions for the installation of the filter are printed on the side of each Caterpillar spin-on filter. For non-Caterpillar filters, refer to the installation instructions that are provided by the supplier of the filter.
7. Open the fuel supply valve. Turn the ignition switch to the ON position or reconnect the battery. Open the fuel supply valve (if equipped).
8. Prime the fuel system. Refer to the Operation and Maintenance Manual, "Fuel System - Prime" topic (Maintenance Section) for more information. Start the engine and inspect the fuel system for leaks.

NOTICE

Do not crank the engine continuously for more than 30 seconds. Allow the starting motor to cool for two minutes before cranking the engine again.

i02919528

Fuel System Water Separator - Inspect/Drain (If equipped)

SMCS Code: 1263**NOTICE**

Care must be taken to ensure that fluids are contained during performance of inspection, maintenance, testing, adjusting and repair of the product. Be prepared to collect the fluid with suitable containers before opening any compartment or disassembling any component containing fluids.

Refer to Special Publication, NENG2500, "Caterpillar Dealer Service Tool Catalog" for tools and supplies suitable to collect and contain fluids on Caterpillar products.

Dispose of all fluids according to local regulations and mandates.

Your water separator may look like one of the following water separators.

Type 1




Illustration 62

g01451240

(1) Bowl

(2) Element

(3) Drain

The bowl should be monitored daily for signs of water. If water is present, drain the water from the bowl.

i03071053

1. Open the drain . The drain is a self-ventilated drain. Catch the draining water in a suitable container. Dispose of the water properly.

2. Close the drain.

NOTICE

The water separator is under suction during normal engine operation. Ensure that the drain valve is tightened securely to help prevent air from entering the fuel system.

Fuel Tank Water and Sediment - Drain

SMCS Code: 1273-543-M&S

NOTICE

Care must be taken to ensure that fluids are contained during performance of inspection, maintenance, testing, adjusting and repair of the product. Be prepared to collect the fluid with suitable containers before opening any compartment or disassembling any component containing fluids.

Refer to Special Publication, NENG2500, "Caterpillar Dealer Service Tool Catalog" or refer to Special Publication, PECJ0003, "Caterpillar Shop Supplies and Tools Catalog" for tools and supplies suitable to collect and contain fluids on Caterpillar products.

Dispose of all fluids according to local regulations and mandates.

Type 2




Illustration 63

g01451247

(4) Element

(5) Spring

(6) Drain

Compress the spring in order to drain the water from the filter. Catch the draining water in a suitable container. Dispose of the water properly.

Fuel Tank

Fuel quality is critical to the performance and to the service life of the engine. Water in the fuel can cause excessive wear to the fuel system. Condensation occurs during the heating and cooling of fuel. The condensation occurs as the fuel passes through the fuel system and the fuel returns to the fuel tank. This causes water to accumulate in fuel tanks. Draining the fuel tank regularly and obtaining fuel from reliable sources can help to eliminate water in the fuel.

Drain the Water and the Sediment

Fuel tanks should contain some provision for draining water and draining sediment from the bottom of the fuel tanks.

Open the drain valve on the bottom of the fuel tank in order to drain the water and the sediment. Close the drain valve.

Check the fuel daily. Drain the water and sediment from the fuel tank after operating the engine or drain the water and sediment from the fuel tank after the fuel tank has been filled. Allow five to ten minutes before performing this procedure.

Fill the fuel tank after operating the engine in order to drive out moist air. This will help prevent condensation. Do not fill the tank to the top. The fuel expands as the fuel gets warm. The tank may overflow.

Some fuel tanks use supply pipes that allow water and sediment to settle below the end of the fuel supply pipe. Some fuel tanks use supply lines that take fuel directly from the bottom of the tank. If the engine is equipped with this system, regular maintenance of the fuel system filter is important.

Fuel Storage Tanks

Drain the water and the sediment from the fuel storage tank during the following conditions:

- Weekly
- Oil change
- Refill of the tank

This will help prevent water or sediment from being pumped from the storage tank into the engine fuel tank. A four micron(c) absolute filter for the breather vent on the fuel tank is also recommended. Refer to Special Publication, SENR9620, "Improving Fuel System Durability".

If a bulk storage tank has been refilled or moved recently, allow adequate time for the sediment to settle before filling the engine fuel tank. Internal baffles in the bulk storage tank will also help trap sediment. Filtering fuel that is pumped from the storage tank helps to ensure the quality of the fuel. When possible, water separators should be used.

i02121526

Hoses and Clamps - Inspect/Replace

SMCS Code: 7554-040; 7554-510

Inspect all hoses for leaks that are caused by the following conditions:

- Cracking

- Softness
- Loose clamps

Replace hoses that are cracked or soft. Tighten any loose clamps.

NOTICE

Do not bend or strike high pressure lines. Do not install bent or damaged lines, tubes or hoses. Repair any loose or damaged fuel and oil lines, tubes and hoses. Leaks can cause fires. Inspect all lines, tubes and hoses carefully. Tighten all connections to the recommended torque.

Check for the following conditions:

- End fittings that are damaged or leaking
- Outer covering that is chafed or cut
- Exposed wire that is used for reinforcement
- Outer covering that is ballooning locally
- Flexible part of the hose that is kinked or crushed
- Armoring that is embedded in the outer covering

A constant torque hose clamp can be used in place of any standard hose clamp. Ensure that the constant torque hose clamp is the same size as the standard clamp.

Due to extreme temperature changes, the hose will heat set. Heat setting causes hose clamps to loosen. This can result in leaks. A constant torque hose clamp will help to prevent loose hose clamps.

Each installation application can be different. The differences depend on the following factors:

- Type of hose
- Type of fitting material
- Anticipated expansion and contraction of the hose
- Anticipated expansion and contraction of the fittings

Replace the Hoses and the Clamps

WARNING

Pressurized System: Hot coolant can cause serious burns. To open the cooling system filler cap, stop the engine and wait until the cooling system components are cool. Loosen the cooling system pressure cap slowly in order to relieve the pressure.

1. Stop the engine. Allow the engine to cool.
2. Loosen the cooling system filler cap slowly in order to relieve any pressure. Remove the cooling system filler cap.

Note: Drain the coolant into a suitable, clean container. The coolant can be reused.

3. Drain the coolant from the cooling system to a level that is below the hose that is being replaced.
4. Remove the hose clamps.
5. Disconnect the old hose.
6. Replace the old hose with a new hose.
7. Install the hose clamps with a torque wrench.

Note: Refer to the Specifications, SENR3130, "Torque Specifications" in order to locate the proper torques.

8. Refill the cooling system.
9. Clean the cooling system filler cap. Inspect the cooling system filler cap's gaskets. Replace the cooling system filler cap if the gaskets are damaged. Install the cooling system filler cap.
10. Start the engine. Inspect the cooling system for leaks.

i02559063

Radiator - Clean

SMCS Code: 1353-070

Note: Adjust the frequency of cleaning according to the effects of the operating environment.

Inspect the radiator for these items: damaged fins, corrosion, dirt, grease, insects, leaves, oil, and other debris. Clean the radiator, if necessary.

WARNING

Personal injury can result from air pressure.

Personal injury can result without following proper procedure. When using pressure air, wear a protective face shield and protective clothing.

The maximum air pressure for cleaning purposes must be reduced to 205 kPa (30 psi) when the air nozzle is deadheaded.

Pressurized air is the preferred method for removing loose debris. Direct the air in the opposite direction of the fan's air flow. Hold the nozzle approximately 6 mm (0.25 inch) away from the fins. Slowly move the air nozzle in a direction that is parallel with the tubes. This will remove debris that is between the tubes.

Pressurized water may also be used for cleaning. The maximum water pressure for cleaning purposes must be less than 275 kPa (40 psi). Use pressurized water in order to soften mud. Clean the core from both sides.

Use a degreaser and steam for removal of oil and grease. Clean both sides of the core. Wash the core with detergent and hot water. Thoroughly rinse the core with clean water.

After cleaning, start the engine and accelerate the engine to high idle rpm. This will help in the removal of debris and drying of the core. Stop the engine. Use a light bulb behind the core in order to inspect the core for cleanliness. Repeat the cleaning, if necessary.

Inspect the fins for damage. Bent fins may be opened with a "comb". Inspect these items for good condition: welds, mounting brackets, air lines, connections, clamps, and seals. Make repairs, if necessary.

For more detailed information on cleaning and inspection, refer to Special Publication, SEBD0518, "Know Your Cooling System".

i01357879

Severe Service Application - Check

SMCS Code: 1000-535

Operation and maintenance practices affect the service life of the components when the engine is operated in severe service applications.

The level of maintenance is crucial to the service life of the engine. Other major factors that affect service life are operating speed and loads.

The conditions that follow can indicate severe service operation:

- Operation above 36,320 kg (80,000 lb) gross vehicle weight (GVW) and other high load factor operations (such as off-highway)
- Frequent high altitude operation above 1525 m (5000 ft)
- Extended operation at low idle
- Arctic operation (regular cold starts at temperatures below -18°C (0°F))
- Extending maintenance beyond the recommended maintenance intervals
- Frequent hot shutdowns (minimum five minute cool down periods after high load factor operation)
- Use of fuels that are NOT recommended by Caterpillar in the Fuel Specifications
- Extreme ambient temperature conditions that may cause the lubricating properties of the fuel to diminish
- Frequent plugging of the fuel filter
- Extended maintenance intervals of the fuel system
- Inadequate maintenance of fuel storage tanks (excessive water, sediment, microorganism growth, etc.)

i01894393

Turbocharger - Inspect

SMCS Code: 1052-040; 1052

Periodic inspection and cleaning is recommended for the turbocharger compressor housing (inlet side).

If the turbocharger fails during engine operation, damage to the turbocharger compressor wheel and/or to the engine may occur. Damage to the turbocharger compressor wheel can cause additional damage to the pistons, the valves, and the cylinder head.

NOTICE

Turbocharger bearing failures can cause large quantities of oil to enter the air inlet and exhaust systems. Loss of engine lubricant can result in serious engine damage.

Minor leakage of a turbocharger housing under extended low idle operation should not cause problems as long as a turbocharger bearing failure has not occurred.

When a turbocharger bearing failure is accompanied by a significant engine performance loss (exhaust smoke or engine rpm up at no load), do not continue engine operation until the turbocharger is repaired or replaced.

A periodic inspection of the turbocharger can minimize unscheduled downtime and the chance for potential damage to other engine parts.

Note: Turbocharger components require precision clearances with proper balancing in order to support high operating speeds. Severe Service Applications can accelerate component wear. Therefore, more frequent inspections of the cartridge are required.

Removal and Installation

For options regarding the inspection, removal, installation, repair and replacement, consult your authorized Caterpillar service center. Refer to the Service Manual for this engine for the procedure and specifications.

i01848805

Valve Actuators - Inspect/Adjust

SMCS Code: 1105-025; 1105-040

The valve actuators should be inspected and adjusted when adjustments to the following components occur.

- Valves
- Injectors
- Compression brakes

Refer to the System Operation, Test and Adjust Manual for the proper adjustment procedure.

i02528180

Walk-Around Inspection

SMCS Code: 1000-040

A walk-around inspection should only take a few minutes. When the time is taken to perform these checks, costly repairs and accidents can be avoided.

NOTICE

Care must be taken to ensure that fluids are contained during performance of inspection, maintenance, testing, adjusting and repair of the product. Be prepared to collect the fluid with suitable containers before opening any compartment or disassembling any component containing fluids.

Refer to Special Publication, NENG2500, "Caterpillar Dealer Service Tool Catalog" for tools and supplies suitable to collect and contain fluids on Caterpillar products.

Dispose of all fluids according to local regulations and mandates.

NOTICE

For any type of leak (coolant, lube, or fuel) clean up the fluid. If leaking is observed, find the source and correct the leak. If leaking is suspected, check the fluid levels more often than recommended until the leak is found or fixed, or until the suspicion of a leak is proved to be unwarranted.

NOTICE

Accumulated grease and/or oil on an engine or deck is a fire hazard. Remove this debris with steam cleaning or high pressure water.

For maximum engine service life, make a thorough inspection of the engine compartment before starting the engine. Look for items such as oil leaks or coolant leaks, loose bolts, worn belts, loose connections and trash buildup. If it is necessary, make repairs or correct fluid levels.

- The guards must be in the proper place. Repair damaged guards or replace missing guards.
- Wipe all caps and plugs before the engine is serviced in order to reduce the chance of system contamination.
- Check the cooling system coolant level. Ensure that the cooling lines are properly clamped and that the cooling lines are tight. Check for leaks. Check the condition of all pipes.
- Inspect the water pumps for coolant leaks. The water pump seal is lubricated by coolant in the cooling system. It is normal for a small amount of leakage to occur as the engine cools down and the parts contract. Excessive coolant leakage may indicate the need to replace the water pump seal. For the removal of water pumps and the installation of water pumps and/or seals, refer to the Service Manual for the engine or consult your Caterpillar dealer.
- Check the engine oil level. Inspect the lubrication system for leaks at the front crankshaft seal, the rear crankshaft seal, the oil pan, the oil filters and the valve cover.
- Inspect the fuel system for leaks. Look for loose fuel line clamps or for loose tie-wraps around fuel lines.
- Check the water separator (if equipped) for water on a daily basis. Drain any water from the water separator. If necessary, drain the water and the sediment from fuel tanks in order to ensure that only clean fuel enters the fuel system.
- Inspect the piping for the air inlet system and the elbows for cracks and for loose clamps. Ensure that hoses and tubes are not contacting other hoses, tubes, wiring harnesses, etc. Check the air cleaner service indicator (if equipped).
- Inspect the alternator belt and the accessory drive belts for cracks, breaks or other damage. Belts for multiple groove pulleys must be replaced as matched sets. If only one belt is replaced, the belt will carry more load than the belts that are not replaced. The older belts are stretched. The additional load on the new belt could cause the belt to break.
- Inspect the wiring and the wiring harnesses for loose connections and for worn wires or frayed wires.
- Inspect the ground strap for a good connection and for good condition.
- Inspect the ECM to the cylinder head ground strap for a good connection and for good condition.
- Disconnect any battery chargers that are not protected against the current drain of the starting motor. Check the condition and the electrolyte level of the batteries, unless the engine is equipped with a maintenance free battery.
- Check the condition of the gauges. Replace any gauges that are cracked. Replace any gauge that can not be calibrated.