

coffee wakes up the world



## Service Manual



Coffee Machine

*presto!*

English

## Table of contents

---

<b>1</b>	<b>Initial operation</b>	
<b>2</b>	<b>Software service info</b>	
2.1	Software Service-Info overview	5
2.2	Service	5
2.3	Maintenance	5
2.4	Brew time	5
2.5	Protocol	5
2.6	Timer	5
2.7	Accounting	5
2.8	Milk temperature	5
<b>3</b>	<b>Software machine data</b>	
3.1	Machine data overview	6
3.2	Submenu counter	6
3.3	Submenu Service date	6
3.4	Temperature submenu	8
3.5	Submenu cleaning	8
3.6	Submenu error list	8
3.7	Submenu portioner	9
3.8	Submenu milk	9
3.9	Submenu access control	9
	Maintenance messages in Key Operator mode . . . . .	9
3.10	Submenu standards factory→service/customer	10
	Factory→service/customer menu 1	
	Factory→service/customer menu 2	
	Factory→service/customer menu 3	
	Factory→service/customer menu 4	
	Factory→service/customer menu 5	
	Factory→service/customer menu 6	
<b>4</b>	<b>Software components test</b>	
4.1	Component tests overview	13
4.2	Submenu brewer motor	13
4.3	Submenu portioner	13
4.4	Valves	14
4.5	SBHWB group (steam boiler and hot water boiler)	14
4.6	Control elements	14
4.7	Manual insert	14
4.8	Current supply	15
4.9	Oscillation pump	15
4.10	Backup battery	15
4.11	Display illumination	15
4.12	Grounds container	15
4.13	Water tank	15
4.14	Fan	15
4.15	Power status	15
4.16	Choc dispenser	16
4.17	Topping	16

<b>5</b>	<b>Software service routines</b>	
5.1	Service routines overview	17
5.2	First Run up	17
5.3	Idling current grinder	18
5.4	Filling the boiler (replacing hot water boiler)	18
5.5	Filling the steam boiler (replacing steam boiler)	18
5.6	Exchanging control battery at F 157	19
5.7	Check pressure reducer	19
5.8	Depressurization	19
5.9	Descaling	19
5.10	Filter replacement	19
<b>6.</b>	<b>Beverage data</b>	
6.1	Beverage data overview	20
	<b>Overview of beverage data main menu</b>	
	e.g. cappuccino . . . . .	20
	<b>Overview of beverage data main menu</b>	
	e.g. hot water . . . . .	20
6.2	Additional laptop setting options (KonfigTool)	20
<b>7</b>	<b>Error messages and events</b>	
7.1	Display messages	21
7.2	Error list	22
<b>8</b>	<b>Mechanical settings</b>	
8.1	Grinder setting (coarse - fine)	26
8.2	Setting pressure reducer	27
<b>9</b>	<b>Milk nozzles</b>	
<b>10</b>	<b>Maintenance concepts 15.000 brewings</b>	
10.1	Overview maintenance sets	30

## 1 Initial operation

During the initial operation the steam boiler respectively the hot water boiler is filled automatically according to the procedure described as follows.

### Machines with steam boiler and hot water boiler:

The steam boiler is filled from the hot water boiler via the steam boiler supply valve. The steam boiler supply valve is opened until the steam boiler electrode is contacted. Then the machine is heated up.

### Machines with only hot water boiler:

As the level of these machines can not be detected, the hot water boiler is filled for 300 s. The waste water is led into the drip tray via the release valve. If the first filling up is interrupted, it will be restarted by switching ON the machine.

#### **Condition:**

Machine is reset to customer setup and connected to the power supply.

- \* Run display-guided setup.  
The following settings are made:
  - Language
  - Descaling filter yes/no
  - Descaling filter range
  - Descaling filter replacement mode  
(customer or service)
- \* Update software to current status  
(only possible with laptop program "KonfigTool")
- \* Set beverages according to customer specifications  
(Customer setting ▷ recipes/buttons or by „KonfigTool"  
▷ beverage configuration)
- \* Enter service point  
(only possible with "KonfigTool").
- \* Save data ▷ Defaults ▷ Customer→Service
- \* Backup machine data on laptop

#### **Before regular operation:**

- \* rinse the pipes, dispense three cups of hot water
- \* perform the cleaning cycle

After setup, the service technician must note the following statement in the assembly invoice:  
"At the end of operation, machine has to be turned off at source. The user manual and accessories were given to the customer."

The customer must acknowledge this with his signature.




*Additional settings for recipes  
after the service PIN is entered*



## 2 Software service info

### 2.1 Software Service-Info overview



### 2.2 Service

- Contact address
- Date of next customer check-up
- Setup start date
- Software version
- Bootmanager version
- Machine number

### 2.3 Maintenance

- Last 100 cleaning operations with date and time ▷ care  
▷ report
- Info Cleaning (last cleaning)
- Info Descaling (liter until descaling)
- Info Water filter (liter until filter change)

### 2.4 Brew time

- last brewing

### 2.5 Protocol

- Error list

### 2.6 Timer

- Timer settings

### 2.7 Accounting

- Info Vending device
- Software version
- Operating state

### 2.8 Milk temperature



- hourly recorded milk temperature

### 3 Software machine data



Machine data


#### 3.1 Machine data overview



#### 3.2 Submenu counter

These displays are only for your information.


We recommend, in order to keep the information, only to reset the counters below mentioned if the components have really been exchanged!



#### 3.3 Submenu Service date



With click on „OK“, the actual date will be entered as the last visit.



With click on „OK“ the error list and FIFO will be erased.

On these three displays all possible service actions are listed. They can be looked at and can be reset if carried out.





Brewings since last customer check-up /Brewings to Customer check-up  
Date of next Customer check-up (MM.JJJJ).

The customer check-up can be reset only here.

Service Maintenance and Revision:

Along the lines of customer check-up, the service dates, service maintenance and revision are composed. Revision is only requested after some time (every 6 years).




Softener exchange:




After confirming with „Yes“ the water filter will be rinsed.

Rinse filter:



Brewer:



Counter brewer gasket: will be reset by customer care  
Counter brewer: will be reset by service maintenance  
Counter brewer drive: no service message

Mixer:




Every 6000 servings, the mixer reports a service message.  
The counter of the mixer can be looked at and reset.

### Maintenance after 6,000 portionings mixer

Parts to be replaced:

- the mixer unit
- the mixer valve


Portioner (example right grinder):



Only grinder disk counter (no service message)

Only drive counter (no service message)

### 3.4 Temperature submenu




Setting range 80 to 100°C, default 96° C

Setting range 110 to 130° C, default 127° C

Changing the steam boiler temperature leads to great changes in the dosage of milk and milk foam. Changes are not recommended.



### 3.5 Submenu cleaning



Number of cleanings performed and to be performed

Number of mixer rinsings performed

Number of milk system cleanings performed



Time until request for cleaning/forced cleaning

Hardware for foamer rinsing available?

Delay in foamer rinsing after last beverage dispensing



Switch warning signal before foamer rinsing on/off

### 3.6 Submenu error list

Delete individual errors: tap on the line


Delete complete error memory: tap **C**



Malfunction and events list see chapter Error list

### 3.7 Submenu portioner

Example right grinder




Idling current (determined via service routine)  
Maximum dosage amount in 1/10 seconds

Only the maximum dosage amount can be set for the powder portioner (default 150). A detection of the idling current is not possible.

### 3.8 Submenu milk




Yes: temperature sensor of cooler activated  
empty message via sensor  
cooler next to or below



air pump delay settable

### 3.9 Submenu access control

The settings correspond to the default of the previous standard setting. However, they can now be changed / assigned independently of each other.



if „yes“ is activated: access to key operator is activated.  
if „yes“ is activated: customer check-up can be performed.  
if „yes“ is activated: water filter can be exchanged and rinsed.

If activated („yes“), the key operator is able to

- do the descaling (turbo descaling)
- carry out and reset the customer check-up
- exchange and rinse the scale filter
- access the component test
- access the service routines
- access the counters



Reset with C on display see  
machine data > service date  
> Customer check-up  
or Menu Care > Maintenance

### Maintenance messages in Key Operator mode

#### Customer check-up

#### Maintenance after 1 year or 15,000 brewings

Tasks to be performed analogy to customer check-up


### 3.10 Submenu standards factory→service/customer

After tapping "self-detect" is first run automatically. All components operating on 24V or 30V are automatically addressed. The components are automatically identified.

During self-detect the grounds container must be in place, the adjustable screen closed or the 24/30V circuits of the components are interrupted.



#### Factory→service/customer menu 1



Configuration of grinders

Configuration of powder portioner

Heating capacity

**Configuration of grinders** is registered automatically (see chapter portioner).


**Configuration of powder portioner** is registered automatically (see chapter portioner).

**Heating capacity** can be changed as required.



See chapter engineering, portioner in the training manual

#### Factory→service/customer menu 2



Steam boiler existent

Steam dispensing valve existent

Fresh milk valve (cappuccino valve) existent

**Steam boiler** is registered automatically by its intake valve (See chapter boiler ▷water system).


**Steam dispensing valve** is automatically detected (See chapter boiler ▷water system).

**Milk** is automatically detected (See chapter boiler ▷water system).



See chapter Boiler water systems in the training manual Part 2 Engineering

#### Factory→service/customer menu 3



Self-Service mode activated?

Water tank / water infeed

Drain drip tray existent? (changes cleaning and descaling )

#### Self-Service mode

The default settings can be adjusted individually in the operating options.

	Default at „No“	Default at „Yes“
2nd level (Yes/No)	depending on configuration	No
On/Off button (direct/through PIN)	directly	directly
Warm rinse pad (active/inactive)	active	inactive
Barista pad (active/inactive)	active	inactive
Cancel Beverage (Yes/No)	active	inactive
Menu pad (immediately/delayed)	immediately	delayed
Error message (normal/symbol)	normal	symbol


**Water tank/ Water infeed** is automatically detected by nonexistent intake valve. The external tank can be selected. By detecting the intake valve the display shows constant water. Option Aquaflex / technical insert (mobile station) can be selected.

**Drain of drip tray** must be correctly adjusted manually.



See chapter Boiler water systems  
See chapter drip tray in the training manual  
Part 2 Engineering

#### Factory→service/customer menu 4



- \_\_\_\_\_ Beverages configured on 2 levels
- \_\_\_\_\_ Manual insert for coffee and cleaning or cleaning only
- \_\_\_\_\_ Accounting via accessory device via MDB or serial connection

It only makes sense to adjust the **2. level** if milk is available.


**Tablet insert** ("Handrein") must be set manually for more than 2 portioners, for up to two portioners manual insert coffee (HandKaff).

**Accounting** must be set manually (MDB or serial connection).



See user manual and additional user manual for accounting.

#### Factory→service/customer menu 5



- \_\_\_\_\_ Operating mode grounds container: external = grounds disposal through counter
- \_\_\_\_\_ Preselect-button for decaf brewing instead of steam button
- \_\_\_\_\_ Daylight saving time selected?

**Grounds disposal through counter** must be correctly set manually. (default = internal)


**Decaf** must be set manually.

**Summertime** automatic change to daylight saving time can be activated.



See user manual

## Factory→service/customer menu 6




---

Option Plug&Clean existant?  
only available for railway version  
Accept


---

**Option Plug&Clean** can be activated  
Safety queries follow **acceptance**.

### Safety queries upon acceptance of the variations:



- If „yes“:
- \* The pre-settings will be transferred
  - \* The default beverages and prices will be set according to factory setting
- If „no“:
- \* The pre-settings will be transferred
  - \* The default beverages and prices remain set



- If „yes“:
- \* the day counter remains unchanged
- If „no“:
- \* the day counter will be reset




## 4 Software components test




### 4.1 Component tests overview

Depending on the machine configuration the following tests are available in the software:



### 4.2 Submenu brewer motor



⏏ Run brewer to end switch


⏏ Run brewer up

⏏ Run brewer down

**End switch:** 0001 end switch contacted

**Current (mA):** Display value during procedure

### 4.3 Submenu portioner



\_\_\_\_\_ Test right grinder

\_\_\_\_\_ Test left grinder

**Current (mA):** Value during portioning procedure is displayed

During the test the grounds container must be in position and the adjustable screen closed as the brewer receives the coffee powder during the test and dumps it afterwards.




## 4.4 Valves

During the test additional data is displayed, e.g. the maximum current consumption of the valve(s) or the number of flowmeter pulses.

When testing the brewer valve the brewer must be in functioning condition as it receives the brewing water during the test and discharges it afterwards.



## 4.5 SBHWB group (steam boiler and hot water boiler)



Additional data during tests:

**Heating units:** display of condition and current temperature.

**Level/feeding:**

**-** - button: The level in the steam boiler is lowered via the steam valve.

**+** - button: The level in the steam boiler is raised by the supply valve.

**Liquid level:** the current capacitive value of the sound is displayed. The trigger value at which the steam boiler is detected as "full" is 180 digits.

Normally the "full" value is at 212 digits.

## 4.6 Control elements




Beverage button LEDs are subsequently addressed

Test beverage buttons by pushing them

Test touch fields on the display by touching them

## 4.7 Manual insert



Test reed switch, manual insert.

Reed switch touched or not.

### 4.8 Current supply



Switch the 24/30V circuits on and off from the mains.

### 4.9 Oscillation pump



Access of the oscillation pump

### 4.10 Backup battery

During the test the battery is short-circuited. This procedure shortens battery life.



### 4.11 Display illumination

The display illumination can be switched off for testing.

### 4.12 Grounds container

Display if the micro switches switch the 24V circuits of the grounds container and the adjustable screen.

### 4.13 Water tank



Function capacitive sensor water tank (touched/not touched).  
Ext. level sensor.

### 4.14 Fan

Test of function and current consumption

### 4.15 Power status



Report "power failure" to the control unit

## 4.16 Choc dispenser

Components	
Choc-Dispens.	
Hot water valve	
Portioner	
Mixer Motor	

---

Test choc valve

---

Test the portioner, the choc valve is also addressed

---

Test mixer motor

---



## 4.17 Topping

Components	
Choc-Dispens.	
Hot water valve	
Portioner	
Mixer Motor	

## 5 Software service routines



### 5.1 Service routines overview



### 5.2 First Run up

The software is restarted, with a "reset event" entered into the laptop ring memory (see chapter "service", reset events).

The cleaning obligation is reset as if a cleaning cycle had just been done.

A cleaning cycle can be interrupted.

A descaling cycle can be interrupted.



*See chapter software, First Run up in the training manual part 4 software*

**Attention:** If a cleaning or descaling cycle has been interrupted adequate measures must be taken to ensure that no residues of cleaning or descaling agents remain in the machine. In this case cleaning or descaling must be repeated.



The reset of the customer settings program is treated in the same way by the software, however does not reset the cleaning and descaling obligations.



### 5.3 Idling current grinder

For a correct "empty" report the grinder idling current must be entered into the system as base following the entering of the factory values or motor replacement. This is done via a service routine.

#### Notices for technicians

The idling current must by all means be determined with the grinder completely empty.



*See chapter software, grinder idling current part 4 software*

*See chapter engineering, portioner, grinder with motor in the training manual Part 2 Engineering*

### 5.4 Filling the boiler (replacing hot water boiler)

Before replacing the hot water boiler the display guided routine „filling up boiler“ must be started.

Only with this routine a blowing of the heating in case of an empty hot water boiler can be avoided (excess water is led into the drip tray via the release valve during the filling routine)

Without doing this routine there is a risk of heating up the still empty hot water boiler, in case that the steam boiler electrode gets in contact with water.

### 5.5 Filling the steam boiler (replacing steam boiler)

Before replacing the steam boiler the display guided routine „filling up steam boiler“ must be started.

Only with this routine it can be assured that the filling level reaches the steam boiler electrode. Without doing this routine there is a risk of not reaching the filling level up to the steam boiler electrode. Because of missing ventilation the steam boiler would be filled up against an air cushion.

## 5.6 Exchanging control battery at F 157

At error message 157 the control battery must be replaced.



The notices on the display are to be followed:

*All data is stored in the service memory.*

Disconnect machine from mains

※ Exchange battery

As soon as the machine is reconnected to the mains all data is automatically loaded into the service memory.

## 5.7 Check pressure reducer

see chapter 8.2.



*See chapter 8.2 Setting pressure reducer*

## 5.8 Depressurization

Before opening the screws at the boiler water system the display guided routine "depressurization" must be started. This is for your own safety, because the steam boiler pressure will be relieved via the Cappuccino and steamer valve.

Please pay attention that the heating only remains switched off until the customer service menu is left and thus the machine is working in a normal operation mode.

## 5.9 Descaling

Constant water supply: see User Manual ▷ *Care*

External tank / technical group: see Info letter 2011-33

## 5.10 Filter replacement

The same function as in the customer care menu.


## 6. Beverage data



Beverage data

### 6.1 Beverage data overview

#### Overview of beverage data main menu e.g. cappuccino





**Shift key:** active = beverage on the 2. level is set.

**General:** Set recipe, portioner, amounts of powder and water.

**Brewing:** Set pre-treatment, dry pressing pause, multiple pressing and water amount for warm rinse.

**Milk:** set dosage time 1 (e.g. milk) and 2 (e.g. foam) and beverage-specific foam quality.

#### Overview of beverage data main menu e.g. hot water



**General:** Set recipe and dosage variation

**Water:** Set dosage amount

### 6.2 Additional laptop setting options (KonfigTool)

#### Page customer\general item pretreatment:

- User-defined pretreatment setting possible (Pressing, pre-infusion, wet pressing, warm rinse)

#### Page customer\general item variety text:

- Random variety text

#### Page general:

- Multiple brewing (e.g. for a pot of coffee)

## 7 Error messages and events

### 7.1 Display messages

#### Operation messages



Water tank is empty or not inserted.




Shut-off valve is closed or flowmeter malfunction.



If temperature in boiler or steam boiler too low.




During automatic (following first heating) or manual (via warm rinse button) warm rinse.



Beans left idling current detected.



Beans right idling current detected.




Grounds container at full limit (Default 200 seconds grinding-time of grinders).



Micro switch grounds container or micro switch adjustable screen without contact.




If grounds container was drawn out for more than 5 seconds.




With Aquaflex only:  
Water in tank but set to permanent water supply.

#### Cleaning messages



Brewing unit not detected following closing of door or inserting of grounds container.



With machines without drain connection and after cleaning with switching off at next switching on of the machine.



A flow error has occurred during the cleaning program.

#### Maintenance and care messages




After 15,000 brewings or 1 year.



With machines with constant water connection.



After 30,000 brewings or 2 years.



With water tank machines.



After 6 years.

## 7.2 Error list

See training manual in part 6 chapter troubleshooting

Report Display	Descr.	Entry ring mem.	Entry display	Comment	No. malfunction memory	
2	F2 Brewer without electricity	√	√		195	
5	F5 Brewer shutoff	√	√		198	
6	F6 Brewer over current	√	√		253	
7	F7 Brewer timeout (no electricity)	√	√		254	
26	F26 Portioner current malfunction	√	√		1	
36	F36 Current malfunction Portioner 2	√	√		3	
46	F46 Current malfunction Portioner 3	√	√	not implemented	5	not implemented
87	F87 Boiler sensor damaged	√	√		40	
88	F88 boiler excess temperature	√	√		39	
89	F89 boiler heating time	√	√		41	

Report Display	Descr.	Entry ring mem.	Entry display	Comment	No. malfunction memory	
130	F130 General current malfunction	✓	✓	Short circuit if immediately at switching-on 24/30V present	28	not implemented
149	F149 General voltage malfunction	✓	✓	If short circuit is present in 24/30V systems	86	
157	Battery must be replaced	✓	✓	Batterie voltage too low to preserve data. Data is automatically stored in service memory.		
161	F161 flowmeter malfunction during brewing	✓	✓		241	
162	F162 flowmeter malfunction during cleaning	✓	✓		242	
163	F163 flowmeter malfunction during warm rinsing	✓	✓		243	
164	F164 flowmeter malfunction during hot water dosage	✓	✓		244	
165	F165 flowmeter malfunction during choc dosage	✓	✓		245	
166	F166 flowmeter malfunction during DK feeding	✓	✓		246	
167	F167 flowmeter malfunction during descaling	✓	✓		274	
186	F186 timeout during steam boiler filling	✓	✓		247	
187	F187 Steam boiler sensor damage	✓	✓		232	

Report Display	Descr.	Entry ring mem.	Entry display	Comment	No. malfunction memory	
188	F188 Excess temperature in steam boiler	√	√		231	
189	F189 Heating-time steam boiler	√	√		43	
9061	Standby Event	√		Coming and going	61	Coming and going
9062	Reset Event!	√		Coming and going	62	
9104	Timer function not possible	√	√	Machine cannot switch off due to cleaning in progress	104	
9118	Fifo was deleted	√	√		118	
9119	Defaults into RAM	√	√		119	
9120	Defaults into flash	√	√		120	
9125	Machine cleaning in progress	√		internal	125	internal
9126	Milk foam cleaning in progress!	√		internal	126	internal
9136	Cleaning was interrupted	√	√	due to an error in the cleaning program	136	Display cleaning obligation
9180	Mixer cleaning in progress	√		internal	180	
9236	AD-transformer ready! (for developers only)	√	√	internal	236	
9248	Malfunction in level sensor	√	√		248	
9256	Auto detect malfunction: Right grinder not detected	√	√		256	
9257	Auto detect malfunction: brewing-valve not detected	√	√		257	
9258	Auto detect malfunction: Oscillating pump not detected	√	√		258	
9259	Auto detect malfunction: Release valve not detected	√	√		259	
9260	Auto detect malfunction: Fan not detected	√	√		260	



Report Display	Descr.	Entry ring mem.	Entry display	Comment	No. malfunction memory	
9261	Auto detect malfunction: Hot water dispensing valve not detected	√	√		261	
9262	Auto detect malfunction: Mixer not detected but choc/topping portioner detected	√	√		262	
9263	Auto detect malfunction: choc/topping portioner not detected but mixer detected	√	√		263	
9264	Auto detect malfunction: Mixer valve detected but no powder portioner detected or; Hot water-Choc/topping valve not detected but choc/topping portioner detected	√	√		264	
9265	Auto detect malfunction: Milk pump detected but no cappuccino valve detected or milk pump not detected but cappuccino valve detected	√	√		265	
9268	Power supply reports voltage too low	√	√	External mains voltage!	268	
9271	Pump switches to pressure -lowering mode (Info = button number)	√	√	Pump pressure lowered. The beverage number is entered into the laptop Info column	271	Pump pressure lowered, 9271
9275	Reset triggered by customer	√	√		275	9275
9288	MDB communication error coin checker	√	√		288	9288
9289	MDB communication error card reader	√	√		289	9289
9290	MDB communication error banknote reader	√	√		290	9290
9291	24 V are switched off and then on again (reset for MDB equipment on 24 V)	√	√		291	9291

## 8 Mechanical settings

### 8.1 Grinder setting (coarse – fine)

#### Setting grinder degree

The grinder must be dismantled. The setting-wheel (with worm gear) is dismantled.

- \* Turn the grinding-disks towards each other until they join and cannot be turned further by hand on the driveshaft.
- \* Fit the setting-wheel with the worm gear.

#### Espresso grinder (right side)

- \* Open the setting-wheel by a total of 10 turns. This setting corresponds to setting no. 1 (espresso)

See chapter troubleshooting or user manual or respective error message no. 161 if powder is too fine.



#### Cream grinder (left side)

- \* Open the setting-wheel for a total of 18 turns. This setting corresponds to setting no. 5 = cream fineness. 2 turns of the setting-wheel are necessary to adjust the fineness by one degree. Machines with only one grinder are set to espresso fineness.

#### Installing replacement grinder:

The replacement grinder is prepared for installation in portioner position 1 and 3 (far right and far left). For installation at portioner position 2 (center) the auger (grinder fineness setting) and its bearings must be reassembled to the intended position.

## 8.2 Setting pressure reducer

### Setting pressure reducer without laptop


- \* Start service program ▷ service routine ▷ setting pressure reducer ▷ start.
- \* Remove screw-cap on water tank filler.
- \* Screw auxiliary nipple (33.2320.8000, O-ring 33.0398.5000) to accept plug-in connector into the water tank filler
- \* Mount auxiliary tool on filler.
- \* Press field **Start**  
Supply valve opens
- \* Read pressure on pressure gauge.
- \* Set pressure to 1.8 bar at pressure reducer.
- \* Finish test (machine is turned off).
- \* Dismantle setting equipment and remove auxiliary nipple.
- \* Replace filler cap.

### Setting pressure reducer with KonfigTool

- \* Adjust test environment ▷ set pressure reducer ▷ start
- \* Remove filler screw-cap
- \* Screw auxiliary nipple to accept plug-in connector into the water tank filler.
- \* Mount auxiliary tool on filler.
- \* Start test on laptop  
Supply valve opens
- \* Read pressure on pressure gauge.
- \* Set pressure to 1.8 bar at pressure reducer.
- \* Finish test
- \* Dismantle setting equipment and remove auxiliary nipple.
- \* Replace filler cap.



## 10 Maintenance concepts 15.000 brewings



Additionally:  
 Brewer: every 30.000 brewings  
 MS Choc: every 6.000 mixer cycles

## 10.1 Overview maintenance sets

Type of maintenance	abbr. Maintenance set	Maintenance cycle	Basic Milk	
			Optimized milk foamer	Previous milk foamer
Care kit	CK	Every 15.000 brewings or once a year	33.2876.5000	33.2828.7000
Service maintenance	MS	every 30.000 brewings or every 2 years	33.2834.9000 MS without brewer 1)	33.2828.8100 MS without brewer 1)
			- n.a. -	33.2828.8000 MS with brewer
			- n.a. -	33.2828.5100 MS with brewer and MS Additional Fresh Milk
Expanded steam boiler and boiler inspection	Additionally for fresh milk machines	Within Service maintenance of maintenance sets that contain safety valves – Details see Info-letter Info-2013-07	33.2828.9100 MS Additional Fresh Milk	
Additional Choc /Topping	MS Choc	every 6.000 mixer cycles	33.2828.6100	
Brewer exchange	Brewer	every 30.000 brewings	33.2823.6199 1) pay attention when ordering MS without brewer. Brewer has to be ordered separately	
Descaling		Due date: without water filter > depending on carbonate hardness; with water filter > once a year	2x 33.7006.2869 Descaling liquid	