

CONTENTS

Introduction	1
Safety Information.	2
Special Information	3
Maintenance	3
Disassembly of Pump.	4
Disassembly of Couplings	7
Disassembly / Assembly Bearing Housing	9
Installation of Bushings	9
Assembly of Pump	9
Pump Rotation	10
Assembly of Couplings	11
Adjusting End Clearance	13
Pressure Relief Valve Instructions	13
Troubleshooting	15

MODEL NUMBER CHART

UNMOUNTED PUMPS	UNITS
GS-855U, GS-855M,	Units are designated by the un-mounted pump model numbers followed by the magnetic coupling size and a letter indicating drive style. (Example: GG-855MA MD2 A9 M) D = Direct Drive M = Motor Mount B = Bearing Carrier R = Viking Reducer Drive P = Commercial Reducer Drive See Page 4 for complete description of the model number
GG-855U, GG-855M	
HJ-855U, HJ-855M	
HL-855U, HL-855M	

TABLE 1

WARNING!

Persons with surgical implants of a metallic or electronic nature should avoid working on pump – especially the inner magnet assembly.

INTRODUCTION

The illustrations used in this manual are for identification purposes only and cannot be used for ordering parts. Obtain a parts list from the factory or a Viking® representative. Always give the complete name of the part, part number and material with the model number and serial number of the pump when ordering repair parts. The unmounted pump or pump unit model number and serial number can be found on the nameplate secured to the pump.

This manual deals only with Series 855 magnetic drive pumps. Refer to Figures 1 through 34 for general configuration and nomenclature used in this manual. Pump specifications and recommendations are listed in Catalog Section 685.

In the Viking model number system, the basic size letters are combined with the series number (855) indicating basic pump construction material.



FIGURE 1
GS,GG SERIES 855MA MD2-A9 B
Pump with Bearing Carrier



FIGURE 2
HJ-HL SERIES 855MB MD2-B M
Pump with Motor Directly Mounted to the Bracket

SAFETY INFORMATION AND INSTRUCTIONS

IMPROPER INSTALLATION, OPERATION OR MAINTENANCE OF PUMP MAY CAUSE SERIOUS INJURY OR DEATH AND/OR RESULT IN DAMAGE TO PUMP AND/OR OTHER EQUIPMENT. VIKING'S WARRANTY DOES NOT COVER FAILURE DUE TO IMPROPER INSTALLATION, OPERATION OR MAINTENANCE.

THIS INFORMATION MUST BE FULLY READ BEFORE BEGINNING INSTALLATION, OPERATION OR MAINTENANCE OF PUMP AND MUST BE KEPT WITH PUMP. PUMP MUST BE INSTALLED, OPERATED AND MAINTAINED ONLY BY SUITABLY TRAINED AND QUALIFIED PERSONS.

THE FOLLOWING SAFETY INSTRUCTIONS MUST BE FOLLOWED AND ADHERED TO AT ALL TIMES.

Symbol
Legend :



Danger - Failure to follow the indicated instruction may result in serious injury or death.

WARNING

Warning - In addition to possible serious injury or death, failure to follow the indicated instruction may cause damage to pump and/or other equipment.



BEFORE opening any liquid chamber (pumping chamber, reservoir, relief valve adjusting cap fitting, etc.) be sure that :

- Any pressure in the chamber has been completely vented through the suction or discharge lines or other appropriate openings or connections.
- The pump drive system means (motor, turbine, engine, etc.) has been "locked out" or otherwise been made non-operational so that it cannot be started while work is being done on the pump.
- You know what material the pump has been handling, have obtained a material safety data sheet (MSDS) for the material, and understand and follow all precautions appropriate for the safe handling of the material.

WARNING

INSTALL pressure gauges/sensors next to the pump suction and discharge connections to monitor pressures.



WARNING

USE extreme caution when lifting the pump. Suitable lifting devices should be used when appropriate. Lifting eyes installed on the pump must be used **only** to lift the pump, **not** the pump with drive and/or base plate. If the pump is mounted on a base plate, the base plate must be used for all lifting purposes. If slings are used for lifting, they must be safely and securely attached. For weight of the pump alone (which does not include the drive and/or base plate) refer to the Viking Pump product catalog.



BEFORE operating the pump, be sure all drive guards are in place.



DO NOT attempt to dismantle a pressure relief valve that has not had the spring pressure relieved or is mounted on a pump that is operating.



DO NOT operate pump if the suction or discharge piping is not connected.



AVOID contact with hot areas of the pump and/or drive. Certain operating conditions, temperature control devices (jackets, heat-tracing, etc.), improper installation, improper operation, and improper maintenance can all cause high temperatures on the pump and/or drive.



DO NOT place fingers into the pumping chamber or its connection ports or into any part of the drive train if there is **any possibility** of the pump shafts being rotated.



WARNING

DO NOT exceed the pumps rated pressure, speed, and temperature, or change the system/duty parameters from those the pump was originally supplied, without confirming its suitability for the new service.



WARNING

THE PUMP must be provided with pressure protection. This may be provided through a relief valve mounted directly on the pump, an in-line pressure relief valve, a torque limiting device, or a rupture disk. If pump rotation may be reversed during operation, pressure protection must be provided on **both** sides of pump. Relief valve adjusting screw caps must always point towards suction side of the pump. If pump rotation is reversed, position of the relief valve must be changed. Pressure relief valves cannot be used to control pump flow or regulate discharge pressure. For additional information, refer to Viking Pump's Technical Service Manual TSM 000 and Engineering Service Bulletin ESB-31.



WARNING

BEFORE operating the pump, be sure that:

- It is clean and free from debris
- all valves in the suction and discharge pipelines are fully opened.
- All piping connected to the pump is fully supported and correctly aligned with the pump.
- Pump rotation is correct for the desired direction of flow.



WARNING

THE PUMP must be installed in a manner that allows safe access for routine maintenance and for inspection during operation to check for leakage and monitor pump operation.

SPECIAL INFORMATION

DANGER !

Before opening any Viking pump liquid chamber (pumping chamber, reservoir, relief valve adjusting cap fitting etc.) Be sure:

1. That any pressure in the chamber has been completely vented through the suction or discharge lines or other appropriate openings or connections.
2. That the driving means (motor, turbine, engine, etc.) has been "locked out" or made non-operational so that it cannot be started while work is being done on pump.
3. That you know what liquid the pump has been handling and the precautions necessary to safely handle the liquid. Obtain a material safety data sheet (MSDS) for the liquid to be sure these precautions are understood.


Failure to follow above listed precautionary measures may result in serious injury or death.

ROTATION: Viking Mag Drive® pumps are designed to run either direction. See **PUMP ROTATION**, page 10.

PRESSURE RELIEF VALVES:

1. Viking pumps are positive displacement pumps and must be provided with some sort of pressure protection. This may be a relief valve mounted directly on the pump, an inline pressure relief valve, a torque limiting device or a rupture disk. Do not rely on decoupling of magnets for protection from over pressure; this may result in damage to the magnets, pump, or other equipment.
2. Relief valves are mounted as standard on the casing of GS, GG, HJ, and HL size pumps.
3. If the pump rotation is to be reversed during operation, pressure protection must be provided on **both** sides of the pump.
4. The relief valve adjusting screw cap must always point towards the suction side of the pump. See Figure 3. If the pump rotation is reversed, remove the pressure relief valve and turn end for end (see **PUMP ROTATION**, page 10 first for additional steps required for proper operation).
5. Pressure relief valves cannot be used to control pump flow or regulate discharge pressure.

For additional information on pressure relief valves, refer to Technical Service Manual TSM000 and Engineering Service Bulletin ESB-31.



**FIGURE 3
RELIEF VALVE POSITION**

CAUTION !

Rare earth magnets used in couplings have extremely strong magnetic fields capable of changing performance or damaging items such as the following:

**Pacemakers
Metal Implants
Watches
Computers & disks
Credit Cards**

Completely assembled magnetic couplings will not affect items listed above – only disassembled components.


There are no known harmful effects of these magnetic fields on the human body.

MAINTENANCE

Series 855 pumps are designed for long, trouble-free service life under a wide variety of application conditions with a minimum of maintenance. The points listed below will help provide long service life.

CLEANING PUMP:

Keep the pump as clean as possible. This will facilitate inspection, adjustment and repair work.



CUTAWAY VIEW MAG DRIVE PUMP, MODEL HL855M MD2-B B ILLUSTRATED. (TYPICAL OF GG-HL SIZES)
FIGURE 4

MAINTENANCE (Cont.)

STORAGE:

If the pump and coupling are to be stored, drain the pump and pour non-detergent SAE 30-weight oil into the pump port. Apply grease to the pump or the coupling shaft extension, if present or accessible.

Viking suggests rotating the pump shaft every 30 days to circulate the oil in the pump. The coupling should be stored in a dry area.

NOTE: If the liquid to be pumped reacts with oil, use an acceptable alternate.

SUGGESTED REPAIR TOOLS:

The following tools are required to properly repair Series 855 pumps. These tools are in addition to standard mechanics' tools such as open-end wrenches, pliers, screwdrivers, etc. Most of the items can be obtained from an industrial supply house.

1. Soft face hammer
2. Metric Allen wrenches (for set screws)
3. Torque Wrench with a locknut socket
4. External snap ring pliers - 2-810-029-375
5. Internal snap ring pliers - 2- 810-047-999
6. Arbor press
7. Brass bar
8. Hook style spanner wrench

PUMP DISASSEMBLY

WARNING!

Refer to DANGER & CAUTION listed on page 2 before proceeding.

1. To drain the liquid being pumped, remove the two (2) drain plugs located in the bottom of the casing. Once the liquid has drained replace the plugs.
2. Refer to Figures 4, 6 & 7 for names of parts.
3. Mark the head and casing before disassembly to insure proper reassembly.
4. To inspect the head and pin assembly and idler and bushing assembly, remove the head capscrews.
5. Remove the head from the pump. Do not allow the idler to fall from the idler pin. Tilt the top of the pump head back when removing to prevent this. Avoid damaging the head shim set since all shims are required to maintain end clearance.
6. Remove the idler and bushing assembly. If the idler bushing needs to be replaced, see **INSTALLATION OF BUSHINGS**, page 9. If further disassembly is required, the pump must be separated from coupling. Refer to **DISASSEMBLY OF COUPLING**, page 7, before proceeding with Step 7.




FIGURE 5
MODEL NUMBER SYSTEM




FIGURE 6
EXPLODED VIEW – SIZES GS, GG, HJ & HL MAG-DRIVE PUMPS

ITEM	NAME OF PART	ITEM	NAME OF PART	ITEM	NAME OF PART
1	Locknut	37	Idle	53	Locating Pin
21	Set Collar	38	Idle Bushing	60	Thrust Washer (2 Req'd)
25	Casing Bushing	39	Idle Pin	61	Machine Screws (2 Req'd)
30	Pipe Plug (2 Req'd)	40	Head and Idle Pin Assembly	62	Drive Key
32	Casing and Bushing Assembly	43	Capscrews for Head	63	Shims for Head (metal)
33	Casing Stem O-ring	45	Relief Valve Gasket		
35	Head O-ring	46	Capscrews for Relief Valve		
36	Rotor and Shaft Assembly	47	Relief Valve		

TABLE 2

MAGNETIC COUPLING OPTIONS		TORQUE RATINGS AND DRIVER CONNECTION OPTIONS				
Pump Size	Magnetic Coupling Sizes	Magnetic Coupling Sizes	Torque Ratings (Ft-Lbs)	Close-Coupled		
				IEC B-5 Flange Motor Mounts	Mounting capscews	Bearing Carrier
GS	A	A	• 4 • 9	• 80/90	10mm	Yes
GG	A			• 100/112	12mm	
HJ	A, B	B	• 14 • 32 • 50	• 100/112 • 132	12mm	Yes
HL	A, B					

TABLE 3
COUPLING TORQUE AND SIZE OPTIONS




FIGURE 7
M DRIVE CONFIGURATION
MD2- A & B SERIES COUPLING AND BEARING CARRIER COMPONENTS

ITEM	DESCRIPTION	ITEM	DESCRIPTION	ITEM	DESCRIPTION
601	Bolt-on Hub with Hardware	607	Capscrews for Pump - (4) Required	613	Drive Key - Outboard Side
602	Outer Magnet Assembly	608	Canister and Bushing Assembly	614	Shaft
603	Bracket	609	Inner Magnet Assembly	615	Drive Key - Inboard Side
604	Capscrew for Disassembly	610	Capscrews for Motor or Bearing Carrier - (4) Required	616	Ball Bearing - (2) Required
605	Lifting Eye	611	Bearing Carrier Housing	617	Spacer
606	Pipe Plug for Sensor Hole	612	External Retaining Ring - (2) Required	618	Internal Retaining Ring

TABLE 4

PUMP DISASSEMBLY (Cont.)

7. With the inner magnet removed, now remove the pump shaft key. Remove the outer thrust washer. The rotor and shaft may now be removed by tapping on the end of the shaft with a soft face hammer (If a soft face hammer is not available a regular hammer may be used with a piece of hardwood).
8. Remove the inner thrust washer from behind the rotor.

The casing should be examined for wear, particularly in the area between ports. Clean all other parts thoroughly and examine for wear or damage. Check bushings, idler pin and thrust washers; replace if necessary.

When making major repairs, such as replacing a rotor and shaft, it is advisable to also install a new head and idler pin, idler and bushing, and casing bushings. See **INSTALLATION OF BUSHINGS**, page 9.

DISASSEMBLY OF COUPLING

Series MD2 - A4 / A9 Coupling




1. Remove piping to the ports and remove the (4) 12mm capscrews-securing the pump to the bracket. See Figure 8. Support the pump with an overhead hoist if possible.

CAUTION !

Do not place fingers onto front of pump mounting flange or face of bracket. Using extreme caution, pull inner magnet away from outer magnet. See Figure 8. If you do not completely pull the pump out it will snap back and could pinch a finger or hand. Once the inner magnet is removed from the bracket be careful setting it down as it will attract any steel object.

2. The canister will contain some liquid, therefore use care while removing from the pump and pull straight off.
3. Remove the (2) 4mm buttonhead machine screws and the set collar. Insert brass bar into rotor teeth through port and remove locknut. Slide off inner magnet assembly (See Figures 9 & 10). Do not forget this is a very strong magnet. If further pump disassembly is required, refer to step 6 of **PUMP DISASSEMBLY**, page 6.
4. Do not remove the O-ring unless it is bad, especially PTFE (derivative) encapsulated. If a new O-ring is required, follow instructions in the **ASSEMBLY** section on page 9.
5. You should be able to visually inspect the outer magnets from the end of the bracket. If removal is

necessary, start by removing the (4) capscrews (See Figure 8). Separate the bracket from the motor or bearing carrier. Loosen the setscrew on the outer shell hub. Pull the outer magnet assembly off the shaft. If the unit features a bearing carrier, the bearings should not require maintenance since they are sealed. For additional information on bearing carrier repair Refer to **ASSEMBLY/DISASSEMBLY OF BEARING**




Series MD2- B14 / MD2 - B50 Coupling

1. Remove the piping to the ports and remove the capscrews securing the pump to the bracket. Support the pump with an overhead hoist if possible. Use the M10 x 120 capscrew in the bracket to separate the inner magnet from the outer. (See Figure 12).


CAUTION !

Do not place your fingers between the pump mounting flange and the face of the bracket. Using extreme caution, pull the inner magnet away from the outer magnet (see figure 9, page 7). If you do not completely pull the pump out it will snap back and could pinch a finger or hand. Once the inner magnet is removed from the bracket be careful setting it down as it will attract any iron or steel object.


2. The canister will contain some liquid, therefore use care while removing from the pump and pull it straight off.
3. Remove the two 6mm buttonhead machine screws and the set collar. Insert a brass bar through a port between two rotor teeth and remove the locknut (See Figure 13). Slide the inner magnet off the shaft. Do not forget this is a very strong magnet. If further pump disassembly is required, refer to Step 7 of **PUMP DISASSEMBLY**, page 4.
4. Do not remove the O-ring unless it is bad, especially if PTFE derivative encapsulated. If a new O-ring is required, follow instructions in the **ASSEMBLY** section, page 9.
5. You should be able to visually inspect the outer magnets from the end of the bracket. If removal is necessary, start by removing the (4) capscrews (See Figure 14) and separate the bracket from the motor or bearing carrier. Loosen the 2 setscrews on the outer shell hub and slide the outer magnet assembly off the shaft. If the unit features a bearing carrier, the bearings should not require maintenance since they are sealed. If necessary, disassemble by removing the single internal retaining ring then press the shaft and bearings out of the housing. Remove the external retaining rings from the shaft to remove the bearings (Refer to Figure 7, page 6 and Figure 15, page 9).




**FIGURE 11
PUMP, INNER MAGNET AND CANISTER ASSEMBLY**



**FIGURE 12
PUMP AND BRACKET SEPARATION SEQUENCE**



**FIGURE 13
INNER MAGNET AND LOCKNUT ASSEMBLY**



**FIGURE 14
MOTOR (OR BEARING CARRIER) AND BRACKET**

DISASSEMBLY / ASSEMBLY OF BEARING CARRIER HOUSING

DISASSEMBLY


The bearing carrier housing features two sealed ball bearings along with an outer magnet assembly. If further disassembly of this unit is required, proceed as follows:

1. Remove the internal retaining ring. Then press the shaft out of the housing.
2. Remove the external retaining rings from shaft, place unit into press and push out shaft out of the bearings.

ASSEMBLY

1. Place some Loctite on the O.D. of the first bearing and press into the housing bore. Position the bearing spacer in the bore and insert the second bearing. Center the bearing spacer then press in shaft with one external retaining ring on shaft. Press down until ring contacts bearing race then install second ring. Install internal retaining ring into bearing housing.
2. Slide outer magnet assembly onto pump shaft. Locate the outer magnet per dimension "A" then tighten the two setscrews.

<u>Coupling Series</u>	<u>"A" Dim.</u>
A Series	165 mm
B Series	198 mm



**FIGURE 15
OUTER MAGNET, BOLT ON HUB
AND BEARING HOUSING**

INSTALLATION OF BUSHINGS


CARBON GRAPHITE

The canister bushing requires a special fixture for proper assembly. It is only sold as an assembly with the canister.

If attempting to install the carbon graphite idler or casing bushing, extreme care must be taken to prevent breaking. Carbon graphite is a brittle material and easily cracked. If cracked, the bushing will quickly disintegrate. Using a lubricant on the bushing and mating part will help facilitate installation.

Figure 16 shows the proper position of the casing bushing after installation. This will require a special fixture for proper position. Improper location may result in a pump with excessive slip or requiring a large number of shims. The additional precautions listed below must be followed for installation:

1. An arbor press must be used for installation.
2. Be certain the bushing is started straight.
3. Do not stop the pressing operation until the bushing is in the proper position; starting and stopping will result in a cracked bushing.
4. After installation, check the bushing for cracks.



**FIGURE 16
CASING BUSHING POSITIONING**

ASSEMBLY OF PUMP

Use a suitable lubricant compatible with the fluid being handled when reassembling the pump.

Inspect all parts, especially drilled holes in the casing (for draining) to make sure they are not plugged. Replace any worn parts, remove any burrs, and clean all parts before assembling the pump.

1. If the canister O-ring needs to be replaced, apply a lubricant to the O-ring and place it into the O-ring groove. If the O-ring is PTFE (derivative) encapsulated, follow these special instructions.

Do not attempt to reuse a PTFE (derivative) encapsulated O-ring if it has been removed. Immerse a new O-ring in boiling water for a few minutes. Remove it from the water and stretch out the O-ring so it will fit onto the casing hub without forcing it over a sharp edge. Run hot water* over the O-ring until it shrinks down tight onto the pilot of the pump. Dry with compressed air.

2. Clean the rotor and shaft so it is free of dirt, grit and other debris and apply lubricant. Place one thrust washer onto shaft so that the blind hole in thrust washer will line up with the drive pin on back of rotor. Push it into the casing as far as it will go.
3. Slide the second thrust washer onto the shaft, drive hole facing out and then install key into the shaft.
4. Slide the inner magnet onto the shaft and engage the pin of magnet into hole of thrust washer. Install the locknut, beveled edge out, set torque to measurements given in Table 5. Place a mark on the trailing edge of the locknut slot. Refer to Figure 17. Back off the locknut until the leading edge of that same slot lines up with the mark. This will establish the proper clearance for the thrust washers.

Locknut Torque Requirement		
	In-Lbs	N-m
MD2-A	25	2.8
MD2-B	60	6.8

TABLE 5

5. Place the set collar on the locknut and install the two machine screws.
6. If the old metal shims are not reusable or if any parts have been replaced, operating clearances will need to be re-established. Refer to **ADJUSTING END CLEARANCE**, page 13. Otherwise, place the head shims on the head. The proper amount of shims should be used to provide the correct end clearance. Table 6 gives the quantity of shims available in a gasket set along with standard end clearance.




FIGURE 17

	NORMAL ¹ END CLEARANCE	SET OF HEAD Shims INCLUDES
GS, GG 855	0.003	(1) .007 (1) .005
HJ, HL 855	0.005	(2) .002 (2) .001

¹ End Clearances are adequate for viscosities up to 2500 SSU / 540 cSt (SAE 40 lube oil at room temperature). Higher viscosities require additional clearances. As a general rule the end clearance is doubled for higher viscosities. For specific recommendations for end clearance for viscosity or for operating temperatures above 225°F, check with your Viking representative or consult the factory.

TABLE 6

7. Coat the idler pin with a suitable lubricant and place the idler on the idler pin in head. Make sure the O-ring for the head is installed.
8. The head can now be assembled onto the pump. Tilt the top of the pump head away from the pump slightly until the crescent enters the inside diameter of the rotor and rotate the idler until its teeth mesh with the rotor teeth.

The pump head and casing should have been marked before disassembly to insure proper reassembly. If not, be sure the idler pin, which is offset in the pump head, is positioned toward and an equal distance from the port connections to allow for proper flow of liquid through the pump. Install the head capscrews. Rotate the shaft to make sure it turns freely.

9. Follow the instructions listed for assembling the appropriate size coupling on pages 11 and 12.

CHANGING PUMP ROTATION

The pump is designed to operate in either direction. Process fluid is generally fed to the inner thrust washer and bushing interface and then through a groove in the bushing to the outer thrust washer. Then the fluid is pulled into the canister bushing and back through the hollow shaft and idler pin to the suction side of the pump. When the pump is operated in the opposite direction, the fluid flow is reversed.




FIGURE 18

*Hot water makes the PTFE® more pliable and allows the inner elastomer to pull the PTFE back to the original size.

ASSEMBLY OF COUPLING

Series MD2- A4 / A9 Coupling

DANGER!

Follow these directions exactly to avoid injury to self or damage to the pumping unit. Be careful to keep inner and outer magnets at least (1) foot apart until step 5. Do not engage the magnets in any other fashion.

1. Inspect the magnets for any steel objects, which may be attached. Remove any foreign material. Locate the outer magnet assembly per dimension (See Figure 19). Apply Loctite and tighten the 2 setscrews onto the motor or bearing carrier key & shaft.
2. Mount the coupling bracket to the motor (or bearing carrier) and secure with 4 capscrews (Figure 20). Carefully reach in and rotate the magnets by hand to make sure there is no interference. If rubbing occurs check the dimension in Figure 19 or contact the factory.
3. Check to make sure the pump rotates freely by turning the inner magnet assembly. Inspect the magnet to make sure it has not picked up any foreign particles, which could damage the pump. Make sure the canister O-ring is in good condition and in place. Place the canister onto the pump and press on until the canister is in contact with the pump mounting flange.


CAUTION !

Do not place fingers onto front of pump mounting flange. Align canister into bore of bracket and gently slide in. When magnets start to engage, the unit will finish engagement on its own very rapidly. Make sure fingers are not on the front of the pump (see Figure 20).

DANGER!

Be certain that the driving means (motor, turbine, engine, etc.) Has been "locked out" or made non-operational so that it cannot be started while work is being done on pump.

4. Finish the assembly by securing the pump to the bracket (See Figure 20). Check that the pump rotates freely by spinning the motor fan blades or bearing carrier shaft.



MD2-A Magnets		
Motor	"A" Dimension (Inch)	"A" Dimension (Metric)
I.E.C. 90/100/112	6.32	160.5 MM
56C/143TC/145TC	6.5	165.1 MM
182TC/184TC	6.7	170.2 MM

FIGURE 19





FIGURE 21

Series MD2 – B14 Through B50 Coupling

DANGER !

Follow these directions exactly to avoid injury to self or damage to the pumping unit. Be careful to keep inner and outer magnets at least (1) foot apart until step 4. Do not engage magnets in any other fashion.

1. Inspect the magnets for any steel objects, which may be attached. Remove any foreign material. Locate the outer magnet assembly per dimension (See Figure 22). Apply Loctite and tighten the setscrews onto the motor or bearing carrier key and shaft.
2. If the bracket is not fastened to a base, clamp it down. Mount the motor or bearing carrier to the bracket. Reach in and rotate the magnets by hand to make sure there is no interference. If rubbing occurs check the dimension in Figure 22 or contact the factory.
3. Check to make sure pump rotates freely by turning inner magnet assembly. Inspect magnet to make sure it has not picked up any foreign particles, which could damage the pump. Make sure the canister O-ring is in good condition and in place. Place canister onto pump and press on until canister is in contact with pump mounting flange.
4. Use a fully threaded M10X120mm capscrew to control assembling the pump. Thread completely into bracket as shown in Figure 23. Support pump with overhead hoist if possible while guiding canister into bracket opening. Back capscrew off while guiding the pump being careful that end of capscrew is positioned in counterbore hole of casing flange. Mount pump with (4) 12mm capscrews.


CAUTION !

Do not place fingers onto front of pump mounting flange. Align canister into bore of bracket and gently slide in. When magnets start to engage, the unit will finish engagement on its own very rapidly unless the M10x120mm capscrew is properly used. Make sure fingers are not on the front of the pump. See Figure 23.

DANGER!

Be certain that the driving means (motor, turbine, engine, etc.) has been “locked out” or made non-operational so that it cannot be started while work is being done on pump.

5. Be certain that the power supply to the pump is “Locked-out”. Finish assembly by securing the pump to the bracket. See Figure 23. Check that pump rotates freely by spinning the motor fan blades or the bearing carrier shaft.



MD2-B Magnets		
Motor	“A” Dimension (Inch)	“A” Dimension (Metric)
I.E.C. 100/112	7.73	196.4 MM
I.E.C. 132	8.53	216.5 MM
182TC/184TC	8.11	206 MM
213TC/215TC	8.49	215.7 MM
254TC/256TC	9.11	231.5 MM

FIGURE 22




FIGURE 23
PUMP AND BRACKET ASSEMBLY SEQUENCE

ADJUSTING END CLEARANCE

Use either of the following procedure to properly adjust the end clearance when replacing shims.

PROCEDURE A

After rotor has been installed and locknut has been positioned and retained, insert a feeler gage of the proper end clearance into the port and between two rotor teeth (See Figure 24). For convenience, remove head O-ring and install one 0.007" shim onto the head. With idler on idler pin, place the head into the pump casing. With the capscrews tight, the feeler gage should fit snugly; otherwise shims should be added or reduced in thickness until the proper clearance is attained.



FIGURE 24

PROCEDURE B

If the pump is in line and ports are not accessible, remove the head and shims. Put the head back on (without shims) and measure the gap as shown (See Figure 25). After determining the gap between the head and casing, select a combination of shims equal to the measured gap plus the desired end clearance (See Figure 25). Remove head, install shims then install head. Tighten the head capscrews and check the pump clearance by making sure the pump turns freely by hand. Since the pump shaft is concealed, it is best to work up the proper end clearance because it is difficult to determine when there is too much end clearance with this approach.




FIGURE 25

PRESSURE RELIEF VALVE INSTRUCTIONS

DANGER !

Before opening any Viking pump liquid chamber (pumping chamber, reservoir, relief valve adjusting cap fitting etc.) Be sure:

1. That any pressure in chamber has been completely vented through suction or discharge lines or other appropriate openings or connections.
2. That the driving means (motor, turbine, engine, etc.) has been "locked out" or made non-operational so that it cannot be started while work is being done on pump.

3. That you know what liquid the pump has been handling and the precautions necessary to safely handle the liquid. Obtain a material safety data sheet (MSDS) for the liquid to be sure these precautions are understood.

Failure to follow above listed precautionary measures may result in serious injury or death.

DISASSEMBLY – RELIEF VALVE

Mark the valve and head before disassembly to insure proper reassembly.

1. Remove the valve cap.
2. Measure and record the length of extension of the adjusting screw. Refer to "A" on Figure 26.
3. Loosen the locknut and back out the adjusting screw until spring pressure is released.
4. Remove the bonnet, spring guide, spring and poppet from the valve body. Clean and inspect all parts for wear or damage and replace as necessary.

ASSEMBLY – RELIEF VALVE

Reverse the procedures outlined under **DISASSEMBLY – RELIEF VALVE**. If the valve is removed for repairs, be sure to replace in the original position. The relief valve adjusting screw cap must **always** point towards the suction side of the pump. If the pump rotation is reversed, remove the relief valve and turn end for end. Refer to Figure 4, page 4.




FIGURE 26
VALVE – GS, GG, HJ AND HL SIZES

VALVE - LIST OF PARTS	
1. Valve Cap	6. Valve Body
2. Adjusting Screw	7. Valve Spring
3. Lock Nut	8. Poppet
4. Spring Guide	9. Cap Gasket
5. Bonnet	

TABLE 7

DANGER!

Before starting pump, be sure all drive equipment guards are in place.

Failure to properly mount guards may result in serious injury or death.

PRESSURE ADJUSTMENT

If a new spring is installed or if the pressure setting of the pressure relief valve is to be changed from that which the factory has set, the following instructions must be carefully followed.

1. Carefully remove the valve cap, which covers the adjusting screw.
2. Loosen the locknut, which locks the adjusting screw so pressure setting will not change during operation of pump.
3. Install a pressure gauge in the discharge line for the actual adjustment operation.
4. Turn the adjusting screw in to increase pressure and out to decrease pressure.
5. With discharge line closed at a point beyond the pressure gauge, gauge will show the maximum pressure valve will allow while the pump is in operation.

IMPORTANT

When ordering parts for the pressure relief valve, always give the model number and serial number of the pump as it appears on nameplate and name of the part wanted. When ordering springs, be sure to give pressure setting desired.

TROUBLESHOOTING

Some of the following may help pinpoint the problem:

Pump does not pump:

- Pump has lost its prime from air leak or low level in tank.
- Suction lift is too high.
- Pump is rotating in the wrong direction.
- The strainer may be clogged.
- The bypass valve is open, the pressure relief valve is set too low or the pressure relief valve poppet is stuck open.
- Improper end clearance.
- The pump is worn out.
- Are there any changes in liquid, system or operation that would influence pump or coupling performance, e.g. new liquid, additional lines or process changes?
- Temperature changes either in the liquid or the environment.
- The magnetic coupling is decoupling. Changes in application (temperature, pressure, viscosity, etc.) may require torque beyond coupling capabilities.

Pump starts, then loses its prime:

- The supply tank is empty.
- Liquid is vaporizing in the suction line.
- An air leak or air pocket in the suction line.

Pump is noisy:

- The pump is being starved (heavy liquid cannot get to pump fast enough). Increase the suction pipe size, reduce its length or slow down the pump.
- The pump is cavitating (liquid vaporizing in suction line). Increase suction pipe size or reduce its length.
- Check alignment.
- The magnetic coupling has decoupled. Shut off and restart.

Pump is not delivering up to capacity:

- The pump is starving or cavitating - increase suction pipe size or reduce length or reduce pump speed.
- The strainer is partially clogged.
- An air leak somewhere in suction line.
- The pump may be running too slow. Is motor the correct speed and wired up correctly ?
- The pressure relief valve is set too low, stuck open or has a damaged poppet or seat.
- The bypass line around the pump is partially open.
- The pump is worn out or there is too much end clearance.

Pump takes too much power (stalls motor):

- The liquid is more viscous than the unit is sized to handle.
- The system pressure relief valve is set too high.
- The bushings have frozen up or the liquid has set up in the pump.



TECHNICAL SERVICE MANUAL

VIKING MAG DRIVE®

SERIES 855

Sizes GS, GG, HJ, HL

SECTION	TSM 685.1
PAGE	16 OF 16
ISSUE	E



WARRANTY

Viking warrants all products manufactured by it to be free from defects in workmanship or material for a period of one (1) year from date of startup, provided that in no event shall this warranty extend more than eighteen (18) months from the date of shipment from Viking. If, during said warranty period, any products sold by Viking prove to be defective in workmanship or material under normal use and service, and if such products are returned to Viking's factory at Cedar Falls, Iowa, transportation charges prepaid, and if the products are found by Viking to be defective in workmanship or material, they will be replaced or repaired free of charge, FOB. Cedar Falls, Iowa.

Viking assumes no liability for consequential damages of any kind and the purchaser by acceptance of delivery assumes all liability for the consequences of the use or misuse of Viking products by the purchaser, his employees or others. Viking will assume no field expense for service or parts unless authorized by it in advance.

Equipment and accessories purchased by Viking from outside sources which are incorporated into any Viking product are warranted only to the extent of and by the original manufacturer's warranty or guarantee, if any.

THIS IS VIKING'S SOLE WARRANTY AND IS IN LIEU OF ALL OTHER WARRANTIES, EXPRESSED OR IMPLIED, WHICH ARE HEREBY EXCLUDED, INCLUDING IN PARTICULAR ALL WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. No officer or employee of IDEX Corporation or Viking Pump, Inc. is authorized to alter this warranty.