


SHARP SERVICE MANUAL

S1802R200BPW/

MICROWAVE OVEN



MODELS **R-200BK** **R-200BW**

In the interest of user-safety the oven should be restored to its original condition and only parts identical to those specified should be used.

WARNING TO SERVICE PERSONNEL: Microwave ovens contain circuitry capable of producing very high voltage and current, contact with following parts may result in a severe, possibly fatal, electrical shock. (High Voltage Capacitor, High Voltage Power Transformer, Magnetron, High Voltage Rectifier Assembly, High Voltage Harness etc..)

TABLE OF CONTENTS

	Page
PRECAUTIONS TO BE OBSERVED BEFORE AND DURING SERVICING TO AVOID POSSIBLE EXPOSURE TO EXCESSIVE MICROWAVE ENERGY	INSIDE FRONT COVER
BEFORE SERVICING	INSIDE FRONT COVER
WARNING TO SERVICE PERSONNEL	1
MICROWAVE MEASUREMENT PROCEDURE	2
FOREWORD AND WARNING	3
PRODUCT SPECIFICATIONS	4
GENERAL INFORMATION	4
OPERATION	6
TROUBLESHOOTING GUIDE	9
TEST PROCEDURE	10
TOUCH CONTROL PANEL	16
COMPONENT REPLACEMENT AND ADJUSTMENT PROCEDURE	20
PICTORIAL DIAGRAM	26
CONTROL PANEL CIRCUIT	27
PRINTED WIRING BOARD	28
PARTS LIST	29
PACKING AND ACCESSORIES	31

SHARP CORPORATION

This document has been published to be used for after sales service only.

The contents are subject to change without notice.

PRECAUTIONS TO BE OBSERVED BEFORE AND DURING SERVICING TO AVOID POSSIBLE EXPOSURE TO EXCESSIVE MICROWAVE ENERGY

- (a) Do not operate or allow the oven to be operated with the door open.
- (b) Make the following safety checks on all ovens to be serviced before activating the magnetron or other microwave source, and make repairs as necessary: (1) interlock operation, (2) proper door closing, (3) seal and sealing surfaces (arcing, wear, and other damage), (4) damage to or loosening of hinges and latches, (5) evidence of dropping or abuse.
- (c) Before turning on microwave power for any service test or inspection within the microwave generating compartments, check the magnetron, wave guide or transmission line, and cavity for proper alignment, integrity, and connections.
- (d) Any defective or misadjusted components in the interlock, monitor, door seal, and microwave generation and transmission systems shall be repaired, replaced, or adjusted by procedures described in this manual before the oven is released to the owner.
- (e) A microwave leakage check to verify compliance with the Federal Performance Standard should be performed on each oven prior to releasing oven to the owner.

BEFORE SERVICING

Before servicing an operative unit, perform a microwave emission check as per the Microwave Measurement Procedure outlined in this service manual.

If microwave emissions level is in excess of the specified limit, contact SHARP ELECTRONICS CORPORATION immediately @1-800-237-4277.

If the unit operates with the door open, service person should 1) tell the user not to operate the oven and 2) contact SHARP ELECTRONICS CORPORATION and Food and Drug Administration's Center for Devices and Radiological Health immediately.

Service personnel should inform SHARP ELECTRONICS CORPORATION of any certified unit found with emissions in excess of $4\text{mW}/\text{cm}^2$. The owner of the unit should be instructed not to use the unit until the oven has been brought into compliance.


WARNING TO SERVICE PERSONNEL

Microwave ovens contain circuitry capable of producing very high voltage and current, contact with following parts may result in a severe, possibly fatal, electrical shock.

(Example)

High Voltage Capacitor, High Voltage Power Transformer, Magnetron, High Voltage Rectifier Assembly, High Voltage Harness etc..


Read the Service Manual carefully and follow all instructions.



**Don't Touch !
Danger High Voltage**

Before Servicing



1. Disconnect the power supply cord , and then remove outer case.
2. Open the door and block it open.
3. Discharge high voltage capacitor.

WARNING: RISK OF ELECTRIC SHOCK. DISCHARGE THE HIGH-VOLTAGE CAPACITOR BEFORE SERVICING.

The high-voltage capacitor remains charged about 60 seconds after the oven has been switched off. Wait for 60 seconds and then short-circuit the connection of the high-voltage capacitor (that is the connecting lead of the high-voltage rectifier) against the chassis with the use of an insulated screwdriver.

Wherever troubleshooting is performed the power supply must be disconnected. It may in, some cases, be necessary to connect the power supply after the outer case has been removed, in this event,

1. Disconnect the power supply cord, and then remove outer case.
2. Open the door and block it open.
3. Discharge high voltage capacitor.
4. Disconnect the leads to the primary of the power transformer.
5. Ensure that the leads remain isolated from other components and oven chassis by using insulation tape.
6. After that procedure, reconnect the power supply cord.

When the testing is completed,

1. Disconnect the power supply cord, and then remove outer case.
2. Open the door and block it open.
3. Discharge high voltage capacitor.
4. Reconnect the leads to the primary of the power transformer.
5. Reinstall the outer case (cabinet).
6. Reconnect the power supply cord after the outer case is installed.
7. Run the oven and check all function.

After repairing

1. Reconnect all leads removed from components during testing.
2. Reinstall the outer case (cabinet).
3. Reconnect the power supply cord after the outer case is installed.
4. Run the oven and check all functions.

Microwave ovens should not be run empty. To test for the presence of microwave energy within a cavity, place a cup of cold water on the oven turntable, close the door and set the power to HIGH and set the microwave timer for two (2) minutes. When the two minutes has elapsed (timer at zero) carefully check that the water is now hot. If the water remains cold carry out **Before Servicing** procedure and re-examine the connections to the component being tested.

When all service work is completed and the oven is fully assembled, the microwave power output should be checked and microwave leakage test should be carried out.

MICROWAVE MEASUREMENT PROCEDURE

A. Requirements:

- 1) Microwave leakage limit (Power density limit): The power density of microwave radiation emitted by a microwave oven should not exceed 1 mW/cm^2 at any point 5cm or more from the external surface of the oven, measured prior to acquisition by a purchaser, and thereafter (through the useful life of the oven), 5 mW/cm^2 at any point 5cm or more from the external surface of the oven.
- 2) Safety interlock switches Primary interlock relay and door sensing switch shall prevent microwave radiation emission in excess of the requirement as above mentioned, secondary interlock switch shall prevent microwave radiation emission in excess of 5 mW/cm^2 at any point 5cm or more from the external surface of the oven.

B. Preparation for testing:

Before beginning the actual measurement of leakage, proceed as follows:

- 1) Make sure that the actual instrument is operating normally as specified in its instruction booklet.

Important:

Survey instruments that comply with the requirement for instrumentation as prescribed by the performance standard for microwave ovens, 21 CFR 1030.10(c)(3)(i), must be used for testing.

- 2) Place the oven tray in the oven cavity.
- 3) Place the load of $275 \pm 15 \text{ ml}$ (9.8 oz) of tap water initially at $20 \pm 5^\circ \text{C}$ (68°F) in the center of the oven cavity. The water container shall be a low form of 600 ml (20 oz) beaker with an inside diameter of approx. 8.5 cm (3-1/2 in.) and made of an electrically nonconductive material such as glass or plastic. The placing of this standard load in the oven is important not only to protect the oven, but also to insure that any leakage is measured accurately.
- 4) Set the cooking control on Full Power Cooking Mode
- 5) Close the door and select a cook cycle of several minutes. If the water begins to boil before the survey is completed, replace it with 275 ml of cool water.

C. Leakage test:

Closed-door leakage test (microwave measurement)

- 1) Grasp the probe of the survey instrument and hold it perpendicular to the gap between the door and the body of the oven.
- 2) Move the probe slowly, not faster than 1 in./sec. (2.5 cm/sec.) along the gap, watching for the maximum indication on the meter.
- 3) Check for leakage at the door screen, sheet metal seams and other accessible positions where the continuity of the metal has been breached (eg., around the switches, indicator, and vents). While testing for leakage around the door pull the door away from the front of the oven as far as is permitted by the closed latch assembly.
- 4) Measure carefully at the point of highest leakage and make sure that the highest leakage is no greater than 4 mW/cm^2 , and that the secondary interlock switch does turn the oven OFF before any door movement.

NOTE: After servicing, record data on service invoice and microwave leakage report.

SERVICE MANUAL

SHARP

MICROWAVE OVEN

R-200BK/ R-200BW

FOREWORD

This Manual has been prepared to provide Sharp Electronics Corp. Service Personnel with Operation and Service Information for the SHARP MICROWAVE OVEN, R-200BK, R-200BW.

It is recommended that service personnel carefully study the entire text of this manual so that they will be qualified to render satisfactory customer service.

Check the interlock switches and the door seal carefully. Special attention should be given to avoid electrical shock and microwave radiation hazard.

WARNING

Never operate the oven until the following points are ensured.

- (A) The door is tightly closed.
- (B) The door brackets and hinges are not defective.
- (C) The door packing is not damaged.
- (D) The door is not deformed or warped.
- (E) There is not any other visible damage with the oven.

Servicing and repair work must be carried out only by trained service personnel.

DANGER

Certain initial parts are intentionally not grounded and present a risk of electrical shock only during servicing. Service personnel - Do not contact the following parts while the appliance is energized;

**High Voltage Capacitor, Power Transformer, Magnetron, High Voltage Rectifier Assembly, High Voltage Harness;
If provided, Vent Hood, Fan assembly, Cooling Fan Motor.**

All the parts marked "*" on parts list are used at voltages more than 250V.

Removal of the outer wrap gives access to voltage above 250V.

All the parts marked "Δ" on parts list may cause undue microwave exposure, by themselves, or when they are damaged, loosened or removed.

PRODUCT DESCRIPTION

GENERAL INFORMATION

OPERATION

TROUBLESHOOTING GUIDE AND
TEST PROCEDURE

TOUCH CONTROL PANEL

COMPONENT REPLACEMENT
AND ADJUSTMENT PROCEDURE

WIRING DIAGRAM

PARTS LIST

SHARP ELECTRONICS CORPORATION

SHARP PLAZA, MAHWAH,
NEW JERSEY 07430-2135

PRODUCT DESCRIPTION

SPECIFICATIONS

ITEM	DESCRIPTION
Power Requirements	120 Volts 60 Hertz Single phase, 3 wire grounded
Power Consumption	1030W / Approx. 9.0 Amperes
Power Output	600 W nominal of RF microwave energy (IEC 705 Test procedure) Operating frequency 2450 MHz
Case Dimensions	Width 18-1/8" Height 11-3/8" Depth 14-5/8"
Cooking Cavity Dimensions (0.7 Cubic feet)	Width 12-3/8" Height 7-7/8" Depth 12-5/8"
Control Complement	Light up dial timer (15 minutes) No cooking control
Oven Cavity Light	Yes
Safety Standard	UL Listed. FCC Authorized DHHS RUIes, CFR, Title 21, Chapter 1, Subchapter J

GENERAL INFORMATION

GROUNDING INSTRUCTIONS

This oven is equipped with a three prong grounding plug. It must be plugged into a wall receptacle that is properly installed and grounded in accordance with the National Electrical Code and local codes and ordinances.

In the event of an electrical short circuit, grounding reduces the risk of electric shock by providing an escape wire for the electric current.

WARNING: Improper use of the grounding plug can result in a risk of electric shock.


Electrical Requirements

The electrical requirements are a 115 -120 volt 60 Hz, AC only, 15 or 20 amp. fused electrical supply. It is recommended that a separate circuit serving only this appliance be provided. When installing this appliance, observe all applicable codes and ordinances.

A short power-supply cord is provided to reduce risks of becoming entangled in or tripping over a longer cord.


Where a two-pronged wall-receptacle is encountered, it is the personal responsibility and obligation of the customer to contact a qualified electrician and have it replaced with a properly grounded three-pronged wall receptacle or have a grounding adapter properly grounded and polarized. If the extension cord must be used, it should be a 3-wire, 15 amp. or higher rated cord. Do not drape over a countertop or table where it can be pulled on by children or tripped over accidentally.

CAUTION: DO NOT UNDER ANY CIRCUMSTANCES CUT OR REMOVE THE ROUND GROUNDING PRONG FROM THIS PLUG.






OVEN DIAGRAM


1. Oven door with see-through window
2. Safety door latches.
3. Door hinges
4. Door seals and sealing surfaces
5. Turntable motor shaft
6. Removable turntable support
7. Removable turntable
8. Ventilation openings. (Rear)
9. Oven lamp.
10. Wave guide cover.
11. Power supply cord







CONTROL PANEL

	BAKED POTATO COOK 1 medium	4~5min.
	FRESH VEGETABLES COOK 2 cups	6~8min.
	POPCORN POP 3.5 oz. bag	3~4min.

Light Up Dial



	DINNER PLATE REHEAT	3~4min.
	SOUP REHEAT 1 cup	4~5min.
	ROLL/MUFFIN REHEAT 1 medium	20sec.
	DEFROST Check chart in Operation Manual	

OPERATION

DESCRIPTION OF OPERATING SEQUENCE

The following is a description of component functions during oven operation.

OFF CONDITION

Closing the door activates door sensing switch and secondary interlock switch. (In this condition, the monitor switch contacts are opened.)

When oven is plugged in, 120 volts A.C. is supplied to the control unit. (Figure O-1).

COOKING CONDITION

When the Light Up Dial is turned, the following operations occur:

1. The contacts of the relay are closed and components connected to the relay are turned on as follows. (For details, refer to Figure O-2)

RELAY	CONNECTED COMPONENTS
RY-1	oven lamp/turntable motor/fan motor power transformer

2. 120 volts A.C. is supplied to the primary winding of the power transformer and is converted to about 3.5 volts A.C. output on the filament winding, and approximately 2000 volts A.C. on the high voltage winding.
3. The filament winding voltage heats the magnetron filament and the H.V. winding voltage is sent to a voltage doubler circuit.
4. The microwave energy produced by the magnetron is channelled through the waveguide into the cavity feed-

box, and then into the cavity where the food is placed to be cooked.

5. Upon completion of the cooking time, the power transformer, oven lamp, etc. are turned off, and the generation of microwave energy is stopped. The oven will revert to the OFF condition.
6. When the door is opened during a cook cycle, monitor switch, door sensing switch, secondary interlock switch and primary interlock relay (RY1) are activated with the following results. The circuits to the oven lamp, turntable motor, the cooling fan motor, and the high voltage components are de-energized, and the Light Up Dial indicates the time still remaining in the cook cycle when the door was opened.
7. The monitor switch is electrically monitoring the operation of the primary interlock relay (RY1) and the secondary interlock switch and is mechanically associated with the door so that it will function in the following sequence.

- (1) When the door opens from the closed position, the secondary interlock switch, door sensing switch and primary interlock relay (RY1) open their contacts. Then the monitor switch contacts close.
- (2) When the door is closed from the open position, the monitor switch contacts open first. Then the contacts of the secondary interlock switch and door sensing switch close.

If the secondary interlock switch and primary interlock relay (RY1) fail with the contacts closed when the door is opened, the closing of the monitor switch contacts will form a short circuit through the C/T fuse and primary interlock relay (RY1), causing the C/T fuse to blow.

SCHEMATIC
NOTE: CONDITION OF OVEN
1. LIGHT UP DIAL OFF.
2. DOOR CLOSED.





Figure O-1. Oven Schematic-Off Condition


SCHEMATIC

NOTE: CONDITION OF OVEN

1. DOOR CLOSED.
2. LIGHT UP DIAL ON.

**Figure O-2. Oven Schematic-Cooking Condition****DESCRIPTION AND FUNCTION OF COMPONENTS****DOOR OPEN MECHANISM**

The door is opened by pulling the door, refer to the Figure D-1.

**Figure D-1. Door Open Mechanism****DOOR SENSING AND SECONDARY INTERLOCK SWITCHES**

The secondary interlock switch is mounted in the lower position of the latch hook and the door sensing switch in the primary interlock system is mounted in the upper position of the latch hook. They are activated by the latch heads on the door. When the door is opened, the switches interrupt the power to all high voltage components. A cook cycle cannot take place until the door is firmly closed thereby activating both interlock switches. The primary interlock system consists of the door sensing switch and primary interlock relay located on the control circuit board.

MONITOR SWITCH

The monitor switch is activated (the contacts opened) by the latch head on the door while the door is closed. The switch is intended to render the oven inoperative, by means of blowing the C/T fuse, when the contacts of the primary interlock relay (RY1) and secondary interlock switch fail to open when the door is opened.

Functions:

1. When the door is opened, the monitor switch contacts close (to the ON condition) due to their being normally closed. At this time the primary interlock relay (RY1) and secondary interlock switch are in the OFF condition (contacts open) due to its being normally open contact switches.
2. As the door goes to a closed position, the monitor switch contacts are first opened and then the door sensing switch and secondary interlock switch contacts close.
3. If the door is opened, and the primary interlock relay (RY1) and the secondary interlock switch contact fail to open, the C/T fuse blows simultaneously with closing of the monitor switch contacts.

CAUTION: BEFORE REPLACING A BLOWN C/T FUSE, TEST THE DOOR SENSING SWITCH, PRIMARY INTERLOCK RELAY (RY1), SECONDARY INTERLOCK SWITCH AND MONITOR SWITCH FOR PROPER OPERATION. (REFER TO CHAPTER "TEST PROCEDURE").

NOTE: C/T FUSE AND MONITOR SWITCH ARE REPLACED AS AN ASSEMBLY

TURNTABLE MOTOR

The turntable motor rotates the turntable located on the bottom of the oven cavity, so that the food on the turntable is cooked evenly. The turntable may turn in either direction.

COOLING FAN MOTOR

The cooling fan motor drives a blade which draws external cool air. This cool air is directed through the air vanes surrounding the magnetron and cools the magnetron. This air is channelled through the oven cavity to remove steam and vapours given off from the heating foods. It is then exhausted through the exhausting air vents at the oven cavity.

MAGNETRON THERMAL CUT-OUT

The thermal cut-out located on the top of the oven cavity is designed to prevent damage to the magnetron if an over heated condition develops in the tube due to cooling fan failure, obstructed air guide, dirty or blocked air intake, etc. Under normal operation, the thermal cut-out remains closed.

However, when abnormally high temperatures are reached within the magnetron, the thermal cut-out will open at 257°F (125°C), causing the oven to shut down.

C/T FUSE

1. The C/T fuse blows when the contacts (COM-NO) of the primary interlock relay (RY2) and secondary interlock switch remain closed with the oven door open and when the monitor switch closes.
2. If the wire harness or electrical components are short-circuited, this C/T fuse blows to prevent an electric shock or fire hazard.
3. The C/T fuse, located on the top of the oven cavity, is designed to prevent damage to the oven by fire. If the food load is overcooked, by either error in cook time or defect in the timer, the C/T fuse will open.

Under normal operation, the C/T fuse remains closed. However, when abnormally high temperatures are reached within the oven cavity, the C/T fuse will open at 248°F (120°C), causing the oven to shut down or when the electric currents beyond 13A flow, the C/T fuse will open.

TROUBLESHOOTING GUIDE

Never touch any part in the circuit with your hand or an uninsulated tool while the power supply is connected.

When troubleshooting the microwave oven, it is helpful to follow the Sequence of Operation in performing the checks. Many of the possible causes of trouble will require that a specific test be performed. These tests are given a procedure letter which will be found in the "Test Procedure" section.

IMPORTANT: If the oven becomes inoperative because of a blown C/T fuse, check the monitor switch, primary interlock relay (RY1), door sensing switch and secondary interlock switch before replacing the C/T fuse. If C/T fuse is replaced, the monitor switch must also be replaced. Use part FFS-BA020WRK0 as an assembly.

IMPORTANT: Wherever troubleshooting is performed with the power supply cord disconnected. It may in, some cases, be necessary to connect the power supply cord after the outer case has been removed, in this event,

1. Disconnect the power supply cord, and then remove outer case.
2. Open the door and block it open.
3. Discharge high voltage capacitor.
4. Disconnect the leads to the primary of the power transformer.
5. Ensure that the leads remain isolated from other components and oven chassis by using insulation tape.
6. After that procedure, reconnect the power supply cord.

When the testing is completed,

1. Disconnect the power supply cord, and then remove outer case.
2. Open the door and block it open.
3. Discharge high voltage capacitor.
4. Reconnect the leads to the primary of the power transformer.
5. Reinstall the outer case (cabinet).
6. Reconnect the power supply cord after the outer case is installed.
7. Run the oven and check all function.

CK = Check / RE = Replace

TEST PROCEDURE		RE	CK	A	B	C	D	E	F	F	G	H	RE	RE	CK	I/J	CK	CK	CK	K
CONDITION	POSSIBLE CAUSE AND DEFECTIVE PARTS PROBLEM	SHORT IN POWER CORD	SHORT OR OPEN WIRING	MAGNETRON	POWER TRANSFORMER	H.V. RECTIFIER ASSEMBLY	HIGH VOLTAGE CAPACITOR	MAGNETRON THERMAL CUT-OUT	PRIMARY INTERLOCK SYSTEM	SECONDARY INTERLOCK SWITCH	MONITOR SWITCH	C/T FUSE	OVEN LAMP OR SOCKET	COOLING FAN MOTOR	TURNTABLE MOTOR	CONTROL UNIT OR RELAY	WRONG OPERATION	LOW VOLTAGE	DIRTY OVEN CAVITY	FOIL PATTERN ON PWB.
OFF CONDITION	Home fuse blows when power cord is plugged into wall receptacle.	<input type="radio"/>	<input type="radio"/>																	
	C/T fuse blows when power cord is plugged into wall receptacle.		<input type="radio"/>						<input type="radio"/>		<input type="radio"/>									
	C/T fuse blows when the door is opened.								<input type="radio"/>	<input type="radio"/>										
COOKING CONDITION	Fan motor does not operate. (All other electric components function.)		<input type="radio"/>											<input type="radio"/>						
	Oven lamp does not light at all. (All other electric components function.)		<input type="radio"/>										<input type="radio"/>							
	Turntable motor does not operate. (All other electric components function.)		<input type="radio"/>												<input type="radio"/>					
	Oven does not go into cook cycle when Light Up Dial is turned		<input type="radio"/>						<input type="radio"/>	<input type="radio"/>						<input type="radio"/>				
	Oven seems to be operating but little or no heat is produced in oven load. (Food incompletely cooked or not cooked at all at end of cook cycle.)		<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>		<input type="radio"/>							<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	
	Oven goes into a cook cycle but extremely uneven heating is produced in oven load (food).		<input type="radio"/>												<input type="radio"/>		<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	
	Oven lamp, turntable motor and fan motor do not operate.		<input type="radio"/>								<input type="radio"/>					<input type="radio"/>				

TEST PROCEDURES

PROCEDURE LETTER	COMPONENT TEST
------------------	----------------

A MAGNETRON ASSEMBLY TEST

1. Disconnect the power supply cord, and then remove outer case.
2. Open the door and block it open.
3. Discharge high voltage capacitor.
4. To test for an open filament, isolate the magnetron from the high voltage circuit. A continuity check across the magnetron filament leads should indicate less than 1 ohm.
5. To test for a shorted magnetron, connect the ohmmeter leads between the magnetron filament leads and chassis ground. This test should indicate an infinite resistance. If there is little or no resistance the magnetron is grounded and must be replaced.
6. Reconnect all leads removed from components during testing.
7. Reinstall the outer case (cabinet).
8. Reconnect the power supply cord after the outer case is installed.
9. Run the oven and check all functions.

MICROWAVE OUTPUT POWER

The following test procedure should be carried out with the microwave oven in a fully assembled condition (outer case fitted).

TEST PROCEDURES

PROCEDURE LETTER	COMPONENT TEST
	<p>HIGH VOLTAGES ARE PRESENT DURING THE COOK CYCLE, SO EXTREME CAUTION SHOULD BE OBSERVED.</p> <p>Power output of the magnetron can be measured by performing a water temperature rise test. This test should only be used if above tests do not indicate a faulty magnetron and there is no defect in the following components or wiring: silicon rectifier, high voltage capacitor and power transformer. This test will require a 16 ounce (453cc) measuring cup and an accurate mercury thermometer or thermocouple type temperature tester. For accurate results, the following procedure must be followed carefully:</p> <ol style="list-style-type: none">1. Fill the measuring cup with 16 oz. (453cc) of tap water and measure the temperature of the water with a thermometer or thermocouple temperature tester. Stir the thermometer or thermocouple through the water until the temperature stabilizes. Record the temperature of the water.2. Place the cup of water in the oven. Operate oven at POWER 10(HIGH) selecting more than 60 seconds cook time. Allow the water to heat for 60 seconds, measuring with a stop watch, second hand of a watch or the digital read-out countdown.3. Remove the cup from the oven and again measure the temperature, making sure to stir the thermometer or thermocouple through the water until the maximum temperature is recorded.4. Subtract the cold water temperature from the hot water temperature. The normal result should be 15 to 28°F(8.3 to 15.6°C) rise in temperature. If the water temperatures are accurately measured and tested for the required time period the test results will indicate if the magnetron tube has low power output (low rise in water temperature) which would extend cooking time or high power output (high rise in water temperature) which would reduce cooking time. Because cooking time can be adjusted to compensate for power output, the magnetron tube assembly should be replaced only if the water temperature rise test indicates a power output well beyond the normal limits. The test is only accurate if the power supply line voltage is 120 volts and the oven cavity is clean.
B	<p><u>POWER TRANSFORMER TEST</u></p> <ol style="list-style-type: none">1. Disconnect the power supply cord, and then remove outer case.2. Open the door and block it open.3. Discharge high voltage capacitor.4. Disconnect the primary input terminals and measure the resistance of the transformer with an ohmmeter. Check for continuity of the coils with an ohmmeter. On the R x 1 scale, the resistance of the primary coil should be less than 1 ohm and the resistance of the high voltage coil should be approximately 164 ohms; the resistance of the filament coil should be less than 1 ohm.5. Reconnect all leads removed from components during testing.6. Reinstall the outer case (cabinet).7. Reconnect the power supply cord after the outer case is installed.8. Run the oven and check all functions. <p>(HIGH VOLTAGES ARE PRESENT AT THE HIGH VOLTAGE TERMINAL, SO DO NOT ATTEMPT TO MEASURE THE FILAMENT AND HIGH VOLTAGE.)</p>
C	<p><u>HIGH VOLTAGE RECTIFIER TEST</u></p> <ol style="list-style-type: none">1. Disconnect the power supply cord, and then remove outer case.2. Open the door and block it open.3. Discharge high voltage capacitor.4. Isolate the rectifier from the circuit. Using the highest ohm scale of the meter, read the resistance across the terminals and observe, reverse the leads to the rectifier terminals and observe meter reading. If a short is indicated in both directions, or if an infinite resistance is read in both directions, the rectifier is probably defective and should be replaced.5. Reconnect all leads removed from components during testing.6. Reinstall the outer case (cabinet).7. Reconnect the power supply cord after the outer case is installed.

TEST PROCEDURES

PROCEDURE LETTER	COMPONENT TEST
	8. Run the oven and check all functions. NOTE: Be sure to use an ohmmeter that will supply a forward bias voltage of more than 6.3 volts.
D	<u>HIGH VOLTAGE CAPACITOR TEST</u> <ol style="list-style-type: none"> 1. Disconnect the power supply cord, and then remove outer case. 2. Open the door and block it open. 3. Discharge high voltage capacitor. 4. If the capacitor is open, no high voltage will be available to the magnetron. Disconnect input leads and check for short or open between the terminals using an ohmmeter. Checking with a high ohm scale, if the high voltage capacitor is normal, the meter will indicate continuity for a short time and should indicate an open circuit once the capacitor is charged. If the above is not the case, check the capacitor with an ohmmeter to see if it is shorted between either of the terminals and case. If it is shorted, replace the capacitor. 5. Reconnect all leads removed from components during testing. 6. Reinstall the outer case (cabinet). 7. Reconnect the power supply cord after the outer case is installed. 8. Run the oven and check all functions.
E	<u>MAGNETRON THERMAL CUT-OUT TEST</u> <ol style="list-style-type: none"> 1. Disconnect the power supply cord, and then remove outer case. 2. Open the door and block it open. 3. Discharge high voltage capacitor. 4. A continuity check across the thermal cut-out terminals should indicate a closed circuit. If the temperature of the magnetron reaches approximately 257°F(125°C), the thermal cut-out opens. An open thermal cut-out indicates overheating of the magnetron. Check for restricted air flow to the magnetron, especially the cooling fan air guide. 5. Reconnect all leads removed from components during testing. 6. Reinstall the outer case (cabinet). 7. Reconnect the power supply cord after the outer case is installed. 8. Run the oven and check all functions. <p style="text-align: center;">CAUTION: IF THE THERMAL CUT-OUT INDICATES AN OPEN CIRCUIT AT ROOM TEMPERATURE, REPLACE THERMAL CUT-OUT.</p>
F	<u>SECONDARY INTERLOCK SWITCH TEST</u> <ol style="list-style-type: none"> 1. Disconnect the power supply cord, and then remove outer case. 2. Open the door and block it open. 3. Discharge high voltage capacitor. 4. Isolate the switch and connect the ohmmeter to the common (COM.) and normally open (NO) terminal of the switch. The meter should indicate an open circuit with the door open and a closed circuit with the door closed. If improper operation is indicated, replace the secondary interlock switch. 5. Reconnect all leads removed from components during testing. 6. Reinstall the outer case (cabinet). 7. Reconnect the power supply cord after the outer case is installed. 8. Run the oven and check all functions. <p><u>PRIMARY INTERLOCK SYSTEM TEST</u></p> <p><u>DOOR SENSING SWITCH</u></p> <ol style="list-style-type: none"> 1. Disconnect the power supply cord, and then remove outer case. 2. Open the door and block it open. 3. Discharge high voltage capacitor. 4. Isolate the switch and connect the ohmmeter to the common (COM.) and normally open (NO) terminal of the switch. The meter should indicate an open circuit with the door open and a closed circuit with

TEST PROCEDURES

PROCEDURE LETTER

COMPONENT TEST

- the door closed. If improper operation is indicated, replace the door sensing switch.
5. Reconnect all leads removed from components during testing.
 6. Reinstall the outer case (cabinet).
 7. Reconnect the power supply cord after the outer case is installed.
 8. Run the oven and check all functions.


PRIMARY INTERLOCK RELAY (RY1)

1. Disconnect the power supply cord, and then remove outer case.
2. Open the door and block it open.
3. Discharge high voltage capacitor.
4. Disconnect two (2) wire leads from the male tab terminals of the Primary Interlock Relay. Check the state of the relay contacts using a ohmmeter. The relay contacts should be open. If the relay contacts are closed, replace the circuit board entirely or the relay itself.
5. Reconnect all leads removed from components during testing.
6. Reinstall the outer case (cabinet).
7. Reconnect the power supply cord after the outer case is installed.
8. Run the oven and check all functions.

G

MONITOR SWITCH TEST

1. Disconnect the power supply cord, and then remove outer case.
2. Open the door and block it open.
3. Discharge high voltage capacitor.
4. Before performing this test, make sure that the secondary interlock switch and the primary interlock relay are operating properly, according to the above Switch Test Procedure. Disconnect the wire lead from the monitor switch (COM) terminal. Check the monitor switch operation by using the ohmmeter as follows. When the door is open, the meter should indicate a closed circuit. When the monitor switch actuator is pushed by a screw driver through the lower latch hole on the front plate of the oven cavity with the door opened (in this condition the plunger of the monitor switch is pushed in), the meter should indicate an open circuit. If improper operation is indicated, the switch may be defective. After testing the monitor switch, reconnect the wire lead to the monitor switch (COM) terminal and check the continuity of the monitor circuit.
5. Reconnect all leads removed from components during testing.
6. Reinstall the outer case (cabinet).
7. Reconnect the power supply cord after the outer case is installed.
8. Run the oven and check all functions.



H

BLOWN C/T FUSE TEST

1. Disconnect the power supply cord, and then remove outer case.
2. Open the door and block it open.
3. Discharge high voltage capacitor.
4. If the C/T fuse is blown when the door is opened, check the primary interlock relay, secondary interlock switch and monitor switch according to the "TEST PROCEDURE" for those switches before replacing the blown C/T fuse.

CAUTION: BEFORE REPLACING A BLOWN C/T FUSE, TEST THE PRIMARY INTERLOCK RELAY, SECONDARY INTERLOCK SWITCH, DOOR SENSING SWITCH AND MONITOR SWITCH FOR PROPER OPERATION.

TEST PROCEDURES

PROCEDURE LETTER	COMPONENT TEST
	<p>If the C/T fuse is blown by improper switch operation, the C/T fuse and monitor switch must be replaced with "C/T fuse and monitor switch assembly" part number FFS-BA020WRK0, even if the monitor switch operates normally. The C/T fuse and monitor switch assembly is comprised of a 13 ampere fuse and switch.</p> <p>A continuity check across the C/T fuse terminals should indicate a closed circuit unless the temperature of the C/T fuse reaches approximately 248°F(120°C).</p> <p>An open C/T fuse indicates the oven overheated, Replace the oven C/T fuse and check the inside of the oven cavity, the proper setting of cooking time and the proper operation of control unit. Also check for proper air flow through the ovens venting system. Especially check the cooling fan for proper operation and the air guide for restriction.</p> <p>CAUTION: IF THE C/T FUSE INDICATES AN OPEN CIRCUIT AT ROOM TEMPERATURE, REPLACE THE C/T FUSE.</p> <ol style="list-style-type: none"> 5. Reconnect all leads removed from components during testing. 6. Reinstall the outer case (cabinet). 7. Reconnect the power supply cord after the outer case is installed. 8. Run the oven and check all functions.

I CONTROL PANEL ASSEMBLY TEST

WARNING : Do not touch the electrical parts and the printed wiring board to prevent an electric shock. Because the control unit is "TRANSLESS CIRCUIT" and many electrical parts are used at A.C. line voltage.

The control panel consists of circuits including semiconductors such as LSI, ICs, etc. Therefore, unlike conventional microwave ovens, proper maintenance cannot be performed with only a voltmeter and ohmmeter. In this service manual troubleshooting by unit replacement is described according to the symptoms indicated.

Before testing,

- 1) Disconnect the power supply cord and then remove outer case.
- 2) Open the door and block it open.
- 3) Discharge high voltage capacitor.
- 4) Disconnect the leads to the primary of the power transformer.
- 5) Ensure that these leads remain isolated from other components and oven chassis by using insulation tape.
- 6) After that procedure, re-connect the power supply cord.

1. Control Panel

The following symptoms indicate a defective control unit.

1-1 In connection with LEDs

- a) At a certain LED, all or some LEDs do not light up.
- b) At a certain LED, brightness is low.
- c) Only one LED does not light up.
- d) All or some LEDs continue to light up.
- e) A certain group of LEDs do not light up.
- f) The LEDs flicker.

1-2 Other possible troubles caused by defective control unit.

- a) Buzzer does not sound or continues to sound.
- b) Clock is not possible.
- c) Cooking time can not be set.

When testing is completed,

- 1) Disconnect the power supply cord and then remove outer case.
- 2) Open the door and block it open.
- 3) Discharge high voltage capacitor.
- 4) Reconnect all leads removed from components during testing.
- 5) Re-install the outer case (cabinet).
- 6) Reconnect the power supply cord after the outer case is installed.
- 7) Run the oven and check all function.

TEST PROCEDURES

PROCEDURE LETTER	COMPONENT TEST
------------------	----------------

J RELAY TEST

1. Disconnect the power supply cord and then remove outer case.
2. Open the door and block it open.
3. Discharge high voltage capacitor.
4. Disconnect the leads to the primary of the power transformer.
5. Ensure that these leads remain isolated from other components and oven chassis by using insulation tape.
6. After that procedure, re-connect the power supply cord.
7. Remove the outer case and check voltage between Pin No. 5 of the 3 pin connector (A) and the common terminal of the relay RY1 on the control unit with an A.C. voltmeter.
The meter should indicate 120 volts, if not check oven circuit.

RY1 Relay Test

These relays are operated by D.C. voltage

Check voltage at the relay coil with a D.C. voltmeter during the microwave cooking operation.

DC. voltage indicated Defective relay.

DC. voltage not indicated Check diode which is connected to the relay coil. If diode is good, control unit is defective.

RELAY SYMBOL	OPERATIONAL VOLTAGE	CONNECTED COMPONENTS
RY1	👉 Approx. 17.0V D.C.	Oven lamp / Turntable motor / Cooling fan motor / Power transformer

👉 The voltage under the condition when all LEDs light up.

8. Disconnect the power supply cord and then remove outer case.
9. Open the door and block it open.
10. Discharge high voltage capacitor.
11. Reconnect all leads removed from components during testing.
12. Re-install the outer case (cabinet).
13. Reconnect the power supply cord after the outer case is installed.
14. Run the oven and check all function.


K FOIL PATTERN ON THE PRINTED WIRING BOARD TEST

To protect the electronic circuits, this model is provided with a fine foil pattern added to the primary on the PWB, this foil pattern acts as a fuse.

1. Foil pattern check and repairs.
 - 1) Disconnect the power supply cord and then remove outer case.
 - 2) Open the door and block it open.
 - 3) Discharge high voltage capacitor.
 - 4) Follow the troubleshooting guide given below for repair.

STEPS	OCCURRENCE	CAUSE OR CORRECTION
1	Only pattern at "a" is broken.	*Insert jumper wire J1 and solder.
2	Pattern at "a" and "b" are broken.	*Insert the coil RCILF2003YAZZ between "c" and "d".

- 5) Make a visual inspection of the varistor.
Check for burned damage.



TEST PROCEDURES

PROCEDURE LETTER	COMPONENT TEST
---------------------	----------------

- 6) Reconnect all leads removed from components during testing.
- 7) Re-install the outer case (cabinet).
- 8) Reconnect the power supply cord after the outer case is installed.
- 9) Run the oven and check all function.
- 2. Follow the troubleshooting guide given below, if indicator does not light up after above check and repairs are finished.
 - 1) Disconnect the power supply cord and then remove outer case.
 - 2) Open the door and block it open.
 - 3) Discharge high voltage capacitor.
 - 4) Disconnect the leads to the primary of the power transformer.
 - 5) Ensure that these leads remain isolated from other components and oven chassis by using insulation tape.
 - 6) After that procedure, re-connect the power supply cord.
 - 7) Follow the troubleshooting guide given below for repair.

STEPS	OCCURRENCE	CAUSE OR CORRECTION
1	The rated AC voltage is not present between Pin No. 5 of the 3-pin connector (A) and the common terminal of the relay RY1	Check supply voltage and oven power cord.

- 8) Disconnect the power supply cord and then remove outer case.
- 9) Open the door and block it open.
- 10) Discharge high voltage capacitor.
- 11) Reconnect all leads removed from components during testing.
- 12) Re-install the outer case (cabinet).
- 13) Reconnect the power supply cord after the outer case is installed.
- 14) Run the oven and check all function.

CONTROL PANEL ASSEMBLY

OUTLINE OF CONTROL PANEL

Control Unit


Control unit consists of LSI, power source circuit, synchronizing signal circuit, ACL circuit, buzzer circuit, encoder circuit and indicator circuit.


1) LSI

This LSI controls the encoder signal, relay driving signal for oven function, buzzer signal and LED signal.

2) Power Source Circuit

This circuit generates voltage necessary in the control unit.

Symbol	Voltage	Application
VC	+5.0V	LSI(I-1)
VR	 +17.0V	RELAY(RY1)

 The voltage under the condition when all LEDs light up. The voltage VR will vary according to the quantity of the LEDs which light up.

3) Synchronizing Signal Circuit

The power source synchronizing signal is available in order to compose a basic standard time in the clock circuit. It accompanies a very small error because it works on commercial frequency.

4) ACL

A circuit to generate a signals which resets the LSI to the initial state when power is supplied.

5) Buzzer Circuit

The buzzer is responsive to signals from the LSI to emit audible sounds (completion sound).

6) Door Sensing Switch (Stop Switch)

A switch to "tell" the LSI if the door is open or closed.

7) Relay Circuit

To drive the magnetron, fan motor, turntable motor and light the oven lamp.

8) Encoder

The encoder generates the pulse signal, and the pulse signal is sent to the LSI.

9) Indicator Circuit

Indicator elements are the Light-emitting diodes (LD1-LD20).


This circuit consists of 4-digits and 5 segments.

DESCRIPTION OF LSI

LSI(IZA860DR)

The I/O signal of the LSI(IZA860DR) are detailed in the following table.

Pin No.	Signal	I/O	Description
1	RST	IN	Auto clear terminal. Signal is input to reset the LSI to the initial state when power is applied. Temporarily set to "L" level the moment power is applied, at this time the LSI is reset. Thereafter set at "H" level.
2	INT	IN	Signal coming from encoder. When the encoder is turned, the contacts of encoder make pulse signals. And pulse signals are input into INT.
3	AVSS	IN	A/D converter power source voltage. The power source voltage to drive the A/D converter in the LSI. Connected to GND.
4	VREF	IN	Reference voltage input terminal. A reference voltage is applied to the A/D converter in the LSI. Connected to GND.
5	K0	IN	Terminal to change functions according to the model. Signal in accordance with the model in operation is applied to set up its function.
6	K1	IN	Connected to GND.
7	AVDD	IN	A/D converter power source voltage. The power source voltage to drive the A/D converter in the LSI.
8	NC	—	No connection terminal.
9	S0	OUT	Digit selection signal. Signal is input to the anodes of the light-emitting diodes (LD1 - LD5).
10	S1	OUT	Digit selection signal. Signal is input to the anodes of the light-emitting diodes (LD6 - LD10).
11	S2	OUT	Digit selection signal. Signal is input to the anodes of the light-emitting diodes (LD11 - LD15).
12	S3	OUT	Digit selection signal. Signal is input to the anodes of the light-emitting diodes (LD16 - LD20).
13-14	NC	—	No connection terminal.
15	D0	OUT	Connected to VC.
16	D1	OUT	Magnetron high-voltage circuit, oven lamp, turntable motor and fan motor driving signal(Square Waveform : 60Hz) To turn on and off the relay (RY1). In 100% POWER operation, the signals hold "L" level during microwave cooking and "H" level while not cooking. 
17	CNVS	IN	Reference voltage input terminal. A reference voltage is applied to the A/D converter in the LSI. Connected to GND.
18	VSS	IN	Power source voltage: -0V. The power source voltage to drive the LSI is input to VSS terminal. Connected to GND.
19	D2	OUT	Segment data signal. Signal is input to the cathodes of the light-emitting diodes (LD1 ,LD6, LD11 and LD16).
20	D3	OUT	Segment data signal. Signal is input to the cathodes of the light-emitting diodes (LD1-LD2, LD6-LD7, LD12, LD16 and LD17).
21	D4	OUT	Segment data signal. Signal is input to the cathodes of the light-emitting diodes (LD1-LD3, LD6-LD8, LD11-LD13, LD16-LD17 and LD18).

Pin No.	Signal	I/O	Description
22	D5	OUT	Segment data signal. Signal is input to the cathodes of the light-emitting diodes (LD1-LD4, LD6-LD9, LD11-LD14, LD16-LD18 and LD19).
23-25	D6-D7	OUT	Segment data signal. Signal is input to the cathodes of all light-emitting diodes (LD1-D20).
26	NC	—	No connection terminal.
27	F0	IN	Input signal which communicates the door open/close information to LSI. Door closed; "L" level signal. Door opened; "H" level signal.
28	F1	OUT	Connected to CNTR.
29	F2	OUT	Terminal not used.
30	F3	IN	Signal coming from encoder. Signal similar to INT. Pulse signals are input into F3.
31-32	NC	—	No connection terminal.
33	XOUT	OUT	Internal clock oscillation frequency control output. Output to control oscillation input of XOUT.
34	XIN	IN	Internal clock oscillation frequency input setting. The internal clock frequency is set by inserting the ceramic filter oscillation circuit with respect to XIN terminal.
35	CNTR	OUT	Signal to sound buzzer. A: Completion sound. 
36	VDD	IN	Power source voltage: +5.0V. The power source voltage to drive the LSI is input to VDD terminal.


SERVICING

1. Precautions for Handling Electronic Components


This unit uses CMOS LSI in the integral part of the circuits. When handling these parts, the following precautions should be strictly followed. CMOS LSI have extremely high impedance at its input and output terminals. For this reason, it is easily influenced by the surrounding high voltage power source, static electricity charge in clothes, etc., and sometimes it is not fully protected by the built-in protection circuit.

In order to protect CMOS LSI.

- 1) When storing and transporting, thoroughly wrap them in aluminium foil. Also wrap PW boards containing them in aluminium foil.
- 2) When soldering, ground the technician as shown in the figure and use grounded soldering iron and work table.



2. Shapes of Electronic Components



Transistor
2SA1267Y
2SC1740S
DTA143ES
DTC143ES

3. Servicing of Touch Control Panel

We describe the procedures to permit servicing of the touch control panel of the microwave oven and the precautions you must take when doing so. To perform the servicing, power to the touch control panel is available either from the power line of the oven itself or from an external power source.

(1) Servicing the touch control panel with power supply of the oven :

CAUTION:

THE HIGH VOLTAGE TRANSFORMER OF THE MICROWAVE OVEN IS STILL LIVE DURING SERVICING AND PRESENTS A HAZARD .

Therefore, before checking the performance of the touch control panel,

- 1) Disconnect the power supply cord and then remove outer case.
- 2) Open the door and block it open.
- 3) Discharge high voltage capacitor.
- 4) Disconnect the leads to the primary of the power transformer.
- 5) Ensure that these leads remain isolated from other components and oven chassis by using insulation tape.
- 6) After that procedure, re-connect the power supply cord.

After checking the performance of the touch control panel,

- 1) Disconnect the power supply cord.
- 2) Open the door and block it open.
- 3) Re-connect the leads to the primary of the power transformer.
- 4) Re-install the outer case (cabinet).

5) Re-connect the power supply cord after the outer case is installed.

6) Run the oven and check all function.

- A. On some models, the power supply cord between the touch control panel and the oven itself is so short that the two can't be separated. For those models, check and repair all the controls (sensor-related ones included) of the touch control panel while keeping it connected to the oven.
- B. On some models, the power supply cord between the touch control panel and the oven proper is so long enough that they may be separated from each other. For those models, therefore, it is possible to check and repair the controls of the touch control panel while keeping it apart from the oven proper; in this case you must short both ends of the door sensing switch (on PWB) of the touch control panel with a jumper, which brings about an operational state that is equivalent to the oven door being closed. As for the sensor-related controls of the touch control panel, checking them is possible if the dummy resistor(s) with resistance equal to that of the controls are used.

(2) Servicing the touch control panel with power supply from an external power source:

Disconnect the touch control panel completely from the oven proper, and short both ends of the door sensing switch (on PWB) of the touch control panel, which brings about an operational state that is equivalent to the oven door being closed. Connect an external power source to the power input terminal of the touch control panel, then it is possible to check and repair the controls of the touch control panel; it is also possible to check the sensor-related controls of the touch control panel by using the dummy resistor(s).

4. Servicing Tools

Tools required to service the touch control panel assembly.

- 1) Soldering iron: 30W
(It is recommended to use a soldering iron with a grounding terminal.)
- 2) Oscilloscope: Single beam, frequency range: DC - 10MHz type or more advanced model.
- 3) Others: Hand tools

5. Other Precautions

- 1) Before turning on the power source of the control unit, remove the aluminium foil applied for preventing static electricity.
- 2) Connect the connector of the key unit to the control unit being sure that the lead wires are not twisted.
- 3) After aluminium foil is removed, be careful that abnormal voltage due to static electricity etc. is not applied to the input or output terminals.
- 4) Attach connectors, electrolytic capacitors, etc. to PWB, making sure that all connections are tight.
- 5) Be sure to use specified components where high precision is required.

COMPONENT REPLACEMENT AND ADJUSTMENT PROCEDURE

WARNING AGAINST HIGH VOLTAGE:

Microwave ovens contain circuitry capable of producing very high voltage and current, contact with following parts may result in severe, possibly fatal, electric shock.

(Example)

High Voltage Capacitor, Power Transformer, Magnetron, High Voltage Rectifier Assembly, High Voltage Harness etc..

WARNING: Avoid possible exposure to microwave energy. Please follow the instructions below before operating the oven.

1. Disconnect the power supply cord.
2. Visually check the door and cavity face plate for damage (dents, cracks, signs of arcing etc.).

Carry out any remedial work that is necessary before operating the oven.

Do not operate the oven if any of the following conditions exist;

1. Door does not close firmly.
2. Door hinge, support or latch hook is damaged.
3. The door gasket or seal is damaged.

4. The door is bent or warped.
5. There are defective parts in the door interlock system.
6. There are defective parts in the microwave generating and transmission assembly.
7. There is visible damage to the oven.

Do not operate the oven:

1. Without the RF gasket (Magnetron).
2. If the wave guide or oven cavity are not intact.
3. If the door is not closed.
4. If the outer case (cabinet) is not fitted.

WARNING FOR WIRING

To prevent an electric shock, take the following precautions.

1. Before wiring,
 - 1) Disconnect the power supply cord.
 - 2) Open the door and block it open.
 - 3) Discharge the high voltage capacitor and wait for 60 seconds.
2. Don't let the wire leads touch to the following parts;
 - 1) High voltage parts:
Magnetron, High voltage transformer, High voltage capacitor and High voltage rectifier assembly.
 - 2) Hot parts:
Oven lamp, Magnetron, High voltage transformer and Oven cavity.


- 3) Sharp edge:
Bottom plate, Oven cavity, Waveguide flange, Chassis support and other metallic plate.
- 4) Movable parts (to prevent a fault)
Fan blade, Fan motor, Switch, Switch lever, Open button.
3. Do not catch the wire leads in the outer case cabinet.
4. Insert the positive lock connector until its pin is locked and make sure that the wire leads do not come off even if the wire leads are pulled.
5. To prevent an error function, connect the wire leads correctly, referring to the Pictorial Diagram.

Please refer to 'OVEN PARTS, CABINET PARTS, CONTROL PANAL PARTS, DOOR PARTS', when carrying out any of the following removal procedures:

OUTER CASE REMOVAL

To remove the outer case, procedure as follows.

1. Disconnect the power supply cord.
2. Open the oven door and block it open.
3. Remove the two (2) screws from the lower portion of the rear cabinet using a T20H Torx type or GTXH20-100 screw driver.
4. Remove the remaining two (2) screws from rear and four (4) screws along the right and left side of outer case.
5. Slide the entire outer case back out about 1 inch (3 cm) to free it from retaining clips on the cavity face plate.
6. Lift entire outer case from the unit.



- CAUTION:** 1. DISCONNECT OVEN FROM POWER SUPPLY BEFORE REMOVING OUTER CASE.
2. DISCHARGE THE HIGH VOLTAGE CAPACITOR BEFORE TOUCHING ANY OVEN COMPONENTS OR WIRING.

NOTE: When replacing the outer case, the 2 special Torx screws must be reinstalled in the same locations.

MAGNETRON REMOVAL

1. Disconnect the power supply cord and remove outer case.
2. Open the oven door and block it open.
3. Discharge high voltage capacitor.
4. Disconnect the wire leads from magnetron.
5. Remove the three (3) screws holding the magnetron to the waveguide.
6. Remove the magnetron from waveguide.
7. Now, the magnetron is free.

CAUTION: WHEN REPLACING THE MAGNETRON, BE SURE THE R.F. GASKET IS IN PLACE AND THE MAGNETRON MOUNTING SCREWS ARE TIGHTENED SECURELY.

HIGH VOLTAGE COMPONENTS REMOVAL (HIGH VOLTAGE CAPACITOR AND HIGH VOLTAGE RECTIFIER ASSEMBLY)

To remove the components, proceed as follows.

1. Disconnect the power supply cord and remove outer case.
2. Open the oven door and block it open.
3. Discharge high voltage capacitor.
4. Remove one (1) screw holding capacitor holder to rear cabinet.
5. Disconnect the H.V. wire of the H.V. rectifier assembly from the magnetron.
6. Disconnect the filament lead of the power transformer from the H.V. capacitor.
7. Remove one (1) screw holding ground side terminal of high voltage rectifier assembly, and remove capacitor holder.

8. Disconnect all the leads and terminals of high voltage rectifier assembly from high voltage capacitor.
9. Now the H.V. rectifier assembly and H.V. capacitor should be free.

CAUTION: WHEN REPLACING HIGH VOLTAGE RECTIFIER ASSEMBLY, ENSURE THAT THE CATHODE (GROUND) CONNECTION IS SECURELY FIXED TO THE CAPACITOR HOLDER WITH A GROUNDING SCREW.

CAUTION: DO NOT REPLACE ONLY HIGH VOLTAGE RECTIFIER. WHEN REPLACING IT, REPLACE HIGH VOLTAGE RECTIFIER ASSEMBLY.

POWER TRANSFORMER REMOVAL

1. Disconnect the power supply cord and remove outer case.
2. Open the oven door and block it open.
3. Discharge high voltage capacitor.
4. Disconnect the wire leads (main wire harness and H.V. wire) from power transformer.
5. Disconnect the lead from magnetron filament.
6. Disconnect the lead of the power transformer from high voltage capacitor.
7. Remove the two (2) screws holding the transformer to bottom plate.
8. Remove the transformer.

9. Now the power transformer is free.

Re-install

1. Rest transformer on the bottom plate with its primary terminals toward the oven face plate.
2. Secure transformer with two (2) screws to the bottom plate.
3. Re-connect wire leads (primary and high voltage) and filament leads to the power transformer, magnetron and high voltage capacitor, referring to "Pictorial Diagram".
4. Re-install outer case and check that the oven is operating properly.

OVEN LAMP AND LAMP SOCKET REMOVAL

1. Disconnect the power supply cord and remove outer case.
2. Open the door and block it open.
3. Discharge high voltage capacitor.
4. Pull the wire leads from the oven lamp socket by pushing the terminal hole of the oven lamp socket with the flat type small screw driver.
5. Tear the cushion from the light mount plate.
6. Bend the tab of the light mount plate holding the oven.
7. Lift up the oven lamp socket.
8. Now, the oven lamp socket is free.




Figure C-1. Oven lamp socket

POSITIVE LOCK® CONNECTOR (NO-CASE TYPE) REMOVAL

1. Disconnect the power supply cord, and remove outer case.
2. Open the door and block it open.
3. Discharge high voltage capacitor.
4. Push the lever of positive lock® connector.
5. Pull down on the positive lock® connector.

CAUTION: WHEN CONNECTING THE POSITIVE LOCK® CONNECTORS TO THE TERMINALS, INSTALL THE POSITIVE LOCK® SO THAT THE LEVER FACES YOU




Figure C-2. Positive lock® connector

CONTROL PANEL ASSEMBLY REMOVAL

1. Disconnect the power supply cord and remove outer case.
2. Open the door and block it open.
3. Discharge high voltage capacitor.
4. Disconnect the leads from the control unit.
5. Remove the one (1) screw holding the chassis support to the front plate of the oven cavity.
6. Remove the chassis support from the oven.
7. Lift up the control panel and release it from the oven cavity.
8. Now, the control panel assembly is free.
9. Open the door. Remove the switch lever from the front plate of the oven cavity.

TURNTABLE MOTOR REMOVAL

Removal

1. Disconnect the power supply cord.
2. Remove the turntable and turntable support from the oven cavity.
3. Turn the oven over.
4. Cut the four (4) bridges holding the turntable motor cover to the bottom plate with the cutting pliers as shown in Figure C-3.

CAUTION: DO NOT DROP THE TURNTABLE MOTOR COVER INTO THE OVEN AFTER CUTTING THE BRIDGES. BECAUSE IT WILL DAMAGE THE WIRE LEADS OF THE MOTOR AND IT IS DIFFICULT TO REMOVE IT OUT OF THE OVEN.

5. Remove the turntable motor cover from the bottom plate.
6. Disconnect the wire leads from the turntable motor.
7. Remove the single (1) screw holding the turntable motor to the oven cavity.




Figure C-3. Turntable Motor Cover

8. Remove the turntable motor from the oven cavity.
9. Remove the O-ring and washer from the turntable motor.
10. Now, the turntable motor is free.

Re-install

1. Remove the any sharp edges on the turntable motor cover and the bottom plate with the cutting pliers.
2. Re-install the O-ring.
3. Apply the grease (Shinetsu silicone grease G-420 of Sinetsu Chemical Co. Ltd. or Toray Silicone grease SH-14 of Toray Silicone Co., Ltd.) to the O-ring and the base of the turntable motor shaft as shown in Figure C-4.
4. Re-install the turntable motor with the O-ring and washer to the oven cavity with the single (1) screw.
5. Re-connect the wire leads to the turntable motor.
6. Insert the tab of the turntable motor cover into the hole of the bottom plate as shown in Figure C-3.
7. Re-install the turntable motor cover to the bottom plate with one (1) screw XHTSD40P08RV0 or XFPSD40P08K00 as shown in Figure C-3.




Figure C-4. Washer and O-ring Installation and Grease Applying.

COOLING FAN MOTOR REMOVAL

REMOVAL

1. Disconnect the power supply cord and remove outer case.
2. Open the door and block it open.
3. Discharge high voltage capacitor.
4. Disconnect the wire leads from the fan motor.
5. Remove the one (1) screw holding the chassis support to the oven cavity front plate.
6. Remove the chassis support .
7. Release the filament lead of the power transformer and the H.V. wire from the fan duct.
8. Remove the one (1) screw holding the light mounting plate to the oven cavity.
9. Release the wire leads (to the oven lamp) from the hole of the fan duct.
10. Release the fan motor assembly from the oven cavity.
11. Remove the fan blade from the fan motor shaft according to the following procedure.
12. Hold the edge of the rotor of the fan motor by using a pair of groove joint pliers.

CAUTION:


- **Make sure that any pieces do not enter the gap between the rotor and the stator of the fan motor. Because the rotor is easy to be shaven by pliers and metal pieces may be produced.**
- **Do not touch the pliers to the coil of the fan motor because the coil may be cut or injured.**
- **Do not disfigure the bracket by touching with the pliers.**

13. Remove the fan blade assembly from the shaft of the fan motor by pulling and rotating the fan blade with your hand.


14. Now, the fan blade will be free.

CAUTION:


- **Do not re-use the removed fan blade because the hole (for shaft) may be larger than normal.**



Rear View



Side View



15. Remove the two (2) screws holding the fan motor to the fan duct.
16. Now, the fan motor is free.

INSTALLATION

1. Install the fan motor to the fan duct with the two (2) screws.
2. Install the fan blade to the fan motor shaft according to the following procedure.
3. Hold the center of the bracket which supports the shaft of the fan motor on the flat table.
4. Apply the screw lock tight into the hole (for shaft) of the fan blade.
5. Install the fan blade to the shaft of fan motor by pushing the fan blade with a small, light weight, ball peen hammer or rubber mallet.

CAUTION:

- **Do not hit the fan blade strongly when installed because the bracket may be transformed.**
- **Make sure that the fan blade rotates smooth after installed.**
- **Make sure that the axis of the shaft is not slanted.**

6. Install the fan motor assembly to the oven cavity by fitting the tabs of the fan duct into the holes of the oven cavity and the waveguide flange.
7. Re-install the light mounting plate to the oven cavity with the one (1) screw.
8. Insert the end of the chassis support into the slit of the oven cavity rear cabinet.
9. Re-install the chassis support to the oven cavity front plate with the one (1) screw.
10. Install the filament lead and the H.V. wire into the hole of the fan duct .
11. Re-install the wire leads (to the oven lamp) to the hole of the fan duct.
12. Connect the wire leads to the fan motor, referring to the pictorial diagram.

DOOR SENSING SWITCH, SECONDARY INTERLOCK SWITCH AND MONITOR SWITCH REMOVAL

1. Disconnect the power supply cord and remove outer case.
2. Open the door and block it open.
3. Discharge high voltage capacitor.
4. Disconnect wire leads from the switches and control panel.
5. Remove the control panel assembly from the oven cavity front flange. Refer to chapter "CONTROL PANEL ASSEMBLY REMOVAL".
6. Remove two (2) screws holding latch hook to oven flange.
7. Remove latch hook assembly from oven flange.
8. To remove the secondary interlock switch.
 - 8-1. Pull out the secondary interlock switch from the latch hook, by pushing outward on the tab that is holding the switch. But the switch will be caught by the bar of the latch hook.

- 8-2. Then pull out the switch while pushing the plunger of the switch again.
- 8-3. Now the secondary interlock switch is free.
9. To remove the monitor switch or door sensing switch.
 - 9-1. Push outward on the tab that is holding the switch then pull the switch upward.
 - 9-2. Pull out the switch from the latch hook. Do not break the pole or tab of the latch hook.
 - 9-3. Now the switch is free.

Re-install

1. Re-install each switch in its place. The secondary interlock switch is in the lower position and the monitor switch is in the middle position. The door sensing switch is in the upper position.
2. Re-connect wire leads to each switch. Refer to chapter "Pictorial Diagram".
3. Secure latch hook (with two (2) mounting screws) to oven flange.
4. Re-install the control panel assembly to the oven cavity front flange.

5. Re-connect wire leads to the control unit. Refer to chapter "Pictorial Diagram".
6. Make sure that monitor switch is operating properly and check continuity of the monitor circuit. Refer to chapter "Test Procedure", and Adjustment Procedure below.




Figure C-5. Latch Switch Removal

DOOR SENSING SWITCH, SECONDARY INTERLOCK SWITCH AND MONITOR SWITCH ADJUSTMENT

1. Disconnect the power supply cord and remove outer case.
 2. Open the door and block it open.
 3. Discharge high voltage capacitor.
- If the door sensing switch, secondary interlock switch and monitor switch do not operate properly due to a misadjustment, the following adjustment should be made.
4. Loosen the two (2) screws holding the latch hook to the flange of the oven front face.
 5. With the door closed, adjust latch hook by moving it back and forth and up and down. In and out play of the door allowed by the upper and lower position of the latch hook should be less than 0.5mm. The horizontal position of the latch hook should be adjusted so that the monitor switch is activated with the door closed. The vertical position of the latch hook should be adjusted so that the door sensing switch and the secondary interlock switch are activated with the door closed.
 6. Secure the screws firmly.
 7. Check the operation of all switches. If each switch has not activated with the door closed, loosen screw and adjust the latch hook position.

After adjustment, make sure of the following.

1. In and out play of the door remains less than 0.5mm when in the latched position. First check upper position of latch hook, pushing and pulling upper portion of door toward the oven face. Then check lower portion of the

latch hook, pushing and pulling lower portion of door toward the oven face. Both results (play in the door) should be less than 0.5mm.

2. The door sensing switch and secondary interlock switch interrupt the circuit before the door can be opened.
3. The monitor switch contacts close when the door is opened.
4. The contacts of door sensing switch and secondary interlock switch open within 1.6mm gap between right side of cavity face plate and door when door is open.
5. Re-install outer case and check for microwave leakage around the door with an approved microwave survey meter. (Refer to Microwave Measurement Procedure.)




Figure C-6. Latch Switch Adjustments

DOOR REPLACEMENT

REMOVAL

1. Disconnect the power supply cord.
2. Open the door slightly.
3. Insert a putty knife (thickness of about 0.5mm) into the

- gap between the choke cover and corner portion of door panel as shown in Figure C-7 to free engaging parts.
4. Pry the principles of the lever and lift up the choke cover by inserting a putty knife in order shown in figure C-7.

5. Release choke cover from door panel.
6. Now choke cover is free.




Figure C-7. Door Disassembly

7. Release two (2) pins of door panel from two (2) holes of upper and lower oven hinges by lifting up.
8. Now, door panel is free from oven cavity.
9. Release door panel from ten (10) tabs of door frame and remove door frame by sliding the door panel downward.
10. Now, door panel with sealer film is free.
11. Tear sealer film from door panel.
12. Now, door panel is free.
13. Slide latch head upward and remove it from door frame with releasing latch spring from door frame and latch head.
14. Now, latch head and latch spring are free.
15. Remove door screen from door frame.
16. Now, door screen is free.

RE-INSTALL

1. Re-install door screen to door frame.
2. Re-install latch spring to the head. Re-install latch spring to the door frame. Re-install latch head to the door frame.
3. Re-install door panel to door frame by fitting ten (10) tabs of door frame to ten (10) holes of door panel.
4. Put sealer film on door panel. Refer to "Sealer Film" and figure C-9, on how to handle the new film.
5. Catch two (2) pins of door panel on two (2) hole of upper and lower oven hinges.
6. Re-install choke cover to door panel by pushing.

Note: After any service to the door;

- (A) **Make sure that door sensing switch, secondary interlock switch and monitor switch are operating properly. (Refer to chapter "Test Procedures").**
- (B) **An approved microwave survey meter should be used to assure compliance with proper microwave radiation emission limitation standards.**

After any service, make sure of the following :

1. Door latch heads smoothly catch latch hook through latch holes and that latch head goes through center of latch hole.
2. Deviation of door alignment from horizontal line of cavity face plate is to be less than 1.0mm.
3. Door is positioned with its face pressed toward cavity face plate.
4. Check for microwave leakage around door with an approved microwave survey meter. (Refer to Microwave Measurement Procedure.)

Note: The door on a microwave oven is designed to act as an electronic seal preventing the leakage of

microwave energy from oven cavity during cook cycle. This function does not require that door be airtight, moisture (condensation)-tight or light-tight. Therefore, occasional appearance of moisture, light or sensing of gentle warm air movement around oven door is not abnormal and do not of themselves, indicate a leakage of microwave energy from oven cavity.




Figure C-8. Door Replacement

SEALER FILM

Installation

1. Put the adhesive tape on the backing film of the sealer film as shown in Fig. C-9.
2. Tear the backing film by pulling the adhesive tape.
3. Put the pasted side of the sealer film on the door panel




Figure C-9. Sealer film




Figure S-1. Pictorial Diagram




Figure S-2. Control Panel Circuit




Figure S-3. Printed Wiring Board

PARTS LIST

Note: The parts marked "Δ" may cause undue microwave exposure.
The parts marked "*" are used in voltage more than 250V.

REF. NO.	PART NO.	DESCRIPTION	Q'TY	CODE
ELECTRIC PARTS				
1- 1	QSW-MA131WRE0	Secondary interlock switch & door sensing switch	2	AG
1- 2	FFS-BA020WRK0	C/T fuse & monitor switch assembly	1	AP
1- 3	FACDA040WRE0	Power supply cord	1	AS
1- 4	QSOCLA021WRE0	Oven lamp socket	1	AH
* 1- 5	FH-DZA082WRK0	High voltage rectifier	1	AQ
* 1- 6	RC-QZA193WRE0	High voltage capacitor	1	AW
* 1- 6	RC-QZA199WRE0	High voltage capacitor (Interchangeable)	1	AT
1- 7	RMOTEA338WRE0	Fan motor	1	AV
1- 7	RMOTEA355WRE0	Fan motor (Interchangeable)	1	AU
*Δ 1- 8	RV-MZA226WRE0	Magnetron	1	BE
*Δ 1- 8	RV-MZA282WRE0	Magnetron (Interchangeable)	1	BP
1- 9	RLMPTA030WRE0	Oven lamp	1	AF
1-10	RMOTDA186WRE0	Turntable motor	1	AW
1-10	RMOTDA211WRE0	Turntable motor (Interchangeable)	1	AS
1-11	RTHM-A078WRE0	Thermal cut-out 125°C	1	AK
* 1-12	RTRN-A560WRE0	Power transformer	1	BK

CABINET PARTS

2- 1	GCABUA657WRP0	Outer case cabinet [R-200BK]	1	AX
2- 1	GCABUA659WRP0	Outer case cabinet [R-200BW]	1	AX
2- 2	GDAI-A304WRP0	Bottom plate	1	AU
2- 3	GLEGPA074WRE0	Foot	2	AC

CONTROL PANEL PARTS

3- 1	CPWBFA758WRK0	Timer unit assembly [R-200BK]	1	BM
3- 1	CPWBFA759WRK0	Timer unit assembly [R-200BW]	1	BM
3- 1-1	CPWBFA772WRK0	Control unit	1	BM
3- 1-1A	QCNCMA430DRE0	3-pin connector (CN-A)	1	AG
3- 1-2	HPNLTA133WRE0	Timer sheet	1	AH
3- 1-3	JKNBKA597WRF0	Timer knob [R-200BK]	1	AF
3- 1-3	JKNBKA598WRF0	Timer knob [R-200BW]	1	AF
3- 1-4	LHLD-A184WRF0	LED holder	1	AH
C1	VCF2B62CA155K	Capacitor 1.5 uF 160VAC	1	AG
C3	VCEAB31EW108M	Capacitor 1000 uF 25V	1	AC
C4	RC-KZA087DRE0	Capacitor 0.1 uF 50V	1	AB
C5	VCEAB31CW476M	Capacitor 47 uF 16V	1	AA
C6	RC-KZA087DRE0	Capacitor 0.1 uF 50V	1	AB
C7	VCKYD11CY103N	Capacitor 0.01 uF 16V	1	AH
C20	VCEAB31HW104M	Capacitor 0.1 uF 50V	1	AB
C21	VCEAB31VW106M	Capacitor 10 uF 35V	1	AB
C30	VCKYD11CY103N	Capacitor 0.01 uF 16V	1	AH
C60-61	VCKYD11CY103N	Capacitor 0.01 uF 16V	2	AH
CF1	RCRS-A012DRE0	Ceramic resonator (CST4.00MGW)	1	AD
D1-4	VHD1N4005E61B	Diode (1N4005E)	4	AE
D20	VHD1SS270A/-1	Diode (1SS270A)	1	AA
D22	VHD1SS270A/-1	Diode (1SS270A)	1	AA
D30	VHD1SS270A/-1	Diode (1SS270A)	1	AA
D70-85	VHD1SS270A/-1	Diode (1SS270A)	16	AA
FUSE1	QFS-AA005DRE0	IC PROTECTOR	1	AE
I-1	RH-IZA860DRE0	LSI	1	AL
LD1-20	VHPLTL1CHE/-3	Light emitting diode (LED)	20	AD
Q1	VS2SC1740S/-3	Transistor (2SC1740S)	1	AB
Q2	VS2SA1267Y/-3	Transistor (2SA1267Y)	1	AA
Q20	VSDTC143ES/-3	Transistor (DTC143ES)	1	AB
Q21	VSDTA143ES/-3	Transistor (DTA143ES)	1	AB
Q40	VSDTC143ES/-3	Transistor (DTC143ES)	1	AB
Q70-73	VSDTA143ES/-3	Transistor (DTA143ES)	4	AB
R1-2	VRD-B12HF201J	Resistor 200 ohm 1/2W	2	AB
R3	VRS-B13AA102J	Resistor 1.0k ohm 1W	1	AA
R5	VRD-B12EF102J	Resistor 1.0k ohm 1/4W	1	AA
R6	VRD-B12EF472J	Resistor 4.7k ohm 1/4W	1	AA
R10	VRD-B12HF104J	Resistor 100k ohm 1/2W	1	AA
R11	VRS-L63DA101J	Resistor 100 ohm 2W	1	AD
R20-21	VRD-B12EF472J	Resistor 4.7k ohm 1/4W	2	AA
R30	VRD-B12EF472J	Resistor 4.7k ohm 1/4W	1	AA
R31	VRD-B12EF473J	Resistor 47k ohm 1/4W	1	AA
R40	VRD-B12EF472J	Resistor 4.7k ohm 1/4W	1	AA
R41	VRD-B12EF102J	Resistor 1.0k ohm 1/4W	1	AA

REF. NO.	PART NO.	DESCRIPTION	Q'TY	CODE
R42	VRD-B12EF332J	Resistor 3.3k ohm 1/4W	1	AA
R60-61	VRD-B12EF104J	Resistor 100k ohm 1/4W	2	AA
R62-63	VRD-B12EF472J	Resistor 4.7k ohm 1/4W	2	AA
R70	VRD-B12EF431J	Resistor 430 ohm 1/4W	1	AA
R71	VRD-B12EF331J	Resistor 330 ohm 1/4W	1	AA
R72	VRD-B12EF241J	Resistor 240 ohm 1/4W	1	AA
R73	VRD-B12EF151J	Resistor 150 ohm 1/4W	1	AA
R74	VRD-B12EF101J	Resistor 100 ohm 1/4W	1	AA
RY1	RRLY-A110DRE0	Relay (OMIF-S-124LM)	1	AL
SP1	RALM-A014DRE0	Buzzer (PKM22EPT)	1	AG
SW1	RVR-BA018WRE0	Rotary encoder	1	AL
VRS1	RH-VZA032DRE0	Varistor (10G471K)	1	AE
ZD1-2	VHEHZ12A1//-1	Zener diode (HZ12A1)	2	AA
ZD4-5	VHEHZ6C3///-1	Zener diode (HZ6C3)	2	AA
ZD6	VHEHZ4C3///-1	Zener diode (HZ4C3)	1	AA
3- 2	HPNLCA438WRR0	Control panel [R-200BK]	1	AV
3- 2	HPNLCA440WRR0	Control panel [R-200BW]	1	AV
3- 3	TCAUAA100WRR0	User caution label [R-200BK]	1	AC
3- 3	TCAUAA156WRR0	User caution label [R-200BW]	1	AF
3- 4	XEPSD30P08XS0	Screw; 3mm X 8mm	3	AA

OVEN PARTS

△ 4- 1	PHOK-A105WRF0	Latch hook	1	AL
4- 2	LANGQA477WRW0	Light mount plate	1	AY
4- 3	PCUSUA502WRP0	Waterproof cushion	1	AD
4- 4	LBNDKA038WRP0	Capacitor holder	1	AF
4- 5	NFANJA029WRE0	Fan blade	1	AL
4- 6	PDUC-A694WRF0	Fan duct	1	AG
4- 7	*****	Oven cavity (Not replaceable part)	1	--
4- 8	GLEGPA073WRF0	Leg	1	AD
4- 9	LANGTA318WRP0	Chassis support	1	AE
4-10	PCUSUA270WRP0	Cushion	1	AG
4-11	PCOVPA276WRE0	Waveguide cover	1	AM
4-12	PCOVPA342WRF0	B-cover Right	1	AH
4-13	PCOVPA343WRF0	B-cover Left	1	AH
4-14	PCUSUA443WRP0	Cushion	1	AE
4-15	PDUC-A700WRF0	Air separator	1	AN
4-16	PPACGA097WRE0	O-ring	1	AG

DOOR PARTS

△ 5- 1	FDORFA321WRT0	Door panel	1	AT
5- 2	GWAKPA552WRF0	Door frame [R-200BK]	1	AY
5- 2	GWAKPA551WRF0	Door frame [R-200BW]	1	AY
5- 3	HPNL-A686WRR0	Door screen	1	AY
△ 5- 4	LSTPPA175WRF0	Latch head	1	AE
5- 5	MSPRTA084WRE0	Latch spring	1	AB
5- 6	PSHEPA622WRE0	Sealer film	1	AG
5- 7	GCOVHA390WRF0	Choke cover	1	AK
5- 8	XCPD40P08000	Screw : 4mm x 8mm	4	AA

MISCLANEOUS

6- 1	FROLPA085WRK0	Turntable support	1	AS
6- 2	NTNT-A094WRE0	Turntable	1	AN
6- 3	TINS-A644WRR0	Instruction book	1	AD
6- 4	TCAUAA145WRR0	Earth caution	2	AG
6- 5	FW-VZB655WRE0	Main wire harness	1	BA
* 6- 6	QW-QZA150WRE0	High voltage wire B	1	AF
6- 7	TCAUAA166WRR0	DHHS caution label	1	AC
6- 8	TCAUAA240WRR0	Screw caution	1	AC
6- 9	TCAUAA239WRR0	Monitor caution	1	AC

SCREWS AND WASHERS

7- 1	XFPSD40P08K00	Screw : 4mm x 8mm	5	AA
7- 2	LX-EZA042WRE0	Special screw	2	AB
7- 3	LX-WZA028WRE0	Special washer	1	AB
7- 4	LX-CZA030WRE0	Special screw	5	AA
7- 5	XHTSD40P08RV0	Screw : 4mm x 8mm	4	AA
7- 6	XHPSD30P06000	Screw : 3mm x 6mm	1	AA
7- 7	XOTSD40P12RV0	Screw : 4mm x 12mm	2	AA
7- 8	XOTSD40P12000	Screw : 4mm x 12mm	6	AA
7- 9	XOTSE40P08000	Screw : 4mm x 8mm [R-200BW]	4	AA
7- 9	XOTSF40P08000	Screw : 4mm x 8mm [R-200BK]	4	AA
7-10	LX-CZA071WRE0	Special screw (Torx tamper proof screw)	2	AC

HOW TO ORDER REPLACEMENT PARTS


To have your order filled promptly and correctly, please furnish the following information.

1. MODEL NUMBER 2. REF. NO. 3. PART NO. 4. DESCRIPTION


Order Parts from the authorized SHARP parts Distributor for your area.


Defective parts required return should be returned as indicated in the Service Policy.

PACKING AND ACCESSORIES



OVEN AND CABINET PARTS





Actual wire harness may be different than illustration.

SHARP

COPYRIGHT © 1997 BY SHARP CORPORATION

ALL RIGHTS RESERVED.

No part of this publication may be reproduced, stored in a retrieval systems, or transmitted in any form or by any means, electronic, mechanical, photocopying, recording, or otherwise, without prior written permission of the publisher.