



Service Manual

Serial number range

GTH-4016 SR

From serial n.: 20094

GTH-4018 SR

From serial n.: 19785

**Part. No. 57.4400.9203
Rev A
March 2010**

Introduction

Important

Read, understand and obey the safety rules and operating instructions in the appropriate Operator's Manual on your machine before attempting any maintenance or repair procedure.

This manual provides detailed scheduled maintenance information for the machine owner and user. It also provides troubleshooting and repair procedures for qualified service professionals.

Basic mechanical, hydraulic and electrical skills are required to perform most procedures. However, several procedures require specialized skills, tools, lifting equipment and a suitable workshop. In these instances, we strongly recommend that maintenance and repair be performed at an authorized Genie dealer service center.

Contact us:

Genie Service Dept:

Area	Phone
UK	+44 1476 584 345
France	+33 237 260 986
Germany	+49 420 288 5232
Italy	+39 075 941 8175
Iberica	+34 935 725 380
Scandinavia	+46 3157 5113
Middle East	+97 143 391 800
	+97 150 459 7937
All other locations	+39 075 941 811

Technical Publications

Genie Industries has endeavored to deliver the highest degree of accuracy possible. However, continuous improvement of our products is a Genie policy. Therefore, product specifications are subject to change without notice.

Readers are encouraged to notify Genie of errors and send in suggestions for improvement. All communications will be carefully considered for future printings of this and all other manuals.



© Copyright 2010 **TEREXLIFT srl** - All rights reserved
Produced by:
TEREXLIFT Technical Literature Dept.
Umbertide (PG) Italy


57.4400.9203 Rev A March 2010
First Edition, First Printing

For the electronic version of this manual visit
http://www.genielift.com/parts_service_manuals.asp



The chassis serial number is punched on the front right part of the chassis side member.





Intentionally blank page

Safety Rules



Danger

Failure to obey the instructions and safety rules in this manual and the appropriate Operator's Manual on your machine will result in death or serious injury.

Many of the hazards identified in the Operator's Manual are also safety hazards when maintenance and repair procedures are performed..

Do Not Perform Maintenance Unless:

- ☒ You are trained and qualified to perform maintenance on this machine.
- ☒ You read, understand and obey:
 - manufacturer's instructions and safety rules
 - employer's safety rules and worksite regulations
 - applicable governmental regulations
- ☒ You have the appropriate tools, lifting equipment and a suitable workshop.

SAFETY RULES

Personal Safety

Any person working on or around a machine must be aware of all known safety hazards. Personal safety and the continued safe operation of the machine should be your top priority.



Read each procedure thoroughly. This manual and the decals on the machine, use signal words to identify the following:



Safety alert symbol: used to alert you to potential personal injury hazards. Obey all safety messages that follow this symbol to avoid possible injury or death



DANGER Red: indicates a hazardous situation which, if not avoided, will result in death or serious injury.



WARNING Orange: indicates a hazardous situation which, if not avoided, could result in death or serious injury.



CAUTION Yellow : indicates a hazardous situation which, if not avoided, could result in minor or moderate injury.



NOTICE Blue: indicates a property damage message.



PROTECT THE ENVIRONMENT Green: used to draw the attention to important information on environment protection.



Be sure to wear protective eye wear and other protective clothing if the situation warrants it.



Be aware of potential crushing hazards such as moving parts, free swinging or unsecured components when lifting or placing loads. Always wear approved steel-toed shoes.

Workplace Safety



Be sure to keep sparks, flames and lighted tobacco away from flammable and combustible materials like battery gases and engine fuels. Always have an approved fire extinguisher within easy reach.



Be sure that all tools and working areas are properly maintained and ready for use. Keep work surfaces clean and free of debris that could get into machine components and cause damage.



Be sure any forklift, overhead crane or other lifting or supporting device is fully capable of supporting and stabilizing the weight to be lifted. Use only chains or straps that are in good condition and of ample capacity.



Be sure that fasteners intended for one time use (i.e., cotter pins and self-locking nuts) are not reused. These components may fail if they are used a second time.



Be sure to properly dispose of old oil or other fluids. Use an approved container. Please be environmentally safe.



Be sure that your workshop or work area is properly ventilated and well lit.

Table of Contents

Introduction

Important Information.....	ii
Machine Identification	iii

Section 1

Safety Rules

Personal Safety Rules	v
-----------------------------	---

Section 2

Rev

Specifications

A	Operation Description	1
	Performance Specifications	8
	Hydraulic Specifications.....	9
	Perkins 1104C-44T Engine.....	10
	Carraro 2632M FR Drive Axle	10
	Hydraulic Hose and Fitting Torque Specifications	11
	Metric Fasteners Torque Charts	12

Section 3

Rev

Scheduled Maintenance Procedures

A	Introduction.....	13
	Pre-delivery Preparation Report	15
	Maintenance Inspection Report.....	17
A	Checklist A Procedures	
	A-1 Inspect the Manuals and Decals	18
	A-2 Perform Pre-operation Inspection	19
	A-3 Perform Function Test.....	19
	A-4 Machine Greasing	20
	A-5 Epicyclic Reduction Gears Oil Level	21
	A-6 Axles Oil Level	21
	A-7 Tyre Inflation	22
	A-8 Engine Oil Level.....	22
	A-9 Engine Cooling System.....	23
	A-10 Lighting System.....	23
	A-11 Clean Engine Air Filter	24
	A-12 Safety Devices	24



TABLE OF CONTENTS

Section 3	Rev	Scheduled Maintenance Procedures , continued	
		A-13 Emergency Pump Operation, if present	25
		A-14 Hydraulic Oil Level In The Tank	25
	A	Checklist B Procedures	
		B-1 Gear Box Oil Level	26
		B-2 Turntable Reduction Gear Oil Level	26
		B-3 Cylinder Rods	27
		B-4 Inspect the Electrical Wiring	27
		B-5 Boom Sliding Pads Adjusting	28
		B-6 Battery Electrolyte Level	28
		B-7 Block Valves	29
		B-8 Tensioning The Boom Chains (Only for GTH-4018 SR)	29
	A	Checklist C Procedures	
		C-1 Smoke From the Exhaust Muffler	30
		C-2 Change Engine Oil and Filter	30
		C-3 Change Engine Air Outer Filter	31
		C-4 Change Hydraulic Oil Filter	31
		C-5 Clean Cabin Air Filter	32
	A	Checklist D Procedures	
		D-1 Change Gear Box Oil	33
		D-2 Change Oil in the Turntable Gear	33
		D-3 Change Engine Air Inner Filter	34
		D-4 Change Hydraulic Oil	34
		D-5 Change Cabin Air Filter	35
		D-6 Change Oil in the Axles	35
		D-7 Change Oil in the Epicyclic Reduction Gears	36
	A	Checklist E Procedures	
		E-1 Change Engine Coolant	37
		E-2 Machine Structure	37

TABLE OF CONTENTS


Section 4	Rev	Repair Procedures	
		Introduction	39
	A	Boom Components	
		1-1 How to Replace the Boom Wear Pads	40
		1-2 How to Remove the Lifting Fork Frame	40
		1-3 How to Remove the Boom	41
		1-4 How to Disassemble the GTH-4018 SR Boom	42
		1-5 How to Assemble the GTH-4018 SR Boom	43
		1-6 How to Disassemble the GTH-4016 SR Boom	45
		1-7 How to Assemble the GTH-4016 SR Boom	46
		1-8 How to Remove a Lift Cylinder	47
		1-9 How to Remove the Second Boom Section Extension Cylinder	48
		1-10 How to Remove the Third Boom Section Extension Cylinder (only for GTH-4016 SR)	48
		1-11 How to Remove the Fork Level Cylinder	49
		1-12 How to Replace the Fork Level Cylinder Hoses (only for GTH-4016 SR) ..	50
	A	Operator's Compartment	
		2-1 How to Remove the Operator's Compartment	51
		2-2 How to Remove the Steering Column	52
		2-3 How to Test the Steering Column	52
		2-4 How to Remove the Steering Selector	53
		2-5 How to Remove the Joystick	53
		2-6 How to Test the Brake Pedal	54
		2-7 How to Remove the Brake Pedal	54
	A	Fuel and Hydraulic Tanks	
		3-1 How to Remove the Fuel Tank and the Hydraulic Tank	55
	A	Transmission	
		4-1 How to Remove the Transmission Pump	56

TABLE OF CONTENTS

Section 4	Rev	Repair Procedures, continued	
	A	Hydraulic Tanks	
		5-1 How to Test and Adjust the Function Pump	57
		5-2 How to Remove the Boom Gear Function Pump	57
		5-3 How to Test the Boom Function Gear Pump	58
		5-4 How to Remove the Auxiliary Gear Pump	58
		5-5 How to Test the Auxiliary Gear Pump	59
	A	Main Valve	
		6-1 How to Remove the Main Valve	60
		6-2 How to Test the Main Valve	60
	A	Outriggers	
		7-1 How to Remove the Outriggers Valves Block	61
		7-2 How to Test the Pressure on the Outriggers Valves Block	61
		7-3 How to Test the Outriggers Retraction Valve (only for GTH-4018 SR)	62
	A	Sensors	
		8-1 How to Remove the Boom Length and Angle Sensor	63
		8-2 How to Test the Boom Length and Angle Sensor	63
		8-3 How to Remove the Transducer Pressure Switches	64
		8-4 How to Test the Transducer Pressure Switches	64
		8-5 How to Test the Turret Proximity Switches	65
		8-6 How to Test the Chassis Proximity Switches	65
		8-7 How to Remove the Outriggers Load Pins	66
	A	Miscellaneous	
		9-1 How to Test the Emergency Pump	67
		9-2 How to Test the Differential Lock Pressure Reducing Valve	67
		9-3 How to Check the Engine RPM	68
Section 5	Rev	Settings	
	A	Introduction	69
		How to Read the Overload Warning System Display	70
		How to Set the Overload Warning System	72
		How to Set the Machine Functions	74

TABLE OF CONTENTS

Section 6	Rev	Troubleshooting	
	A	Introduction	81
		Overload Warning System Fault Codes	82
		How to Troubleshoot the Boom Movements.....	84
		How to Troubleshoot the Transmission	85
		How to Troubleshoot the Mechanical Gear	86
Section 6	Rev	Troubleshooting, continued	
		How to Troubleshoot the Jobsite Position	86
		How to Troubleshoot the Outriggers Movements	87
		How to Troubleshoot the Working Mode Selecting.....	88
Section 7	Rev	Schematics	
	A	Introduction	89
		Electrical Component Legend.....	90
		Hydraulic Component Legend	92
		Electrical Schematic	94
		Hydraulic Schematic (<i>GTH-4016 SR</i>).....	110
		Hydraulic Schematic (<i>GTH-4018 SR</i>).....	111



Intentionally blank page

REV A

Specification

GTH-4016SR & GTH-4018SR

Operation Description

The system layout of this machine consists of two main sections: an undercarriage and a slewing turret; these two main subassemblies incorporate all the components of the machine.

The source of mechanical power of this machine is a Perkins turbocharged diesel engine **(1)**, model 1104D-44T without intercooler, which supplies a power of 74 kW at 2300 rev/min and is capable of a max torque of 392 Nm at 1400 rpm.

On the flywheel housing of the engine, and linked to its flywheel through a PTO (gear ratio 1:1) provided with an elastic joint, is installed a Rexroth closed-loop hydrostatic transmission pump **(2)**, model A4VG71, equipped with a DA hydraulic automotive control valve.

The max displacement of this swash-plate pistons type pump is 71 cm³ and its max working pressure is 430 bar.

This pump transforms most of the mechanical power (torque*rotational speed) received from the diesel engine into hydraulic power (pressure*flow rate) of the hydraulic fluid contained in the transmission closed loop.

This power is then used to move the machine.

This piston pump is equipped with an internal gear pump acting as a charge pump for the transmission closed circuit, to generate pressure for the pump piloting lines and for other external purposes. In particular in this machine, the low pressure generated by this charge pump is used to power, through the port G, the low pressure circuits which will be described later.

The standard setting pressure for this circuit is 25 bar.

The transmission pump is provide with a passing through PTO on its back side which is used to drive an open circuit type gear pump **(3)**, having a displacement of 43 cm³.

The function of this pump is to provide hydraulic power to most of the functional subsystems of the machine: the steering, the telescopic boom, the turret slewing and the stabilizers.

Another open circuit type gear pump **(4)**, having a displacement of 14 cm³, is installed on the PTO provided on the diesel engine distribution side.

The function of this pump is to provide hydraulic power to the braking systems (service and parking) and to the air conditioning system compressor (optional).

When the work platform attachment (optional) is installed, the additional emergency powerpack **(5)** is provided with the aim to allow the work platform recovery in case of failure on the main power generation system and controls.

This powerpack mainly consists of a 12 VDC electrical motor, powered by the machine battery, and of a small gear pump, having a displacement of 2.6 cm³ and driven by the electrical motor directly.

The maximum pressure on the emergency hydraulic line is controlled by the pressure relief valve **(6)** which is set to 150 bar.

The two check valves **(7)** having a cracking pressure of 0.5 bar, are installed on the open circuit main and emergency pressure lines, to prevent any interference between these two lines and any flow loss to the tank, considering that these pumps normally work separately.

All the pumps described before receive oil from a steel tank **(8)** installed on the left side of the undercarriage and having a nominal capacity of 220 liters.

In particular, the gear pumps **(3)**, **(4)** and **(5)** receive oil from a dedicated suction line provided with a mechanical shutoff valve **(9)**, installed immediately downstream of the tank and used during the maintenance operations on the hydraulic system.

Inside the tank and on the same suction line, a dedicated hydraulic screen **(10)** is installed with the aim reduce the contamination level of the oil before it enters into the suction line.

The transmission pump **(2)** receives oil from the special filter **(11)** which has a double function: to filter most of the return oil of all the open type circuits of the machine and to provide a filtered, cooled and pressurized suction line for any pump requiring a good level of oil filtration on the suction line.

In particular the minimum pressure of 0.5 bar guaranteed on the suction line for the transmission pump, reduce the risk of oil cavitation during the engine starting phase at very low ambient

SPECIFICATION

REV A

temperatures.

This filter package, which is flanged directly on the top side of the tank, is provided with a electrical pressure switch **(12)** indicating when the filter cartridge is clogged and then has to be replaced.

The maximum pressure on the brake circuit line is controlled by the pressure relief valve **(13)** which is set to 180 bar.

The mechanical shutoff valve **(14)** when closed, allows the pressure relief valve setting pressure can be checked and adjusted as necessary.

In the normal machine working conditions this shutoff valve must be placed in its fully open position.

The hydrostatic pump **(2)** hydraulically powers the Rexroth hydrostatic motor closed loop, piston bent axis type **(15)**, model A6VM80 which transforms the hydraulic power (pressure*flow rate) of the oil contained in the hydrostatic transmission closed loop circuit into mechanical power (torque*rotational speed) to be used for the machine displacement.

The low pressure line, which is part of the hydrostatic transmission, is also used to cool the hydrostatic pump a motor through a drain case line routed between the pump and the motor and finally connected to the tank where the warm oil is finally sent.

This drain case flow rate is controlled by the check valve **(16)** having a cracking pressure of 2.5 bar. When the pressure in the drain case line exceeds 2.5 bar, the flow rate in excess can be directly discharged to the tank so preventing any damage at the pump and motor sealing gaskets.

The hydrostatic motor is directly flanged on a Carraro two-speed gear box **(17)** installed on the central part of the undercarriage.

The speed shifting phase is activated by the hydraulic actuator **(18)**, which is part of the gearbox itself, and controlled by the 4 ways/3 positions electrical selector valve **(19)**.

This selector valve is powered by the low pressure generated by the hydrostatic transmission charge pump.

The gearbox is mechanically linked, through two distinct drive shafts, to the front axle **(20)** and to the

rear axle **(21)**, both manufactured by Carraro, so transmitting to the wheels the torque generated by the hydrostatic motor.

The front axle, provided with an embedded steering cylinder **(22)** and articulation, is rigidly secured on the front area of the undercarriage whilst the rear axle, provided with an embedded steering cylinder **(23)** and articulation, is floating around its pivoting axle in most of the machine displacement conditions.

The floating condition of the rear axle is controlled by the single effect right and left rear axle pivoting cylinders **(24)** and **(25)** which, when the rear axle is floating, are completely free to extend/retract exchanging oil between their piston chambers and giving a negligible resistance to the rear axle floating movement.

The free flow between the two cylinder is allowed by the two 2 ways/2 positions electrical rear axle pivoting lockout valves **(26)** which are energized when the rear axle is floating free.

These valves are directly embedded in the cylinder body and, when not energized, close the line between the two cylinders piston chamber so locking the floating movement of the rear axle.

The two air bleeding valves **(27)**, embedded one for each cylinder, are used to eliminate air from the cylinders after the first machine installation or in occasion of maintenance operations.

The oil used to fill the rear axle pivoting cylinders is provided by the low pressure line, powered by the hydrostatic transmission charge pump, and is controlled through the rear axle lockout cylinders control valve **(28)**.

The scope of this valve is to provide a free flow of oil when this is requested by the rear axle pivoting cylinders (check valve opens) and to prevent any pressure surges and peaks on the low pressure line when the quantity of oil in the rear axle pivoting cylinders is in excess (damping effect due to the calibrated restrictor).

The machine open circuits are linked to the tank through the heat exchanger **(29)** which cools the oil before it is filtered through the special filter package **(11)** already described.

REV A

SPECIFICATION

When the pressure upstream of the heat exchanger exceeds 8 bar, the flow rate in excess is directly discharged to the tank through the check valve **(30)** having a cracking pressure of 8 bar indeed.

The scope of this valve is to prevent any risk of heat exchanger damage due to excessive pressure (machine start-up at very low temperatures).

This heat exchanger is part of the main machine radiator (cooling also the engine) and is installed inside the engine compartment.

The gear pump **(4)** feeds the hydraulically powered service/emergency brakes pedal pump **(31)** which is installed underneath the cabin bottom in such a way the operator can easily control the service brake circuit by a mechanical pedal which is a part of the pump itself.

The main function of this pump is to use the pressurized oil available from the gear pump **(4)** to maintain two hydraulic accumulators **(32)** and **(33)** charged at a pressure not exceeding 150 bar.

The first accumulator **(32)**, having a capacity of 0.5 liters and a nitrogen pre-charge pressure of 50 bar, feeds the service brake line whilst the second one **(33)**, having a capacity of 1.5 liters and a nitrogen pre-charge pressure of 35 bar, feeds the parking brake line.

The electrical pressure switch **(34)**, installed on the service brake pressure line, signals when the pressure is applied to the service brake line.

The electrical pressure switch **(35)**, installed on the parking brake pressure line, signals when the pressure charging the accumulators is too low and then the pump **(31)** is expected to recharge them using the flow coming from the gear pump **(4)**.

The service brake output line is linked, through the electrical 3 ways/2 positions selector valve **(36)**, to the wet type brake disks packages, which are installed inside the axles.

When the selector valve **(36)** is not energized, the brake pump **(31)** is directly linked to the brakes disks so producing the requested braking effect when the operator in the cabin pushes on the brake pedal.

When the selector valve **(36)** is energized, the service brakes ports of the front axle, receive a

pressure of 10 bar which makes stronger the effect of the anti-slipping device, device which is installed inside the front axle.

This low pressure is generated by a pressure reducing valve **(37)** fed by the low pressure generated by the transmission charge pump.

The brakes pedal pump **(31)** is also linked, through the port "R", to the parking brake handle selector valve **(38)** controlling the parking brake function.

When the handle of this valve, which is located in the cabin on left of the operator's seat, is placed in the parking brake "on" position, the parking brake hydraulic line, connected to the front axle **(20)**, is vented to the tank.

This condition allows the parking brake package, installed inside the axle, to be self-activated, through an internal mechanism energized by disk springs, so maintaining the machine in the parking condition.

On the other position of the lever, the parking brake hydraulic line is pressurized at 30 bar so maintaining the parking brake disks released and then allowing the machine to move without any braking effect.

Two electrical pressure switches **(39)** signals when the parking brake is activated.

After the flow rate generated by the gear pump **(4)** and used by the brakes pedal pump **(31)** to maintain the accumulators **(32)** and **(33)** charged, leaves the brakes pedal pump itself, this is available to power the air condition compressor hydraulic gear motor **(40)** which can be installed on the machine as an option.

The gear pump **(3)** powers two distinct and separated circuits: the steering circuit (priority circuit) and the circuit driving the boom functions, the slewing turret and the stabilizers operations (secondary circuit).

The flow rate coming from this pump is controlled by the load sensing priority valve **(41)** which is controlled by the steering load sense line "LS".

The principle of this valve is to ensure that all the necessary flow rate is available to the steering circuit when requested by the steering operation and to give the exceeding flow rate to the secondary

SPECIFICATION

REV A

circuit. Off course, when the steering is not used, most of the flow rate is available for the secondary circuit.

The priority line of the valve **(41)** powers the steering rotating actuator **(42)** which is mechanically linked to the steering wheel.

The scope of this actuator is to send a flow rate to the steering cylinders which is proportional, in addition to the actuator displacement, also to the steering wheel rotational speed.

The actuator is also provided with a pressure relief valve, which is adjusted to 190 bar, and two anti-shock relief valves, which are adjusted to 260 bar.

The machine is provide with 3 distinct steering modes (2 wheel, 4 wheels and crab steering) which are implemented in the circuit by the 4 ways/3 positions electrical selector valve **(43)**.

When the valve is not energized the 2 wheels steering mode is selected, when one solenoid of the valve is energized the 4 wheels is selected and when the other solenoid is energized the crab steering model is selected.

The secondary line of the valve **(41)** is linked to the telescopic boom, turret and undercarriage main valve **(44)**.

This valve is a pressure compensated, modular, flow sharing type valve controlling the boom and attachments functions, the slewing turret and the stabilizers operations. It mainly consists of one inlet manifold, containing the main 3 ways pressure compensator, the maximum pressure relief valve, adjusted to 280 bar, the pressure reducing valve feeding the spools actuators and the 2 enabling function electrical valves, of 5 modules having electro-proportional controls and of one module having electrical on/off type control.

The first section of the valve, pressure compensated, controls the boom up/down functions and is linked to the telescopic boom lift cylinder **(45)** through the single over-center safety valve **(46)**.

The hydraulic accumulator **(47)**, having a capacity of 0.5 liters and a nitrogen pre-charge pressure of 35 bar, is installed on the boom down hydraulic line to prevent any oscillation of the boom during the boom-down movement.

The second section of the valve, not pressure compensated, controls the forks tilt up/down functions and is linked to the forks tilt cylinder **(48)** through the double over-center safety valve **(49)**.

On the same line of the forks tilt cylinder **(48)** is installed, in parallel, the forks self-leveling articulation slave cylinder **(50)** provided with a double over-center safety valve **(51)**.

This cylinder, which is linked to the boom and to the turret, works as a pump and maintain leveled the forks articulation when the boom is moved up and down.

The output lines of the valve second section are protected by 2 pressure relief valves, adjusted to 320 bar.

The third section of the valve, pressure compensated, controls the boom telescoping in/out functions and is linked to the second section boom telescopic cylinder **(52)** through the double over-center safety valve **(53)**.

On the GTH-4016 SR only, the second section boom telescopic cylinder **(52)** is linked to the third section boom telescopic cylinder **(70)**, provided with a single over-center safety valve **(71)**.

The fourth section of the valve, not pressure compensated, controls the attachment quick coupling device (optional) and is used to power optional attachments requiring an hydraulic flow to work.

This section is linked to the forks attachment quick coupling cylinder **(56)** through the double piloted safety valve **(57)** and the quick coupling hydraulic ports **(58)**.

The fifth section of the valve, pressure compensated, controls the turret slewing functions and is linked to the turret rotation hydraulic motor **(54)** through the special double over-center safety valve **(55)**.

The hydraulic motor is installed on a planetary type gear, for the turret slewing, provided by an internal negative type brake which is capable to maintain the turret locked when no pressure is applied to the hydraulic motor.

The sixth section of the valve, provided by an electrical on/off type control, drives the stabilizers through the stabilizers electrical selector valves

REV A

SPECIFICATION

block **(59)**.

The four valves of the block **(59)** are linked to the four stabilizer cylinder **(60, 62, 64 and 66)** which are equipped with hydraulically piloted double check valves **(61, 63, 65 and 67)** preventing any movement of the cylinders when they are not pressurized.

On the GTH-4018 SR only, the four valves of the block **(59)** feed in parallel the four stabilizers telescope lockout cylinders **(73)** through the four stabilizers electrical lockout valve 2 ways/2 positions **(72)**.

On the stabilizers selector valves block **(59)** inlet line, linked to the stabilizers up movements, a pressure relief valve **(74)**, adjusted to 100 bar, is installed.

The scope of this relief valve is to limit the loads against the stabilizers telescope lockout mechanisms, in case of failure of the stabilizers telescope arm and rotating foot sequence control.

The scope of this additional circuit, which is installed on the GTH-4018 SR only, is to give the right functioning sequence to the stabilizers telescope arms and rotating feet, since each of them is moved by the same cylinder.

In order to reduce the number of hoses linking the undercarriage and the turret sections of the hydraulic circuit, a tank lines collector **(68)** is installed on the turret receiving a number of tank lines coming from several valves installed on the turret itself.

In order to improve the life of the hoses passing through the slewing ring and connecting the undercarriage and turret sections of the machine, hydraulic circuit, single rotating joints **(69)** are installed on each of these hoses and grouped together on a single panel mounted on the central section of the machine undercarriage.


REV A

[illegible]

REV A

SPECIFICATION

GTH-4018SR Hydraulic Schematic

Genie
A TEREX BRAND

SPECIFICATION

REV A

Performance Specifications

Fluid capacities

Fuel tank	205 L
Hydraulic tank	220 L

Tires and wheels

Tire size	18-19.5
Tire pressure	5.5 bar
Tire ply rating	16
Wheel diameter	1104 mm
Wheel width	460 mm
Lug pattern	14x19.5
Lug nut torque, dry	630 Nm

Drive speed, maximum

GTH-4016SR & GTH-4018SR	35 km/h
-------------------------	---------

Towing capacity at dynamometer

max load	7,000 kg
without load	6,900 kg

Lift capacity, maximum

GTH-4016SR & GTH-4018SR	4,000 kg
-------------------------	----------

Continuous improvement of our products is a Genie policy. Product specifications are subject to change without notice.

REV A

SPECIFICATION

Hydraulic Specifications

Hydraulic Oil Specifications (all models)

Hydraulic oil type	SHELL TELLUS 46 DENISON HF-1 DIN51524 part2&3
ISO viscosity grade	46
Viscosity index	147

Optional Fluids

Biodegradable	Petro Canada Environ MV46 Statoil Hydra Way Bio Pa 32
Fire resistant	UCON Hydrolube HP-5046 Quintolubric 822
Extreme Cold Oils	Chevron Oil 5606A

Function Pump

Type:	Fixed displacement gear pump
Flow rate @ 2300 rpm	100 L/min
Pump pressure (measured at test port TP7)	193 bar

Continuous improvement of our products is a Genie policy. Product specifications are subject to change without notice.

Main Valve

System relief valve pressure, maximum	280 bar
Forks tilt section relief valves pressure, max.	320 bar

Steering Circuit

Steer relief valve pressure, maximum	190 bar
--------------------------------------	---------

Braking Circuit

Brake pump relief valve pressure, max.	150 bar
--	---------

Hydrostatic Transmission Pumps

Setting relief valve pressure, max.	450 bar
Cutting relief valve pressure, max.	430 bar
Charge pump relief valve pressure, max.	25 bar
Auxiliary circuit relief valve pressure, max.	180 bar
Outriggers retraction line relief valve P, max.	100 bar

SPECIFICATION

REV A

Perkins 1104D-44T Engine

Displacement	4400cc
Number of cylinders	4
Bore and stroke	105 x 127 mm
Horsepower	74.5 kW @ 2300 rpm
Firing order	1 - 3 - 4 - 2
Compression ratio	18.2:1
Low idle	900 rpm
High idle	2300 rpm
Lubrication system	
Oil capacity (including filter)	11.5 liters
Oil viscosity requirements	

Units ship with 15W-40.
Extreme operating temperatures may require the use of alternative engine oils. For oil requirements, refer to the Engine Operation and Maintenance Manual on your machine.

Fuel requirement

For fuel requirements, refer to the engine Operation Manual on your machine.

Engine coolant

Capacity	15 liters
----------	-----------

Alternator

Output	100 A, 12V DC
--------	---------------

Battery

Type	12V DC
Quantity	1
Cranking ampere	1200 EN

Continuous improvement of our products is a Genie policy. Product specifications are subject to change without notice.

Carraro 2632M FR Drive Axle**GTH-4016SR and GTH-4018SR**

Steering	Intergrated steer cylinder
Joints	Heavy duty double U-joints
Steering angle, maximum	40°

Front Axle Lubrication

Front differential	8 liters
Axle planetary end (each)	1.3 liters

Rear Axle Lubrication

Rear differential	8 liters
Axle planetary end (each)	1.3 liters

Oil viscosity requirements

Differential	API GL4
Planet ends	API GL4

Continuous improvement of our products is a Genie policy. Product specifications are subject to change without notice.

REV A

SPECIFICATION


Hydraulic Hose and Fitting Torque Specifications

Your machine is equipped with ORFS type fittings and hose ends. Genie specifications require that fittings and hose ends be torqued to specification when they are removed and installed or when new hoses or fittings are installed.

Torque Procedure

- 1 Align the tube flare (hex nut) against the nose of the fitting body (body hex fitting) and tighten the hex nut to the body hex fitting to hand-tight, approximately 3.4 Nm.
- 2 Make a reference mark on one of the flats of the hex nut, and continue it on to the body hex fitting with a permanent ink marker.


- a hydraulic hose
- b hex nut
- c reference mark
- d body hex fitting



- 3 Working clockwise on the body hex fitting, make a second mark with a permanent ink marker to indicate the proper tightening position.

NOTICE

The marks indicate that the correct tightening positions have been determined. Use the second mark on the body hex fitting to properly tighten the joint after it has been loosened.







- a body hex fitting
- b reference mark
- c second mark

- 4 Tighten the hex nut until the mark on the hex nut is aligned with the second mark on the body hex fitting.
- 5 Operate all machine functions and inspect the hoses and fittings and related components to confirm that there are no leaks.

SPECIFICATION

REV A

METRIC FASTENER TORQUE CHART																
• This chart is to be used as a guide only unless noted elsewhere in this manual •																
Size (mm)	Class 4.6 				Class 8.8 				Class 10.9 				Class 12.9 			
	LUBED		DRY		LUBED		DRY		LUBED		DRY		LUBED		DRY	
	in-lbs	Nm	in-lbs	Nm	in-lbs	Nm	in-lbs	Nm	in-lbs	Nm	in-lbs	Nm	in-lbs	Nm	in-lbs	Nm
5	16	1.8	21	2.4	41	4.63	54	6.18	58	6.63	78	8.84	68	7.75	91	10.3
6	19	3.05	36	4.07	69	7.87	93	10.5	100	11.3	132	15	116	13.2	155	17.6
7	45	5.12	60	6.83	116	13.2	155	17.6	167	18.9	223	25.2	195	22.1	260	29.4
	LUBED		DRY		LUBED		DRY		LUBED		DRY		LUBED		DRY	
	ft-lbs	Nm	ft-lbs	Nm	ft-lbs	Nm	ft-lbs	Nm	ft-lbs	Nm	ft-lbs	Nm	ft-lbs	Nm	ft-lbs	Nm
8	5.4	7.41	7.2	9.88	14	19.1	18.8	25.5	20.1	27.3	26.9	36.5	23.6	32	31.4	42.6
10	10.8	14.7	14.4	19.6	27.9	37.8	37.2	50.5	39.9	54.1	53.2	72.2	46.7	63.3	62.3	84.4
12	18.9	25.6	25.1	34.1	48.6	66	64.9	88	69.7	94.5	92.2	125	81	110	108	147
14	30.1	40.8	40	54.3	77.4	105	103	140	110	150	147	200	129	175	172	234
16	46.9	63.6	62.5	84.8	125	170	166	226	173	235	230	313	202	274	269	365
18	64.5	87.5	86.2	117	171	233	229	311	238	323	317	430	278	377	371	503
20	91	124	121	165	243	330	325	441	337	458	450	610	394	535	525	713
22	124	169	166	225	331	450	442	600	458	622	612	830	536	727	715	970
24	157	214	210	285	420	570	562	762	583	791	778	1055	682	925	909	1233

Scheduled Maintenance Procedures



Observe and Obey:

- ☑ Maintenance inspections shall be completed by a person trained and qualified on the maintenance of this machine.
- ☑ Scheduled maintenance inspections shall be completed daily, quarterly, semi-annually, annually and every 2 years as specified on the *Maintenance Inspection Report*.

⚠ WARNING Failure to perform each procedure as presented and scheduled could result in death, serious injury or substantial damage.

- ☑ Immediately tag and remove from service a damaged or malfunctioning machine.
- ☑ Repair any machine damage or malfunction before operating the machine.
- ☑ Keep records on all inspections for three years.
- ☑ Machines that have been out of service for a period longer than 3 months must complete the quarterly inspection.
- ☑ Unless otherwise specified, perform each maintenance procedure with the machine in the following configuration:
 - Machine parked on a firm, level surface
 - Boom in the stowed position
 - Key switch in the off position with the key removed
 - Wheels chocked

About This Section

This section contains detailed procedures for each scheduled maintenance inspection.

Each procedure includes a description, safety warnings and step-by-step instructions.

Symbols Legend



Safety alert symbol—used to alert personnel to potential personal injury hazards. Obey all safety messages that follow this symbol to avoid possible injury or death.



Used to indicate the presence of an imminently hazardous situation which, if not avoided, will result in death or serious injury.



Used to indicate the presence of a potentially hazardous situation which, if not avoided, could result in death or serious injury.



Used to indicate the presence of a potentially hazardous situation which, if not avoided, may cause minor or moderate injury.



Used to indicate the presence of a potentially hazardous situation which, if not avoided, may result in property damage.

- ⦿ Indicates that a specific result is expected after performing a series of steps.
- ⊖ Indicates that an incorrect result has occurred after performing a series of steps.

SCHEDULED MAINTENANCE PROCEDURES

Maintenance Symbols Legend

NOTICE

The following symbols have been used in this manual to help communicate the intent of the instructions. When one or more of the symbols appear at the beginning of a maintenance procedure, it conveys the meaning below.



Indicates that tools will be required to perform this procedure.



Indicates that new parts will be required to perform this procedure.



Indicates that a cold engine will be required to perform this procedure.



Indicates that a warm engine will be required to perform this procedure.



Indicates that dealer service will be required to perform this procedure.

Pre-delivery Preparation Report

The pre-delivery preparation report contains checklists for each type of scheduled inspection.

Make copies of the *Pre-delivery Preparation* report to use for each inspection. Store completed forms as required.

Maintenance Schedule

There are five types of maintenance inspections that must be performed according to a schedule—daily, quarterly, semi-annually, annually, and two year. The *Scheduled Maintenance Procedures Section and the Maintenance Inspection Report* have been divided into five subsections—A, B, C, D, and E. Use the following chart to determine which group(s) of procedures are required to perform a scheduled inspection.

Inspection	Checklist
Daily or every 8 hours	A
Quarterly or every 250 hours	A + B
Semi-annually or every 500 hours	A + B + C
Annually or every 1000 hours	A + B + C + D
Two year or every 2000 hours	A + B + C + D + E

Maintenance Inspection Report

The maintenance inspection report contains checklists for each type of scheduled inspection.

Make copies of the *Maintenance Inspection Report* to use for each inspection. Store completed forms for three years.

Pre-Delivery Preparation

Fundamentals

It is the responsibility of the dealer to perform the Pre-delivery Preparation.

The Pre-delivery Preparation is performed prior to each delivery. The inspection is designed to discover if anything is apparently wrong with a machine before it is put into service.

A damaged or modified machine must never be used. If damage or any variation from factory delivered condition is discovered, the machine must be tagged and removed from service.

Repairs to the machine may only be made by a qualified service technician, according to the manufacturer's specifications.

Scheduled maintenance inspections shall be performed by qualified service technicians, according to the manufacturer's specifications and the requirements listed in the responsibilities manual.

Instructions

Use the operator's manual on your machine.

The Pre-delivery Preparation consists of completing the Pre-operation Inspection, the Maintenance items and the Function Tests.

Use this form to record the results. Place a check in the appropriate box after each part is completed. Follow the instructions in the operator's manual.

If any inspection receives an N, remove the machine from service, repair and re-inspect it. After repair, place a check in the R box.

Legend

Y = yes, completed

N = no, unable to complete

R = repaired

Comments

Pre-Delivery Preparation	Y	N	R
Pre-operation inspection completed			
Maintenance items completed			
Function tests completed			

Model

Serial number

Date

Machine owner

Inspected by (print)


Inspector signature

Inspector title

Inspector company



Terexlift
Zona Industriale I
06019 Umbertide (Pg)
Italy



Intentionally blank page

Maintenance Inspection Report

Model
Serial number
Date
Hour meter
Machine owner
Inspected by (print)
Inspector signature
Inspector title
Inspector company

Instructions

- Make copies of this report to use for each inspection.
- Select the appropriate checklist(s) for the type of inspection to be performed.

<input type="checkbox"/>	Daily or 8 hour Inspection:	A
<input type="checkbox"/>	Quarterly or 250 hour Inspection:	A+B
<input type="checkbox"/>	Semi-annually or 500 hour Inspection:	A+B+C
<input type="checkbox"/>	Annually or 1000 hour Inspection:	A+B+C+D
<input type="checkbox"/>	2 Year or 2000 hour Inspection:	A+B+C+D+E

- Place a check in the appropriate box after each inspection procedure is completed.
- Use the step-by-step procedures in this section to learn how to perform these inspections.
- If any inspection receives an "N", tag and remove the machine from service, repair and re-inspect it. After repair, place a check in the "R" box.

Legend

- Y = yes, acceptable
N = no, remove from service
R = repaired

Checklist A - Rev A		Y	N	R
A-1	Manuals and decals			
A-2	Pre-operation inspect			
A-3	Function tests			
A-4	Machine greasing			
A-5	Epicyclic reduction gears oil level			
A-6	Axles oil level			
A-7	Tyre inflation			
A-8	Engine oil level			
A-9	Engine cooling system			
A-10	Lighting system			
A-11	Clean engine air filters			
A-12	Safety devices			
Perform after 50 hours:				
A-13	Emergency pump operation, if present			
A-14	Hydraulic oil level in the tank			
Checklist B - Rev A				
B-1		Y	N	R
B-1	Gearbox oil level			
B-2	Turntable reduction gear oil level			
B-3	Cylinder rods			
B-4	Inspect the electrical wiring			
B-5	Boom sliding pads adjusting			
B-6	Battery electrolyte level			
B-7	Block Valves			
B-8	Tensioning the boom chains			

Checklist C - Rev A		Y	N	R
C-1	Smoke from the exhaust muffler			
C-2	Change engine oil and filter			
C-3	Change engine air outer filter			
C-4	Change hydraulic oil filter			
C-5	Clean cabin air filter			
Checklist D - Rev A				
D-1		Y	N	R
D-1	Change gear box oil			
D-2	Change oil in the turntable gear			
D-3	Change engine air inner filter			
D-4	Change hydr. oil			
D-5	Change cabin air filter			
Perform every 1500 hours:				
D-6	Change oil in the axles			
D-7	Change oil in the epicyclic reduction gears			
Checklist E - Rev A				
E-1		Y	N	R
E-1	Change engine coolant			
Perform every 6000 hours:				
E-2	Structure status			

Checklist A Procedures

REV A

A-1

Inspect the Manuals and Decals

Maintaining the operator's manual in good condition is essential to safe machine operation. Manual is included with each machine and should be stored in the container provided in the operator's compartment. An illegible or missing manual will not provide safety and operational information necessary for a safe operating condition.

In addition, maintaining all of the safety and instructional decals in good condition is mandatory for safe machine operation. Decals alert operators and personnel to the many possible hazards associated with using this machine. They also provide users with operation and maintenance information. An illegible decal will fail to alert personnel of a procedure or hazard and could result in unsafe operating conditions.

- 1 Check to make sure that the operator's manual is present and complete in the storage container in the operator's compartment.
- 2 Examine the pages of the manual to be sure that it is legible and in good condition.

- Result: The operator's manual is appropriate for the machine and it is legible and in good condition.
- ⊘ Result: The operator's manual is not appropriate for the machine or it is not in good condition or is illegible. Remove the machine from service until the manual is replaced.

- 3 Open the operator's manual to the decals inspection section. Carefully and thoroughly inspect all decals on the machine for legibility and damage.

- Result: The machine is equipped with all required decals, and all decals are legible and in good condition.

- ⊘ Result: The machine is not equipped with all required decals, or one or more decals are illegible or in poor condition. Remove the machine from service until the decals are replaced.

- 4 Always return the manual to the storage container after use.

NOTICE

Contact your authorized Genie distributor or Genie Industries if replacement manual or decals are needed.

REV A

CHECKLIST A PROCEDURES

A-2**Perform Pre-operation Inspection**

Completing a Pre-operation Inspection is essential to safe machine operation. The Pre-operation Inspection is a visual inspection performed by the operator prior to each work shift. The inspection is designed to discover if anything is apparently wrong with a machine before the operator performs the function tests. The Pre-operation Inspection also serves to determine if routine maintenance procedures are required.

Complete information to perform this procedure is available in the appropriate operator's manual. Refer to the Operator's Manual on your machine.

A-3**Perform Function Tests**

Completing the function tests is essential to safe machine operation. Function tests are designed to discover any malfunctions before the machine is put into service. A malfunctioning machine must never be used. If malfunctions are discovered, the machine must be tagged and removed from service.

Complete information to perform this procedure is available in the appropriate operator's manual. Refer to the Operator's Manual on your machine.

CHECKLIST A PROCEDURES

REV A

A-4 Machine Greasing



NOTICE

Genie specifications require that this procedure be performed every 8 hours or daily, whichever comes first.

Greasing the specified locations is essential for good machine performance and service life. Operating the machine with little or no grease may cause the machine to perform poorly and continued use may cause component damage.

- 1 Fully extend the boom. Raise the boom as needed.
- 2 Locate the grease fittings at both sides of all boom tubes except the innermost tube. Refer to the illustration.
- 3 Pump grease into the fittings until the inner boom rollers are thoroughly lubricated.
- 4 Lubricate the top boom tube wear pads.


NOTICE

Do not lubricate the side wear pads at the boom rollers, if equipped.

- 5 Return the boom to the stowed position.
- 6 Locate a grease fitting at one of the locations shown in the illustration.
- 7 Pump grease into the fitting until the joint is thoroughly lubricated.
- 8 Repeat this procedure, beginning with step 6, for each remaining grease fitting shown in the illustration.
- 9 Locate the grease fittings on the stabilizer frame at the front of the machine.
- 10 Pump grease into each fitting until the joints are thoroughly lubricated.
- 11 Locate the grease fittings on the outriggers at the front of the machine.
- 12 Pump grease into each fitting until the joints are thoroughly lubricated.

Grease Specification

PTFE INTERFLON FIN GREASE LS 2



Genie
A TEREX BRAND

REV A

CHECKLIST A PROCEDURES


A-5 Epicyclic Reduction Gears Oil Level



1. Stop the machine on a level ground and ensure the parking brake is engaged and plug fits on the horizontal axis.
2. Clean the plug all around, then remove it and check if oil is level with the hole.
3. If necessary, add new oil through hole until it is level.
4. Refit the plug.

A-6 Axles Oil Level

1. Stop the machine on a level ground and engage the parking brake.
2. Loosen level plug ① and check if oil is level with the hole.
3. If necessary, top-up through the same hole.
4. Refit and tighten plug ①.



CHECKLIST A PROCEDURES

REV A

A-7 Tyre Inflation

1. Put on protective clothing and eye wear
2. Rotate the wheel until the tire stem is at the 12 o'clock position.
3. Check the air pressure in the tire.
 - Result - models with air-filled tires: The air pressure meets specification. The tire is at the correctly filled level.
 - ⊖ Result - models with air-filled tires: The air pressure does not meet specification. Add air until the air pressure meets specification.
4. Repeat this procedure for each remaining tire.

A-8 Engine Oil Level

**NOTICE**

Engine specifications require that this procedure be performed daily.

Required maintenance procedures and additional engine information is available in the *Perkins 1104D Operation and Maintenance Manual*

REV A

CHECKLIST A PROCEDURES

A-9 Engine Cooling System



NOTICE

Engine specifications require that this procedure be performed daily.

Required maintenance procedures and additional engine information is available in the *Perkins 1104D Operation and Maintenance Manual*

A-10 Lighting System

1. Stop the machine on a level ground and ensure the parking brake is engaged.
2. Switch on the different traffic and work lights and check the inside cabin warning lights are on order.
3. Leave the cabin and check if the lamps are working properly.

CHECKLIST A PROCEDURES

REV A


A-11 Clean Engine Air Filter

1. Cleaning the External Element

- Shut the engine down and put the parking brake.
- Open the four latches **A**.
- Remove the protection cap **B**.
- Extract the external cartridge **C**.
- Clean the filter bowl.
- Beat the cartridge against a piece of wood surface to eliminate any dust.
- Dry clean the cartridge (max. pressure: 6 bar).
- Check for cracks in the filtering element.
- Before refitting the cleaned cartridge smear its seal with a thin coat of grease; fit the cartridge and make sure it is properly positioned.
- Refit cap **A**.

NOTICE

As soon as the warning lamp 40 on the cab dashboard switches on, replace the outer element. Never wash the cartridge with water or solvents.



A-12 Safety Devices

1. Moment Limiting System

- Load a weight of 1000 kg.
- Raise the boom about 30 cm above the ground.
- Extend the telescope and check if the system enters the alarm mode once reached the distance indicated in the load charts for the attachment fitted to the machine.

2. Joystick Enabling Function Switch

- Attempt to operate the joystick without pressing this button: in this condition, the joystick shall not activate any movement.

3. Emergency Stop Pushbutton

- To check the efficiency of this pushbutton, simply press it down during a movement. The pressure of the pushbutton shall cause the movement to stop and the engine to shut down.

4. Seat Switch

- Attempt to make the machine to move without sitting on the drive seat. In this condition, the machine shall not move.

5. Outriggers Sensors

- Lower or raise all the outriggers.
- The display of the moment limiter will change the scale of the admissible payloads accordingly.

6. Pressure Switch On The Parking Brake

- Engage the parking brake and start the engine.
- The warning light 41 should come on.
- Attempt to move with the machine. The machine must not move.

REV A

CHECKLIST A PROCEDURES

A-13 Emergency Pump Operation, if present

1. stop the engine,
2. press the on-off button for some seconds
3. check that the pump works regularly.

A-14 Hydraulic Oil Level In The Tank



Fine jets of hydraulic oil under pressure can penetrate the skin. Do not use your fingers, but a piece of cardboard to detect oil leaks.

1. Check the hydraulic oil level (visually) through the special level fitted into the tank and placed on the cabin access steps.
2. If necessary, add new oil through the dedicated filler placed under the cover.
3. Unscrew knobs and remove the cover.
4. Add new oil.

Checklist B Procedures


REV A

B-1

Gear Box Oil Level



1. Stop the machine on a level ground and make sure the parking brake is engaged.
2. Clean level plug ① all around.
3. Remove the plug and check if oil is level with the hole.
4. When necessary, add new oil through plug ① until it is level with the hole.
5. Refit and tighten the plug.




- | | |
|---|--------------|
| ① | Filling plug |
| ② | Drain plug |

B-2

Turntable Reduction Gear Oil Level



1. Stop the machine on a level ground and engage the parking brake.
2. Clean level plug **A** all around.
3. Loosen level plug **A** and check if oil is level with the hole.
4. If necessary, unscrew the filling plug **B** and pour new oil through the hole until it starts flowing out of hole **A**.
5. Refit and tighten plugs **A** and **B**.



REV A

CHECKLIST B PROCEDURES

B-3 Cylinder Rods

NOTICE

Genie requires that this procedure be performed every 250 hours or quarterly, whichever comes first.

1. Visually check the cylinder rods for scoring
2. For this operation, fully extend all of the cylinders and check that their rods are intact.

B-4 Inspect the Electrical Wiring

**NOTICE**

Genie requires that this procedure be performed every 250 hours or quarterly, whichever comes first.

Maintaining electrical wiring in good condition is essential to safe operation and good machine performance. Failure to find and replace burnt, chafed, corroded or pinched wires could result in unsafe operating conditions and may cause component damage.

⚠ WARNING

Electrocution hazard. Contact with hot or live circuits could result in death or serious injury. Remove all rings, watches and other jewelry.

1. Inspect the following areas for burnt, chafed, corroded and loose wires:
 - Inside of the operator's compartment
 - Underside of the chassis
 - Boom assembly
2. Inspect for a liberal coating of dielectric grease in the following locations:
 - All harness connectors
3. Start the engine and raise the boom so there is enough room to access and remove all the covers attached to the chassis.

CHECKLIST B PROCEDURES

REV A

B-5 Boom Sliding Pads Adjusting



Any boom section is fitted with adjustable pads located on the four sides of the profile. These pads are secured to both fixed and mobile part of every section.

All pads can be adjusted by the special shims supplied by TEREXLIFT upon demand.

Adjusting the pads:

1. Remove or loosen the screws fixing the pads in relation to type of shims used (with or without slots).
2. Fit the necessary amount of shims.
3. If the residual thickness of the pad is insufficient or near the maximum wearing limit, renew the pad.
4. Tighten the screws fixing the pads at the recommended torque (see below). Use a dynamometric wrench.

Tightening torques of the pad screws in relation to the screw diameter

Screws M10	Nm 30
Screws M14	Nm 50

NOTICE

Tightening torques higher than those recommended can cause the break of the pad or of the locking threaded bush.

B-6 Battery Electrolyte Level

1. Check the electrolyte level every 250 working hours; if necessary, add distilled water.
2. Ensure the fluid is 5÷6 mm above the plates and the cell levels are correct.
3. Check the cable clips are well secured to the battery terminals. To tighten the clips, always use a box wrench, never pliers.
4. Protect the terminals smearing them with pure vaseline.

⚠ WARNING

Battery electrolyte contains sulphuric acid. It can burn you if it touches your skin and eyes. Always wear goggles and protective gloves, and handle the battery with caution to prevent spillage. Keep metal objects (watch straps, rings, necklaces) clear of the battery leads, since they can short the terminals and burn you.

⚠ WARNING

Because the electrolyte is highly corrosive, it must never come in contact with the frame of the handler or electric/electronic parts. If the electrolyte comes in contact with these parts, contact the nearest authorised assistance centre.

⚠ WARNING

Do not add sulphuric acid; add only distilled water.

REV A

CHECKLIST B PROCEDURES

B-7 Block Valves

NOTICE

Genie requires that this procedure be performed every 250 hours or quarterly, whichever comes first.

The piloted blocking valves allow to held the load in position in case of burst of a flexible hose.

1. Load a weight near the maximum payload onto the boom.
2. Raise the load some centimetres above the ground (max 10 cm). To check the valve on the telescope extension cylinder move the boom to maximum height and extend it some centimetres.
3. Loosen the oil hoses to the cylinder of which you are checking the valve with caution.
4. To check the efficiency of the block valves of the outriggers, lower them to the ground and unload the weight of the tyres without raising them. Loosen the cylinder hoses to check the efficiency of the valve.

During the check, the oil will flow out of the hoses and the load shall remain blocked in position.

B-8 Tensioning The Boom Chains (Only for GTH-4018 SR)

To tighten the boom chains, follow the instructions below:

1. Fully extend the boom
2. Retract the boom by some 20/30 cm.
3. Tighten the chain up to a maximum tension value of 50 Nm
4. Check that all chains have been equally tensioned. If not, repeat the operation described above
5. Lock the chain tensioners by means of a counter-nut and locknut.

Checklist C Procedures

REV A

C-1

Smoke From the Exhaust Muffler

To check the quantity of smoke evacuated from the engine exhaust, proceed as follows:

1. Start the engine of the machine.
2. Wait for a few minutes so the engine can warm up correctly.
3. Visually check that the amount of smoke coming out of the exhaust is normal; repeat the check while accelerating the engine.



CAUTION *Do this check outdoors or use an adequate smoke extraction system.*



CAUTION *In case of excess smoke, strictly obey the instructions provided in the relevant Use and maintenance manual enclosed with the technical literature of the machine.*

C-2

Change Engine Oil and Filter



NOTICE

Engine specifications require that this procedure be performed semi-annually or after 500 hours, whichever comes first.

Required maintenance procedures and additional engine information is available in the *Perkins 1104D Operation and Maintenance Manual*

REV A

CHECKLIST C PROCEDURES

C-3 Change Engine Air Outer Filter

**NOTICE**

Engine specifications require that this procedure be performed semi-annually or after 500 hours, whichever comes first.

Required maintenance procedures and additional engine information is available in the *Perkins 1104D Operation and Maintenance Manual*

C-4 Change Hydraulic Oil Filter



1. Stop the machine on a level ground and engage the parking brake.
2. Place a container of suitable size under the filter to collect any oil leaks.
3. Remove the filter cover to get access to the filter element A.
4. Change the filter element, then, before fitting a new one, thoroughly clean and grease both seat and gasket.
5. Refit and tighten the filter cover.

NOTICE

The hydraulic oil filter cartridge shall be replaced as soon as the relative warning light comes on.

NOTICE

Hydraulic oil filter canisters cannot be cleaned or washed and refitted. They must be replaced with new ones of the type recommended by the manufacturer.



The handling and disposing of used oils may be ruled by local or national regulations. Address to authorised centres.

CHECKLIST C PROCEDURES

REV A

C-5
Clean Cabin Air Filter

1. Shut the engine down and engage the parking brake.
2. Pull filter out of the housing accessible from the outside of the cab.
3. Clean the filter bowl.
4. Clean the filter cartridge by beating it against a piece of wood.

NOTICE

Paper filters must never be cleaned using compressed air or washed with water and/or solvents.

Checklist D Procedures


REV A

D-1

Change Gear Box Oil



1. Place a container of suitable size under the drain plug.
2. Remove the plug ①.
3. Remove the drain plug ② and empty the gearbox.
4. Refit and tighten the drain plug ②.
5. Pour in new oil through the filler ① placed at the top of the reduction gear of the power divider. Stop when oil is level with hole ①.
6. Refit and tighten plug ①.




- | | |
|---|--------------|
| 1 | Filling plug |
| 2 | Drain plug |

D-2

Change Oil in the Turntable Gear



1. Stop the machine on a level ground and engage the parking brake.
2. Place a container of suitable size under drain plug C.
3. Remove drain plug C and let oil flow out of the reduction gear.
4. Unscrew the filling plug B.
5. Clean level plug A all around.
6. Loosen level plug A.
7. Refit and tighten drain plug C.
8. Pour new oil through the hole of plug B until it starts flowing out of hole A.
9. Refit and tighten plugs A and B.



CHECKLIST D PROCEDURES

REV A

D-3 Change Engine Air Inner Filter

**NOTICE**

Engine specifications require that this procedure be performed annually or after 1000 hours, whichever comes first.

Required maintenance procedures and additional engine information is available in the *Perkins 1104D Operation and Maintenance Manual*

D-4 Change Hydraulic Oil



1. Stop the machine on a level ground and make sure the parking brake is engaged.
2. Release the pressure from the hydraulic circuit.
3. Place a container of suitable size under the drain plug, placed in the lower part of the reservoir, and collect any oil leaks.
4. Remove the drain plug and allow oil to flow out into the container.
5. Refit the drain plug.
6. Add new oil by making sure that it matches the recommended type until it is level with the sight glass.



Handling and disposal of exhausted oils may be ruled by local or national regulations. Dispose of the exhausted oils through the special authorised centres.

REV A

CHECKLIST D PROCEDURES

D-5 Change Cabin Air Filter




1. Shut the engine down and engage the parking brake.
2. Pull filter out of the housing accessible from the outside of the cab.
3. Replace the cartridge.

D-6 Change Oil in the Axles




1. Place a container of suitable size under drain plug ②.
2. To drain the oil remove one the two level plugs ① and the drain plug ②.
3. Drain all oil.
4. Clean the plug ② and tighten it to a 60Nm torque.
5. Unscrew the oil fill plug ① and fill to the bottom of the level plug hole with the specified oil.
6. Wait to allow the oil to flow through the axle. Check oil level and fill to the specified level if necessary.
7. Screw the plug ① to a 60Nm torque.




CHECKLIST D PROCEDURES

REV A

D-7**Change Oil in the Epicyclic Reduction Gears**

1. Before draining the oil from wheel end rotate the wheel end so that the plug ④ is at the highest position [pos.A] and partially unscrew to release possible pressure.
2. Rotate the wheel end so that the plug ④ is toward the ground [pos.B].
3. Remove the plug and drain the oil.
4. Rotate the wheel end so that the hole ④ is in the position as shown in beside fig.

5. Fill to the bottom of the fill plug hole with specified oil.
6. Tighten the plug to a 60Nm torque.



Checklist E Procedures

REV A

E-1 Change Engine Coolant

**NOTICE**

Engine specifications require that this procedure be performed after 2 years or after 2000 hours, whichever comes first.

Required maintenance procedures and additional engine information is available in the *Perkins 1104D Operation and Maintenance Manual*

E-2 Machine Structure

NOTICE


Terexlift require that this procedure be performed after 5 years or after 6000 hours, whichever comes first

Check the state of the structure paying attention to the welded supporting joints, the boom pins, the platform and all attachment (if installed).



After the first 5 years, repeat this check every 2 years.

REV A



Intentionally blank page

Repair Procedures



Observe and Obey:

- ☑ Repair procedures shall be completed by a person trained and qualified on the repair of this machine.
- ☑ Immediately tag and remove from service a damaged or malfunctioning machine.
- ☑ Repair any machine damage or malfunction before operating the machine.

Before Repairs Start:

- ☑ Read, understand and obey the safety rules and operating instructions in the appropriate operator's manual on your machine.
- ☑ Be sure that all necessary tools and parts are available and ready for use.
- ☑ Read each procedure completely and adhere to the instructions. Attempting shortcuts may produce hazardous conditions.
- ☑ Unless otherwise specified, perform each maintenance procedure with the machine in the following configuration:
 - Machine parked on a firm, level surface
 - Boom in the stowed position
 - Key switch in the off position with the key removed
 - Wheels chocked

About This Section

Most of the procedures in this section should only be performed by a trained service professional in a suitably equipped workshop. Select the appropriate repair procedure after troubleshooting the problem. Perform disassembly procedures to the point where repairs can be completed. To re-assemble, perform the disassembly steps in reverse order.

Symbols Legend



Safety alert symbol—used to alert personnel to potential personal injury hazards. Obey all safety messages that follow this symbol to avoid possible injury or death.



Used to indicate the presence of an imminently hazardous situation which, if not avoided, will result in death or serious injury.



Used to indicate the presence of a potentially hazardous situation which, if not avoided, could result in death or serious injury.



Used to indicate the presence of a potentially hazardous situation which, if not avoided, may cause minor or moderate injury.



Used to indicate the presence of a potentially hazardous situation which, if not avoided, may result in property damage.

- Indicates that a specific result is expected after performing a series of steps.
- Indicates that an incorrect result has occurred after performing a series of steps.

Boom Components

REV A

1-1 How to Replace the Boom Wear Pads

1. Extend the boom until the wear pads are accessible.
2. Lower wear pads: Attach a lifting strap from an overhead crane to the fork end of the boom. Lift the boom just enough to remove the weight from the pads and allow the pad to be replaced.
3. Remove the wear pad mounting fasteners and remove the wear pads from the boom.
4. Lubricate the wear surface of the new pads with interflon grease.
5. Install the new wear pads. Install and securely

1-2 How to Remove the Lifting Fork Frame

1. With the boom in the stowed position, attach a lifting strap from an overhead crane to the top of the lifting fork frame at the front of the boom. Support the frame. Do not apply any lifting pressure.
2. If the machine is equipped with the lifting fork frame locking cylinder, disconnect the locking cylinder hoses from the boom.
3. Remove the screw securing the fork level cylinder pivot pin to the lifting fork.
4. Use a soft metal drift to remove the pivot pin.
5. Remove the screw securing the fork frame pivot pin to the boom.
6. Use a soft metal drift to remove the pivot pin.

⚠ WARNING

Crushing hazard. The fork frame could fall if not properly supported when the pivot pin is removed from the machine.

7. Remove the fork frame from the boom.

REV A

BOOM COMPONENTS

1-3 How to Remove the Boom



⚠ WARNING Bodily injury hazard. This procedure requires specific repair skills, lifting equipment and a suitable workshop. Attempting this procedure without these skills and tools could result in death or serious injury and significant component damage. Dealer service is strongly recommended.

NOTICE When removing a hose assembly or fitting, the O-ring on the fitting and/or hose end must be replaced and then torqued to specification during installation. Refer to paragraph “*Hydraulic Hose and Fitting Torque Specifications*” into Specification Section

1. Remove the lifting fork (see “*How to Remove the Lifting Fork Frame*” paragraph)
2. Tag and disconnect the cable reel plug placed at the top of the boom and remove the plastic clamps which secure the harness to the boom iron hoses.
3. Lift the boom up to when the rod end pivot pin is higher than the top of the cabin.
4. Place a support under the lifting cylinder.
5. Tag, disconnect and plug the two hydraulic hoses from the main valve of the extension cylinder.
6. Tag, disconnect and plug the four hydraulic hoses from the main valve to the boom iron hoses (two for tilting function and two for the attachment lock/unlock cylinder, when fitted).
7. Attach four lifting straps to the dedicated lifting points, from a total overhead 10 ton crane to the boom.

8. Using a punch and a hammer, remove the rod end pivot pin from the lifting cylinder. Keep attention to choose a punch smaller than the pivot pin!
9. Using a punch and a hammer, remove the rod end pivot pin from the slave cylinder. Keep attention to choose a punch smaller than the pivot pin!
10. Using a punch and a hammer, remove the rod end pivot pin from the bottom boom end. Keep attention to choose a punch smaller than the pivot pin!
11. Using the crane, raise the boom and lay it on a dedicated place.

BOOM COMPONENTS

REV A

1-4 How to Disassemble the GTH-4018 SR Boom



⚠ WARNING

Bodily injury hazard. This procedure requires specific repair skills, lifting equipment and a suitable workshop. Attempting this procedure without these skills and tools could result in death or serious injury and significant component damage. Dealer service is strongly recommended.


NOTICE

When removing a hose assembly or fitting, the O-ring on the fitting and/or hose end must be replaced and then torqued to specification during installation. Refer to paragraph “Hydraulic Hose and Fitting Torque Specifications” into Specification Section


NOTICE

Place the telehandler with enough room for stabilizing the machine and totally extended the boom.

1. Using a punch and a hammer, remove the rod end pivot pin from the tilting cylinder. Keep attention to choose a punch smaller than the pivot pin!
2. Remove the bottom end carter of the boom.
3. Tag, disconnect and plug the four hydraulic hoses from bracket **3**.
4. Remove the two brackets **2** with the relative pulleys.



5. Extend the boom for making accessible the inspection holes on inner section of boom.
6. Inserting a spanner through the inspection holes, remove the screws which fix the hoses holder block and disconnect the hydraulic hoses on the upper boom side.




7. Completely retract the boom.
8. Pull-out the internal steel hoses assembly.
9. Using a punch and a hammer, remove the rod end pivot pin from the extension cylinder. Keep attention to choose a punch smaller than the pivot pin!
10. In the lower part of the boom, tag and disconnect the chains from the chain tensioner.
11. Same for the upper part.
12. Tag and disconnect the chains placed in the rear part of the boom
13. Remove all the pads present inside the boom but the ones in the lower side
14. With a textile bridle connected to the bridge crane, sling the second, the third and fourth boom out of the first one.
15. Laying those boom sections on trestles.
16. Let the third boom section slide out of the second one.
17. Laying those boom sections on trestles.
18. Let the fourth boom section slide out of the third one.

Genie
A TEREX BRAND

REV A

BOOM COMPONENTS

1-5 How to Assemble the GTH-4018 SR Boom



1. Fit the two brackets with the relative pulleys (7) in the boom rear part;
2. Fit the chain bracket (6) with the relative chains (4) in the rear upper part of the fourth boom section; hook up a rope to the end of the chain for pulling it inside the boom;
3. Fit the chain bracket (2) with the relative chains (5) in the rear lower part of the fourth boom section;
4. Fit the rear lateral paths of the fourth boom section and the two lower ones;
5. Slide in the fourth boom section into the third boom section, pull the rope hooked up to the chains and make them pass on the pulley (7);
6. Fit the rear upper paths of the fourth boom section and all the ones of the third boom section;
7. Fit the pulley with the relative bracket (8);
8. Fit the two brackets with the relative pulleys (11);
9. Fit the chain bracket (10) with the relative chains (3) in the rear upper part of the third boom section; hook up a rope to the end of the chain for pulling it inside the boom;
10. Fit the chain bracket (9) with the relative chains (11) in the rear lower part of the third boom section;
11. Fit the rear lateral paths of the third boom section;
12. Slide in the third boom section into the second boom section, pull the rope hooked up to the chains (3) and make them pass on the pulley (11);
13. Fit the rear upper paths of the third boom section and all the ones of the second boom section;
14. Fit the rear lower paths of the second boom section and the rear lateral ones;
15. Fit the chain bracket (12) with the relative pin make the chains pass on the pulley;
16. Slide in the second boom section into the first boom section;
17. Fit all the paths of the first boom section;
18. Install the extension cylinder (16);
19. Install the boom on the machine and connect the hoses of the boom controls;
20. Retract the boom up to when chains (3) reach their anchoring point (17) and then fix them with the screws;
21. Fix the chains to the dedicated chain tentionairs (13), (14), (15)
22. Fit the steel pipes between the first and the second boom sections (18);
23. Fit internal steel hoses assembly (19) and the two lateral pulleys with the relative brackets (20);
24. Extend the boom for making accesible the inspection holes on the fourth boom section;



BOOM COMPONENTS

REV A

25. fix the hydraulic hoses to the hoses holder block **(20)**;
26. Follow these instructions to register the chains:
 - for the lower side chains, completely extend the boom and then retract it of 1 meter. Torque the chain tensioner to 50N/m;
 - for the upper side chains, completely retract the boom and then extend it of 1 meter. Torque the chain tensioner to 50N/m.

⚠ WARNING

Bodily injury hazard. This procedure requires specific repair skills, lifting equipment and a suitable workshop. Attempting this procedure without these skills and tools could result in death or serious injury and significant component damage. Dealer service is strongly recommended.


NOTICE

When removing a hose assembly or fitting, the O-ring on the fitting and/or hose end must be replaced and then torqued to specification during installation. Refer to paragraph "*Hydraulic Hose and Fitting Torque Specifications*" into Specification Section

REV A

BOOM COMPONENTS

1-6 How to Disassemble the GTH-4016 SR Boom



⚠ WARNING

Bodily injury hazard. This procedure requires specific repair skills, lifting equipment and a suitable workshop. Attempting this procedure without these skills and tools could result in death or serious injury and significant component damage. Dealer service is strongly recommended.

NOTICE


When removing a hose assembly or fitting, the O-ring on the fitting and/or hose end must be replaced and then torqued to specification during installation. Refer to paragraph "Hydraulic Hose and Fitting Torque Specifications" into Specification Section

1. Stabilizing the machine and set the boom to horizontal position.
2. Remove the pins (1), (2), (3) and (4).
3. Slide out the third boom section extension cylinder (5).
4. Remove the pin (6) and the forks frame (7).
5. Remove the internal hydraulic hoses for extension, fork levelling and attachment locking cylinder (when present).
6. Remove the front (11) and upper (12) lateral paths of the first boom section.
7. Remove the rear lateral (13) and upper (14) paths of the second boom section.
8. Slide out the second boom section: just before completely separating the two sections, remove the lower paths (15) of the first boom section.
9. Laying those boom sections on trestles.
10. Remove the front lateral (16) and upper (17) paths of the second boom section.
11. Remove the rear lateral (18) paths of the third boom section.
12. Slide out the third boom section: just before completely separating the two sections, remove the front lower paths (19).

BOOM COMPONENTS

REV A

1-7 How to Assemble the GTH-4016 SR Boom



1. Insert the cylinder (1) inside the third boom section and fit the pin;
2. Fix the cylinder to the boom;
3. Fit the rear lateral paths of the third boom section (4) and the lower ones (5);
4. Slide the third boom section into the second one;
5. Fit the rear upper paths of the third boom section (6);
6. In the second boom section, fit all the paths: front lower (7), lateral (8), upper (9);
7. Fit the rear lateral paths of the second boom section (10) and the lower ones (11);
8. Slide the second boom section into the first one;
9. Fit the upper paths of the second boom section (12);
10. In the first boom section, fit all the paths: front lateral (13), lower (14), upper (15);
11. Insert the cylinder pin (16);
12. Insert the extension cylinder pin (17);
13. Insert the pins (18-19-21), the fork levelling cylinder (20) and the fork frame (22);
14. Fit the hoses of the extension cylinder as follow:
 - slide in the hoses through the opening under the boom (A);
 - push the hoses towards the rear part of the boom;
 - connect the hoses between the safety valve (B) and the steel hoses (C);
15. Follow the same procedure for the other two hoses couples making them pass inside the conduit (D);
16. Connect the left two hoses to the safety valve of the fork levelling cylinder (E) and the right two hoses to the fitting bracket placed on the right side of the top boom end.

REV A

BOOM COMPONENTS

1-8 How to Remove a Lift Cylinder



⚠ WARNING

Bodily injury hazard. This procedure requires specific repair skills, lifting equipment and a suitable workshop. Attempting this procedure without these skills and tools could result in death or serious injury and significant component damage. Dealer service is strongly recommended.

1. Release the attachment.
2. Anchor the attachment holding frame to the hooks of the slinging chain.
3. Raise the boom to max. height (the hinging pin of the cylinder rod must be over the driving cabin) operating alternately the bridge crane and the hydraulic boom raising control of the machine.
4. Stop raising when the slinging chains are slightly under tension.
5. Place a container of suitable size under the hydraulic piping before disconnecting.
6. Disconnect two hydraulic hoses from the blocking valve, then plug the disconnected connectors to prevent dust and impurities from entering the circuit.
7. To move the boom using the up/down controls of the bridge crane, previously disconnect the rod of the fork balance cylinder.



Used oils must be handled and disposed of according to local regulations. Address to legally authorised centres.

8. Remove the screw fixing the pitching cylinder pin.
9. Knock out and extract the pin using a plug of soft material (aluminium, copper, wood, etc.).
10. Fix the balance cylinder to the cabin with a sling and ensure it does not hinder the movement of the boom.
11. Secure the raising cylinder to the boom with a sling.
12. Remove the screw which fixes the rod pin to the boom.
13. Knock out and extract the pin using a plug of soft material (aluminium, copper, wood, etc.).
14. Put two wooden plugs, each 100mm high, on the oil tank to support the raising cylinder.
15. Lower the boom until the cylinder rests on the supporting plugs previously positioned.
16. Untie the sling fixing the cylinder to the boom, then raise the boom with the bridge crane to go on working.
17. Remove the screw which fixes the bottom-side pin of the cylinder.
18. Knock out the pin using a plug of soft material (aluminium, copper, wood, etc.) and extract it through the hole on the frame.
19. Lower the boom onto the adjustable stand to remove the slinging chains.
20. Sling the cylinder with a textile bridle and remove it from the machine using the bridge crane.

⚠ CAUTION

To reassemble the cylinder, repeat the steps above in reversed order. Remember to set the circuit under pressure before releasing the bridge crane.

BOOM COMPONENTS

REV A

1-9 How to Remove the Second Boom Section Extension Cylinder**⚠ WARNING**

Bodily injury hazard. This procedure requires specific repair skills, lifting equipment and a suitable workshop. Attempting this procedure without these skills and tools could result in death or serious injury and significant component damage. Dealer service is strongly recommended.

1. Set the boom to horizontal position with the telescope slightly extended to work on the cylinder connecting pin (rod side).
2. Remove the screw fixing the pin to the boom section.
3. Extract out and knock the pin using a plug of soft material (aluminium, copper, wood, etc.).
4. Remove the two screws of the cylinder holder.
5. Place a container of suitable size under the hydraulic piping before disconnecting



Used oils must be handled and disposed of according to local regulations. Address to legally authorised centres

6. Disconnect the hydraulic hoses of the cylinder, then plug the disconnected connectors to prevent dust and impurities from entering the circuit.
7. Loosen and remove the screw fixing the cylinder pin (bottom side).
8. Extract out and knock the pin using a plug of soft material (aluminium, copper, wood, etc.).
9. Pull out the cylinder from the boom section and sling it with the textile bridles connected to the bridge crane.

1-10 How to Remove the Third Boom Section Extension Cylinder (only for GTH-4016 SR)**⚠ WARNING**

Bodily injury hazard. This procedure requires specific repair skills, lifting equipment and a suitable workshop. Attempting this procedure without these skills and tools could result in death or serious injury and significant component damage. Dealer service is strongly recommended.

1. Set the boom to horizontal position and extend it until the pin of the rod side is on the 3rd boom section.
2. Remove the screw fixing the pin to the 3rd boom section.
3. Extract out and knock the pin using a plug of soft material (aluminium, copper, wood, etc.). If necessary, lift the cylinder using a jack under the boom, corresponding to the hole inside the 3rd boom section.
4. Retract the boom entirely, remove the screw that locks the pin (bottom side). Extract out and knock the pin using a plug of soft material (aluminium, copper, wood, etc.).
5. Place a container of suitable size under the hydraulic piping before disconnecting.



Used oils must be handled and disposed of according to local regulations. Address to legally authorised centres

6. Disconnect the two hydraulic hoses from the blocking valve, then plug the disconnected connectors to prevent dust and impurities from entering the circuit.

REV A

BOOM COMPONENTS

7. Remove the four screws fixing the cylinder to the 3dr section boom.
8. Pull out the cylinder from the boom section and sling it with the textile bridles connected to the bridge crane. When half cylinder is out, sling it in the center so it can be in horizontal position.
9. Extract the cylinder from the boom entirely and place it on to a bench.
10. Lock the cylinder to avoid damage for people and things.

1-11 How to Remove the Fork Level Cylinder



1. Release the attachment.
2. Remove the screw fixing the rod pin.
3. Knock out and extract the pin using a plug of soft material (aluminium, copper, wood, etc.).
4. Fix the cylinder with a textile bridle connected to the bridge crane to support its weight.
5. Place a container of suitable size under the hydraulic piping before disconnecting



Used oils must be handled and disposed of according to local regulations. Address to legally authorised centres

6. Disconnect three hydraulic hoses from the blocking valve, then plug the disconnected connectors to prevent dust and impurities from entering the circuit.
7. Drive out the lower pin.
8. Unscrew and extract the screw fixing the pin.
9. Knock out the pin using a plug of soft material (aluminium, copper, wood, etc.) and extract it through the hole on the frame.
10. Remove the cylinder from the machine using the bridge crane.

BOOM COMPONENTS

REV A

1-12 How to Replace the Fork Level Cylinder Hoses (*only for GTH-4016 SR*)

**⚠ WARNING**

Bodily injury hazard. This procedure requires specific repair skills, lifting equipment and a suitable workshop. Attempting this procedure without these skills and tools could result in death or serious injury and significant component damage. Dealer service is strongly recommended.

1. Before disconnecting or refitting a flexible hose, carefully clean the area all around.
2. Blow some compressed air to remove any impurity.
3. For an easier renewal of the hoses, whose run is not clearly visible, proceed as follows:
 - disconnect the hose to be replaced from both sides
 - attach a cord to the side of the hose which reaches the boom tip
 - disconnect the hose from the rear side of the boom
 - remove the hose from the hole under the first section boom until it comes out completely
 - disconnect the cord and reconnect the same to the end of the new flexible hose making sure the hose has been previously plugged to prevent dirt from entering the circuit
 - proceed in reverse order and reassemble the hose.

Operator's Compartment

REV A

2-1 How to Remove the Operator's Compartment



The operator's compartment is used to activate machine functions while sitting in the operator's drivers seat.

Within the operator's compartment there is a transmission column shifter, steering selector, 4-way controller, accelerator pedal, brake pedal and a differential lock switch. All of these components are replaceable.

For further information or assistance, consult the Genie Industries Service Department.

⚠ WARNING

Bodily injury hazard. This procedure requires specific repair skills, lifting equipment and a suitable workshop. Attempting this procedure without these skills and tools could result in death or serious injury and significant component damage. Dealer service is required.

1. Cut the plastic fasteners fixing the electrical cables, then disconnect all of the electrical wires.
2. Disconnect the hydraulic lines of the power steering unit and of the heater.
3. Disconnect the electrical and hydraulic connections of the brake pump.
4. Disconnect the wire of the throttle pedal:
 - Remove the locking clip;
 - Remove the screws fixing the throttle rope.
5. Disconnect the wire of the manual throttle:
 - Disconnect the wire of the manual accelerator.
 - Remove the screws fixing the throttle bracket.
6. Disconnect the power cables of the horn.
7. Disconnect the ground wire.
8. Remove the 4 fixing screws of the cabin.
9. Fit and screw down two eyebolts to the top the cabin in the special seats.
10. Fix a two-leg chain connected to the bridge crane, to the cabin. Raise slowly after having checked that all electrical and hydraulic connections have been disconnected. Avoid crashing against parts of the machine. Lower the cabin to the ground in a site where it can not hinder other maintenance operations.

OPERATOR'S COMPARTMENT

REV A

2-2 How to Remove the Steering Column

1. Remove the lower part of the dashboard
2. Tag the hoses.
3. Remove the hoses
4. Cap the steering column holes and hoses holes.
5. Remove the screws which fix the steering to the frame
6. Remove the steering column

2-3 How to Test the Steering Column

1. Completely raise the boom.
2. Apply the maintenance collar to the lifting cylinder.
3. Disconnect the hose fitted in the "CF" position of the priority valve.
4. Insert a "T" fitting between the priority valve and the hose and then apply a testing port.
5. Install a 600 bar pressure gauge into the testing port
6. Start the engine, completely turn the steering wheel and check the reading on the pressure gauge: it must be 190 bar.
7. If not, set the valve fixed on the steering device up to when the reading on the pressure gauge will be 190 bar.

REV A

OPERATOR'S COMPARTMENT

2-4 How to Remove the Steering Selector

1. Locate and open the battery access door.
2. Disconnect the battery from the machine.

⚠ WARNING Electrocutation hazard. Contact with electrically charged circuits could result in death or serious injury. Remove all rings, watches and other jewelry.

3. Remove the dashboard.
4. Slip off the steering plug.
5. Remove the upper plastic part of the steering selector.
6. Remove all the screws that fix it in place.
7. Slip off the selector.

2-5 How to Remove the Joystick

1. Locate and open the battery access door.
2. Disconnect the battery from the machine.

⚠ WARNING Electrocutation hazard. Contact with electrically charged circuits could result in death or serious injury. Remove all rings, watches and other jewelry.

3. Remove the screws which fix the joystick to the harmrest.
4. Slip off the joystick.
5. Disconnect the joystick plug.

OPERATOR'S COMPARTMENT

REV A

2-6 How to Test the Brake Pedal

1. Disconnect the hose which goes to the accumulator.

⚠ WARNING Bodily injury hazard. Spraying hydraulic oil can penetrate and burn skin. Loosen hydraulic connections very slowly to allow the oil pressure to dissipate gradually. Do not allow oil to squirt or spray.

2. Apply a testing port on the accumulator fitting.
3. Reconnect the hose.
4. Install a pressure gauge into testing port
5. Start the engine and allow the engine to idle after warming the engine to operating temperature.
6. Observe the reading on the pressure gauge: it must be 150 bar.
7. Fully press and release the brake pedal.
8. The reading on the pressure gauge starts to decrease.
9. Once it reaches the 70 bar, the automatic accumulator filling starts pumping the oil into the two accumulators up to when the reading on the pressure gauge reaches 150 bar.
10. If not, set the valve.

2-7 How to Remove the Brake Pedal

1. Set the ignition switch in position 1
2. Fully press and release the brake pedal up to when the low brake pressure warning light comes on.
3. Set the ignition switch in position 0
4. Remove all the electrical connections
5. Tag the hoses
6. Remove the screws securing the brake pedal in place.

REV A

Fuel and Hydraulic Tanks

3-1 How to Remove the Fuel Tank and the Hydraulic Tank.

WARNING

Bodily injury hazard. This procedure requires specific repair skills, lifting equipment and a suitable workshop. Attempting this procedure without these skills and tools could result in death or serious injury and significant component damage. Dealer service is strongly recommended.

1. Close the oil intake valve.
2. Empty the tanks.
3. Remove all the screws.
4. Loosen all the clamps and pull out the hoses.
5. Disconnect the electrical wire.
6. Remove the electrical wire from bulb on the hydraulic filter.
7. Place a container of suitable size under the hydraulic piping before disconnecting

PROTECT THE ENVIRONMENT

Used oils must be handled and disposed of according to local regulations. Address to legally authorised centres

8. Disconnect all flexible hoses.
9. Remove the screws fixing the tanks to the turret of the machine.
10. Fix the tanks assy firmly using some textile bridles connected to the bridge crane, check that all parts have been loosened, then raise and lower the assy to the ground in a site where it cannot hinder other operations.

Transmission

REV A

4-1 How to Remove the Transmission Pump

⚠ WARNING Bodily injury hazard. This procedure requires specific repair skills, lifting equipment and a suitable workshop. Attempting this procedure without these skills and tools could result in death or serious injury and significant component damage. Dealer service is strongly recommended.

NOTICE When removing a hose assembly or fitting, the O-ring on the fitting and/or hose end must be replaced and then torqued to specification during installation. Refer to paragraph "*Hydraulic Hose and Fitting Torque Specifications*" into Specification Section

NOTICE Perform this procedure with the engine off and cool.

⚠ WARNING Bodily injury hazard. Spraying hydraulic oil can penetrate and burn skin. Loosen hydraulic connections very slowly to allow the oil pressure to dissipate gradually. Do not allow oil to squirt or spray.

1. Completely open the engine hood.
2. Remove the front cover of the engine housing.
3. Remove the cover that is under engine.
4. Using the cut-off battery switch, disconnect the battery.
5. Remove the screws that fix the cut-off battery switch support.
6. Remove the hydrostatic transmission pump.
7. Remove the two connectors.
8. Tag, disconnect and plug the hoses.
9. Cap the hydrostatic transmission pump's holes.
10. Remove the hydrostatic transmission pump's screws .

11. Tag and disconnect the harness from the transmission.
12. Support and secure the rear of the engine to a lifting device of suitable capacity. Do not apply any lifting pressure.
13. Remove the hydrostatic transmission pump.

REV A

Hydraulic Pumps

5-1 How to Test and Adjust the Function Pump

NOTICE

When removing a hose assembly or fitting, the O-ring on the fitting and/or hose end must be replaced and then torqued to specification during installation. Refer to paragraph "*Hydraulic Hose and Fitting Torque Specifications*" into Specification Section.

1. Insert the 600bar manometer in the TP2 port.
2. Insert the 600bar manometer on the TP3 port.
3. Start the engine.
4. Verify that 2nd gear is inserted.
5. Using the manual accelerator, increase the engine up to 1100rpm (see How to Check the Engine RPM paragraph).
6. Using the brake pedal, keep the machine stopped.
7. Engage the forward or backward and check that the manometer, on the port TP3 (0-600psi), reads a value of 50psi.
8. If not, set the valve under the pump.
9. With the machine at the maximum rpm check that, in the port TP3, the pressure gauge reads 450psi.
10. If not, set the valve on the right side of the pump.

5-2 How to Remove the Boom Gear Function Pump

1. Closed the valve of the main hydraulic line. It is behind the cabin steps.
2. Tag the hoses.
3. Remove the hoses screws.
4. Remove the hoses.

⚠ WARNING

Bodily injury hazard. Spraying hydraulic oil can penetrate and burn skin. Loosen hydraulic connections very slowly to allow the oil pressure to dissipate gradually. Do not allow oil to squirt or spray.

5. Cap the boom function gear pump holes and the hoses holes.
6. Remove the boom function gear pump screws.
7. Remove the boom function gear pump.

HYDRAULIC PUMPS

REV A

5-3 How to Test the Boom Function Gear Pump

1. Insert the 600 bar manometer in the TP1 port above the main valve
2. Start the engine.
3. Completely retract the boom
4. Without releasing the joystick, keep pushing the throttle pedal.
5. Check the pressure in the manometer. It must be 280 bar.
6. If not, set the pressure of the relief valve.

5-4 How to Remove the Auxiliary Gear Pump

1. Closed the valve of the main hydraulic line. It is behind the cabin steps.
2. Tag the hoses
3. Remove the connectors.
4. Remove the hoses

⚠ WARNING

Bodily injury hazard. Spraying hydraulic oil can penetrate and burn skin. Loosen hydraulic connections very slowly to allow the oil pressure to dissipate gradually. Do not allow oil to squirt or spray.

5. Cap the auxiliary gear pump holes and the hoses ones.
6. Remove the auxiliary gear pump screws
7. Remove the auxiliary gear pump.

REV A

HYDRAULIC PUMPS

5-5 How to Test the Auxiliary Gear Pump

1. Insert the 0-60psi manometer in the TP4 port
2. Start the engine.
3. Increase the engine up to 2000rpm
4. Close the valve placed near to the relief valve.
5. Check the pressure in the manometer. It must be 180psi.
6. If not, set the relief valve.
7. Open the valve.

Main Valve

REV A

6-1 How to Remove the Main Valve

1. Closed the valve of the main hydraulic line. It is behind the stair for the cabin.
2. Tag the hoses.
3. Remove the connectors.
4. Remove the hoses

⚠ WARNING

Bodily injury hazard. Spraying hydraulic oil can penetrate and burn skin. Loosen hydraulic connections very slowly to allow the oil pressure to dissipate gradually. Do not allow oil to squirt or spray.

5. Cap the main valve holes and the hoses holes
6. Remove the main valve screws
7. Support and secure the main valve to a lifting device of suitable capacity. Do not apply any lifting pressure.
8. Raise the main valve and laying it on the floor.

6-2 How to Test the Main Valve

1. Insert the 600 bar manometer in the TP1 port, above the main valve
2. Start the engine.
3. Press the throttle pedal and let the engine increases up to 2000 rpm.
4. Moving the joystick, retract the boom and check that the manometer reads 280 bar
5. If not, set the valve placed above the main valve.

REV A

Outriggers

7-1 How to Remove the Outriggers Valves Block

1. Tag all the hoses connected to the outriggers valves block placed in the front part of the chassis
2. Remove the connectors.
3. Remove the hoses.
4. Cap the outriggers valves block holes and the hoses holes.
5. Remove the screws that fix the valves block.
6. Remove the outrigger valves block.

7-2 How to Test the Pressure on the Outriggers Valves Block

1. Insert a 600 bar pressure gauge in the TP1 port of the main valve.
2. Start the engine and lower the outriggers.
3. Press the throttle pedal and make the engine increases up to maximum of rpm.
4. Pushing the dedicated buttons, keep lower the outriggers and check that the manometer reads 280 bar
5. If not, proceed with the procedure of paragraph 7-1.

OUTRIGGERS

REV A

7-3 How to Test the Outriggers Retraction Valve (only for GTH-4018 SR)

1. Insert a 600 bar pressure gauge in the TP5 port placed into the engine compartment.
2. Start the engine and completely retract (or extend) the outriggers.
3. Keep the outriggers in this position and check that the manometer reads 100 bar.
4. If not, set the valve placed in the front part of the chassis, on a support in front of the slewing ring.
5. Keeping the outriggers completely retracted (or extended), check that the manometer reads 100 bar.

Sensors

REV A

8-1 How to Remove the Boom Length and Angle Sensor

1. Disconnect the connector
2. Remove the retainer on the cable keeping a lot of attention.
3. Remove the screws.
4. Remove the boom length and angle sensor.

8-2 How to Test the Boom Length and Angle Sensor

1. See paragraph "Overload Warning System Fault Codes" from point 5 to point 10.

NOTICE

After reinstalling the sensors, follow the *"How to Set the Overload Warning System"* paragraph.

SENSORS

REV A

8-3 How to Remove the Trasducer Pressure Switches

1. Lift the boom up to 50°.
2. Support and secure the boom to a lifting device of suitable capacity.
3. Remove the connector.
4. Slowly remove the trasducer pressure switch.

▲WARNING

Bodily injury hazard. Spraying hydraulic oil can penetrate and burn skin. Loosen hydraulic connections very slowly to allow the oil pressure to dissipate gradually. Do not allow oil to squirt or spray.

5. Cap the valve hoses.

8-4 How to Test the Trasducer Pressure Switches

1. See paragraph "Overload Warning System Fault Codes", point 11 and 12.

REV A

SENSORS

8-5 How to Test the Turret Proximity Switches

1. Align the turret to the chassis.
2. Insert the turret locking pin.
3. Check that, on the overload system display, the writing "TURRET ALIGNED" appears on the 8th row.
4. Check that, on the overload system display, the writing "TYRES FRONTAL" (or "OUTRIGGERS FRONTAL" if the machine is on stabilizers) appears on the 2th row.
5. Remove the turret locking pin.
6. Turn the turret more than 10° (refers to the decal applied on the chassis)
7. Check that, on the overload system display, the writing "TYRES LATERAL" (or "OUTRIGGERS LATERAL" if the machine is on stabilizers) appears on the 2th row.

8-6 How to Test the Chassis Proximity Switches

1. Remove the outriggers steel guards.
2. Raise the outriggers and verify that the yellow LED placed on the proximity switch is on
3. Check that the machine can move.
4. Lower the outriggers.
5. Remove the turret locking pin.
6. On the overload system display, simultaneously press the two buttons **PLUS (+)** and **MINUS (-)** to access the *Diagnostic Screen Pages*.
7. Using the **ARROW** buttons, reach the page "**STABILIZERS SENSOR**" to verify that:
 - ✓ all the "safety switch" values correspond to 1
 - ✓ all the "stab down" values correspond to 1
8. Using the selector dedicated, set the steering mode to four-wheel steering and completely turn the steering wheel.
9. Using the dedicated selector, set the steering mode to two-wheel steering and slowly turn the steering wheel in the opposite direction than above.
10. Check that, on the overload system display, the writing "REAR TIRES ALIGNED" appears on the 8th row.

SENSORS

REV A

8-7 How to Remove the Outriggers Load Pins

1. Lower the outriggers.
2. Remove the connectors.
3. Remove the screws.
4. Using a teflon punch and a hammer, pull out the load cell pin.
5. Reassemble the load cell pin making sure the arrow is directed towards the external part of the machine.

Miscellaneous

REV A

9-1 How to Test the Emergency Pump

1. Set the ignition switch in position 1.
2. Press the emergency stop button.
3. Press the emergency pump switch in the cab and, using the joystick, retract the boom.
4. Insert the 600 bar pressure gauge in the TP6 port placed into the engine compartment.
5. Keep doing the retraction movement and check the pressure: it must be 150 bar
6. If not, set the valve placed above the emergency pump.

9-2 How to Test the Differential Lock Pressure Reducing Valve

1. In the valve placed on the front right side of the chassis, install a 60 bar pressure gauge connected to the TP7
2. Start the engine and check the pressure: it must be 10 bar.
3. If not, set the valve up to get 10 bar pressure.

MISCELLANEOUS

REV A

9-3 How to Check the Engine RPM

1. Take a multimeter and set it on “freq or Hz”
2. Connect the negative prod to the ground
3. Connect the positive prod to the “W” pin of the alternator
4. Start the engine
5. Using the manual accelerator, increase the engine up to 1100rpm (which on the multimeter corresponds to a reading of 0.40)

Settings



Observe and Obey:

- ☒ Repair procedures shall be completed by a person trained and qualified on the repair of this machine.
- ☒ Immediately tag and remove from service a damaged or malfunctioning machine.
- ☒ Repair any machine damage or malfunction before operating the machine.

Before Repairs Start:

- ☒ Read, understand and obey the safety rules and operating instructions in the appropriate operator's manual on your machine.
- ☒ Be sure that all necessary tools and parts are available and ready for use.
- ☒ Read each procedure completely and adhere to the instructions. Attempting shortcuts may produce hazardous conditions.
- ☒ Unless otherwise specified, perform each maintenance procedure with the machine in the following configuration:
 - Machine parked on a firm, level surface
 - Boom in the stowed position
 - Key switch in the off position with the key removed
 - Wheels chocked

SETTINGS

REV A

How to Read the Overload Warning System Display

1. Start the engine
2. Select "Forks"
3. ENTER
4. Simultaneously press the two buttons PLUS (+) and MINUS (-)
5. **Page 1 - SENSOR PAGE :**
 - **frontal turret** when the value is 1 it indicates the turret is between -10° and $+10^{\circ}$;
 - **aligned turret** when the value is 1 it indicates the turret is perfectly aligned for inserting the Lock Turret Pin;
 - **rear tires aligned** when the value is 1 it indicates the rear tires are perfectly aligned;
 - **boom plug connected** when the value is 1 it indicates the manplatform plug is connected and the controls from the cabin are disabled.
6. Press button ARROW UP
7. **Page 2 - "STABILIZERS SENSOR"**
 - **stab down** when the value is 1 it indicates the outrigger is on the ground. It's connected to the load cell pin
 - **safety switch** when the value is 1 it indicates the outrigger is down.
8. Press button ARROW UP
9. **Page 3 - "STABILIZERS SENSOR"**
 - **stab down** when the value is 1 it indicates the outrigger is on the ground. It's connected to the load cell pin
 - **bit** is the signal that the load cell pin sent. If the value is lower than 82 bit the cell is broken or disconnected. If the value is higher than 940 bit the cell is broken. In both situation the warning system will enter in alarm mode and the writing "err stab fw/bw left/right open" will appear on the bottom row of the main page. If the load cell seized up, the displayed warning will be "err stab fw/bw left/right vbat".
10. Press button ARROW UP
11. **Page 4 - "TILT SENSOR"**
 - it represents (in bit) the electronic levelling sensor and it ranges between $\pm 2,5^{\circ}$. When the value it registers is besides that range, it is not possible to use the controls from the man-platform and machine levelling warning light placed on the instrument dashboard starts flashing.
12. Press button ARROW UP
13. **Page 5 - "MOTION SENSORS"**
 - **raised stab** when the value is 1 it indicates the outrigger is in storage position, so the machine can move
 - **parking brake** when the value is 1 it indicates the parking brake is not engage
14. Press button ARROW UP
15. **Page 6 - "STABILIZERS PUSHBUTTON"**
 - when the value is 1 it indicates the outriggers pushbutton is active.
16. Press button ARROW UP
17. **Page 7 - "SWITCHES/PUSHBUTTON"**
this screen includes the following pushbutton:
 - **jobsite, platform, 2nd hydr line, mixing bucket, load limiter bypass, coordinate steering, crab steering:** for each of them, when the value is 1 it indicates the pushbutton is active.
18. Press button ARROW UP
19. **Page 8 - "MAX SPEED TUR ROT POT"**
it indicates the % value of the turret rotation speed potentiometer
 - **Environment temperat** it indicates the environment temperature, joystick doesn't work under -20° .
 - **Dump valve status** when the value is 1 it indicates the dump valve status is active

REV A

SETTINGS

20. Press button ARROW UP

21. Page 9 - “RIGHT JOYSTICK”

it indicates the right joystick movement values

- **y** raise/lower
- **x** forks rotation/attachment hydraulic locking %
- **fpry** extension/retraction %
- **fprx** turret rotation %
- **aut.Funct.Button** when the value is 1 it indicates the white pushbutton placed on the joystick is active
- **enabling button** when the value is 1 it indicates the enabling control switch placed on the joystick is active
- **function button** not active

22. Press button ARROW UP

23. Page 10 - “LEFT JOYSTICK”

it indicates the left joystick movement values

- **y** lower/recover the winch rope
- **x** turret rotation %
- **enabling button** when the value is 1 it indicates the enabling control switch placed on the joystick is active

24. Press button ARROW UP

25. Page 10 - “PRESSURE SENSORS”

it represents the pressure value (in bar and bit) for the pressure switches of the lifting and levelling cylinders

- **Psp** pressure switch value for lifting cylinder rod chamber
- **psr** pressure switch value for lifting cylinder piston chamber
- **pep** pressure switch value for levelling cylinder rod chamber
- **per** pressure switch value for levelling cylinder piston chamber

26. Press button ARROW UP

27. Page 10 - “MAIN VALVE DRIVER”

indicates the INPUT values to the control unit from the main valve and from the joystick.

- **pwm** is the value in bit from the joystick
- **pos** is the value in bit from the main valve. This value can be visualized only with the engine on.

SETTINGS

REV A

How to Set the Overload Warning System

1. Start the engine.
2. Stabilize the machine on a level ground.
3. Align the turret to the chassis.
4. Insert the turret locking pin.
5. Turn off the engine
6. Start the engine again.
7. Press "ENTER" and then simultaneously press the two buttons PLUS (+) and MINUS (-) up to the request of password.
8. To dial the password (contact the Service), keep in mind that pressing button PLUS (+) figures increase and pressing button MINUS (-) figures decrease.
9. Confer each figure pressing "ENTER"
10. Once the password has been completed, the writing "2nd LEVEL ACCESS" appears.
11. Keep the button PLUS (+) pressed to make the setting options appear.
12. Language
13. ENTER
14. Once entered, use ARROW UP or ARROW DOWN pushbuttons to select the language
15. ENTER
16. By using PLUS (+) and MINUS (-) pushbuttons, select "SAVE"
17. ENTER
18. By using PLUS (+) and MINUS (-) pushbuttons, select "EXIT"
19. ENTER
20. By using ARROW UP or ARROW DOWN pushbuttons, select "LENGHT"
21. Completely retract the boom.
22. ENTER
23. By using PLUS (+) and MINUS (-) pushbuttons, select "MIN"
24. ENTER
25. By using PLUS (+) and MINUS (-) pushbuttons, select "SAVE"
26. ENTER
27. Completely extend the boom.
28. By using PLUS (+) and MINUS (-) pushbuttons, select "MAX"
29. ENTER
30. By using PLUS (+) and MINUS (-) pushbuttons, select "SAVE"
31. ENTER
32. By using PLUS (+) and MINUS (-) pushbuttons, select "EXIT"
33. ENTER
34. By using ARROW UP or ARROW DOWN pushbuttons, select "ANGLE"
35. ENTER
36. Put the boom in horizontal position helping you by a tilt device.
37. By using PLUS (+) and MINUS (-) pushbuttons, select "ZERO"
38. ENTER
39. By using PLUS (+) and MINUS (-) pushbuttons, select "SAVE"
40. ENTER
41. By using PLUS (+) and MINUS (-) pushbuttons, select "EXIT"
42. ENTER
43. TILT SENSOR (if present)
44. ENTER



REV A

SETTINGS

45. By using PLUS (+) and MINUS (-) pushbuttons, select "ZERO"
46. ENTER
47. By using PLUS (+) and MINUS (-) pushbuttons, select "SAVE"
48. ENTER
49. By using PLUS (+) and MINUS (-) pushbuttons, select "EXIT"
50. Check that the Machine Levelled Warning Light is on.
51. CLOCK
52. ENTER
53. By using PLUS (+) and MINUS (-) pushbuttons, select "MODIF"
54. ENTER
55. Blinking cursor pass to year field: by using PLUS (+) and MINUS (-) pushbuttons set the right year
56. ENTER
57. Blinking cursor pass to month field: by using PLUS (+) and MINUS (-) pushbuttons set the right month
58. ENTER
59. Blinking cursor pass to day field: by using PLUS (+) and MINUS (-) pushbuttons set the right day
60. By using PLUS (+) and MINUS (-) pushbuttons, select "SAVE"
61. ENTER
62. By using PLUS (+) and MINUS (-) pushbuttons, select "EXIT"
63. ENTER
64. By using ARROW UP or ARROW DOWN pushbuttons, select "ENABLING IMPLEMENTS"
65. ENTER
66. By using ARROW UP or ARROW DOWN pushbuttons, select the attachment that have to be modified
67. ENTER
68. By using PLUS (+) and MINUS (-) pushbuttons, select "MODIF"
69. ENTER
70. By using PLUS (+) and MINUS (-) pushbuttons, select "0" when the attachment is not present, or select "1" when the attachment is present
71. By using PLUS (+) and MINUS (-) pushbuttons, select "SAVE"
72. ENTER
73. By using PLUS (+) and MINUS (-) pushbuttons, select "EXIT"
74. ENTER
75. ESC
76. Turn off the engine and then start it again.



SETTINGS

REV A

How to Set the Machine Functions

1. Open the dashboard and find the connector X941 behind the fuses board.
2. Install the cable 55.0602.0203 from the connector X941 to the computer.
3. In the computer the program "MTGTH40XX-R.exe" has to be installed. If not, contact the Genie Service dept.
4. Switch on the instrument panel.
5. Make the program run.
6. Select the right "COM"
7. Click on Parameters menu and then select one of the options by clicking on it
8. Setting allows to select a parameter group:
 - Function: speed and ramp time for each function
 - Slowing: reduction speed of some functions depending on telehandler geometrical and current mass value and contemporary operations

PARAMETERS - SETTING

By means of each one of parameter setting menu is possible to:

- Open file reading parameter data
- Save file with parameter data (only when parameters data have been read from display unit or when a file has been opened)
- Read data from display unit (only when COM is selected, serial adapter connected to PC and telehandler harness and telehandler has power switched on)
- Write data to display unit (only when COM is selected, serial adapter connected to PC and telehandler harness and telehandler has power switched on)

When a file is both opened and saved all parameters (functions, slowing and general) are read and saved then the file can be used to download all parameters through Parameter-Download.


But, by pressing on write data button, for example after a modification of some parameters, ONLY parameters related to the window (functions, slowing or general) are written to display unit.

When a window is activated no parameters are shown until either a read from display unit or a file opening are done; once parameters have been read passing to another window will show you parameters either read or opened from a file.

REV A

SETTINGS


Once clicked on *Parameters - Setting- Functions*, following window will be displayed:



SETTINGS

REV A

After opening a file or reading from display unit, all function parameters available for the place where functions are operated will be displayed



REV A

SETTINGS

Now it is possible to change parameters by clicking on arrow in the box of the parameter, arrow up to increase the value and arrow down to decrease it.

When the system detect that parameter is different from the initial value the box will become orange.


In order to write data to the unit, **WRITE DATA button MUST be pressed**, parameters will be soon used by the unit, but if a function is activated parameters just written will be used when joystick pass through neutral.

- Minimum (MIN) driving value is the command voltage that system uses when a function is operated and joystick is put just outside central neutral zone
- Maximum (MAX) driving value is the command voltage that system uses when a function is operated and joystick is put at its maximum stroke in one direction.
- Ramp-up parameter is the speed at which the proportional command voltage follows joystick analog signal when it is increased (it goes away from neutral position)
- Ramp-down parameter is the speed at which the proportional command voltage follows input analog signal when it is decreased (it goes towards neutral position).

SETTINGS

REV A

Once clicked on *Parameters - Setting- Slowing*, following window will be displayed:



After opening a file or reading from display unit, all slowing parameters will be displayed

Slowing Function Parameters

Slowing Parameters

Pre alarm load limit

Boom Raising

69.0

72.0

85.8

Boom Lowering

63.0

73.5

86.0

Boom Extension

67.5

70.6

80.8

Fork Lowering

64.5

70.9

89.9

Turret Rotation

73.5

69.4

81.4

Unlock Implement

50.5

67.1

87.9

"Limit inf" and "Limit Sup" are in % of maximum load allowed

Boom angle limits

Boom Raising

79.0

69.0

87.7

Boom Lowering

75.0

-3.6

2.3

"Limit inf" and "Limit Sup" are in angular degrees
(Note that for boom lowering, speed starts to decrease at "limit sup" and reaches "slow speed" at "limit inf")

Boom length limits

Boom Extending

75.5

6.96

8.79

Boom Retracting

75.0

6.98

8.68

"Limit inf" and "Limit Sup" are in m
(Note that for boom retracting, speed starts to decrease at "limit sup" and reaches "slow speed" at "limit inf")

Boom length limits during boom extending

Boom Raising

75.0

6.90

8.80

Boom Lowering

96.5

6.97

8.74

Turret Rotation

77.0

6.84

8.82

"Limit inf" and "Limit Sup" are in m

READ DATA

WRITE DATA

File

FILE OPEN

FILE SAVE

Instruction

SLOW SPEED

LIMIT INF

LIMIT SUP


Function speed starts to decrease at "limit inf" and reaches "slow speed" at "limit sup"

"Slow speed" is in % of maximum speed

Data Changed

Data Not Changed

REV A



Intentionally blank page

Troubleshooting



Observe and Obey:

- ☑ Troubleshooting and repair procedures shall be completed by a person trained and qualified on the repair of this machine.
- ☑ Immediately tag and remove from service a damaged or malfunctioning machine.
- ☑ Repair any machine damage or malfunction before operating the machine.

Before Troubleshooting:

- ☑ Read, understand and obey the safety rules and operating instructions in the appropriate operator's manual on your machine.
- ☑ Be sure that all necessary tools and parts are available and ready for use.
- ☑ Be aware of the following hazards and follow generally accepted safe workshop practices.

⚠ DANGER

Crushing hazard. When testing or replacing any hydraulic component, always support the structure and secure it from movement


⚠ WARNING

Electrocution hazard. Contact with electrically charged circuits could result in death or serious injury. Remove all rings, watches and other jewelry.

⚠ WARNING

Bodily injury hazard. Spraying hydraulic oil can penetrate and burn skin. Loosen hydraulic connections very slowly to allow the oil pressure to dissipate gradually. Do not allow oil to squirt or spray.

General Repair Process



TROUBLESHOOTING

REV A

Overload Warning System Fault Codes

1. CAN ERROR

display unit does not receive correct CAN messages or does not receive at all CAN messages from Control unit or Platform unit in case platform is selected, telehandler can not work

2. LOAD TABLE ERROR

load table data read from EEPROM are corrupted then telehandler can not work

3. MACHINE DATA ERROR

telehandler data read from EEPROM are corrupted then telehandler can not work

4. CB0 TABLE ERROR

Cb0 table data read from EEPROM are corrupted then telehandler can not work

5. ERR LEN SENS 1 VBAT / ERR LEN SENS 2 VBAT

Length sensor 1 or 2 signal is larger than MAX1/MIN2 stored value then telehandler can not work. Sensor has not yet been calibrated or potentiometer is broken or wire is connected to +5Vdc or +12Vdc voltage

6. ERR LEN SENS 1 OPEN / ERR LEN SENS 2 OPEN

Length sensor 1 or 2 signal is less than MIN1 stored value then telehandler can not work. Sensor has not yet been calibrated or potentiometer is broken or wire is connected to ground or wire cut or sensor is not correctly connected to power supply

7. ERR LEN SENS DIFF

Length sensor 1 and 2 does not give the same length value then telehandler can not work. Sensor has not yet been calibrated or potentiometers are broken or there is some wire wrong connections

8. ERR ANG SENS 1 VBAT / ERR ANG SENS 2 VBAT

Angle sensor 1 or 2 signal is larger than maximum possible (4.5V or 920 BIT) then telehandler can not work. Sensor is broken or wire is connected to +5Vdc or +12Vdc voltage or sensor is not correctly connected to power supply

9. ERR ANG SENS 1 OPEN / ERR ANG SENS 2 OPEN

Angle sensor 1 or 2 signal is less than minimum possible (0.5V or 102 BIT) then telehandler can not work. Sensor is broken or wire is connected to ground or wire is cut or sensor is not correctly connected to power supply

10. ERR ANG SENS DIFF

Angle sensor 1 and 2 does not give the same angle value then telehandler can not work. Sensor are broken or there is some wires wrong connection

11. ERR SENS PSP VBAT/ERR SENS PSR VBAT/ERR SENS PEP VBAT/ERR SENS PER VBAT

Pressure sensor signal is larger than maximum possible (4.5V or 920 BIT) then telehandler can not work. Sensor is broken or wire is connected to +5Vdc or +12Vdc voltage or sensor is not correctly connected to power supply

12. ERR SENS PSP OPEN/ERR SENS PSR OPEN/ERR SENS PEP OPEN/ERR SENS PER OPEN

Pressure sensor signal is less than minimum possible (0.5V or 102 BIT) then telehandler can not work. Sensor is broken or wire is connected to ground or wire is cut or sensor is not correctly connected to power supply

13. ONLY IMPLEMENTS

Platform/Road/Jobsite switch is on Jobsite position but a platform is selected therefore telehandler can not work

REV A

TROUBLESHOOTING

14. ONLY PLATFORMS

Platform/Road/Jobsite switch is on Platform position but an implement is selected therefore telehandler can not work

15. ERR MODE SELECTOR

Both jobsite signal and platform signal are at +12Vdc, it is not a possible configuration then telehandler can not work. The Platform/Road/Jobsite switch is broken or some wiring connection is wrong. Red LED is switched on and buzzer is not activated.

TROUBLESHOOTING

REV A

How to Troubleshoot the Boom Movements

1. Check if the display is in alarm.
2. Check the main valve values show on the display (see “*How to Read the Overload Warning System Display*” paragraph, point 27)
3. After that, it’s possible to understand if the problem has an electric or hydraulic cause
4. If the problem is electrical (PWM doesn’t change), check the following items:
 - Check the joystick screen page (see “*How to Read the Overload Warning System Display*” paragraph, point 21). If the values shown don’t correspond to the relatives joystick movements verify the following items:
 - a. Check the Jobsite/Road/Platform Selector S21 is set on jobsite position;
 - b. If there are some anomalies, check the F13 fuse;
 - c. Check the Jobsite/Road/Platform Selector connections;
 - d. Check the joystick harness;
 - e. If all these conditions are present, replace the joystick.
 - Check the joystick screen page (see “*How to Read the Overload Warning System Display*” paragraph, point 21). If the values shown correspond to the relatives joystick movements, verify the following items:
 - a. Check the harnesses and the connections of the main unit (placed behind the seat) and of the main valve;
 - b. If the harness is damaged, replace it.
 - c. If the harness is not damaged, use a tester to make the following check:
 - If there are 12V, move the joystick and simultaneously make the same movements using the main valve manual controls: if the boom works, replace the solenoids, if not check the pressures of the main valve (see paragraph “*How to test the main valve*” into Repair Procedure Section)

REV A

TROUBLESHOOTING

How to Troubleshoot the Transmission

MOTION SENSOR		
1	RAISED STAB	1
1	RAISED STAB	1
	PARKING BRAKE	.0

1. Start from the above screen page.
2. If one or more values are **0**, the transmission doesn't work (ex: parking brake engaged, outriggers not in storage position).
3. If all the values shown in this screen page are **1**, then check the following items:
 - check there are 12V on connector X910 pin 18 (seat switch - operator not seated) and connector X208 pin 17;
 - check fuse F14-10A integrity;
 - check connector X182 (Gear Selector);
 - check connector X16 pin 2 (gear selector input), pin 12 (gear selector input), pin 11 and 9 (solenoids output);
 - check connector X170 pin 5 and pin 6;
 - engaging the relative gear, check there are 12V on connector X179 (forward gear) and connector X180 (reverse gear);
4. If at least one of the **RAISED STAB** values shown in this screen page is **0**, then check the following items:
 - check fuse F20-10A integrity;
 - check there are 12V on pin A of the connectors X140 (R-front outrigger), X143 (L-front outrigger), X147 (L-rear outrigger), X148 (R-rear outrigger). If the outrigger is in storage position and the relative LED lights on, on pin C there should be 12V;
 - If all listed above is confirmed, check pin 1 (R-rear) and pin 2 (L-rear) of the connector X129, and pin 3 (R-front) and pin 6 (L-front) of the connector X130;
5. If at least one of the **PARKING BRAKE** value shown in this screen page is **0**, then check the following items:
 - If all listed above is confirmed, check pin 48 (L-rear) and pin 49 (L-front) of the connector X935 (main unit, behind the seat), and pin 50 (R-rear) and pin 51 (R-front) of the connector X934;
 - If all listed above is confirmed, the problem comes from the Software and/or Hardware. Contact Genie Service.

TROUBLESHOOTING

REV A

How to Troubleshoot the Mechanical Gear

1. Check if the gear selector is in neutral position.
2. Check fuse F14-10A integrity.
3. Check the mechanical gear selector connector S14.
4. Check connector X16 pin 6 and pin 7 (fuses board) for verifying K5 relay.
5. Check connector X162 (speed sensor B162): if it's disconnected the main unit doesn't allowed shifting.
6. Check pin 13 of the connector X16 (speed sensor input), placed in the fuses board.
7. If all listed above is confirmed, replace the shift control unit K24, otherwise:
 - Verify there are 12V on one of the two shifting valve connectors: X131 (first gear) and X132 (second gear).
8. If all listed above is confirmed, check the hydraulic system. Keep particular attention for the overcharged pressure which must be about 25 bar.

How to Troubleshoot the Jobsite Position

1. Check if the Jobsite/Road/Platform selector is in Jobsite position.
2. Check fuse F13-10A integrity.
3. Check if there are 12V on connector X231/3 (steering selection); if not, verify connector X180.2; if not, verify connector X180.1. If not, replace the connector.
4. Verify there are 12V on pin 41 or pin 42 of the connectors X934 (main control unit), placed behind the seat.
5. If not, verify there are 12V on pin 24 or pin 25. If not, the problem comes from the Software and/or Hardware. Contact Genie Service.
6. If all listed above is confirmed, check pin 24 and pin 23 of the connector X130
7. If all listed above is confirmed, verify that, according to the selected steering mode, there are 12V on one of the two valve connectors: EV137 and EV138.
8. If all listed above is confirmed, check the hydraulic system.

REV A

TROUBLESHOOTING

How to Troubleshoot the Outriggers Movements

1. Verify the boom is under 20° and that the machine is not in alarm.
2. Verify the Jobsite/Road/Platform selector is in Jobsite position.
3. Check fuse F13-10A integrity.

STABILIZERS PUSHBUTTON			
0	EXTENSION	0	
0	RETRACT	0	
0	EXTENSION	0	
0	RETRACT	0	

4. Using the screen page above, test the four outrigger pushbuttons. When the pushbutton is active, the value shown on the display goes from 0 to 1; if, pressing the button, this doesn't happen, verify the button connector: X171, X172, X173, X174. Replace it if necessary.
5. If all listed above is confirmed, check pin 1,2,3,4,5,6,7,8 of the connector X201.
6. If all listed above is confirmed, check pin 9,10,11,12,29,38,39,40 of the connector X935.
7. If all listed above is confirmed, check pin 42 (L-front), pin 19 (R-front), pin 12 (L-rear) and pin 16 (R-rear) of the connector X935. If there aren't 12V the problem comes from the Software and/or Hardware. Contact Genie Service.
8. If all listed above is confirmed, check pin 19,20,21,22 of the connector X130.
9. If all listed above is confirmed, verify that, each time the dedicated button is pressed, there are 12V on one of the following valve connectors: EV133 (L-front), EV134 (R-front), EV135 (L-rear), EV136 (R-rear).
10. If all listed above is confirmed, check the hydraulic system.



TROUBLESHOOTING

REV A

How to Troubleshoot the Working Mode Selecting

1. Set the machine on stabilizers.
2. Using the screen page below, verify the value of each of the four SAFETY SWITCH sensors is **1**. Verify the value of the four load cells, STAB DOWN, is **1**.

STABILIZERS SENSOR		
0	STAB DOWN	0
0	SAFETY SWITCH	0
0	STAB DOWN	0
0	SAFETY SWITCH	0
STATUS		

3. If all listed above is confirmed but the system doesn't change scale then the problem comes from the Software and/or Hardware. Contact Genie Service.
4. If one or more of the value listed on item 2 is **0**, check the following items:
 - If the value of one of the four SAFETY SWITCH sensors is **0**:
 - a. Check that the specific sensor and the target are lined up;
 - b. Check the fuse F20-10A integrity;
 - c. Check there are 12V on pin 1 (power) and pin 2 (signal) of the connectors X901 (R-front), X902 (L-front), X905 (L-rear), X907 (R-rear);
 - d. If all listed above is confirmed, check pin 3,6,8,10,15,17,25,26 of the connector X130;
 - e. If all listed above is confirmed, verify there are 12V on pin 38 of the connectors X935 (L-rear) and pin 43 (R-rear), pin 48 (L-front), pin 19 (R-front) of connector X934;
 - f. If all listed above is confirmed, the problem comes from the Software and/or Hardware. Contact Genie Service.
 - If the value of one of the load cell, STAB DOWN, is **0**, verify, using the screen page STABILIZER SENSOR, the value of the cell: if this is above 940 bit the cell is broken, if not do as follow:
 - a. Check the fuse F20-10A integrity;
 - b. Check there are 12V on pin A (power) of the connectors X900 (R-front), X903 (L-front), X904 (L-rear), X906 (R-rear);
 - c. If all listed above is confirmed, verify there are 12V on pin 9 (L-rear) and pin 11 (R-rear), pin 18 (L-front), pin 16 (R-front) of connector X130;
 - d. If all listed above is confirmed, verify there are 12V on pin A6 (L-rear) and pin B5 (R-rear), pin A2 (L-front), pin B6 (R-front) of connector X933 of the display;
 - e. If all listed above is confirmed, the problem comes from the Software and/or Hardware. Contact Genie Service.

REV A

Schematics



Observe and Obey:

- ☑ Troubleshooting and repair procedures shall be completed by a person trained and qualified on the repair of this machine.
- ☑ Immediately tag and remove from service a damaged or malfunctioning machine.
- ☑ Repair any machine damage or malfunction before operating the machine.

Before Troubleshooting:

- ☑ Read, understand and obey the safety rules and operating instructions in the appropriate operator's manual on your machine.
- ☑ Be sure that all necessary tools and test equipment are available and ready for use.

About This Section

There are two groups of schematics in this section. An illustration legend precedes each group of drawings.

Electrical Schematics




Electrocution hazard. Contact with electrically charged circuits could result in death or serious injury. Remove all rings, watches and other jewelry.

Hydraulic Schematics




























































Bodily injury hazard. Spraying hydraulic oil can penetrate and burn skin. Loosen hydraulic connections very slowly to allow the oil pressure to dissipate gradually. Do not allow oil to squirt or spray.

General Repair Process




Electrical Component Legend

REV A

        	ACTUATORS Emergency controls Pushbutton control Rotary control Pedal control Proximity control Lever control Timed control Mechanical/manual control Key control	         	ACCUMULATORS Battery Thermocouple Element TERMINALS AND GROUNDS Ring Ground Terminal Ground to frame Knot Protection ground Frame ground 2 COILS Coil Mechanical coupling coil Winding A/C coil Coil with diode Winding with diode	      	DYNAMIC APPLICATIONS Motor Generator As_3p_motor ELECTRONIC PARTS Rectifier Light-emitting diode Diode Condenser
   	RESISTANCES Resistance Resistor Potentiometer Variable resistance	     	COILS Coil Mechanical coupling coil Winding A/C coil Coil with diode Winding with diode	         	PUSHBUTTONS Manual NC contact Manual NO contact NC mushroom-head pushbutton NO mushroom-head pushbutton NC level NO level Pushbutton with NC return Pushbutton with NO return NC tie-rod NO tie-rod
      	SIGNALS Intermittent lamp Whistle Lamp Buzzer Siren Bell Horn	  	CONNECTORS Connector STATIC APPLICATIONS Auto-transformer Transformer		
	FUSES AND RELAYS Horizontal fuse Relay				

REV A





























































ELECTRICAL COMPONENT LEGEND



- CONTACTS**
- Thermal
 - Normally open (NO)
 - Normally closed (NC)
 - NO limit switch
 - NC limit switch
 - Contactor
 - Magneto-thermal closure
 - Magneto-thermal opening
 - Thermal closure
 - Thermal opening
 - Exchange
 - NC proximity
 - NO proximity
 - NO mechanical
 - NC mechanical
 - Selector
 - Selector2

Hydraulic Component Legend

REV A

   	MOTORS Fixed motor with one direction of flow Fixed motor with two directions of flow Variable motor with two directions of flow Reversible fixed motor with two directions of flow	   	Mechanical control with roller Electro-magnetic control with winding (solenoid) Control with electric motor Direct pressure control	   	Combined non-return and throttle valve Switching valve Pressure relief valve with direct control Pressure relief valve with hydraulic control
   	PUMP Fixed displacement pump with one direction of flow Fixed displacement pump with two directions of flow Variable displacement pump with one direction of flow Variable displacement pump with flow regulator	 	Indirect (piloted) pressure control Control with electromagnet and piloted distributor	   	Sequence valve Adjustable throttle valve Two-way flow regulator Cut-out cock
    	CYLINDERS Single-acting cylinder Single-acting cylinder with spring return Double-acting cylinder Double-acting cylinder with bilateral rod Telescopic cylinder	      	PIPES AND CONNECTIONS Induction and return pipe Piloting pipe Blow-by pipe Flexible hose Connecting point Pipe cross without connection Breather	 	POWER SOURCES Electric motor Thermal engine
       	COMMANDS AND CONTROLS Shaft rotating in one direction Shaft rotating in two directions Hand-operated control Hand-operated control with pushbutton Hand-operated control with lever Hand-operated control with pedal Mechanical control with pushbutton Mechanical control with spring	      	DISTRIBUTION - SETTING ELEMENTS Non-return valve Calibrated non-return valve Unlockable non-return valve	        	OTHER EQUIPMENT Accumulator Water tank Compressor Filter Cooler Pressure gauge Thermometer Flowmeter Pressure switch Drain to tank indication


REV A

HYDRAULIC COMPONENT LEGEND

	DISTRIBUTION - SETTING ELEMENTS Two-position and two-way distributor, with manual lever control and spring return
	Three-way and two-position distributor, with hydraulic control
	Two-position, three-way distributor, with electro-magnetic control and spring return
	Distributor with mechanical control and span proportional to the action of the same control
	Two-position, three-way distributor, with representation of transient connection during passage phase
	Electro-hydraulic single-acting servo valve

REV A

Page 1 of 16



REV A

Page 2 of 16



REV A


Page 3 of 16



REV A


Electrical Schematic - GTH-4016SR and GTH-4018SR

Page 4 of 16

Genie
A TEREX BRAND

REV A


Page 5 of 16



REV A

Electrical Schematic - GTH-4016SR and GTH-4018SR


Page 6 of 16

Genie
A TRERCO BRAND

Electrical Schematic - GTH-4016SR and GTH-4018SR

REV A

Page 7 of 16

Genie
A TEREX BRAND

REV A


Page 8 of 16



Electrical Schematic - GTH-4016SR and GTH-4018SR

REV A

Page 9 of 16




Genie
A TEREX BRAND

REV A


Electrical Schematic - GTH-4016SR and GTH-4018SR

Page 10 of 16

Genie
A TEREX BRAND

REV A


Page 11 of 16



REV A

Electrical Schematic - GTH-4016SR and GTH-4018SR

Page 12 of 16




Genie
A TEREX BRAND

Electrical Schematic -

GTH-4016SR and GTH-4018SR

REV A

Page 13 of 16




Genie

REV A

Electrical Schematic - GTH-4016SR and GTH-4018SR


Page 14 of 16




Genie
A TEREX BRAND

REV A

Page 15 of 16






Hydraulic Schematic -

GTH-4016 SR

REV A



REV A

Hydraulic Schematic - GTH-4018 SR

