

# DC INVERTER SERIES

## Service Manual 2013

LIS-E-1312



i

Part 1 General Information	1
Part 2 Indoor Units	6
Part 3 Outdoor Units	
Part 4 Installation	
Part 5 Electrical Control System	

% The specifications, designs, and information in this book are subject to change without notice for product improvement.

## Part 1 General Information

1. Model Lists	2
2. External Appearance	3
2.1 Indoor Units	3
2.2 Outdoor Units	3
3. Nomenclature	4
4. Features	5

## 1. Model Lists

					10000	4
R410A			capacity m	nultiplied b	y 1000Btu/	'n
Туре	Function	48	51	53	55	60
Super-slim four-way cassette	Cooling and heating	•	•			
3 <sup>rd</sup> generation ceiling & floor	Cooling and heating	•		•		
Duct	Cooling and heating	•			•	
GA floor-standing	Cooling and heating	•				•
M floor-standing	Cooling and heating	•			•	

## 1.2 Outdoor Units

Universal Outdoor unit Model	Compressor type	Compressor Brand	Matched indoor units
MOU-48HDN1-Q	Rotary DC Inverter	GUANGZHOU MITSUBISHI	MTB-48HWFN1-Q MUE-48HRFN1-Q MCD-48HRFN1-Q
MOU-48HDN1-R	Rotary DC Inverter	GUANGZHOU MITSUBISHI	MTB-48HWFN1-Q MUE-48HRFN1-Q MCD-48HRFN1-Q MFGA-48ARFN1-R MFM-48ARFN1-RC2
MOU-48HFN1-RC2	Rotary DC Inverter	GUANGZHOU MITSUBISHI	MTB-48HWFN1-QC2 MUE-48HRFN1-QC2 MCD-48HRFN1-QC2
MOU-60HDN1-R	Rotary DC Inverter	GUANGZHOU MITSUBISHI	MTB-55HWFN1-Q MUE-53HRFN1-Q MCD-51HRFN1-Q MFGA-60ARFN1-R MFM-55ARFN1-RC2

## 2. External Appearance 2.1 Indoor Units

Duct	Ceiling&floor
Super-slim Four-way Cassette	GA Floor Standing
M Floor Standing	

## 2.2 Outdoor Units



## 3. Nomenclature

#### 3.1 Indoor Unit



### 4. Features

4.1 Universal outdoor unit design

Indoor unit with the same capacity can match with the same outdoor unit.

4.2 High efficiency and energy saving.

Thanks to the DC inverter technology and optimized piping system, the EER and COP of whole series can easily reach A-class.

- 4.3 Low ambient kit is standard for outdoor units
- 4.4 Network control function is standard for the indoor units
- 4.5 Standard auto restart function and follow me function
- 4.6 Cassette, ceiling & floor with standard remote controller, wire controller and CCM for optional. Med Duct with standard wired controller, remote controller and CCM for optional.
- 4.7 Standard anti-cold air function
- 4.8 Standard auto defrosting function
- 4.9 Standard self-diagnose function.
- 4.10 Standard timer function and sleep mode function controlled by controller.

## Part 2 Indoor Units

Super Slim Cassette Type	7
Duct Type	21
Ceiling & Floor Type	34
GA Floor-standing Type	44
M Floor-standing Type	55

## Super Slim Cassette Type

1.	Features8
2.	Dimensions12
3.	Service Space13
4.	Wiring Diagrams14
5.	Air Velocity and Temperature Distributions(Reference Data)15
6.	Electric Characteristics16
7.	Sound Levels17
8.	Accessories18
9.	The Specification of Power19
10	.Field Wiring20

### 1. Features

#### 1.1 Overview

- > Compact design, super slim body size, less space requiring in installation
- > Each louver can be separately controlled, more comfort air blowing is possible.
- > Auto-lifting panel design, more convenient to clean and maintain the filter. (optional)



	Old (	Cassette	New slim cassette		Volume change
	18K-24K:	840*230*840	18K-24K:	840*205*840	11%↓
Dimonsion	30K:	840*300*840	30K:	840*205*840	32%↓
Dimension	36K-48K:	840*300*840	36K-48K:	840*245*840	18%↓
	48K-60K:	840*300*840	48K-60K:	840*287*840	4%↓

### 1.2 Fresh air intake function

- > Fresh air fulfills air quality more healthy and comfortable.
- > Ventilation motor is optional to increase the effect of fresh air.



#### 1.3

Optional ionizer generator lonizer generator is optional to get refreshing air to your room.  $\geq$ 



Ionizer generator connector

Ventilation motor connector

lonizer can be switched on or off by remote controller. When pressing the Clean Air button on the remote controller, lonizer will work and the indicator light on  $\triangleright$ display board will shine.



#### 1.4

External air duct design Reserve external air duct, more flexible for the air supply.  $\geq$ 



#### 1.5

**Built-in draining pump** Due to the improvement of structure, more convenient to repair or replace the draining pump.  $\triangleright$ 



Draining Pump

Built-in draining pump to make sure condensed water drain out reliably.  $\triangleright$ 



- 1.6 Terminals for alarm lamp and long-distance on-off controller connection are standard
- Reserve terminals for the connection of alarm lamp and long-distance on-off controller, more human control.



#### 1.7 Optional touch screen wired controller

- Touch screen wired controller is optional, with error code indication function. Better man-machine conversation interface.
- Undated structure design, 4-way wire layout design, no raised part at backside, more convenient to place the wires and install the device.





## 2. Dimensions



## 3. Service Space





#### 4. Wiring Diagrams MCD-48HRFN1-QC2, MCD-48HRFN1-Q, MCD-51HRFN1-Q

## 5. Air Velocity and Temperature Distributions(Reference Data)





## 6. Electric Characteristics

Model	Indoor Unit				Power Supply
Model	Hz	Voltage	Min	Max	MFA
MCD-48HRFN1-QC2	50	220-240	198	254	10
MCD-48HRFN1-Q	50	220-240	198	254	10
MCD-51HRFN1-Q	50	220-240	198	254	10

Notes:

MFA: Max. Fuse Amps. (A)

## 7. Sound Levels



Model	Noise level dB(A)			
Model	Н	М	L	
MCD-48HRFN1-QC2	53	50	46	
MCD-48HRFN1-Q	53	50	46	
MCD-51HRFN1-Q	54	51	46	

8. Accessories			
	Name	Shape	Quantity
INSTALLATION FITTINGS	Installation paper board		1
	Bolt M5	s m	4
Tubing & Fittings	Soundproof / insulation sheath	0	2
	Out-let pipe		1
Drainpipe Fittings	Out-let pipe sheath	0	1
	Out-let pipe clasp		1
	Remote controller & Its Frame		1
Remote controller & Its Frame	Remote controller holder		1
T Tullio	Mounting screw(ST2.9×10-C-H)	E Mar	2
	Remote controller manual		1
	Alkaline dry batteries (AM4)	G	2
	Owner's manual		1
Others	Installation manual		1
	Network wires		1
Installation accessory (The product you have	Expansible hook		4
might not be provided the following accessories	Installation hook	{]_] <u>™∞∞∞∞∞∞∞∞∞∞∞∞∞∞∞</u>	4
ICHOWING ACCESSURES	Orifice		1

## 9. The Specification of Power

Model	Model(Btu/h)		60000	48000-60000	
	Phase	1-phase	1-phase	1-phase	
INDOOR UNIT	Frequency and Voltage	220-240V, 50Hz	220-240V, 50Hz	220-240V, 50Hz	
POWER	Power Wiring (mm <sup>2</sup> )	3×1.0	3×1.0	3×1.0	
	Circuit Breaker/Fuse (A)	15/10	15/10	15/10	
	Phase	1-phase	1-phase	3-phase	
OUTDOOR UNIT	Frequency and Voltage	220-240V, 50Hz	220-240V, 50Hz	380-415V, 50Hz	
POWER	Power Wiring (mm <sup>2</sup> )	3×4.0	3×4.0	5×2.5	
	Circuit Breaker/Fuse (A)	40/35	50/40	50/40	
Indoor/Outdoor Connecting Wiring (Weak Electric Signal) (mm <sup>2</sup> )		3×0.5	3×0.5	3×0.5	
Indoor/Outdoor C (Strong Electric					

## 10. Field Wiring



## **Duct Type**

1. Features	.22
2. Dimensions	.25
3. Service Space	.26
4. Wiring Diagrams	.27
5. Static Pressure	.28
6. Electric Characteristics	.29
7. Sound Levels	.30
8. Accessories	.31
9. The Specification of Power	.32
10. Field Wiring	.33

### 1. Features

### 1.1 Installation accessories: (Optional)

Front Board, Canvas Air Passage, Filter, Panel, for easy installation  $\geq$ 



Canvas Air Passage



#### 1.2 Easy Installation: Two air inlet styles (Bottom side or Rear side)

- Air inlet from rear is standard for all capacity; air inlet from bottom is optional.  $\triangleright$
- $\triangleright$ The size of air inlet frame from rear and bottom is same, it's very easy to move the cover from bottom to rear side, or from rear to the bottom, in order to matching the installation condition.





Air intake from bottom (Optional)

### 1.3 Fresh air intake function(Optional for 18~60k)

Install one duct from the reserved fresh-air intake to outdoor.  $\geq$ Continually inhale the fresh air to improve the quality of the indoor air, fulfills air quality more healthy and comfortable.



#### 1.4 Easy maintenance

- Clean the filter (Optional, standard product without filter)  $\triangleright$
- It is easy to draw out the filter from the indoor unit for cleaning, even the filter is installed in rear side or bottom side.



Replace the motor or centrifugal fan

Remove the ventilated panel firstly. Remove a half of blower housing and take out the motor with centrifugal fan. Directly remove two bolts, and then replace the motor or centrifugal fan easily.



#### 1.5 Reserved remote on-off and central control ports

Reserved remote on-off ports and central control ports, can connect the cable of an on-off controller or a central controller to realize remote on-off control function or group control function.



Remote on-off ports Central control ports

#### 1.6 Built-in drain pump (Optional):

Built-in drain pump can lift the water to 750mm upmost. It's convenient to install drainage piping under most space condition.



#### 1.7 Built-in display board

- > The standard indoor unit can be controlled by wired controller.
- There is a display board with a receiver in the E-box. Move out the display, and fix it in other place, even in the distance of 10m. The unit will realized remoter control.
- > The wired controller and the display board can display the error code or production code when the chips detect some failure.

Wired Controller (Standard)



Remote Controller (Optional)



## 2. Dimensions



Model Outline dimension(mm)		mm)	Air outlet opening size			Air return opening size			Size of outline dimension mounted plug				
	А	В	С	D	E	F	G	Н		J	К	L	М
MTB-48HWFN1-QC2	1200	300	865	800	80	968	40	204	1094	288	45	1240	500
MTB-48HWFN1-Q	1200	300	865	800	80	968	40	204	1094	288	45	1240	500
MTB-55HWFN1-Q	1200	300	865	800	80	968	40	204	1094	288	45	1240	500

## 3. Service Space

Ensure enough space required for installation and maintenance.



All the indoor units reserve the hole to joint the fresh air pipe. The hole size as following:





#### 4. Wiring Diagrams MTB-48HWFN1-QC2, MTB-48HWFN1-Q, MTB-55HWFN1-Q





## 6. Electric Characteristics

Model		Indoor	Power Supply		
Woder	Hz	Voltage	Min.	Max.	MFA
MTB-48HWFN1-QC2	50	220-240	198	254	10
MTB-48HWFN1-Q	50	220-240	198	254	10
MTB-55HWFN1-Q	50	220-240	198	254	10

Notes:

MFA: Max. Fuse Amps. (A)

## 7. Sound Levels



Model	Noise level dB(A)					
WOder	Н	М	L			
MTB-48HWFN1-QC2	45	41	37			
MTB-48HWFN1-Q	45	41	37			
MTB-55HWFN1-Q	45	41	37			

## 8. Accessories

	Name	Shape	Quantity
Tubing & Fittings	Soundproof / insulation sheath	0	2
	Binding tape		1
	Seal sponge		1
Drainpipe Fittings (for cooling & heating)	Drain joint	) IIII	1
	Seal ring	0	1
Wired controller & Its Frame	Wired controller		1
Others	Owner <sup>,</sup> s manual		1
	Installation manual		1
EMS & It's fitting	Magnetic ring (twist the electric wires L and N around it to five circles)		1

## 9. The Specification of Power

Model(	Btu/h)	48000	60000	48000-60000			
	Phase	1-phase	1-phase	1-phase			
INDOOR UNIT	Frequency and Voltage	220-240V, 50Hz	220-240V, 50Hz	220-240V, 50Hz			
POWER	Power Wiring (mm <sup>2</sup> )	3×1.0	3×1.0	3×1.0			
	Circuit Breaker/Fuse (A)	15/10	15/10	15/10			
	Phase	1-phase	1-phase	3-phase			
OUTDOOR UNIT POWER	Frequency and Voltage	220-240V, 50Hz	220-240V, 50Hz	380-415V, 50Hz			
	Power Wiring (mm <sup>2</sup> )	3×4.0	3×4.0	5×2.5			
	Circuit Breaker/Fuse (A)	40/35	50/40	30/25			
Indoor/Outdoor Co (Weak Electric		3×0.5	3×0.5	3×0.5			
Indoor/Outdoor Connecting Wiring (Strong Electric Signal) (mm <sup>2</sup> )							
#### 10. Field Wiring Air Condition Link-Circuit 202042890198 INDOOR UNIT INDOOR UNIT P Q E 🖶 Ρ Q E 🖶 L N 🕀 L N 🕀 J E ב Ľ Power supply: 1-Phase 220-240V~ Power supply: 1-Phase 220-240V~ Use 3-core cable 3x2.5mm <sup>2</sup> Use 3-core cable 3x2.5mm<sup>2</sup> for the models which with auxiliary electric heater(PTC) ; Use 3-core cable 3x1.0mm <sup>2</sup> for the models which with $\oplus$ auxiliary electric heater(PTC) ; $\oplus$ Use 3-core cable 3x1.0mm<sup>2</sup> (L1) for the others. OUTDOOR UNIT for the others. ĹΤ.) UNIT Q 3-core shielded cable Ø L. $(3 \times 0.5 \text{mm}^2)$ L. 3-core shielded cable OUTDOOR (3×0.5mm<sup>2</sup>) $\oplus$ Ν Power supply:1-Phase 220-240V~ 18K-30K: 3-core cable 3x 2.5mm<sup>2</sup> 36K-60K: 3-core cable 3x 4.0mm<sup>2</sup> Power supply:3-Phase 380-415V~ 30K-60K: 5-core cable 5x2.5mm<sup>2</sup> ΓЗ Ζ L) L2 ш L1 ш For 30K-60K Btu/h For 18K-60K Btu/h (with 3-Phase outdoor unit) (with 1-Phase outdoor unit)

## **Ceiling & Floor Type**

1.	Features	35
2.	Dimensions	36
3.	Service Space	37
4.	Wiring Diagrams	38
5.	Electric Characteristics	39
6.	Sound Levels	40
7.	Accessories	41
8.	The Specification of Power	42
9.	Field Wiring	43

#### 1. Features

1.1. New design, more modern and elegant appearance.





#### 1.2. Convenient installation

--The ceiling type can be easily installed into a corner of the ceiling even if the ceiling is very narrow --It is especially useful when installation of an air conditioner in the center of the ceiling is impossible due to a structure such as one lighting.

#### 1.3. Two direction auto swing (vertical & horizontal) and wide angle air flow,

--Air flow directional control minimizes the air resistance and produces wilder air flow to vertical direction.

--The range of horizontal air discharge is widened which secures wider air flow distribution to provide more comfortable air circulation no matter where the unit is set up



- 1.4. Three level fan speed, more humanism design, meets different air-supply requirement.
  - Foam case Plastic-spraying surface
- 1.5. New foam drain pan with plastic-spraying inner surface

- 1.6. Easy operation.
- 1.7. Remote control and optional wired control method.

## 2. Dimensions



Model	А	В	С	D	E
MUE-48HRFN1-QC2	1650	675	235	1565	220
MUE-48HRFN1-Q	1650	675	235	1565	220
MUE-53HRFN1-Q	1650	675	235	1565	220

## 3.Service Space



#### 4.Wiring Diagrams

#### MUE-48HRFN1-QC2, MUE-48HRFN1-Q, MUE-53HRFN1-Q



### **5.Electric Characteristics**

Model		Power Supply			
Model	Hz	Voltage	Min.	Max.	MFA
MUE-48HRFN1-QC2	50	220-240V	198V	242V	10
MUE-48HRFN1-Q	50	220-240V	198V	242V	10
MUE-53HRFN1-Q	50	220-240V	198V	242V	10

Note:

MFA: Max. Fuse Amps. (A)

### 6.Sound Levels



Ceiling

Floor

Model	Noise level dB(A)			
Moder	Н	М	L	
MUE-48HRFN1-QC2	57	54	52	
MUE-48HRFN1-Q	57	54	52	
MUE-53HRFN1-Q	56	53	51	

#### 7.Accessories

	1. Remote controller		1
Remote controller & Its holder	2. Remote controller holder	Ē	1
	3. Mounting screw (ST2.9×10-C-H)		2
	4. Alkaline dry batteries (AM4)	Œ	2
	5. Owner's manual		1
Others	6. Installation manual		1
	7. Remote controller manual		1

#### Model(Btu/h) 48000 60000 48000-60000 Phase 1-phase 1-phase 1-phase Frequency and 220-240V, 50Hz 220-240V, 50Hz 220-240V, 50Hz Voltage INDOOR UNIT Power Wiring (mm<sup>2</sup>) POWER 3×1.0 3×1.0 3×1.0 **Circuit Breaker/Fuse** 15/10 15/10 15/10 (A) Phase 1-phase 1-phase 3-phase Frequency and 220-240V, 50Hz 220-240V, 50Hz 380-415V, 50Hz Voltage OUTDOOR UNIT Power Wiring (mm<sup>2</sup>) POWER 3×4.0 3×4.0 5×2.5 Circuit Breaker/Fuse 40/35 50/40 50/40 (A) Indoor/Outdoor Connecting Wiring 3×0.5 3×0.5 3×0.5 (Weak Electric Signal) (mm<sup>2</sup>) Indoor/Outdoor Connecting Wiring (Strong Electric Signal) (mm<sup>2</sup>)

#### 8. The Specification of Power



	GA Floor-standing Type
1. Features	错误!未定义书签。
2. Dimensions	错误!未定义书签。
3. Service Space	错误!未定义书签。
4. Wiring Diagrams	错误!未定义书签。
5.Air Velocity and Temperatur	re istributions(Reference Data) 错误!未定义书
签。	
6. Electric Characteristics	
7. Sound Levels	错误!未定义书签。
8. Accessories	错误!未定义书签。
9. The Specification of Power	·错误!未定义书签。
10. Field Wiring	

#### 1. Features

1.1. Fashionable design, more modern and elegant appearance.

		4 4 9 9 9		
	• 1	Guidee		
_				
-			_	. (m. em. (m

#### **1.2. Air Outlet Dustproof**

When turned off, the air outlet louver of the unit can be closed manually to prevent the dust falling in.

#### 1.3. Simple and bright panel

Adopts simple and bright style panel, GA series are suitable for most different space, and show in good taste.

#### 1.4. Big LCD display, easy to read and to operate



1.5. Optional GA1 & GA2 panel, healthy filter and auto-restart function

### 2. Dimensions



Dimension	W(mm)	D(mm)	H(mm)
MFGA-48ARFN1-R	610	390	1925
MFGA-60ARFN1-R	610	390	1925

### 3. Service Space







#### 5. Air Velocity and Temperature Distributions(Reference Data) Model 48K-60K:

Airflow velocity



Temperature



#### 6. Electric Characteristics

Model	Indoor Units				Power Supply
Model	Hz	Voltage	Min.	Max.	MFA
MFGA-48ARFN1-R	50	380-420V	342V	440V	16
MFGA-60ARFN1-R	50	380-420V	342V	440V	16

Note:

MFA: Max. Fuse Amps. (A)

### 7. Sound Levels

Medal		Noise level dB(A)	
Model	Н	М	L
MFGA-48ARFN1-R	58	54	49
MFGA-60ARFN1-R	58	54	49

#### 8. Accessories

NO.	Part Name	Shape	Quantity
1	Safety Lock		1
2	Self-tapping Screw 3.9×25	+ <u>111111</u>	2
3	Flat Washers	$\bigcirc$	2
4	Bushing-Sleeve Cover	0	1
5	Sound/Heat Insulation Sleeves	0	2
6	Seal	0	1
7	Drain joint		1
8	Pipe - hole - protection Ring	(~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~	1
9	Remote Battery	G	2
10	Remote Controller		1
11	Connection Cables		1
12	Remote controller manual		1
13	User's manual		1
14	Installation manual		1

### 9. The Specification of Power

Mod	MFGA-48ARFN1-R MFGA-60ARFN1-R	
	Phase	3-phase
INDOOR UNIT POWER	Frequency and Voltage	380-420V, 50Hz
INDOOR ONIT POWER	POWER WIRING (mm <sup>2</sup> )	5×1.5
	CIRCUIT BREAKER (A)	16
	Phase	3-phase
OUTDOOR UNIT POWER	Frequency and Voltage	380-420V, 50Hz
OUTDOOR UNIT POWER	POWER WIRING (mm <sup>2</sup> )	5×2.5
	CIRCUIT BREAKER (A)	30
Indoor/Outdoor Connecting Wirin	3×0.5	
Indoor/Outdoor Connecting Wirin	g(Strong Electric Signal) (mm <sup>2</sup> )	

### **10.Field Wiring**



#### MFGA-48ARFN1-R MFGA-60ARFN1-R



# **M Floor-standing Type**

1.	Features	.56
2.	Dimensions	.57
3.	Service Space	.58
4.	Wiring Diagrams	.59
5.	Electric Characteristics	.60
6.	Sound Levels	.61
7.	Accessories	.62
8.	The Specification of Power	.63
9.	Field Wiring	.64

#### 1. Features

1.1. Fashionable design, concise and easy design better suits decoration style.



#### 1.2. Air Outlet Dustproof

When turned off, the air outlet louver of the unit can be closed manually to prevent the dust falling in.

#### 1.3. Easy Control

Big LCD display shows multi-information very clearly. Slight-touch buttons make the operation easy, clear and precise.

#### 1.4. Comfortable Air Flow

Long distance air supply. 3D air distribution(Vertical and horizontal louvers auto swing)(optional)

#### 1.5. Fresh Air (Optional)

A fresh air inlet can be customized on the return air channel. When the indoor fan runs, the fresh air will be sucked inside through the fresh air pipe, which makes the air more clear and healthy.

#### 1.6 Double Air Filters (Optional)

Various healthy filters are optional.

#### 1.7 Ionizer (Optional)

Ionizer generator brings refreshing air to your room.

## 2. Dimensions

т





Dimension	W(mm)	D(mm)	H(mm)
MFM-48ARFN1-RC2	600	455	1934
MFM-55ARFN1-RC2	600	455	1934

### 3. Service Space



#### 4. Wiring Diagrams MFM-48ARFN1-RC2 MFM-55ARFN1-RC2



### 5. Electric Characteristics

Model	Indoor Units				Power Supply
Model	Hz	Voltage	Min.	Max.	MFA
MFM-48ARFN1-RC2	50	380-420V	342V	440V	16
MFM-55ARFN1-RC2	50	380-420V	342V	440V	16

Note:

MFA: Max. Fuse Amps. (A)

### 6. Sound Levels

Medal	Noise level dB(A)				
Model	Н	М	L		
MFM-48ARFN1-RC2	52	48	43		
MFM-55ARFN1-RC2	54	49	45		

#### 7. Accessories

NO.	Part Name	Shape	Quantity
1	Safety Lock		1
2	Self-tapping Screw 3.9×25	(+) <u>//////</u>	2
3	Flat Washers	$\odot$	2
4	Bushing-Sleeve Cover	$\bigcirc$	1
5	Sound/Heat Insulation Sleeves	0	2
6	Seal	0	1
7	Drain joint		1
8	Band	<b></b>	2
9	Pipe - hole - protection Ring		1
10	Remote Battery	<u> </u>	2
11	Remote Controller		1
12	Ratproof board		1
13	Connection Cables		1
14	Putty		1
15	Remote controller manual		1
16	User's manual		1
17	Installation manual		1

### 8. The Specification of Power

Mod	MFM-48ARFN1-RC2 MFM-55ARFN1-RC2	
	Phase	3-phase
INDOOR UNIT POWER	Frequency and Voltage	380-420V, 50Hz
INDOOR UNIT POWER	POWER WIRING (mm <sup>2</sup> )	5×1.5
	CIRCUIT BREAKER (A)	16
	Phase	3-phase
OUTDOOR UNIT POWER	Frequency and Voltage	380-420V, 50Hz
OUTDOOR UNIT POWER	POWER WIRING (mm <sup>2</sup> )	5×2.5
	CIRCUIT BREAKER (A)	30
Indoor/Outdoor Connecting Wirin	3×0.5	
Indoor/Outdoor Connecting Wirin		

#### 9. Field Wiring



#### MFM-48ARFN1-RC2 MFM-55ARFN1-RC2



# Part 3 Outdoor Units

1. Dimensions	66
2. Service Space	67
3. Piping Diagrams	68
4. Wiring Diagrams	69
5. Electric Characteristics	71
6. Operation Limits	72
7. Sound Levels	73

### 1. Dimensions





Model							Unit: mm							
Model	А	В	С	D	E	F	Н							
MOU-48HDN1-Q	MOU-48HDN1-Q	000 5 404												
MOU-48HDN1-R	029		600 F	600 F	000 F	000 F	000 F	101	440	404 449 270 20	270	449 270 202	202	202 1
MOU-60HDN1-R	938	633.5	404	448	370	392	1369							
MOU-48HFN1-RC2														

### 2. Service Space




# 4. Wiring Diagrams



#### MOU-48HDN1-R MOU-60HDN1-R MOU-48HFN1-RC2



# **5. Electric Characteristics**

Model		Outdoor Unit			
Model	Hz	Voltage	Min. Max.   198 254   342 440   342 440		
MOU-48HDN1-Q	50	220-240	198	254	
MOU-48HDN1-R	50	380-415	342	440	
MOU-60HDN1-R	50	380-415	342	440	
MOU-48HFN1-RC2	50	380-415	342	440	

# 6. Operation Limits

Temperature Mode	Cooling operation	Heating operation
Room temperature	≥17°C	≤30°C
Outdoor temperature	0°C∼50°C (-15°C∼50°C: For the models with low temperature cooling system)	-15°C∼24°C

#### CAUTION:

1. If the air conditioner is used beyond the above conditions, certain safety protection features may come into operation and cause the unit to operate abnormally.

2. The room relative humidity should be less than 80%. If the air conditioner operates beyond this figure, the surface of the air conditioner may attract condensation. Please set the vertical air flow louver to its maximum angle (vertically to the floor), and set HIGH fan mode.

3. The optimum performance will be achieved during this operating temperature zone.

# 7. Sound Levels

Outdoor Unit



Note: H= 0.5 × height of outdoor unit

Model	Noise level dB(A)
	Н
MOU-48HDN1-Q	62
MOU-48HDN1-R	62.5
MOU-60HDN1-R	62
MOU-48HFN1-RC2	62

# Part 4 Installation

1.	Installation Procedure	75
2.	Location selection	.76
3.	Indoor unit installation	.77
4.	Outdoor unit installation (Side Discharge Unit)	.91
5.	Refrigerant pipe installation	.92
6.	Drainage pipe installation	.93
7.	Vacuum Drying and Leakage Checking	.97
8.	Additional refrigerant charge	.98
9.	Engineering of insulation	.98
10	.Engineering of electrical wiring	.99
11	. Test operation1	00

# 1. Installation Procedure



# 2. Location selection

## 2.1 Indoor unit location selection

- > The place shall easily support the indoor unit's weight.
- > The place can ensure the indoor unit installation and inspection.
- > The place can ensure the indoor unit horizontally installed.
- > The place shall allow easy water drainage.
- > The place shall easily connect with the outdoor unit.
- > The place where air circulation in the room should be good.
- > There should not be any heat source or steam near the unit.
- > There should not be any oil gas near the unit
- > There should not be any corrosive gas near the unit
- > There should not be any salty air neat the unit
- > There should not be strong electromagnetic wave near the unit
- > There should not be inflammable materials or gas near the unit
- > There should not be strong voltage vibration.

## 2.2 Outdoor unit location selection

- > The place shall easily support the outdoor unit's weight.
- > Locate the outdoor unit as close to indoor unit as possible
- > The piping length and height drop can not exceed the allowable value.
- > The place where the noise, vibration and outlet air do not disturb the neighbors.
- > There is enough room for installation and maintenance.
- > The air outlet and the air inlet are not impeded, and not face the strong wind.
- > It is easy to install the connecting pipes and cables.
- > There is no danger of fire due to leakage of inflammable gas.
- > It should be a dry and well ventilation place
- > The support should be flat and horizontal
- Do not install the outdoor unit in a dirty or severely polluted place, so as to avoid blockage of the heat exchanger in the outdoor unit.
- If is built over the unit to prevent direct sunlight, rain exposure, direct strong wend, snow and other scraps accumulation, make sure that heat radiation from the condenser is not restricted.



# 3. Indoor unit installation

# 3.1 A5 duct indoor unit installation

## 3.1.1 Service space for indoor unit



3.1.2 Bolt pitch



Consoity//KPtu)	Size of outline dimension mounted plug		
Capacity(KBtu)	L	М	
48/60	1240	500	

#### 3.1.3 Install the pendant bolt

Select the position of installation hooks according to the hook holes positions showed in upper picture. Drill four holes of Ø12mm, 45~50mm deep at the selected positions on the ceiling. Then embed the expansible hooks (fittings).





#### 3.1.4 Install the main body

Make the 4 suspender through the 4 hanger of the main body to suspend it. Adjust the hexangular nuts on the four installation hooks evenly, to ensure the balance of the body. Use a leveling instrument to make sure the levelness of the main body is within  $\pm 1^{\circ}$ .



## 3.1.5 Install the air filter

Insert the air filter through the filter slot and fix it with 2 screws.



#### 3.1.6 Install the air duct

Please design the air duct as below recommended picture



#### 3.1.7 Change the air inlet direction

① Take off ventilation panel and flange, cut off the staples at side rail.



② Stick the attached seal sponge as per the indicating place in the following fig, and then change the mounting positions of air return panel and air return flange .



③ When install the filter mesh, please plug it into flange inclined from air return opening, and then push up.



④ The installation has finish, upon filter mesh which fixing blocks have been insert to the flange positional holes.



# 3.2 Ceiling & floor indoor unit installation

## 3.2.1 Service space for indoor unit



# 3.2.2 Bolt pitch

 $(\ensuremath{\underline{1}})$  Ceiling installation



2 Wall-mounted installation



#### 3.2.3 Install the pendant bolt

 $(\ensuremath{\underline{1}})$  Ceiling installation

Select the position of installation hooks according to the hook holes positions showed in upper picture. Drill four holes of Ø12mm, 45~50mm deep at the selected positions on the ceiling. Then embed the expansible hooks (fittings).





2 Wall-mounted installation

Install the tapping screws onto the wall.(Refer to picture below)



#### 3.2.4 Install the main body

① Ceiling installation (The only installation method for the unit with drain pump) Remove the side board and the grille.



Locate the hanging arm on the hanging screw bolt. Prepare the mounting bolts on the unit.



Put the side panels and grilles back.





Downward declicity lower between(1-2)/100

2 Wall-mounted installation

Hang the indoor unit by insert the tapping screws into the hanging arms on the main unit. (The bottom of body can touch with floor or suspended, but the body must install vertically.)





# 3.3 Super slim cassette indoor unit installation



Model	Α	Н	Remark	
48-60	287	>317	R410A and R22	Cooling / Cooling & Heating

## 3.3.2 Bolt pitch



#### 3.3.3 Install the pendant bolt

Select the position of installation hooks according to the hook holes positions showed in upper picture. Drill four holes of Ø12mm, 45~50mm deep at the selected positions on the ceiling. Then embed the expansible hooks (fittings).





#### 3.3.4 Install the main body

Make the 4 suspender through the 4 hanger of the main body to suspend it. Adjust the hexangular nuts on the four installation hooks evenly, to ensure the balance of the body. Use a leveling instrument to make sure the levelness of the main body is within  $\pm 1^{\circ}$ .



Adjust the position to ensure the gaps between the body and the four sides of ceiling are even. The body's lower part should sink into the ceiling for 10~12 mm. In general, L is half of the screw length of the installation hook.



Locate the air conditioner firmly by wrenching the nuts after having adjusted the body's position well.





**3.3.5 Install the panel** Remove the grille



Remove the 4 corner covers.



Hang the panel to the hooks on the mainbody. If the panel is with auto-lift grille, please watch the ropes lifing the grille, DO NOT make the ropes enwinded or blocked.



Tighten the screws under the panel hooks till the panel closely stick on the ceiling to avoid condensate water.



Hang the air-in grill to the panel, then connect the lead terminator of the swing motor and that of the control box with corresponding terminators on the body respectively.

Install the 4 corner covers back.



Note: The panel shall be installed after the wiring connected.

## 3.4 GA floor standing indoor unit installation

#### 3.4.1 Service space for indoor unit

- a. A place which provides the spaces around the indoor unit as required above in the diagram.
- b. A place where is no obstacle near the inlet and outlet area.
- c. A place which can bear the weight of the indoor unit.
- d. A place which allows the air filter to be removed downward.
- e. A place where the reception range is not exposed to direct sunlight.
- f. In the center of the room where possible.
- 3.4.1.1 Please stand the unit in hard and flat ground;

Please reserve space for installation and maintenance.





Elevation difference: no more than30m (if the elevation difference between indoor and outdoor unit is more than 30 meters, it is recommended that the indoor unit be located higher than the outdoor unit.)

Pipe length: no more than 65m.

Bends: no more than 3 places.

#### 3.4.2 Installing

3.4.2.1. Anti-falling;

To prevent the indoor unit from falling, you must:

a. Pay full attention to the unit because its long outer shape makes it easy to fall;

b. Firmly fix the unit to the wall or in the ground to avoid accidental falling.



3.4.2.2. Dismounting the lower front panel

Please take off the lower front panel before connecting the pipes/wires.

Pull down the two knobs on the grille, take off the two screws, then the air-inlet grille goes free.



3.4.2.3. Take the Pipe Clip off before connecting the pipes and wiring; fit it when these finished. Use accessories to connect the pipes/wires on both sides and back side.



#### 3.5 M floor standing indoor unit installation

#### 3.5.1 Service space for indoor unit

- a. A place which provides the spaces around the indoor unit as required above in the diagram.
- b. A place where is no obstacle near the inlet and outlet area.
- c. A place which can bear the weight of the indoor unit.
- d. A place which allows the air filter to be removed downward.
- e. A place where the reception range is not exposed to direct sunlight.
- f. In the center of the room where possible.
- 3.5.1.1 Please stand the unit in hard and flat ground;

Please reserve space for installation and maintenance.



3.5.1.2 Please check the elevation difference between the indoor unit and the outdoor unit, the length of the refrigerant pipe, and the curved places (bend) of the pipe are no more than the following numbers:

Elevation difference: no more than30m (if the elevation difference between indoor and outdoor unit is more than 30

meters, it is recommended that the indoor unit be located higher than the outdoor unit.)

Pipe length: no more than 65m.

Bends: no more than 5 places.

#### 3.5.2 Installing

3.5.2.1. Anti-falling;

To prevent the indoor unit from falling, you must:

a. Pay full attention to the unit because its long outer shape makes it easy to fall;

b. Firmly fix the unit to the wall or in the ground to avoid accidental falling.



3.5.2.2. Dismounting the air-inlet grid

Please take off the air-inlet grid before connecting the pipes/wires.

The grid is hitched by a loop inside. To dismount the air-inlet grid, hold both sides of the grid and pull it up, let it slant downwards until the loop become straight. Then removing the screws fastened the loop with the grid, and the grid goes free.



3.5.2.3. Take the Pipe Clip off before connecting the pipes and wiring; fit it when these finished. Use accessories to connect the pipes/wires on both sides and back side.



Pipe/wire-hole position on back side



Pipe/wire-hole positions on both sides

Pipe/wire-hole position on the bottom



# 4. Outdoor unit installation (Side Discharge Unit)

# 4.1 Service space for outdoor unit



## 4.2 Bolt pitch



Model	В	С	D
48K	633.5	404	448
60K	633.5	404	448

## 4.3 Install the Unit

Since the gravity center of the unit is not at its physical center, so please be careful when lifting it with a sling. Never hold the inlet of the outdoor unit to prevent it from deforming.

Do not touch the fan with hands or other objects.

Do not lean it more than 45, and do not lay it sidelong.

Make concrete foundation according to the specifications of the outdoor units.

Fasten the feet of this unit with bolts firmly to prevent it from collapsing in case of earthquake or strong wind.



# 5. Refrigerant pipe installation

# 5.1 Maximum pipe length and height drop

Considering the allowable pipe length and height drop to decide the installation position. Make sure the distance and height drop between indoor and outdoor unit not exceeded the date in the following table.

Model	Max. Length	Max. Elevation
48,000Btu/h ~60,000Btu/h	65m	30m

## 5.2 The procedure of connecting pipes

- 5.2.1 Choose the pipe size according to the specification table.
- 5.2.2 Confirm the cross way of the pipes.
- 5.2.3 Measure the necessary pipe length.
- 5.2.4 Cut the selected pipe with pipe cutter
- > Make the section flat and smooth.



#### 5.2.5 Insulate the copper pipe

> Before test operation, the joint parts should not be heat insulated.

#### 5.2.6 Flare the pipe

- > Insert a flare nut into the pipe before flaring the pipe
- > According to the following table to flare the pipe

Pipe diameter	Flare dimen	sion A (mm)	
Pipe diameter	Min	Max	Max Flare shape
1/4" (6.35)	8.3	8.7	90°±4
3/8" (9.52)	12.0	12.4	
1/2" (12.7)	15.4	15.8	R0.4~0.8
5/8" (15.9)	18.6	19.1	
3/4" (19)	22.9	23.3	

- After flared the pipe, the opening part must be seal by end cover or adhesive tape to avoid duct or exogenous impurity come into the pipe.
- 5.2.7 Drill holes if the pipes need to pass the wall.
- 5.2.8 According to the field condition to bend the pipes so that it can pass the wall smoothly.
- 5.2.9 Bind and wrap the wire together with the insulated pipe if necessary.
- 5.2.10 Set the wall conduit
- 5.2.11 Set the supporter for the pipe.
- 5.2.12 Locate the pipe and fix it by supporter

- > For horizontal refrigerant pipe, the distance between supporters should not be exceed 1m.
- For vertical refrigerant pipe, the distance between supporters should not be exceed 1.5m.
- 5.2.13 Connect the pipe to indoor unit and outdoor unit by using two spanners.
- Be sure to use two spanners and proper torque to fasten the nut, too large torque will damage the bellmouthing, and too small torque may cause leakage. Refer the following table for different pipe connection.

Dine Diameter	Г	orque	Sketch map
Pipe Diameter	(kgf.cm)	(N.cm)	
1/4" (6.35)	144~176	1420~1720	T STE
3/8" (9.52)	333~407	3270~3990	
1/2" (12.7)	504~616	4950~6030	
5/8" (15.9)	630~770	6180~7540	
3/4" (19)	990~1210	9270~11860	

# 6. Drainage pipe installation

Install the drainage pipe as shown below and take measures against condensation. Improperly installation could lead to leakage and eventually wet furniture and belongings.

## 6.1 Installation principle

- > Ensure at least 1/100 slope of the drainage pipe
- > Adopt suitable pipe diameter
- > Adopt nearby condensate water discharge

## 6.2 Key points of drainage water pipe installation

#### 6.2.1 Considering the pipeline route and elevation

Before installing condensate water pipeline, determine its route and elevation to avoid intersection with other pipelines and ensure slope is straight.

#### 6.2.2 Drainage pipe selection

- > The drainage pipe diameter shall not small than the drain hose of indoor unit
- According to the water flowrate and drainage pipe slope to choose the suitable pipe, the water flowrate is decided by the capacity of indoor unit.

#### Relationship between water flowrate and capacity of indoor unit

Capacity (x1000Btu)	Water flowrate (I/h)
12	2.4
18	4
24	6
30	7
36	8
42	10
48	12
60	14

According to the above table to calculate the total water flowrate for the confluence pipe selection.

For horizontal drainage pipe (The following table is for reference)

Ī	PVC pipe Refe	Reference value of inner	Allowable maximum water flowrate (I/h)		Remark
	FVC pipe	diameter of pipe (mm)	Slope 1/50	Slope 1/100	Reliaik
	PVC25	20	39	27	For branch pipe
Ī	PVC32	25	70	50	For branch pipe

PVC40	31	125	88	Could be used for confluence pipe
PVC50	40	247	175	
PVC63	51	473	334	

Attention: Adopt PVC40 or bigger pipe to be the main pipe. **For Vertical drainage pipe** (The following table is for reference)

		5		
PVC pipe	Reference value of inner diameter of pipe (mm)	Allowable maximum water flowrate (I/h)	Remark	
PVC25	20	220	For branch nino	
PVC32	25	410	For branch pipe	
PVC40	31	730		
PVC50	40	1440		
PVC63	51	2760	Could be used for confluence pipe	
PVC75	67	5710		
PVC90	77	8280		

Attention: Adopt PVC40 or bigger pipe to be the main pipe.

#### 6.2.3 Individual design of drainage pipe system

- The drainage pipe of air conditioner shall be installed separately with other sewage pipe, rainwater pipe and drainage pipe in building.
- > The drainage pipe of the indoor unit with water pump should be apart from the one without water pump.

#### 6.2.4 Supporter gap of drainage pipe

- In general, the supporter gap of the drainage pipe horizontal pipe and vertical pipe is respectively 1m~1.5m and 1.5m~2.0m.
- > Each vertical pipe shall be equipped with not less than two hangers.
- > Overlarge hanger gap for horizontal pipe shall create bending, thus leading to air block.



#### 6.2.5 The horizontal pipe layout should avoid converse flow or bad flow





- The correct installation will not cause converse water flow and the slope of the branch pipes can be adjusted freely
- > The false installation will cause converse water flow and the slope of the branch pipe can not be adjusted.

#### 6.2.6 Water storage pipe setting

If the indoor unit has high extra static pressure and without water pump to elevate the condensate water, such as high extra static pressure duct unit, the water storage pipe should be set to avoid converse flow or blow water phenomena.



#### 6.2.7 Lifting pipe setting of indoor unit with water pump

The length of lifting pipe should not exceed the pump head of indoor unit water pump. Pump head of big four way cassette: 750mm

Pump head of compact four way cassette: 500mm

- The drainage pipe should be set down inclined after the lifting pipe immediately to avoid wrong operation of water level switch.
- > Refer the following picture for installation reference.



#### 6.2.8 Blowhole setting

- For the concentrated drainage pipe system, there should design a blowhole at the highest point of main pipe to ensure the condensate water discharge smoothly.
- > The air outlet shall face down to prevent dirt entering pipe.

- > Each indoor unit of the system should be installed it.
- > The installation should be considering the convenience for future cleaning.



6.2.9 The end of drainage pipe shall not contact with ground directly.

#### 6.3 Drainage test

#### 6.3.1 Water leakage test

After finishing the construction of drainage pipe system, fill the pipe with water and keep it for 24 hours to check whether there is leakage at joint section.

#### 6.3.2 Water discharge test

- Natural drainage mode(the indoor unit with outdoor drainage pump) Infuse above 600ml water through water test hole slowly into the water collector, observe whether the water can discharge through the transparent hard pipe at drainage outlet.
- 2. Pump drainage mode
- 2.1 Disconnect the plug of water level switch, remove the cover of water test hole and slowly infuse about 2000ml water through the water test hole, be sure that the water will not touch the motor of drainage pump.



- 2.2 Power on and let the air conditioner operate for cooling. Check operation status of drainage pump, and then connect the plug of water level switch, check the operation sound of water pump and observe whether the water can discharge through the transparent hard pipe at drainage outlet. (In light of the length of drainage pipe, water shall be discharged about 1 minute delayed)
- 2.3 Stop the operation of air conditioner, power off the power supply and put the cover of water test hole back to the original place.
- a. After stopped the air conditioner 3 minutes, check whether there is anything abnormal. If drainage pipes have not been distributed properly, over back-flow water shall cause the flashing of alarm indicator at remote-controlled receiving board and even water shall run over the water collector.
- b. Continuously infusing water until water level alarmed, check whether the drainage pump could discharge water at once. If water level does not decline under warning water level 3 minutes later, it

shall cause shutdown of unit. When this situation happens, the normal startup only can be recovered by turning down power supply and eliminating accumulated water.

**Note:** Drain plug at the main water-containing plate is used for eliminating accumulated water in water-containing plate when maintaining air conditioner fault. During normal operation, the plug shall be filled in to prevent leakage.

### 6.4 Insulation work of drainage pipe

Refer the introduction to the insulation engineering parts.

# 7. Vacuum Drying and Leakage Checking

## 7.1 Purpose of vacuum drying

- Eliminating moisture in system to prevent the phenomena of ice-blockage and copper oxidation. Ice-blockage shall cause abnormal operation of system, while copper oxide shall damage compressor.
- Eliminating the non-condensable gas (air) in system to prevent the components oxidizing, pressure fluctuation and bad heat exchange during the operation of system.

#### 7.2 Selection of vacuum pump

- > The ultimate vacuum degree of vacuum pump shall be -756mmHg or above.
- > Precision of vacuum pump shall reach 0.02mmHg or above.

## 7.3 Operation procedure for vacuum drying

Due to different construction environment, two kinds of vacuum drying ways could be chosen, namely ordinary vacuum drying and special vacuum drying.

#### 7.3.1 Ordinary vacuum drying

- 1. When conduct first vacuum drying, connect pressure gauge to the infusing mouth of gas pipe and liquid pipe, and keep vacuum pump running for 1hour (vacuum degree of vacuum pump shall be reached -755mmHg).
- 2 If the vacuum degree of vacuum pump could not reach -755mmHg after 1 hour of drying, it indicates that there is moisture or leakage in pipeline system and need to go on with drying for half an hour.
- 3 If the vacuum degree of vacuum pump still could not reach -755mmHg after 1.5 hours of drying, check whether there is leakage source.
- 4 Leakage test: After the vacuum degree reaches -755mmHg, stop vacuum drying and keep the pressure for 1 hour. If the indicator of vacuum gauge does not go up, it is qualified. If going up, it indicates that there is moisture or leak source.

#### 7.3.2 Special vacuum drying

The special vacuum drying method shall be adopted when:

- 1. Finding moisture during flushing refrigerant pipe.
- 2. Conducting construction on rainy day, because rain water might penetrated into pipeline.
- 3. Construction period is long, and rain water might penetrated into pipeline.
- 4. Rain water might penetrate into pipeline during construction.

Procedures of special vacuum drying are as follows:

- 1. Vacuum drying for 1 hour.
- 2. Vacuum damage, filling nitrogen to reach 0.5Kgf/cm2.
  - Because nitrogen is dry gas, vacuum damage could achieve the effect of vacuum drying, but this method could not achieve drying thoroughly when there is too much moisture. Therefore, special attention shall be drawn to prevent the entering of water and the formation of condensate water.
- 3. Vacuum drying again for half an hour.

If the pressure reached -755mmHg, start to pressure leakage test. If it can not reached the value, repeat vacuum damage and vacuum drying again for 1 hour.

4 Leakage test: After the vacuum degree reaches -755mmHg, stop vacuum drying and keep the pressure for 1 hour. If the indicator of vacuum gauge does not go up, it is qualified. If going up, it indicates that there is moisture or leak source.

# 8. Additional refrigerant charge

- After the vacuum drying process is carried out, the additional refrigerant charge process need to be performed.
- The outdoor unit is factory charged with refrigerant. The additional refrigerant charge volume is decided by the diameter and length of the liquid pipe between indoor and outdoor unit. Refer the following formula to calculate the charge volume.

Diameter of liquid pipe (mm)	Ф6.35	Ф9.52
Formula	V=15g/m×(L-5)	V=30g/m×(L-5)

V: Additional refrigerant charge volume (g). L : The length of the liquid pipe (m).

#### Note:

- > Refrigerant may only be charged after performed the vacuum drying process.
- > Always use gloves and glasses to protect your hands and eyes during the charge work.
- Use electronic scale or fluid infusion apparatus to weight refrigerant to be recharged. Be sure to avoid extra refrigerant charged, it may cause liquid hammer of the compressor or protections.
- Use supplementing flexible pipe to connect refrigerant cylinder, pressure gauge and outdoor unit. And The refrigerant should be charged in liquid state. Before recharging, The air in the flexible pipe and manifold gauge should be exhausted.
- After finished refrigerant recharge process, check whether there is refrigerant leakage at the connection joint part.(Using gas leakage detector or soap water to detect).

# 9. Engineering of insulation

## 9.1 Insulation of refrigerant pipe

#### 9.1.1 Operational procedure of refrigerant pipe insulation

Cut the suitable pipe  $\rightarrow$  insulation (except joint section)  $\rightarrow$  flare the pipe  $\rightarrow$  piping layout and connection  $\rightarrow$  vacuum drying  $\rightarrow$  insulate the joint parts

#### 9.1.2 Purpose of refrigerant pipe insulation

- During operation, temperature of gas pipe and liquid pipe shall be over-heating or over-cooling extremely. Therefore, it is necessary to carry out insulation; otherwise it shall debase the performance of unit and burn compressor.
- Gas pipe temperature is very low during cooling. If insulation is not enough, it shall form dew and cause leakage.
- ➤ Temperature of gas pipe is very high (generally 50-100°C) during heating. Insulation work must be carried out to prevent hurt by carelessness touching.

#### 9.1.3 Insulation material selection for refrigerant pipe

- $\blacktriangleright$  The burning performance should over 120 °C
- > According to the local law to choose insulation materials
- The thickness of insulation layer shall be above 10mm. If in hot or wet environment place, the layer of insulation should be thicker accordingly.

#### 9.1.4 Installation highlights of insulation construction

Gas pipe and liquid pipe shall be insulated separately, if the gas pipe and liquid pipe were insulated together; it will decrease the performance of air conditioner.



- > The insulation material at the joint pipe shall be 5~10cm longer than the gap of the insulation material.
- > The insulation material at the joint pipe shall be inserted into the gap of the insulation material.
- > The insulation material at the joint pipe shall be banded to the gap pipe and liquid pipe tightly.
- > The linking part should be use glue to paste together
- Be sure not bind the insulation material over-tight, it may extrude out the air in the material to cause bad insulation and cause easy aging of the material.

## 9.2 Insulation of drainage pipe

#### 9.2.1 Operational procedure of refrigerant pipe insulation

Select the suitable pipe  $\rightarrow$  insulation (except joint section)  $\rightarrow$  piping layout and connection $\rightarrow$  drainage test $\rightarrow$  insulate the joint parts

#### 9.2.2 Purpose of drainage pipe insulation

The temperature of condensate drainage water is very low. If insulation is not enough, it shall form dew and cause leakage to damage the house decoration.

#### 9.2.3 Insulation material selection for drainage pipe

- The insulation material should be flame retardant material, the flame retardancy of the material should be selected according to the local law.
- > Thickness of insulation layer is usually above 10mm.
- Use specific glue to paste the seam of insulation material, and then bind with adhesive tape. The width of tape shall not be less than 5cm. Make sure it is firm and avoid dew.

#### 9.2.4 Installation and highlights of insulation construction

- The single pipe should be insulated before connecting to another pipe, the joint part should be insulated after the drainage test.
- > There should be no insulation gap between the insulation material.

# 10. Engineering of electrical wiring

#### 10.1 Highlights of electrical wiring installation

- > All field wiring construction should be finished by qualified electrician.
- > Air conditioning equipment should be grounded according to the local electrical regulations.
- > Current leakage protection switch should be installed.
- > Do not connect the power wire to the terminal of signal wire.
- When power wire is parallel with signal wire, put wires to their own wire tube and remain at least 300mm gap.
- According to table in indoor part named "the specification of the power" to choose the wiring, make sure the selected wiring not small than the date showing in the table.

- > Select different colors for different wire according to relevant regulations.
- > Do not use metal wire tube at the place with acid or alkali corrosion, adopt plastic wire tube to replace it.
- > There must be not wire connect joint in the wire tube If joint is a must, set a connection box at the place.
- > The wiring with different voltage should not be in one wire tube.
- Ensure that the color of the wires of outdoor and the terminal No. are same as those of indoor unit respectively.

# **11. Test operation**

11.1 The test operation must be carried out after the entire installation has been completed.

## **11.2** Please confirm the following points before the test operation.

- > The indoor unit and outdoor unit are installed properly.
- > Tubing and wiring are correctly completed.
- > The refrigerant pipe system is leakage-checked.
- > The drainage is unimpeded.
- > The ground wiring is connected correctly.
- > The length of the tubing and the added stow capacity of the refrigerant have been recorded.
- > The power voltage fits the rated voltage of the air conditioner.
- > There is no obstacle at the outlet and inlet of the outdoor and indoor units.
- > The gas-side and liquid-side stop values are both opened.
- > The air conditioner is pre-heated by turning on the power.

#### 11.3 Test operation

Set the air conditioner under the mode of "COOLING" by remote controller, and check the following points. **Indoor unit** 

- > Whether the switch on the remote controller works well.
- > Whether the buttons on the remote controller works well.
- > Whether the air flow louver moves normally.
- > Whether the room temperature is adjusted well.
- > Whether the indicator lights normally.
- > Whether the temporary buttons works well.
- > Whether the drainage is normal.
- > Whether there is vibration or abnormal noise during operation.

#### Outdoor unit

- > Whether there is vibration or abnormal noise during operation.
- Whether the generated wind, noise, or condensed of by the air conditioner have influenced your neighborhood.
- > Whether any of the refrigerant is leaked.

# Part 5 Electrical Control System

1.	Electrical Control Function	102
2.	Troubleshooting	111
3.	Controller	140

# **1. Electrical Control Function**

## **1.1 Definition**

- T1: Indoor room temperature
- T2: Coil temperature of indoor heat exchanger middle.
- T2B: Coil temperature of indoor heat exchanger outlet.
- T3: Coil temperature of condenser
- T4: Outdoor ambient temperature
- T5: Compressor discharge temperature

#### **1.2 Main Protection**

#### 1.2.1 Time delay at restart for compressor.

#### 1.2.2 Temperature protection of compressor top

The unit will stop working when the compressor top temp. protector cut off, and will restart after the compressor top temp. protector restart.

#### 1.2.3 Temperature protection of compressor discharge

When the compressor discharge temp. is getting higher, the running frequency will be limited as below rules:

----If 102°C<T5<115°C, decrease the frequency to the lower level every 2 minutes till to F1.

---If T5>115°C for 10 seconds, the compressor will stop and restart till T5<90°C.

#### 1.2.4 Sensor protection at open circuit and breaking disconnection.

#### 1.2.5 Indoor fan delayed open function

For floor-standing:

When the unit starts up, the louver will be active immediately and the indoor fan will open 5s later.

If the unit runs in heating mode, the indoor fan will be also controlled by anti-cold wind function.

For other models:

When the unit starts up, the louver will be active immediately and the indoor fan will open 10s later.

If the unit runs in heating mode, the indoor fan will be also controlled by anti-cold wind function.

#### 1.2.6 Fan speed is out of control

For A5 duct &Ceiling&floor:When indoor fan speed keeps too low (lower than 300RPM) for 50s, the indoor fan will shut off and restart 30s later, if protection happened 3 times when fan motor restart continuously, the unit will stop and the LED will display the failure.

For super slim cassette: When indoor fan speed keeps too low (lower than 200RPM) for 50s, the unit will stop and the LED will display the failure.

For GA floor-standing: When indoor fan speed keeps too low (lower than 300RPM) for 50s, the unit will stop and the LED will display the failure.

For M floor-standing: When indoor fan speed keeps too low (lower than 300RPM) for 10s, the unit will stop and the LED will display the failure.

#### **1.3 Operation Modes and Functions** 1.3.1 Fan mode

- (1) Outdoor fan and compressor stop.
- (2) Temperature setting function is disabled, and no setting temperature is displayed.
- (3) Indoor fan can be set to high/med/low/auto.
- (4) The louver operates same as in cooling mode.
- (5) Auto fan:



#### 1.3.2 Cooling Mode

#### 1.3.2.1 Outdoor PMW open angle control

The unit is working in cooling mode with the EXV open 300P for 3 minutes, then adjusting PMW open angle according to the temperature of compressor discharge every 2 minutes. **1.3.2.2 Outdoor fan running rules** 

#### MOU-48HFN1-RC2



# For the others models:



Outdoor fan in low temperature cooling mode acts as follow:



## 1.3.2.3 Indoor fan running rules

In cooling mode, indoor fan runs all the time and the speed can be selected as high, medium, low and auto. The auto fan:



# 1.3.2.4 Evaporator low temperature T2 protection.

When T2<2°C and lasts for 3 minutes, the indoor has no capacity demand and resume till T2 $\ge$ 7°C.

# 1.3.2.5 Condenser high temperature T3 protection

When T3 $\geq$ 65°C for 3 seconds, the compressor will shut off. When T3 $\leq$ 52,the compressor will restart.

# 1.3.3 Heating Mode
#### 1.3.2.1 Outdoor PMW open angle control

The unit is working in heating mode with the EXV open 300P for 3 minutes, then adjusting PMW open angle according to the temperature of compressor discharge every 2 minutes.

## 1.3.3.2 Outdoor fan running rules:

#### For MOU-48HFN1-RC2:



For the others models:



#### 1.3.3.3 Indoor fan running rules:

When the compressor is on, the indoor fan can be set to high/med/low/auto. And the anti-cold wind function has the priority.

#### Auto fan action:



#### 1.3.3.4 Defrosting mode:

#### Condition of defrosting:

T4	Time1
3℃	Time2

Time conditions:

time1

Time conditions(Meet the following conditions)

1. Running in heating mode

**2. T4≥3**℃

3. Compressor is on

4. T3≤TempEnterDefrost\_ADD °C

Cleared conditions (Meet any one of the following conditions)

- 1. Compressor is off.
- 2. T3>TempEnterDefrost\_ADD °C

#### Time2

Time conditions (Meet the following conditions)

- 1. Running in heating mode
- **2. T4<3**℃
- 3. Compressor is on
- 4. T3≤TempEnterDefrost\_ADD °C

Cleared conditions (Meet any one of the following conditions)

- 1. Compressor is off and T3>TempEnterDefrost\_ADD +2°C last for 20 minutes
- 2. Running in cooling mode.
- 3. Compressor is off for 1 hour.

#### Condition of entry defrosting:

time1+ time2≥40 minutes, When defrosting is end,time1 and time2 are cleared. **Defrosting action**:



#### Condition of ending defrosting:

If any one of following items is satisfied, defrosting will stop and the machine will turn to normal heating mode.

- ① The defrosting time achieves 10min;
- ② T3 ≥15℃;
- ③ T3  $\geq$ 7°C for 60seconds.

#### 1.3.3.5 High evaporator coil temp.T2 protection:

T2>60°C, the compressor will stop and restart when T2<54°C.

#### 1.3.4 Auto-mode

This mode can be chosen with remote controller and the setting temperature can be changed between  $17\sim30^{\circ}$ C.

In auto mode, the machine will choose cooling, heating or fan-only mode according to  $\Delta T$  ( $\Delta T$  =T1-Ts).

ΔT=T1-Ts	Running mode
ΔT≥2°C	Cooling
-1≤ΔT<2°C	Fan-only
ΔT<-1°C	Heating

Indoor fan will run at auto fan of the relevant mode.

The louver operates same as in relevant mode.

If the machine switches mode between heating and cooling, the compressor will keep stopping for 15 minutes and then choose mode according to T1-Ts.

If the setting temperature is modified, the machine will choose running function again.

#### 1.3.5 Drying mode

Drying mode works the same as cooling mode in low speed.

All protections are active and the same as that in cooling mode.

#### 1.3.6 Timer function

1.3.6.1 Timing range is 24 hours.

1.3.6.2 Timer on. The machine will turn on automatically when reaching the setting time.

1.3.6.3 Timer off. The machine will turn off automatically when reaching the setting time.

1.3.6.4 Timer on/off. The machine will turn on automatically when reaching the setting "on" time, and then turn off automatically when reaching the setting "off" time.

1.3.6.5 Timer off/on. The machine will turn off automatically when reaching the setting "off" time, and then turn on automatically when reaching the setting "on" time.

1.3.6.6 The timer function will not change the AC current operation mode. Suppose AC is off now, it will not start up firstly after setting the "timer off" function. And when reaching the setting time, the timer LED will be off and the AC running mode has not been changed.

1.3.6.7 The setting time is relative time.

#### **1.3.7 Economy function**

1.3.7.1 The sleep function is available in cooling, heating or auto mode.

1.3.7.2. Operation process in sleep mode is as follow:

When cooling, the setting temperature rises 1°C (be lower than 30°C) every one hour, 2 hours later the setting temperature stops rising and the indoor fan is fixed at low speed. (For floor-standing, the indoor fan is fixed at auto speed)

When heating, the setting temperature decreases 1°C (be higher than 17°C) every one hour, 2 hours later the setting temperature stops rising and indoor fan is fixed at low speed. (Anti-cold wind function has the priority).

1.3.7.3 Operation time in sleep mode is 7 hours. After 7 hours the AC quits this mode but doesn't turns off 1.3.7.4 Timer setting is available

#### 1.3.8 Auto-Restart function

The indoor unit is equipped with auto-restart function, which is carried out through an auto-restart module. In case of a sudden power failure, the module memorizes the setting conditions before the power failure. The unit will resume the previous operation setting automatically after 3 minutes when power returns.

#### 1.3.9 Drain pump control (For Cassette)

Adopt the water-level switch to control the action of drain pump.

Main action under different condition :( every 5 seconds the system will check the water level one time)

1. When the A/C operates with cooling (including auto cooling), dehumidifying, and forced cooling mode, the pump will start running immediately and continuously, till stop cooling.

2. Once the water level increase and up to the control point, LED will alarm and the drain pump open and continue checking the water level. If the water level fall down and LED disalarmed (drain pump delay close 1 minute) and operate with the last mode. Otherwise the entire system stop operating (including the pump) and LED remain alarming after 3 minutes,

#### 1.3.10 Point Check Function

There is a check switch in outdoor PCB.

Press the switch SW1 to check the states of unit when the unit is running.

Press the switch N times it will display the content corresponding to No. N. After getting into the check

function, it will display No. N with 1.5s, meanwhile the low bit decimal of digit display flashing, indicated to

get into the check function display. After 1.5s, it will display the content corresponding to No. N.

the digital display tube will display the follow procedure when push SW1 each time.

Ν	Display	Remark				
00	Normal display	Display running frequency, running state or malfunction cod				
01	Indoor unit capacity demand code	Actual data*HP*10 If capacity demand code is higher than 99, the digital displa tube will show single digit and tens digit. (For example, th digital display tube show "5.0",it means the capacity deman is 15. the digital display tube show "60",it means the capacit demand is 6.0)				
02	Amendatory capacity demand code					
03	The frequency after the capacity requirement transfer					
04	The frequency after the frequency limit					
05	The frequency of sending to 341					
06	Indoor unit evaporator outlet temp.(heating T2, cooling T2B)	If the temp. is lower than 0 degree, the digital display tube v show "0".If the temp. is higher than 70 degree, the digi display tube will show "70".				
07	Condenser pipe temp.(T3)	If the temp. is lower than -9 degree, the digital display tube v				
08	Outdoor ambient temp.(T4)	show "-9".If the temp. is higher than 70 degree, the digit display tube will show "70". If the indoor unit is not connected the digital display tube will show: "——"				
09	Compressor discharge temp.(T5)	The display value is between 13~129 degree. If the temp. lower than 13 degree, the digital display tube will show "13' the temp. is higher than 99 degree, the digital display tube v show single digit and tens digit. (For example, the digit display tube show "0.5", it means the compressor discharge temp. is 105 degree. the digital display tube show "1.6" means the compressor discharge temp. is 116 degree)				
10	AD value of current	The display value is hex number.				
11	AD value of voltage	The display value is hex humber.				
12	Indoor unit running mode code	Off:0, Fan only 1,Cooling:2, Heating:3				
13	Outdoor unit running mode code	Off:0, Fan only 1,Cooling:2, Heating:3, Forced cooling:4				
14	EXV open angle	Actual data/4. If the value is higher than 99, the digital display tube will sho single digit and tens digit. For example ,the digital display tube show "2.0",it means t EXV open angle is 120×4=480p.)				
		Frequency limit Bit7 caused by IGBT radiator				
		Bit6 Frequency limit caused by PFC The display value is her number. For example,				
		Bit5 Frequency limit caused by T4. the digital display tube				
15	Frequency limit symbol	Bit4 Caused by T2. Bit3=1, Bit1=1.				
		Bit3 Frequency limit caused by T3. caused by T4,T3 and				
		Bit2 Frequency limit caused by T5.				
		Bit1 Frequency limit caused by current				

		Bit0	Frequency limit caused by voltage			
16	DC fan motor speed					
17	IGBT radiator temp.	The display value is between 30~120 degree. If the temp. is lower than 30 degree, the digital display tube will show "30".If the temp. is higher than 99 degree, the digital display tube will show single digit and tens digit. (For example, the digital display tube show "0.5", it means the IGBT radiator temp. is 105 degree. the digital display tube show "1.6", it means the IGBT radiator temp. is 116 degree)				
18	Indoor unit number	The indoor	unit can communicate w	ith outdoor unit well.		
19	Condenser pipe temp. of 1# indoor unit	If the temp. is lower than 0 degree, the digital display tube will				
20	Condenser pipe temp. of 2# indoor unit	show "0".lf	the temp. is higher than 7	70 degree, the digital		
21	Condenser pipe temp. of 3# indoor unit	display tube will show "70". If the capacity demand is 0, , the digital display tube will show "0. If the indoor unit is not connected, the digital display tube will show: "——"(heating T2, cooling T2B)				
22	1# Indoor unit capacity demand code	Actual data				
23	2# Indoor unit capacity demand code	tube will sh	ow single digit and tens of			
24	3# Indoor unit capacity demand code	is 15. the d demand is	gital display tube show "	ans the capacity demand 60",it means the capacity not connected, the digital		

## 2. Troubleshooting

### 2.1 Display board

2.1.1 Icon explanation on indoor display board (Big cassette).



2.1.2 Icon explanation on indoor display board (Ceiling & Floor)



or FAN indicator(cooling only type)

#### 2.1.3 Icon explanation on indoor display board (A5 Duct)



#### 2.1.4 Display board of auto-lifting panel of 4 way cassette



#### 2.1.5 Display board of GA floor standing

## Unit Control Panel





## 2.2 Indoor unit malfunction For GA & M floor standing:

Codes	Contents			
P0	Evaporator low temp. protection			
Ed	Outdoor unit malfunction			
E1	Indoor / outdoor units communication error			
E2	Open or short circuit of T1 temperature sensor			
E3	Open or short circuit of T2 temperature sensor			
E4	Open or short circuit of T2B temperature sensor			
E7	EEPROM chip malfunction			
E8	Indoor fan speed is out of control			

## For the others types:

NO.	Malfunction	Defrosting lamp	Alarm Iamp	Running lamp	Timer lamp	Display(digital tube)
1	Communication malfunction between indoor and outdoor units.	Х	х	х	$\Delta$	E1
2	Open or short circuit of T1 temperature sensor	х	х	\$	х	E2
3	Open or short circuit of T2 temperature sensor	Х	х	${\bigtriangledown}$	х	E3
4	Open or short circuit of T2B temperature sensor	Х	х	\$	х	E4
5	Full-water malfunction	Х	$\Delta$	Х	Х	EE
6	Indoor EEPROM malfunction	${\leftrightarrow}$	Х	Х	Х	E7
7	Refrigerant Leakage Detection	${\leftrightarrow}$	${\sim}$	0	Х	EC
8	Outdoor unit malfunction	Х	O	Х	Х	Ed
9	Indoor fan speed is out of control	${\leftarrow}$	\$	Х	Х	E8
10	Communication malfunction between main PCB and up-down panel PCB	${\leftrightarrow}$	Å	\$	х	F0
11	Up-down panel malfunction	${\leftarrow}$	${\sim}$	Х	\$	F1
12	Up-down panel is not closed	${\leftarrow}$	${\sim}$	Х	0	F2
13	Communication malfunction between master unit and slave unit	х	47	х	$\Delta$	F3
14	Other malfunction of master unit or slave unit	Х	${\sim}$	${\leftrightarrow}$	Х	F4
	O (on) X(off) Notes: Digital display is only av F0,F1,F2 are only av	•	er-slim 4-way	/ cassette & duct	type.	

#### 2.3 Outdoor unit malfunction

Display	Malfunction or Protection
E0	Outdoor EEPROM malfunction
E2	Indoor / outdoor units communication error
E3	Communication malfunction between IPM board and outdoor main board
E4	Open or short circuit of T3 or T4 temperature sensor
E5	Voltage protection of compressor
E6	PFC module protection (Only for 48K with 1 phase)
P0	Top temperature protection of compressor
P1	High pressure protection
P2	Low pressure protection
P3	Current protection of compressor
P4	Discharge temperature protection of compressor
P5	High temperature protection of condenser
P6	IPM module protection
P7	High temperature protection of evaporator

In low ambient cooling mode, the LED displays "LC" or alternative displays between running frequency and "LC" (each displays 0.5s)

## 2.4 Solving steps for typical malfunction

2.4.1 For the indoor unit

2.4.1.1 Open or short circuit of temperature sensor







#### 2.4.1.4. Full-water malfunction



2.4.1.5. Indoor fan Speed has been out of control.



#### DC motor voltage input and output (control chip is inside the motor)



DC motor voltage	input and	output
------------------	-----------	--------

NO.	Color	Signal	Voltage		
1	Red Vs/Vm		Red Vs/Vm 280V~380		280V~380V
2					
3	Black	GND	0V		
4	White	Vcc	14-17.5V		
5	Yellow	Vsp	0~5.6V		
6	Blue	FG	14-17.5V		



Color	Red	Blue	Yellow
Signal	W	V	U

- 1) Release the UVW connector. Measure the resistance of U-V, U-W, V-W. If the resistance is not equal to each other, the fan motor must have problems and need to be replaced. Otherwise, go to step 2.
- 2) Power on and when the unit is in standby, measure the voltage of pin4-5 in feedback signal connector. If the value is not 5V, change the PCB. Otherwise, go to step 3.
- 3) Rotate the fan by hand, measure the voltage of pin1-5, pin 2-5 and pin 3-5 in feedback signal connector. If any voltage is not positive voltage fluctuation, the fan motor must have problems and need to be replaced.

#### 2.4.2 For the super-slim cassette with up-down panel

- 2.4.2.1 Communication error between indoor unit and up-down panel
- 2.4.2.2 Up-down panel is defective



# 2.4.2.3 Up-down panel is not closed F2 Displayed The up-down panel is not closed Check if the filter panel of up-down panel is closed Yes Yes Problem is solved













2.4.3.6. E5 malfunction(For three phases units)











Electrical Control System



#### 2.4.3.12. P4 malfunction

When compressor discharge temperature is higher than 115°C, the unit will stop, and unit runs again when compressor discharge temperature is lower than 90°C.



#### 2.4.3.13. P5 malfunction

When condenser high temp. is more than 65°C, the unit will stop, and unit runs again when outdoor pipe temp. less than 52°C.









Appendix 1 Temperature Sensor Resistance Value Table (°C--K)

Appendix	Appendix 1 Temperature Sensor Resistance Value Table (℃K)								
Ĉ	K Ohm	ĉ	K Ohm	ĉ	K Ohm	ĉ	K Ohm		
-20	115.266	20	12.6431	60	2.35774	100	0.62973		
-19	108.146	21	12.0561	61	2.27249	101	0.61148		
-18	101.517	22	11.5000	62	2.19073	102	0.59386		
-17	96.3423	23	10.9731	63	2.11241	103	0.57683		
-16	89.5865	24	10.4736	64	2.03732	104	0.56038		
-15	84.2190	25	10.000	65	1.96532	105	0.54448		
-14	79.3110	26	9.55074	66	1.89627	106	0.52912		
-13	74.5360	27	9.12445	67	1.83003	107	0.51426		
-12	70.1698	28	8.71983	68	1.76647	108	0.49989		
-11	66.0898	29	8.33566	69	1.70547	109	0.48600		
-10	62.2756	30	7.97078	70	1.64691	110	0.47256		
-9	58.7079	31	7.62411	71	1.59068	111	0.45957		
-8	56.3694	32	7.29464	72	1.53668	112	0.44699		
-7	52.2438	33	6.98142	73	1.48481	113	0.43482		
-6	49.3161	34	6.68355	74	1.43498	114	0.42304		
-5	46.5725	35	6.40021	75	1.38703	115	0.41164		
-4	44.0000	36	6.13059	76	1.34105	116	0.40060		
-3	41.5878	37	5.87359	77	1.29078	117	0.38991		
-2	39.8239	38	5.62961	78	1.25423	118	0.37956		
-1	37.1988	39	5.39689	79	1.21330	119	0.36954		
0	35.2024	40	5.17519	80	1.17393	120	0.35982		
1	33.3269	41	4.96392	81	1.13604	121	0.35042		
2	31.5635	42	4.76253	82	1.09958	122	0.3413		
3	29.9058	43	4.57050	83	1.06448	123	0.33246		
4	28.3459	44	4.38736	84	1.03069	124	0.32390		
5	26.8778	45	4.21263	85	0.99815	125	0.31559		
6	25.4954	46	4.04589	86	0.96681	126	0.30754		
7	24.1932	47	3.88673	87	0.93662	127	0.29974		
8	22.5662	48	3.73476	88	0.90753	128	0.29216		
9	21.8094	49	3.58962	89	0.87950	129	0.28482		
10	20.7184	50	3.45097	90	0.85248	130	0.27770		
11	19.6891	51	3.31847	91	0.82643	131	0.27078		
12	18.7177	52	3.19183	92	0.80132	132	0.26408		
13	17.8005	53	3.07075	93	0.77709	133	0.25757		
14	16.9341	54	2.95896	94	0.75373	134	0.25125		
15	16.1156	55	2.84421	95	0.73119	135	0.24512		
16	15.3418	56	2.73823	96	0.70944	136	0.23916		
17	14.6181	57	2.63682	97	0.68844	137	0.23338		
18	13.9180	58	2.53973	98	0.66818	138	0.22776		
19	13.2631	59	2.44677	99	0.64862	139	0.22231		

## Appendix 2

	1	omn concortabl	0				
20		Jnit: ℃K	68.00	Discharge temp. sensor table 6 60 13.59 100			
-20	542.7	20	68.66				3.702
-19	511.9	21	65.62	61	13.11	101	3.595
-18	483	22	62.73	62	12.65	102	3.492
-17	455.9	23	59.98	63	12.21	103	3.392
-16	430.5	24	57.37	64	11.79	104	3.296
-15	406.7	25	54.89	65	11.38	105	3.203
-14	384.3	26	52.53	66	10.99	106	3.113
-13	363.3	27	50.28	67	10.61	107	3.025
-12	343.6	28	48.14	68	10.25	108	2.941
-11	325.1	29	46.11	69	9.902	109	2.86
-10	307.7	30	44.17	70	9.569	110	2.781
-9	291.3	31	42.33	71	9.248	111	2.704
-8	275.9	32	40.57	72	8.94	112	2.63
-7	261.4	33	38.89	73	8.643	113	2.559
-6	247.8	34	37.3	74	8.358	114	2.489
-5	234.9	35	35.78	75	8.084	115	2.422
-4	222.8	36	34.32	76	7.82	116	2.357
-3	211.4	37	32.94	77	7.566	117	2.294
-2	200.7	38	31.62	78	7.321	118	2.233
-1	190.5	39	30.36	79	7.086	119	2.174
0	180.9	40	29.15	80	6.859	120	2.117
1	171.9	41	28	81	6.641	121	2.061
2	163.3	42	26.9	82	6.43	122	2.007
3	155.2	43	25.86	83	6.228	123	1.955
4	147.6	44	24.85	84	6.033	124	1.905
5	140.4	45	23.89	85	5.844	125	1.856
6	133.5	46	22.89	86	5.663	126	1.808
7	127.1	47	22.1	87	5.488	127	1.762
8	121	48	21.26	88	5.32	128	1.717
9	115.2	49	20.46	89	5.157	129	1.674
10	109.8	50	19.69	90	5	130	1.632
11	104.6	51	18.96	91	4.849		
12	99.69	52	18.26	92	4.703		
13	95.05	53	17.58	93	4.562		
14	90.66	54	16.94	94	4.426		
15	86.49	55	16.32	95	4.294	B(25/50	)=3950K
16	82.54	56	15.73	96	4.167		
17	78.79	57	15.16	97	4.045	<b>R(90</b> ℃)=	5KΩ±3%
18	75.24	58	14.62	98	3.927		
19	71.86	59	14.09	99	3.812		

## 3. Controller

#### 3.1Wireless Remote Controller 3.1.1RG51Q1/BGE





#### General Function for wireless remote controller:

Model	RG51Q1/BGE
Rated voltage	3.0V(2pieces of LR03 7 # batteries)
Min voltage for sending signal of CPU	2.4V
Effective receiving distance	8m~11m
Operation condition	- <b>5~60</b> ℃

#### **Buttons and functions**

**1. Adjust** ▼ : Decrease the set temp. Keeping pressing will decrease the temp with 1°C per 0.5s.

**2.** Adjust **A** : Increase the set temp. Keeping pressing will increase the temp with 1°C per 0.5s.

**3. MODE**: Once pressing, running mode will be selected in the following sequence:

#### NOTE: No heating mode for cool only type unit.

**4. VERT SWING:** Used to stop or start horizontal louver movement or set the desired up/down air flow direction. The louver changes 6 degree in angle for each press. If keep pushing more than 2 seconds, the louver will swing up and down automatically.

5. HORIZ SWING: Used to stop or start vertical louver movement.

**6. AIR DIRECTION**: Used to set the desired up/down air flow direction. The louver changes 6 degree in angle for each press.

7. ON/OFF: For turning on or turning off the air conditioner.

8. FAN SPEED: Fan speed will be selected in following sequence once pressing this button:

→AUTO→LOW→MED→HIGH

**9. TIME ON:** For time ON setting. Once pressing this button, the time will increase by 0.5 hour. When the set time exceeds 10 hours, pressing the button will increase the time by 1 hour. Adjusting the figure to 0.00 will cancel time ON setting.

**10. ECO:** Activate or turn off economic operation mode. It is suggested to turn on this function when sleeping. (Only available when remote controller is used with corresponding unit.)

**11. TIME OFF:** For time OFF setting. Once pressing this button, the time will increase by 0.5 hour. When the set time exceeds 10 hours, pressing the button will increase the time by 1 hour.

Adjust the figure to 0.00 will cancel time ON setting.

**12. C/H** (inner located): Press this button with a needle of 1mm to shift the mode between Cooling only and Cooling & Heating according to the feature of the machine.

**13.RESET** (inner located): Press this button with a needle of 1mm to cancel the current setting and reset remote controller.

## 3.1.2 RG51C/E

#### **Remote Controller Specifications**

Model	RG51C/E
Rated Voltage	3.0V(2pieces of LR03 7 # batteries)
Lowest Voltage of CPU Emitting Signal	2.0V
Reaching Distance	8m (when using 3.0 voltage, it can get 11m)
Environment Temperature Range	-5℃ <b>~60</b> ℃

Introduction of Function Buttons on the Remote Controller



- **1. Adjust**  $\blacksquare$  : Decrease the set temp. Keeping pressing will decrease the temp with 1 °C per 0.5s.
- 2. Adjust 🔺 : Increase the set temp. Keeping pressing will increase the temp with 1 °C per 0.5s.
- **3. MODE**: Once pressing, running mode will be selected in the following sequence:



#### NOTE: No heating mode for cool only type unit.

**4. VERT SWING:** Used to stop or start horizontal louver movement. The louver will swing up and down automatically if push this button.

**AIR DIRECTION**: Used to set the desired up/down air flow direction. The louver changes 6 degree in angle for each press.

- 5. HORIZ SWING: Used to stop or start vertical louver movement.
- 6. FAN SPEED+ MODE: Press the Mode and Fan speed button simultaneously for 2 seconds. The remote

controls into faceplate setting state and the LCD shows F2.Press the TEMPUP( $\triangleq$ ) to control the faceplate up and press the TEMP DOWN( $\checkmark$ ) to control the faceplate down. Press any button to exit the faceplate setting state, then the LCD back to the normal display.

7. ON/OFF: For turning on or turning off the air conditioner.

**8. FAN SPEED:** Fan speed will be selected in following sequence once pressing this button:

→AUTO→LOW → MED→HIGH →

**9. TIME ON:** For time ON setting. Once pressing this button, the time will increase by 0.5 hour. When the set time exceeds 10 hours, pressing the button will increase the time by 1 hour. Adjusting the figure to 0.00 will cancel time ON setting.

10. ECO: Select this function during the sleeping time. It can maintain the most comfortable temperature

and save energy. This function is available on COOL, HEAT or AUTO mode only .

NOTE: While the unit is running under Energy-saving mode, it would be cancelled if press MODE, FAN SPEED or ON/OFF button.

**11. TIME OFF:** For time OFF setting. Once pressing this button, the time will increase by 0.5 hour. When the set time exceeds 10 hours, pressing the button will increase the time by 1 hour.

Adjust the figure to 0.00 will cancel time ON setting.

**12. LOCK** (inner located): Push this button to lock in all the current settings, and the remote controller will not accept any operation except that of the LOCK. Use the LOCK mode when you want to prevent settings

from being changed accidentally. Press the LOCK button again to cancel the LOCK function. A lock symbol will appear on the remote controller display when the lock function is activated.

**13.RESET** (inner located): Once the recessed RESET button is pressed, all of the current settings will be cancelled and the controller will return to the initial settings..

## 3.1.3 R51M/(C)E

#### **Remote Controller Specifications**

Model	R51M/(C)E
Rated Voltage	3.0V
Reaching Distance	8m
Environment Temperature Range	-5℃ <b>~60</b> ℃

Introduction of Function Buttons on the Remote Controller



**1. Adjust** ▼ : Decrease the set temp. Keeping pressing will decrease the temp with 1°C per 0.5s.

2. Adjust ▲: Increase the set temp. Keeping pressing will increase the temp with 1°C per 0.5s.
3. MODE: Once pressing, running mode will be selected in the following sequence:

AUTO - COOL - DRY - HEAT - FAN-

#### NOTE: No heating mode for cool only type unit.

4. SWING: Used to stop or start horizontal louver movement. The louver will swing up and down

automatically if push this button.

**5. RESET** (inner located): Once the recessed RESET button is pressed, all of the current settings will be cancelled and the controller will return to the initial settings.

**6. AIR DIRECTION**: P Press this button to change the swing angle of the louver. The swing angle of the louver is 60 for each press. When the louver swing at a certain angle which would affect the cooling and heating effect of the air conditioner, it would automatically change the swing direction . No symbol will appear in the display area when press this button. (Not applicable to units without this function).

7. LED: Press this button to clear the digit display in the air conditioner, press it again to activate it (Not

available for the units without LED display window).

8. FAN SPEED: Fan speed will be selected in following sequence once pressing this button:

→AUTO → LOW → MED → HIGH →

9. ON/OFF: For turning on or turning off the air conditioner

**10. TIME ON:** For time ON setting. Once pressing this button, the time will increase by 0.5 hour. When the set time exceeds 10 hours, pressing the button will increase the time by 1 hour. Adjusting the figure to 0.00 will cancel time ON setting.

**11.SLEEP:** Press this button to go into the Energy-Saving operation mode. Press it again to cancel. This function is only can be used on COOL, HEAT and AUTO mode and maintain the most comfortable temperature for you.

**12. TIME OFF:** For time OFF setting. Once pressing this button, the time will increase by 0.5 hour. When the set time exceeds 10 hours, pressing the button will increase the time by 1 hour.

Adjust the figure to 0.00 will cancel time ON setting.

**13. LOCK** (inner located): Push this button to lock in all the current settings, and the remote controller will not accept any operation except that of the LOCK. Use the LOCK mode when you want to prevent settings

from being changed accidentally. Press the LOCK button again to cancel the LOCK function. A lock symbol will appear on the remote controller display when the lock function is activated.

**14. TURBO:** Push this button to activate/cancel the Turbo function which enables the unit to reach the preset temperature in the shortest time. On cooling mode, the unit will blow strong cooling air with super high fan speed. On heating mode (applicable to the unit adopts PTC only), the PTC will bring fast heating operation.

## 3.2 Wired Remote Controller 3.2.1KJR-12B



#### Name and functions of buttons on the wire controller



1. Mode button: When press this button, the operation mode change as the following sequence: →AUTO→COOL→DRY→HEAT→FAN→

**Remark:** For the cooling only model, the heating mode is skipped.

- 2. Timer on button: Press this button, timer on function is active. Then every press, the time increase 0.5h, after 10h, 1h increasement after each press. If cancel this Function, just set it to "0.0"
- 3. Timer off button: Press this button, timer off function is active. Then every press, the time increase 0.5h, after 10h, 1h increasement after each press. If cancel this function, just set it to "0.0".
- 4. Follow me button: When under cool, heat and auto mode, press this button, follow me function is active. Press again, this function is ineffective.
- 5. Electrical heater button: If press this button in heat mode, electrical heater function become ineffective.
- 6. Reset button (hidden): Use a 1mm stick to press in the little hole , then the current setting is canceled . The wire controllers enter into original state.

- 7. ON/OFF button: When in off state, press this button, the indicator is on, the wire controller enter into on state, and send setting information to indoor PCB. When in on state, press this button, the indicator is off, and send instruction. If timer on or timer off has been set, it cancel this setting then send instruction to stop the machine.
- 8. Adjust button: Set indoor temperature up. If press and hold on, it will increase at 1degree per 0.5 second.
- 9. Adjust button: Set indoor temperature down. if press and hold on, it will decrease at 1degree per 0.5 Second.
- 10. Swing button: First press, start swing function; second press, stop swing. (Match to some model with swing function).
- 11. Economy operation button: press this button, the indoor unit operates in economy mode, press again, exit this mode (it may be ineffective for some models)
- 12. Fan speed button: press this button consecutively; the fan speed will circle as follow:



13. Lock button (hidden): When you push the LOCK button, all current settings are locked in and the wire controller does not accept any operation except that of the LOCK button. Use the lock mode when you want to prevent setting from being changed accidentally or play fully. Push the LOCK button again when you want to cancel the LOCK mode.

#### Name and function of LCD on the wire controller



 Operation mode indication: When press" MODE" button, the following mode can be selected in circle. Auto Cool Dry Heat Fan only Auto. Auto→ Cool→ Dry →Heat→ Fan only →Auto

For cooling only model, heat mode is skipped.

- 2. Timer: When adjust setting on time or only on time is set, the "ON" is lighted. When adjust setting off time or only off time is set, the" OFF" is lighted. If on and off timer are both set, the "ON" and "OFF" are both lighted.
- 3. Follow me function: There is a temperature sensor inside the wire controller, after setting temperature, it will compare the two temperatures, and the space of wire controller will be the same as setting temperature. It is available under cooling, heating, auto mode.
- 4 ON/OFF indication: When it is on, the icon display, otherwise it is extinguished.
- 5. Fan speed indication: There are four fan modes: low, middle, high, auto. For some models, no middle fan then the middle fan is seen as high speed.
- 6. Lock: When the "LOCK" button is pressed, the icon appears and other buttons is unable, press again, the icon disappears.
- 7. Temperature display zone: Generally it displays setting temperature; it can be adjusted by press temperature button▲and▼.But in fan mode, no display here.

#### **Remark:**

The wired controller will reset to factory setting with auto mode, auto fan and 24°C setting temperature when the air conditioner restarts after power failure.

And this may cause inconsistent displays on the wired controller and on the air conditioner. You need to readjust the running status through the wired controller.

#### Installation

Wiring Principle Sketch:



#### Installation Notice:

When the air conditioner needs the constant frequency wire controller, be sure adding a wire joint with 5 terminal named A, B, C, D, E in indoor unit, and fixing an infrared emitter whose anode and cathode connecting with A and B near the receiver in the indoor unit switch board, then connecting the terminal +5v, GND, Run in the switch board to C,D,E respectively.



#### NOTE

The connecting wire should be a little longer as to take away the switch board easily for maintenance.

The connecting wire should be a little longer as to take away the controller easily for maintenance.