



MOTOROLA

C E L L U L A R



Profile

Owner's Manual



ENHANCED CELLULAR TELEPHONE

Welcome Thank you for selecting Motorola — *a world leader in communications technology.*

All Motorola cellular phones are designed and manufactured in the United States to meet Motorola's exacting specifications and world class quality standards. The *Profile* cellular phone is no exception. This personal phone withstands our rigorous durability tests including temperature, humidity, shock, dust, vibration, and a drop test.

Product superiority is yours with the *Profile* cellular phone.

- For any information about your product or accessories for your product, please call Motorola at: **1-800-331-6456** (USA) or **1-800-461-4575** (Canada).
- For any information about your cellular service, please call your service provider (Carrier).

Carrier's Name _____

Carrier's Phone Number _____

- You will need to have the following information when you inquire about your phone or service. This information is located on the back of your phone after you remove the battery.

ESN Number _____

MSN Number _____

Model Number _____

Cellular Phone Number _____

Unlock Code — The sequential code of **1, 2, 3** is the standard unlock code programmed into all phones by the factory. It is often changed to the last three digits of your cellular phone number by the Carrier. For easy access to this unlock code in the future, please list it here now: _____. (Please contact your place of purchase if your unlock code has been changed and you do not have this information.)

Warranty Expiration Date _____

Date of Purchase _____

Table of Contents

Introduction

Cellular Operation Safety Information	vi
---	----

Introduction	ix
------------------------	----

Controls and Indicators

Controls and Indicators	x
-----------------------------------	---

Getting Started

Prepare the Battery for Initial Use	1
---	---

Attach the Battery	2
------------------------------	---

Remove the Battery	2
------------------------------	---

Standard Method	2
---------------------------	---

Quick-Change Battery Removal/Replacement	3
--	---

Using Plug-In Chargers	3
----------------------------------	---

Basic Operation

About the Antenna	4
-----------------------------	---

Turning Phone On and Off	4
------------------------------------	---

Start-up Self Tests	4
-------------------------------	---

Start-up Messages	4
-----------------------------	---

Start-up Status Indicators	5
--------------------------------------	---

Illuminated Keypad	5
------------------------------	---

Placing a Call	6
--------------------------	---

To Correct an Error	6
-------------------------------	---

If Entering More Than 10 Digits	6
---	---

Unsuccessful Call Attempts	7
--------------------------------------	---

Automatic Redialing	7
-------------------------------	---

Ending a Call	8
-------------------------	---

Receiving a Call	8
----------------------------	---

Call In Absence Indicator	9
-------------------------------------	---

Signal Strength Meter	9
---------------------------------	---

Table of Contents

Volume Meter	10
Adjusting Earpiece Volume	10
Adjusting Ringer Volume	10
Low Battery Warning	10
Battery Voltage Meter	11

Storing Numbers in Memory

About Memory	12
Storing a Phone Number	12
Storing an Area Code and Prefix (Postscripting) . . .	13
Memory Protect Feature	13
Deleting a Memory Entry	14
Changing a Memory Entry	14

Placing Calls From Memory

About Recalling from Memory	15
Placing Calls by Entering Two-Digit Number	15
Placing Calls by Scrolling	16

Advanced Memory Dialing Features

Last Number Redial	17
Recalling Last Number Called	17
Recalling Area Code and Prefix (Postscripting) . . .	17
Turbo Dial Feature	17
Priority Call	18
Super Speed Dial Feature	18
Scratch Pad Memory	19
Two-Part Tone Dialing	19
Memory Linking	20
Example of Memory Linking	20

Special Call Features

Display Own Phone Number	23
---	----

Microphone Muting	23
To mute microphone	23
To disable mute	23
Automatic Answer	23
One Minute Beep	23
Multiple Key Answer	24
Hands Free Operation	24
Distinctive Ringer	24
Multiple Language Display	25
Extended Talk Time	25

Special System Features

About Special System Features	26
Calling Line ID	26
Receiving Calls with Calling Line ID	26
Recalling/Viewing Calling Line ID Messages	27
Placing a Call to a Calling Line ID Number	27
Storing a Calling Line ID Number in Memory	28
Deleting an Individual Message	28
Deleting All Messages	28
Other Messaging Services	28
VOX Operation	29
Reminder Beeps	29
PIN Code Operation	29
Overview	29
Placing a Call using PIN Operation	29

Using the Feature Menu

About the Feature Menu	31
Selecting and Deselecting Features	31
Status Review	35

Call Timers

About Timers	36
Individual Call Timer	36
To Display	36
Resettable Call Timer	36
To Display	36
To Reset	36
Cumulative Call Timer	36
To Display	36
Automatic Display Timer	37

Security Features

About Security Codes	38
Electronic Lock	38
To Lock	38
To Unlock	38
Displaying the Unlock Code	39
Changing the Unlock Code	39
Automatic Lock	39
Setting Outgoing Call Restrictions	39

Cellular System Information

Cellular System Overview	41
Service Area	41
Weak Signal Alert	41
Switchhook and Advanced System Services	42
Roaming	42
Two-System Operation	43

Programming Scanning Modes

Overview	44
Reviewing / Changing Scanning Mode	44

To Review Scanning Mode	44
To Change Scanning Modes.	44
Scanning Modes	45
Troubleshooting	
Before Calling For Service	47
Reference	
Regulations and Precautions	48
Message Glossary	50
Index	53
FDA Consumer Update	57
Patent Information	62

Safety Information (US Version)

IMPORTANT:

Read this information before using your wireless handheld phone.

Exposure to Radio Frequency Signals

Your wireless handheld portable telephone is a low power radio transmitter and receiver. When it is ON, it receives and also sends out radio frequency (RF) signals.

In August 1996, The Federal Communications Commission (FCC) adopted RF exposure guidelines with safety levels for handheld wireless phones.

Those guidelines are consistent with safety standards previously set by both U.S. and international standards bodies:

- American National Standards Institute (ANSI) IEEE. C95. 1-1992
- National Council on Radiation Protection and Measurement (NCRP). Report 86
- International Commission on Non-Ionizing Radiation Protection (ICNIRP) 1996
- Ministry of Health (Canada), Safety Code 6

Those standards were based on comprehensive and periodic evaluations of the relevant scientific literature. For example, over 120 scientists, engineers, and physicians from universities, government health agencies, and industry reviewed the available body of research to develop the ANSI Standard (C95.1).

The design of your phone complies with the FCC guidelines (and those standards). For additional information concerning exposure to radio frequency signals, see the statement by the FDA at the end of this user guide. To maintain compliance with FCC RF exposure guidelines, if you wear a handset on your body, use the Motorola-supplied or approved carrying case, holster, or other body-worn accessory. If you do not use a body-worn accessory, ensure the antenna is at least one inch (2.5 centimeters) from your body when transmitting. Use of non-Motorola accessories may violate FCC RF exposure guidelines.

Antenna Care

Use only the supplied or an approved replacement antenna. Unauthorized antennas, modifications, or attachments could damage the phone and may violate FCC regulations.

Phone Operation

Normal Operation

Hold the phone as you would any other telephone, with the antenna pointed up and over your shoulder.

Tips on Efficient Operation

Observe the following guidelines to operate your phone most efficiently.

- Extend your antenna fully, if applicable.

- Do not touch the antenna unnecessarily when the phone is in use. Contact with the antenna affects call quality and may cause the phone to operate at a higher power level than otherwise needed.

Batteries

Caution: All batteries can cause property damage, injury, or burns if a conductive material, such as jewelry, keys or beaded chains, touches exposed terminals. The material may complete an electrical circuit and become quite hot. To protect against such unwanted current drain, exercise care in handling any charged battery, particularly when placing it inside your pocket, purse, or other container with metal objects. When the battery is detached from the phone, your batteries are packed with a protective battery cover; please use this cover for storing your batteries when not in use.

Driving

Check the laws and regulations on the use of wireless telephones in the areas where you drive. Always obey them. Observe the following guidelines when using your phone while driving.

- Give full attention to driving—driving safely is your first responsibility.
- Use hands-free phone operation, if available.
- Pull off the road and park before making or answering a call if driving conditions so require.

Electronic Devices

Most modern electronic equipment is shielded from RF signals. However, certain equipment may not be shielded against the RF signals from your wireless phone.

Pacemakers

The Health Industry Manufacturers Association recommends that a minimum separation of six inches (6") be maintained between a handheld wireless phone and a pacemaker to avoid potential interference with the pacemaker. These recommendations are consistent with the independent research by and recommendations of Wireless Technology Research.

Persons with pacemakers:

- should ALWAYS keep the phone more than six inches from their pacemaker when the phone is turned ON
- should not carry the phone in a breast pocket
- should use the ear opposite the pacemaker to minimize the potential for interference
- should turn the phone OFF immediately if you have any reason to suspect that interference is taking place

Hearing Aids

Some digital wireless phones may interfere with some hearing aids. In the event of such interference, you may want to consult your hearing aid manufacturer to discuss alternatives.

Other Medical Devices

If you use any other personal medical device, consult the manufacturer of your device to determine if it is adequately shielded from external RF energy. Your physician may be able to assist you in obtaining this information. Turn your phone OFF in health care facilities when any regulations posted in these areas instruct you to do so. Hospitals or health care facilities may be using equipment that could be sensitive to external RF energy.

Vehicles

RF signals may affect improperly installed or inadequately shielded electronic systems in motor vehicles. Check with the manufacturer or its representative regarding your vehicle. You should also consult the manufacturer of any equipment that has been added to your vehicle.

Posted Facilities

Turn your phone OFF in any facility where posted notices so require.

Aircraft

Switch OFF your phone before boarding an aircraft.

Airline regulations prohibit using your phone while in the air. Check and comply with the policy of your airline regarding the use of your phone while the aircraft is on the ground.

Blasting Areas

To avoid interfering with blasting operations, turn your phone OFF when in a "blasting area" or in areas posted: "Turn off two-way radio." Obey all signs and instructions.

Potentially Explosive Atmospheres

Turn your phone OFF, do not remove your battery when you are in any area with a potentially explosive atmosphere, and obey all signs and instructions. Sparks from your battery in such areas could cause an explosion or fire resulting in bodily injury or even death.

Areas with a potentially explosive atmosphere are often but not always clearly marked. They include: fueling areas such as gasoline stations; below deck on boats; fuel or chemical transfer or storage facilities; areas where fuel odors are present (for example, if a gas/propane leak occurs in a car or home); areas where the air contains chemicals or particles, such as grain, dust, or metal powders; and any other area where you normally would be advised to turn off your vehicle engine.


For Vehicles Equipped with an Air Bag

An air bag inflates with great force. Do NOT place objects, including both installed or portable wireless equipment, in the area over the air bag or in the air bag deployment area. If in-vehicle wireless equipment is improperly installed and the air bag inflates, serious injury could result.

US021600

Introduction

The *Profile* cellular phone represents the state-of-the-art in personal cellular telephones today.

This *Profile* phone features the  *Enhanced Feature Set*, which includes a large display, Extended Talk Time and Standby Time, and improved charging performance.

In addition, your *Profile* phone also offers the following exceptional features.

- Calling Line ID Capable
- 9 Selectable Ringer Styles
- Call Timers
- Priority Calling
- Super Speed Dialing
- Memory Protect
- Multilingual Prompts
- Two-System Operation
- Turbo Dial Operation
- Multiple Key Answer
- Auto Answer

Remember, these are just a few of the great features that your *Profile* cellular phone provides to meet your business and personal needs. In addition, a number of optional accessories are available to help you tailor your phone to your individual preferences. These include a full range of Batteries, Chargers, Vehicle Adapters, and Data Products.

To help you become familiar with your telephone's features, we suggest that you experiment with them as you progress through this manual.

Please read *General Safety Information* before operating your phone.


❶ Retractable Antenna

Extend for optimum performance.

❷ Earpiece

❸ Status Indicators

Provide a visual indication of conditions associated with cellular telephone service.



IU (In Use) — Flashes slowly when call is in progress.

RM(Roam) — Flashes if your phone is accessing another cellular system other than your home registered system.

NS (No Service) — Flashes slowly when the phone is out of service range of a cellular system. Calls cannot be placed or received when this light is on.

Signal Strength Indicator — Flashes the relative strength of the signal received by the phone (see page 9).

Battery Strength Indicator — Lights steadily to indicate the estimated remaining capacity of the battery (see page 11).

❹ Number Display

(Be sure to remove the protective label affixed to the display.) Displays phone number, memory location number, or message. Some information will require viewing sequentially displayed messages.

⑤ Function Keys

- RCL** Recalls and displays telephone numbers stored in memory.
- STO** Stores numbers into any of the memory locations.
- CLR** Clears last digit when pressed and released. Press and hold to clear entire display in the event of an error (does not affect numbers stored in memory).
- SND** Initiates a call to the entered telephone number or answers a call. Sends a switchhook flash when a call is in progress.
- PWR** Turns phone on and off.
- FCN** Used in combination with other buttons for specific user-programmed functions (e.g., **FCN**, **5** activates lock mode).
- END** Terminates a call in progress and exits special functions.
- ▲** and **▼** Adjusts the earpiece and ringer volume.

⑥ Numeric Keypad

- 1**, **2**, **3**, etc., are used to enter call information.
- #** scrolls forward. ***** scrolls backward.

⑦ Headset Jack


Connect an optional accessory headset to this jack to provide simple hands-free conversations.

⑧ Mouthpiece


Notes...

Prepare the Battery for Initial Use

The Nickel Metal Hydride or Nickel-Cadmium battery supplied with your phone must be fully charged before placing your phone into service. The batteries are shipped from the factory in a discharged state in order to extend the life of the battery. It is recommended that you charge new batteries for at least 4 hours using the AC Charger/Transformer, or overnight using the *IntelliCharge™* Desktop Charger. Do not charge the battery longer than 24 hours. (Refer to page 3 if you are using a plug-in charger.)



AC Charger/Transformer



IntelliCharge Desktop Charger

Motorola desktop chargers for this line of products are dual pocket chargers. The charger's front pocket can charge a battery while attached to the phone or by itself. The charger's rear pocket can charge any compatible battery (not attached to a phone).

WARNING *Battery may explode if exposed to fire.*


WARNING *To prevent injuries or burns, and to avoid damage to the battery, do not allow metal objects to contact or short circuit the battery terminals. Refer to "Batteries" on page vii for details.*

CAUTION *Charging your battery in anything other than a Motorola charger will void your warranty.*

CAUTION *To avoid damage to the battery, do not place it anywhere that might cause the battery terminals to short together.*

Attach the Battery


1. Place the battery on the phone so that its grooves align. Align the top of the battery with the line on the back of the phone right below the arrows.
2. Slide upward in the direction of the arrows on the back of the phone until it clicks into place.



Remove the Battery

Standard Method

1. Turn your phone off.
2. Depress the latch button on the rear of the battery and slide the battery downward until it stops.
3. Lift the battery off.




Quick-Change Battery Removal/Replacement

The quick-change method allows you to remove your battery at any time and replace it with a charged spare battery during a telephone call. This is especially useful if you receive the low battery message (*LOW BATT*) or audible tone during a call.

Simply remove the battery from the phone and put on the spare battery. The phone will not go through the normal power-up cycle described on page 4. You will only have four seconds to complete this action before your telephone call is terminated. It is a good idea to practice this procedure a few times before using it on an actual telephone call. Advise the party on the other end of the call before beginning this procedure.

Using Plug-In Chargers

If you are using a charger that plugs into the bottom of the phone, you must remove the small plastic cover to gain access to the receptacle, as shown below.



About the Antenna

There are two parts to the handset antenna, one internal and one retractable. This allows your phone to detect incoming calls without having the antenna extended. For optimum performance, fully extend the antenna when in a call or when placing a call.

Turning Phone On and Off

1. Press **PWR** to turn your phone on.
2. Press **PWR** again to turn your phone off.




Start-up Self Tests

Each time the phone is turned on, it performs a series of self tests, sounds a tone, and lights all display positions and status indicators to check their operation. The Signal Strength and Battery Meters then display and the keypad lights momentarily, as it will any time a key is pressed.

Start-up Messages

Message	Explanation
<i>R 1</i>	<ul style="list-style-type: none">• If your phone is programmed for two cellular systems, one of these messages will appear in the display upon power up.• These are reminders as to which system and phone number are currently in use.
<i>R 2</i>	
<i>b 1</i>	
<i>b 2</i>	
<i>Loc 'd</i>	<ul style="list-style-type: none">• Indicates that the phone has been locked and cannot send or receive calls until unlocked.

Start-up Status Indicators

<i>Indicator</i>	<i>Explanation</i>
	IU (In Use) Indicator <ul style="list-style-type: none"> Flashes slowly while a call is in progress
	NS (No Service) Indicator <ul style="list-style-type: none"> Flashes slowly if phone is beyond range of a cellular service area Calls cannot be placed or received while <i>NS</i> is lit
	RM (Roam) Indicator <p>If flashing, you are accessing a Cellular System other than your home system.</p>

Illuminated Keypad

Your keypad lights whenever the phone is turned on, a call is received, or a key is pressed. To help conserve battery power and minimize distractions while driving at night, the display and keypad backlighting will turn off after 16 seconds if no key is pressed. You may reactivate the display by pressing any key. The display and keypad backlighting remain lit during menu use.

Placing a Call

1. With power on, enter the number you wish to call.
2. Press **(SND)**. *dialing* and the dialed number will alternate in the display until the called party answers.
3. Begin the conversation when the called party answers.

To Correct an Error

To correct an error, press and quickly release **(CLR)** to delete the last character. To clear the entire entry, press and hold **(CLR)** for about 1 second. Your entire entry will be deleted, and you may now re-enter the number you wish to call.

If Entering More Than 10 Digits

You can call a phone number with up to 16 digits, but only the last 10 digits will appear in the display.

To recall a stored phone number that is longer than 10 digits, press **(RCL)** and the memory location number. The display will flash the memory location number and the last 10 digits of the number. Press **(RCL)** again to view the entire number.

Unsuccessful Call Attempts

If you hear one of the following signals, you have not successfully completed your call.

<i>Tone / Message</i>	<i>Description</i>
fast busy (reorder signal) <i>Snd to rEd ,AL</i>	Cellular System Busy Press (SND) again before ending the unsuccessful call attempt to automatically redial the call (refer to Automatic Redialing below), or press (END) and dial the call again.
alternating high/low tone (intercept) <i>Snd to rEd ,AL</i>	Cellular System Could Not Complete the Call You may have tried to place a call before the green IU indicator was flashing to let you know your phone was fully operative. Either press (SND) again before ending the unsuccessful call attempt to automatically redial the call (refer to Automatic Redialing below), or press (END) and dial the call again.
busy signal	The Called Party's Line is Busy

Automatic Redialing

Your phone includes a convenient feature that eliminates the need for you to make repetitive call attempts when a cellular system is busy.

If you receive an alternating high/low signal (intercept) or the fast busy tone (reorder signal) when attempting to place a call and wish to retry the call, press **(SND)** before ending the unsuccessful call attempt. *rEd ,AL* is then displayed.

Your phone will make the call attempt continuously over the next four minutes. Once a connection is made, the phone will ring once to alert you so that you may lift the phone to your ear and begin the conversation. You do not have to press **(SND)** to answer the call.

If four minutes is insufficient time, press **(SND)** to begin another cycle. You may terminate Automatic Redial by turning off the phone, or by pressing **(END)**.

NOTE *Automatic Redial applies only if the cellular system is busy, and will not engage when the called party's line is busy.*

Ending a Call

Press **(END)**.

The green *IU* will extinguish.

Receiving a Call

When you hear the ring tone indicating an incoming call, press **(SND) to answer the call.**

NOTE *Your phone is equipped with an Automatic Answer feature that allows you to answer calls without pressing **(SND)**. Refer to "Automatic Answer" on page 23 for details.*

NOTE *Pressing **(SND)** may activate call transfer or other optional system features. Contact your Cellular System Provider for more information.*

NOTE *If you have subscribed to Calling Line ID, the calling party's phone number (if available) will appear in the display. Refer to "Calling Line ID" on page 26 for details on the Calling Line ID feature.*


Call In Absence Indicator

If your phone is on and an incoming call is unanswered, **CALL** is displayed for 16 seconds. The display and keypad backlight will then extinguish to conserve the battery level. Pressing any key but **CLR** or **END** redisplay **CALL** to inform you of the call attempt. You must press **CLR** or **END** to cancel the message and clear the display.


NOTE Unless you have subscribed to Calling Line ID, the phone will not display or retrieve the phone number of the calling party.

Signal Strength Meter

The Signal Strength Meter (SSM) indicates the relative strength of the signal received by your phone. The SSM is displayed as shown below. The **I** alone represents the lowest strength, with each additional **)** representing a stronger signal.



Weak Signal



Strong Signal


The SSM appears every time you turn your phone on. After the display blanks out (after about 16 seconds), the SSM will “strobe” to indicate that the phone is on. To redisplay the SSM press any key.

To best utilize the SSM, you should familiarize yourself with the relative signal strength levels and their associated call placement and call-in-progress qualities.


Any messages, such as **Loc'd**, appearing in the display as a result of activation of a feature will take priority over SSM. You will not see the SSM displayed in these cases.

Volume Meter

The Volume Meter represents the current volume setting and is displayed whenever you adjust the earpiece or ringer volume. The volume level is displayed as a bar graph following the letter **U** at the left side of the display. The **U** alone represents the lowest volume setting, with each additional bar representing a higher volume setting.



Lowest Volume



Highest Volume

Adjusting Earpiece Volume

Press and hold **▲** to raise the volume level. Press and hold **▼** to lower the volume.

Adjusting Ringer Volume

1. Press **FCN**.
2. Press and hold **▲** to raise the volume level. Press and hold **▼** to lower the volume.

Low Battery Warning

Low battery power is indicated by a short dual-tone alert repeated periodically, and the displayed message **Lo BAT**. As the battery approaches discharge, the unit will automatically turn itself off.


Battery Voltage Meter

Press **FCN**, **4**.

The Battery Voltage Meter (BVM) represents the current voltage level of the battery being used. You can use this to estimate the amount of battery capacity remaining. The BVM is displayed as a bar graph following the letter **b** at the left side of the display. Note that three battery symbols (**■ ■ ■**) are also provided to indicate the relative battery level whenever the display backlighting is on.



Low Battery



Charged Battery

NOTE Variables such as temperature, battery age, and charging conditions may affect battery voltage.

About Memory

Your phone provides a numeric memory in which to store frequently called phone numbers. The memory will accept entries designated by location numbers 01, 02, etc. Calls are placed from within memory by pressing **[SND]** when the number is displayed. Each memory location accepts up to 16 phone number digits.

The next two sections describe how to store numbers in memory and how to place calls from memory. Before setting up your memory, we suggest you read the rest of these sections to become familiar with the ways in which you will access and use it.

Storing a Phone Number

1. Enter the phone number you wish to store (up to 16 digits).
2. Press **[STO]**.
3. Enter a two-digit location number (e.g., **[0]** **[1]**, **[0]** **[2]**, etc.).
4. The location entered is displayed to confirm storage.

NOTE If *FULL* displays, refer to "Memory Protect Feature" on page 13.

Storing an Area Code and Prefix (Postscripting)

1. Enter the area code and prefix you wish to store.
2. Press **(STO)**.
3. Enter a two-digit location number (e.g., **(0)** **(1)**, **(0)** **(2)**, etc.).
4. The location entered is displayed to confirm storage.

NOTE If *FULL* displays, refer to “Memory Protect Feature” below.

Storing an area code and prefix for a frequently called location (such as an office) offers a convenient means of “postscripting” the four-digit extension of the party you wish to call.

To place a call using postscripting, see “Recalling Area Code and Prefix (Postscripting)” on page 17.

Memory Protect Feature

The directory has an automatic memory protect feature which prevents the accidental overwriting and loss of previously stored numbers in memory. If you attempt to store an entry to a currently occupied memory location, the location number and *FULL* will display. The display will then alternate between the previously stored number and *CHANGE*.

If you wish to save to that location, thus overwriting and erasing the old information, press **(STO)**.

If you wish to store the entry in an alternate location, press **(END)**, **(STO)** and the alternate location number.

Deleting a Memory Entry

1. Press and hold **(CLR)**, then press **(STO)**, and enter the two-digit location number you wish to delete.
2. The phone will display *FULL*, flash the number in memory, followed by *CHANGEP*.
3. Press **(STO)** to delete, or press **(END)** to exit without deleting the entry.

Changing a Memory Entry

1. Press **(RCL)** and the two-digit location number so that the number to be changed is displayed.
2. Repeatedly press **(CLR)** to “back out” each of the digits displayed (all the digits, or just the ones you wish to change).
3. Enter the new digits.
4. Press **(STO)** and the same two-digit location number.
5. The location number and *FULL* will display. The display will then alternate between the currently stored number and *CHANGEP*.
6. Press **(STO)** to save the newly entered number in this memory location, overwriting the currently stored number.

About Recalling from Memory

Phone numbers stored in memory can be recalled in either of the following two ways:

- By entering a two-digit location number
- By scrolling using the Memory Location Numbers

Using any of these methods, once a phone number is displayed, you may place a call to that number by pressing **(SND)**.

NOTE *You may also scroll through the memory locations while in a call (for instance, if you want to look up a phone number to pass along to the other party). When finished, press **(END)**. This will cancel scrolling, but will not end your current call.*

Placing Calls by Entering Two-Digit Number

1. Press **(RCL)**.
2. Enter the desired two-digit location number. The display shows the location number, then the last 10 digits of the stored phone number. Press **(RCL)** again to view the complete number.
3. Press **(SND)** to place a call to the number stored at the two-digit memory location.

Placing Calls by Scrolling

This method allows you to review your memory locations by memory number, beginning with the location of your choice. This is useful when searching for a specific number in memory when you are not certain of its location.

1. Press **RCL**, then the two-digit memory location number where you wish to begin your review. (For example, to scroll from the beginning, press **RCL**, **0**, **1**.)
2. The location number and digits stored will appear in the display. An apostrophe (') following the location number confirms that you have enabled memory scrolling.
3. Press **#** to scroll forward thru the memory locations. Press **↔** to scroll backwards.
4. At any time while scrolling, you may press **SND** to place a call to the displayed number.

NOTE *Memory Scrolling may also be performed during a call. Pressing **END** while scrolling during a call extinguishes the apostrophe (') and cancels scrolling, but does not terminate the call.*

Last Number Redial

Press **[SND]** to place a call to the last number entered.

This feature automatically remembers the last phone number entered from the keypad or recalled from memory, but not actually placed (by pressing **[SND]**).

Recalling Last Number Called

1. Press **[RCL]**, **[0]**, **[0]**. The display will show the last number called.
2. Press **[SND]** to place a call to this number.

Recalling Area Code and Prefix (Postscripting)

1. Recall two-digit location number where an area code and prefix is stored.
2. Add additional digits as needed.
3. Press **[SND]**.

You can append additional digits to recalled numbers by entering them before pressing **[SND]**. This is particularly useful if you often place calls to the same area code and prefix.

Turbo Dial Feature

Press and hold either of the Turbo Dial keys **[2]** through **[9]** for one second.

Once numbers have been stored in Memory Locations 02 through 09, calls can be placed from these numbers by pressing and holding the associated key for approximately one second. A call will be placed to the phone number stored in that memory location, but the number will not be displayed. There is no need to press **[SND]**.

NOTE Memory Location 01 is reserved for Priority Calling (if the Priority Call feature is enabled; refer to "Selecting and Deselecting Features" on page 31).

Priority Call

Press **[1]** and hold to automatically place a call to the priority number stored in location 01.

When Priority Call is activated on your cellular phone you can use this feature to call an important number you have stored in memory location **[1]** even if the phone is locked.

At any time if you dial 911 or an emergency number previously stored by your cellular service provider, the display will read "dIAL INg EMrgncy." If the unit is locked and you press and hold the **[1]** or enter an emergency number, the phone will still display "LocEd" but will place the emergency call.

If you have stored an alternate non-emergency number in memory location 01, such as your home phone number, and press and hold **[1]** the phone will display "Priority CALL."

Please keep in mind:

- Your emergency or priority number must be stored in memory location 01 to be able to place a call when the unit is locked. Be careful not to overwrite the number stored in this location.
- Some cellular systems have their own emergency numbers and do not allow access to numbers such as 911. Check with your cellular service provider for details about emergency calling in your area.

Super Speed Dial Feature

1. Enter the memory location number.

2. Press **[SND]**. The number will not appear in the display.

All memory locations are equipped with the Super Speed Dial feature. Once information is stored in these locations, the Super Speed Dial feature allows you to place a call without pressing **[RCL]**.

NOTE The sequence **[0]**, **[SND]** will place a call to the local operator.

Scratch Pad Memory

The scratch pad permits entry of numbers from the keypad during conversation.

If your party gives you another number to call, simply enter this from the keypad. If you make an error, press **(CLR)** to erase the last digit entered, or hold **(CLR)** to erase the entire entry.

Advise your party that they will hear tones as you enter the number. To call the scratch pad number at the end of an ongoing conversation, press **(END)**, **(SND)**.

Two-Part Tone Dialing

Your phone provides the standard Dual Tone Multi-Frequency (DTMF) signals typically used to access alternate long distance services, signal pagers, answering machines, etc. Generally, these services use a two-part procedure: First, a call is placed from memory or by using the keypad to a central telephone number. Then, you either receive a secondary dial tone, or are prompted to enter additional digits, such as a pager number, calling card number, etc.

To tone dial from the keypad, make the initial call, either from memory or by using the keypad. When prompted, enter additional tone digits using the keypad. The tones are automatically sent as you press the keys. Do not press **(SND)**.

To tone dial from memory, make the initial call, either from memory or by using the keypad. When prompted, recall from memory (using **(RCL)**, location number) the number you wish to send as DTMF digits. Press **(RCL)**, **(SND)**. Repeat these steps as required to send additional groups of numbers.


Memory Linking

The Memory Linking feature provides improved convenience when dialing constant number sequences, such as when accessing paging systems, retrieving voice mail, etc. It allows multiple number groups (e.g., main number, PIN, and account number) to be stored in a single memory location, each group separated by a pause (⏸). Pauses are created by pressing **(FCN)**, **(SND)**. You may then place a call using this memory location, and sequentially transmit each number group (by pressing **(RCL)**, **(SND)**) at the appropriate system prompt.

Example of Memory Linking

In the following example, a Memory Linked number is created to access information for a bank account. The number consists of the bank's telephone number (123-4567), a PIN number (888) and # sign, and an account number (22) and # sign, as shown below.

NOTE A maximum of 16 digits can be stored in a memory location. A pause counts as one digit. If your Memory Linked number requires more than 16 digits, you can store part of the number in one memory location (e.g., the main access number) and the remainder in another memory location.



Advanced Memory Dialing Features

To construct the Memory Linked number, perform the following steps.

Instruction and Key Sequence	Display
1 Enter the bank's telephone number — (1), (2), (3), (4), (5), (6), (7) or recall it from memory location xx — (RCL), x, x	1234567
2 Create a pause — (FCN), (SND)	2345670
3 Enter the PIN number and # sign — (8), (8), (8), (#)	345 670888C
4 Create another pause — (FCN), (SND)	456 70888C0
5 Enter the account number and # sign— (2), (2), (#)	708 88C022c
6 To store the number, press (STO) and the two-digit location number.	

Now that the Memory Linked number has been created and stored in memory, you may place the call as follows.

1. Press (RCL), 2-digit location number, and (SND). (Your phone will send the bank's phone number, and then wait at the first pause.)
2. When the system answers and prompts you for your PIN number, simply press (RCL), (SND) to transmit your PIN number and # sign.
3. When the system prompts you for your account number, press (RCL), (SND) again to transmit your account number and # sign.

NOTE If the PIN code feature is activated (see "PIN Code Operation" on page 29), the PIN code will automatically

Advanced Memory Dialing Features

be sent after the first pause by pressing **[SND]**. Do not add your PIN code to the linked sequence.

NOTE If you have divided your Memory Linked number into two memory locations (e.g., 03 and 04), place the initial call by pressing **[RCL]**, **[0]**, **[3]**, **[SND]**. When the system answers and prompts you, press **[RCL]**, **[0]**, **[4]**, **[RCL]**, **[SND]** to send the first number group (up to the pause). Press **[RCL]**, **[SND]** to send each remaining number group stored in location 04.

NOTE Some electronic systems require that DTMF tones be sent for several seconds by pressing and holding a key. These signals, known as Long Tone DTMF, cannot be transmitted using Memory Linking. If Long Tone DTMF signals are required, you must send them manually.

Display Own Phone Number

1. Press **RCL**, **#**.
2. Your phone number will be displayed.
3. When you have finished viewing, press **CLR**.

Microphone Muting

To mute microphone

While in a call, press **FCN**, **6**.

To disable mute

Press **FCN**, **6** again.

This feature allows you to confer privately with others in the car during a call. It will disable the microphone and display **FMUTE**. The mute feature is canceled when you end your call.

Automatic Answer

This feature allows you to answer calls without pressing **SND**. When your phone receives a call, it will ring twice and then the **In Use** indicator will illuminate to let you know that the call has been automatically answered and is live. Simply lift the phone to your ear and begin the conversation.

To enable/disable the Automatic Answer feature, refer to "Selecting and Deselecting Features" on page 31.

One Minute Beep

This feature allows your phone to emit an audible tone ("beep") ten seconds before the end of each minute during calls.

To enable/disable the One Minute Beep feature, refer to "Selecting and Deselecting Features" on page 31.

Multiple Key Answer

This feature allows the user to answer an incoming call by pressing **[SND]**, either volume button, or any other digit key after the first ring has been completed.

To enable/disable the Multiple Key Answer feature, refer to "Selecting and Deselecting Features" on page 31.

Hands Free Operation

When using a vehicular accessory you can carry on conversations in Hands Free mode. Hands Free mode allows your cellular phone to operate like an office speakerphone. A microphone picks up your voice, while the called party's voice is heard through an external speaker. Your entire conversation can be carried on without having to take your hands off the wheel. See the DHFA instructions (supplied with DHFA option) for details.

Distinctive Ringer

This feature allows you to select from any of 9 ringer styles to help you distinguish your phone's ringer from those of other phones. To select a ringer style:

1. Press **[FCN]**, **[1]**.
2. Scroll through the menu (using **[#]** or **[*]**) until *ringer and STYLE 1-9* alternate in the display.
3. Press **[STO]**. A brief sample of the ringer style currently selected will be heard, and the display will show *SELECT*, then *1-9*.
4. Press **[1]** thru **[9]**, or use **[#]** or **[*]** to scroll through the ringer styles. A brief sample of the ringer style will be heard as you make each selection, and the display will show the number of the selected ringer style.
5. When you hear the ringer style you wish to select, press **[STO]**. The display will display *ringer and 1-9 SET*.
6. Press **[END]** to exit the Feature Menu.

Multiple Language Display

This feature allows you to select in which language (English, French, Spanish, and Portuguese) your phone will display messages and prompts. To select a language:

1. Press **(FCN)**, **(1)**.
2. Scroll through the menu (using **(#)** or **(*)**) until **SELEct** and **LANGuAG** alternate in the display.
3. Press **(STO)**. The language currently selected will be displayed (for example, **EngL ish**).
4. Press **(#)** or **(*)** to scroll through the languages (**EngL ish**, **ESPAñOL**, **FrAnc**, **Portug**).
5. With the language you wish to select displayed, press **(STO)**. **SELEct** and **LANGuAG** will alternate in the display in the language you have selected.
6. Press **(END)** to exit the Feature Menu.

Extended Talk Time

The Extended Talk Time feature is useful when operating your phone in strong signal areas (i.e., not in fringe areas of cellular coverage). When enabled, this feature minimizes the signaling communications between your phone and the cellular system, thus substantially extending your battery's charge and providing you with extra talk time. To enable/disable the Extended Talk Time feature, refer to "Selecting and Deselecting Features" on page 31.

About Special System Features

Some Cellular Service Providers offer enhanced features for your cellular phone. Contact your Cellular Service Provider to see if these features are available in your area, and to receive any necessary support in using them (such as assignment of a PIN code).

NOTE *If these features are not supported by your Cellular Service Provider, selecting them will have no effect.*

Calling Line ID

Your *Profile* phone features Calling Line ID, which allows the phone number of the calling party to be displayed in the handset (when receiving a call).

The Calling Line ID numbers are stored in the message center (a special memory in your phone), which can store up to 20 phone numbers.

NOTE *You must subscribe with your Cellular Service Provider for the Calling Line ID service.*

Receiving Calls with Calling Line ID

When receiving a call that includes Calling Line ID information, the phone number of the calling party will appear in the display, letting you know who the calling party is before you answer the call. Press **[SND]** to answer the call. (Note that if you should miss the call, **[CALL]** will remain in the display.)

NOTE *Not all calls include the Calling Line ID information. If you receive a call that does not include this information, **[PRIVATE]** or **[NO ID]** will be displayed.*

Each time you receive a call that includes Calling Line ID information, the information is stored as a message(s) in the message center. Messages are stored with the most recent message in location #1 and the oldest message in the highest occupied location in the message center. When a new message is received and the message center is full,

the oldest message is deleted, the rest of the messages are shifted down one location, and the new message is stored in location #1.

Recalling/Viewing Calling Line ID Messages

1. Press **[RCL]** and release, then press **[RCL]** again and hold until one of the following messages appears in the display:

HH nELU (HH is the number of new messages)

00 nELU (when there are no new messages)

no n7E555 (when there are no old or new messages)

2. Scroll through the messages in the message center by pressing **[#]** to move forward and **[*]** to move backward.
3. Press **[END]** to exit the message center.

As you scroll through the messages, each Calling Line ID message will be labeled with either *HH nELU* (new message) or *HH L id* (old message), where *HH* is the message center location number. As you view each message, the display will cycle through the Calling Line ID information (as shown in the following example) until you scroll to the next message or place a call to the displayed number.

Example *1847555 12 12*

Placing a Call to a Calling Line ID Number

After recalling the desired Calling Line ID number (the number appearing in the display), press **[SND]** to place a call to this number.

Storing a Calling Line ID Number in Memory

With a Calling Line ID message displayed, press **(STO)** and select a memory location (as described in “Storing a Phone Number” on page 12). The Calling Line ID number will be stored in the selected location.

Deleting an Individual Message

1. While in the message center, scroll through the messages using **(#)** and **(X)** until the message you wish to delete is displayed.
2. Press and hold **(CLR)** until *deleted* appears in the display.

After deleting a message, the message center will be automatically renumbered. For example, if message #5 is deleted, messages #6 through #20 will be moved up one to become #5 through #19.

Deleting All Messages

1. While in the message center, press and hold **(CLR)** until *ERASE* and *ALL?* alternate in the display. (The display will briefly show *deleted* before *ERASE* and *ALL?* appear.)
2. Release **(CLR)**, then press **(CLR)** again to confirm erasing all of the messages. *17595 ERASEd* will appear in the display.

Other Messaging Services

In addition to the Calling Line ID feature, some cellular systems allow other types of messages to be sent to your cellular phone. One such service is **Voice Mail Notification**. This service provides a notification message to the your cellular phone each time a new message is recorded in the Voice Mail system. Voice mail notification messages are stored in the same message center that stores your Calling Line ID numbers.

Contact your Cellular Service Provider for more information and availability of these messaging services.

VOX Operation

Voice Operated Transmission (VOX) is a method of conserving battery power by activating the phone's transmitter only while talking. In this manner, your battery's charge can be extended.

To enable/disable the VOX feature, refer to "Selecting and Deselecting Features" on page 31.

Reminder Beeps

If your phone has Calling Line ID or Voice Mail Notification services, the Reminder Beeps feature is an audible notification to alert the user that they have received a message. It will beep every 2 minutes until the new messages have been read.

To enable/disable the Reminder Beeps feature, refer to "Selecting and Deselecting Features" on page 31.

PIN Code Operation

Overview

Your Cellular Service Provider may require a Personal Identification Number (PIN) when placing outbound calls. This PIN assures the cellular system that the person placing the call is an authorized user.

If PIN operation is required in your system, you must enable PIN Code operation as described in "Selecting and Deselecting Features" on page 31.

Placing a Call using PIN Operation

- 1. Enter the number you wish to call, or recall the number from memory.**
- 2. Press **[SND]**.**
- 3. Wait for the system prompt (usually a "Beep Beep").**
- 4. Enter your PIN Code number (provided by your Cellular Service Provider).**
- 5. Press **[SND]**.**

NOTE Your phone is designed with a “shortcut” method for dialing the PIN Code number. Simply store your PIN Code number (supplied by your Cellular Service Provider) in **memory location 07** (as described in “Storing a Phone Number” on page 12). Then, you may simply press **[SND]** after hearing the system prompt (for example, some systems use a double tone) when placing calls; your phone will automatically send the PIN Code number stored in memory location **07**. Using this shortcut method, you will not have to enter your PIN Code number each time you place a call.

A maximum of 7 digits are allowed. (Remember – Do not store any other number in memory location **07** once you have stored your PIN number.)

About the Feature Menu

The Feature Menu allows you to review and select/deselect most of your phone's features through the keypad and display. The table below shows all features available through the menu and the pages where detailed information is found.

Note that telephones ship from the factory with default settings whereby most features are in the canceled (or OFF) position.

NOTE *There are additional features that may be available with your phone that are not accessed through the feature menu. These features are described throughout this manual.*

Selecting and Deselecting Features

1. Press **(FCN)**, **(1)** to enter the Feature Menu.
2. Scroll the menu by pressing **(*)** or **(#)** until the desired feature is displayed.
3. Press **(CLR)** to turn the feature off, press **(STO)** to turn the feature on.
4. Press **(END)** to exit the Feature Menu.

EXAMPLE To activate Automatic Answer, press **(FCN)**, **(1)** and scroll using **(*)** or **(#)** until **Auto** and **AnsOFF** alternate in the display.

Press **(STO)** to activate this feature. The display will then alternate between **Auto** and **Ans_On**.

Press **(END)** to exit the menu.

Alternate in Display (as shipped from factory)	Feature	Page
<i>ONE MIN and EXT OFF</i>	One Minute Beep <i>Phone emits a tone ten seconds before the end of each minute during a call.</i>	23
<i>INDIC and EXT OFF</i>	Automatic Display Timer <i>Displays the accumulated time in minutes and seconds during and after a call.</i>	37
<i>ringer and STYLE 1-9</i>	Distinctive Ringer <i>Allows you to select from 9 ringer styles to distinguish your phone's ringer from other phones.</i>	24
<i>Auto and ANS OFF</i>	Automatic Answer <i>Automatic answer allows phone to answer calls automatically, without pressing (SND).</i>	23
<i>PT KEY and ANS OFF</i>	Multiple Key Answer <i>Allows you to answer an incoming call by pressing any key.</i>	24
<i>Auto and LOCK OFF</i>	Auto Lock <i>Locks phone each time phone is turned off.</i>	39

<i>Alternate in Display (as shipped from factory)</i>	<i>Feature</i>	<i>Page</i>
<i>PRIORITy and CALL On</i>	Priority Call <i>When enabled, you may use 1 to place a one button call to a priority number stored in Memory Location 01, even when the phone is locked.</i>	18
<i>VOX and OFF</i>	VOX mode <i>Conserves battery power by causing phone to transmit only while talking.</i>	29
<i>EXTEnd and TALK On</i>	Extended Talk Time	25
<i>REM ind and MSG On</i>	Reminder Beeps <i>When enabled, audible beeps alert user that one or more messages have been received (available in some models).</i>	29
<i>SELEct and LANGUAGE</i>	Language Select <i>Allows you to select English, French, Spanish or Portuguese text for prompts appearing in the display.</i>	25

<i>Alternate in Display (as shipped from factory)</i>	<i>Feature</i>	<i>Page</i>
<i>P in and inRct u</i>	PIN Code Operation <i>When used in a Cellular System supporting this feature, requires a Personal Identification Number to be dialed when placing outbound calls (to provide additional system security).</i>	29

Status Review

1. Press **FCN**, **0**, **9**, **RCL**.
2. Scroll thru the messages by pressing **✕** or **#** to view the features that you have changed from the factory default settings.
3. Press **END** to exit the feature status review.

Feature status review allows you to scroll thru the list of features that you have changed from the factory default settings (shown in previous table). If no features have been changed from the factory settings, *Std* will be displayed.

Alternate in Display <i>(if changed from factory defaults)</i>	Description
<i>P in and Act iUE</i>	PIN Code operation is enabled
<i>rEPn ind and nns9OFF</i>	Reminder Beeps is disabled
<i>OnEPn in and tPnr On</i>	One Minute Beep is enabled
<i>Auto and Lock On</i>	Auto Lock is enabled
<i>Priority and CALLOFF</i>	Priority Call is disabled
<i>uOH and On</i>	VOX mode is enabled
<i>EHtEnd and tRLt On</i>	Extended Talk Time is enabled
<i>Auto and Ansr On</i>	Automatic Answer is enabled
<i>n KEY and Ansr On</i>	Multiple Key Answer enabled
<i>ind iU and tPnr On</i>	Automatic Display Timer is enabled
<i>r in9Er and StYLE 1-9</i>	Distinctive Ringer is available

About Timers

Call timers provide a useful means of monitoring the air-time spent in conversation. Your phone is equipped with three timers, resettable, individual, and cumulative. These timers operate in the background and can be displayed at any time. Each timer begins counting as a cellular channel is assigned, or when the phone rings to signal an incoming call. If an incoming call is not answered, the timers revert to their previous values.

Individual Call Timer

To Display

Press **RCL**, **##**, **##**

This timer accumulates the air-time of a call in minutes and seconds. It automatically resets before a new call is placed and when the phone is turned off.

Resettable Call Timer

To Display

Press **RCL**, **##**, **##**, **##**. **RESETBL** alternates in display.

To Reset

Press **FCN**, **0**, **7**, **CLR**

This timer accumulates the air-time of all calls in minutes from the point at which it is reset. This resettable timer is generally used to track monthly air-time usage and is set in conjunction with the monthly billing cycle.

Cumulative Call Timer

To Display

Press **RCL**, **##**, **##**, **##**, **##**. **CUMTUL** alternates in display.

This non-resettable timer accumulates the phone's total air-time in minutes, starting with the initial factory setting.

Automatic Display Timer

This feature allows your phone to display (in minutes and seconds) the accumulated time during and after each call.

To enable/disable the Automatic Display Timer feature, refer to “Selecting and Deselecting Features” on page 31.

About Security Codes

Your phone offers several forms of security features against unauthorized use. Activating these features requires either your three-digit unlock code, or the six-digit security code. The factory programmed unlock code is **123** and the factory programmed security code is **000000**.

NOTE *It is common for the unlock code to be the last 3 digits of your phone number when it is programmed by your Service Provider.*

Electronic Lock

To Lock

1. Press **(FCN)**, and hold **(5)**.
2. **Loc 'd** will display.
3. Press **(STO)** to lock your phone, or press **(END)** to exit without locking your phone.
4. **Loc 'd** will display and the green indicator will light steadily.

NOTE *You must press and hold **(5)** until **Loc 'd** appears in the display. This is a safety feature to prevent you from accidentally locking your phone.*

To Unlock

Enter your three-digit unlock code. If you make an error, press **(CLR) and start again.**

The electronic lock prevents use of the phone by disabling both incoming and outgoing calls.

If a call is received while your phone is locked, the phone will ring and you must enter the unlock code before the call can be answered.

Displaying the Unlock Code

1. Press **(FCN)**, **(0)**.
2. Enter your six-digit security code.
3. Press **(RCL)**. The phone will display *LocCode* and your three-digit unlock code.

Changing the Unlock Code

1. Press **(FCN)**, **(0)**.
2. Enter your six-digit security code.
3. Enter the new desired three-digit unlock code.
4. Press **(STO)**. *CHANGED to* and the new unlock code will display to confirm storage.

Automatic Lock

This feature automatically locks your phone each time you turn your phone off. When locked, your phone still rings while receiving an incoming call, but you cannot answer the call until you have entered the unlock code.

To enable/disable the Automatic Lock feature, refer to "Selecting and Deselecting Features" on page 31.

Setting Outgoing Call Restrictions

1. Press **(FCN)**, **(0)**.
2. Enter your six-digit security code.
3. Enter the number of the service level (1 or 4) you wish to use.
4. Press **(STO)**. The phone will display *SERVICE LEVEL* and the number selected.

Your phone can be set to restrict call placement (as when lending the phone to another person). Using the six-digit security code, you may select one of the following two levels of restriction.

<i>Description</i>	<i>Display</i>
No restrictions. (Standard setting)	LEVEL 4
Phone will place calls only from memory locations 1 thru 10 (RCL, 0 1 - 1 0, SND). If locations 1-10 are cleared, no outgoing calls can be made. No keypad dialing. No directory storage. No Turbo Dial or Super Speed Dial features.	LEVEL 1

To change the phone to unrestricted operation, use the procedure above and enter service level 4.

Cellular System Overview

There are generally two types of cellular systems serving any metropolitan area. One of these will most likely be operated by the telephone company that provides telephone service to your community, generally referred to as a wireline carrier. The other cellular service provider is a radio common carrier, referred to as a non-wireline carrier. Your Cellular Service Operator will provide information concerning specific features, procedures, and coverage in your particular area.

Service Area

The area within which the phone operates is defined by your cellular service provider. Since this is a radio system, no exact boundaries (as on a map) can be drawn. The red **NS** (No Service) flashes if you are beyond range of a service area. There may be locations within your area, such as tunnels and underground parking facilities, where the unit may act as if it were beyond range.

Weak Signal Alert

If you are called in a location the system determines is inadequate for high quality service, you may hear series of beeps to inform you of the call attempt. The caller will receive the recorded "Not In Service" message. **[RLL]** will appear in the display, and the green on indicator will flash quickly. If this occurs, you must press **[CLR]** before the phone will operate. Most systems do not impose air-time charges for such call attempts.

NOTE *This indicator is controlled through the initial programming of your phone. Refer to the Programming Guide for more details.*

Switchhook and Advanced System Services

Press **SND**.

During a call, pressing **SND** performs a switchhook function used to access enhanced Cellular System features such as call waiting and conference calls. For the functioning of these features with **SND**, consult your Cellular Service Provider.

Roaming

The term "Roaming" applies to the use of cellular telephones within systems other than those designated as their "Home" systems. **RM** (Roam) lights whenever the phone comes within range of a visited system. As your phone begins to roam, it seeks service according to the conditions you have selected (see "Reviewing / Changing Scanning Mode" on page 44).

Contact your system operator, or that of the visited system, for information on dialing and billing procedures.

To use alternate long distance services when roaming, be certain to dial the appropriate area code and local number to access the alternate carrier in the visited area. Then use the tone dialing sequence described on page 19. If you selected Two-System Operation (see "Two-System Operation" on page 43), enter **RCL**, **#** to verify the currently active number. This is especially important if your two home systems have different area codes, or if **RM** is flashing within your home service area.

Two-System Operation

Your cellular telephone is equipped with a feature that allows you to maintain two telephone numbers from two different system operators. Both are designated as your 'home system' but are accessed separately. At the time your phone was programmed, you elected whether to enable this feature and which two systems would be treated as your home systems.

While you may switch from one system to the other, only one of the two can be active at any given time. Calls are placed and received through the active system only.

To switch from one system to the other:

1. Press **RCL**, **#**, **STO**.
2. The display will blank to confirm the switch and the newly activated number will appear.
3. When you have finished viewing, press **CLR**.

If you have two phone numbers programmed into your phone, each time the phone is turned on, it displays a message indicating which home system type and phone number is currently active. Possible messages are as follows:

<i>System Type and Phone Number</i>	<i>Display</i>
Non-wireline (A type) with phone number 1	<i>A 1</i>
Non-wireline (A type) with phone number 2	<i>A 2</i>
Wireline (B type) with phone number 1	<i>b 1</i>
Wireline (B type) with phone number 2	<i>b 2</i>

If a call is placed to the inactive phone number, the caller will receive the "Not in Service" message.

Overview

The characteristics that determine the way your phone operates in the Cellular System are determined by the Scanning Mode programmed for your phone.

Reviewing / Changing Scanning Mode

Typically, the scanning mode for your phone is programmed by your Service Provider. However, you may review the current scanning mode and (if desired) change it by following these procedures.

To Review Scanning Mode

1. Press **RCL**, **✖**. The display will show the current active system choice.
2. Press **END** to exit without changing selections.

To Change Scanning Modes

1. Press **RCL**, **✖**. The display will show the current active system choice.
2. Repeatedly press **✖** or **#** to cycle through the scanning modes.
3. When the desired scan setting appears in the display, press **STO**.
4. Press **END** to exit to normal operation.

NOTE Constant flashing of **RM**, or a steadily lit **NS** while within your home service area may indicate an unintentional choice has been made. If this occurs, review the System Type to see if the unit is operating in Standard Mode, or if an alternate selection has been made.

Scanning Modes

The following table lists the scanning modes available for your phone.

Scanning Mode	Display
Standard Mode Your phone first seeks a home type system, then a non-home type. If home system is <i>non-wireline</i> (type A) If home system is <i>wireline</i> (type B)	Std Ab Std bA
Invert Preference Mode Your phone first seeks a non-home type system. (Select this mode if in a fringe area of your home system or in certain roaming situations.) If home system is non-wireline (type A) Flashing RM = call on B system Flashing IU = call on home system If home system is wireline (type B) Flashing RM = call on A system Flashing IU = call on home system	SCAn bA SCAn Ab
Home Only Mode Phone will not operate outside its home system.	HOME
Scan A Mode Phone will operate only within non-wireline (A) systems.	SCAn A
Scan B Mode Phone will operate only within wireline (B) systems.	SCAn b

Programming Scanning Modes

Scanning Mode	Display
Enhanced Preferred Scanning Mode Phone will scan for home or programmed preferred SIDs first. This choice requires entry of up to 60 System ID numbers for those systems in which you wish to operate. Contact your Cellular Service Provider for SID information.	P SCAN

If you have selected two system operation, the phone seeks cellular service according to the system type mode selected for each phone number.

NOTE In order to program Preferred SIDs to be used in P SCAN mode, press **7**, **9**, **7**, **4**, **3** (spells SYSID), then press **FCN**, **FCN** and enter the appropriate 5-digit SID number (from your Cellular Service Provider), then press **STO**. Now press **✕** or **#** to cycle through the system type choices (HDPPE, rDPPE, or HDPPE). With the desired system type displayed, press **STO** to select that choice. To program another Preferred SID, press **#** and repeat the above process, or press **END** to exit Preferred SIDs programming.

Before Calling For Service

Is the phone locked?

See Electronic Lock, page 38.

Is NS (No Service) lit?

See "Start-up Status Indicators" on page 5.

Have you charged the battery?

Refer to "Prepare the Battery for Initial Use" on page 1 for charging instructions.

Have you programmed a unique operating mode?

Constant flashing of *RM* while in your home service area may indicate that an incompatible System Type has been selected. Refer to "Reviewing / Changing Scanning Mode" on page 44.


Is the phone operating with non-standard settings?


You may have inadvertently selected improper operating characteristics. See Feature Menu, page 31.

Have you selected the wrong home system?

If your phone is programmed for Two-System Operation (see page 43), press **[RCL]**, **[#]** to display the active telephone number.

Are new Profile accessories not working with older Profile phones?

Because of increased charging capabilities designed into your new Profile  phone, some accessories that plug into the data connector will not fit older versions of Profile phones.

NOTE Older versions of Profile charging accessories that plug into the data connector may not charge new Profile  phones.

Regulations and Precautions

The U.S. Federal Communications Commission and the Canadian Department of Communications regulate cellular radiotelephone service in their respective countries. It is important for you, the *Profile* phone user, to observe the applicable regulations when operating your phone in either country. In addition to these U. S. and Canadian federal regulations, you may also be bound by certain state, provincial, territorial, and local rules and regulations, as well as by your cellular carrier's tariff (the rates, terms, and conditions of its service). If you wish to use your phone in both the U.S. and Canada, please consult with your system operator.

Furthermore, you should remember that your *Profile* phone is a radiotelephone system (i.e., it combines both wireline technology, as used in your home or office telephone system, and radio technology), and that the scope of regulations and precautions is therefore broader than the scope of regulations and precautions relating to wireline-only telephone usage.

Some of the major points of consideration are set out below. Please note, however, that this "Rules, Regulations, and Precautions" section does not constitute legal advice, and is intended merely for general information purposes. If you have any specific questions, please contact your Cellular Carrier (System Operator).

License - If your home system is in the U.S., you do not require a separate license to operate your *Profile* phone; obtaining a cellular telephone access number is sufficient to register you as a user. If your home system is in Canada, a separate license is required. Your carrier will assist you in the licensing process. If you wish to use your *Profile* phone in both the U.S. and Canada, please contact your Cellular Carrier (System Operator). Your base should operate in only one location.

Denial of Service - A cellular carrier may deny service temporarily or terminate service for violation of any governmental regulations or of its tariff.

Driving - Your *Profile* phone is considered a cellular telephone. Some jurisdictions prohibit your using a cellular telephone while driving a vehicle. Even if your jurisdiction does not have such a law, we strongly suggest that, for safety reasons, the driver use extreme caution when operating the *Profile* phone while the vehicle is in motion (see "**Driving**" on page vii).


Consumer Responsibilities - Remember that the wireline and radio regulations with respect to harassing calls, false distress calls, obscene language, etc., apply to cellular phone usage.

Privacy - As a telephone user, you have come to assume a certain standard of privacy when you place or receive a telephone call via traditional wireline systems. However, because *Profile* phones utilize radio transmissions to effect calls, the same standard cannot always be assured. While it is unlawful for any unauthorized person to divulge or use any information obtained from intercepting or 'listening in on' conversations intended for others, you should not assume that your conversation is completely secure. Commercially available scanning equipment can permit a third party to monitor the radio channels used for *Profile* phone calls.

Interference - No person shall interfere with or cause interference to any radio communication or signal.

Equipment Modifications - The U.S. Federal Communications Commission has type-approved the model of *Profile* phone which you have purchased, and both have allocated a specific frequency range for cellular service. No changes or adjustments are to be made to your *Profile* phone.

Message Glossary

<i>A1</i>	System "A" phone number 1
<i>A2</i>	System "A" phone number 2
<i>Auto Answer OFF</i>	Automatic Answer feature disabled
<i>Auto Answer On</i>	Automatic Answer feature enabled
<i>Auto Lock OFF</i>	Automatic Lock feature disabled
<i>Auto Lock On</i>	Automatic Lock feature enabled
<i>b1</i>	System "B" phone number 1
<i>b2</i>	System "B" phone number 2
<i>b---==≡≡</i>	Battery Meter
<i>CUMUL</i>	Precedes Cumulative Timer display (also used to display )
<i>CHANGE</i>	Memory Protect is activated to prevent accidental overwriting of a memory location
<i>cid</i>	Calling Line ID number answered (p/o Messaging Services)
<i>deleted</i>	Message in message stack deleted (p/o Messaging Services)
<i>English</i>	English message prompts selected
<i>ERASE ALL</i>	All messages in message stack deleted (p/o Messaging Services)
<i>ESPAÑOL</i>	Spanish message prompts selected
<i>FRANC</i>	French message prompts selected

<i>FULL</i>	All memory locations are full or requested block is unavailable
<i>HOM E</i>	System Type Selection — Home Mode
<i>invalid Location</i>	Memory location chosen for storage of phone number is invalid
<i>LEVEL 1</i>	Call Restriction selected
<i>LEVEL 4</i>	No Restrictions (standard setting)
<i>Low Bat</i>	Low Battery
<i>Loc Code</i>	3-digit Unlock Code is displayed
<i>Locked</i>	Unit is locked
<i>Multiple Key Answer OFF</i>	Multiple Key Answer is disabled
<i>Multiple Key Answer On</i>	Multiple Key Answer is enabled
<i>Messages Erased</i>	All messages in Message Center erased
<i>MUTE</i>	Microphone muted
<i>New</i>	New message(s) received (p/o Messaging Services)
<i>Pin Act on</i>	PIN Code feature enabled
<i>Pin in Act on</i>	PIN Code feature disabled
<i>PRIORITY CALL On</i>	Priority Call enabled
<i>Portug</i>	Portuguese message prompts selected
<i>PSR</i>	System Type Selection — Preferred SID Mode
<i>Resettable</i>	Precedes Resettable Call Timer Display
<i>Redial</i>	Automatic Redial

Reference

<code>REMINDER OFF</code>	Reminder Beeps feature disabled
<code>REMINDER ON</code>	Reminder Beeps feature enabled
<code>RINGER STYLE</code>	Select from 9 ringer styles
<code>SCAN A</code>	System Type Selection (scan non-wireline "A" only)
<code>SCAN Ab</code>	System Type Selection (scan "A" type first, then "B")
<code>SCAN b</code>	System Type Selection (scan wireline "B" only)
<code>SCAN bA</code>	System Type Selection (System Type Selection (scan "B" type first, then "A"))
<code>SELECT</code>	Ringer style chosen
<code>SELECT LANGUAGE</code>	Select language chosen
<code>SET</code>	Ringer style choice confirmed
<code>Send to Redial</code>	Indicates Cellular System is busy and unable to place call
<code>Std</code>	Standard setting
<code>Std Ab</code>	System Type Selection (non-wireline standard mode)
<code>Std bA</code>	System Type Selection (wireline standard mode)
<code>toAL</code>	Number of messages in message stack (p/o Messaging Services)
<code>U _ _ _ _ _</code>	Volume Meter
<code>VOX OFF</code>	VOX Mode feature disabled
<code>VOX ON</code>	VOX Mode feature enabled

Index

A

About Special System Features	26
Advanced System Services	43
Antenna Care	vi
Antenna, extending	4
Automatic Answer	23
Automatic Display Timer	37
Automatic Lock	39
Automatic Redialing.	7

B

Battery Voltage Meter	1
---------------------------------	---

C

Call Attempts, unsuccessful	7
Call, ending.	8
Call, placing	6
Call, receiving	8
Calling Line ID Feature	27
Cellular Operation Safety Information	vi
Changing the Unlock Code	39
Cumulative Call Timer	36

D

Deleting All Messages	28
Deleting an Individual Message	28
Deselecting Features	31
Display own phone number	23
Displaying the Unlock Code.	39
Distinctive Ringer	24
Driving	vii

E

Earpiece	x
Earpiece Volume	10
Electronic Lock	38
Ending a Call.	8

F

Feature Menu	31
Function Keys	xi

H

Hands Free Operation.. . . .	24
Headset Jack	xi

I

Illuminated Keypad	5
Individual Call Timer	36

L

Last Number Recall	17
Last Number Redial	17
Low Battery Warning	10

M

Memory Entry, changing	14
Memory Entry, deleting	14
Memory Linking	20
Messages, recalling/viewing	27
Messaging Services	28
Microphone Muting	23
Mouthpiece	xi
Multiple Key Answer	24
Multiple Languages	25

N

Number Display	x
Numeric Keypad	xi

O

One Minute Beep	23
---------------------------	----

P

Patent Information	62
Placing a Call	6
Placing Call to Calling Line ID Number	27
Postscripting	13
Priority Call	18

R

Recalling from Memory	15
Receiving a Call	8
Receiving Calls with Calling Line ID.	26
Reminder Beeps	30
Resetable Call Timer.	37
Retractable Antenna.	x
Review Scanning Modes	45
Review System Types	45
Ringer Volume.	10
Roaming	42

S

Scratch Pad Memory	19
Scrolling	16
Security Codes	38
Selecting Features	31
Service Area	41
Setting Outgoing Call Restrictions.	39
Signal Strength Meter	9
Start-up Messages	4
Start-up Self Tests.	4
Start-up Status Indicators	5
Status Indicators.	x
Status Review	35
Storing Calling Line ID Number in Memory	28
Storing Numbers	12
Super Speed Dial Feature.	18
Switchhook	42

T

Troubleshooting.	47
Turbo Dial Feature.	17
Two-Part Tone Dialing	19
Two-System Operation.	43

V

Volume Meter	10
VOX Operation	29

W

Weak Signal Alert	41
-----------------------------	----

The U.S. Food and Drug Administration's Center for Devices and Radiological Health Consumer Update on Mobile Phones

FDA has been receiving inquiries about the safety of mobile phones, including cellular phones and PCS phones. The following summarizes what is known--and what remains unknown--about whether these products can pose a hazard to health, and what can be done to minimize any potential risk. This information may be used to respond to questions.

Why the concern?

Mobile phones emit low levels of radiofrequency energy (i.e., radiofrequency radiation) in the microwave range while being used. They also emit very low levels of radiofrequency energy (RF), considered non-significant, when in the stand-by mode. It is well known that high levels of RF can produce biological damage through heating effects (this is how your microwave oven is able to cook food). However, it is not known whether, to what extent, or through what mechanism, lower levels of RF might cause adverse health effects as well. Although some research has been done to address these questions, no clear picture of the biological effects of this type of radiation has emerged to date. Thus, the available science does not allow us to conclude that mobile phones are absolutely safe, or that they are unsafe. However, the available scientific evidence does not demonstrate any adverse health effects associated with the use of mobile phones.

What kinds of phones are in question?

Questions have been raised about hand-held mobile phones, the kind that have a built-in antenna that is positioned close to the user's head during normal telephone conversation. These types of mobile phones are of concern because of the short distance between the phone's antenna--the primary source of the RF--and the person's head. The exposure to RF from mobile phones in which the antenna is located at greater distances from the user (on the outside of a car, for example) is drastically lower than that from hand-held phones, because a person's RF exposure decreases rapidly with distance from the source. The safety of so-called "cordless phones," which have a base unit connected to the telephone wiring in a house and which operate at far lower power levels and frequencies, has not been questioned.

How much evidence is there that hand-held mobile phones might be harmful?

Briefly, there is not enough evidence to know for sure, either way; however, research efforts are on-going. The existing scientific evidence is conflicting and many of the studies that have been done to date have suffered from flaws in their research methods. Animal experiments investigating the effects of RF exposures characteristic of mobile phones have yielded

conflicting results. A few animal studies, however, have suggested that low levels of RF could accelerate the development of cancer in laboratory animals. In one study, mice genetically altered to be predisposed to developing one type of cancer developed more than twice as many such cancers when they were exposed to RF energy compared to controls. There is much uncertainty among scientists about whether results obtained from animal studies apply to the use of mobile phones. First, it is uncertain how to apply the results obtained in rats and mice to humans. Second, many of the studies that showed increased tumor development used animals that had already been treated with cancer-causing chemicals, and other studies exposed the animals to the RF virtually continuously--up to 22 hours per day.

For the past five years in the United States, the mobile phone industry has supported research into the safety of mobile phones. This research has resulted in two findings in particular that merit additional study:

1. In a hospital-based, case-control study, researchers looked for an association between mobile phone use and either glioma (a type of brain cancer) or acoustic neuroma (a benign tumor of the nerve sheath). No statistically significant association was found between mobile phone use and acoustic neuroma. There was also no association between mobile phone use and gliomas when all types of types of gliomas were considered together. It should be noted that the average length of mobile phone exposure in this study was less than three years.

When 20 types of glioma were considered separately, however, an association was found between mobile phone use and one rare type of glioma, neuroepitheliomatous tumors. It is possible with multiple comparisons of the same sample that this association occurred by chance. Moreover, the risk did not increase with how often the mobile phone was used, or the length of the calls. In fact, the risk actually decreased with cumulative hours of mobile phone use. Most cancer causing agents increase risk with increased exposure. An ongoing study of brain cancers by the National Cancer Institute is expected to bear on the accuracy and repeatability of these results.

2. Researchers conducted a large battery of laboratory tests to assess the effects of exposure to mobile phone RF on genetic material. These included tests for several kinds of abnormalities, including mutations, chromosomal aberrations, DNA strand breaks, and structural changes in the genetic material of blood cells called lymphocytes. None of the tests showed any effect of the RF except for the micronucleus assay, which detects structural effects on the genetic material. The cells in this assay showed changes after exposure to simulated cell phone radiation, but only after 24 hours of exposure.

It is possible that exposing the test cells to radiation for this long resulted in heating. Since this assay is known to be sensitive to heating, heat alone could have caused the abnormalities to occur. The data already in the literature on the response of the micronucleus assay to RF are conflicting. Thus, follow-up research is necessary.

FDA is currently working with government, industry, and academic groups to ensure the proper follow-up to these industry-funded research findings. Collaboration with the Cellular Telecommunications Industry Association (CTIA) in particular is expected to lead to FDA providing research recommendations and scientific oversight of new CTIA-funded research based on such recommendations.

Two other studies of interest have been reported recently in the literature:

1. Two groups of 18 people were exposed to simulated mobile phone signals under laboratory conditions while they performed cognitive function tests. There were no changes in the subjects' ability to recall words, numbers, or pictures, or in their spatial memory, but they were able to make choices more quickly in one visual test when they were exposed to simulated mobile phone signals. This was the only change noted among more than 20 variables compared.
2. In a study of 209 brain tumor cases and 425 matched controls, there was no increased risk of brain tumors associated with mobile phone use. When tumors did exist in certain locations, however, they were more likely to be on the side of the head where the mobile phone was used. Because this occurred in only a small number of cases, the increased likelihood was too small to be statistically significant.

In summary, we do not have enough information at this point to assure the public that there are, or are not, any low incident health problems associated with use of mobile phones. FDA continues to work with all parties, including other federal agencies and industry, to assure that research is undertaken to provide the necessary answers to the outstanding questions about the safety of mobile phones.

What is known about cases of human cancer that have been reported in users of hand-held mobile phones?

Some people who have used mobile phones have been diagnosed with brain cancer. But it is important to understand that this type of cancer also occurs among people who have not used mobile phones. In fact, brain cancer occurs in the U.S. population at a rate of about 6 new cases per 100,000 people each year. At that rate, assuming 80 million users of mobile phones (a number increasing at a rate of about 1 million per

month), about 4800 cases of brain cancer would be expected each year among those 80 million people, whether or not they used their phones. Thus it is not possible to tell whether any individual's cancer arose because of the phone, or whether it would have happened anyway. A key question is whether the risk of getting a particular form of cancer is greater among people who use mobile phones than among the rest of the population. One way to answer that question is to compare the usage of mobile phones among people with brain cancer with the use of mobile phones among appropriately matched people without brain cancer. This is called a case-control study. The current case-control study of brain cancers by the National Cancer Institute, as well as the follow-up research to be sponsored by industry, will begin to generate this type of information.

What is FDA's role concerning the safety of mobile phones?

Under the law, FDA does not review the safety of radiation-emitting consumer products such as mobile phones before marketing, as it does with new drugs or medical devices. However, the agency has authority to take action if mobile phones are shown to emit radiation at a level that is hazardous to the user. In such a case, FDA could require the manufacturers of mobile phones to notify users of the health hazard and to repair, replace or recall the phones so that the hazard no longer exists.

Although the existing scientific data do not justify FDA regulatory actions at this time, FDA has urged the mobile phone industry to take a number of steps to assure public safety. The agency has recommended that the industry:

- support needed research into possible biological effects of RF of the type emitted by mobile phones;
- design mobile phones in a way that minimizes any RF exposure to the user that is not necessary for device function; and
- cooperate in providing mobile phone users with the best possible information on what is known about possible effects of mobile phone use on human health.

At the same time, FDA belongs to an interagency working group of the federal agencies that have responsibility for different aspects of mobile phone safety to ensure a coordinated effort at the federal level. These agencies are:

- National Institute for Occupational Safety and Health
- Environmental Protection Agency
- Federal Communications Commission
- Occupational Health and Safety Administration
- National Telecommunications and Information Administration

The National Institutes of Health also participates in this group.

In the absence of conclusive information about any possible risk, what can concerned individuals do?

If there is a risk from these products--and at this point we do not know that there is--it is probably very small. But if people are concerned about avoiding even potential risks, there are simple steps they can take to do so. For example, time is a key factor in how much exposure a person receives. Those persons who spend long periods of time on their hand-held mobile phones could consider holding lengthy conversations on conventional phones and reserving the hand-held models for shorter conversations or for situations when other types of phones are not available.

People who must conduct extended conversations in their cars every day could switch to a type of mobile phone that places more distance between their bodies and the source of the RF, since the exposure level drops off dramatically with distance. For example, they could switch to

- a mobile phone in which the antenna is located outside the vehicle,
- a hand-held phone with a built-in antenna connected to a different antenna mounted on the outside of the car or built into a separate package, or
- a headset with a remote antenna to a mobile phone carried at the waist.

Again, the scientific data do not demonstrate that mobile phones are harmful. But if people are concerned about the radiofrequency energy from these products, taking the simple precautions outlined above can reduce any possible risk.

Where can I find additional information?

For additional information, see the following websites:

Federal Communications Commission (FCC) RF Safety Program (select "Information on Human Exposure to RF Fields from Cellular and PCS Radio Transmitters"):
<http://www.fcc.gov/oet/rfsafety>

World Health Organization (WHO) International Commission on Non-Ionizing Radiation Protection (select Qs & As):
<http://www.who.int/emf>

United Kingdom, National Radiological Protection Board:
<http://www.nrpb.org.uk>

Cellular Telecommunications Industry Association (CTIA):
<http://www.wow-com.com>

U.S. Food and Drug Administration (FDA) Center for Devices and Radiological Health: <http://www.fda.gov/cdrh/consumer/>

Patent Information

This phone may be manufactured under one or more of the following U.S. Patents.

4291475	5649309	4870686	5764730	5057762	5862460	5877633	5205751
4302845	5656914	4872196	5764743	5058136	5862493	5878075	5210793
4312074	5656917	4873683	5766794	5059885	5087004	5878209	5211581
4365221	5657418	4876552	5771182	5060264	5093632	5878336	5212815
4369516	5659601	4876656	5771471	5063340	5095503	5878353	5212826
4369520	5660945	4876740	5777521	5065408	5107487	5880637	5214675
4369522	5661433	4879533	5777856	5067139	5109400	5880646	5214774
4374370	5664973	4885553	5784368	5070310	5111162	5881377	5216389
4378603	5666429	4887050	5784419	5077757	5113400	5889737	5220290
4390963	5668871	4890199	5784585	5077790	5113436	5889768	5220936
4398265	5670912	4896124	5787128	5081674	5117073	5889859	5222078
4400584	5673001	4896361	5787577	5083304	5117441	5892410	5222104
4400585	5673003	4897873	5793315	5805992	5117449	5893036	5222251
4434461	5673287	4903326	5793866	5807012	5117450	5894597	5230007
4455534	5674326	4903327	5796822	5808585	5121047	5896054	5230093
4486624	5675591	4904549	5797101	5808586	5121288	5896261	5233506
4491972	5675702	4904992	5798716	5809020	5121412	5898933	5233633
4523155	5678201	4905288	5799011	5809419	5122480	5900829	5235492
4546329	5678221	4905301	5799256	5809421	5122722	5901347	5237257
4574243	5678227	4912602	5801513	5809430	5124889	5901357	5237570
4581602	5680063	4916262	5801567	5809433	5127040	5903825	5239127
4581749	5684384	4918431	5802111	5809544	5127042	5903852	5241545
4585957	5691947	4918732	4972355	5812093	5127100	5905956	5241548
4593155	5692046	4922178	4972432	5812542	5128834	5907418	5241592
4594657	5692101	4941203	4972455	5812590	5133010	5907615	5241688
4602218	5696497	4942570	4975808	5814798	5134717	5909102	5242767
4605987	5696821	4945570	4977589	5815507	5140286	5910944	5243355
4616314	5699070	4956854	4977616	5815570	5140635	5912648	5247544
4617520	5699389	4959851	4979207	5815804	5142551	5920549	5247565
4628529	5699408	4963812	4984219	5815805	5142696	5920550	5249302
4629829	5701130	4964121	4984290	5815807	5144533	5923007	5251331
4633141	5701244	4970475	4989230	5815820	5146620	5924044	5255292
4636593	5701589	5715520	4992753	5821820	5148471	5925835	5257414
4636741	5703470	5715524	4996529	5822726	5148473	5925942	5259005
4648125	5703539	5717307	5008925	5826224	5150075	5926119	5940452
4649543	5703909	5722052	5010309	5831826	5150359	5926503	5940746
4654655	5706019	5724004	5010570	5832080	5150384	5926751	5943027
4680787	5706313	5726983	5014294	5832388	5151643	5930268	5945852
4704588	5708445	5729221	5014346	5835006	5152006	5930288	5945964
4711361	5710862	5732350	5017856	5835535	5152007	5930299	5946395
4715063	5710987	5737327	5018188	5835785	5153590	5933330	5949020
4717884	5711001	5737685	5020076	5838202	5157693	5936516	5950131
4730195	4794489	5738954	5020091	5841851	5160898	5936972	5950139
4731813	4797929	5739792	5020092	5842122	5162144	5939939	5953413
4736277	4797947	5740525	5020093	5844943	5163159	5175874	5954817
4737976	4798975	5742894	5023580	5846094	5164652	5182749	5955700
4741018	4802236	5745116	5023866	5848072	5166596	5185566	5955999
4742562	4803726	5745566	5023911	5848152	5166642	5185790	5956626
4761621	4809356	5745848	5025387	5848356	5168522	5187640	5963848
4764737	4811377	5747970	5027388	5848718	5170173	5187809	5963876
4775998	4811404	5748727	5028083	5850440	5170485	5192924	5964858
4791527	4817157	5754141	5028859	5854549	5170492	5193223	5966101
5630213	4827507	5754455	5029233	5854785	5175729	5195106	5966667
5630215	4829543	5754583	5036532	5854972	5175759	5195108	5966671
5631538	4831647	5754645	5038253	5856763	5864799	5198887	5969545
5633484	4843621	5754956	5040127	5856766	5865487	5200655	5974042
5633786	4845772	5758271	5042071	5857148	5867063	5201069	5977916
5634202	4851966	5760714	5045824	5857192	5867127	5203009	5980268
5640690	4852090	5761300	5053924	5859522	5867140	5203012	5982881
5642368	4860336	5761610	5055800	5859567	5867510	5203013	5983082
5646576	4860341	5764100	5055802	5859890	5870670	5203021	5987012
5649306	4868576	5764111	5055803	5861853	5872744	5204977	5988577

5995050	5365549	5402448	D340906	5542103	5561437	D378366	D395875
5996178	5366826	5404580	D341589	5542106	5561852	D378911	D396472
5999115	5367538	5404582	D342248	5542116	5565881	D379558	D397337
5999821	5367558	5406146	D342663	5544250	5566224	D379624	D397689
5999832	5371791	5406562	D342729	5546275	5568548	D379981	D397694
6002922	5373101	5408693	D342730	5546380	5570453	D379982	D398926
6002937	5375143	5410275	D342741	5551078	5572223	D380468	D400161
6005498	6018584	5410741	D343173	5551627	5572224	D380751	D400165
6006104	6018651	5414711	D343615	D348427	5574976	D381021	D400204
6008636	6018671	5420759	D343616	D348470	5577267	D381664	D400209
6009168	6021332	5424689	D343834	D348665	5577268	D382537	D400496
6009309	D284759	5428362	D343835	D348666	5583520	D382538	D400526
6009325	D285439	5428820	D343836	D348668	5584054	D382872	D400527
6009336	D288432	5428836	D344087	D348674	5586146	D383115	D400874
6009552	D288683	5430416	D344271	D348880	5588041	D383748	D401554
6011699	D289156	5432017	D344444	D349273	5589796	D383749	D401929
6011784	D292578	5434947	D344511	D349701	5590177	D383759	D403265
6011959	D292920	5436802	D344512	D350113	5594778	D384080	D404397
6011961	D295627	5438684	D344945	D350348	5594951	D384662	D405080
6012634	D295973	5442680	D345977	D350349	5598129	D384951	D405782
6014376	D295975	5444764	D346785	D350350	5598431	D384952	D405801
6014552	D296187	5446763	D346786	D351375	5600341	D385271	D406098
6016312	D297734	5446766	D346798	D351840	5604050	D385283	D406191
6016422	D297735	5448763	D348071	D352497	5604468	D385555	D406586
5260170	D297736	5448770	D348250	D352503	5604787	D385873	D406695
5260988	D299136	5448771	5475752	D352946	5606332	D385874	D406812
5261119	D299137	5453997	5477192	D353131	5606560	D385875	D407063
5262710	D299232	5457744	5485506	D353361	5606730	D385877	D407685
5263052	D300742	5459640	5485513	D353587	5613229	D385888	D407708
5263055	D300827	5459774	5486843	D353588	5613863	D386175	D408401
5265271	D301473	5461643	5487184	D353591	5615233	D386494	D408402
5267230	D301476	5463351	5488649	D354055	5615259	D386757	D408418
5276588	D301883	5463406	5490177	D354062	5615260	D387054	D408783
5276707	D302015	5463628	5491739	D355181	5621763	D387055	D408815
5276913	D303656	5463646	5493198	D355895	5621766	D387199	D409186
5276915	D304189	5463674	5493700	D356084	5625316	D387346	D410459
5278832	D305427	5463688	5493714	D356309	5625683	D388078	D410460
5278994	D305717	5463694	5495206	D357224	5628001	D388079	D410929
5280630	D306015	5465409	5495208	D357249	5628057	D388080	D411165
5280637	D306163	5465412	5497126	D357457	5628089	D388081	D411196
5280644	D306293	5469177	5497382	D357680	5629979	D388082	D411202
5285443	D306299	5471671	5497383	D357681	5630159	D388424	D411204
5287013	D306441	D324024	5499273	D358148	5630210	D388429	D411507
5287553	D306583	D324388	5499394	D359052	D386359	D388430	D411535
5287555	D306594	D325028	5499397	D359734	D369797	D388775	D411843
5287556	D307271	D325029	5502437	D359735	D370016	D388783	D411844
5289505	D309301	D325032	5504494	D359959	D370463	D388793	D412000
5297142	D309451	D325583	5504812	D360398	D370672	D389157	D412487
5299232	D314173	D325915	5506490	D360632	D372237	D389476	D412709
5301365	D315330	D327061	5508709	D361070	D372481	D389478	D413893
5308716	D315346	D327062	5509048	D361763	D372703	D389488	D413898
5321705	D315543	D328302	5510693	D362840	D372896	D389641	D414159
5321737	D315559	D332261	5511235	D362852	D372919	D390221	D415122
5321847	D315565	D332785	5513078	D365094	D373585	D390222	D415499
5323421	D315907	D334746	5513996	D365817	D373764	D390509	D416226
5325405	D316417	D337332	5519303	D366872	D374013	D391567	D417224
5325429	D316859	D338012	5519346	D367640	D374014	D391955	D417449
5327578	D320780	D338887	5519506	D368479	D374227	D391966	D419155
5327642	D322783	D339127	5519777	D368696	D374424	D393470	D419290
5331123	5375258	D339335	5524276	D369162	D374872	D394256	D419565
5333153	5379324	D339336	5526398	5553137	D375732	D394423	PAT02250
5336984	5381114	D339337	5528666	5553376	D375733	D394425	
5338909	5384825	D339564	5530399	5554996	D375734	D394433	
5343213	5392000	D339578	5530922	5555550	D375932	D394438	
5349588	5392023	D339581	5533119	5557743	D375935	D394439	
5351245	5392331	D339582	5535258	5559471	D375952	D395301	
5359696	5396654	D340709	5535434	5559522	D376127	D395302	
5361400	5401927	D340710	5539360	5559806	D377792	D395431	
5363071	5402447	D340711	5542016	5561436	D377934	D395642	

Quick Reference Card

Turn On and Off

Turn On / Turn Off (PWR)

Placing / Receiving Calls

Place Call Enter number, (SND)

Clear Entry Hold (CLR) to clear all digits. Press and release (CLR) to clear one digit.

Automatic Redial At system busy signal, (SND) before ending call attempt.

Receive Call (SND)

End Call (END)

Locking / Unlocking

Lock Telephone (FCN), (5) (hold (5) until *LOCK* appears, then press (STO))

Unlock Telephone Enter three-digit unlock code.
If you make an error, (END) and enter again.

Memory Dialing

Store Number Phone number, (STO), two digit location number.

Recall Number Press (RCL), then two digit location number.

Emergency Dialing Store emergency number in location 01. Hold (1) to dial, even on locked unit.

Recall Last Number Called (RCL), (0), (0)

Call Timers

Individual Call Timer (RCL), (#), (#)

Resettable Call Timer (RCL), (#), (#), (#)
To reset (FCN), (0), (7), (CLR)

Cumulative Call Timer (RCL), (#), (#), (#), (#)

Volume Adjustments

Adjust Volume *Earpiece* — press (▲) to raise. Press (▼) to lower.
Ringer — (FCN) and use (▲) and (▼) as described above.

Additional Features

Battery Voltage Meter (FCN), (4)

Display Own Phone Number (RCL), (#)

Mute While in a call, (FCN), (6). To unmute, (FCN), (6).

Access Feature Menu (FCN), (1)



**THIS PACKAGE MAY CONTAIN A NICKEL CADMIUM BATTERY
WHICH MUST BE RECYCLED OR DISPOSED OF PROPERLY.**



- Refer to the battery label for battery type.
- Recycling facilities may not be available in all areas.
- For additional information regarding disposal or recycling, call 1-800-331-6456 (in U.S.A.).



MOTOROLA

Pan American Cellular Subscriber Group
600 North U.S. Highway 45
Libertyville, Illinois 60048
1-800-331-6456 (in U.S.A.)
1-800-461-4575 (in Canada)

Please visit us at:
www.mot.com

 **MOTOROLA**,  E•P, Turbo Dial, Super Speed Dial, Ultra Saver, IntelliCharge, THE Cellular Connection, and Performance Matched are registered trademarks of Motorola, Inc.