

FISHiN'TIME™



OWNERS AND SERVICE MANUAL
INNOVATIVE CONCEPTS IN ENTERTAINMENT INC.

OWNERS AND SERVICE MANUAL

Fishin' Time

© Innovative Concepts in Entertainment Inc.
10123 Main Street, Clarence, NY 14031

Table of Contents

CHAPTER 1 – SAFETY AND WARNINGS.....	2	1.3 View Coin Audits	9
CHAPTER 2 – GAME SETUP AND FEATURES.	3	1.4 Game Adjustments	9
Player Controls.....	3	1.5 Coinage Adjustments.....	10
Start/Fish Button	3	1.6 Ticket Adjustments.....	11
Playing The Game.....	3	1.7 Clear Audits.....	12
Coins	3	CHAPTER 4 – TROUBLESHOOTING.....	13
Tickets	3	CAUTION	13
Time Limit	3	Game Is Non-Functional	13
Ticket Payout	3	Monitor Is Non-Functional	14
Credit Amount.....	3	Sound Is Non-Functional.....	14
Payout Percentage.....	4	Game Controls Are Non-Functional.....	14
Points Per Ticket	4	CHAPTER 5 – PARTS	15
Control Switches	4	Mechanical Parts.....	15
Volume Up.....	4	Electrical Parts	15
Volume Down	4	Graphics and Decals	15
Diagnostics Button.....	4		
Coin Meters.....	4		
CHAPTER 3 – DIAGNOSTIC, ADJUSTMENT AND AUDIT MENU SYSTEM.....	5		
Menu System	5		
Starting The Menu System.....	5		
Navigating The Menu	5		
1.0 Main Menu.....	5		
1.1 System Test Menu	6		
1.2 View Game Audits	7		

Chapter 1 – Safety and Warnings

BEFORE YOU BEGIN

WARNING: WHEN INSTALLING THIS GAME, A GROUNDED A.C. RECEPTACLE MUST BE USED. FAILURE TO DO SO COULD RESULT IN INJURY TO YOURSELF OR OTHERS. FAILURE TO USE A GROUNDED RECEPTACLE COULD ALSO CAUSE IMPROPER GAME OPERATION, OR DAMAGE TO THE ELECTRONICS.

DO NOT DEFEAT OR REMOVE THE GROUNDING PRONG ON THE POWER CORD FOR THE SAME REASON AS GIVEN ABOVE. USING AN IMPROPERLY GROUNDED GAME COULD VOID YOUR WARRANTY.

HAVE A QUALIFIED ELECTRICIAN CHECK YOU'RE A.C. RECEPTACLE TO BE SURE THE GROUND IS FUNCTIONING PROPERLY.

INSTALLATION

The game comes ready to play with just a few simple things to keep in mind.

1. Plug the game into the A.C. outlet and turn on power to the game. The switch for the game is located on a power module on the outside rear of the game.

THIS GAME IS DESIGNED TO DISSIPATE STATIC ELECTRICITY THROUGH THE GROUNDING PLANE OF THE GAME. IF THE A.C. GROUND DOES NOT WORK, THE GAME COULD DISCHARGE STATIC ELECTRICITY THROUGH THE GAME CIRCUITRY, WHICH COULD CAUSE DAMAGE.

2. Make sure the game is level after installation. It is necessary to make sure the game is level for safety concerns.
3. Place the game into its final location and use the adjusting feet to level the game.
4. Check that the A.C. voltage rating on the back of the game matches the A.C. voltage of your location.

THE POWER SUPPLY IS NOT VOLTAGE ADJUSTABLE. TO OPERATE THE GAME AT VOLTAGES OTHER THAN THOSE IT WAS DESIGNED FOR. PLEASE CONTACT OUR SERVICE DEPARTMENT FOR VOLTAGE CONVERSION INFORMATION.

WARNING

DO NOT remove any of the components on the main board (e.g. compact flash and eproms) while the game is powered on. This may cause permanent damage to the parts and the main board. Removing any main board component part while powered on will void the warranty.

**NOTE: THIS GAME IS INTENDED FOR INDOOR USE ONLY.
ON THE BACK PANEL OF THE GAME: WARNING: SHOCK HAZARD - DO NOT
OPEN. REFER SERVICING TO SERVICE PERSONNEL.**

Chapter 2 – Game Setup and Features

Player Controls

Start/Fish Button

The Start/Fish button is used to start a game once the proper number of credits has been inserted. Once a game has been started, the Start/Fish button is used to drop the hook in order to catch fish. There are two Start/Fish buttons, one for the left player and one for the right player.

Playing The Game

The objective of the game is to catch as many fish as possible within the game time in order to accumulate points and tickets. Fish come out on 4 different levels with the highest points being awarded for the fish on the bottom level.

There are other bonus items such as: treasure chest – awards jackpot amount, blow fish – multiplies fish amounts X 2 for the remainder of the game, and time bonus – awards more time. In addition, there are junk items (tire, boot, license plate and can) that award no points.

Initial Game Setup

The game is setup at the factory with the recommended factory settings. The following outlines the important adjustments an operator may adjust during initial game setup. For more detailed instructions on setting these adjustments, see Chapter 3.

Coins

Set the number of credits required to start the game. Also set the number of credits for each coin inserted in coin mechanism 1, coin mechanism 2 and the DBV. These settings are adjusted in the COINAGE ADJUSTMENTS menu.

Tickets

Setup the points per ticket, minimum tickets paid, maximum tickets paid and ticket threshold. Also, setup whether tickets should be dispensed while playing or at the end of the game. These settings are adjusted in the TICKET ADJUSTMENTS menu.

Time Limit

Set the amount of game time for each start. These settings are adjusted in the GAME ADJUSTMENTS menu.

Ticket Payout

Set the value per ticket (in Dollars). This will be used to calculate the Total Ticket Payout and Average Ticket Payout Per Play.

Credit Amount

Set the amount that each credit is worth (in Dollars). This will be used to calculate the payout percentage.

Payout Percentage

Set the maximum payout percentage. If actual payout percentage is greater than this setting, game will automatically adjust the output of fish, blow fish, treasure chest and time bonus. In effect, this will help reduce the payout percentage. If set to Zero, auto percentage will be turned off.

Points Per Ticket

Set the number of points required to earn one ticket.

Control Switches

The control switches are inside the front coin door.

Volume Up

Press the volume up button to increase the volume in the game and the attract mode. Pressing this button when playing the game will increase the game volume. Pressing this button when the game is in the attract mode will increase the attract mode volume.

Volume Down

Press the volume down button to decrease the volume in the game and the attract mode. Pressing this button when playing the game will decrease the game volume. Pressing this button when the game is in the attract mode will decrease the attract mode volume.

Diagnostics Button

Press this button to go into the diagnostics MAIN MENU.

Coin Meters

The game has two mechanical meters. The left meter will be incremented by 1 each time a coin is dropped into the coin mechanisms. The right meter will be incremented by 1 each time a ticket is dispensed.

Chapter 3 – Diagnostic, Adjustment and Audit Menu System

Menu System

The game's menu system is a series of on screen menus that allow the operator to setup and adjust the settings. Each menu item leads to another menu, a list of data or provides the ability to modify the adjustment.

Starting The Menu System

Press the Diagnostics control switch inside the coin door to access the on screen menu system.


Navigating The Menu

Use the following buttons to navigate the menu system:

- Left Start/Fish button to move the cursor.
- Right Start/Fish button to select.
- Once an item has been selected, use the Left Start/Fish button to change the settings. Once an item has been changed, press the Right Start/Fish button to save the desired setting.


1.0 Main Menu

All system tests, audits and game adjustments are accessible from the MAIN MENU.



1.1 System Test Menu

Select SYSTEMS TEST at the MAIN MENU.




Switch Input Test - Select SWITCH INPUT TEST to manually test all of the switch inputs. When in this screen, activate the start button, select button, test button, volume up, volume down, ticket sensor 1, ticket sensor 2, coin 1, coin 2, game control pad 1 and game control pad 2 to determine if the game recognizes input from each.

Video Screen Tests - Select VIDEO SCREEN TESTS to test the following: Screen Color, Screen Size, Red Color, Green Color, Blue Color, and White Color.

Sound Test - Select SOUND TEST to test various game sounds and songs.

Watchdog Test - The watchdog automatically restarts the game in the event it locks up. Select WATCHDOG TEST to determine if the watchdog is functioning properly.



Color Adjustment – Displays multiple colors for screen color adjustment.

Screen Size Adjustment – Displays grid for screen size adjustments.

Red Screen – Displays full red for screen color adjustments.

Green Screen - Displays full green for screen color adjustments.

Blue Screen - Displays full blue for screen color adjustments.

White Screen - Displays full white for screen color adjustments.

1.2 View Game Audits

Select VIEW GAME AUDITS at the MAIN MENU to view import audit data about the game. Use the Pads and Start button to navigate through the page navigation items at the bottom of each page.

NOTE: All Game Audits will be reset if you RESET AUDITS or RESTORE FACTORY SETTINGS from the UTILITIES menu.

Page 1

Fishin Time V1.00.00	Serial #: 00001
GAME AUDITS	
Up Time H:M:S	189:34:36
Total Game Time H:M:S	0:21:21
Avg Time Per Play H:M:S	0:00:32
NEXT PAGE EXIT AUDITS	

Up Time H:M:S - Total up time. Reported in Hours, Minutes and Seconds.

Total Game Time H:M:S – Total time game. Reported in Hours, Minutes and Seconds.

Avg Time Per Play H:M:S – Average amount of game time per game played. Reported in Hours, Minutes and Seconds.

Page 2

Fishin Time V1.00.00	Serial #: 00001
GAME AUDITS	
Player Starts	39
Player 1 Starts	17
Player 2 Starts	22
Game Overs	39
Player 1 Game Overs	17
Player 2 Game Overs	22
NEXT PAGE PREVIOUS PAGE EXIT AUDITS	

Player Starts – Number of games started.

Game Overs – Number of games ended.

Page 3

Fishin Time V1.00.01	Serial #: 00001
GAME AUDITS	
High Score	70
High Ticket	4
Average Score	8
Tickets Dispensed 1	10
Tickets Dispensed 2	2
Average Tickets Dispensed Per Play	0.85
Total Ticket Payout [in dollars]	0.12
Average Ticket Payout Per Play [in cents]	0.85
Payout Percentage [in percent]	3
NEXT PAGE PREVIOUS PAGE EXIT AUDITS	

High Score – Highest Score achieved.

High Ticket – Highest Tickets awarded.

Average Score – Average score per game played. Use this setting to help determine ticket settings from the TICKET UTILITIES menu.

D1 Total Tickets Dispensed – Total tickets dispensed from dispenser 1.

D2 Total Tickets Dispensed – Total tickets dispensed from dispenser 2.

Average Tickets Dispensed Per Play – Average tickets dispensed per game.

Total Ticket Payout – Total tickets dispensed times TICKET PAYOUT (TICKET PAYOUT is set in

COINAGE ADJUSTMENTS)

Average Ticket Payout Per Play – AVERAGE TICKETS DISPENSED PER PLAY times TICKET PAYOUT. (Display is in cents)

Payout Percentage – Average Ticket Payout Per Play divided by CREDIT AMOUNT

Page 4

Fishin Time V1.00.01	Serial #: 00001
GAME AUDITS	
Level 1 Fish	7
Average Per Play	0.50
Level 2 Fish	8
Average Per Play	0.57
Level 3 Fish	4
Average Per Play	0.28
Level 4 Fish	1
Average Per Play	0.07
NEXT PAGE PREVIOUS PAGE EXIT AUDITS	

Level 1 Fish – Number of fish caught on level 1.

Average Per Play – Average number of fish caught on level 1.

Level 2 Fish – Number of fish caught on level 2.

Average Per Play – Average number of fish caught on level 2.

Level 3 Fish – Number of fish caught on level 3.

Average Per Play – Average number of fish caught on level 3.

Level 4 Fish – Number of fish caught on level 4.

Average Per Play – Average number of fish caught on level 4

Page 5

Fishin Time V1.00.01	Serial #: 00001
GAME AUDITS	
Blow Fish	0
Average Per Play	0.00
Time Bonus	0
Average Per Play	0.00
Treasure Chest	0
Average Per Play	0.00
Watchdogs	0
EXIT AUDITS PREVIOUS PAGE	

Blow Fish – Number of Blow fish caught.

Average Per Play – Average number of Blow fish caught.

Time Bonus – Number of Time Bonus caught.

Average Per Play – Average number of Time Bonus caught.

Treasure Chest – Number of Treasure Chests caught.

Average Per Play – Average number of Treasure Chests caught.

Watchdogs – Number of game resets.

1.3 View Coin Audits

Select VIEW COIN AUDITS at the MAIN MENU to view coin data about the game.

Fishin Time V1.00.00		Serial #: 00001
Coin Audits		
Coin 1		10
Coin 2		29
DBV		1
Paid Credits		43
Lifetime Coin Count		155
EXIT AUDITS		

Coin 1 – Number of coins inserted in coin mechanism 1.

Coin 2 – Number of coins inserted in coin mechanism 2.

DBV – Number of bills inserted in DBV mechanism.

Paid Credits – Number of coins inserted in all coin devices.

Lifetime Coin Count – Number of coins inserted in all coin devices since the game has been installed. This WILL NOT be reset by CLEAR COIN COUNTERS or RESTORE FACTORY SETTINGS from the UTILITIES menu.

1.4 Game Adjustments

Select GAME ADJUSTMENTS at the MAIN MENU. Modify these game adjustments to change the way the game functions.

Fishin Time V1.00.01		Serial #: 00001
GAME ADJUSTMENTS MENU		
Use PADS to move.		
Use START to select.		
MINIMUM VOLUME		30
GAME VOLUME		130
ATTRACT MODE VOLUME		70
TIME LIMIT		30
JUNK		Rare
BLOW FISH		Rare
TREASURE CHEST		Very Rare
TIME BONUS		Rare
TREASURE CHEST AMOUNT		200
TIME BONUS AMOUNT		20
HOOK TYPE		Hover
MINIMUM DEPTH		1
MAIN MENU		

Minimum Volume – Minimum volume setting for the game. Set from 0 – 255. The higher the setting the higher the volume.

Game Volume – Volume setting for the game. Set from Minimum Volume – 255. The higher the setting the higher the volume.

Attract Mode Volume – Volume setting for the attract mode. Set from Minimum Volume – 255. The higher the setting the higher the volume.

Time Limit – Game Time. Maximum time = 15 seconds, Maximum = 90 seconds.

Junk Frequency – Frequency of Junk coming out. Settings are Common, Rare, Very Rare, None.

Blow Fish – Frequency of the Blow Fish coming out. Settings are Common, Rare, Very Rare, None.

Treasure Chest – Frequency of the Treasure Chest coming out. Settings are Common, Rare, Very Rare, None.

Time Bonus – Frequency of the Time Bonus coming out. Settings are Common, Rare, Very Rare, None.

Treasure Chest Value – Number of points for catching the Treasure Chest.

Time Bonus Amount – Amount of additional time given for catching the time bonus icon.

Hook Type – The game play style of how the hook functions.

Hover – When fish button held down, hook goes down to the bottom and returns to the top. If fish button is released, hook returns to the top. Hook always goes to Minimum Depth when held down or touched. Once hook reaches Minimum Depth, hook can be bobbed up and down by the player.

No Hover - When fish button held down, hook goes down to the bottom and returns to the top. If fish button is released, hook returns to the top. Hook always goes to Minimum Depth when held down or touched. Hook must return to the top before it can be sent down again.

Minimum Depth – For Hover and No Hover, hook will go to at least this depth setting before returning to the top.

1.5 Coinage Adjustments

Select COINAGE ADJUSTMENTS at the MAIN MENU. Modify these coinage adjustments to change the price of the game.

Fishin Time V1.00.08	Serial #: 00002
COINAGE ADJUSTMENTS MENU	Coinage Version: 0
Use PAD 1 to move down. Use PAD 2 to select.	
FREE PLAY	No
CREDITS TO START	1
COIN1 CREDITS	1
COIN2 CREDITS	1
DBV CREDITS	4
TICKET PAYOUT	.01
PAYOUT PERCENTAGE	.40
CREDIT AMOUNT	.25
MAIN MENU	

Free Play – If set to 'Yes' the game is set on free play and no coins or credits will be required to play.

Credits to Start – Set the number of credits required to start a game. Set from 1 – 9.

Coin 1 Credits – Set the number of credits received when a coin or token is inserted in coin mechanism 1. Set from 1 – 8.

Coin 2 Credits – Set the number of credits received when a coin or token is inserted in coin mechanism 2. Set from 1 – 8.

DBV Credits – Set the number of credits received when a bill is inserted in the DBV. Set from 1 – 20.

Ticket Payout – Indicates value per ticket (in Dollars)

Payout Percentage – Maximum payout percentage. If actual payout percentage is greater than this setting, game will automatically adjust the output of ish, blow fish, treasure chest and time bonus. In

effect, this will help reduce the payout percentage. If set to zero, auto percentaging will be turned off.

Credit Amount – Dollar amount of each credit. Used to calculate Payout Percentage audit.

1.6 Ticket Adjustments

Select TICKET ADJUSTMENTS at the MAIN MENU. Modify these ticket adjustments to change the number of tickets dispensed by the game.

TICKET ADJUSTMENTS MENU	
Use Pad 1 to move.	
Use Pad 2 to select.	
POINTS PER TICKET	15
MINIMUM TICKET OUT	0
MAXIMUM TICKET OUT	500
DISPENSE WHILE PLAYING	No
TICKET THRESHHOLD	0
POINTS LEVEL 1	2
POINTS LEVEL 2	5
POINTS LEVEL 3	15
POINTS LEVEL 4	30
MAIN MENU	

Points Per Ticket – This setting determines the number of points required to earn one ticket. Set from 0 – 100,000. If the game does not have a ticket dispenser, set to 0.

Minimum Tickets Out – This setting determines the minimum number of tickets to be dispensed for each game played. Set from 0 – 10. If the game does not have a ticket dispenser, set to 0.

Maximum Tickets Out – This setting determines the maximum number of tickets to be dispensed for each game played. Set from 0 – 50. If the game does not have a ticket dispenser, set to 0.

Dispense While Playing – Set to 'No' to dispense tickets at the end of each game. Set to 'Yes' to dispense tickets as they are earned during game play.

Ticket Threshold – This setting determines the number of points required before the first ticket will be earned. Set from 0 – 300,000

Points Level 1 – Number of points awarded for each fish caught on level 1. Set from 0 – 75.


Points Level 2 – Number of points awarded for each fish caught on level 2. Set from 0 – 75.

Points Level 3 – Number of points awarded for each fish caught on level 3. Set from 0 – 75.

Points Level 4 – Number of points awarded for each fish caught on level 4. Set from 0 – 75.

1.7 Clear Audits

Select CLEAR AUDITS at the MAIN MENU. Modify these ticket adjustments to change the number of tickets dispensed by the game.



Clear Credits – This will clear the credits currently in the game.

Clear Coin Counters – This will clear all of the coin counters in the game.

Clear Game Audits – This will clear all the game audits.

Reset High Scores – This will reset the high score tables.

Reset Tickets – This will reset the ticket counter.

Default Adjustments – This will reset the game using all of the default adjustments. Default Adjustments are as follows:

Game Adjustments:

Minimum Volume	30
Game Volume	130
Attract Volume	160
Time Limit	30
Junk Frequency	None
Blow Fish Frequency	Very Rare
Treasure Chest Freq.	Very Rare
Time Bonus Frequency	Very Rare
Treasure Chest Value	200
Time Bonus Amount	30
Hook Type	Hover
Minimum Depth	1

Coin Adjustments:

Freeplay	No
Credits to Start	1
Coin 1	1
Coin 2	1
DBV	4
Ticket Payout	.01
Payout Percentage	.40
Credit Amount	.25

Tickets Adjustments:

Points Per Ticket	15
Minimum Tickets	1
Maximum Tickets	50
Dispense While Playing	Yes
Ticket Threshold	0
Points Level 1	5
Points Level 2	8
Points Level 3	10
Points Level 4	15

Factory Settings – This will reset the game using all of the default settings above and clear credits, game audits, coin audits, ticket counter and reset high scores. It will NOT reset the Lifetime Coin Counter.

Chapter 4 – Troubleshooting

CAUTION

This game uses complex electronic components that are very sensitive to static electricity. Observe precautions below before handling these electronics. Failure to do so may void the warranty and damage electronic assemblies.

- Before servicing electronics, turn off AC power to the game. Wait for capacitors to discharge.
- DO NOT remove any of the components on the main board (e.g. compact flash and eproms) while the game is powered on. This may cause permanent damage to the parts and the main board.
- Before touching or handling electronic assemblies, discharge static electricity on your body. To discharge this static, begin by connecting the line cord to a grounded outlet. Don't turn on the game. Next, touch the safety ground stud of the power supply chassis.
- Store electronic assemblies in an anti-static area. Use anti-static bags to store or transport the game circuit boards.
- Don't remove or connect electronic assemblies when cabinet power is on. Otherwise, you'll damage electronic assemblies and void the game's warranty.
- After you complete maintenance or service, replace ground wires, shields, safety covers and install and tighten ground and mounting screw.
- Video game monitors generate and store potentially high voltages. Avoid touching any part of the monitor until power has been off for some time. A picture tube can maintain a hazardous charge for up to several days. Only qualified technicians should service monitors.

Game Is Non-Functional

1.	Verify that the game power switch is turned on.
2.	Verify that the line cord connector is firmly and correctly seated into the power entry module of AC power chassis.
3.	Verify that correct AC line voltage is present at the outlet
4.	Verify that the JAMMA wire harness connector is firmly and properly seated to the mating JAMMA PCB edge connector. DO NOT remove or install JAMMA connector when power is turned on. Doing so will damage the CPU assembly and void the warranty.
5.	Verify that the DC power supply voltages at the game CPU assembly are set as follows. The following voltages should be set when the game CPU assembly is connected and the game is powered on. +5V: +4.9V - +5.1V /// +12V: +11.5V - +12.5V //// -5V:-4.75V - -5.25V

6.	Verify that the non-JAMMA connectors are attached at the proper location and are firmly seated.
7.	Verify that the game DIP switches are set properly.
8.	Inspect CPU board under low-light conditions. LED's glow if processor circuits receive voltage. These indications prove presence of some DC from power supply. Still, voltages or signals may not be present.

Monitor Is Non-Functional

1.	Verify that the cabinet AC line voltage cable is firmly and properly connected to mating AC connector on monitor.
2.	Verify that the cabinet video signal cable connector is firmly and properly connected to the mating video signal input connector of the monitor.
3.	Verify that the monitor remote adjustment board is properly installed and connected to the monitor chassis.
4.	Verify monitor is operating properly by replacing with know good unit.
5.	Verify that brightness and contrast are set above their minimum levels.
6.	Verify that the game is using a low-res monitor.

Sound Is Non-Functional

1.	Verify the cabinet wiring is correct. Ensure that the speakers are properly connected to the audio wires from the JAMMA connector.
2.	Verify that the power is providing: +5V: +4.9V - +5.1V +12V: +11.5V - +12.5V -5V: -4.75V - -5.25V
3.	Verify that the above listed voltages are present at the correct JAMMA connector pins.
4.	Verify that the game volume has been turned up.

Game Controls Are Non-Functional

1.	Verify that the each individual switch is working by doing the SWITCH INPUT TEST under the SYSTEM TESTS MENU.
2.	Verify that the each individual signal wire for each switch is connected.

Chapter 5 – Parts

Mechanical Parts

211	Low Ticket Switch
1024	Ticket Bin
5001	Coin Door
5008	Ticket Door
FG3004	Button Base – Left (Starfish)
FG3005	Button Base – Right (Starfish)
FG3014	Acrylic Ring Light Holder
FG3027	Monitor Glass
FG7012	Control Panel
FG7027	Marquee
FP1004	Leveler Foot
MZ2005	Button – Large Round White

Electrical Parts

2033X	Rope Light Controller PC Board
2133	Rope Light – Blue, Chasing
8716	Flash Card - Compact
FG2007	Speaker 6" X 9"
FG2052X	Main Harness
MON29CF	Monitor – 29" Flat Screen
RN2034FGX	PCB (Main)
WA2010	Power Supply

Graphics and Decals

FG7001	Decal – Cabinet Side
FG7005	Decal – Button
FG9010	Bezel