


# SUPPLEMENT

## 3 & 4 SHAFT DROP BOX

To be used in conjunction  
with the T12000 3, 4 & 6 Speed  
Intermediate Drop



CD-ROM: 8100038

MANUAL: 8100039

**SPICER OFF-HIGHWAY COMPONENTS**



---

## NOTICE

All information mentioned in the maintenance and service manual T12000 powershift transmission 3, 4 & 6 speed Intermediate Drop is valid, unless otherwise specified in this 3 & 4 shaft drop box supplement for the T12000 Intermediate Drop.

©Copyright **DANA CORPORATION** 1990. Unpublished material.

All rights reserved. Limited Distribution.

No part of this work may be reproduced in any form under any means without direct written permission of the **DANA CORPORATION**.



---

## FOREWORD

This manual has been prepared to provide the customer and the maintenance personnel with information and instructions on the maintenance and repair of the **SPICER OFF-HIGHWAY PRODUCTS** product.

Extreme care has been exercised in the design, selection of materials, and manufacturing of these units. The slight outlay in personal attention and cost required to provide regular and proper lubrication, inspection at stated intervals, and such adjustments as may be indicated, will be reimbursed many times in low cost operation and trouble-free service.

In order to become familiar with the various parts of the product, its principle of operation, troubleshooting and adjustments, it is urged that the mechanic studies the instructions in this manual carefully and uses it as a reference when performing maintenance and repair operations.

Whenever repair or replacement of component parts is required, only **SPICER OFF-HIGHWAY PRODUCTS** approved parts as listed in the applicable parts manual should be used. Use of "will-fit" or non-approved parts may endanger proper operation and performance of the equipment. **SPICER OFF-HIGHWAY PRODUCTS** does not warrant repair or replacement parts, nor failures resulting from the use of parts which are not supplied or approved by **SPICER OFF-HIGHWAY PRODUCTS**.




### IMPORTANT

ALWAYS FURNISH THE DISTRIBUTOR WITH THE SERIAL AND MODEL NUMBER WHEN ORDERING PARTS.



---


**3 SHAFT**





---

**4 SHAFT**





# Table of Content

<b>1. SAFETY PRECAUTIONS .....</b>	<b>1</b>
<b>2. CLEANING, INSPECTION AND LEGEND SYMBOLS .....</b>	<b>1</b>
2.1 CLEANING .....	1
2.1.1 Bearings .....	1
2.1.2 Housings .....	1
2.2 INSPECTION .....	1
2.2.1 Bearings .....	1
2.2.2 Oil seals, gaskets, etc. ....	2
2.2.3 Gears and Shafts .....	2
2.2.4 Housing, Covers, etc. ....	2
2.3 LEGEND SYMBOLS .....	2
<b>3. TECHNICAL SPECIFICATIONS .....</b>	<b>1</b>
3.1 IDENTIFICATION OF THE UNIT .....	1
3.2.1 Transmission with a 3 shaft Drop Box .....	2
3.2.2 Transmission with a 4 shaft Drop Box .....	2
3.3 TIGHTENING TORQUES .....	3
3.3.1 Torque specifications for lubricated or plated screw treads .....	3
3.3.2 Pipe plug torque chart .....	4
3.3.3 Permanent metric plug torque chart .....	4
<b>4. MAINTENANCE .....</b>	<b>1</b>
4.1 OIL SPECIFICATIONS .....	1
4.1.1 Recommended lubricants .....	1
4.2 MAINTENANCE INTERVALS FOR THE TRANSMISSION. ....	3
4.3 MAINTENANCE INTERVALS FOR THE 3 & 4 SHAFT DROP BOX .....	3
4.3.1 Daily .....	3
4.3.2 Normal drain period .....	3
<b>5 TROUBLESHOOTING GUIDE .....</b>	<b>1</b>
5.1 CHECK POINTS (3 SHAFT DROP BOX .....	1
5.1.1 Transmission with a 3 shaft drop box .....	1
5.1.2 Transmission with a 3 shaft drop box .....	2
5.1.3 Transmission with a 3 shaft drop box .....	3
5.2 CHECK POINTS (4 SHAFT DROP BOX .....	4
5.2.1 Transmission with a 4 shaft drop box .....	4
5.2.2 Transmission with a 4 shaft drop box .....	5
5.2.3 Transmission with a 4 shaft drop box .....	6
<b>6. SECTIONAL VIEWS AND PARTS IDENTIFICATION .....</b>	<b>1</b>
<b>7. ASSEMBLY INSTRUCTIONS .....</b>	<b>1</b>
<b>8 DISASSEMBLY AND REASSEMBLY 3 &amp; 4 SHAFT DROP BOX .....</b>	<b>1</b>



---

## 1. SAFETY PRECAUTIONS

To reduce the chance of personal injury and/or property damage, the following instructions must be carefully observed.

Proper service and repair are important to the safety of the service technician and the safe reliable operation of the machine. If replacement parts are required, the parts must be replaced by spare parts which have the same part number or with an equivalent part. **DO NOT USE A SPARE PART OF LESSER QUALITY.**

The service procedures recommended in this manual are effective methods for performing service and repair. Some of these procedures require the use of tools specifically designed for the purpose.

Accordingly, anyone who intends to use a spare part, service procedure or tool, which is not recommended by **SPICER OFF-HIGHWAY PRODUCTS**, must first determine that neither his safety nor the safe operation of the machine will be jeopardised by the spare part, service procedure or tool selected.



### IMPORTANT

IT IS IMPORTANT TO NOTE THAT THIS MANUAL CONTAINS VARIOUS 'CAUTIONS AND NOTICES' THAT MUST BE CAREFULLY OBSERVED IN ORDER TO REDUCE THE RISK OF PERSONAL INJURY DURING SERVICE OR REPAIR, OR THE POSSIBILITY THAT IMPROPER SERVICE OR REPAIR MAY DAMAGE THE UNIT OR RENDER IT UNSAFE.

IT IS ALSO IMPORTANT TO UNDERSTAND THAT THESE 'CAUTIONS AND NOTICES' ARE NOT EXHAUSTIVE, BECAUSE IT IS IMPOSSIBLE TO WARN ABOUT ALL POSSIBLE HAZARDOUS CONSEQUENCES THAT MIGHT RESULT FROM FAILURE TO FOLLOW THESE INSTRUCTIONS.



---

## 2. CLEANING, INSPECTION AND LEGEND SYMBOLS

### 2.1 CLEANING

Clean all parts thoroughly using solvent type cleaning fluid. It is recommended that parts be immersed in cleaning fluid and moved up and down slowly until all old lubricant and foreign material is dissolved and parts are thoroughly cleaned.



#### CAUTION

CARE SHOULD BE EXERCISED TO AVOID SKIN RASHES, FIRE HAZARDS, AND INHALATION OF VAPOURS WHEN USING SOLVENT TYPE CLEANERS.

#### 2.1.1 Bearings

Remove bearings from cleaning fluid and strike flat against a block of wood to dislodge solidified particles of lubricant. Immerse again in cleaning fluid to flush out particles. Repeat above operation until bearings are thoroughly clean. Dry bearings using moisture-free compressed air. Be careful to direct air stream across bearing to avoid spinning. DO NOT SPIN BEARINGS WHEN DRYING. Bearings may be rotated slowly by hand to facilitate drying process.

#### 2.1.2 Housings

Clean interior and exterior of housings, bearing caps, etc... thoroughly. Cast parts may be cleaned in hot solution tanks with mild alkali solutions providing these parts do not have ground or polished surfaces. Parts should remain in solution long enough to be thoroughly cleaned and heated. This will aid the evaporation of the cleaning solution and rinse water. Parts cleaned in solution tanks must be thoroughly rinsed with clean water to remove all traces of alkali. Cast parts may also be cleaned with steam cleaner.



#### CAUTION

CARE SHOULD BE EXERCISED TO AVOID INHALATION OF VAPOURS AND SKIN RASHES WHEN USING ALKALI CLEANERS.

All parts cleaned must be thoroughly dried immediately by using moisture-free compressed air or soft lintless absorbant wiping rags, free of abrasive materials such as metal fillings, contaminated oil or lapping compound.

### 2.2 INSPECTION

The importance of careful and thorough inspection of all parts cannot be overstressed. Replacement of all parts showing indication of wear or stress will eliminate costly and avoidable failures at a later date.

#### 2.2.1 Bearings

Carefully inspect all rollers: cages and cups for wear, chipping, or nicks to determine fitness of bearings for further use. DO NOT REPLACE A BEARING CONE OR CUP INDIVIDUALLY without replacing the mating cup or cone at the same time. After inspection, dip bearings in Automatic Transmission Fluid and wrap in clean lintless cloth or paper to protect them until installed.



### 2.2.2 Oil seals, gaskets, etc.

Replacement of spring load oils seals, "O" rings, metal sealing rings, gaskets and snap rings is more economical when the unit is disassembled than premature overhaul to replace these parts at a future time.

Further loss of lubricant through a worn seal may result in failure of other more expensive parts of the assembly. Sealing members should be handled carefully, particularly when being installed. Cutting, scratching or curling under of lips of seals seriously impairs its efficiency.

When assembling new metal type sealing rings, these should be lubricated with a coat of chassis grease to stabilise rings in their grooves for ease of assembly of mating members. Lubricate all "O" rings and seals with recommended type Automatic Transmission Fluid before assembly.





















### 2.2.3 Gears and Shafts

If Magna-Flux process is available, use process to check parts. Examine teeth on all gears carefully for wear, pitting, chipping, nicks, cracks or scores. If gear teeth show spots where case hardening is worn through or cracked, replace with new gear. Small nicks may be removed with suitable hone. Inspect shafts and quills to make certain they are not sprung, bent or spline-twisted, and that shafts are true.

### 2.2.4 Housing, Covers, etc.

Inspect housings, covers and bearing caps to ensure that they are thoroughly clean and that mating surfaces, bearing bores, etc... are free from nicks or burrs. Check all parts carefully for evidence of cracks or conditions which would cause subsequent oil leaks or failures.


## 2.3 LEGEND SYMBOLS

	Smontaggio di sottogruppi Disassembly of assembly groups		Sostituire con ogni montaggio Renew at each reassembly
	Montaggio di sottogruppi Reassemble to from assembly group		Togliere - mettere la sicura Unlock - lock e.g. split pin, locking plate, etc.
	Smontaggio di particolari ingombranti Remove obstruction parts		Mettere la sicura, incollare (mastice liquido) Lock - adhere (liquid sealant)
	Montaggio di particolari ingombranti Reinstall - remount parts which had obstructed disassembly		Evitare danni ai materiali, danni ai pezzi Guard against material damage, damage to parts
	Attenzione, indicazione importante Attention! important notice		Marchiare prima dello smontaggio (per il montaggio) Mark before disassembly, observe marks when reassembl.
	Controllare regolare p.e. coppie, misure, pressione etc. Check - adjust e.g. torque, dimensions, pressures etc.		Carricare riempire (olio - lubrificante) Filling - topping up - refilling e.g. oil, cooling water, etc.
	T = Attrezzature speciali P = Pagina T = Special tool P = Page		Scarricare olio, lubrificante Drain off oil, lubricant
	Rispettare direzione di montaggio Note direction of installation		Tendere Tighten - clamp ; tightening a clamping device
	Controllare esaminare controllo visuale Visual inspection		Inserire pressione nel circuito idraulico Apply pressure into hydraulic circuit
	Eventualmente riutilizzabile (sostituire se necessario) Possibly still serviceable, renew if necessary		Pulire To clean



---

### 3. TECHNICAL SPECIFICATIONS



#### 3.1 IDENTIFICATION OF THE UNIT

1. Model and Type of the unit
2. Serial number



## ***Technical specifications***

---

### **3.2 WEIGHT, DIMENSIONS, OIL CAPACITY**

#### **3.2.1 Transmission with a 3 shaft Drop Box**

Weight (dry):  $\pm 255$  kg [562 Lbs.]

Max. length: 529.3 mm [20.84"]

Max. Width: 872.0 mm [34.33"]

Max. Height: 619.2 mm [24.38"]

#### **Oil Capacity**

Transmission:  $\pm 13.5$  l [3.6 US gallon]

(without cooler and hydraulic lines.

Consult Operator's Manual on applicable machine for system capacity.)

Drop Box:  $\pm 0.75$  l [0.2 US gallon]

#### **3.2.2 Transmission with a 4 shaft Drop Box**

Weight (dry):  $\pm 272$  kg [600 Lbs.]

Max. length: 529.3 mm [20.84"]

Max. Width: 1007.2 mm [39.66"]

Max. Height: 619.2 mm [24.38"]

#### **Oil Capacity**

Transmission:  $\pm 13.5$  l [3.6 US gallon]

(without cooler and hydraulic lines.

Consult Operator's Manual on applicable machine for system capacity.)

Drop Box:  $\pm 1.0$  l [0.26 US gallon]



#### **NOTE:**


THE OIL OF THE DROP BOX IS COMPLETELY SEPARATED FROM THE OIL OF THE TRANSMISSION.




## Technical specifications

### 3.3 TIGHTENING TORQUES

#### 3.3.1 Torque specifications for lubricated or plated screw threads

NOM. SIZE	GRADE 5 			
	FINE THREAD		COARSE THREAD	
	LBF - FT	[N.m]	LBF - FT	[N.m]
.2500	9 - 11	[12 - 15]	8 - 10	[11 - 14]
.3125	16 - 20	[22 - 27]	12 - 16	[16 - 22]
.3750	26 - 29	[35 - 39]	23 - 25	[31 - 34]
.4375	41 - 45	[56 - 61]	37 - 41	[50 - 56]
.5000	64 - 70	[87 - 95]	57 - 63	[77 - 85]
.5625	91 - 100	[123 - 136]	82 - 90	[111 - 122]
.6250	128 - 141	[174 - 191]	113 - 124	[153 - 168]
.7500	223 - 245	[302 - 332]	200 - 220	[271 - 298]

NOM. SIZE	GRADE 8 			
	FINE THREAD		COARSE THREAD	
	LBF - FT	[N.m]	LBF - FT	[N.m]
.2500	11 - 13	[15 - 18]	9 - 11	[12 - 15]
.3125	28 - 32	[38 - 43]	26 - 30	[35 - 41]
.3750	37 - 41	[50 - 56]	33 - 36	[45 - 49]
.4375	58 - 64	[79 - 87]	52 - 57	[71 - 77]
.5000	90 - 99	[122 - 134]	80 - 88	[108 - 119]
.5625	128 - 141	[174 - 191]	115 - 127	[156 - 172]
.6250	180 - 198	[224 - 268]	159 - 175	[216 - 237]
.7500	315 - 347	[427 - 470]	282 - 310	[382 - 420]

NOM. SIZE	GRADE 8.8 or 9.8		GRADE 10.9	
	COARSE THREAD		COARSE THREAD	
	LBF - FT	[N.m]	LBF - FT	[N.m]
M10	30 - 37	[40 - 50]	44 - 48	[60 - 65]
M12	50 - 55	[65 - 75]	74 - 81	[100 - 110]
M16	125 - 140	[170 - 190]	177 - 203	[240 - 275]



### 3.3.2 Pipe plug torque chart

THREAD NPTF	TORQUE	
	LBF - FT	[N.m]
1/16-27	5-7	[7-9]
1/8-27	7-10	[9-14]
1/4-18	15-20	[20-27]
3/8-18	25-30	[34-41]
1/2-14	30-35	[41-47]
3/4-10	40-45	[54-61]

### 3.3.3 Permanent metric plug torque chart

THREAD SIZE	TORQUE	
	LBF - FT	[N.m]
M18 x 1.5 6H	25-30	[34-41]
M26 x 1.5 6H	45-50	[61-68]



---

## 4. MAINTENANCE

### 4.1 OIL SPECIFICATIONS

Both transmission and Drop Box use the same type of oil.

#### 4.1.1 Recommended lubricants

- |                |                                |
|----------------|--------------------------------|
| 1. Caterpillar | TO-4                           |
| 2. John Deere  | J20 C, D                       |
| 3. Military    | MIL-PRF-2104G                  |
| 4. Allison     | C-4                            |
| 5. Dexron*     | II Equivalent - See note below |



#### Note:

DEXRON\* II EQUIVALENT IS ACCEPTABLE; HOWEVER IT IS NOT COMPATIBLE WITH TORQUE CONVERTERS OR TRANSMISSIONS EQUIPED WITH GRAPHITIC FRICTION MATERIAL CLUTCH PLATES.



#### Caution:

DEXRON\* III, ENGINE OIL OR GL-5 OILS ARE NOT RECOMMENDED.

### PREFERRED OIL VISCOSITY


It is recommended that the highest viscosity monograde lubricant available be used for the anticipated ambient temperature. Typically this will be a CAT TO-4 qualified lubricant. When large swings in ambient temperature are possible, J20 C, D multigrades are recommended. Multigrade lubricants should be applied at the lower viscosity rating for the prevailing ambient temperature, i.e. a 10W20 should be used where a 10W monograde is used. If a C-4 multigrade is used instead of J20 lubricant it is recommended that the viscosity spans no more than 10 points, i.e. 10W20.



#### Caution:

SYNTHETIC LUBRICANTS ARE APPROVED IF QUALIFIED BY ONE OF THE ABOVE SPECIFICATIONS. OIL VISCOSITY GUIDELINES APPLY, BUT SYNTHETIC MULTIGRADES MAY SPAN MORE THAN 10 POINTS.

FOR FIRE RESISTANT FLUID RECOMMENDATIONS PLEASE CONTACT **SPICER OFF-HIGHWAY PRODUCTS**.





### **NORMAL OIL CHANGE INTERVAL**

Drain and refill system every 1000 hours of average environmental and duty cycle conditions. Severe or sustained high operating temperature or very dusty atmospheric conditions will result in accelerated deterioration or contamination. Judgement must be used to determine the required change intervals for extreme conditions.

### **EXTENDED OIL CHANGE INTERVAL**

Extended oil service life may result when using synthetic fluids. Appropriate change intervals should be determined for each transmission by measuring oil oxidation and wear metals over time, to determine a baseline. Wear metal analysis can provide useful information, but a transmission should not be removed from service based solely on this analysis.

---

\* Dexron is a registered trademark of GENERAL MOTORS CORPORATION.




### 4.2 MAINTENANCE INTERVALS FOR THE TRANSMISSION.




#### NOTE:

TO DRAIN THE TRANSMISSION, BOTH DRAIN PLUGS (A & B) NEED TO BE REMOVED

- 3 shaft drop box




REAR VIEW




LEFT VIEW

- 4 shaft drop box



REAR VIEW



LEFT VIEW

### 4.3 MAINTENANCE INTERVALS FOR THE 3 & 4 SHAFT DROP BOX

#### 4.3.1 Daily

Check oil level daily.

Maintain oil level at full mark. (Middle of oil level glass)

#### 4.3.2 Normal drain period

Normal drain period is every 1000 hours for average environment and duty cycle condition.

Severe or sustained high operating temperature or very dusty atmospheric conditions will cause accelerated deterioration and contamination.


For extreme conditions judgement must be used to determine the required change intervals.




## 5 TROUBLESHOOTING GUIDE

### 5.1 CHECK POINTS

#### 5.1.1 Transmission with a 3 shaft drop box



FRONT VIEW





LEFT SIDE VIEW



### 5.1 CHECK POINTS (CONTINUED)

#### 5.1.2 Transmission with a 3 shaft drop box






## Troubleshooting guide

---

### 5.1 CHECK POINTS (CONTINUED)


#### 5.1.3 Transmission with a 3 shaft drop box





### 5.1 CHECK POINTS (CONTINUED)



#### 5.2.1 Transmission with a 4 shaft drop box





### 5.1 CHECK POINTS (CONTINUED)

#### 5.2.2 Transmission with a 4 shaft drop box






## Troubleshooting guide

### 5.1 CHECK POINTS (CONTINUED)

#### 5.2.3 Transmission with a 4 shaft drop box






---

**6. SECTIONAL VIEWS AND PARTS IDENTIFICATION**



## TRANSMISSION CASE & PLATE GROUP






## TRANSMISSION CASE & PLATE GROUP

Item	Description	Qty
1	Case - Transmission .....	1
2	Breather - Air .....	1
3	Nipple Pipe .....	1
4	Coupling - Pipe .....	1
5	Fitting - Elbow .....	1
6	Plug - Magnetic drain .....	2
7	Pin - Plate to transmission case dowel .....	2
8	Gasket - Plate to transmission case .....	1
9	Ring - Oil supply tube seal .....	1
10	Plate - Spacer .....	1
11	Seat - Safety valve .....	1
12	Snpring - Seat .....	1
13	poppet - Converter safety valve .....	1
14	Spring - Converter safety valve .....	1
15	Washer - Puppet retaining .....	1
16	Plug .....	1
17	Plug .....	3
18	"O" ring - Plug .....	3
19	Screw - Plate to transmission case .....	7
20	Screw - Plate to transmission case .....	2
21	Lockwasher - Plate to transmission .....	9
22	Assembly - Tube & screen .....	1
23	Plug - Filler .....	1
24	Plug .....	1
25	Plug .....	1
26	Assembly - Dipstick tube .....	1
27	Dipstick .....	1
28	Plug - Speed sensor port .....	2
29	"O" ring - Speed sensor port plug .....	2
30	Screw - Speed sensor port plug .....	2



### 3 SHAFT DROP BOX GROUP






### 3 SHAFT DROP BOX GROUP

Item	Description	Qty
1	Cover - Drop box front .....	1
2	Cover - Drop box rear .....	1
3	Gasket - Rear to front cover .....	1
4	Shaft - Drop box input .....	1
5	Gear - Drop box idler .....	1
6	Shaft - Drop box output .....	1
7	Bearing - Drop box input shaft .....	2
8	Bearing - Drop box output shaft .....	2
9	Bearing - Drop box idler shaft .....	2
10	Pin - Dowel .....	2
11	Screw - Rear cover to front cover .....	10
12	Lockwasher - Rear cover to front cover screw .....	10
13	Seal - Drop box output shaft oil .....	2
14	Flange - Output .....	2
15	"O" ring - Output flange .....	2
16	Washer - Output flange .....	2
17	Nut - Output flange .....	2
18	Sleeve - Oil seal .....	1
19	"O" ring - Oil seal sleeve .....	1
20	Seal - Oil seal sleeve oil .....	2
21	Lockwasher - Drop box mounting screw .....	8
22	Screw - Drop box mounting .....	8
23	Glass - Oil level .....	1
24	Plug - Magnetic drain .....	1
25	Plug .....	1
26	"O" ring - Plug .....	1
27	Sleeve - Pilot .....	1
28	"O" ring - Sleeve .....	2
29	Ring - Retaining .....	1
30	Breather - Air .....	1
31	Fitting - Elbow 90° street .....	1
32	Sticker .....	1



## 4 SHAFT DROP BOX GROUP





## 4 SHAFT DROP BOX GROUP

Item	Description	Qty
1	Cover - Drop box rear .....	1
2	Cover - Drop box front .....	1
3	Gasket - Rear to front cover .....	1
4	Shaft - Drop box input .....	1
5	Shaft - Drop box idler .....	1
6	Shaft - Drop box idler .....	1
7	Shaft - Drop box output .....	1
8	Bearing - Drop box input shaft .....	2
9	Bearing - Drop box output shaft .....	2
10	Bearing - Drop box idler shaft .....	4
11	Pin - Dowel .....	2
12	Screw - Rear cover to front cover .....	13
13	Lockwasher - Rear cover to front cover screw .....	13
14	Seal - Drop box output shaft .....	2
15	Flange - Output .....	2
16	"O" ring - Output flange .....	2
17	Washer - Output flange .....	2
18	Nut - Output flange .....	2
19	Sleeve - Oil seal .....	1
20	"O" ring - Oil seal sleeve .....	1
21	Seal - Oil seal sleeve oil .....	1
22	Lockwasher - Drop box mounting screw .....	8
23	Screw - Drop box mounting .....	8
24	Plug - Magnetic drain .....	1
25	Glass - Oil level .....	1
26	Plug .....	1
27	Sleeve - Pilot .....	1
28	"O" ring - Sleeve .....	2
29	Ring - Retaining .....	1
30	Breather - Air .....	1
31	Fitting - Elbow 90° street .....	1
32	Sticker .....	1




---

**7. ASSEMBLY INSTRUCTIONS**



# 7. ASSEMBLY INSTRUCTIONS


## 3 Shaft Drop Box





7. ASSEMBLY INSTRUCTIONS (CONTINUED)

4 Shaft Drop Box





---

## 8 DISASSEMBLY AND REASSEMBLY 3 & 4 SHAFT DROP BOX




**Note:**


THIS SECTION SHOWS DISASSEMBLY AND REASSEMBLY OF A 4 SHAFT DROP BOX. THE PROCEDURE IS ALSO VALID FOR THE 3 SHAFT DROP BOX AS IT HAS ONLY ONE IDLER GEAR AND SHAFT, WHEREAS THE 4 SHAFT DROP BOX HAS TWO.




## Disassembly of 4 shaft drop box




**Figure 1**  
Front view of 4 shaft drop box.



**Figure 4**  
Remove coupling sleeve.



**Figure 2**  
Support box with chain hoist. Remove drop box mounting screws and lockwashers.



**Figure 5**  
Remove output shaft front bearing retaining ring.




**Figure 3**  
Pry box from transmission housing.



**Figure 6**  
Remove output gear retaining ring.




## Disassembly of 4 shaft drop box




**Figure 7**

From the rear, remove output shaft bore plug.




**Figure 10**

Remove output shaft gear and retaining ring.




**Figure 8**

From the front tap output shaft and rear bearing from housing.




**Figure 11**

Remove output shaft front bearing.



**Figure 9**

Output shaft and rear bearing removed.



**Figure 12**


Remove output shaft front bearing retaining ring.



---



## Disassembly of 4 shaft drop box

---



**Figure 13**

From the rear, remove rear bearing retaining ring.






---


## Disassembly of 4 shaft drop box

---




**Figure 14**

Use an impact wrench to loosen flange nut.



**Figure 17**

Use a gear puller to remove pilot sleeve.



**Figure 15**

Output flange (rear) "O" ring, washer and nut removed.




**Figure 18**

Pilot sleeve and inner "O" ring removed.



**Figure 16**

Remove sleeve outer "O" ring.



**Figure 19**

Remove coupling sleeve retaining ring.



---

## Disassembly of 4 shaft drop box

---




**Figure 20**

Use an impact wrench to loosen flange nut.



**Figure 23**

Support front cover with a chain hoist. Pry front cover from rear cover.



**Figure 21**

Output flange (front) "O" ring, washer and nut removed.




**Figure 24**

Front cover removed.



**Figure 22**

Remove front to rear cover screws and lockwashers.




**Figure 25**

Remove idler shaft and gear.




## Disassembly of 4 shaft drop box



**Figure 26**

Remove idler shaft and gear.



**Figure 29**

Output shaft assembly removed.




**Figure 27**

Pry input assembly from cover.



**Figure 30**

If bearing outer races have to be replaced, remove outer races.



**Figure 28**

Input shaft assembly removed.



**Figure 31**

Remove seal sleeve retaining ring.







**Figure 32**  
Tap seal sleeve from cover.



**Figure 33**  
Seal sleeve removed.





## Reassembly of 4 shaft drop box

Refer to "Cleaning & Inspection" pages.



**Figure 34**

Install two new oil seals in the seal sleeve.  
See assembly instructions (page 7-2 and 7-3).



**Figure 37**

With new "O" rings installed. Tap center sleeve into position.



**Figure 35**

Install two new output shaft oil seals in front and rear cover.  
See assembly instructions (page 7-2 and 7-3).



**Figure 38**

With new "O" ring installed. Install seal sleeve.



**Figure 36**

Install seal sleeve retaining ring.



**Figure 39**

Install input shaft into rear cover.  
Use caution as not to damage oil seals.





## Reassembly of 4 shaft drop box




**Figure 40**

Install output shaft into rear cover.  
Use caution as not to damage oil seal.



**Figure 43**

Position new gasket on rear cover.




**Figure 41**

If bearing outer races have been removed,  
install bearing outer races.



**Figure 44**

Position drop box front cover on rear cover.  
Use caution as not to damage oil seal.



**Figure 42**

Install idler shafts and gears.



**Figure 45**

Install capscrews and lockwashers.





**Reassembly of 4 shaft drop box**



**Figure 46**  
Tighten screws to specified torque.  
(See torque chart).




**Figure 47**  
Install coupling sleeve retaining ring.






## Reassembly of 4 shaft drop box




**Figure 48**  
Install output shaft rear bearing locating ring.




**Figure 51**  
Install output shaft rear bearing in case against locating ring.



**Figure 49**  
Install output shaft front bearing locating ring.



**Figure 52**  
Position output shaft. Align splines on shaft with splines in output gear. Tap shaft into position.



**Figure 50**  
From the front of transmission case, position output gear with long hub of gear towards the front.



**Figure 53**  
Install new bore plug.







---

## Reassembly of 4 shaft drop box


---



**Figure 54**  
Install output shaft gear retaining ring.



**Figure 57**  
Install coupling sleeve.



**Figure 55**  
Install output shaft front bearing in case against locating ring.



**Figure 58**  
Install drop box assembly.



**Figure 56**  
Install front bearing retaining ring.



**Figure 59**  
Install drop box mounting screws and lockwashers. Tighten to specified torque. (See torque chart).




---

## Reassembly of 4 shaft drop box

---



**Figure 60**  
Install front and rear output flanges.



**Figure 63**  
Install breather.



**Figure 61**  
Install flange "O" rings, washers and nuts



**Figure 62**  
Block flanges to prevent turning.  
Tighten flange nuts to specified torque.  
See assembly instructions page 7-4.

