

# ISOBAR II


---

## Service Manual

---

---

### Main Menu



1. To Enter Main Menu Press the *Menu/Enter* Button  
(Time of Day will Flash)
2. To Set the **Time of Day** Press the *Set/Change* Button  
(First Digit will Flash) *Example [ 12:00 ]*
  - To Change Digit Value Press the *Set/Change* Button
  - To Accept the Digit Value Press the *Menu/Enter* Button
  - Next Digit will Flash to Begin Setting
  - Once the Last Digit Display is Accepted all Digits will Flash
3. To Set **A.M or P.M.** Press the *Menu/Enter* Button *Example [ A ]*
  - To Change Digit Value Press the *Set/Change* Button
  - To Accept the Digit Value Press the *Menu/Enter* Button
  - Once A.M./P.M. is Accepted the Next Menu Item will Flash
4. To Set the **Number of Days between Regeneration Cycles (A)** Press the *Set/Change* Button *Example [ A - 07 ]*
  - Repeat instructions from step (2)
  - Notes: 1) Maximum Value is 29
  - 2) If Value Set to 0, Automatic Regeneration will Never Occur
  - 3) Default Setting is 7 days
  - 4) On Metered models an "H" will appear to enter Compensated Hardness *Example [ H-20 ]*
5. To Set the **Number of Days between Air-Draw Cycles (d)** Press the *Set/Change* Button *Example [ d - 01 ]*
  - Repeat instructions from step (2) **"Used on Centurion Filter Only"**
  - Notes: 1) Maximum Value is 29
  - 2) If Value Set to 0, Air-Draw is Turned Off, but an Air Cycle will still be Completed when a Regeneration Cycle Occurs. If the *Number of Days between Air-Draw Cycles* is set to a Higher Number of Days than the *Number of Days between Regeneration Cycles*, it will have No Effect. In Order to turn Off All Cycles, both the *Days Between Regeneration* and *Days Between Air-Draw Cycles* must be Set to 0.
  - 3) Default Setting is 1 day
6. To Exit Main Menu Press the *Menu/Enter* Button  
Note: If No Buttons are Pressed for 60 Seconds, the Main Menu will be Exited Automatically.

### Normal Operation

#### 1. *Home Display*

- Alternates Between the display of *Time of Day* and *Number of Days Until the Next Regeneration*.
- *Days Remaining Until the Next Regeneration* will Count Down from the entered Regeneration Day Override Value Until it Reaches 0 Days Remaining.
- A Regeneration Cycle will then be Initiated at the next Designated Regeneration Time
- **Metered** models alternate the *Time of Day* and *Gallons Left Until the Next Regeneration*. The meter will count down to zero and then regenerate at the scheduled time set.

#### 2. *Battery Back-Up* (Uses a Standard 9-Volt Alkaline Battery)

- Installing the Battery
- Features of Battery Back-Up
  - Maintains the *Time of Day* During Power Failures


- Notes:
- 1) During Power Failures, the Display is Turned Off to Conserve Battery Power. However, to Confirm that the Battery is Working, Press Either Button and the Display will Turn On for Five Seconds.
  - 2) If Power Failure Occurs while System is Regenerating, the Isobar II Completes its Current Position and then Pauses Until Power is Restored. The Next Position is then Commenced from its Beginning.
  - 3) When Used without Battery Back-Up, the Unit Acts Like a Standard Valve—When a Power Failure Occurs, the Unit Stops at its Current Point in the regeneration Position and then Restarts at that Point when the Power is Restored. However, the Time will be Offset by the Increment of Time the Unit was without Power.

### Electronic Connections

**P = Power Supply**

**B = Powered in Backwash Cycle Only**

**S = Powered in Entire Regen. Cycle**



## Starting Extra Regeneration Cycle

---

1. To Start **Delayed Extra Cycle** *Example [ 1 ]*
  - If *Days Remaining Until Next Regeneration* does not Read '1', Press and Hold the *Set/Change* Button for 3 Seconds Until the Display Reads '1' or '0000' on metered models
  - Regeneration Cycle will Initiate at the Next Designated Regeneration Time
2. To Start **Immediate Extra Cycle** → First Complete Above Step
  - With *Days Remaining Until the Next Regeneration* at '1' or '0000'
  - Press and Hold the *Set/Change* Button
  - After 3 Seconds the Regeneration Cycle will Begin
3. To **Fast Cycle** Thru Regeneration → First Complete Above 2 Steps  
Note: *Fast Cycling* is Not Necessary unless Desired to Manually Step Through Each Cycle Step
  - Press and Hold the *Set/Change* Button for 3 Seconds to Advance to the Next Cycle Step

### Softeners

- Step 1: Backwash
- Step 2: Brine and Rinse
- Step 3: Rapid Rinse
- Step 4: Brine Refill

### Filters

- Step 1: Backwash
- Step 2: Rest
- Step 3: Rapid Rinse
- Step 4: Not used

## Centurion Only Regeneration Cycle Step Explanations

**Step 1: Air Release Step**  
For 3 to 4 Minutes  
- Not Programmable



**Step 4: Rapid Rinse Step**  
- Default of 12 Minutes



**Step 2: Backwash Step**  
- Default of 20 Minutes



2-20

**Step 3: Rest Step**  
- Default of 12 Minutes




**Step 5: Air Draw Step**  
- Default of 12 Minutes



**Notes:**

- When the Valve is Between Positions, the Display will Flash the Number of the Step it is Moving Towards.
- The Default Time at Which a Regeneration will Occur is 2:00 A.M.

**New feature:** The Motor's Run Direction During a Particular Regeneration Cycle Step is Indicated by the Rotation Direction of the Last 2 Digit Displays.



### Final Set-Up

---

With Proper Valve Operation Verified:

1. Add water to the top of the air check. Manually step the valve to the Brine Draw Position and allow the valve to draw water from the brine tank until it stops. Note: The air check will check at approximately the midpoint of the screened intake area.
  2. Next, manually step the valve to the Brine Refill Position and allow the valve to return to Service automatically.
  3. With the valve in Service, check that there is about 3.0' to 5.0' above the grid in the brine tank, if used.
  4. Fill the brine tank with salt to complete Set-Up. The control will run automatically.
- 

### Error Codes

There are four (4) error codes which could indicate a possible problem with the control valve:

**Error 2** - Homing slot expected. Valve will begin searching for home  
(Normal operation continues)

**Error 3** - Encoder is not sending a signal  
(Valve requires service to continue)

**Error 4** - Unable to find homing slot  
(Valve requires service to continue)

**Error 5** - Motor overload (stalled position or shorted motor)  
(Valve requires service to continue)

Error 5 Explanation: The unit thinks the motor is locked. This can only happen when the valve is running the motor, it is not seeing any encoder slots, and the motor is overloaded. This usually alerts the presence of corrosion inside the valve clogging the system

## Master Programming Mode

---

To Enter Master Programming Mode, Press and Hold both Buttons for 5 Seconds.

Note: all Master Programming functions have been preset at the factory. Unless a change is desired, it is **NOT** necessary to enter Master Programming Mode.

### 1. **Regeneration Type (t)**

- This Display is used to set the Regeneration Type. This option setting is identified by the letter 't' in the left digit. There are two possible settings:
- **Timeclock / Filter Delayed** – The control will determine that regeneration is required when the set regeneration time has been reached. The regeneration frequency setting will determine which days a regeneration cycle will be initiated. Example (t - - c)
- **Meter Delayed (Demand)** The control will determine that a regeneration is required when the available volume of softened water drops to or below zero. Regeneration is to begin at the scheduled time set. Example (t - - d)
  - The Set/Change button will adjust this value. To accept the digit value press the Menu/Enter button.

### 2. **Regeneration Day Override (A) – Meter Mode Only**

- Press Menu/Enter button. This display is used to set the maximum amount of time (in days) the unit can be in service without a regeneration. This option setting is identified by the letter 'A' in the left digit. Regeneration will begin at the scheduled time. A setting of zero will cancel this feature.
- Example: Override every 7 days (A- 07) or Cancel setting (A-00) Maximum setting is 29.

### 3. To Set **Regeneration Time (r)**

*Example [r 12A]*

- The time of day at which a regeneration may take place is designated by the letter 'r'.
- The first display digit indicates A.M or P.M. To change the value press the *Set/Change* button.
- Press *Menu/Enter* button to accept the value and move to the next digit.
- The second and third display digits indicate the hour at which the regeneration will occur.
- Change the Digits with the *Set/Change* button and accept with the *Menu/Enter* button.
- After the entire display flashes, press the *Menu/Enter* button to move to the next menu item.

### 4. To Set **Regeneration Cycle Step Times (2)(3)(4)(5)**

*Example [ # - 20]*

- The next 4 displays set the duration of time in minutes for each regeneration cycle step.
- The step number which is currently modifiable is indicated on the far left of the display screen.
- The number of minutes allotted for the selected regeneration step is displayed on the far right.
- Change the digits values using the *Set/Change* and *Menu/Enter* buttons as described above.

#### Note on Air-Draw Cycle (5): Centurion Filter Only

The longer the unit is set to remain in the air-draw cycle (5), the more air is drawn into the system. A default setting of 12 minutes draws air down to the level of a normal resin bed height and then returns the unit to the home display. If the system needs more air, increase the time setting for step (5) or change the number of days between air-draw cycles to 2-3 days (or lower than your current setting). There is no way to view the number of days until the next air draw will take place.

---

### 5. System Capacity in Grains (c) – Meter Mode Only


- Press the Menu/Enter button. This display is used to set the system capacity in grains and is used in conjunction with the hardness setting to calculate total gallons of treated water available between regenerations. This option is identified by the letter 'c' in the left digit. The maximum value for this item is 399.  
Example: 32,000 grain capacity (c 032)

### 6. To Exit the Master Programming Mode Press the *Menu/Enter* Button


**Note:** If no buttons are pressed for 60 seconds, the Master Programming Mode will be exited automatically.



## Master Programming Mode Flow Chart




# Control Valve Drive Assembly



## Valve Drive Assembly Parts List

	<u>Part Number</u>	<u>Description</u>
1	20111X001	Slide Cover
2	20111X002	Front Bracket
3	20001X124	Encoder
4	20001X004	Front Plate
5	20001X007	Encoder Wheel
6	20001X120	Main Gear
7	20001X001	Screws Power Head
8	20001X005	Back Plate
9	20111X003	Back Bracket
10	VH1-B (Softeners)	Body Assembly
	VH2-B (Filters)	Body Assembly
11	EVB-015	Elec. Board Soft & Filter
	EVB-015-CF	Elec. Board Centurion
	20111X012	Nipple Check Valve
	20111X009	Air Injector Assembly
	20111X013	Air Injector O-Ring
	EVB-010 MTR PA	Motor
	EVB-015 MTR	Centurion Motor
	20111X010	Electronic Housing Cover
	20111X007	Electronic Housing Button
	L-Iso2S, L-Iso2F, L-CF	Electronic Housing Label
<b>11</b>	<b>Not Shown</b>	

# Control Valve Drive Assembly (Softener Version)



# Control Valve Drive Assembly Parts List


(Softener Version)

Ref #	Description	Part #	Qty
0	Valve Body Complete	20001X200	1
1	Valve Body Only	20001X201	1
2	End Spacer	N/S	1
3	Seal	N/S	5
4	Spacer	N/S	4
4A	Seal & Spacer Kit - Incl. (1) #2, (5) #3, & (4) #4	20001X232	1
5	Down Flow Piston	N/S	1
6	Piston End Rod Retainer	N/S	1
7	End Plug Assembly	N/S	1
8	<b>Piston Arm</b>	<b>N/S</b>	<b>1</b>
8A	Piston Assembly - Incl. (1) EA. #5 Through #8	20001X231	1
9	Hex Washer HD. 10-24 X 13/16" Screw	N/S	3
10	Drain Retainer	20001X214	1
11	O-Ring	20251X254	1
12	Flow Control Button 1.5 GPM	20251X266	1
	Flow Control Button 2.0 GPM	20251X267	1
	Flow Control Button 2.4 GPM	20251X268	1
	Flow Control Button 3.0 GPM	20251X269	1
	Flow Control Button 3.5 GPM	20251X270	1
	Flow Control Button 4.0 GPM	20251X271	1
	Flow Control Button 5.0 GPM	20251X272	1
	Flow Control Button 7.0 GPM	20251X274	1
13	Plastic Flow Control Housing	N/S	1
14	Drain Line Fitting 90° Elbow 1/2" NPT X 1/2" Tubing	20251X255	1
14A	Flow Control Assembly - Specify GPM on Order. - Incl. (1) EA. #11 Through #14		
	Flow Control Assembly 1.5 GPM - PVC	20251X256	1
	Flow Control Assembly 2.0 GPM - PVC	20251X257	1
	Flow Control Assembly 2.4 GPM - PVC	20251X258	1
	Flow Control Assembly 3.0 GPM - PVC	20251X259	1
	Flow Control Assembly 3.5 GPM - PVC	20251X260	1
	Flow Control Assembly 4.0 GPM - PVC	20251X261	1
	Flow Control Assembly 5.0 GPM - PVC	20251X262	1
	Flow Control Assembly 7.0 GPM - PVC	20251X264	1

15	O-Ring	20561X204	1
16	O-Ring	20001X215	1
17	O-Ring	N/S	2
18	Injector Plug	N/S	1
19	O-Ring	N/S	2
19A	Injector Plug & O-Ring Assembly - Incl. (1) EA. #17 Through #19	20001X217	1
20	Injector Seal	20001X224	1
21	Injector Cap	20001X223	1
22	10-24 X 1 Hex Washer HD Screw	20001X226	2
22A	Filter Conversion Kit - Incl. (1) EA. #19A, #24A, #26A, #20, #21, & (2) #22	20001X221	1
23	O-Ring	N/S	1
24	Filter Plug	N/S	1
24A	O-Ring & Filter Plug Assembly - Incl. (1) EA. #23 & #24	20001X229	1
25	O-Ring	N/S	1
26	Brine Valve Cap	N/S	1
26A	O-Ring & Brine Valve Cap Assembly	20001X230	1
Items #27 Through #30 Used Only With Clock Regeneration			
27	Adapter Coupling	N/S	2
28	O-Ring	20561X216	4
28A	Adapter Coupling & O-Ring Assembly - Incl. (1) #27 & (2) #28	20561X215	1
29	Mounting Clip	20561X201	2
30	8-18 X 5/8" Hex Washer HD Screw	20561X217	2

N/S Indicates Non-Stocked Item  
 Shaded Ref # Indicates Assembly or Kit

# Control Valve Assembly (Filter Version)



## Control Valve Drive Assembly Parts List *(Filter Version)*


Ref #	Description	Part #	Qty
0	Valve Body Complete	20001X200	1
1	Valve Body Only	20001X201	1
2	End Spacer	N/S	1
3	Seal	N/S	5
4	Spacer	N/S	4
4A	Seal & Spacer Kit - Incl. (1) #2, (5) #3, & (4) #4	20001X232	1
5	Down Flow Piston	N/S	1
6	Piston End Rod Retainer	N/S	1
7	End Plug Assembly	N/S	1
8	<b>Piston Arm</b>	<b>N/S</b>	<b>1</b>
8A	Piston Assembly - Incl. (1) EA. #5, #6, #7, & #8	20001X231	1
9	Hex Washer HD. 10-24 X 13/16" Screw	N/S	3
10	Brine Valve Seat	N/S	1
11	Brine Valve Stem	N/S	1
12	Brine Valve Spacer	N/S	1
13	O-Ring	N/S	1
14	Quad Ring	N/S	1
15	Brine Valve Cap	N/S	1
16	Brine Valve Spring	N/S	1
17	Plain Nylon Washer	N/S	1
18	Retaining Ring	N/S	1
18A	Brine Assembly - Incl. (1) EA. #10 Through #18	20001X210	1
19	Drain Retainer	20001X214	1
20	O-Ring	20251X254	1
21	Flow Control Button 1.5 GPM	20251X266	1
	Flow Control Button 2.0 GPM	20251X267	1
	Flow Control Button 2.4 GPM	20251X268	1
	Flow Control Button 3.0 GPM	20251X269	1
	Flow Control Button 3.5 GPM	20251X270	1
	Flow Control Button 4.0 GPM	20251X271	1
	Flow Control Button 5.0 GPM	20251X272	1
	Flow Control Button 7.0 GPM	20251X274	1
22	Plastic Flow Control Housing	N/S	1
23	Drain Line Fitting 90° Elbow 1/2" NPT X 1/2" Tubing	20251X255	1
23A	Flow Control Housing - Specify GPM on Order. - Incl. (1) EA. #20 Through #23		
	Flow Control Assembly 1.5 GPM - PVC	20251X256	1
	Flow Control Assembly 2.0 GPM - PVC	20251X257	1
	Flow Control Assembly 2.4 GPM - PVC	20251X258	1
	Flow Control Assembly 3.0 GPM - PVC	20251X259	1
	Flow Control Assembly 3.5 GPM - PVC	20251X260	1
	Flow Control Assembly 4.0 GPM - PVC	20251X261	1
	Flow Control Assembly 5.0 GPM - PVC	20251X262	1
Flow Control Assembly 7.0 GPM - PVC	20251X264	1	

Ref #	Description	Part #
24	O-Ring	20561X204
25	O-Ring	20001X215
26	O-Ring	N/S
27	Injector Plug	N/S
28	O-Ring	N/S
28A	Injector Plug & O-Ring Assembly - Incl. (1) EA. #26, Through #28	20001X217
29	Injector Throat	N/S
30	Injector Nozzle	N/S
31	Vortex Generator	N/S
31A	Injector Assembly - Specify Size Incl. (1) EA. #26, & #28 Through #31	20001X219
32	Injector Screen	20001X222
33	Injector Seal	20001X224
34	Injector Cap	20001X223
35	10-24 X 1 Hex Washer HD Screw	20001X226
35A	Injector Kit - Specify Size - Incl. (1) EA. #31A, #32, #33, #34, & (2) #35	20001X220
36	BLFC Button Retainer	20561X240
37	5 GPM BLFC Button	20251X318
38	O-Ring	20561X239
39	BLFC Adapter	20561X241
39A	BLFC Assembly .5 GPM - Incl. (1) EA. #36 through #39	20001X228

Items #40 Through Used Only With Clock Regeneration			
40	Adapter Coupling	N/S	2
41	O-Ring	20561X216	4
41A	Adapter Coupling & O-Ring Assembly - Incl. (1) #40 & (2) #41	20561X215	1
42	Mounting Clip	20561X201	2
43	8-18 X 5/8" Hex Washer HD Screw	20561X217	2

N/S Indicates Non-Stocked Item  
 Shaded Ref # Indicates Assembly or Kit

# Meter Assembly




# Meter Assembly Parts List

Ref #	Description	Part #	Qty
1A	Meter Assembly, Turbine Complete	20564X200	1




# By-Pass Assembly (Plastic)



Ref #	Description	Part #	Qty
1	Plastic Bypass Valve Assembly	20561X292	1

# By-Pass Assembly (Stainless Steel)

Ref #	Description	Part #	Qty
1	Bypass Valve 3/4" Stainless Steel	20561X270	1
	Bypass Valve 1" Stainless Steel	20561X283	1



## Service Instructions

### **A. General Preliminary Instructions—PERFORM BEFORE ALL SERVICING OPERATIONS!**

1. Turn off water supply to conditioner:
  - If the conditioner installation has a “three valve” by-pass system, first open the valve in the by-pass line, then close the valves at the conditioner inlet and outlet.
  - If the conditioner has an integral by-pass valve, put it in the by-pass position.
  - If there is only a shut-off valve near the conditioner inlet, close it.
2. Relieve water pressure in the conditioner by stepping the control into the backwash position momentarily. Return the control to the service position.
3. Unplug electrical cord from outlet.
4. Disconnect brine tube and drain line connections at the injector body.

### **B. To Replace Brine Valve (need first A1-A3?)**

1. Remove the control valve back cover.  
Disconnect the meter signal wire from the meter
2. Remove screw and washer at drive yoke.  
Remove powerhead mounting screws. The entire powerhead assembly will now lift off easily.
3. Remove piston retaining plate screws and pull upward on end of piston yoke until assembly is out of valve.
4. Pull brine valve from injector body, also remove and discard O-ring at bottom of brine valve hole.
5. Apply silicone lubricant to new O-ring and reinstall at bottom of brine valve hole.
6. Apply silicone lubricant to O-ring on new Brine valve assembly and press into brine valve hole, shoulder on bushing should be flush with injector body.
7. Insert screws through injector cap and into mating holes in the valve body. Tighten screws.
8. Reconnect brine tube and drain line.
9. Return by-pass or inlet valving to normal service position. Water pressure should now be applied to the conditioner, and any by-pass line shut off.
10. Check for leaks at all seal areas. Check drain seal with the control in the backwash position.
11. Plug electrical cord into outlet.
12. Set time of day and cycle the control valve manually to assure proper function. Make sure control valve is returned to the service position.
13. Make sure there is enough salt in the brine tank.
14. Start regeneration cycle manually if water is hard.

### **C. To Replace Injectors and Screen (need first A1-A3?)**

1. Remove injector cap screws, remove cap and discard gasket. Remove vortex generator from end of the injector assembly.
2. Remove injector assembly. Apply silicone lubricant to new injector assembly O-rings and install. Be sure to push injector assembly tightly so O-rings are seated. Replace vortex generator. Install a new screen.
3. Apply silicone lubricant to new gasket and install around oval extension on injector cap.
4. Repeat B7-B14

### **D. To Replace Powerhead**

1. Remove the control valve back cover. Remove the three screws along the outer edge of the back plate and remove the front cover. Disconnect the power supply and the circuit board signal wire from the motor and feed them back through the control. Disconnect the optical sensor signal wire. Disconnect the meter signal wire from circuit board and feed back through the control.
2. Remove screw and washer at drive yoke. Remove powerhead mounting screws. The entire powerhead assembly will now lift off easily.
3. Put new powerhead on top of the valve. Be sure the drive pin on main gear engages slot in drive yoke (wide side of drive yoke upright must face to the left away from the motor).
4. Replace powerhead mounting screws. Replace screw and washer at drive yoke.
5. Reconnect meter signal, optical sensor, power supply, and circuit board signal wires.
6. Reinstall front cover and back cover.

### **E. To Replace Piston Assembly**

1. Follow Steps A.1 through A.3
2. Remove control valve back cover. Disconnect the meter signal wire from the meter
3. Remove screw and washer at drive yoke. Remove powerhead mounting screws. The entire powerhead assembly will now lift off easily.
4. Remove piston retaining plates screws.
5. Pull upward on end of piston yoke until assembly is out of valve.
6. Inspect the inside of the valve to make sure that all spacers and seals are in place, and that there is no foreign matter that would interfere with the valve operation.
7. Take new piston assembly as furnished and push piston into valve by means of the end plug. Twist drive yoke carefully in a clockwise direction to properly align it with drive gear. Reinstall piston retaining plate screws.
8. Place powerhead on top of valve. Be sure drive pin on main gear engages slot in drive yoke (wide side of drive yoke upright must face to the left away from the motor).
9. Replace powerhead mounting screws. Replace screw and washer at drive yoke.
10. Reconnect brine tube and drain line.
11. Return by-pass or inlet valving to normal service position. Water pressure should now be applied to the conditioner, and any by-pass line shut off.
12. Replace the control valve back cover.
13. Follow Steps A.9 through A.13

### **F. To Replace Seals and Spacers**

1. Follow Steps A.1 through A.3
2. Remove the control valve back cover. Disconnect the meter signal wire from the meter.
3. Remove screw and washer at drive yoke. Remove powerhead mounting screws. The entire powerhead assembly will now lift off easily. Remove piston retaining plate screws.
4. Pull upward on end of piston rod yoke until assembly is out of valve. Remove and replace seals and spacers.
5. Take piston assembly and push piston into valve by means of the end plug. Twist drive yoke carefully in a clockwise direction to properly align it with drive gear. Reinstall piston retaining plate screws. (Same as E7-E9?)

6. Place powerhead on top of valve. Be sure drive pin on main gear engages slot in drive yoke (wide side of drive yoke upright must face to the left away from the motor).
7. Replace powerhead mounting screws. Replace screw and washer at drive yoke.
8. Return by-pass or inlet valving to normal service position. Water pressure should now be applied to the conditioner, and any by-pass line shut off.
9. Replace the control valve back cover. (Same as E11-E13?)
10. Follow Steps A.9 through A.13

### **G. To Replace Meter**

1. Follow Steps A.1 through A.3
2. Remove two screws and clips at by-pass valve or yoke. Pull resin tank away from plumbing connections.
3. Remove signal wire from meter.
4. Remove two screws and clip at meter and pull the meter out of the control valve.
5. Apply silicone lubricant to four new O-rings and assemble to four ports on new meter.
6. Assemble meter to control valve. Note: meter portion of module must be assembled at valve outlet. Install two screws and clips.
7. Install signal wire into new meter.
8. Push resin tank back to the plumbing connections and engage meter ports with by-pass valve or yoke.
9. Attach two clips and screws at by-pass valve or yoke. Be sure clip legs are firmly engage with lugs.
10. Return by-pass or inlet valving to normal service position. Water pressure should now be applied to the conditioner, and any by-pass line shut off.
11. Check for leaks at all seal areas.
12. Follow steps A.9 through A.13.

### **H. To Check Drive Motor Operation**

1. Remove the control valve back cover.
2. To verify drive motor operation, push service button located on back of motor. Motor should run. Release button. After 1 minute, the control should automatically advance to Rapid Rinse (cycle #4) Position. It will remain in Rapid Rinse for 5 minutes and then advance to Service Position.

# Troubleshooting Guide

<b>SYMPTOM</b>	<b>PROBABLY CAUSE</b>	<b>CORRECTION</b>
1. Softener fails to regenerate automatically	Power supply plugged into intermittent or dead power source.	Connect to constant power source
	Disconnected meter cable	Reconnect cable
	Improper control valve programming	Reset program settings
	Defective power supply	Replace power supply
	Defective circuit board or meter	Replace or repair
	Defective drive motor	Check motor operation by activating the service button on back of motor
2. Regeneration at wrong time	Time of day improperly set, due to power failure	Reset time of day programming and install 9-Volt battery
	Regeneration time set improperly	Reset Regeneration time programming
3. Loss of capacity	Increase raw water hardness	Reset unit to the new capacity
	Brine concentration and/or quantity	Keep brine tank full of salt at all times. Clean it yearly. Salt may be bridged. If using a salt grid pate, ensure refill water is over it.
	Resin fouling	Call dealer, find out how to confirm it. Clean the resin and prevent future fouling.
	Poor distribution, Channeling (uneven bed surface)	Call dealer. Check distributors and backwash flow.
	Internal valve leak	Call dealer. Replace spacers, seals and/or piston.
	Resin age	Call dealer. Check for resin oxidation caused by chlorine. Mushy resin.
	Resin loss	Call dealer. Check for correct bed depth. Broken distributors. Air or gas in bed: Well gas eliminator. Loose brine line.
4. Poor water quality	Check items listed in #1, #2, & #3	
	Bypass valve open	Close by-pass valve
	Channeling	Check for too slow or high service flow. Check for media fouling.
5. High salt usage	High salt setting	Adjust brine tank refill time
	Excessive water in brine tank	See symptom #7
	Constant flow through the unit	Indicates plumbing leak (i.e. toilet tank)
	Improperly set hardness, regeneration frequency or regeneration day	Reset programming

<b>SYMPTOM</b>	<b>PROBABLY CAUSE</b>	<b>CORRECTION</b>
6. Loss of water pressure	Scaling/fouling of inlet pipe	Clean or replace pipeline. Pretreat to prevent
	Fouled resin	Clean resin. Pretreat to prevent
	Improper backwash	Too many resin fines and/or sediment. Call dealer, reset backwash flow rate, and/or adjust
7. Excessive water in brine tank and/or salty water to service	Plugged drain line	Check flow to drain. Clean flow control
	Dirty or damaged brine valve	Clean or replace brine valve
	Plugged injector	Clean injector and replace screen
	Low inlet pressure	Increase pressure to allow injector to perform properly. (20 psig minimum)
	Excessive brine refill cycle time	Reset brine refill cycle time
8. Softener fails to use salt	Check items listed in #1	
	Improper control valve programming	Check and reset programming
	Plugged/restricted drain line	Clean drain line and/or flow control
	Injector is plugged	Clean or replace injector and screen
	No water in brine tank	Check for restriction in BLFC. Ensure safety float is not stuck. Check brine tank for leaks.
	Water pressure is too low	Line pressure must be at least 20 psi.
	Brine line injects air during brine draw	Check brine line for air leaks
	Internal control leak	Call dealer, check piston, seals and spacers for scratches and dents
9. Control cycles continuously	Faulty circuit board	Replace circuit board
10. Continuous flow to drain	Foreign material in control	Call dealer. Clean valve, rebuild unit
	Internal control leak	Same as above
	Valve jammed in backwash, brine, or Rapid rinse position	Same as above
	Motor stopped or jammed	Replace motor