




Bulletin SM1532-001/US


Pump/Motor Division

Effective: May 2006




716 Series Low Speed High Torque Service Procedure

 WARNING	A WARNING refers to procedures that must be followed for the safety of the equipment operator and the person inspecting or repairing the motor.
--	--

 CAUTION	A CAUTION refers to a mandatory procedure which avoids damage to the motor or other system component.
--	--

NOTE	A NOTE provides key information to make a procedure easier or quicker to complete.
-------------	---

 WARNING
FAILURE OR IMPROPER SELECTION OR IMPROPER USE OF THE PRODUCTS AND/OR SYSTEMS DESCRIBED HEREIN OR RELATED ITEMS CAN CAUSE DEATH, PERSONAL INJURY AND PROPERTY DAMAGE.
This document and other information from Parker Hannifin Corporation, its subsidiaries and authorized distributors provide product and/or system options for further investigation by users having technical expertise. It is important that you analyze all aspects of your application and review the information concerning the product or system in the current product catalog. Due to the variety of operating conditions and applications for these products or systems, the user, through its own analysis and testing, is solely responsible for making the final selection of the products and systems and assuring that all performance, safety and warning requirements of the application are met.
The products described herein, including without limitation, product features, specifications, designs, availability and pricing, are subject to change by Parker Hannifin Corporation and its subsidiaries at any time without notice.

Offer of Sale
The items described in this document are hereby offered for sale by Parker Hannifin Corporation, its subsidiaries or its authorized distributors. This offer and its acceptance are governed by the provisions stated in the "Offer of Sale".

Table of Contents

Section 1 General Information

Definitions/Disclaimer..... Inside Front Cover

Introduction4

Troubleshooting Guide5

Troubleshooting Checklist.....6

Tools & Materials Required for Servicing7

Seal Kit Components & Service Parts List8

Exploded Views..... 9-11

Section 2 Repair

Disassembly & Inspection12-17

Assembly.....18-23

Solenoid Assembly24

Final Checks25

Section 3 Maintenance

Hydraulic Fluids.....25

Filtration25

Oil Temperature.....25

System Maintenance Tips26

Offer of SaleInside Back Cover

Introduction

This service manual has one purpose: to guide you in maintaining, troubleshooting, and servicing the 716 Two Speed High Torque Motor. These motors provide long life while operating with low radial side loads.

Read the troubleshooting information to eliminate non-hydraulic causes and hydraulic system problems. The check list identifies hydraulic system and possible motor component problems.

The two column format of the Disassembly and Inspection, and Assembly sections make it easier to conduct major work on the motor. Column one explains the procedure in detail. Column two illustrates this procedure with photographs. Read all material carefully and pay attention to the notes, cautions, and warnings.

The component part names and item numbers assigned on the exploded assembly views correspond to names and item numbers (in parentheses) used in the disassembly and assembly instructions.

Service part number charts display exploded view item numbers and part numbers.

Obtain service parts from the Original Equipment Manufacturer or your local Parker distributor.

We welcome suggestions to make this manual clearer or more complete. If you are stuck, contact Parker Hannifin Corp. Hydraulic Pump/Motor Division. Don't second guess the manual. Following this safe and productive procedure results in restoring the reliable long-life operation engineered into the motor.


Troubleshooting Guide


NOTE	Before troubleshooting any system problem, check service literature published by the equipment and/or component manufacturers. Follow their instructions, if given, for checking any component other than the motor unit.
-------------	---

Preparation

Make your troubleshooting easier by preparing as follows:

- work in a clean, well-lighted place
- have proper tools and materials nearby
- have an adequate supply of clean, petroleum-based solvent
- prior to any motor disassembly, plug the open ports and case drain
- clean all dirt from outside the motor
- prior to assembly, lightly oil all seals, rollers, rolls and the threaded bolt ends

 WARNING	Since solvents are flammable, be extremely careful when using any solvent. Even a small explosion could cause injury or death.
--	--

 WARNING	Wear eye protection and be sure to comply with OSHA and other maximum air pressure requirements.
--	--

Preliminary Checks

Hydraulic systems are often trouble-free. Hence, the problem an operator complains of could be caused by something other than the hydraulic components.

Thus, once you have determined that a problem exists, start with the easy-to-check items, such as:

- Parts damaged from impact that were not properly repaired, or that should have been replaced
- Improper replacement parts used in previous servicing
- Mechanical linkage problems such as binding, broken or loose parts, or slipping belts

Hydraulic Components


If the motor has low speed or torque, look at the check list on the next page first. Since these motors maintain volumetric and torque efficiencies during their usual life, the problem is usually elsewhere in the hydraulic system.

However, there are hydraulic system problems which can drastically reduce the long life designed into these motors. Three key areas to check are:

- Temperature: Do not exceed 180°F.
- Fluid: Viscosity at the maximum temperature must exceed 50 ssu.
- Filtration: A Beta 25 ratio of at least 2.


Troubleshooting Checklist

Trouble	Cause	Remedy
Oil Leakage	1. Hose fittings loose, worn or damaged.	Check & replace damaged "O" Rings. Torque to manufacturer's specifications.
	2. Motor section seal rings (7) deteriorated by excess heat.	Replace oil seal rings. Correct heat problem.
	3. Tie bolt loose	If bolts are loose because of excessive pressures as indicated by most or all being loose, replace bolts & advise customer to correct the pressure regulation.
	4. Broken tie bolts.	Replace bolts.
	5. Internal shaft seal worn or damaged.	Replace seal.
	6. Worn shaft and internal seal.	Replace shaft and seal.
Significant loss of speed under load	1. Lack of sufficient oil supply.	(a) Check for faulty relief valve and adjust/replace as required. (b) Check for/repair worn pump. (c) Check for and use correct oil for temperature of operation. Check reservoir fluid level.
	2. High internal motor leakage.	Replace worn IGR™ set.
	3. Excessive heat.	Locate excessive heat source (usually a restriction or lack of an oil cooler) and correct.
Low mechanical efficiency or undue high pressure required to operate motor	1. Line blockage.	Locate blockage source and repair or replace.
	2. Internal interference.	Disassemble motor, identify and remedy cause.
	3. Excessive binding or loading in system external to motor.	Locate source and eliminate cause.
Lack of pressure	1. Low flow output of pump.	Repair or replace worn pump.
	2. Relief valve set incorrectly or not closing completely.	Reset relief, look for contamination or replace.

 CAUTION	Seals in the system will shrink, harden or crack if fluid temperatures exceed 180°F (82.2°C), resulting in loss of ability to seal.
--	---

Tools and Materials Required for Servicing

- Clean, petroleum-based solvent
- Emery paper
- Vice with soft jaws
- Air-pressure source
- Screwdriver
- Tape
- Breaker bar or impact wrench
- Torque wrench 50 ft. lbs.
- Socket, 1/2"
- Allen wrench, 1/4"
- Adjustable crescent wrench or hose fitting wrenches

 CAUTION	Mixing greases that have different bases can be detrimental to bearing life.
--	--

Item No.	Qty	Part Number	Description
1	8	See Below	Bolts
2	1	M110C-6	4 Dowel End Cover (standard)
3	6	1046	O-Rings
4	1	See Below	IGR™ Set, Rear
5	2	1660	Clip
6	1	See Below	Shaft
7	2	SM015995	Commutator Plate
8	4	1021	Check Ball
9	1	SM012002A1 (7/8-14 O-Ring, Pilot Act.) SM012001A1 (7/8-14 O-Ring, Solenoid) SM012003A1 (BSPP, Pilot, Act.) SM012004A1 (BSPP, Solenoid)	Center Block
10	1	PA-2532-2	Front Bearing Housing/Flange BSPP Case Drain
	1	SM012006A1	Front Bearing Housing/Flange 7/16 Case Drain
11	1	1825 (Open Center)	Valve
	1	2792 (Closed Center)	
12	1	036300	7/8-14 SAE Plug
13	1	1826	Spring
14	1	1156	Bearing
15	4	1320	Check Balls-Solenoid Block
16	5	032841	O-Rings-Solenoid Block
17	1	See Below	IGR™ Set, Front
18	1	481006 (With Manual Override) 2891 (Without Manual Override)	Solenoid Solenoid
19	2	021442 (5/16-24 x 1.875)	Bolt, Hex
20	1	1141	Seal, Dust
21	1	2332 (.875)	Seal, High Pressure Lip Seal
25	1	1823	Solenoid Block


Motor Disp.	Item 6 Shaft	Item 17 (Front) IGR™ Set	Item 4 (Rear) IGR™ Set	Item 1 Hex Bolt
12.9/25.8	2216-258	SM012907005A2	SM012907008A1	021437
10.6/21.2	2216-212	SM010607005A2	SM010607008A1	021382
8.8/17.6	2216-176	SM008807005A1	SM008807008A1	021306
7.1/14.2	2216-142	SM007107005A1	SM007107008A1	021356
5.4/10.8	2216-108	SM005407005A1	SM005407008A1	021428
3.6/7.2	2216-072	SM003607005A1	SM003607008A1	021463

Seal Kit


Seal Kit - Complete: SK000189

P/N	Qty	Description
1046	6	Body O-Rings
1141	1	Dust Seal
2332	1	High Pressure Seal
032844	5	Solenoid Block O-Rings
1660	2	Snap Ring
050058	1	Service Bulletin







Item No.	Description
1	Bolt, Hex
10	Front Bearing Housing/Flange
3	O-Ring
17	IGR™ Matched Set
6	Shaft
7	Commutator Plate
8	Check Ball
9	Center Block
12	Plug, Spool Port
20	Seal, Dust
21	Seal, High Pressure



Item No.	Description
1	Bolt, Hex
2	Cover
3	O-Ring
4	IGR™ Matched Set
5	Clip
6	Shaft
7	Commutator Plate
8	Check Ball
9	Center Block
12	Plug, Spool Port





Solenoid Block
Bottom View


Item No.	Description
12	Plug, Spool Port
13	Spring, Valve
11	Valve
15	Check Ball, Solenoid Block
16	O-Ring Solenoid
25	Solenoid Block
18	Solenoid
19	Hex Bolt

(Preparation Before Disassembly)

- Before you disassemble the motor unit of any of its components, read this entire manual. It provides important information on parts and procedures you will need to know to service the motor.
- Refer to page four for tools and other items required to service the motor and have them available.
- Thoroughly clean off all outside dirt, especially from around fittings and hose connections, before disconnecting and removing the motor. Remove rust or corrosion from coupling shaft.
- Remove coupling shaft connections and hose fittings. Immediately plug port holes and fluid lines.
- Remove the motor from system. Drain it of fluid and take it to a clean work surface.
- Clean and dry the motor before you start to disassemble the unit.
- As you disassemble the motor, clean all parts - except seals - in a clean, petroleum-based solvent and blow them dry.
- Keep parts separate to avoid nicks and burrs.
- Discard all seals and seal rings as they are removed from the motor. Replace all seals, seal rings and any damaged or worn parts with genuine Parker or OEM approved service parts.

 **WARNING** Since they are flammable, be extremely careful when using any solvent. Even a small explosion or fire could cause injury or death.

 **WARNING** Wear eye protection and be sure to comply with OSHA or other maximum air pressure requirements.

 **CAUTION** Never steam or high pressure wash hydraulic components. Do not force or abuse closely fitted parts.

(Reference Exploded Assembly View)

1. Mount the motor in a soft jawed vice, shaft up, clamping on the cover assembly. Remove manifold port o-rings if applicable. SEE FIGURE D1




Figure D1

2. Remove the 8 5/16-24 bolts (1)SEE FIGURES D2.




Figure D2

3. Lift front bearing housing/flange (10) by lightly tapping the flange up off the dowels with a soft hammer. Do not remove the dowel pins., SEE FIGURES D3.




Figure D3

4. Remove the locating ring carefully to prevent rollers from falling or remove rollers with a magnet. SEE FIGURE D4.





Figure D4

 CAUTION	The rollers & check balls will fall out so be ready to catch them to prevent damage and loss.
---	---

NOTE	The check balls may fall into the bolt holes or into the commutator ports.
------	--

5. Remove outer, rolls, inner and valve plate. SEE FIGURES D5, D6, D7.




Figure D6



Figure D5




Figure D7

6. Remove commutator plate assembly (7) and seal (3). SEE FIGURE D8.



Figure D8

7. Turn motor assembly upside down and clamp center block (9) in vise. SEE FIGURE D9.



Figure D9

- 8. Loosen and remove the 8 5/16-24 bolts (1), remove the cover (2), locating ring, check valve balls (quantity 2) (8) and rollers. SEE FIGURES D10 & D11.

CAUTION The rollers will fall out so be ready to catch them to prevent damage and loss.




Figure D10



Figure D11

- 9. Remove the outer, rolls, inner and valve plate. SEE FIGURE D12.




Figure D12

- 10. Lift shaft (6) up a short distance, push the valve plate down and remove the 2 snap ring pieces (5). SEE FIGURE D13.

NOTE With the snap ring removed, the shaft will fall out of the motor unless you remain a grip on it.



Figure D13

11. Remove the valve plate. Lift and remove shaft (6). SEE FIGURE D14.
12. Remove commutator plate (7) and seal (3).
13. If the locating ring and front bearing housing (10) did not separate when the front bearing housing was removed they can be separated by holding the locating ring by hand and tapping the cover with a soft nose hammer.



Figure D14

CAUTION If placed in a vise, use minimal clamping force to prevent a permanent out of round condition.

SEAL REMOVAL

(700 Series Flange shown for illustration purpose only)

14. Remove dust seal (20) by leveraging it outward.




Figure D15

15. To remove the high pressure lip seal, the roller bearing must first be removed. Use a suitable bearing puller while taking care not to damage the flange. Once the bearing is removed, the seal can be pushed out of the flange using a blunt instrument. SEE FIGURE D15.

CAUTION Do not scratch the flange seal area. A scratch would possibly create a leak path.

Pilot Option

To change pilot from normally parallel to normally series or vice versa. Also valid for solenoid shift motors.

1. Remove the plugs (12) on the center block (9). SEE FIGURE D16.




Figure D16

2. Remove the spool (11) and spring(13). SEE FIGURE D17.
3. Looking at the port surface, install the spool with ...
 - A) the "double" or "wide" land nearest the "pilot port" for **normally parallel** operation. SEE FIGURE D18.
 - B) the "double" or "wide" land opposite the "pilot port" for **normally series** operation. SEE FIGURE D19.
4. The spring is always located on the side, opposite the "pilot port". SEE FIGURES 18 & 19.




Figure D17

The disassembly of the motor is completed.



Figure D18

PARTS INSPECTION

Inspect the shaft for a smooth polish in the bearing and seal areas. If scratched, polish with fine emery paper in circumferential direction. If pitted, or if scratches are deep, replace shaft and check the rest of the motor for scratches, galling, or contamination damage. Replace parts as needed.

If your motor has a thru shaft option and the seals were leaking, the entire cover must be replaced. Thru covers contain no servicable parts.




Figure D19

Replace all seals and seal rings with new ones each time you reassemble the motor unit. Lubricate all seals and seal rings with oil or clean grease before assembly.

NOTE	Individual seals and seal rings as well as a complete seal kit are available. The parts should be available through most OEM or Parker Distributors. Contact your local dealer for availability.
-------------	--

NOTE	Unless otherwise indicated, do not oil or grease parts before assembly.
-------------	---

Wash all parts in clean petroleum-based solvents before assembly. Blow them dry with compressed air. Remove any paint chips from mating surfaces and from port and sealing areas.

! WARNING	SINCE THEY ARE FLAMMABLE, BE EXTREMELY CAREFUL WHEN USING ANY SOLVENT. EVEN A SMALL EXPLOSION OR FIRE COULD CAUSE DEATH OR INJURY.
------------------	---

! WARNING	WEAR EYE PROTECTION AND BE SURE TO COMPLY WITH OSHA OR OTHER MAXIMUM AIR PRESSURE REQUIREMENTS.
------------------	--

PROCEDURE

1. Before assembling the flange seals and bearing, visually inspect the flange bores for deep scratches, raised material or sharp edges that would interfere with assembly or cause leaks.
2. Using a suitable installation tool, press the high pressure lip seal (21) into the seal bore (the longer, internal bore) and bottom it against the shoulder. The seal must be installed with the inside lip pointing towards the inside of the motor. Using an arbor press and suitable bearing installation tool, the bearing (14) can then be pressed in after the seal .065" to .085" below the face of the flange.
3. Install the dust seal (20) using a suitable seal driver in the outside seal bore of the flange. The dust seal should be installed with the inside lip facing away from the flange and flush with the flange face.
4. Position the center block so the pilot port or solenoid ports are on your right and lock in the vise. SEE FIGURE A01.
5. Place the o-ring (3) in center block seal gland. SEE FIGURE A02




Figure A01




Figure A02

6. Place commutator plate (7) on the center block (9) with the square ring groove facing up. Align the 8 bolt holes in the plate with the 8 tapped holes in the body. (The holes will align in only 1 position). **Note:** Do not dislodge square ring seal (3) while positioning the commutator plate (7). SEE FIGURE A03




Figure A03

7. Insert the internal shaft through the commutator plate and center block with the spline snap ring groove "up". SEE FIGURE A04 Then place the counterbored (at the splines) valve plate on the shaft with the 7 port windows sharp edge facing the commutator plate. SEE FIGURE A05 Next put both snap ring halves (5) into the snap ring groove on the shaft (6). Hold the snap rings in place with pliers while gently tapping the shaft down, seating the snap rings into the counterbore. SEE FIGURES A05



Figure A04



Figure A05

8. Place the square cut seal (3) in the commutator plate (7) seal gland. SEE FIGURE A06.




Figure A06

9. Place the inner counterbored side down on the splines so that the semi-circular roll pockets are between the rotary valve port windows. SEE FIGURE A07.




Figure A07

10. Place the outer over the inner and insert the rolls. The rolls should not block the ports in the valve plate. Place the check balls on their seats on the commutator plate. Assembly grease can be used to keep the check balls in place during assembly. SEE FIGURE A08.



Figure A08

11. Place the locating ring over the inner with the square ring groove up and the check ball counterbores over the check balls. Align the 8 bolt holes with the commutator holes. SEE Figure A09.
12. Alternate inserting long and short rollers between the outer and locating ring to match up with 4 dowels in the cover (2).

NOTE	The difference between rolls and rollers is that rolls have square ends and rollers have a radius on the end.
-------------	---



Figure A09

13. Place o-ring (3) in cover (2) seal groove. Assembly grease can be used to hold the o-ring in place during assembly. SEE FIGURE A10.



Figure A10

14. Place the cover (2) so the port markings (IN) (IN) are lined up with the corresponding ports. Also check the square ring seal (3) to verify that it hasn't dropped out. SEE FIGURE A11.




Figure A11

15. Install lubricated bolts (1) and torque diagonally to 15 ft lbs.
- A. Increase torque diagonally 5 foot lbs on each bolt.
 - B. Rotate the shaft by hand through several rotations.
 - C. Repeat steps A & B until torque is 30 foot lbs.

SEE FIGURE A12




Figure A12

16. Turn motor right side up in the vice and install the square cut seal (3) in the center block seal gland. SEE FIGURE A13.




Figure A13

17. Place the commutator plate on the center block with the square ring groove facing up. Align the 8 bolt holes with the 8 tapped holes in the center block. SEE FIGURE A14



Figure A14

18. Place the valve plate, with the seven port window's sharp edge facing the commutator plate, over the splines of the shaft. The plate should be positioned one tooth off the opposite end valve plate when viewing valve plate port timing with respect to the commutator plate. SEE FIGURE A15.




Figure A15

19. Install a o-ring into the groove in the commutator plate (7) then place the check balls (8) on their seats on the commutator plate. Assembly grease can be used to hold the check balls in place during assembly. SEE FIGURE A16

! WARNING Do not rotate the locating ring or check balls will drop into the bolt holes.




Figure A16

20. Place the inner over the splines of the shaft. Position the inner so the semi-circular roll pockets are between the rotary valve port windows. SEE FIGURE A17.
21. Place the outer over the inner and insert the rolls into the inner pockets.

NOTE The difference between rolls and rollers is that rolls have square ends and rollers have a radius on both ends.




Figure A17

22. Place the locating ring section onto the commutator plate with the check ball counterbored facing downward over the balls. Align the 8 bolt holes with the commutator holes. Place the rollers in position alternating long and short to match up with the 4 dowels in the front bearing housing/flange (10). SEE FIGURE A18



Figure A18

23. Install a square ring seal (3) into the groove of the front bearing housing/flange (10). Place the front bearing housing w/ square ring over the shaft and onto the locating ring. Be sure to align the 4 dowels with the short dowels inside the locating ring and to align the bolt holes with the holes in the locating ring. (bolt hole pattern will only match one way.) SEE FIGURE A19




Figure A19

24. Install the 8 lubricated bolts and torque diagonally to 15 ft lbs.
- A. Increase torque diagonally 5 foot lbs on each bolt.
 - B. Rotate the shaft by hand through several rotations.
 - C. Repeat steps A & B until torque is 30 foot lbs.

SEE FIGURE A20




Figure A20

1. Place 4 check balls on their seats on the center block (15) SEE FIGURE A21




Figure A21

2. Place 5 O-rings (16) in the grooves on the solenoid block (17). SEE FIGURE A22




Figure A22

3. Place solenoid valve assembly on the center block, insert bolts and torque to 15 ft lbs. SEE FIGURE A23




Figure A23

The assembly of the Motor is now complete except for keys, nuts, etc. at installation if applicable. See final checks.

Final Checks

- Pressurize the motor with 100 psi dry air or nitrogen and submerge in solvent to check for external leaks.
- Port with **IN** cast adjacent to the port indicates shaft rotation.
- Check operation of the motor with a test stand.

Hydraulic Fluid

- Hydraulic fluid as recommended by equipment manufacturer, with viscosity no less than 50 SSU.

! CAUTION	Do not mix oil types. Any mixture or non-approved oil could deteriorate the seals. Maintain the proper fluid level in the reservoir. When changing fluid, completely drain old oil from the system. It is suggested also that you flush the system with clean oil, especially if there was a major hydraulic component failure. In addition, run the system with no load for a period of time to allow the filters to clean up the oil. Then, change the filters before returning the machine to service.
------------------	---

Filtration


- Recommended filtration: Beta 25 ratio of at least 2.


Oil Temperature


- Maximum operating temperature 180°.


Maintenance Tips


- Adjust fluid level in reservoir as necessary.
- Encourage all operators to report any malfunction or accident that may have damaged the hydraulic system or component.
- Do not attempt to weld any broken motor component. Replace the component with original equipment only.
- Do not cold straighten or bend any motor part.
- Prevent dirt or other foreign matter from entering the hydraulic system. Clean the area around the filler caps before checking oil level.
- Investigate and correct any external leak in the hydraulic system no matter how minor.
- Comply with manufacturer's specifications for cleaning or replacing the filter.

 **CAUTION** Do not strike or drop the motor on the shaft end. This will cause internal damage.

 **CAUTION** Do not weld, braze, solder or in any way alter any motor component.

 **CAUTION** Maximum operating pressure must not exceed recommended motor pressure capacity.

 **CAUTION** Always carefully inspect any system component that may have been struck or damaged during operation or in an accident. Replace any component that is damaged or that is questionable.

 **CAUTION** Do not force any coupling onto the motor coupling shaft as this could damage the unit internally.

Parker Hannifin Corp. extends close technical cooperation and assistance. If problems occur that you cannot solve, please contact our Parker Technical Service Representative or local Parker Distributor. See the back cover of this manual for our address, phone and fax numbers.

The items described in this document and other documents or descriptions provided by Parker Hannifin Corporation, its subsidiaries and its authorized distributors are hereby offered for sale at prices to be established by Parker Hannifin Corporation, its subsidiaries and its authorized distributors. This offer and its acceptance by any customer ("Buyer") shall be governed by all of the following Terms and Conditions. Buyer's order for any such item, when communicated to Parker Hannifin Corporation, its subsidiary or an authorized distributor ("Seller") verbally or in writing, shall constitute acceptance of this offer.

1. Terms and Conditions of Sale: All descriptions, quotations, proposals, offers, acknowledgments, acceptances and sales of Seller's products are subject to and shall be governed exclusively by the terms and conditions stated herein. Buyer's acceptance of any offer to sell is limited to these terms and conditions. Any terms or conditions in addition to, or inconsistent with those stated herein, proposed by Buyer in any acceptance of an offer by Seller, are hereby objected to. No such additional, different or inconsistent terms and conditions shall become part of the contract between Buyer and Seller unless expressly accepted in writing by Seller. Seller's acceptance of any offer to purchase by Buyer is expressly conditional upon Buyer's assent to all the terms and conditions stated herein, including any terms in addition to, or inconsistent with those contained in Buyer's offer. Acceptance of Seller's products shall in all events constitute such assent.

2. Payment: Payment shall be made by Buyer net 30 days from the date of delivery of the items purchased hereunder. Amounts not timely paid shall bear interest at the maximum rate permitted by law for each month or portion thereof that the Buyer is late in making payment. Any claims by Buyer for omissions or shortages in a shipment shall be waived unless Seller receives notice thereof within 30 days after Buyer's receipt of the shipment.

3. Delivery: Unless otherwise provided on the face hereof, delivery shall be made F.O.B. Seller's plant. Regardless of the method of delivery, however, risk of loss shall pass to Buyer upon Seller's delivery to a carrier. Any delivery dates shown are approximate only and Seller shall have no liability for any delays in delivery.

4. Warranty: Seller warrants that the items sold hereunder shall be free from defects in material or workmanship for a period of 18 months from date of shipment from Parker Hannifin Corporation. THIS WARRANTY COMPROMISES THE SOLE AND ENTIRE WARRANTY PERTAINING TO ITEMS PROVIDED HEREUNDER. SELLER MAKES NO OTHER WARRANTY, GUARANTEE, OR REPRESENTATION OF ANY KIND WHATSOEVER. ALL OTHER WARRANTIES, INCLUDING BUT NOT LIMITED TO, MERCHANTABILITY AND FITNESS FOR PURPOSE, WHETHER EXPRESS, IMPLIED, OR ARISING BY OPERATION OF LAW. TRADE USAGE, OR COURSE OF DEALING ARE HEREBY DISCLAIMED.

NOTWITHSTANDING THE FOREGOING, THERE ARE NO WARRANTIES WHATSOEVER ON ITEMS BUILT OR ACQUIRED WHOLLY OR PARTIALLY, TO BUYER'S DESIGNS OR SPECIFICATIONS.

5. Limitation of Remedy: SELLER'S LIABILITY ARISING FROM OR IN ANY WAY CONNECTED WITH THE ITEMS SOLD OR THIS CONTRACT SHALL BE LIMITED EXCLUSIVELY TO REPAIR OR REPLACEMENT OF THE ITEMS SOLD OR REFUND OF THE PURCHASE PRICE PAID BY BUYER, AT SELLER'S SOLE OPTION. IN NO EVENT SHALL SELLER BE LIABLE FOR ANY INCIDENTAL, CONSEQUENTIAL OR SPECIAL DAMAGES OF ANY KIND OR NATURE WHATSOEVER. INCLUDING BUT NOT LIMITED TO LOST PROFITS ARISING FROM OR IN ANY WAY CONNECTED WITH THIS AGREEMENT OR ITEMS SOLD HEREUNDER, WHETHER ALLEGED TO ARISE FROM BREACH OF CONTRACT, EXPRESS OR IMPLIED WARRANTY, OR IN TORT, INCLUDING WITHOUT LIMITATION, NEGLIGENCE, FAILURE TO WARN OR STRICT LIABILITY.

6. Changes, Reschedules and Cancellations: Buyer may request to modify the designs or specification for items sold hereunder as well as the quantities and delivery dates thereof, or may request to cancel all or part of this order, however, no such requested modification or cancellation shall become part of the contract between buyer and Seller unless accepted by Seller in written amendment to this Agreement. Acceptance of any such requested modification or cancellation shall be at Seller's discretion, and shall be upon such terms and conditions as Seller may require.

7. Special Tooling: A tooling charge may be imposed for any special tooling, including without limitation, dies, fixtures, molds and patterns, acquired to manufacture items sold pursuant to this contract. Such special tooling shall be and remain Seller's property notwithstanding payment of any charges by Buyer, in no event will Buyer acquire any interest in apparatus belonging to Seller which is utilized in the manufacture of the items sold hereunder, even if such apparatus has been specially converted or adapted for such manufacture and notwithstanding any charges paid by Buyer. Unless otherwise agreed, Seller shall have the right to alter, discard or otherwise dispose of any special tooling or other property in its sole discretion at any time.

8. Buyer's property: Any designs, tools, patterns, materials, drawings. Confidential information or equipment furnished by buyer, or any other items which become Buyer's property, may be considered obsolete and may be destroyed by Seller after two (2) consecutive years have elapsed without Buyer placing an order for the items which are manufactured using such property. Seller shall not be responsible for any loss or damage to such property while it is in Seller's possession or control.

9. Taxes: Unless otherwise indicated on the face hereof, all prices and charges are exclusive of excise, sales, use, property, occupational or like taxes which may be imposed by any taxing authority upon the manufacture, sale or delivery of the items sold hereunder. If any such taxes must be paid by Seller or if Seller is liable for the collection of such tax, the amount hereof shall be in addition to amounts for the items sold. Buyer agrees to pay all such taxes or to reimburse Seller therefore upon receipt of its invoice. If Buyer claims exemption from any sales, use or other tax imposed by any taxing authority, Buyer shall save Seller harmless from and against any such tax together with any interest or penalties thereon which may be assessed if the items are held to be taxable.

10. Indemnity For Infringement of Intellectual Property Rights: Seller shall have no liability for infringement of any patents, trademarks, copyrights, trade dress, trade secrets or similar rights except as provided in this Part 10. Seller will defend and indemnify Buyer against allegations of infringement of U.S. patents, U.S. Trademarks, copyrights, trade dress and trade secrets (hereinafter "Intellectual Property Rights"). Seller will defend at its expense and will pay the cost of any settlement or damages awarded in an action brought against Buyer based on an allegation that an item sold pursuant to this contract infringes the Intellectual Property Rights of a third party. Seller's obligation to defend and indemnify Buyer is contingent on Buyer notifying Seller within ten (10) days after Buyer becomes aware of such allegations of infringement, and Seller having sole control over the defense of any allegations or actions including all negotiations for settlement or compromise. If an item sold hereunder is subject to a claim that it infringes the Intellectual Property Rights of a third party, Seller may, at its sole expense and option, procure for Buyer the right to continue using said item, replace or modify said item so as to make it noninfringing, or offer to accept return of said item and return the purchase price less a reasonable allowance for depreciation. Notwithstanding the foregoing, Seller shall have no liability for claims of infringement based on information provided by Buyer, or directed to items delivered hereunder for which the designs are specified in whole or part by Buyer, or infringements resulting from the modification, combination or use in a system of any item sold hereunder. The foregoing provisions of this Part 10 shall constitute Seller's sole and exclusive liability and buyer's sole and exclusive remedy for infringement of Intellectual Property Rights.

If a claim is based on information provided by Buyer or if the design for an item delivered hereunder is specified in whole or in part by Buyer, buyer shall defend and indemnify Seller for all costs, expenses of or judgments resulting from any claim that such item infringes any patent, trademark, copyright, trade dress, trade secret or any similar right.

11. Force Majeure: Seller does not assume the risk of and shall not be liable for delay or failure to perform any of Seller's obligations by reason of circumstances beyond the reasonable control of Seller (hereinafter "Events of Force Majeure"). Events of Force Majeure shall include without limitation, accidents, acts of god, strikes or labor disputes, acts, laws, rules or regulations of any government or government agency, fires, floods, delays or failures in delivery of carries or suppliers, shortages of materials and any other cause beyond Seller's control.

12. Entire Agreement/Governing Law: The terms and conditions set forth herein, together with any amendments, modifications and any different terms or conditions expressly accepted by Seller in writing, shall constitute the entire Agreement concerning the items sold, and there are no oral or other representation or agreements which pertain thereto. This Agreement shall be governed in all respects by the law of the State of Ohio. No actions arising out of the sale of the items sold hereunder or this Agreement may be brought by either party more than two (2) years after the cause of action accrues.