





TROOPER[®] SCALE & TROOPER[®] COUNT SCALE SERVICE MANUAL



Trooper[®] Scale & Trooper[®] Count Scale SERVICE MANUAL



TROOPER[®] SCALE



TROOPER COUNT[®] SCALE

The information contained in this manual is believed to be accurate at the time of publication, but Ohaus Corporation assumes no liability arising from the use or misuse of this material. Reproduction of this material is strictly prohibited.

Material in this manual is subject to change.

**© Copyright 2004 Ohaus Corporation, all rights reserved.
® Registered trademark of Ohaus Corporation.**

TABLE OF CONTENTS

CHAPTER 1 INTRODUCTION

	Page
1. Introduction	1-1
1.1 Service Facilities	1-1
1.2 Tools and Equipment	1-2
1.2.1 Standard Tools and Test Equipment	1-2
1.2.2 Special Tools	1-2
1.3 Calibration Masses Required	1-2
1.4 Service Strategy	1-3

CHAPTER 2 DIAGNOSIS

2. Diagnosis	2-1
2.1 Scale Setup and Examination	2-1
2.2 Preliminary Checks	2-1
2.3 Troubleshooting Tables	2-1
2.4 Trooper Scale Diagrams	2-7
2.5 Trooper Scale Error Code Table	2-8
2.6 Trooper Count Scale Diagram	2-15
2.7 Trooper Count Scale Error Code Table	2-16

CHAPTER 3 REPAIR PROCEDURES

3.1 Repair Procedures	3-1
3.1 Replacing the Trooper Scale Membrane Switch	3-1
3.2 Replacing the Trooper Scale Main PC Board	3-2
3.3 Replacing the Trooper Scale Load Cell Assembly	3-4
3.4 Replacing the Trooper Count Scale Membrane Switch	3-6
3.5 Replacing the Trooper Count Scale Main PC Board	3-7
3.6 Replacing the Trooper Count Scale Display PC Board	3-8
3.7 Replacing the Trooper Count Scale Load Cell Assembly	3-9

CHAPTER 4 TESTING

4.1 Testing	4-1
4.1 Trooper Scale Operational Test	4-1
4.1.1 Segment Display Test	4-1
4.2 Trooper Count Scale Operational Test	4-1
4.2.1 Segment Display test	4-1
4.3 Performance Tests	4-2
4.3.1 Repeatability Test	4-2
4.3.2 Off-Center Load Test	4-4
4.3.3 Linearity Test	4-5
4.4 Trooper Scale Specifications	4-6
4.5 Trooper Count Scale Specifications	4-6
4.6 Communication Test	4-7
4.6.1 Setting Trooper Scale Print Menu	4-7
4.6.2 Setting Trooper Count Scale Print Menu	4-7
4.6.3 Connecting the RS232 Interface	4-8
4.6.4 Print Test	4-9

TABLE OF CONTENTS (Cont.)

	Page
CHAPTER 5 PARTS LISTS	
5. Parts Lists	5-1
5.1 Trooper Scale/Trooper Count Scale Exploded View	5-2
APPENDIX A CALIBRATION	
A.1 Trooper Scale Linearity Calibration	A-1
A.2 Trooper Count Scale Linearity Calibration	A-2
A.3 Linearity Calibration Weights	A-4
APPENDIX B TROOPER COUNT SCALE TOOLS	
B.1 Introduction	B-1
B.2 Installation	B-1
B.2.1 Minimum Requirements	B-1
B.2.2 Connecting the RS232 Interface	B-1
B.2.3 Installing the Trooper Count Scale Tools Software Program	B-1
B.2.4 Opening the Trooper Count Scale Tools Software Program	B-1
B.3 Screen Operations	B-2
B.3.1 Configuration (Config)	B-2
B.3.2 Library	B-4
B.3.3 Test Command	B-7
B.3.4 Com Port	B-8
B.4 Troubleshooting	B-9

TABLE OF CONTENTS (Cont.)

LIST OF TABLES

TABLE NO.	TITLE	PAGE
1-1	Calibration Masses	1-2
2-1	Trooper Scale - Will Not Turn on With AC Adapter	2-1
2-2	Trooper Scale - Will Not Turn on Using Batteries	2-2
2-3	Trooper Scale - Does Not Respond to Front Panel Controls	2-3
2-4	Trooper Scale - No Display or Partial Display	2-4
2-5	Trooper Scale - Cannot Calibrate	2-4
2-6	Trooper Scale - Communications Failure	2-6
2-7	Trooper Scale Error Codes	2-8
2-8	Trooper Count Scale - Will Not Turn on With AC Adapter	2-9
2-9	Trooper Count Scale - Will Not Turn on Using Batteries	2-10
2-10	Trooper Count Scale - Does Not Respond to Front Panel Controls	2-11
2-11	Trooper Count Scale - No Display or Partial Display	2-12
2-12	Trooper Count Scale - Cannot Calibrate	2-13
2-13	Trooper Count Scale - Communications Failure	2-14
2-14	Trooper Count Scale Error Codes	2-15
4-1	Trooper Scale Specifications	4-6
4-2	Trooper Count Scale Specifications	4-6
4-3	Trooper Scale RS232 Commands	4-8
4-4	Trooper Count Scale RS232 Commands	4-9
5-1	Trooper Scale (TR) and Trooper Count Scale (TC) Parts List	5-3
A-1	Trooper Scale Linearity Weights	A-4
A-2	Trooper Count Scale Linearity Weights	A-4

LIST OF ILLUSTRATIONS

FIGURE NO.	TITLE	PAGE
2-1	Trooper Scale Interconnection Diagram	2-7
2-2	Trooper Scale Membrane Switch Wiring Diagram	2-7
2-3	Trooper Count Scale Interconnection Diagram	2-17
2-4	Trooper Count Scale Membrane Switch Wiring Diagram	2-18
3-1	Trooper Scale Connector Locations	3-2
3-2	Trooper Scale RS Connector and Loadcell Connector Wiring	3-3
3-3	Trooper Scale Component Locations	3-5
3-4	Trooper Count Scale Main PC Board Connector Locations	3-7
3-5	Trooper Count Scale RS Connector and Loadcell Connector Wiring	3-8
3-6	Trooper Count Scale Component Locations	3-10
4-1	Trooper Scale Segment Displays	4-1
4-2	Trooper Count Scale Segment Displays	4-1
4-3	Standard Deviation Worksheet	4-3
4-4	Calculation of Standard Deviation	4-3

LIST OF ILLUSTRATIONS (Cont.)

FIGURE NO.	TITLE	PAGE
4-5	Sample Calculation of Standard Deviation	4-4
4-6	Off-Center Load Test Weight Locations	4-4
4-7	RS232 Interface Pin Connections	4-8
5-1	Exploded View of Trooper Scale and Trooper Count Scale	5-2

1. INTRODUCTION

This service manual contains instructions for the repair and maintenance work to be performed by Ohaus Dealers or Ohaus authorized service centers. Knowledge of the operation of the Scale is assumed. Instruction manuals are included with this service manual. For complete information on operation, refer to the Instruction Manual.

This manual covers maintenance on the following:

Trooper® Scales (capacities 3kg, 6kg, 15kg and 30kg.)

Trooper® Count Scales (capacities 3kg, 6kg, 15kg and 30kg.)

The contents of this manual are contained in five chapters and an Appendix with calibration information.

Chapter 1 Introduction - Contains information about service facilities, tools and test equipment, test masses, and service strategy.

Chapter 2 Diagnosis - Contains information on problem verification, scale examination, preliminary checks, troubleshooting tables, interconnection diagrams and wiring diagrams.

Chapter 3 Repair Procedures - Contains detailed repair procedures for all major components.

Chapter 4 Testing - Contains performance tests, specifications and communications testing procedures.

Chapter 5 Parts Lists - Contains exploded views of Trooper Scale and Trooper Count Scale identifying all serviceable replacement components with associated parts lists.

Appendix A Calibration - Contains linearity calibration procedures for the Trooper Scale and Trooper Count Scale.

Appendix B Trooper Count Scale Tools - Contains information on scale configuration, library data and testing output commands from a computer.

1.1 SERVICE FACILITIES

The service area should be a stable environment.

The bench area should be clean and should contain an antistatic mat with a personnel grounding clip to protect internal circuit boards. The ideal electrical power source for the scales should be a dedicated line to avoid sudden fluctuations or voltage drops caused by external equipment drawing heavy current.

The service area for the scales should be away from direct sunlight, overhead heating or air conditioning ducts, magnetic fields such as motors or large transformers or near vibrating sources such as machinery, motors or vibrating equipment.

The power outlet should be grounded for safety. Sufficient space should be provided around the scale as not to be affected by other equipment. This will ensure that the scale is operated under ideal conditions.

CHAPTER 1 INTRODUCTION

1.2 TOOLS AND EQUIPMENT

1.2.1 Standard Tools and Test Equipment

The service shop should contain the following equipment:

1. Digital Voltmeter (DVM).
2. Standard Electronics tool kit.
3. Desk magnifier on a stand.
4. Grounding mat and clip.
5. Flat Exacto® blades and holder.

1.2.2 Special Tools

To service the Ohaus Trooper Scale and Trooper Count Scale, the following equipment is recommended:

1. A PC computer with a terminal program for communications.
2. Trooper Count Scale Tools- software program, Ohaus P/N 80500590.
3. RS-232 Cable - Ohaus P/N 80500433, IBM-PC 9 pin or standard null modem cable.
4. RS-232 Cable - Ohaus P/N 80500431, IBM - PC 25 Pin
5. Ohaus Printer Model SF42
6. Ohaus Printer Cable P/N 80500571
7. AC adapter, 120V, 60Hz (US) Ohaus P/N 80500435
8. AC adapter, 230V, 50Hz (EU) Ohaus P/N 80500436
9. AC adapter, 230V, 50Hz (UK) Ohaus P/N 80500437
10. AC adapter, 240V, 50 Hz (AU) Ohaus P/N 80500462
11. Load Cell Simulator

1.3 CALIBRATION MASSES REQUIRED

The masses required to test the Ohaus Trooper Scale and Trooper Count Scale must meet the requirements of ASTM Class 4 or OIML F2. The mass values are listed in Table 1-1. Bolded values are default settings.

TABLE 1-1. CALIBRATION MASSES

TROOPER COUNT SCALE Cal in kg:	TROOPER SCALE Cal in kg:	Span Cal choices Masses Totaling	Linearity Cal (fixed) Masses Totaling
TC3RS	TR3RS	1, 2 , 3kg	2 & 3 kg
TC6RS	TR6RS	2, 4 , 6kg	4 & 6 kg
TC15RS	TR15RS	5, 10 , 15kg	10 & 15 kg
TC30RS	TR30RS	10, 20 , 30kg	20 & 30 kg
Cal in lb:	Cal in lb:	Span Cal choices Masses Totaling	Linearity Cal (fixed) Masses Totaling
TC3RS	TR3RS	2, 4 , 6 lb	4 & 6 lb
TC6RS	TR6RS	5, 10 , 15 lb	10 & 15 lb
TC15RS	TR15RS	10, 20 , 30 lb	20 & 30 lb
TC30RS	TR30RS	20, 40 , 60 lb	40 & 60 lb

1.4 SERVICE STRATEGY

The repair method for the Trooper Scale and Trooper Count Scale is the direct substitution of major assemblies.

The Trooper Scale contains 3 major replaceable assemblies: Cover Assembly with Membrane Switch, Load Cell Assembly with Frame and the Main PC Board with LCD.

The Trooper Count Scale contains 4 major replaceable assemblies: Cover Assembly with Membrane Switch, Display PC Board with LCD, Load Cell Assembly with Frame and the Main PC Board.

This service manual contains sufficient information to isolate the problem, replace the component, test and restore the Scale to original factory specifications.

CHAPTER 1 INTRODUCTION

2. DIAGNOSIS

This section contains information needed to properly evaluate the reported problem and diagnose its cause.

2.1 SCALE SETUP AND EXAMINATION

Set up the scale according to the Instruction manual. Allow the scale to stabilize to room temperature. Examine the scale for signs of corrosion or physical damage.

2.2 PRELIMINARY CHECKS

Power up the scale using the customer's ac adapter. In the case where the scale will not power up, check the ac adapter. Observe and record the error codes and software revision. Record all menu settings if possible as received.

2.3 TROUBLESHOOTING TABLES

Troubleshooting tables 2-1 through 2-14 identify actual types of problems that could be encountered with the scale.

Trooper Scales are covered in Tables 2-1 through 2-7.

Trooper Count Scales are covered in Tables 2-8 through 2-14.

The troubleshooting tables refer to interconnection and wiring diagrams in this section to assist in locating the problem.

TABLE 2-1 TROOPER SCALE - WILL NOT TURN ON WITH AC ADAPTER.

SYMPTOM	PROBABLE CAUSE	REMEDY
Scale will not turn on with AC adapter supplied	Adapter defective.	Check the ac adapter voltage output. The ac adapter output should measure 12-16 Volts dc. If voltage is low or nonexistent, replace the ac adapter. If OK, proceed.
	DC input connector at rear of scale is defective.	Disconnect the ac adapter. Remove the 6 screws from the bottom cover of the scale, carefully remove the platform, top cover and disconnect the flexible cable from the Main PC Board. See Figure 2-1. Reconnect the ac adapter to the scale. Check dc voltage at pins 1 and 4 of connector J7 on the Main PC Board. Should read between 12-16 Volts dc (power off), 12-14 Volts dc (power on). If voltage is not present, replace the Main PC Board. If OK, proceed.
	Membrane Switch defective.	See Table 2-3.
	Main PC Board is defective.	If the scale fails to turn on with a new Membrane Switch, the Main PC Board is defective and should be replaced. -> <u>Repair Procedures 3.2.</u>

CHAPTER 2 DIAGNOSIS

TABLE 2-2 TROOPER SCALE - WILL NOT TURN ON USING BATTERIES.

SYMPTOM	PROBABLE CAUSE	REMEDY
<p>Scale will not turn on with new batteries installed.</p>	<p>Incorrect battery installation.</p> <p>Wiring harness defective or battery clips connection broken.</p> <p>Membrane Switch defective.</p> <p>Main PC Board is defective.</p>	<p>Check position of batteries.</p> <p>Remove the 6 screws from the bottom cover of the scale, carefully remove the platform, top cover and remove the flexible cable from the Main PC Board.</p> <p>Check dc voltage at pins 1 and 3 of connector J6 on the Main PC Board. See Figure 2-1. Voltage should read approximately 9 Volts dc. If voltage is not present at the connector, remove the batteries and make a continuity test between each of the connectors in the battery box to connector J6, pins 1 and 3 on the Main PC Board. Resistance should be 0 ohms for the red lead and 0 ohms for the black lead. If an open condition exists, trace wiring and resolder or replace wiring as necessary. If OK, proceed.</p> <p>See Table 2-3.</p> <p>If the scale fails to turn on with a new Membrane Switch, the Main PC Board is defective and should be replaced. -> <u>Repair Procedures 3.2.</u></p>

TABLE 2-3 TROOPER SCALE - DOES NOT RESPOND TO FRONT PANEL CONTROLS.

SYMPTOM	PROBABLE CAUSE	REMEDY
<p>Scale does not respond to front panel controls.</p> <p>NOTE: Use a known good ac adapter for this test.</p>	<p>Membrane Switch is defective.</p>	<ol style="list-style-type: none"> 1. Open the scale, remove six screws from the bottom of the scale. 2. Refer to Figure 2-2. Using an Ohmmeter, measure the resistance between pins 1 to all other pins on the membrane switch cable, they should all be open, then press each button and check that the resistance is zero for each button. If continuity is not present, the membrane switch is defective. Replace Membrane Switch -> <u>Repair Procedures 3.1.</u> or Substitute with a good membrane switch plugged into the Main PC Board and press each button if they work, the original Membrane Switch is defective and should be replaced. -> <u>Repair Procedures 3.1.</u> 3. If Membrane Switches are OK, replace Main PC Board. -> <u>Repair Procedures 3.2.</u>

CHAPTER 2 DIAGNOSIS

TABLE 2-4 TROOPER SCALE - NO DISPLAY OR PARTIAL DISPLAY.

SYMPTOM	PROBABLE CAUSE	REMEDY
Display is not on or partial characters are displayed.	Main PC Board is defective.	<p>The Main PC Board is replaced as a whole assembly. Check procedures in Table 2-1 first and verify that other problems do not exist.</p> <p>Replace Main PC Board. -> <u>Repair Procedures 3.2.</u></p>

TABLE 2-5 TROOPER SCALE - CANNOT CALIBRATE.

SYMPTOM	PROBABLE CAUSE	REMEDY
Scale can be turned on but will not calibrate.	<p>Incorrect weights.</p> <p>LFT lock switch is in the locked position and/or</p> <p>The software lock menu is set to ON (LCL On).</p> <p>Load cell assembly defective.</p>	<p>Verify that proper weights are used.</p> <p>Set LFT lock switch to unlocked position and/or</p> <p>Set the software lock menu to OFF (LCLOFF), then refer to instruction manual.</p> <p>Remove the 6 screws from the bottom cover of the scale. Carefully remove the platform. Lift the top cover and lay aside leaving the cables connected to the Main PC Board.</p> <p>With the scale plugged in and turned on, measure voltage on terminals -EXE and +EXE. The nominal voltage should be 5 V dc. If the voltage is much lower, disconnect the load cell from the PC Board and measure again. If 5V dc is present, the load cell may be shorted and requires replacement. Continue, see next page.</p>

CHAPTER 2 DIAGNOSIS

TABLE 2-6 TROOPER SCALE - COMMUNICATIONS FAILURE.

SYMPTOM	PROBABLE CAUSE	REMEDY
Communications cannot be established with scale turned on.	Communication cable is not plugged in or the incorrect cable is being used. Improper settings in the Print menu. Main PC Board is defective.	Tighten connectors and use the proper cable. Ensure that the communications parameters of the scale and peripheral device match. Replace Main PC Board. -> <u>Repair Procedures 3.2.</u> Reassemble the scale. Perform tests in Section 5 and verify operation.

2.4 TROOPER SCALE DIAGRAMS




Figure 2-1. Trooper Scale Interconnection Diagram.




Figure 2-2. Trooper Scale Membrane Switch Wiring Diagram.

CHAPTER 2 DIAGNOSIS

2.5 TROOPER SCALE ERROR CODE TABLE

The Trooper Scale is equipped with software which will display an error condition when it occurs. Review the listed codes and follow instructions to correct the problem.

TABLE 2-7. TROOPER SCALE ERROR CODES

ERROR CODE	CAUSE	REMEDY
LoBat	Batteries are weak.	Replace batteries.
Error 1	The load on the platform exceeds the rated capacity of the scale (overload condition).	Remove excess load. Check load cell connections. Refer to the Troubleshooting Tables.
Error 2	Underload condition. The load cell signal is more than 9 divisions below zero.	Press the ON/ZERO Off button. If the problem persists, refer to the troubleshooting section to check the load cell assembly.
Error 7	EEPROM data incorrect.	Turn scale on and off and on again. If error 7 remains, replace the Main PC board. -> <u>Repair Procedures 3.2</u> .
Error 14	When ZERO button is pressed, the load on the pan exceeds zero % menu setting. Could be caused by a load on the pan. At power up, the load cell signal is outside the allowable limit.	Enter the Setup Menu and set the zero % to a higher setting. (See Instruction Manual.) Perform a linearity calibration. If this fails, substitute the load cell assembly and perform the linearity calibration again. Refer to Table 2-5. If the substitute load cell does not correct the condition, re-install the original load cell and replace the Main PC board. -> <u>Repair Procedures3.2</u>
Error 21	Checksum error.	Replace the load cell-> <u>Repair Procedures 3.3</u> and or Main PC board as required -> <u>Repair Procedures3.2</u> Recalibrate and check.

TABLE 2-8 TROOPER COUNT SCALE - WILL NOT TURN ON WITH AC ADAPTER.

SYMPTOM	PROBABLE CAUSE	REMEDY
<p>Scale will not turn on with AC adapter supplied.</p>	<p>Adapter defective.</p>	<p>Check the ac adapter voltage output. The ac adapter output should measure 12-16 Volts dc. If voltage is low or nonexistent, replace the ac adapter. If OK, proceed.</p>
	<p>DC input connector at rear of scale is defective.</p>	<p>Disconnect the ac adapter. Remove the 6 screws from the bottom cover of the scale, carefully remove the platform, top cover and remove the three flexible cables from the Main PC board.</p> <p>Reconnect the ac adapter to the scale. Check dc voltage at pins 1 and 4 of connector J8 on the Main PC board. Should read between 12-16 Volts dc. If voltage is not present, replace the Main PC board. See Figure 2-3. If OK, proceed.</p>
	<p>Membrane switch defective.</p>	<p>See Table 2-10.</p>
	<p>Main PC Board is defective.</p>	<p>If the scale fails to turn on with a new membrane switch, the Main PC board is defective and should be replaced. Replace Membrane Switch. -> <u>Repair Procedures 3.4.</u></p>

CHAPTER 2 DIAGNOSIS

TABLE 2-9 TROOPER COUNT SCALE - WILL NOT TURN ON USING BATTERIES.

SYMPTOM	PROBABLE CAUSE	REMEDY
<p>Scale will not turn on with new batteries installed.</p>	<p>Incorrect battery installation.</p> <p>Wiring harness defective or battery clips connection broken.</p> <p>Membrane switch defective.</p> <p>Main PC Board is defective.</p>	<p>Check position of batteries.</p> <p>Remove the 6 screws from the bottom cover of the scale, carefully remove the platform, top cover and remove the flexible cable from the Main PC board.</p> <p>Check dc voltage at pins 1 and 3 of connector J7 on the Main PC board. See Figure 2-3. Voltage should read approximately 9 Volts dc. If voltage is not present at the connector, remove the batteries and make a continuity test between each of the connectors in the battery box to connector J7, pins 1 and 3 on the Main PC board. Resistance should be 0 ohms for the red lead and 0 ohms for the black lead. If an open condition exists, trace wiring and resolder or replace wiring as necessary. If OK, proceed.</p> <p>See Table 2-10.</p> <p>If the scale fails to turn on with a new membrane switch, the Main PC board is defective and should be replaced. -> <u>Repair Procedures 3.5.</u></p>

TABLE 2-10 TROOPER COUNT SCALE - DOES NOT RESPOND TO FRONT PANEL CONTROLS.

SYMPTOM	PROBABLE CAUSE	REMEDY
<p>Scale does not respond to front panel controls.</p> <p>NOTE: Use a known good ac adapter for this test.</p>	<p>Membrane switch defective.</p>	<ol style="list-style-type: none"> 1. Open the scale, remove six screws from the bottom of the scale. 2. Refer to Figure 2-4. Using an Ohmmeter, measure the resistance on all switches on the membrane switch cable, they should all be open, then press each button and check that the resistance is zero for each button. If continuity is not present, the membrane switch is defective. Replace membrane Switch -> <u>Repair procedures 3.4</u> or Substitute with a good membrane switch plugged into the Main PC board and press each button if they work, the original membrane switch is defective and should be replaced. -> <u>Repair procedures 3.4</u> 3. If the membrane switch is OK, replace the Main PC Board. -> <u>Repair procedures 3.5</u>

CHAPTER 2 DIAGNOSIS

TABLE 2-11 TROOPER COUNT SCALE - NO DISPLAY OR PARTIAL DISPLAY.

SYMPTOM	PROBABLE CAUSE	REMEDY
<p>Display is not on or partial characters are displayed.</p>	<p>Either the display board connector is loose from the Main PC board</p> <p>or the display PC board is defective.</p> <p>Main PC board is defective.</p>	<p>Remove the 6 screws from the bottom cover of the scale, carefully remove the platform, top cover and remove the three flexible cables from the Main PC board. Check that the cable connectors were not loose.</p> <p>The display PC board is replaced as a whole assembly. Check procedures in Table 2-8 first and verify that other problems do not exist.</p> <p>Install a new display PC board, connect all cables. -> <u>Repair Procedures 3.6</u>. Put the cover and platform in place. Do not install cover screws.</p> <p>Turn on the scale and observe the display. If the display functions properly, install the cover screws. If the display fails to operate, continue.</p> <p>Replace the Main PC board, reassemble, perform tests in Section 5 and verify operation. -> <u>Repair Procedures 3.5</u>.</p>

TABLE 2-12 TROOPER COUNT SCALE - CANNOT CALIBRATE.

SYMPTOM	PROBABLE CAUSE	REMEDY
<p>Scale can be turned on but will not calibrate.</p>	<p>Incorrect weights.</p> <p>The software lock menu is set ON.(LOC CAL ON)</p> <p>Load cell assembly defective.</p>	<p>Verify that proper weights are used.</p> <p>Set the software lock menu to OFF. Access to the software switch is when the hardware switch is OFF.</p> <p>Remove the 6 screws from the bottom cover of the scale. Carefully remove the platform. Lift the top cover and lay aside leaving the cables connected to the Main PC Board.</p> <p>With the scale plugged in and turned on, measure voltage on terminals -EXE and +EXE. The nominal voltage should be 5 V dc. If the voltage is much lower, disconnect the load cell from the Main PC Board and measure again. If 5V dc is present, the load cell may be shorted and requires replacement.</p> <p>With the platform in place and the scale turned on, measure across pins -SIG and +SIG on the Main PC Board. Typical no load output from the load cell is -1.0 mv to + 1.0 mv. If the output exceeds this value, replace the load cell.</p> <p>If this measurement is within limits, place a full load on the platform and measure again. The difference between zero and full load reading should be as shown on the table on the next page. If the reading is out of this range, replace the Load Cell. -> <u>Repair Procedures 3.7.</u></p> <p>NOTE: Readings may differ from table due to load cell tolerances.</p> <p>Reassemble, the scale, perform tests in Section 5 and verify operation.</p>

CHAPTER 2 DIAGNOSIS

TABLE 2-12 TROOPER COUNT SCALE - CANNOT CALIBRATE (Cont.).

SYMPTOM	PROBABLE CAUSE	REMEDY										
Scale can be turned on but will not calibrate.	Main PC Board is defective.	<p>If the above readings are within limits, the Main PC Board is defective.</p> <p>To check the Main PC Board if unsure about the load cell, connect a known good load cell or load cell simulator to connector J1 as shown in Figure 2-3. Use an output of 0 mv/V for CAL ZERO and 1 mv/V for span calibration. If unable to calibrate, the Main PC Board is defective.</p> <p>Replace the Main PC Board. -> <u>Repair Procedures 3.5.</u></p>										
<p>LOAD CELL OUTPUT READINGS</p> <table border="0"> <tr> <td>MODEL</td> <td>SPAN SIGNAL</td> </tr> <tr> <td>TC3RS</td> <td>4.0-5.0mv</td> </tr> <tr> <td>TC6RS</td> <td>3.5-4.5mv</td> </tr> <tr> <td>TC15RS</td> <td>4.5-5.5mv</td> </tr> <tr> <td>TC30RS</td> <td>6.5-8.3mv</td> </tr> </table> <p>NOTE: Span signal readings are approximate. If readings are slightly above or below these limits, the loadcell may still function properly.</p>			MODEL	SPAN SIGNAL	TC3RS	4.0-5.0mv	TC6RS	3.5-4.5mv	TC15RS	4.5-5.5mv	TC30RS	6.5-8.3mv
MODEL	SPAN SIGNAL											
TC3RS	4.0-5.0mv											
TC6RS	3.5-4.5mv											
TC15RS	4.5-5.5mv											
TC30RS	6.5-8.3mv											

TABLE 2-13 TROOPER COUNT SCALE - COMMUNICATIONS FAILURE.

SYMPTOM	PROBABLE CAUSE	REMEDY
Communications cannot be established with scale turned on.	<p>Communication cable is not plugged in or the incorrect cable is being used.</p> <p>Improper settings in the Print menu.</p> <p>Main PC Board is defective.</p>	<p>Tighten connectors and use the proper cable.</p> <p>Ensure that the communications parameters of the scale and peripheral device match.</p> <p>Replace Main PC Board. -> <u>Repair Procedures 3.5.</u> Reassemble the scale. Perform tests in Chapter 4 and verify operation.</p>

2.6 TROOPER COUNT SCALE DIAGRAM




Figure 2-3. Trooper Count Scale Interconnection Diagram.

CHAPTER 2 DIAGNOSIS

2.7 TROOPER COUNT ERROR CODE TABLE

TABLE 2-14. TROOPER COUNT SCALE ERROR CODES.

ERROR CODE	CAUSE	REMEDY
[Batt][Low]	Batteries are weak.	Replace batteries.
[Err 1][over][Load]	The load on the platform exceeds the rated capacity of the scale (overload condition).	Remove excess load. Refer to the Troubleshooting Tables.
[Err 2][Under][Load]	Underload condition. The load cell signal is more than 9 divisions below zero.	Press the ON/ZERO Off button. If problem persists, refer to the troubleshooting section to check load cell assembly.
[Err 3][Low][APW]	APW is below minimum allowed value.	Correct the APW setting.
[Err 4][Low][ref]	Reference weight is below minimum value.	Correct the reference weight setting.
[Err 7][EEpr][Error]	EEPROM hardware problem.	Turn unit on and off and on again. If error 7 remains, replace the Main PC board. -> <u>Repair Procedures 3.5</u> .
[Err 14][Zero][Error]	<p>When ON/ZERO OFF button is pressed, the load on the pan exceeds zero % menu setting. Could be caused by a load on the pan.</p> <p>At power up, the load cell signal is outside the allowable limit.</p>	<p>Enter the Setup Menu and set the zero % to a higher setting. (See Instruction Manual.)</p> <p>Perform a linearity calibration. If this fails, substitute the load cell assembly and perform the linearity calibration again. Refer to Table 2-12. If the substitute load cell does not correct the condition, re-install the original load cell and replace the Main PC board. -><u>Repair Procedures 3.5</u></p>
[Err 21][CAL][Error]	Calibration incorrect.	Recalibrate scale. If the problem persists, replace the Main PC board or Load Cell.
[CAL][data][Error]	Span point parameter check failed during program running.	Recalibrate scale. If the problem persists, replace the Main PC board or Load Cell.

TABLE 2-14. TROOPER COUNT SCALE ERROR CODES (Cont.).

SYMPTOM	CAUSE	REMEDY
[CAP][data][Error]	Capacity point parameter check failed during program running.	Recalibrate scale. If the problem persists, replace the Main PC board or Load Cell.
[Load][Error][]	Incorrect calibration weight was used.	Recalibrate the scale.
[Entry][Too][High]	keypad input number is over limit.	Enter proper value within limits.
[Start][Stable][Error]	Scale is not stable at power on. Interference between platform and load cell.	Check that the surface the scale is resting on is stable. Check that proper clearances exist between the cover and the load cell under the platform.

CHAPTER 2 DIAGNOSIS




Figure 2-4. Trooper Count Scale Membrane Switch Wiring Diagram.

3. REPAIR PROCEDURES

This section describes how to change individual components of the Trooper Scale and Trooper Count Scale. When doing this, please refer to the exploded view drawings and parts lists in section 5.

Important: After replacing components, a functional check of the scale must always be carried out.

3.1 REPLACING THE TROOPER SCALE MEMBRANE SWITCH

The membrane switch is affixed to the upper housing of the scale. To replace the membrane switch, the scale must be disassembled to gain access to the switch connections.

1. Remove power from the scale.
2. Carefully lift and remove the platform from the scale. One rubber foot remains attached to the platform. This ensures that the platform is properly located on the weighing load cell.
3. Turn the scale over and remove the six screws which hold the upper housing.

CAUTION

Use care in the next step as the membrane switch wiring is attached to the PC board.

4. Place the scale in the upright position and carefully lift the upper housing from the bottom housing about two to three inches. Reach under the upper housing from the front and carefully disconnect the flexible cable from connector J5A on the Main PC board.
5. On the upper housing, lift up the defective membrane switch (if necessary carefully prying it up with a knife) and gently peel it off the upper housing.

CAUTION

Do not use any solvents that may harm the finish or cause damage to the cover.

6. Carefully clean the upper housing membrane switch area (removing all traces of adhesive). The best method is to use a flat razor blade.
7. Insert the cable from the new membrane switch through the hole in the upper housing. Peel off the protective film from the new membrane switch and carefully align and affix to the upper housing.
8. Press the membrane switch down uniformly. Using your fingers with a cloth, roll from the center of the membrane switch outward towards the edges to remove any air bubbles that may be trapped.
9. Position the upper housing in place over the scale and connect the flexible cable from the membrane switch to socket J5A on the Main PC board.
10. Reassemble the scale by replacing the six screws at the bottom of the scale which secure the upper housing.
11. Replace the platform on top of the scale.

CHAPTER 3 REPAIR PROCEDURES

3.2 REPLACING THE TROOPER SCALE MAIN PC BOARD

The Main PC Board is located inside the scale towards the front. To replace the Main PC Board, it is necessary to disassemble the scale.

1. Perform steps 1 through 4 of paragraph 3.1.
2. Remove the connector plugs from J6 and J7 on the Main PC Board which is battery and external power. See Figure 3-1.




Figure 3-1. Trooper Scale Connector Locations.

3. Carefully remove the wires coming from J10 which is the RS232 connector and J4 which is used to connect the loadcell.
 4. Remove the four corner screws on the Main PC Board
 5. Replace the Main PC Board and install the four screws previously removed.
- NOTE:** Make sure that Jumper 1 and Jumper 2 are connected as shown in Figure 3-1.
6. Replace the color coded wiring for connectors J4 and J10. Check color coded wiring is correctly installed. See Figure 3-2 for wire color and locations.
 7. Replace the connectors to J6 and J7 on the Main PC Board.
 8. Put the jumper across both pins of W1.
 9. Position the upper housing in place over the scale and connect the flexible cable from the membrane switch to J5A connector on the Main PC board.

3.2 REPLACING THE TROOPER SCALE MAIN PC BOARD (Cont.)




Figure 3-2. Trooper Scale RS Connector and Loadcell Connector Wiring.

10. Check the LFT lock switch (legal for trade) switch (S1). Make sure it is in the ON position.
11. Turn on the scale. When self testing is completed, the display may indicate an error code. This is normal.
12. Do not turn off the power. Switch LFT lock switch to its OFF position.
13. Set the capacity and readability according to Table 4-1 in Chapter 4 of this manual. Refer to Setup menu procedures in the Instruction manual.
14. Calibrate the scale according to the Instructions in Appendix A
15. After finishing all of the necessary configuration, remove the jumper from W1 and keep the LFT lock switch in its OFF position.
16. Turn the scale off then on. It will go through all the self testing.
17. If the scale locks up, with software revision showing, this means that W1 is in the closed position and the LFT lock switch is in the ON position. Change them to the correct position, W1=Open and LFT lock switch=OFF.
18. Reassemble the scale.
19. Replace the platform on top of the scale.
20. After installation, check all operations, if possible, set the original customer settings back into the scale and calibrate the scale.

CHAPTER 3 REPAIR PROCEDURES

3.3 REPLACING THE TROOPER SCALE LOAD CELL ASSEMBLY

The Load Cell Assembly is centrally located inside the scale. See Figure 3-3. The load cell is factory assembled and the down stops are preadjusted. There are no adjustments to be made on this assembly after installation.

1. Perform steps 1 through 4 of paragraph 3.1.
2. Carefully remove the load cell wires from connector J4. See Figure 3-2 for wire color and locations.
3. Remove the four screws holding the Load Cell Assembly to the bottom housing.
4. Lift the Load Cell Assembly out of the bottom housing and replace with a new one.
5. Connect the color coded wiring from the load cell to connector J4. Check that color coded wiring is correctly installed. See Figure 3-2.
6. Put the jumper across both pins of W1
7. Position the upper housing in place over the scale and connect the flexible cable from the membrane switch to connector J5A on the Main PC board.
8. Check the LFT lock switch. Make sure it is in the ON position.
9. Turn on the scale. When self testing is completed, the display may indicate an error code. This is normal.
10. Do not turn off the power. Switch LFT lock switch to its OFF position.
11. Calibrate the scale according to the instructions in Appendix A.
12. After finishing all of the necessary configuration, remove the jumper from W1 and keep the LFT lock switch in its OFF position.
13. Turn the scale off then on. It will go through all the self testing.
14. If the scale locks up, with software revision showing, this means that W1 is in the closed position and the LFT lock switch is in the ON position. Change them to the correct position, W1=Open and LFT lock switch=OFF.
15. Reassemble the scale.
16. Replace the platform on top of the scale.
17. After installation, check all operations, if possible, set the original customer settings back into the scale and calibrate the scale.

3.3 REPLACING THE TROOPER SCALE LOAD CELL ASSEMBLY (Cont.)




Figure 3-3. Trooper Scale Component Locations.

CHAPTER 3 REPAIR PROCEDURES

3.4 REPLACING THE TROOPER COUNT SCALE MEMBRANE SWITCH

The membrane switch is affixed to the upper housing of the scale. The scale must be disassembled to gain access to the membrane switch connections.

1. Remove power from the scale.
2. Carefully lift and remove the platform from the scale. One rubber foot remains attached to the platform. This ensures the platform is properly located on the weighing load cell.
3. Turn the scale over and remove the six screws which hold the upper housing. One screw is located underneath the rear most sealing cover. The cover screw will have to be removed first.

CAUTION

Use care in the next step as the membrane switch wiring is attached to the PC board.

4. Place the scale upright position and carefully lift the upper housing from the bottom housing about two to three inches. Reach under the upper housing from the front and carefully disconnect the three flexible cables from the Main PC board. Two cables are part of the membrane switches and the other cable is for the display PC board.
5. On the upper housing, lift up the defective membrane switch (if necessary carefully prying it up with a knife) and gently peel it off the upper housing.

CAUTION

Do not use any solvents that may harm the finish or cause damage to the cover.

6. Carefully clean the upper housing membrane switch area (removing all traces of adhesive). The best method is to use a flat razor blade.
7. Insert the two cables from the membrane switch through the hole in the upper housing. Peel off the protective film from the new membrane switch and carefully affix to the upper housing.
8. Press the membrane switch down uniformly. Using your fingers with a cloth, roll from the center of the membrane switch outward towards the edges to remove any air bubbles that may be trapped.
9. Position the upper housing in place over the scale and connect the two flexible cables from the membrane switch to connectors J2 and J3 on the Main PC board and the single cable from the display PC board to connector J4 on the Main PC board.
10. Reassemble the scale.
11. Replace the platform on top of the scale.

3.5 REPLACING THE TROOPER COUNT SCALE MAIN PC BOARD

NOTE: Do not attempt this procedure unless you have the Trooper Count Scale Tools program.

The Main PC Board is located inside the scale towards the front. To replace the Main PC Board, it is necessary to disassemble the scale. After replacement, use the OHAUS TROOPER COUNT SCALE TOOLS program to enter data into the EEPROM.

CAUTION
THE TROOPER COUNT SCALE PC BOARD WILL NOT OPERATE
UNLESS THE TROOPER COUNT SCALE TOOLS PROGRAM IS USED.

1. Perform steps 1 through 4 of section 3.4.
2. Remove the connector plugs from connectors J7, J8 and J10 from the Main PC Board which is the battery, external power wires and Load Cell. See Figure 3-4.




Figure 3-4. Trooper Count Scale Main PC Board Connector Locations.

3. Carefully remove the wires coming from J6 which is the RS232 connector. See Figure 3-5 for wire color and locations.
4. Remove the four corner screws on the Main PC Board
5. Replace the Main PC Board and install the four screws previously removed.
6. Replace the color coded wiring for connector J6. Check color coded wiring is correctly installed.
7. Replace the connectors to J7, J8 and J10 on the Main PC Board.
8. Position the upper housing in place over the scale and connect the flexible cables from the membrane switch to connectors J2, J3 on the Main PC board and the cable from the display PC board to connector J4.
9. Check that the LFT lock switch is in the unlocked position.

CHAPTER 3 REPAIR PROCEDURES

3.5 REPLACING THE TROOPER COUNT SCALE MAIN PC BOARD (Cont.)




Figure 3-5. Trooper Count Scale RS Connector and Loadcell Connector Wiring.

10. After the scale is turned on, the display will show Error 21 => Cal => Data.
11. Refer to Appendix B and start Trooper Count Scale Tools.
12. Select the model of the Trooper Count Scale in the Model box.
13. Enter the serial number in the serial number box.
14. Check the box labeled Do Calibration After Config.
15. Click on the button labeled Write Config Data to Scale.
16. The configuration data will be written to the scale and a calibration will start. Follow the on screen directions.
17. Turn the scale off then on. It will go through all the self testing.
18. Reassemble the scale.
19. Replace the platform on top of the scale.
20. After installation, check all operations, if possible, set the original customer settings back into the scale and calibrate the scale.

3.6 REPLACING THE TROOPER COUNT SCALE DISPLAY PC BOARD

The Display PC Board is located on the inside of the upper housing. To replace the Display PC Board, it is necessary to disassemble the scale.

1. Perform steps 1 through 4 of paragraph 3.4.
2. Remove the connector plugs from connectors J2, J3 and J4 from the Main PC Board which is the membrane switch and display cables. See Figure 3-4.
3. Remove the four corner screws on the Display PC Board.
4. Replace the Display PC Board and install the four screws previously removed.
5. Position the upper housing in place over the scale and connect the two flexible cables from the membrane switch to connectors J2 and J3 on the Main PC board and the single cable from the display PC board to connector J4 on the Main PC board.
6. Reassemble the scale.
7. Replace the platform on top of the scale.
8. After installation, check all operations, if possible, set the original customer settings back into the scale and calibrate the scale.

3.7 REPLACING THE TROOPER COUNT SCALE LOAD CELL ASSEMBLY

The Load Cell Assembly is centrally located inside the scale. See Figure 3-6. The Load Cell is factory assembled and the downstops are preadjusted. There are no adjustments to be made on this assembly after installation.

1. Perform steps 1 through 4 of paragraph 3.4.
2. Disconnect cable connector from J10 which is connected to the Load Cell. See Figure 3-5 for wire color and locations.
3. Remove the four screws holding the Load Cell Assembly to the bottom housing.
4. Lift the Load Cell Assembly out of the bottom housing and replace with a new one.
5. Connect cable from the Load Cell to connector J10.
6. Position the upper housing in place over the scale and connect the flexible cables from the membrane switch to connectors J2, J3 and the cable from the display PC board to connector J4 on the Main PC board.
7. Check the LFT lock switch. Make sure it is in the ON position.
8. Turn on the scale. When self testing is completed, the display may indicate an error code. This is normal.
9. Do not turn off the power. Switch LFT lock switch to its OFF position.

CHAPTER 3 REPAIR PROCEDURES

10. Place the top cover and platform temporarily on the scale.
11. Refer to Appendix A and perform a LIN calibration.
12. Turn the scale off then on. It will go through all the self testing.
13. Reassemble the scale by replacing the six screws at the bottom of the scale which secure the upper housing.
14. Replace the platform on top of the scale.
15. After installation, check all operations, if possible, set the original customer settings back into the scale and calibrate the scale.




Figure 3-6. Trooper Count Scale Component Locations.

4. TESTING

Before and after servicing the Trooper Scale and Trooper Count Scale, they should have an operational test and various performance tests made to ascertain whether or not the scale meets specifications.

Turn the scale on and allow it warm up for at least one hour before performing these tests. Make sure the test area is free from drafts and the surface that the scale rests on is level and vibration free. The masses used for the performance tests and adjustments must meet or exceed ASTM Class 4 or OIML F2 Tolerance.

4.1 TROOPER SCALE OPERATIONAL TEST

Connect the AC Adapter into a suitable power source and connect to the scale.

4.1.1 Segment Display Test

Turn the scale on, all segments are enabled and displayed briefly followed by a software revision number. This is a segment display test. Figure 4-1 is a full display test.




Figure 4-1. Trooper Scale Segment Displays.

4.2 TROOPER COUNT SCALE OPERATIONAL TEST

Connect the AC Adapter into a suitable power source and connect to the scale.

4.2.1 Segment Display Test

Turn the scale on, all segments are enabled and displayed briefly followed by a software revision number. This is a segment display test. Figure 4-2 is a full display test.




Figure 4-2. Trooper Count Scale Segment Displays.

NOTE: For menu structures, operation, calibration procedures and menu lockout procedures, refer to the respective Instruction manuals.

CHAPTER 4 TESTING

4.3 PERFORMANCE TESTS

Accurate performance of the Trooper Scale and Trooper Count Scale is determined by a series of three performance tests. These tests are used to evaluate the scale performance before and after repairs. Each scale tested must meet the requirements specified in each test as well as the specifications listed in Tables 4-1 and 4-2. Before proceeding with the following tests, all the procedures beginning with section 4. must be successfully completed and the displayed unit must be set to kg. Set the scale readability to the factory default setting. This can be done by means of the Setup Menu – Reset function for the Trooper Count Scale and setting the Trooper Scale to kg. A scale passing each of these three tests complies with Ohaus specifications.

4.3.1 Repeatability Test

Repeatability is the standard deviation of a set of similar weight readings. To determine the repeatability, perform the following test:

1. Zero the scale. The reading on the display should be 0kg.
2. Select a test weight near the maximum capacity of the scale and place it on the **center** of the pan. Observe and record the reading.
3. Remove the test weight. The reading should return to 0g.
4. Repeat this test for **ten** readings. Calculate the standard deviation of the ten load readings using a calculator with statistical capabilities or use the following formula:

$$\text{Standard Deviation } (\sigma) = \sqrt{\frac{\sum [x - \bar{x}]^2}{n - 1}}$$

x = weight reading in kg

\bar{x} = Mean (average) of 10 readings

n = number of readings

A worksheet has been provided for entering the data and calculation results for the Standard Deviation (Figure 4-3). Step by step instructions for calculating the standard deviation are provided in Figure 4-4 and a sample calculation is provided in Figure 4-5.

4.3.1 Repeatability Test (Cont.)

Figure 4-3. Standard Deviation (σ) Worksheet.

Reading	Weight (kg)	Weight - Mean	(Weight – Mean) ²
1			
2			
3			
4			
5			
6			
7			
8			
9			
10			
	SUM = Mean = SUM/10 Mean =		SUM = Variance = SUM/9 $\sigma = \sqrt{\text{Variance}}$ $\sigma = \sqrt{\quad}$

Figure 4-4. Calculation of Standard Deviation (σ).

Reading	Weight (kg)	Weight - Mean	(Weight – Mean) ²
1		(3)	(4)
2		(3)	(4)
3		(3)	(4)
4		(3)	(4)
5		(3)	(4)
6		(3)	(4)
7		(3)	(4)
8		(3)	(4)
9		(3)	(4)
10		(3)	(4)
	SUM = (1) Mean = SUM/10 Mean = (2)		SUM = (5) Variance = SUM/9 (6) $\sigma = \sqrt{\text{Variance}}$ $\sigma = (7)$

After recording the ten weight readings in the Weight column perform the following steps:

1. Record the sum of the ten weight readings here.
2. Record the Mean (Avg) of the ten weight readings here. (SUM divided by 10)
3. For each weight reading, subtract the calculated Mean and record the result.
4. For each weight reading, record the square of the (Weight – Mean) from step 3.
5. Record the sum of the squared (Weight – Mean) values from step 4.
6. Record the Variance of the ten weight readings here. (SUM divided by 9)
7. Record the Standard Deviation of the ten weight readings here. (square root of the Variance)

CHAPTER 4 TESTING

4.3.1 Repeatability Test (Cont.)

Figure 4-5. Sample Calculation of Standard Deviation (σ).

Reading	Weight (kg)	Weight - Mean	(Weight - Mean) ²
1	3000.0	-.02	.0004
2	3000.0	-.02	.0004
3	3000.2	.18	.0324
4	3000.0	-.02	.0004
5	3000.2	.18	.0324
6	3000.0	-.02	.0004
7	2999.8	-.22	.0484
8	3000.0	-.02	.0004
9	3000.0	-.02	.0004
10	3000.0	-.02	.0004
	SUM = 30,000.2 Mean = SUM/10 Mean = 3000.02		SUM = 0.116 Variance SUM/9=.0129 $\sigma = \sqrt{\text{Variance}}$ $\sigma = 0.114$

4.3.2 Off-Center Load Test

The Off-Center Load Test is used to determine whether displayed weight values will be affected by moving the load to different areas of the weighing pan. See Figure 4-6.




Figure 4-6. Off-Center Load Test Weight Locations.

4.3.2 Off-Center Load Test (Cont.)

1. Zero the scale.
2. Place a test weight equal to 1/2 the scale capacity in the center of the weighing platform and record the reading.
3. Move the test weight to the mid-point between the center and the left edge of the weighing platform and record the reading.
4. Move the test weight to the mid-point between the center and the rear of the weighing platform and record the reading.
5. Move the test weight to the mid-point between the center and the right edge of the weighing platform and record the reading.
6. Move the test weight to the mid-point between the center and the front of the weighing platform and record the reading.
7. Subtract the center position reading from the reading at each outer position. The difference at each test position should be within the cornerload tolerance specified in Table 4-1 for Trooper Scale and Table 4-2 for Trooper Count Scale.

4.3.3 Linearity Test

The Linearity test is used to determine the linearity of the scale throughout its operating range.

NOTE: The scale must pass the Repeatability and Off-Center Load Tests before the Linearity test is performed. Before performing this test, calibrate the scale according to Appendix A.

1. Place masses totaling 1/3 of the capacity of the scale on the platform and note the weight. Set this mass aside, it will become the test mass.
2. Place masses totaling 1/3 of the capacity of the balance on the platform and zero the scale.
3. Place the test mass on the platform and record the weight.
4. Place masses totaling 2/3 of the capacity of the scale on the platform and zero the scale.
5. Place the test mass on the platform and record the weight.
6. The difference of the 3 recorded weights should be less than or equal to the tolerance values listed in tables 4-1 and 4-2.

CHAPTER 4 TESTING

4.4 TROOPER SCALE SPECIFICATIONS

TABLE 4-1. TROOPER SCALE SPECIFICATIONS.

Model	TR3RS	TR6RS	TR15RS	TR30RS
Default Capacity X Readability (lb)	6lb X 0.001lb	15lb X 0.002lb	30lb X 0.005lb	60lb X 0.01lb
Default Capacity X Readability (kg)	3kg X 0.0005kg	6kg X 0.001kg	15kg X 0.002kg	30kg X 0.005kg
Default Capacity X Readability (g)	3000g X 0.5g	6000g X 1g	15000g X 2g	30000g X 5g
Default Capacity X Readability (oz)	96oz X 0.02oz	240oz X 0.05oz	480oz X 0.1oz	960oz X 0.2oz
Type Approved Capacity X Readability (lb)	6lb X 0.002lb	15lb X 0.005lb	30lb X 0.01lb	60lb X 0.02lb
Type Approved Capacity X Readability (kg)	3kg X 0.001kg	6kg X 0.002kg	15kg X 0.005kg	30kg X 0.01kg
Type Approved Capacity X Readability (g)	3000g X 1g	6000g X 2g	15000g X 5g	30000g X 10g
Type Approved Capacity X Readability(oz)	96oz X 0.05oz	240oz X 0.1oz	480oz X 0.2oz	960oz X 0.5oz
Linearity (g)	±0.5g	±1g	±2g	±5g
Repeatability	±0.5g	±1g	±2g	±5g
Off Center Load	±0.5g	±1g	±2g	±5g

4.5 TROOPER COUNT SCALE SPECIFICATIONS

TABLE 4-2. TROOPER COUNT SCALE SPECIFICATIONS.

Model	TC3RS	TC6RS	TC15RS	TC30RS
Default Capacity X Readability (lb)	6lb X 0.001lb	15lb X 0.002lb	30lb X 0.005lb	60lb X 0.01lb
Default Capacity X Readability (kg)	3kg X 0.0005kg	6kg X 0.001kg	15kg X 0.002kg	30kg X 0.005kg
Default Capacity X Readability (g)	3000g X 0.5g	6000g X 1g	15000g X 2g	30000g X 5g
Default Capacity X Readability (oz)	96oz X 0.02oz	240oz X 0.05oz	480oz X 0.1oz	960oz X 0.2oz
Type Approved Capacity X Readability (lb)	6lb X 0.002lb	15lb X 0.005lb	30lb X 0.01lb	60lb X 0.02lb
Type Approved Capacity X Readability (kg)	3kg X 0.001kg	6kg X 0.002kg	15kg X 0.005kg	30kg X 0.01kg
Type Approved Capacity X Readability (g)	3000g X 1g	6000g X 2g	15000g X 5g	30000g X 10g
Type Approved Capacity X Readability(oz)	96oz X 0.05oz	240oz X 0.1oz	480oz X 0.2oz	960oz X 0.5oz
Linearity (g)	±0.5g	±1g	±2g	±5g
Repeatability	±0.5g	±1g	±2 g	±5g
Off Center Load	±0.5g	±1g	±2g	±5g

4.6 COMMUNICATION TEST

The Trooper Scale and Trooper Count Scale each contain a communication port for RS232 protocol communications. The RS232 Interface is a bi-directional interface that enables the scale to communicate with a printer or computer equipped with an RS232 serial port. After the scale has been repaired and calibrated and all menu functions operate normally, the communication function between the scale and a computer has to be checked.

For this test, you will require a PC computer with communication capabilities such as a Hyper-Terminal or a Terminal program that allows setting of communication parameters and an Ohaus RS-232 Cable P/N 80500433, IBM-PC -9 pin or a standard null modem cable.

The RS232 Interface in the Trooper Scale and Trooper Count Scale can have its performance monitored using an external printer or computer connected to the scale. It is preferable to use a computer so commands can be sent to the scale to verify operation.

4.6.1 Setting Trooper Scale Print Menu

The Trooper Scale Print menu provides communication parameters which can be set to accommodate external printers or computers. It contains the following submenus: **Reset, Baud Rate, Parity Bit, Data Length, Stop Bits, Auto Print, Interval, Stable,** and **save settings** which enable you to program RS232 port parameters.

Set the Trooper Scale print menu to factory settings which should be: Baud rate=2400, Parity Bit=None, Data Length=7, Stop Bits=2, Auto print=Off, Interval=1 and Stable=Off. Save these settings.

4.6.2 Setting Trooper Count Scale Print Menu

The Trooper Count Scale also contains a print menu with the following submenus: **Baud Rate, Data Length, Parity Bit, Print Part No., Print Count, Print APW, Print Net, Print Tare, Print Total PCS, Print Gross, print on Stable, Print Header and Print Style.**

Set the Trooper Count Scale Print menu to factory settings which should be: Baud Rate=2400, Data Length=7, Parity Bit=None, Print Part No.=Off, Print Count=On, Print APW=On, Print Net=On, Print Tare=Off, Print Total PCS=On, Print Gross=Off, Print on Stable=Off, Print Header=Off and Print Style=Col.

CHAPTER 4 TESTING

4.6.3 Connecting the RS232 Interface

Connect the RS-232 cable from the Scale to the Computer. When the interface is connected to a computer, two way communication between the computer and scale is possible using the commands outlined in the RS232 Command Table 4-3 for Trooper Scale and Table 4-4 for Trooper Count Scale. See Figure 4-7 for connections. When the scale is connected directly to a printer, displayed data can be output at any time by simply pressing **PRINT UNITS** button on the Trooper Scale and Trooper Count Scale.




Figure 4-7. RS232 Interface Pin Connections.

RS232 Commands

All communication is accomplished using standard ASCII format. Only the characters shown in the RS232 Command Table 4-3 and 4-4 are acknowledged by the scale. Invalid command response "ES" error indicates the scale has not recognized the command. Commands sent to the scale must be terminated with carriage return and line feed (CRLF). Data output by the scale is always terminated with a carriage return and line feed (CRLF).

TABLE 4-3. TROOPER SCALE RS232 COMMANDS

Command Character	Description
?	Print current mode: kg, g, lb, oz.
P	Same as pressing PRINT button.
T	Same as pressing TARE button.
Z	Same as pressing ZERO button.
xS	Print Stable only. Where x=0 Off, and x=1 On.
AS	Automatically send data when stable after motion.
xxxxS	Send at interval. Where xxxx=1 to 3600 seconds.
CS	Send as fast as possible (continuous print).
M	Increment to next enabled unit.
V	Output software version. For example: "TC30 Sr. 1.20"

To turn auto printing, interval printing or continuous printing off, send P to reset normal printing mode.

4.6.3 Connecting the RS232 Interface (Cont.)

TABLE 4-4. TROOPER COUNT SCALE RS232 COMMANDS

Command Character	Description (LFT is OFF)
P	Same as pressing PRINT button. Sends print data to peripheral device.
V	Output software version. For example: "TC30 Sr. 1.20"
T	Same as pressing TARE. If the Scale accepts the command, it will respond "OK". If the Scale is in motion, it will output "CANT TARE" until the Scale is stable. When stable, tare is accepted. (NOTE: If LFT is ON, special tare rules apply.)
Z	Same as pressing ZERO button. If the Scale accepts the command, it will respond "OK".

4.6.4 Print Test

1. Remove all weight from the platform.
2. To zero the scale, press the **ON/ZERO/OFF** button once.
3. Place a mass on the Platform.
4. Press **PRINT Unit** button, the computer or a printer should record the weight value.
5. Refer to Tables 4-3 for the Trooper Scale and 4-4 for the Trooper Count Scale and try all commands and verify operation of the scale.

CHAPTER 4 TESTING

5. PARTS LISTS

This section of the manual contains exploded views, and parts lists for the Trooper Scale and Trooper Count Scale. The exploded view drawings identifies the replaceable parts.

NOTE:

In all cases where a part is replaced, the scale must be thoroughly checked after the replacement is made. The scale **MUST** meet the parameters of all applicable specifications in this manual.

If further technical information is needed, in the United States call toll-free 1-800-526-0659 between 8.00 a.m. and 4.00 p.m. EST. An Ohaus factory service technician will be available to provide assistance. Outside the U.S.A., please contact:

Ohaus Corporation
19A Chapin Road
P.O. Box 2033
Pine Brook, NJ 07058, USA
Tel: (973) 377-9000,
Fax: (973) 593-0359

CHAPTER 5 PARTS LISTS

5.1 Trooper Scale/Trooper Count Scale Exploded View




Figure 5-1. Exploded View of Trooper Scale and Trooper Count Scale.

TABLE 5-1. TROOPER SCALE (TR) AND TROOPER COUNT SCALE (TC) PARTS LIST

ITEM NO.	PART NO.	DESCRIPTION	QUANTITY
1	71133849	Platform Assembly, TR, TC	1
2	71133037	Membrane Switch, TR	1
2	71138748	Membrane Switch, TC	1
3	71102326	Level, TR, TC	1
4	71133160	Upper Housing, Assy w Membrane Switch, TR 1	
4	71152365	Upper Housing, Assy w Membrane Switch, TC 1	
5	See Note 1	Screw, M4x8	4
6	71133746	Load Cell Assembly, 3kg, TR3RS	1
6	71133747	Load Cell Assembly, 6kg, TR6RS	1
6	71133748	Load Cell Assembly, 15kg, TR15RS	1
6	71133749	Load Cell Assembly, 30kg, TR30RS	1
6	71127150	Load Cell Assembly, 3kg, TC3RS	1
6	71128566	Load Cell Assembly, 6kg, TC6RS	1
6	71128567	Load Cell Assembly, 15kg, TC15RS	1
6	71141919	Load Cell Assembly, 30kg, TC30RS	1
7	71134281	Main PCB Assembly, TR	1
7	71138662	Main PCB Assembly, TC	1
8	See Note 1	Screw, M4x6	2
9	See Note 1	Screw, M3x8	2
10	See Note 1	Washer, 3mm	2
11	See Note 1	Nut, DS026AS	1
12	See Note 1	Nut, M3, GB6170-86	2
13	71133660	Harness, PWR/COM, TR, TC	1
14	71133035	Bottom Housing, TR, TC	1
15	71133036	Cover, Battery, TR, TC	1
16	71127394	Contact, Battery, Positive, TR, TC	1
17	71127395	Contact, Battery, Dual, TR, TC	1
18	71133155	Sealing, Cover, TR, TC	2
19	71127396	Contact, Battery, Negative, TR, TC	1
20	71123028	Foot, w/Nut, TR, TC	4
21	See Note 2	Screw, Sealing, M4x8	2
22	See Note 1	Screw, M4x8	6

NOTES:

1. Item included in Fastener Kit, P/N 71139672
2. Item included in LFT Sealing Kit, P/N 71138587

CHAPTER 5 PARTS LISTS

TABLE 5-1. TROOPER SCALE (TR) AND TROOPER COUNT SCALE (TC) PARTS LIST (Cont.)

ITEM NO.	PART NO.	DESCRIPTION	QUANTITY
23	71132592	Display, LCD, TR	1
24	71138664	Display PC Board Assembly, TC	1
25	71115243	Spacer, Rubber, TR, TC	4
26	71116785	Display, LCD, TC	1
---	71139672	Fastener Kit, TR, TC	1
---	71138587	Sealing Kit, TR, TC	1
---	80500435	AC Adapter 120V 50/60Hz US	1
---	80500436	AC Adapter 230V 50/60Hz EU	1
---	80500437	AC Adapter 240V 50/60Hz UK	1
---	80500462	AC Adapter 240V 50/60Hz AU	1

A.1 TROOPER SCALE LINEARITY CALIBRATION

CAL .

SPAN Y

Lin Y

-[-

LIN CP

4 kg

-[-

FULLCP

6 kg

-[-

6.000 kg
Gross
Brutto

If required turn the Calibration Lock Switch off.

With the Scale ON, press and hold the button **G/N/T/MENU** until MENU is displayed. When you release the **G/N/T/MENU** button, CAL is displayed.

Press **G/N/T/MENU** button, SPAN Y is displayed.

Press **PRINT/UNITS** button, Lin Y is displayed.

Press **G/N/T/MENU** button, -[- is displayed. The scale MUST be stable during this period and is establishing a zero point. After a few seconds, the display flashes LIN CP twice and the requested weight value is displayed. The sample illustration indicates a 4kg mid point for a 6kg scale. (Linearity calibration for Trooper is 0, 2/3 and full capacity).

Place the indicated mass on the platform. Keep the platform stable during this period.

Press **G/N/T/MENU** button, -[- is displayed. The scale MUST be stable during this period and is establishing the intermediate point. After a few seconds, the display flashes FULLCP and the requested weight value is displayed.

Place the indicated mass on the platform and press the **G/N/T/MENU** button -[- is displayed. The scale MUST be stable during this period and is establishing the full scale point.

If linearity calibration was successful, the calibration mass is displayed and the calibration data is saved automatically. If unsuccessful, refer to the troubleshooting section.


Remove calibration masses from platform.

NOTE: If the Scale is to be used for legal for trade applications, it must be calibrated and the Lock Switch must be set to lock out the menus. Refer to the Instruction Manual, sealing for legal for trade use.


APPENDIX A - CALIBRATION

A.2 TROOPER COUNT SCALE LINEARITY CALIBRATION


The following example is with a 6kg Scale. With the Scale ON, press and hold the *SAMPLE Menu* button until CAL MENU is displayed.




Press the **Enter** button.





Press the **M-** button.





Press the **Enter** button.



Press the **M+** button, then press the **Enter** button. Follow display instructions.




(Scale is determining zero value)




Place the indicated calibration mass on the pan. Press the **Enter** button. The sample illustration indicates a 6kg Scale using a 4kg mass for the first linearity entry.

(Scale is determining first linearity value)




A.2 TROOPER COUNT SCALE LINEARITY CALIBRATION (Cont.)




Place the indicated calibration mass on the pan. Press the **Enter** button. The sample illustration indicates a 6kg Scale using a 6kg mass.

(Scale is determining second linearity value)



If the calibration was successful, LIN TEST DONE is displayed momentarily followed by CAL MENU and the calibration data is saved automatically. Remove calibration masses from pan.



To return to weighing, press the **Data** button.

APPENDIX A - CALIBRATION

A.3 LINEARITY CALIBRATION WEIGHTS

Linearity calibration weights are defined in Tables A1 and A-2 for the Trooper Scale and Trooper Count Scale.

TABLE A-1 TROOPER SCALE LINEARITY WEIGHTS

Cal in kg:	Linearity cal (fixed) Masses Totaling
TR3RS	2 & 3 kg
TR6RS	4 & 6 kg
TR15RS	10 & 15 kg
TR30RS	20 & 30 kg
Cal in lb:	Linearity cal (fixed) Masses Totaling
TR3RS	4 & 6 lb
TR6RS	10 & 15 lb
TR15RS	20 & 30 lb
TR30RS	40 & 60 lb

TABLE A-2 TROOPER COUNT SCALE LINEARITY WEIGHTS

Cal in kg:	Linearity Cal (fixed) Masses Totaling
TC3RS	2 & 3 kg
TC6RS	4 & 6 kg
TC15RS	10 & 15 kg
TC30RS	20 & 30 kg
Cal in lb:	Linearity Cal (fixed) Masses Totaling
TC3RS	4 & 6 lb
TC6RS	10 & 15 lb
TC15RS	20 & 30 lb
TC30RS	40 & 60 lb

NOTE: Recommended tolerance Class for the calibration masses: ASTM Class 4 or OIML F2.

APPENDIX B - TROOPER COUNT SCALE TOOLS

B.1 INTRODUCTION

This Appendix covers the use of the Trooper Count Scale Tools software from Ohaus Corporation.

Trooper Count Scale Tools is a maintenance software program designed to work with the Trooper Count Scale. Through the RS232 interface, this program allows a user to configure the scale settings and library data and test output commands from a PC. Use of the Trooper Count Scale Tools is required after the main PC board of the Trooper Count Scale is replaced.

B.2 INSTALLATION

B.2.1 Minimum Requirements

The following are minimum requirements for installing and using Trooper Count Scale Tools:

- Ohaus Trooper Count Scale (with standard RS232 serial port)
- Ohaus compatible Serial Cable (Ohaus part number: 80500433 or 80500431)
- IBM PC (or compatible) – Pentium™ 75Mhz or better
- Windows™ 95, 98, NT or 2000
- 5 MB of free hard disk space

B.2.2 Connecting the RS232 Interface

Connect the Serial Cable between the RS232 serial port of the Trooper Count Scale and the serial port of the computer. Note which serial port of the computer (i.e., COM1, COM2, etc.) the cable was connected, as this information may be required when configuring the software.

B.2.3 Installing the Trooper Count Scale Tools Software Program

With the Trooper Count Scale Tools CD on-hand:

- Load the CD containing the Trooper Count Scale Tools software program onto the computer.
- Open the CD directory folder.
- Select "Setup" to install the program.
- Follow the installation instruction as they appear on-screen.

B.2.4 Opening the Trooper Count Scale Tools Software Program

Select the TC Tools application icon located in the program destination folder specified during installation. With a functional RS232 connection, TC Tools automatically sets up the communication parameters (these settings can be manually set up in the COM Port screen).

Subsequent to accepting the End-user License Agreement during program start up, the first screen Config appears. There are 4 screens available:

- Configuration (Config)
- Library
- Test Command
- COM Port


Refer to the following sections for applicable screen operations.

APPENDIX B - TROOPER COUNT SCALE TOOLS

B.3 SCREEN OPERATIONS

B.3.1 Configuration (Config)

The Configuration Screen allows the user to modify scale model data and setup parameters.



Configurable parameters are highlighted in blue text on-screen and are described as follows:

- **Model**
Fixed model selections are available: TC3RS, TC6RS, TC15RS, TC30RS. Selecting a model automatically loads the associated default scale Personality Setup and Menu Setup parameters.
- **Serial No.**
Up to a 6-digit serial number of the Trooper Count Scale is entered in this field.
- **Metric Unit Setting**
Selecting the Metric Unit Setting deactivates non-metric units from the screen and from the scale (non-metric units are not visible in the scale menus). To select, click on the "Only Metric" field (a check mark will appear in the box) then click on the "Change" button. To de-select, click on the "Only Metric" field to remove the check mark then click on the "Change" button.

APPENDIX B - TROOPER COUNT SCALE TOOLS


- **Print Headers**

User-defined Printer Headers can be entered in the fields: Line 1 and Line 2 (up to 15 characters each). After entering the Printer Headers, click on the [Update] button to save the text into the scale.

- **Do Calibration after Config**

Selecting this option (box is checked off) automatically initiates Linearity Calibration procedures when Configuration parameters are ready to be transferred to the scale ("Write Config Data to Scale" button is selected). Make sure appropriate calibration weights are available at this time.

After transferring data to the scale, select [OK] from the following acknowledgement screen. Follow subsequent calibration instructions accordingly.



Other Configuration Screen items are described as follows:

- **Personality Setup and Menu Setup**

These setup parameters designate scale model and menu mode settings, and are automatically updated based on the Model and Metric Unit Setting selected. Sub-menu items cannot be configured manually by the user.

- **[Read Config Data from Scale] Button**

Select this button to load and display the configuration data from the scale into the Trooper Count Scale Tools program.

- **[Write Config Data to Scale] Button**

Select this button to transfer the configuration data from the computer to the scale. The transfer is acknowledged on-screen as follows (if the "Do Calibration after Config" setting was not selected):



APPENDIX B - TROOPER COUNT SCALE TOOLS

B.3.2 Library

The Library Screen offers a method to quickly and conveniently read, enter, and save individual Library records.

ID #	Part #	APW	P-Tare	Under	Over	Count	Unit
0		0.000	<input type="checkbox"/> 0.000	0	0	<input type="checkbox"/> 0	Gram
1		0.000	<input type="checkbox"/> 0.000	0	0	<input type="checkbox"/> 0	Gram
2		0.000	<input type="checkbox"/> 0.000	0	0	<input type="checkbox"/> 0	Gram
3		0.000	<input type="checkbox"/> 0.000	0	0	<input type="checkbox"/> 0	Gram
4		0.000	<input type="checkbox"/> 0.000	0	0	<input type="checkbox"/> 0	Gram
5		0.000	<input type="checkbox"/> 0.000	0	0	<input type="checkbox"/> 0	Gram
6		0.000	<input type="checkbox"/> 0.000	0	0	<input type="checkbox"/> 0	Gram
7		0.000	<input type="checkbox"/> 0.000	0	0	<input type="checkbox"/> 0	Gram
8		0.000	<input type="checkbox"/> 0.000	0	0	<input type="checkbox"/> 0	Gram
9		0.000	<input type="checkbox"/> 0.000	0	0	<input type="checkbox"/> 0	Gram
10		0.000	<input type="checkbox"/> 0.000	0	0	<input type="checkbox"/> 0	Gram
11		0.000	<input type="checkbox"/> 0.000	0	0	<input type="checkbox"/> 0	Gram
12		0.000	<input type="checkbox"/> 0.000	0	0	<input type="checkbox"/> 0	Gram
13		0.000	<input type="checkbox"/> 0.000	0	0	<input type="checkbox"/> 0	Gram
14		0.000	<input type="checkbox"/> 0.000	0	0	<input type="checkbox"/> 0	Gram
15		0.000	<input type="checkbox"/> 0.000	0	0	<input type="checkbox"/> 0	Gram
16		0.000	<input type="checkbox"/> 0.000	0	0	<input type="checkbox"/> 0	Gram
17		0.000	<input type="checkbox"/> 0.000	0	0	<input type="checkbox"/> 0	Gram
18		0.000	<input type="checkbox"/> 0.000	0	0	<input type="checkbox"/> 0	Gram

The Library screen displays up to 60 part-files, each line representing a record that contains unique part-file information. Each part-file data are entered or changed manually (selected record to be modified will be highlighted in yellow) and are described as follows:

- **ID #**
A fixed record location in the scale where the information is stored.
- **Part #**
A user-designated identifying number assigned to an item.
- **APW (Average Piece Weight)**
The total weight of a given number of pieces of the item divided by the number of pieces.
- **P-Tare (Pre-set Tare)**
The weight of the empty container. When the P-Tare field box is checked off, Pre-set Tare will be active during scale operation.
- **Under, Over**
The under and over tolerance weight values. With a value entered, the checkweighing feature of the scale will be active during operation.
- **Count**
The accumulated piece count of the item. When the Count field box is checked off, Count Accumulation will be active during scale operation.

APPENDIX B - TROOPER COUNT SCALE TOOLS

- **Unit**

The selected unit of measurement. Select by scrolling through the available units: kg, lb, g or oz.

Note: Any changes to the record data will not be saved or take effect for scale operation until transferred into the scale or a file. Refer to the following section.



The Library screen features 5 function buttons to read and save all or individual Library records. Each button and its function is described as follows:

- **[Read Scale Library] Button**

Select this button to read (extract) the library data from the scale. Library data will be uploaded from the scale and displayed on-screen.


- **[Write Lib to Scale] Button**

Select this button to write (save) all Library data displayed on-screen into the scale. Thereafter, confirm the following acknowledgement screens to execute or cancel the process.



- **[Write Rec. to Scale] Button**

Select this button to write (save) data of a highlighted record into the scale. Thereafter, confirm the following acknowledgement screens to execute or cancel the process.




APPENDIX B - TROOPER COUNT SCALE TOOLS




- **[Read Library File] Button**

Select this button to read (extract) all Library data from a file created from the [Write to File] Button in the Trooper Count Scale Tools program (refer following section). Specify the source directory, folder and file name as prompted on the following "Open" screen. Then select [Open] to execute the process.



- **[Write to File] Button**


Select this button to write (save) all Library data displayed on-screen into a user-designated file. Specify the destination directory, folder and file name as prompted on the following "Save As" screen. Keep the "Save as Type" field blank. Then select [Save] to execute the process.



APPENDIX B - TROOPER COUNT SCALE TOOLS

B.3.3 Test Command

The Test Command Screen enables the user to send (type in) a test command from the computer keyboard and log the data output on-screen. Most commands mimic the button functions of the scale.



Initiate use of the Test Command screen by selecting the [Connect] button first to establish connection between the scale and the computer.

Note: A communication error message will appear if connection cannot be established (refer to Sections B.4: Troubleshooting and B.3.4: COM Port Screen for further details).


Type in a test command followed by the [Enter] key (**test commands are case-sensitive, use upper-case letters only**). The available Test Commands are listed and described as follows (for examples, refer to Test Command Screen):

- **P (Print)**
Displays the print data output of the scale on the "Response from scale" field.
- **Z (Zero)**
Zeroes the scale (similar to pressing the [ON/ZERO Off] button from the scale). A result of "OK" on-screen confirms the operation. The scale will also reflect that the operation was executed.
- **T (Tare)**
Tares the scale (similar to pressing the [TARE] button from the scale). A result of "OK" on-screen confirms the operation. The scale will also reflect that the operation was executed.
- **V (Get Version Number)**
Displays the model and software version of the Trooper Count Scale on the "Response from scale" field.

APPENDIX B - TROOPER COUNT SCALE TOOLS

B.3.4 COM PORT

The COM Port Screen allows the user to automatically set up RS232 connections, or manually specify scale print settings to establish proper communications.



Automatic Setup is the default setting. The following scale Print Menu settings can be specified when selecting Manual Setup (bolded selections are default settings):


- **Port**
Available selections are: **COM1**, COM2, COM3 or COM4.
- **Baud Rate**
Available selections are: 1200, **2400**, 4800, 9600 or 19200.
- **Data Bits**
Available selections are: **7** or 8.
- **Parity**
Available selections are: **None**, Even or Odd.

B.4. TROUBLESHOOTING

Several Error screens may appear due to conditions listed as follows:


- **Communication Error**

The following error message appears when a communication error between the scale and the computer is detected. Check and remedy the appropriate connections and/or settings to establish functional communications.




- **Library error: Read Library File**

The following error message appears (after selecting the [Read Library File] Button from the Library Screen) when attempting to read a file that was not created from the [Write to File] Button in the Trooper Count Tools program. Open a file created from the [Write to File] Button.



- **Library error: Part number entry**

The following error message appears after entering non-numeric entries in the "Part #" field in the Library Screen. Only numeric entries are allowed in this field.



APPENDIX B - TROOPER COUNT SCALE TOOLS



Ohaus Corporation
19A Chapin Road,
P.O. Box 2033
Pine Brook, NJ 07058, USA
Tel: (973) 377-9000,
Fax: (973) 593-0359
www.ohaus.com

With offices worldwide.
www.ohaus.com

