

Edition: January 15, 2007



Service Manual

Lexmark™ Forms Printer

4227-300

- ***Table of contents***
- ***Start diagnostics***
- ***Safety and notices***
- ***Trademarks***
- ***Index***

LEXMARK™

Lexmark and Lexmark with diamond design are trademarks of Lexmark International, Inc., registered in the United States and/or other countries.

Edition: January 15, 2007

The following paragraph does not apply to any country where such provisions are inconsistent with local law: LEXMARK INTERNATIONAL, INC. PROVIDES THIS PUBLICATION "AS IS" WITHOUT WARRANTY OF ANY KIND, EITHER EXPRESS OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. Some states do not allow disclaimer of express or implied warranties in certain transactions, therefore, this statement may not apply to you.

This publication could include technical inaccuracies or typographical errors. Changes are periodically made to the information herein; these changes will be incorporated in later editions. Improvements or changes in the products or the programs described may be made at any time.

Comments may be addressed to Lexmark International, Inc., Department D22/035-3, 740 New Circle Road N.W., Lexington, Kentucky 40550, U.S.A. Lexmark may use or distribute any of the information you supply in any way it believes appropriate without incurring any obligation to you.

Lexmark and Lexmark with diamond design are trademarks of Lexmark International, Inc., registered in the United States and/or other countries.

Color Jetprinter is a trademark of Lexmark International, Inc.

All other trademarks are the property of their respective owners.

© 1996, 2006 Lexmark International, Inc.

All rights reserved.

UNITED STATES GOVERNMENT RIGHTS

This software and any accompanying documentation provided under this agreement are commercial computer software and documentation developed exclusively at private expense.

Table of contents

Table of contents	ii
Safety information	1-vi
Prefacexi
Definitions	xi
.....	1-xi
General information	1-1
Description	1-1
Voltage, ground, and continuity readings	1-2
Voltage readings	1-2
Ground checks	1-2
Continuity readings	1-2
Maintenance approach	1-3
Options	1-3
Tools	1-3
Abbreviations	1-4
Using the operator panel	1-5
Using the function menus	1-6
Setting printer functions	1-7
Overview of function menus	1-8
Buttons	1-10
Lights	1-11
Diagnostic information	2-1
Start	2-1
Error indication table	2-1
Symptom tables	2-3
Abnormal Indications	2-4
Abnormal print operation problems	2-4
Auto Sheet Feeder problems	2-5
6XX Error indications	2-5
Paper feed problems	2-6
Operator panel problems	2-8
Power Problems	2-8
Print quality problems	2-9
Ribbon feed problems	2-10
Service checks	2-11
Auto Gap service check	2-11
Auto Sheet Feeder (ASF) service check	2-13
Auto Sheet Feeder principles of operation	2-13
Carrier drive service check	2-15
Intermittent problem service check	2-16
No print or abnormal print service check	2-19

Operator panel service check	2-20
Paper feed service check	2-21
POST service check	2-24
Power failure service check	2-25
Print quality service check	2-27
Print wire drive failure service check	2-28
Ribbon drive service check	2-30
Tractor 2 service check	2-31
Diagnostic aids	3-1
Power-On Self Test (POST)	3-1
Hex trace mode	3-2
Hex trace mode sample	3-2
Interface selection	3-3
Operation with the top cover removed	3-3
Service Menu	3-3
Button Test	3-4
Factory Setting	3-4
Printhead Bank	3-4
Jam/PSet Sensor Test	3-4
Impact force	3-4
Log clear	3-4
Print Test	3-5
Other print tests	3-5
Error log	3-5
Repair information	4-1
Handling ESD-sensitive parts	4-1
Adjustments	4-2
Printhead installation adjustment	4-2
Printhead-to-platen gap adjustment	4-2
Bidirectional print adjustment	4-3
Removals	4-5
Top cover removal	4-5
Auto Gap motor removal	4-8
Auto Sheet Feeder gears removal	4-9
Auto Sheet Feeder pick-up roller removal	4-10
Belt tension pulley plate assembly removal	4-11
Base assembly removal	4-11
Carrier removal	4-12
Carrier motor assembly removal	4-15
Carrier plate removal	4-16
Label jam removal	4-16
Lower feed roller removal	4-17
Lower pinch roller removal	4-21
Main logic board removal	4-21
Memory Module removal	4-22

Operator panel assembly removal	4-22
Paper Empty sensor/TOF sensor removal	4-22
Paper feed motor removal	4-25
Paper guide removal	4-25
Paper guide/platen assembly removal	4-25
Paper Select lever removal	4-25
Paper Select sensor removal	4-26
Paper separator removal	4-27
Power supply removal	4-29
Power supply fan removal	4-29
Print unit removal	4-29
Printhead removal	4-32
Printhead cables removal	4-33
Ribbon drive motor assembly removal	4-34
Right side frame removal	4-35
Sub logic board removal	4-37
Upper feed roller removal	4-38
Preventive maintenance	5-1
Lubrication	5-1
Specified lubricants	5-1
Lubrication points	5-2
Locations and connectors	6-1
4227-300	6-1
Main Logic Board Connectors	6-2
Operator panel connectors	6-3
Component locations	6-4
Component location illustrations	6-5
Component location illustrations (Continued)	6-6
Signal connections	6-7
Main Logic Board<-->Paper Empty & TOF Sensors	6-9
Main Logic Board<-->Carrier Motor Cable #1	6-9
Main Logic Board<-->Paper Feed Motor	6-9
Main Logic Board<-->Tractor 2 DIN	6-10
Main Logic Board<-->Carrier Motor Cooling Fan	6-10
Main Logic Board<-->5 V dc Power	6-10
Main Logic Board<-->Operator Panel	6-11
Main Logic Board<-->Tractor PSet & Jam Sensors	6-11
Main Logic Board<-->Ribbon Motor	6-12
Main Logic Board<-->Auto Gap Motor	6-12
Main Logic Board<-->Serial Board	6-12
Serial Board<-->Serial Cable	6-13
Sub Logic Board<-->Printhead	6-14
Operator Panel Board<-->Ribbon Cover Sensor	6-14
Tractor 2 cable connectors	6-15
Connector block diagram	6-16


Parts catalog7-1

- How to use this parts catalog7-1
- Assembly 1: Covers and operator panel7-2
- Assembly 2: Paper feed7-4
- Assembly 3: Carrier7-6
- Assembly 4: Base and electronics7-8
- Assembly 5: ASF side frame/covers7-10
- Assembly 6: ASF roller/support7-12
- Assembly 7: Tractor 2 option7-14


Index I-1

Part number index I-5

Safety information

- The safety of this product is based on testing and approvals of the original design and specific components. The manufacturer is not responsible for safety in the event of use of unauthorized replacement parts.
- The maintenance information for this product has been prepared for use by a professional service person and is not intended to be used by others.
- There may be an increased risk of electric shock and personal injury during disassembly and servicing of this product. Professional service personnel should understand this and take necessary precautions.
-  **CAUTION:** When you see this symbol, there is a danger from hazardous voltage in the area of the product where you are working. Unplug the product before you begin, or use caution if the product must receive power in order to perform the task.

Consignes de sécurité

- La sécurité de ce produit repose sur des tests et des agrégations portant sur sa conception d'origine et sur des composants particuliers. Le fabricant n'assume aucune responsabilité concernant la sécurité en cas d'utilisation de pièces de rechange non agréées.
- Les consignes d'entretien et de réparation de ce produit s'adressent uniquement à un personnel de maintenance qualifié.
- Le démontage et l'entretien de ce produit pouvant présenter certains risques électriques, le personnel d'entretien qualifié devra prendre toutes les précautions nécessaires.
-  **ATTENTION :** Ce symbole indique la présence d'une tension dangereuse dans la partie du produit sur laquelle vous travaillez. Débranchez le produit avant de commencer ou faites preuve de vigilance si l'exécution de la tâche exige que le produit reste sous tension.

Norme di sicurezza

- La sicurezza del prodotto si basa sui test e sull'approvazione del progetto originale e dei componenti specifici. Il produttore non è responsabile per la sicurezza in caso di sostituzione non autorizzata delle parti.
- Le informazioni riguardanti la manutenzione di questo prodotto sono indirizzate soltanto al personale di assistenza autorizzato.
- Durante lo smontaggio e la manutenzione di questo prodotto, il rischio di subire scosse elettriche e danni alla persona è più elevato. Il personale di assistenza autorizzato deve, quindi, adottare le precauzioni necessarie.



ATTENZIONE: Questo simbolo indica la presenza di tensione pericolosa nell'area del prodotto. Scollegare il prodotto prima di iniziare o usare cautela se il prodotto deve essere alimentato per eseguire l'intervento.


Sicherheitshinweise

- Die Sicherheit dieses Produkts basiert auf Tests und Zulassungen des ursprünglichen Modells und bestimmter Bauteile. Bei Verwendung nicht genehmigter Ersatzteile wird vom Hersteller keine Verantwortung oder Haftung für die Sicherheit übernommen.
- Die Wartungsinformationen für dieses Produkt sind ausschließlich für die Verwendung durch einen Wartungsfachmann bestimmt.
- Während des Auseinandernehmens und der Wartung des Geräts besteht ein zusätzliches Risiko eines elektrischen Schlags und körperlicher Verletzung. Das zuständige Fachpersonal sollte entsprechende Vorsichtsmaßnahmen treffen.




ACHTUNG: Dieses Symbol weist auf eine gefährliche elektrische Spannung hin, die in diesem Bereich des Produkts auftreten kann. Ziehen Sie vor den Arbeiten am Gerät den Netzstecker des Geräts, bzw. arbeiten Sie mit großer Vorsicht, wenn das Produkt für die Ausführung der Arbeiten an den Strom angeschlossen sein muß.


Pautas de Seguridad

- La seguridad de este producto se basa en pruebas y aprobaciones del diseño original y componentes específicos. El fabricante no es responsable de la seguridad en caso de uso de piezas de repuesto no autorizadas.
- La información sobre el mantenimiento de este producto está dirigida exclusivamente al personal cualificado de mantenimiento.
- Existe mayor riesgo de descarga eléctrica y de daños personales durante el desmontaje y la reparación de la máquina. El personal cualificado debe ser consciente de este peligro y tomar las precauciones necesarias.
-  **PRECAUCIÓN:** este símbolo indica que el voltaje de la parte del equipo con la que está trabajando es peligroso. Antes de empezar, desenchufe el equipo o tenga cuidado si, para trabajar con él, debe conectarlo.


Informações de Segurança

- A segurança deste produto baseia-se em testes e aprovações do modelo original e de componentes específicos. O fabricante não é responsável pela segurança, no caso de uso de peças de substituição não autorizadas.
- As informações de segurança relativas a este produto destinam-se a profissionais destes serviços e não devem ser utilizadas por outras pessoas.
- Risco de choques eléctricos e ferimentos graves durante a desmontagem e manutenção deste produto. Os profissionais destes serviços devem estar avisados deste facto e tomar os cuidados necessários.
-  **CUIDADO:** Quando vir este símbolo, existe a possível presença de uma potencial tensão perigosa na zona do produto em que está a trabalhar. Antes de começar, desligue o produto da tomada eléctrica ou seja cuidadoso caso o produto tenha de estar ligado à corrente eléctrica para realizar a tarefa necessária.


Informació de Seguretat

- La seguretat d'aquest producte es basa en l'avaluació i aprovació del disseny original i els components específics.
El fabricant no es fa responsable de les qüestions de seguretat si s'utilitzen peces de recanvi no autoritzades.
- La informació pel manteniment d'aquest producte està orientada exclusivament a professionals i no està destinada a ningú que no ho sigui.
- El risc de xoc elèctric i de danys personals pot augmentar durant el procés de desmuntatge i de servei d'aquest producte. El personal professional ha d'estar-ne assabentat i prendre les mesures convenients.
-  **PRECAUCIÓ:** aquest símbol indica que el voltatge de la part de l'equip amb la qual esteu treballant és perillós. Abans de començar, desendolleu l'equip o extremeu les precaucions si, per treballar amb l'equip, l'heu de connectar.

안전 사항

- 본 제품은 원래 설계 및 특정 구성품에 대한 테스트 결과로 안정성이 입증된 것입니다. 따라서 무허가 교체부품을 사용하는 경우에는 제조업체에서 안전에 대한 책임을 지지 않습니다.
- 본 제품에 관한 유지 보수 설명서는 전문 서비스 기술자 용으로 작성된 것이므로, 비전문가는 사용할 수 없습니다.
- 본 제품을 해체하거나 정비할 경우, 전기적인 충격을 받거나 상처를 입을 위험이 커집니다. 전문 서비스 기술자는 이 사실을 숙지하고, 필요한 예방 조치를 취하도록 하십시오.
-  **주의:** 이 표시는 해당영역에서 고압전류가 흐른다는 위험 표시입니다. 시작전에 플러그를 뽑으시거나, 주의를 기울여 주시기 바랍니다.

安全信息

- 本产品的安全性以原来设计和特定产品的测试结果和认证为基础。万一使用未经许可的替换部件，制造商不对安全性负责。
- 本产品的维护信息仅供专业服务人员使用，并不打算让其他人使用。
- 本产品在拆卸、维修时，遭受电击或人员受伤的危险性会增高，专业服务人员对这点必须有所了解，并采取必要的预防措施。
-  **切记：**当您看到此符号时，说明在您工作的产品区域有危险电压的存在。请在开始操作前拔掉产品的电源线，或者在产品必须使用电源来执行任务时，小心从事。

Preface

This manual contains maintenance procedures for service personnel. It is divided into the following chapters:

1. **General information** contains a general description of the MFP and the maintenance approach used to repair it. Special tools and test equipment are listed, as well as general environmental and safety instructions.
2. **Diagnostic information** contains an error indicator table, symptom tables, and service checks used to isolate failing field replaceable units (FRUs).
3. **Diagnostic aids** contains tests and checks used to locate or repeat symptoms of MFP problems.
4. **Repair information** provides instructions for making MFP adjustments and removing and installing FRUs.
5. **Connector locations** uses illustrations to identify the connector locations and test points on the printer.
6. **Preventive maintenance** contains the lubrication specifications and recommendations to prevent problems.
7. **Parts catalog** contains illustrations and part numbers for individual FRUs.

Definitions

Note: A note provides additional information.

Warning: A warning identifies something that might damage the product hardware or software.

CAUTION: A caution identifies something that might cause a service harm.



CAUTION: When you see this symbol, there is a danger from hazardous voltage in the area of the product where you are working. Unplug the product before you begin, or use caution if the product must receive power in order to perform the task.

1. General information

Description

The Lexmark™ Form Printer 4227-300 is a dot matrix, electro-mechanical printer that forms characters on a print media using a printhead and fabric ribbon. The printhead is composed of 18 miniature solenoids containing print wires and operates on electromagnetic principles. When a solenoid is energized, the small print wire pin is “fired” toward the ribbon to make a dot on the paper. The printer receives commands in the form of an electronic data stream from the PC through the parallel or serial port connector. The printer logic receives and translates the electronic data stream into carrier returns, line spacing, characters, or graphics as instructed.

This is a versatile printer that combines excellent print quality along with the ability to print several print styles and graphics. Some of the features and functions included with this printer are:

Feature	Function
Multi-speed Printing	FastDraft -720 cps Draft - 600 cps Courier and Gothic (NLQ) - 150 cps
Resident Fonts	FastDraft, Draft, Courier, and Gothic
Forms Handling	Forms (straight paper path) Automatic tear-off Automatic paper loading/unloading
Cut Sheets	Manual Optional Auto Sheet Feeder
Multiple Part Forms	6-part Forms (carbon and carbonless) (4227-300 - up to 8-part Forms)
Interface Connection	Parallel, Serial RS-422, Serial RS-232
Auto Gap	When Auto Gap is set to On, the printer automatically adjusts to the thickness of paper you are using.

Voltage, ground, and continuity readings

Voltage readings

All DC voltages must be within +5% through -10% of the values to be considered correct. Unless stated otherwise, all connectors should be connected normally when a voltage measurement is done.

When a “line voltage” measurement is to be done, the voltage on United States and Canada machines should be between 100 V ac and 127 V ac. On World Trade machines, the voltage is according to each country's specification.

Ground checks



To check for a correct ground, measure the voltage between the ground and a known good voltage source. The voltage measurement must be the same as the source voltage to consider the ground is correct.

Continuity measurements may be used to check grounds; however, be sure to measure to a known good ground using the lowest ohms scale and check for zero ohms.

WARNING: Always unplug the power cord before doing any continuity measurement.

Continuity readings

When measuring continuity, be sure no back circuits affect the measurement. If necessary, unplug connectors to remove any back circuits. Zero the ohm range on the lowest scale (X1). An open circuit will read infinity. A circuit with correct continuity will read zero ohms.

Maintenance approach

The diagnostic information in this manual leads you to the correct field replaceable unit (FRU) or part. Use the error indication table, symptom/check table, service checks and diagnostic aids to determine the symptom and repair the failure. Begin with “**Power-On Self Test (POST)**” on page 3-1.

Options

The following options may be installed:

- Automatic Sheet Feeder (ASF)
- Tractor 2
- Extended Cut-sheet Paper Guides
- 32kb Memory Module
- Extended National Language Support modules (Non-U.S. only)

Tools

The basic tools needed are:

- Basic CE tool kit
- #1 magnetic Phillips screwdriver
- #2 magnetic Phillips screwdriver
- Feeler gauges 0.35 mm (0.014 in.) 0.4 mm (0.016 in.)
- Analog or digital volt-ohmmeter

Abbreviations

ASF	Automatic Sheet Feeder
ASIC	Application-Specific Integrated Circuit
CSU	Customer Setup
DRAM	Dynamic Random Access Memory
EPROM	Erasable Programmable Read-Only Memory
ESD	Electrostatic Discharge
FRU	Field Replaceable Unit
HVPS	High Voltage Power Supply
LAN	Local Area Network
LCD	Liquid Crystal Display
LED	Light-Emitting Diode
LVPS	Low Voltage Power Supply
NVRAM	Nonvolatile Random Access Memory
OEM	Original Equipment Manufacturer
POR	Power-On Reset
POST	Power-On Self Test
PQET	Print Quality Enhancement Technology
ROS	Read-Only Storage
SRAM	Static Random Access Memory
UPR	Used Parts Replacement
V ac	Volts alternating current
V dc	Volts direct current

Using the operator panel


This section provides a brief description of the operator panel buttons, lights, and settings. Refer to the User's Guide for additional information.

Note: Application software may allow the user to operate the printer from a computer. Changes made to the printer settings from a software application override settings made from the operator panel, with the exception of the Font and Pitch Lock features.

Changeable printer functions include:

- Set Top of Form
- Tractor selection
- Character options
- Paper handling options
- Interface options
- Emulation options
- Macro definition and selection
- Print tests
- Auto Gap functions

Using the function menus



Use the **Item** ↓ and **Item** ↑ buttons to move through the menu and option directories. Press **Next** → to move away from the Main Menu to the subordinate directories and choices. Press **Prev.** ← if you want to go back in a menu or return to the Main Menu.

Setting printer functions

1. Press **Start/Stop**.
2. Press **Menu** to enter the function menu.
3. Press **Item** ↓ or **Item** ↑ until the function menu you want appears on the display.

Note: The selectable function menu is different depending on the selected data stream mode (IBM PPDS or Epson emulation) and the Interface mode (Parallel, RS-232 or RS-422).

4. Press **Next** → to enter that menu item.
5. Press **Item** ↓ or **Item** ↑ until the value you want appears on the display.
6. Press **Store** to save the selected value.

Note: The currently selected default value is displayed with an asterisk (*).

If you want to change the optional value in another function menu, repeat steps 3 through 5. Otherwise, go to the next step.


7. To print the function setting, press **Item** ↓ or **Item** ↑ until the **Print Settings** message appears on the display.
8. Press **Start/Stop** to print the current setting values.
9. Press **Quit** to exit the function menus.


Note: If you have changed any settings, the printer performs a Power-On Self Test. For more information, see **“Power-On Self Test (POST)” on page 3-1**. If you did not change any settings, the printer enters the not-ready state.

Overview of function menus

Use the **Item** ↑ and **Item** ↓ buttons to move through the menu and option directories. Press **Next** → to move away from the Main Menu to the subordinate directories and choices. Press **Prev.** ← if you want to go back in a menu or return to the Main Menu.

Menu items marked with an asterisk (*) may not appear on the operator panel, depending on the printer settings or what printer options are installed.





Buttons

When using the function menus, press **Item** ↓ or **Item** ↑ to scroll through the menu items. Press **Next** → or **Prev.** ← to move to the next, or previous menu level.

Press	To
Menu	Enter the function menu. The printer goes offline.
Quit	<ul style="list-style-type: none"> • Exit the function menus. • Run a Power-On Self Test (POST).
Tear Off	<ul style="list-style-type: none"> • Advance the forms to the tear-off position. • Retract the forms to the Top-of-Form (TOF) position when the forms are at the tear-off position.
Store	Save the values selected in the menus.
Font	Select a font.
Item ↓	Scroll down.
Pitch	Select a pitch.
Item ↑	Scroll up.
Micro ↓	Advance the forms down 0.35 mm (1/72 in.).
Next →	Scroll forward.
Micro ↑	Advance the forms up 0.35 mm (1/72 in.).
Prev. ←	Return to the previous function menu.
Start/Stop	<ul style="list-style-type: none"> • To return to Ready and to Start/Stop. • Load the forms to TOF position with the ready light on.
Load/Unload	<ul style="list-style-type: none"> • Load paper (cut or continuous forms) to the TOF position. • Retract the forms to the tractor position.
LineFeed	Advance the paper to the next line.
FormFeed	<ul style="list-style-type: none"> • Advance the paper to the TOF position on the next page. • Load the forms to the TOF position.

Lights

Light	Description
Power (Green)	The printer power is on.
Ready (Green)	<p>The printer is online and ready to print. The following conditions cause the Ready light to turn off:</p> <ul style="list-style-type: none"> • Pressing Start/Stop • An end-of-form (EOF) • A paper jam • A cover open • A hardware error • A Power-On Self Test failure • The printer is offline.
Check (Yellow)	<p>Any of the following conditions may have occurred:</p> <ul style="list-style-type: none"> • An end-of-form (EOF) • A paper jam • A cover open • A hardware error • A data transmission error • An interface mode error • A Power-On Self Test (POST) failure
Auto Gap (Green)	Auto Gap is on. Auto Gap automatically adjusts the printer according to the thickness of the paper you are using.
Tractor 2 (Green)	The Tractor 2 Feeder is selected. (The Tractor 2 Feeder option must be installed.)

4227-300

2. Diagnostic information

Start

Make a quick visual check for defects (loose or broken parts, unplugged connectors, or paper jams).

If there is no power after turning the printer on, go to the **“Power failure service check” on page 2-25.**

If an error indicator appears, go to the **“Error indication table” on page 2-1** and take the indicated action.

Run the **“Print Test” on page 3-5** and refer to the **“Error log” on page 3-5** for details of error indication information. If no error indication appears, refer to **“Symptom tables” on page 2-3.**

Error indication table

The following table describes the service check entries for the printer error indication codes.

When an error indication changes after you have entered a service check, you have an intermittent problem. If this occurs, leave the service check and go to **“Symptom tables” on page 2-3.**

Display Indication	Description/Action
631 Machine Check Display RAM Error	Display RAM Read/Write Error. This error is detected only during POST. Replace the operator panel.
632 Machine Check System RAM Error	System RAM Read/Write Error. Replace the main logic board and perform the “Bidirectional print adjustment” on page 4-3. Check the “Printhead-to-platen gap adjustment” on page 4-2.

Display Indication	Description/Action
633 Machine Check Timer Interrupt Error	Timer Interrupt Controller Error. Replace the main logic board and perform the “Bidirectional print adjustment” on page 4-3. Check the “Printhead-to-platen gap adjustment” on page 4-2.
636 Machine Check NOVRAM Error	Non-Volatile Memory Read/Write Error. Replace the main logic board and perform the “Bidirectional print adjustment” on page 4-3. Check the “Printhead-to-platen gap adjustment” on page 4-2.
637 Machine Check CA Drive Error	Home Timeout Error. Go to the “Carrier drive service check” on page 2-15.
638 Machine Check CA Drive Error	Carrier Drive Error. No emitter pulse detected. Go to the “Carrier drive service check” on page 2-15.
639 Machine Check CA Drive Error	Carrier Drive Error. Carrier positioning error. Go to the “Carrier drive service check” on page 2-15.
63B Machine Check Key Scan Error	Button Scanning Error. Go to the “Operator panel service check” on page 2-20.
63C Machine Check Auto Gap Error	Auto Gap Error. Go to the “Auto Gap service check” on page 2-11.
63D Machine Check Tractor 2 HP Error	Tractor 2 Home Position Error. Go to the “Tractor 2 service check” on page 2-31.
63E Machine Check Head Thermal Error	Head Thermal Sensor Error. Go to the “Print wire drive failure service check” on page 2-28.
63F Machine Check Option RAM Error	Option RAM Read/Write Error. Replace the 32Kb Memory Module.
640 Machine Check CA Thermal Error	Carrier Thermal Sensor Error. Go to the “Carrier drive service check” on page 2-15.

Symptom tables

1. Select the symptom that best describes the problem.
2. Perform the appropriate action before you go to the indicated service check.

Abnormal Indications

Symptom	Action
All LEDs turn on but do not turn off.	Disconnect the interface cable from the printer and turn the printer off and then back on. If POST now runs correctly, the problem is in the computer or interface cable.
The Power LED is on, but POST will not run.	Go to the “POST service check” on page 2-24.

Abnormal print operation problems

Symptom	Action
Printer will not print, or become Ready. Abnormal operation, incorrect characters, or incorrect line width Printer is ready but will not print from the computer correctly. Undefined or incorrect characters	Be sure the interface cable is connected properly. Go to the “No print or abnormal print service check” on page 2-19.

Auto Sheet Feeder problems

Symptom	Action
Auto Sheet Feeder will not feed paper.	Be sure Auto Sheet Feed is set to On in the Paper Handling Option Menu.
Auto Sheet Feeder double feeds.	Be sure the paper select lever is in the cut sheet position.
Auto Sheet Feeder has intermittent feed problems.	Go to the “Auto Gap service check” on page 2-11.
Paper skews.	Isolate the problem by removing the Auto Sheet Feeder and then feed paper using the manual feed tray. Go to the “Auto Sheet Feeder (ASF) service check” on page 2-13.

6XX Error indications

Symptom	Action
6XX Machine Check is displayed.	Turn the printer off and then on. Go to “Error indication table” on page 2-1.

Paper feed problems

Symptom	Action
<p>Paper Empty Add Paper is displayed with paper in the printer.</p> <p>Print operation starts without paper.</p>	<p>Be sure the Paper Empty Sensor is not blocked.</p> <p>There may be a problem with the Paper Select Sensor. Go to the “Paper feed service check” on page 2-21.</p>
<p>Load/Unload does not function.</p> <p>Form feed length is not correct.</p> <p>Load/Unload functions with cut sheets in use.</p>	<p>Be sure the Paper Select lever is in the correct position.</p> <p>There may be a problem with the Paper Select Sensor. Go to the “Paper feed service check” on page 2-21.</p>
<p>Paper feeds, but Auto Loading does not work.</p>	<p>Be sure the Paper Select lever is in the cut sheet position.</p> <p>Be sure Auto Cut Sheet is enabled in the Paper Handling Option Menu.</p> <p>Go to the “Paper feed service check” on page 2-21.</p>


4227-300

Symptom	Action
<p>Lower feed roll shaft rotates, but paper does not feed.</p> <p>Pressing Form Feed does not feed paper.</p> <p>Abnormal noise while feeding</p> <p>Paper jams, skews, or creases.</p> <p>Incorrect or no line spacing: wider, narrower, or overlapping lines.</p> <p>Incorrect Top of Form positioning</p>	<p>Be sure the Paper Select lever is in the correct position.</p> <p>Go to the “Paper feed service check” on page 2-21.</p>

Operator panel problems

Symptom	Action
<p>Start/Stop does not function but no error is indicated.</p> <p>Only the Power light comes on.</p> <p>One or more buttons do not function.</p> <p>One or more lights do not function.</p> <p>Blank display</p> <p>Cover open displayed.</p>	<p>Turn the printer off and then back on.</p> <p>Go to the “Operator panel service check” on page 2-20.</p>

Power Problems

Symptom	Action
<p>When the power switch is on, the Power light does not come on or the printer does not start.</p> <p>The Power light blinks or changes intensity.</p>	<div style="display: flex; align-items: center;">  <div> <p>Check the continuity of the power cord and the voltage of the electrical outlet.</p> <p>Go to the “Power failure service check” on page 2-25.</p> </div> </div>

Print quality problems

Symptom	Action
No print, but carrier moves as if printing.	<p>Be sure the printhead cables are not loose or damaged.</p> <p>Be sure the interface cable is connected properly.</p> <p>Check the ribbon cartridge for binds or damage.</p> <p>Go to the “Print wire drive failure service check” on page 2-28.</p>
Print density is light.	<p>If the ribbon has reached its end of life or is worn, the ribbon cartridge needs to be replaced.</p> <p>Go to the “Auto Gap service check” on page 2-11. If no problem is found, go to the “Ribbon drive service check” on page 2-30.</p>
<p>Uneven print density across the print line</p> <p>Specific dots missing.</p>	<p>Be sure the printhead cables are connected correctly to the printhead and the sub logic board.</p> <p>Clean the printhead.</p> <p>Set the Auto Gap to On in the user menus and run the print test. If the print is light at one edge and uniformly gets darker across the page to the other edge, perform the “Printhead-to-platen gap adjustment” on page 4-2.</p> <p>Go to the “Print wire drive failure service check” on page 2-28.</p>
<p>Scattered ink, smearing, blurred characters</p> <p>Fuzzy print</p>	<p>Clean the printhead nose.</p> <p>Clean the ribbon guide and shield.</p> <p>If the ribbon has reached its end of life or is worn, the ribbon cartridge needs to be replaced.</p> <p>Go to the “Print quality service check” on page 2-27.</p>

Symptom	Action
<p>Wavy vertical lines, uneven left margin, or character width is reduced.</p>	<p>Clean and lubricate the carrier shaft.</p> <p>If the carrier drive belt is worn or broken, replace the carrier unit. Perform the “Bidirectional print adjustment” on page 4-3.</p> <p>Go to the “Carrier drive service check” on page 2-15.</p>

Ribbon feed problems

Symptom	Action
<p>Ribbon comes off, becomes loose or folded, or jams.</p> <p>Ribbon feeds correctly but is noisy.</p>	<p>Check the ribbon cartridge for binds or damage.</p> <p>Go to the “Ribbon drive service check” on page 2-30.</p>

Service checks

Auto Gap service check

Theory of operation

The Auto Gap motor and Gap Home sensor automatically set the printhead gap for the thickness of paper being used by rotating the eccentric carrier shaft. The printer detects maximum gap with the Gap Home sensor, and minimum gap by driving the printhead against the platen. In addition to compensating for the thickness of the paper itself, the printer must increase the air gap for thicker papers.

With Auto Gap On, the following occurs:

- POST
- Auto Gap resets.
- The printer unloads paper, if it is loaded, to prepare to measure the travel span.
- The Auto Gap motor drives the printhead against the platen to measure the total travel span.
- Auto Gap resets again, to make room for paper to be loaded.
- The paper feeds to the print line.
- The Auto Gap motor drives the printhead against the paper to measure the total travel span minus the paper thickness.
- Auto Gap resets again.
- The printhead moves to the appropriate gap position for the installed paper.
- The **Ready** LED comes on, the carrier centers, and the paper moves to the tearoff position.

Auto Gap can be set to off to reduce time-to-print if the printer is always used with a single type of paper. With Auto Gap off, the gap can be set to Manual Position 1 (thinnest paper) to 7 (thickest paper). With Auto Gap off, Single Auto Gap has two selections:

- Fixed—The printhead gap is never changed.
- Open—The gap is opened when loading forms.

Note: If there is a 63C Auto Gap Error, the Gap Home sensor did not detect that the carrier shaft homed, or it detected that the carrier shaft homed at the wrong time.

	FRU	Action
1	Auto Gap Sensor	Inspect the Gap Home flag on the end of the carrier shaft and make sure it blocks the sensor when the gap is at its largest. Turn the printer on and watch the carrier shaft and the Gap Home flag. If the shaft rotates before the error occurs, the sensor may have failed. Perform the Sensor 2 Test in the Service Menu and test the Gap Home sensor.
2	Auto Gap Motor Gear Train	<p>If the carrier shaft does not rotate, look for an Auto Gap motor or Auto Gap gear train problem. Disconnect CN20 from the main logic board.</p> <p>Check the resistance of pins: 1 and 5, 2 and 6, 3 and 5, and 4 and 6.</p> <p>All resistances should be 180 ± 5 ohms. No pin should have continuity to ground.</p> <p>If there is no 63C Auto Gap Error but there is a gap problem (light print or no print, or paper catching on the printhead or ribbon shield), enter the user menus to make sure the gap settings are appropriate for the paper being used. If Auto Gap is off, Manual Position 1 should be used only with single-part 16 lb. or 20 lb. forms. Refer the customer to the <i>User's Guide</i> for the appropriate Manual Position settings.</p>

Auto Sheet Feeder (ASF) service check

Auto Sheet Feeder principles of operation

The Auto Sheet Feeder (ASF) feeds into the cut sheet paper entry throat. To use the ASF:

- The Paper Select lever must be set to Cut Sheet.
- **Auto Sheet Feeder** must be selected in the display menu.

Continuous forms can be used with the ASF installed by moving the paper select lever to Continuous Forms and pressing **Start** to feed the continuous forms to the first print line.

The ASF contains no electrical parts. It is driven from the gear on the inside of the printer's right side frame.

The combination lock mechanism is a clutch that causes the ASF pick rollers to feed only one sheet of paper at a time. When **Auto Sheet Feeder** is selected on the Paper Handling Options Menu, the cut sheet paper drive reverses itself for a short distance during paper loading. This engages the clutch and engages the paper pick rollers, which feed the top sheet from the cut sheet paper stack. The sheet is fed about 5 inches (125 mm) and the paper path briefly reverses again; this disengages the clutch and the pick rollers. The sheet is then fed to the print line by the ASF's upper and lower feed rollers and the printer's lower feed rollers. Although the ASF pick rollers continue to turn as the paper is fed, their drive is disengaged and they are actually being turned by the paper.

	FRU	Action
1	Paper Select Sensor	<p>With the Paper Select lever in the Cut Sheet position, do the following:</p> <ul style="list-style-type: none"> • Try to load a sheet with Load/Unload. (This button should not work.) • If the paper loads, go to the "POST service check" on page 2-24.


	FRU	Action
2	Paper Feed	<p>If the paper does not feed, do the following:</p> <ul style="list-style-type: none"> • Remove the ASF. • Be sure the base printer feeds paper correctly. • If it does not feed paper correctly, go to the “Paper feed service check” on page 2-21.
3	Gear Train	<p>Be sure the ASF drive gear on the inside of the printer's right frame rotates.</p> <p>Inspect the right side gear train for damage or debris.</p> <p>Remove the ASF right cover and ensure that all gears are in good condition.</p>
4	Combination Lock Mechanism	<p>Install the ASF and press FormFeed.</p> <p>If the pick drive shaft does not rotate, replace the combination lock mechanism.</p>
5	Left and Right Hoppers	<p>If the ASF pick rollers rotate but a single sheet is not picked, inspect the springs and corner separators on the left and right hoppers.</p> <p>Make sure the paper load lever is in the correct position.</p>
6	Pick Rollers Paper Guides Feed Rollers	<p>Paper skew can be caused by worn, dirty, or binding pick and feed rollers. Remove the Auto Sheet Feeder, load paper, and hand cycle the feeder while observing the pick and feed rollers. If the skew problem is in the base machine, examine all feed rollers for wear.</p>


Carrier drive service check


Note: When a 637, 638, or 639 error is detected while printing, verify that the same error is detected after removing jammed paper and checking that the ribbon guide is in place.

	FRU	Action
1	637, 638, 639 CA Drive Error	<p>Carrier positioning error.</p> <p>Inspect the following:</p> <ul style="list-style-type: none"> • Tension pulley plate • Carrier • Carrier belt <p>Loosen and tighten the tension pulley plate screws to make sure the carrier belt is tight.</p> <p>Disconnect CN9 and move the carrier manually from left to right and check for smooth movement.</p> <p>With CN9 disconnected, check for 5 to 8 ohms between pins 1 and 2 on the motor cable. If the reading is incorrect, replace the motor.</p> <p>Check for motor pins shorted to the housing. If you find a pin shorted to the housing, replace the motor.</p> <p>If no problems are found, replace the carrier motor.</p>
2	640 CA Thermal Error	<p>The printer has stopped to protect the carrier motor from overheating. Normally this will not occur until after several hours of continuous heavy use in a warm environment, and only then after going through several stages of thermal slowdown.</p> <p>Wait for the machine to cool and see if the error goes away.</p> <p>If the machine was not being used heavily before the error occurred, or if the error returns when the machine is cool, replace the carrier motor.</p>

Intermittent problem service check

	FRU/Symptom	Action 
1	The machine sometimes fails before POST is complete.	<p>Check for the following:</p> <ol style="list-style-type: none"> 1. Loose connectors. Reconnect all connectors to the main and sub logic boards. 2. Electrical noise or static discharge. Check the following items: <ul style="list-style-type: none"> • Power supply ground • Machine frame ground • Printer interface cable is grounded and shielded. 3. Intermittently low voltages. Check for ac and all dc voltages and short-circuits on the main and sub logic boards. <ol style="list-style-type: none"> a. Check the electrical voltage and ensure that it is within tolerance. b. Check the continuity of the power cord. c. Disconnect the power supply cable from the connectors CN11 on the main logic board and CN1 on the sub logic board. Turn the printer power on and check all dc output voltages at CN11 and CN1. <p>Ensure the output voltages are:</p> <p>CN11-1 (+40 ±4 V dc) & CN11-3 (GND) CN11-2 (+40 ±4 V dc) & CN11-3 (GND) CN11-5 (+5 ±0.5 V dc) & CN11-6 (Signal GND) CN 1-1 (+40 ±4 V dc) & CN1-3 (GND) CN 1-2 (+40 ±4 V dc) & CN1-3 (GND) CN 1-5 (+5 ±0.5 V dc) & CN1-6 (Signal GND)</p> <p>If the voltages are not correct, replace the power supply unit. If the failure remains, replace the main logic board and sub logic board. Note: When replacing the main logic board, always perform the “Bidirectional print adjustment” on page 4-3 and the “Printhead-to-platen gap adjustment” on page 4-2.</p>

	FRU/Symptom	Action 
2	Machine power sometimes turns off.	<p>The cause of this problem may be that the power circuit is failing, or the wiring is intermittently open. Check the following in sequence:</p> <ol style="list-style-type: none"> 1. Check the electrical voltage and be sure it is within tolerance. 2. Check the continuity of the power cord. 3. Disconnect the power supply cable from the connectors CN11 on the main logic board and CN1 on the sub logic board. Turn the printer power on and check all dc output voltages at CN11 and CN1. <p>Be sure the output voltages are as follows:</p> <p>CN11-1 (+40 ±4 V dc) & CN11-3 (GND) CN11-2 (+40 ±4 V dc) & CN11-3 (GND) CN11-5 (+5 ±0.5 V dc) & CN11-6 (Signal GND) CN 1-1 (+40 ±4 V dc) & CN1-3 (GND) CN 1-2 (+40 ±4 V dc) & CN1-3 (GND) CN 1-5 (+5 ±0.5 V dc) & CN1-6 (Signal GND)</p> <p>If one of the voltages is 0, go to the “Power failure service check” on page 2-25. If the voltages are not 0 but are incorrect, replace the power supply unit.</p>
3	Intermittently poor print quality.	<p>Do the following:</p> <ul style="list-style-type: none"> • Remove paper jams from the paper path. • Clean all feed roller surfaces. • Clean the ribbon shield and printhead. • Clean the platen surface. • Install the ribbon cartridge correctly. • If the ribbon end of life has been reached, have the customer replace the ribbon cartridge.

	FRU/Symptom	Action 
4	The previous suggestions have not corrected the problem	<p>The service check has not defined the failure, or the machine is having intermittent failures. The following may cause undefined or intermittent failures:</p> <ol style="list-style-type: none"> 1. Customer's electrical voltage. Be sure that it is within the tolerance. 2. Loose connector pins or keys that fail to contact. Check the following: <ol style="list-style-type: none"> a. Reconnect the connectors of all FRUs and printer interface cables. b. Check the continuity of the line cord. 3. Electrical noise. Check the following: <ol style="list-style-type: none"> a. Power supply ground b. Machine frame ground c. Printer interface cable is grounded or shielded. 4. Undefined data in customer applications. Check the baud rate at the controller. Check that the printer interface cable matches the printer.
5	Problem occurs only in specific customer applications.	<p>Perform the Trace Print (hexadecimal printing) by the following procedure and check the data streams.</p> <ol style="list-style-type: none"> 1. Press Menu. 2. Press Item ↑ to display Trace Mode. 3. Press Start. 4. Have the customer print the failing job. 5. To stop printing, turn the power switch off. <p>If the failure still occurs, perform the “Bidirectional print adjustment” on page 4-3 and the “Printhead-to-platen gap adjustment” on page 4-2.</p>

No print or abnormal print service check

	FRU/Function	Action
1	Carrier	If the carrier moves, but nothing is printed, go to the “Print wire drive failure service check” on page 2-28.
2	Configuration	<p>Enter the user menus and be sure the correct emulation (IBM/EPSON) and interface (parallel/serial) are selected.</p> <p>If the printer is serially attached, be sure the RS232/RS422 switch is in the correct position, and the host communications parameters are correct.</p>
3	Main Logic Board	<p>If the Print Test does not print, or prints incorrectly, do the following:</p> <ul style="list-style-type: none"> • Replace the main logic board. • Perform the “Bidirectional print adjustment” on page 4-3 and the “Printhead-to-platen gap adjustment” on page 4-2.

Operator panel service check

Note: Press any button except **Start/Stop**, **Load/Unload**, or **FormFeed**. If **Operator Panel Disabled** is displayed, unlock the operator panel by powering up with the **Micro**↑ and **Micro**↓ keys pressed. Use the same procedure to re-lock the panel after service is complete.

	FRU	Action
1	Operator Panel	<p>If there is a 631 Display RAM Error, replace the operator panel.</p> <p>If there is a 63B Key Scan Error, one or more buttons are being detected as pressed during power-up.</p> <p>Replace the operator panel.</p>
2	Printer Cable Operator Panel	<p>During power-up, all LEDs and all LCD pels should turn on briefly.</p> <p>Enter the Service Menu and perform the Button Test. If there are missing or extra pels displayed, or if any of these tests fail, check the condition and continuity of the operator panel cable.</p> <p>Replace the cable or the operator panel.</p>
3	Cover Switch	<p>If Cover Open is displayed, check the cover switch.</p> <p>Jumper the cover switch connector on the operator panel. If Cover Open is displayed, check the condition and continuity of the operator panel cable. Replace the cable or the operator panel.</p>
4	Main Logic Board	<p>If the symptom has not changed, replace the main logic board.</p>

Paper feed service check

Note: If the problem is frequent jams or paper creases, verify that the paper is neither very thick nor very thin. If necessary refer the customer to the *User's Guide* for specifications of acceptable papers.

	FRU/Symptom	Action
1	Auto Sheet Feeder	<p>If the Auto Sheet Feeder is installed, remove it. Enter the Paper Handling Options Menu and set ASF to off. Verify that the machine works correctly without the ASF installed.</p> <p>If the printer fails only with the Auto Sheet Feeder installed, go to the "Auto Sheet Feeder (ASF) service check" on page 2-13.</p>
2	Tractor 2	<p>If the Tractor 2 option is installed, remove it.</p> <p>Verify that the machine works correctly without Tractor 2 installed.</p> <p>If the printer fails only with Tractor 2 installed, go to the "Tractor 2 service check" on page 2-31.</p>
3	Paper Feed Motor	<p>If there is no paper motion, disconnect the paper feed motor connector CN10 from the main logic board.</p> <p>Check the resistance of pins: CN-1 and 6, 2 and 5, 3 and 6, and 4 and 5.</p> <p>All resistances should be 5.8 ± 0.5 ohms. No pin should have continuity to ground.</p>

	FRU/Symptom	Action
4	Gear Train and Paper Feed Motor	<p>Remove all paper from the machine.</p> <p>Press FormFeed several times and examine all rotating parts to find the problem.</p> <p>For better visibility, remove the covers and reconnect the operator panel to the main logic board.</p> <p>The upper and lower feed rollers and the upper and lower pinch rollers should all be clean and in good condition, and should all rotate during Form Feed.</p> <p>To turn the gear train manually, turn the right end of the lower feed roller shaft with a 6 mm wrench.</p>

	FRU/Symptom	Action
5	PE Sensor TOF Sensor PSet Sensor Jam Sensor	<p>The printer has four sensors in the paper path, plus one which detects the position of the Paper Select lever. Enter the Service Menu and perform the sensor tests.</p> <ul style="list-style-type: none"> • PE Sensor—Rounded flag, detects the presence of paper at the platen. • TOF Sensor—Sharp flag, determines TOF at paper load. • PSet Sensor—Paper set, detects presence of paper in the tractors and looks for end of forms. • Jam Sensor—Senses the holes in the paper and detects paper jams by the lack of paper movement. <p>When the PSet sensor detects EOF, it lets printing continue to the bottom of the form. When the PE sensor detects no paper, it stops print within a few lines.</p> <p>The jam sensor stops printing after about 50 mm of no signal change; for example, if 50 mm of pinfeed is removed from a sheet, the sensor stops printing. Less than 50 mm will probably be ignored. Therefore, the paper motion must have stopped for the equivalent of about 12 printed lines to cause a jam.</p> <p>If either the PE or the PSet sensor detects no paper during print, printing stops at the end of the current page.</p> <p>The Tractor 2 option also has PSet and Jam sensors on the left tractor.</p> <p>Enter the service menu and perform the sensor tests.</p> <p>Replace any failed or damaged sensors.</p>
6	Paper Select Sensor	<p>Enter the Service Menu and perform the Sensor Test 2 for "Lever."</p> <p>Move the Paper Select lever to test the sensor.</p> <p>Replace any sensor if failed or damaged.</p>


	FRU/Symptom	Action
7	Operator Panel	If paper does not move at all, verify the FormFeed button is working correctly by performing the Service Menu Button Test.
8	Main Logic Board	If no other problem is found, replace the main logic board. Perform the “Bidirectional print adjustment” on page 4-3 , and “Printhead-to-platen gap adjustment” on page 4-2 .

POST service check

	FRU	Action
1	Power	Disconnect the parallel or serial cable and turn the power on. If there is no printer activity, go to the “Power failure service check” on page 2-25 .
2	Operator Panel	If the power supply fan turns on but no LEDs light, go to the “Operator panel service check” on page 2-20 .
3	Main Logic Board	If the Power LED turns on but POST does not complete, replace the main logic board. Perform the “Bidirectional print adjustment” on page 4-3 and check the “Printhead-to-platen gap adjustment” on page 4-2 .
4	Printer Cable	If POST completes, reconnect the parallel or serial cable and turn power on again. If POST now fails, there is a problem with the cable, or the parallel connector on the main logic board.

Power failure service check

For more information see [“Voltage, ground, and continuity readings”](#) on page 1-2.

	FRU	Action
1	Operator Panel	<p>If the operator panel or cable is damaged or disconnected, the machine is completely inoperable, except for the power supply fan noise.</p> <p>If the power LED is not on steady, check the cable continuity and replace the cable or the operator panel.</p>
2	Power Supply  Fuse	<p>If the printer is completely inoperable, disconnect the power cables from the main logic board (CN11) and the sub logic board (CN1).</p> <p>Turn the power on and measure $+5 \pm 0.5$ V dc at the sub logic board cable CN1-5 and $+40 \pm 4$ V dc at CN1-1 and CN1-2. If there is no voltage, check the internal fuse before replacing the power supply.</p> <p>A 634 Power Failure indicates that the +5 V dc is OK but the +40 V dc is not. Power the printer off, wait 10 seconds, and power back on. If the 634 reappears either the power supply has failed or there is a short in a motor that uses +40 V dc.</p>

	FRU	Action
3	Ribbon Motor Paper Feed Motor Carrier Motor Sub Logic Board 4227-300 Carrier Motor Cooling Fan	<p>Disconnect the carrier motor (CN9 and CN15), the paper feed motor (CN10), the ribbon motor (CN19) and the (4227-300) carrier motor cooling fan (CN17) from the main logic board, and disconnect the power connector CN-1 from the sub logic board. Turn the power on again. If there is still a power problem, replace the main logic board.</p> <p>If the machine posts a different error, one of these items is shorted and is holding down the +40 V dc line. Reconnect them one at a time, turning the printer on in between each connection.</p> <p>Replace the item that causes the power failure.</p>
4	Printhead Cables Printhead	<p>Disconnect the printhead cables from the sub logic board and turn the printer on. If the power LED lights correctly only with the printhead cables disconnected from the sub logic board, there is a short in the printhead or printhead cables.</p>
5	Main Logic Board	<p>If all the above items have been examined and there is still a power problem, replace the main logic board. (Retain the old board for reinstallation if the problem is not fixed.)</p> <p>Perform the “Bidirectional print adjustment” on page 4-3 and check the “Printhead-to-platen gap adjustment” on page 4-2.</p>

Print quality service check

	FRU	Action
1	Ribbon and Shield	Be sure the ribbon is not worn and feeds smoothly when the knob is turned. Inspect the ribbon shield for dirt or damage.
2	Ribbon Drive	Be sure the ribbon drive post rotates when printing.
3	Auto Gap Auto Gap Motor Bracket	Check the "Printhead-to-platen gap adjustment" on page 4-2 . If Auto Gap is off, be sure the manual position setting is appropriate for the paper used. If the failure remains, replace the Auto Gap motor bracket.
4	Printhead Cables	Inspect both ends of the printhead cables for proper connection.
5	Carrier Belt Adjustment	Loosen and tighten the tension pulley plate screws to make sure the carrier belt is tight.
6	Carrier Movement	With the power off, manually move the carrier from side to side to inspect for drag or binds.
7	Bidirectional Print Adjustment	Perform the "Bidirectional print adjustment" on page 4-3 .
8	Carrier Motor	The carrier motor should turn smoothly and quietly when printing.
9	Paper Feed Gears	Inspect the paper feed gears for wear and tear.
10	Paper Feed Motor	The paper feed motor should turn smoothly and quietly when printing.
11	Tractors	Inspect the tractors for damage or looseness.
12	Feed Roller Surfaces	Inspect the feed roller surfaces for dirt or wear.

Print wire drive failure service check

	FRU/Symptom	Action																				
1	<p>Missing Dots</p> <p>Carrier moves, but there is no printing or printhead sound.</p>	<p>Perform the Print Test to determine which wires are not printing. Disconnect the printhead cables from the sub logic board and check the resistance for the affected wires. The resistance for each wire should be around 8.5 ohms.</p> <table border="1" data-bbox="419 532 934 1047"> <thead> <tr> <th data-bbox="419 532 719 591">Left Bank</th> <th data-bbox="719 532 934 591">Right Bank</th> </tr> </thead> <tbody> <tr> <td data-bbox="419 591 719 643">Wire 1 CN3-11 & CN3-18</td> <td data-bbox="719 591 934 643">CN3- 9 & CN3- 4</td> </tr> <tr> <td data-bbox="419 643 719 695">Wire 2 CN4-11 & CN4-20</td> <td data-bbox="719 643 934 695">CN4- 9 & CN4- 2</td> </tr> <tr> <td data-bbox="419 695 719 747">Wire 3 CN3-13 & CN3-16</td> <td data-bbox="719 695 934 747">CN3- 7 & CN3- 6</td> </tr> <tr> <td data-bbox="419 747 719 799">Wire 4 CN4-13 & CN4-18</td> <td data-bbox="719 747 934 799">CN4- 7 & CN4- 4</td> </tr> <tr> <td data-bbox="419 799 719 850">Wire 5 CN4-15 & CN4-16</td> <td data-bbox="719 799 934 850">CN4- 5 & CN4- 6</td> </tr> <tr> <td data-bbox="419 850 719 902">Wire 6 CN4-17 & CN4-14</td> <td data-bbox="719 850 934 902">CN4- 1 & CN4-8</td> </tr> <tr> <td data-bbox="419 902 719 954">Wire 7 CN3-15 & CN3-14</td> <td data-bbox="719 902 934 954">CN3- 3 & CN3- 8</td> </tr> <tr> <td data-bbox="419 954 719 1006">Wire 8 CN4-19 & CN4-12</td> <td data-bbox="719 954 934 1006">CN4- 3 & CN4-10</td> </tr> <tr> <td data-bbox="419 1006 719 1047">Wire 9 CN3-17 & CN3-12</td> <td data-bbox="719 1006 934 1047">CN3- 5 & CN3-10</td> </tr> </tbody> </table> <p data-bbox="472 1058 887 1117">Note: 4227-300 connectors will be CN1 and CN2.</p> <p data-bbox="423 1187 921 1317">If the resistance for the affected wires is incorrect, disconnect the printhead cables from the printhead and measure the resistance of the printhead for the same wires. The resistance should be around 7.9 ohms.</p> <ul data-bbox="431 1344 878 1448" style="list-style-type: none"> • If the resistance is correct, replace the printhead cables. • If the resistance is incorrect, replace the printhead. 	Left Bank	Right Bank	Wire 1 CN3-11 & CN3-18	CN3- 9 & CN3- 4	Wire 2 CN4-11 & CN4-20	CN4- 9 & CN4- 2	Wire 3 CN3-13 & CN3-16	CN3- 7 & CN3- 6	Wire 4 CN4-13 & CN4-18	CN4- 7 & CN4- 4	Wire 5 CN4-15 & CN4-16	CN4- 5 & CN4- 6	Wire 6 CN4-17 & CN4-14	CN4- 1 & CN4-8	Wire 7 CN3-15 & CN3-14	CN3- 3 & CN3- 8	Wire 8 CN4-19 & CN4-12	CN4- 3 & CN4-10	Wire 9 CN3-17 & CN3-12	CN3- 5 & CN3-10
Left Bank	Right Bank																					
Wire 1 CN3-11 & CN3-18	CN3- 9 & CN3- 4																					
Wire 2 CN4-11 & CN4-20	CN4- 9 & CN4- 2																					
Wire 3 CN3-13 & CN3-16	CN3- 7 & CN3- 6																					
Wire 4 CN4-13 & CN4-18	CN4- 7 & CN4- 4																					
Wire 5 CN4-15 & CN4-16	CN4- 5 & CN4- 6																					
Wire 6 CN4-17 & CN4-14	CN4- 1 & CN4-8																					
Wire 7 CN3-15 & CN3-14	CN3- 3 & CN3- 8																					
Wire 8 CN4-19 & CN4-12	CN4- 3 & CN4-10																					
Wire 9 CN3-17 & CN3-12	CN3- 5 & CN3-10																					

	FRU/Symptom	Action
2	63E Head Thermal Error	<p>The printer has stopped to protect the printhead from overheating. Normally this occurs after several hours of continuous heavy use in a warm environment, and only then after going through several stages of thermal slowdown.</p> <p>Wait for the machine to cool and see if the error goes away.</p> <p>If the machine was not being used heavily before the error occurred, or if the error returns when the machine is cool, replace the printhead.</p>
3	Auto Gap	<p>If the printhead is firing, manually rotate the carrier shaft during printing by pushing down on the Auto Gap Home sensor flag.</p> <p>If printing starts and is correct, go to the “Auto Gap service check” on page 2-11.</p>
4	Printhead Cables	Inspect for improper connection or damage.
5	Sub Logic Board	If there is carrier motion but no printhead noise, and the printhead cables do not appear to be the problem, replace the sub logic board.
6	Ribbon	<p>A problem with the ribbon shield can keep the print wires too far from the page.</p> <p>Inspect the ribbon shield. When the printer is Ready with the ribbon installed, make sure the ribbon shield can float slightly front to back.</p>
7	Printhead	<p>The printhead probably is not the problem if there is no printing.</p> <p>Check the winding resistances as described above and look for open circuits or shorts between neighboring pins.</p> <p>Do not replace the printhead unless a specific problem is found.</p>

	FRU/Symptom	Action
8	Main Logic Board	<p>If no other problem is found, replace the main logic board, retaining the old board for reinstallation if the problem is not fixed.</p> <p>Perform the “Bidirectional print adjustment” on page 4-3 and the “Printhead-to-platen gap adjustment” on page 4-2.</p>

Ribbon drive service check

In normal operation, the ribbon knob rotates counterclockwise whenever the carrier moves to the left.

	FRU/Symptom	Action
1	Ribbon Drive Gear Train	<p>Remove and inspect the ribbon. Make sure the knob turns with even, moderate force and the ribbon feeds correctly.</p> <p>Inspect the gear train from the ribbon motor to the ribbon drive post.</p> <p>Check the “Printhead-to-platen gap adjustment” on page 4-2.</p>
2	Ribbon Motor	<p>If printing seems normal, but the ribbon is not moving, remove the ribbon and turn power on.</p> <p>The ribbon drive post should turn several times during POST. Disconnect the ribbon motor connector CN19 from the main logic board.</p> <p>The winding resistance should be 118 ohms \pm 5 between pins: 1 and 5, 3 and 5, 2 and 6, 4 and 6.</p> <p>Pin 5 should show an open circuit to pins 2, 4 and 6. Pin 6 should show an open circuit to pins 1, 3, and 5.</p>

Tractor 2 service check

The Tractor 2 sensor opens during installation, when its actuator touches the printer cover. The home sensor detects the position of the slider.

- When Tractor 2 is selected, the motor-driven Tractor 2 slider pushes the printer sub slider cam lever to engage the printer gear train, which drives the Tractor 2 tractors.
- When the Tractor 2 is deselected, the motor retracts the slider, disengaging the Tractor 2 gear drive and reengaging the printer tractors.

63D Tractor 2 HP error

The Tractor 2 Home sensor was never initialized after turning the printer off and then on, or made at the wrong time.

(The same error indication is used for carrier home failure.)

	FRU	Action
1	Tractor 2 Home Sensor	Remove the Tractor 2 and turn the printer off and then back on again to determine whether the fault is in the printer or in Tractor 2. If the gear teeth chatter just before the error is displayed, replace the home sensor.

	FRU	Action
2	Main Logic Board	<p>Remove Tractor 2 from the printer but leave the cable connected.</p> <p>Make sure the slider (the black plastic piece just above the right cover) moves after turning the printer off and then back on. If the slider does not move after turning the printer off and then back on:</p> <ul style="list-style-type: none"> • Make sure the slider and gear train are properly connected and move freely with the power off. • Make sure the Tractor 2 board is receiving: +26 V dc on CN1-1 and + 5 V dc on CN1-5 <p>If not, check the cable connection and the voltages at main logic board CN13-1. The upper right pin at CN13 is pin 1 (+26 V dc) and the pin just beneath it is pin 5 (+5 V dc).</p> <p>If these voltages are not present, replace the main logic board.</p>
3	Tractor 2 Motor Board/Cable Asm	<p>Check the following resistances of the Tractor 2 motor windings: 101 ± 5 ohms between pins: 1 and 6, 3 and 6, 2 and 5, 4 and 5.</p> <p>If the motor is good, replace the board/cable assembly.</p> <p>For more information on the Tractor 2 cable connectors, see “Tractor 2 cable connectors” on page 6-15.</p>

Tractor 2 installed, but not shown in User Menu

Tractor 2 is selected from operator panel but the printer does not detect Tractor 2, or detects that the Tractor 2 mechanism is not installed.

Power the printer off and reinstall the Tractor 2. Power the printer on and verify the problem still occurs.

	FRU	Action
1	Tractor 2 Board/Cable Asm.	<p>Check the Tractor 2 sensor or the cable connection.</p> <p>The sensor actuator extends through the Tractor 2 cover and rests on the printer cover when Tractor 2 is installed.</p> <p>Remove the Tractor 2 cover and make sure the sensor opens when the Tractor 2 is installed. The voltage at Tractor 2 CN1-13 should be +5 V dc with the sensor open, and 0 with it closed.</p> <p>Replace the Tractor 2 board/cable asm if the sensor signal is wrong.</p> <p>For more information on the Tractor 2 cable connectors, see "Tractor 2 cable connectors" on page 6-15.</p>
2	Main Logic Board	<p>Check the cable connection from Tractor 2 to the printer.</p> <p>If possible, try the Tractor 2 with another printer to determine if the problem is the Tractor 2 board/cable assembly or the printer main logic board.</p>

Paper feed problems

	FRU	Action
1	Tractor 2	<p>On the printer, make sure the Tractor 2 driving gear turns freely when the white sub slider cam is not pressed. Be sure the driving gear does not move when the sub slider cam behind the gear is pressed.</p> <p>Remove Tractor 2 from the printer and remove all paper. With the paper select lever in the continuous forms position, press LineFeed; the tractors should rotate.</p> <p>Press the sub slider cam below the ASF/ Tractor 2 drive gear and press LineFeed again; the tractors should not rotate but the drive gear should.</p> <p>Check the condition of the pin feed belts. With the power off, make sure the slider does not bind.</p> <p>Verify:</p> <ul style="list-style-type: none"> • When the slider is to the rear, the white gear drives the tractors. • When the slider is to the front, the gear and tractors are not connected. <p>Remove the Tractor 2 cover and reinstall Tractor 2 in the printer (if necessary remove the printer covers also). Note that the small idler gear just below the slider is held in place by the cover; with the cover removed it will tend to move off the stud. Also note that when operating the Tractor 2 with the printer cover removed, the Tractor 2 sensor must be held open.</p> <p>Turn the printer on and look for mechanical problems.</p> <p>For more information on the Tractor 2 cable connectors, see “Tractor 2 cable connectors” on page 6-15.</p>

3. Diagnostic aids

The printer contains self tests to help find and solve problems. You do not need to connect the printer to a computer or terminal to run these tests.

Types of self tests are as follows:

- Power-On Self Test (POST)
- Hex Trace Mode (a computer or terminal is needed)
- Print Tests
- Error Log

Power-On Self Test (POST)

The Power-On Self Tests diagnose the basic hardware printer functions and initialize the default value settings. POST starts automatically when power to the printer is turned on, or when the printer receives an INIT signal from the controller.

- The power supply fan comes on.
- LED Test—All LEDs turn on briefly.
- LCD Test—All pels of the display are activated twice, and then "initialize" is displayed.
- RAM Test—Checks that the CPU can write/read the RAM.
- ROM Test—Checks that the ROM data is correct.
- Timer/Interrupt Controller Test—Checks that this function is working.
- Button Scan Test—Scans all operator panel buttons.
- NVRAM Test—Checks that the NVRAM data is correct.
- The ribbon motor feeds ribbon.
- The carrier moves to the left side frame, and then back to the right.
- The auto Gap sequence occurs.

If any errors occur during the POST tests, an error indicator shows which test failed. See ["Start" on page 2-1](#).

Hex trace mode

The hex trace mode can help test and troubleshoot programs. You can use the hex trace procedure to get a hexadecimal printout of the data stream sent to the printer. All data, including control and character data, print in hexadecimal instead of ASCII.

To activate hex trace mode:

1. Press **Menu**.
2. Press **Item** ↓ until **Trace Mode** appears on the operator panel.
3. Press **Start**.

Hex trace mode sample

```

20 20 20 30 20 20 40 20 20 20 20 A0 20 20 B0 20 20 C0 20
20 00 20 20 E0 20 20 F0 00 20 61 20 20 71 20 20 81 20 20
91 20 20 A1 20 20 B1 20 20 C1 22 20 20 32 20 20 42 20 20 52
20 20 62 20 20 72 20 20 82 20 20 D2 20 20 E2 20 20 F2 00 0A
0A 23 20 20 33 20 20 43 20 93 20 20 A3 20 20 B3 20 20 C3
20 20 D3 20 20 E3 20 20 F3 20 20 64 20 20 74 20 20 84 20
20 94 20 20 A4 20 20 B4 20 0A 25 20 20 35 20 20 45 20 20
55 20 20 65 20 20 75 20 20 20 20 05 20 20 E5 20 20 F5 00
0A 0A 26 20 20 36 20 20 46 20 96 20 20 A6 20 20 B6 20 20
C6 20 20 D6 20 20 E6 20 20 57 20 20 67 20 20 77 20 20 87
20 20 97 20 20 A7 20 20 B7 20 0A 28 20 20 38 20 20 48 20
20 58 20 20 68 20 20 78 20 20 20 20 08 20 20 EB 20 20 FB
00 0A 0A 29 20 20 39 20 20 49 20 99 20 20 A9 20 20 B9 20
20 C9 20 20 D9 20 20 E9 20 20 A 20 20 6A 20 20 7A 20 20
8A 20 20 9A 20 20 AA 20 20 BA 20 0A 28 20 20 3B 20 20 4B
20 20 5B 20 20 6B 20 20 7B 20 20 3 20 20 DB 20 20 EB 20 20
FB 00 0A 0A 2C 20 20 3C 20 20 20 20 20 9C 20 20 AC 20 20 BC
20 20 CC 20 20 DC 20 20 EC 20 20 0 5D 20 20 6D 20 20 7D 20
20 8D 20 20 9D 20 20 AD 20 20 0D 0A 0A 2E 20 20 3E 20 20
4E 20 20 5E 20 20 6E 20 20 7E 20 CE 20 20 DE 20 20 EE 20
20 FE 0D 0A 0A 2F 20 20 3F 20 BF 20 20 9F 20 20 AF 20 20
8F 20 20 CF 20 20 DF 20 20 E

```

Interface selection

Serial or parallel attachment can be selected from the User Menu under Interface Options. If **serial attachment** is selected, RS-232 or RS-422 can be selected with the switch that is accessible through the rear cover. Serial attachment parameters are set in the Interface Options menu.

Operation with the top cover removed

After you remove the top cover, the printer can be operated for service purposes by positioning the cover near the main logic board and reconnecting the operator panel cable. The ribbon cover must be in place on the top cover. Or, you can remove the operator panel and cable, jumper the two pins of the ribbon cover sensor connector CN1 together on the back of the panel, and reconnect the operator panel flex cable to the main logic board.

Note: Printing without the top cover affects print quality and may cause paper jams, since the upper feed rollers on the ribbon cover do not help restrain and feed paper.

Service Menu

Enter the Service Menu by pressing **Menu/Quit** during POR.

Release the button when the carrier strikes the left side frame. Exit the Service Menu by pressing **Menu/Quit**.

- Sensor Test 1: Tests PSet, Jam, PE & TOF sensors.
- Sensor Test 2: Tests Paper Select, Gap Home, and Cover sensors.

These tests display an underline () if the sensor is open or a block (**■**) if the sensor is blocked. Use paper, tools, or fingers to block and unblock the sensors to verify that each is functional. Return to the Service Menu by pressing **Menu/Quit**.

Button Test

Pressing each operator panel button causes the alarm to beep. Pressing multiple buttons simultaneously results in no beep. Return to the Service Menu by pressing **Menu/Quit**.

Factory Setting

Factory Setting allows the selection of the default page length and code page from U.S. defaults (11", Code Page 437, Character Set 1) to Non-U.S. defaults (12", Code Page 850, Character Set 2).

Printhead Bank

This allows the 18-wire printhead to be set to use the left bank only, the right bank only, or both banks (default). This allows the printer to continue to print with a damaged printhead or cable.

Jam/PSet Sensor Test

This test enables or disables the PSet and Jam sensors on the left tractor.

Impact force

Impact force enables the striking force of the printhead pins to be changed. Three selections are possible.

- **Normal Auto**—This is the default value. Impact force of the printhead pins is adjusted automatically for paper thickness.
- **High**—This is the highest impact force and overrides the Normal Auto selection. High pin force is used to obtain clearer print on medium thickness forms. Leaving the printer in High can damage the printhead, especially if printing on single-sheet forms.
- **Normal 1P**—Disables the automatic setting of the impact force. Normal 1P is used to print in normal force when thicker print media is used, such as labels.

Log clear

Clears the error log.

Print Test

The Print Test prints:

- The ASCII character set
- A line from each print wire
- The bidirectional print alignment pattern
- The contents of NVRAM
- The error log

Other print tests

The following print tests are accessed outside the Service Menu:

- A draft only 8-inch-wide continuous print test. This test is activated by turning the printer on with the **Load/Unload** and **LineFeed** buttons pressed.
- A draft only 13.6-inch-wide continuous print test. This test is activated by turning the printer on with the **LineFeed** and **FormFeed** buttons pressed.

Note: These tests print a running page count at the bottom of each page. Use the **Start/Stop** button to start and stop the test. Other buttons that are active during this test are the **Micro** ↓ or **Micro** ↑ , **Load/Unload**, **LineFeed** and **FormFeed** buttons.

Print Demo and the **Print Settings** page are accessed from the user menus. **Print Settings** prints Macro status and paper handling settings and prints 8 inches wide.

Error log

The Error Log printout is part of the Service Menu test print page. Error indicators print on the top line of the Error Log and their corresponding counters print below. The error indicators are the last two digits of the "6XX Machine Check" display indication. An error indicator 00 indicates no errors are registered in the counter. Each new error appears in the left-most position and the previous error indicator shifts one position to the right. If the new error indicator is the same as the previous error indicator, the counter is increased by 1. The maximum count number for the same error is 256, and the counter remains at this value (X'FF'). No more than 16 most recent error indicators can be printed in the error log area.

4. Repair information

This chapter explains how to make adjustments to the printer and how to remove defective parts.

Warning: Read the following before handling electronic parts.

Handling ESD-sensitive parts

Many electronic products use parts that are known to be sensitive to electrostatic discharge (ESD). To prevent damage to ESD-sensitive parts, follow the instructions below:

- Keep the ESD-sensitive part in its original shipping container (a special “ESD bag”) until you are ready to install the part into the machine.
- Make as few movements as possible with your body to prevent an increase of static electricity from clothing fibers, carpets, and furniture.
- Put the ESD wrist strap on your wrist. Connect the wrist band to the system ground point. This discharges any static electricity in your body to the machine.
- Hold the ESD-sensitive part by its edge connector shroud (cover); do not touch its pins. If you are removing a pluggable module, use the correct tool.
- Do not place the ESD-sensitive part on the machine cover or on a metal table; if you need to put down the ESD-sensitive part for any reason, first put it into its special bag.
- Machine covers and metal tables are electrical grounds. They increase the risk of damage because they make a discharge path from your body through the ESD-sensitive part. (Large metal objects can be discharge paths without being grounded.)
- Prevent ESD-sensitive parts from being accidentally touched by other personnel. Install machine covers when you are not working on the machine, and do not put unprotected ESD-sensitive parts on a table.
- If possible, keep all ESD-sensitive parts in a grounded metal cabinet (case).
- Be extra careful in working with ESD-sensitive parts when cold-weather heating is used, because low humidity increases static electricity.

Adjustments

Printhead installation adjustment

1. Hold the printhead down while pressing it toward the platen, and tighten the two printhead mounting screws.
2. Perform the **“Printhead-to-platen gap adjustment”** on page 4-2.

Printhead-to-platen gap adjustment

Perform this adjustment:

- When the platen, printhead, carrier, carrier shaft, or main logic board is removed or replaced
- When the print density varies across the page

There are two adjustments to this procedure.

Printhead-to-platen gap left and right

1. Turn the power off.
2. Remove the top cover.
3. Remove the ribbon.
4. Position the carrier to the left.
5. Using a .014 inch (.35 mm) feeler gauge as the Go gauge and a .016 inch (.40 mm) feeler gauge as the No-Go gauge, rotate the carrier shaft and measure the printhead-to-platen gap.
6. Position the carrier to the right.
7. Adjust the carrier shaft bearing on the right side frame so the right gap matches the left gap.

Printhead-to-platen gap electronic setting

Be sure there is no paper in the printer.

1. Install a ribbon.
2. Hold down **FormFeed** and power on the printer.
3. Remove the ribbon guide.
4. Measure the printhead-to-platen gap. The gap specification is between .011 inch (.275 mm) and .015 inch (.375 mm).
5. Use the **Micro**↑ or **Micro**↓ to change the printhead-to-platen gap setting. The **Micro**↑ button increases the clearance and the **Micro**↓ button decreases the clearance.
6. Install the ribbon guide.
7. Press **Start/Stop** to reset the new printhead-to-platen gap setting.
8. Remove the ribbon guide and check the setting with a feeler gauge.
9. Repeat steps 5 through 8 until the gap is within the specification.
10. Press **Store** to save the setting in NVRAM.


Bidirectional print adjustment

Perform this adjustment whenever the main logic board, carrier, or printhead is replaced. This test is in the User Menu and uses a line length corresponding to the right margin setting. Run the test at both the Draft speed setting and the Courier speed setting.

The following steps tell how to adjust the alignment of the print wires, and assumes that macros are disabled.


1. Load continuous forms.
2. Press **Menu**.
3. Press **Item** ↓ until **Print Adjust** appears on the display.
4. Press **Next** →
5. Press **Item** ↓ or **Item** ↑ to choose Draft or Courier. Draft prints each alignment pattern once (unidirectional). Courier prints each alignment pattern twice (bidirectional).
6. Press **Start/Stop** to print the alignment pattern.

The following example shows a printer that needs alignment.



The message **Choose the Best Alignment** appears on the display.

7. Press **Next** → or **Prev.** ← to adjust the alignment.
 Lines 2 and 4 move to align with lines 1 and 3. The printer is aligned correctly when lines 2 and 4 are vertically aligned with lines 1 and 3.
 - Press **Item** ↑ to move lines 2 and 4 to the right.
 - Press **Item** ↓ to move lines 2 and 4 to the left.
8. Press **Store** to save the selected value.
9. Press **Start/Stop** to print the alignment pattern. The example below shows proper alignment.



10. Press **Quit** to exit the menu.


Removals

Use the following procedures to remove and replace individual FRUs.

Top cover removal

CAUTION: Be sure to unplug the power cord whenever you are working on the printer with any of the covers removed.

1. Turn the printer off.
2. Disconnect the power cord and parallel cable at the printer.
3. Remove the front cover (1).
4. Remove the acoustic and ribbon access covers (2).




5. Set the Paper Select lever to the cut sheet position.

6. There are two screws (3) and six latches (4) securing the top cover to the bottom cover. Remove the two top cover (3) mounting screws.



7. Place the printer on its left side. Insert a flat blade screwdriver into the two slots (4) and release the cover by pushing on the left side latches and up on the top cover.
8. Place the printer on its right side and release the two right side latches (4).



9. Place the printer on its feet and release the remaining two top cover latches (4).



10. While lifting the top cover slightly, disconnect the operator panel cable from the main logic board, and then remove the top cover.

To Reinstall:

Be sure that the operator panel cable is correctly aligned and inserted securely.

WARNING: Damage to the operator panel cable may cause failure of other electrical components of the printer. Be sure not to crimp or pinch this cable while reinstalling the top cover.




CAUTION:

Be sure to unplug the power cord whenever you are working on the printer with one of the covers removed.


Auto Gap motor removal

1. Remove the top cover. See **“Top cover removal”** on page 4-5.
2. Disconnect gap adjust motor connector CN20 from the main logic board.
3. Remove the sub logic card.
4. Remove the paper feed motor.
5. Remove the two gap adjust motor screws (1) through the access holes in the carrier motor mounting bracket, and remove the motor (2).




Auto Sheet Feeder gears removal

1. Remove the right cover (1).
2. Release the latch, and then remove the joint gear (2).
3. Remove the latch, and then remove the idler gear (3).
4. Release the latches, and then remove the pick-up gear (4).
5. Release the latch, and then remove the combination lock mechanism (5).



Auto Sheet Feeder pick-up roller removal

1. Remove the covers and the cut sheet support.
2. Remove the idler gear and the pick-up gear. See ["Auto Sheet Feeder gears removal"](#) on page 4-9.
3. Remove the left roller bushing (1).
4. Remove the right roller bushing (2).
5. Move the pick-up roller (3) to both ends of the shaft, and then remove them.



Belt tension pulley plate assembly removal

1. Remove the top cover. See [“Top cover removal” on page 4-5](#).
2. Turn the printer so the rear of the printer faces you.
3. Remove both tension pulley plate mounting screws (1).
4. Manipulate the left side of the tension spring off the lug.
5. Slide the pulley plate to the right and off the carrier plate.
6. Slide the pin out of the pulley, and manipulate the belt out of the tension pulley plate.




Base assembly removal

1. Remove the tractor assembly.
2. Remove the top cover. See [“Top cover removal” on page 4-5](#).
3. Remove the print unit.
4. Remove the power supply.
5. Remove the main logic board.
6. Remove the tractor cable and bracket.
7. If you are replacing the bottom cover, write the machine serial number and part number on the blank label.


Carrier removal

1. Remove the top cover. See [“Top cover removal”](#) on page 4-5.
2. Remove the printhead. See [“Printhead removal”](#) on page 4-32.
3. Remove the carrier roller spring.
4. Remove the sub logic board. See [“Sub logic board removal”](#) on page 4-37.
5. Remove the ribbon drive motor assembly (1).




4227-300

6. Loosen the two tension pulley plate screws (2). Pull up on both sides of the belt to move the tension pulley plate as far as possible toward the center of the printer, and then retighten the large screw.



7. Remove the belt from the carrier motor pulley.
8. Push the tension pulley toward the outside of the printer and remove its shaft through the large part of the keyhole. Push the pulley up and remove it to free the carrier belt.

9. Remove the gear/flag (3) from the end of the carrier shaft.




10. Remove the bearing (4) and its retainer (5) by pulling the bearing free and lifting the end of the carrier shaft.
11. Slide the carrier shaft toward the carrier motor to free the other end.

To reinstall:

1. The bearing and retainer must be on the shaft when the shaft is lowered into place. Make sure the bearing flange goes behind the black double gear.
2. Rotate the shaft to get the bearing to seat in the side frame.
3. After reinstalling, perform the **“Printhead-to-platen gap adjustment”** on page 4-2.

Carrier motor assembly removal

1. Remove the top cover. See [“Top cover removal” on page 4-5](#).
2. Disconnect carrier motor connectors CN9 and CN15 from the main logic board.
3. Loosen the two tension pulley plate screws. Pull up on both sides of the belt to move the tension pulley plate as far as possible toward the center of the printer, and then retighten the large screw.
4. Remove the three screws (1) holding the motor to its bracket.
5. Remove the carrier motor.



To reinstall:

1. Be sure the motor pulley goes inside the belt as the motor is being reinstalled.
2. The shaft bearing should be under the ribbon motor plate, mounted to the carrier motor shaft.
3. The ribbon motor screws should be loosened when reinstalling the carrier motor.
4. Tighten the carrier motor screws before you tighten the ribbon motor assembly mounting screws.

Carrier plate removal

1. Remove the top cover. See [“Top cover removal” on page 4-5](#).
2. Remove the print unit.
3. Remove the carrier.
4. Remove the lower pinch roller.
5. Remove the carrier motor.
6. Remove the Auto Gap motor and its bracket.
7. Remove the carrier motor bracket.
8. Remove the right side frame.
9. Remove the two screws holding the carrier plate to the left side frame, and then remove the carrier plate.


Label jam removal

When a pressure-sensitive label separates from its protective backing and jams and sticks to the paper separator below the carrier plate, use the following procedure to remove the label.


1. Remove the top cover. See [“Upper feed roller removal” on page 4-38](#).
2. Remove the tractor assembly.
3. Remove the print unit. See [“Print unit removal” on page 4-29](#).
4. Remove the paper separator. See [“Paper separator removal” on page 4-27](#).
5. Carefully remove the label from the paper separator. If the label is jammed below the carrier plate or on the lower portion of the paper guide/platen assembly, carefully remove the label without scratching either surface.

Lower feed roller removal

1. Remove the top cover. See ["Top cover removal" on page 4-5.](#)
2. Remove the print unit.
3. Remove the sub logic board.
4. Remove the paper feed motor.
5. Remove the large gear from the left side frame by prying it from behind with a flat-blade screwdriver.
6. Remove the support bracket (1) from the back of the platen.
7. Remove the Paper Select lever.




8. Remove the gear shaft support plate (2) and the two gears with their springs (3).
9. Remove the large screw (4) holding the tension pulley plate to the side frame.
10. Remove the gear, clip, and bearing (5) from the end of the lower feed roller shaft.




4227-300

11. Release and remove the separator plate spring (6).
12. Release the spring (7) from the right end of the lower pinch roller.



13. Remove the two carrier plate screws (8). One is in the slot in the slider cam.
14. Remove the support shaft screw (9).

15. Remove the two platen screws (10).



16. Remove the right side frame.
17. Remove the lower feed roller shaft.


Note: The upper feed roller bearing should stay in the side frame. The lower pinch roller bushing is free on the end of the shaft.

To reassemble:

1. Remove the paper separator while first installing the side frame loosely. Make sure the lower pinch roller spring is above the bushing.
2. Remove the screw from the right end of the paper separator.
3. Install the left end of the paper separator first, and then flex the right side frame slightly to get the right end installed.
4. Reinstall the screw through the hole above the slider cam.

Lower pinch roller removal

1. Remove the ribbon cover and the ribbon.
2. Remove the U-shaped ground spring (1).
3. Release the left and right pinch roller springs (2).



4. Move the carrier to the right as far as it will go.
5. Lift the left end of the lower pinch roller and move it to the left until the right end clears the carrier. Be sure not to lose the right bearing.
6. Remove the shaft to the right.

Main logic board removal

1. Remove the top cover. See [“Top cover removal” on page 4-5.](#)
2. Disconnect all cables connected to the main logic board.
3. Remove the three screws at the rear edge of the board, and then remove the board.
4. Remove the EPROM from the old board and install it on the new one.

To reinstall:

After replacing the main logic board, recheck the [“Bidirectional print adjustment” on page 4-3](#) and the [“Printhead-to-platen gap adjustment” on page 4-2.](#)

Memory Module removal

The Memory Module is an option.

1. Turn the printer off and disconnect the power cord at the printer.
2. Remove the rear cover.
3. Remove the paper support.
4. Insert a small flat screwdriver under each end of the module and lift gently. Do not insert the screwdriver too far, or the main logic board may be damaged.


Note: Be careful not to bend the pins when you reinstall the module.

Operator panel assembly removal


1. Remove the top cover. See [“Top cover removal” on page 4-5](#).
2. Disconnect the ribbon cover sensor connector from the back of the operator panel.
3. Disconnect the operator panel cable from the back of the operator panel.
4. Push up on the lower latches to free the operator panel from the top cover.

Paper Empty sensor/TOF sensor removal

1. Remove the top cover. See [“Top cover removal” on page 4-5](#).
2. Remove the print unit. See [“Print unit removal” on page 4-29](#).
3. Remove the right screw (1) in the support shaft.



4. To remove the Paper Empty sensor:
 - a. Release the four latches (2) and remove the Paper Empty sensor.
 - b. Carefully grasp the Paper Empty flag with a pair of needle nose pliers and remove the flag by pulling it vertically away from the paper guide. Do not damage or lose the Paper Empty sensor spring.




5. Unsnap the TOF sensor from the back of the paper guide using a screwdriver as illustrated (3).

To replace the TOF Sensor Flag:

Unless necessary, do not replace the sensor flag when replacing the sensor.

1. With diagonal pliers, cut the post and two tabs (5) off as flush as possible.
2. Unsnap both ends of the sensor flag from the paper guide. Carefully remove the sensor flag spring (4) from the bottom end of the sensor flag.
3. Pivot the upper tip of the sensor flag downward through the open area just to the right of the center feed roll, and lift the lower end of the flag until it becomes free.
4. The sensor flag spring hooks over the lower arm of the flag. Be sure the point of the sensor flag is kept in the paper path by the spring force. Be sure the leaf spring is in contact with the lower feed roller shaft.



Paper feed motor removal

1. Remove the top cover. See [“Top cover removal” on page 4-5.](#)
2. Disconnect the paper feed motor connector CN10 from the main logic board.
3. Remove the sub logic board.
4. Remove the four screws holding the motor in place and remove the motor.
5. Remove the double gear from the shaft on the face of the motor.

To reinstall

With the screwdriver, hold the bottom screw in place in the motor bracket. This screw is difficult to reach once the motor is in place.

Paper guide removal

1. Remove the front cover and place it front down on a flat surface.
2. Pry under the front part of the guide to release the two latches, and then remove the paper guide.

Paper guide/platen assembly removal


1. Remove the top cover. See [“Top cover removal” on page 4-5.](#)
Remove the print unit.
2. Remove the sub logic card.
3. Remove the large gear on the left side frame by prying it from behind with a flat-blade screwdriver.
4. Remove the support shaft screw and the two platen screws from the left side frame.
5. Remove the right side frame.
6. Remove the paper guide/platen assembly.

Paper Select lever removal

1. Remove the top cover. See [“Top cover removal” on page 4-5.](#)
2. Release the latch, and then remove the Paper Select lever from the right side frame.


Paper Select sensor removal

1. Remove the top cover. See [“Top cover removal” on page 4-5](#).
2. Remove the print unit. See [“Print unit removal” on page 4-29](#).
3. Use a #1 Phillips screwdriver to remove the two screws (1) holding the Paper Select sensor to the left side frame.




Paper separator removal


1. Remove the top cover. See [“Top cover removal”](#) on page 4-5.
2. Remove the print unit from the base. See [“Print unit removal”](#) on page 4-29.
3. Remove the Paper Select lever.
4. Remove the gear shaft support plate and the two gears with their springs (1).
5. Remove the large screw (2) holding the tension pulley plate to the side frame.



6. Release and remove the separator plate spring (3) from the right side frame.
7. Remove the paper separator screw (4) from above the slider cam.
8. Remove the two carrier plate screws (5) from the right side frame. One is behind the slider cam.
9. Loosen several turns but do not remove the support shaft screw (6) and the two platen screws.



10. Wiggle the right side frame and pull it about 2 mm to the right.
11. Flex the front of the side frame outward slightly to free the right end of the paper separator (7).



12. Remove the paper separator.

Power supply removal

CAUTION: The power supply may be hot.

1. Turn off the printer and disconnect the power cord at both ends.
2. Remove the top cover. See ["Top cover removal" on page 4-5](#).
3. Disconnect the power connectors from the sub logic board and main logic board.
4. Remove the five mounting screws and the ground wire screw.
5. Lift the rear edge of the supply and remove it from the printer.


Power supply fan removal

1. Remove the power supply.
2. Remove the four screws holding the power supply board to the cover.
3. Pivot the board out of the cover far enough to disconnect the fan connector.
4. Remove the three screws holding the fan to the cover.


Print unit removal

1. Remove the top cover. See ["Top cover removal" on page 4-5](#).
2. Disconnect the tractor connector.
3. Disconnect the flexible signal cable and the power cable from the sub logic card.
4. Remove the ground leads from the four corners of the print unit.
5. Disconnect the following connectors from the main logic board: CN4, CN7, CN8, CN9, CN10, CN15, CN17, CN18, CN19, and CN20.
6. Remove the upper screw from the serial port card mounting bracket.

7. On the left side, remove the three screws (1) holding the print unit to the base.




8. On the right side, remove the screw (2) holding the print unit to the base.



4227-300

- Slide the printer partway off the edge of the table. From the bottom, remove the screw (3) holding the front of each side frame to the base.



- Lift the print unit from the base.

To Reinstall

For ease of reassembly, remove the flexible signal cable from the main logic board and connect it to the sub logic board before reinstalling the print unit.


Printhead removal

1. Turn the printer off.
2. Disconnect the power cord at the printer.

CAUTION: Allow the printhead to cool for 15 minutes.



3. Remove the ribbon cover and ribbon.
4. Remove the two screws (1) on the cable retainer and disconnect the two cables. These are ZIF connectors.
5. Remove the two screws (2) holding the printhead to the carrier, and then lift the printhead out.



To reinstall

1. Fold the printhead cables under the printhead to prevent the tension pulley plate from interfering with the cables.
2. Hold the printhead down while pressing it toward the platen, and then tighten the two printhead mounting screws.
3. Perform the **“Printhead-to-platen gap adjustment”** on page 4-2.

Printhead cables removal


1. Remove the top cover. See ["Top cover removal" on page 4-5.](#)
2. Remove the two screws on the cable retainer and disconnect the two cables. These are ZIF connectors.
3. Disconnect the other end of the cables from the sub logic board, and then pull the cables from under the ribbon motor.
4. The cables are attached to the carrier plate with double-faced tape.

To reinstall

Be sure the tension pulley plate does not interfere with the printhead cables.


Ribbon drive motor assembly removal

1. Remove the top cover. See **“Top cover removal”** on page 4-5.
2. Remove the sub logic board.
3. Remove the ribbon drive post cover and the ribbon drive post (1).
4. Remove the Auto Gap sensor (2) from the motor bracket.
5. Disconnect ribbon motor connector CN19 from the main logic board.
6. Remove the carrier motor bearing retainer and bearing (3) from the ribbon motor bracket.
7. Remove the three screws (4) holding the ribbon drive motor bracket, and then remove the ribbon drive motor assembly.




Right side frame removal


1. Remove the top cover. See **"Top cover removal"** on page 4-5.
2. Remove the print unit.
3. Remove the Paper Select lever.
4. Remove the gear shaft support plate (2) and the two gears with their springs (3).
5. Remove the large screw (4) holding the tension pulley plate to the side frame.
6. Remove the gear, clip, and bearing (5) from the end of the lower feed roller shaft.



7. Release and remove the separator plate spring (6).
8. Release the spring (7) from the right end of the lower pinch roller.



9. Remove the two carrier plate screws (8). One is in the slot in the slider cam.
10. Remove the support shaft screw (9) and the two platen screws (10).



4227-300

11. Remove the right side frame.

Note: The upper feed roller bearing should stay in the side frame. The lower pinch roller bushing is free on the end of the shaft.

To reassemble

1. Install the side frame first, and then remove the paper separator. Be sure the lower pinch roller spring is above the bushing.
2. Remove the screw from the right end of the paper separator.
3. Install the left end of the paper separator first, and then bend the right side frame slightly to get the right end installed.
4. Reinstall the separator screw through the hole above the slider cam.
5. Set the printhead to platen gap.

Sub logic board removal


1. Remove the top cover. See ["Top cover removal" on page 4-5](#).
2. Disconnect the power connector and the signal connector from the sub logic board.
3. Remove the three screws.
4. Disconnect the printhead cables and remove the sub logic board.

To reinstall

For ease of reassembly, remove the flexible signal cable from the main logic board and connect it to the sub logic board before you reinstall the sub logic board. Remember to reconnect the ground lead to the bottom mounting screw.

Upper feed roller removal

1. Remove the top cover. See **“Top cover removal”** on page 4-5.
2. Release the latches and remove the gear (1) from the left end of the shaft.



3. Remove the clip from the left end.
4. Slide the shaft to the left, making sure the right bearing comes out of the side frame with the shaft.
5. Lift the shaft out to the right. Be sure not to lose the bearings; they are both free to come off the shaft.

5. Preventive maintenance

This chapter describes procedures for preventive maintenance for the printer. Following these recommendations can help prevent problems and maintain optimum performance.

Lubrication

Warning: Petroleum-based lubricants can attack polycarbonate parts, causing premature failure. Use only mineral oil-based lubricant.

The following parts should be lubricated when replaced:

- Oil felt (carrier block)
- Tractor unit
- Side frame (left)
- Side frame (right)
- Pinch roller (lower)
- Pinch roller spring (left)
- Pinch roller spring (center)
- Pinch roller spring (right)
- Paper separator

Specified lubricants

- Oil—P/N 1280443
- Approved equivalents:
 - Mobil DTE27
 - Shell Tellus 100
 - Fuchs Renolin MR30
- Grease—P/N 6934659
- Approved equivalent:
Mobil 28

Lubrication points

Oil

Lubricate the following contact positions:

- Oil felt on carrier shaft (under carrier)
- Square tractor shaft, where left end enters left tractor side frame


Grease

Lubricate the following contact positions:

- Two gear mounting studs on the right side frame
- ASF gear mounting stud on the right gear plate
- Slider cam and sub slider cam on the right side frame
- Mounting stud for large spur gear on left side frame
- Mounting studs for Auto Gap gears
- Lower pinch roller and ground spring
- Right ASF side frame studs and all gears
- Left ASF side frame studs and upper feed roll shaft
- ASF pick-up roller Shaft and L & R roller bushings
- Tractor 2 right side frame studs and all gears


6. Locations and connectors

4227-300



Main Logic Board Connectors

Connectors	Description
CN1	Parallel Serial Port
CN3	Sub Logic Board Flex Cable
CN4	Paper Select Sensor
CN7	Paper Empty and TOF Sensors
CN8	Gap Home Sensor
CN9	Carrier Motor Cable #1
CN10	Paper Feed Motor
CN11	Power Supply
CN13	Tractor 2 DIN
CN14	Operator Panel
CN15	Carrier Motor Cable #2
CN17	Carrier Motor Cooling Fan
CN18	Tractor PSet & Jam Sensors
CN19	Ribbon Motor
CN20	Auto Gap Motor
CN22	Serial Port
CN23	Serial Interface 5 V dc



CN1	Printhead
CN2	Printhead
CN3	Main Logic Board Flex Cable
CN4	Power Supply

Operator panel connectors



CN1	Ribbon Cover Sensor
CN2	LCD Board (soldered)
CN3	Main Logic Board

Component locations



This chapter shows the location of specific parts of the printer.

Part name	Ref.	Part name	Ref.
Auto Gap Motor	W	Parallel/Serial Interface Connector	Y
Auto Gap Sensor	V	Platen	B
Carrier	P	Power Supply	BB
Carrier Motor	K	Printhead	Q
Carrier Plate	I	Printhead Cables	C
Jam Sensor	R	PSet Sensor	S
Left Side Frame	L	Ribbon Drive Motor	U
Lower Feed Roller	M	Ribbon Drive Post	T
Lower Pinch Roller	N	Right Side Frame	D
Main Logic Board	AA	RS232/RS422 Switch	Z
Paper Empty Sensor	DD	Sub Logic Board	A
Paper Feed Motor	X	Tension Pulley Plate	E
Paper Select Lever	F	TOF Sensor	CC
Paper Select Sensor	J	Tractor Unit	G
Paper Separator	H	Upper Feed Roller	O

Component location illustrations



Component location illustrations (Continued)



Signal connections

Power Supply ->Main Logic Board<-->Sub Logic Board

Power Supply	Main Logic Board CN11	Sub Logic Board CN4 - 4227-300
+40 V dc	Pin 1 +40 V dc	Pin 1 +40 V dc
+40 V dc	Pin 2 +40 V dc	Pin 2 +40 V dc
Power Gnd	Pin 3 Power Gnd	Pin 3 Power Gnd
Power Gnd	Pin 4 Power Gnd	Pin 4 Power Gnd
+5 V dc	Pin 5 +5 V dc	Pin 5 +5 V dc
Signal Gnd	Pin 6 Signal Gnd	Pin 6 Signal Gnd

Main Logic Board<-->Parallel Interface Cable

Main Logic Board CN1			
Pin 1	Strobe	Pin 19	Signal Gnd
Pin 2	Data1	Pin 20	Signal Gnd
Pin 3	Data2	Pin 21	Signal Gnd
Pin 4	Data3	Pin 22	Signal Gnd
Pin 5	Data4	Pin 23	Signal Gnd
Pin 6	Data5	Pin 24	Signal Gnd
Pin 7	Data6	Pin 25	Signal Gnd
Pin 8	Data7	Pin 26	Signal Gnd
Pin 9	Data8	Pin 27	Signal Gnd
Pin 10	-Acknlg	Pin 28	Signal Gnd
Pin 11	Busy	Pin 29	Signal Gnd
Pin 12	PE	Pin 30	Signal Gnd
Pin 13	Select	Pin 31	-INIT
Pin 14	-AF	Pin 32	-Error
Pin 15	NC	Pin 33	Signal Gnd
Pin 16	Signal Gnd	Pin 34	NC
Pin 17	Chassis Gnd	Pin 35	+5 V dc
Pin 18	+5 V dc	Pin 36	-SE

Main Logic Board<-->Sub Logic Board

Main Logic Board CN3		Sub Logic Board CN3	
Pin 1	HCSEL	Pin 22	HCSEL
Pin 2	Signal Gnd	Pin 21	Signal Gnd
Pin 3	HDTHERMO	Pin 20	HDTHERMO
Pin 4	R1COM	Pin 19	R1COM
Pin 5	L1COM	Pin 18	L1COM
Pin 6	R2COM	Pin 17	R2COM
Pin 7	L2COM	Pin 16	L2COM
Pin 8	L3COM	Pin 15	L3COM
Pin 9	R3COM	Pin 14	R3COM
Pin 10	L4COM	Pin 13	L4COM
Pin 11	R4COM	Pin 12	R4COM
Pin 12	L5COM	Pin 11	L5COM
Pin 13	R5COM	Pin 10	R5COM
Pin 14	L6COM	Pin 9	L6COM
Pin 15	R6COM	Pin 8	R6COM
Pin 16	L7COM	Pin 7	L7COM
Pin 17	R7COM	Pin 6	R7COM
Pin 18	L8COM	Pin 5	L8COM
Pin 19	L8COM	Pin 4	R8COM
Pin 20	L9COM	Pin 3	L9COM
Pin 21	R9COM	Pin 2	R9COM
Pin 22	BUZZER	Pin 1	BUZZER

Main Logic Board<-->Paper Select Sensor

CN4	
Pin 1	Not Used
Pin 2	Signal Gnd
Pin 3	FRETRA
Pin 4	Signal Gnd

Main Logic Board<-->Paper Empty & TOF Sensors

CN7	
Pin 1	PE1P
Pin 2	PE1
Pin 3	Signal Gnd
Pin 4	PE2P
Pin 5	PE2
Pin 6	Signal Gnd

Main Logic Board<-->Auto Gap Sensor

CN8	
Pin 1	+5 V dc
Pin 2	AGHPC
Pin 3	AGHP

Main Logic Board<-->Carrier Motor Cable #1

CN9	
Pin 1	CA+
Pin 2	CA-

Main Logic Board<-->Paper Feed Motor

CN10	
Pin 1	FDO
Pin 2	FDC
Pin 3	FDB
Pin 4	FDA
Pin 5	FDCOM
Pin 6	FDCOM

Main Logic Board<-->Tractor 2 DIN

CN13	
Pin 1	+26Vdc
Pin 2	+26Vdc
Pin 3	Power Gnd
Pin 4	PSET
Pin 5	+5Vdc
Pin 6	DTCOM
Pin 7	DSET
Pin 8	Signal Gnd
Pin 9	DTMTA
Pin 10	DTMTB
Pin 11	JAM
Pin 12	DHP
Pin 13	DPOS

Main Logic Board<-->Carrier Motor Cooling Fan

CN17	
Pin 1	Fan+
Pin 2	Fan-

Main Logic Board<-->5 V dc Power

CN23	
Pin 1	Signal Gnd
Pin 2	+5 V dc

Main Logic Board<-->Operator Panel

Main Logic Board CN14	Operator Panel Board CN3
Pin 1 +5Vdc	Pin 1 +5 V dc
Pin 2 SLATCH	Pin 2 SLATCH
Pin 3 +5Vdc	Pin 3 +5 V dc
Pin 4 TXD	Pin 4 TXD
Pin 5 Signal Gnd	Pin 5 Signal Gnd
Pin 6 RXD	Pin 6 RXD
Pin 7 Signal Gnd	Pin 7 Signal Gnd
Pin 8 SCLK	Pin 8 SCLK
Pin 9 Signal Gnd	Pin 9 Signal Gnd
Pin 10 LLATCH	Pin 10 LLATCH

Main Logic Board<-->Carrier Motor Cable #2

CN15	
Pin 1	+5Vdc
Pin 2	EA
Pin 3	Gnd
Pin 4	EB
Pin 5	Gnd
Pin 6	CATHM
Pin 7	Not Used

Main Logic Board<-->Tractor PSet & Jam Sensors

CN18	
Pin 1	TRPSS
Pin 2	TRPSG
Pin 3	TRJMP
Pin 4	TRJAM
Pin 5	TRJMG
Pin 6	DSET

Main Logic Board<-->Ribbon Motor

CN19	
Pin 1	RBD
Pin 2	RBC
Pin 3	RBB
Pin 4	RBA
Pin 5	RBCOM
Pin 6	RBCOM

Main Logic Board<-->Auto Gap Motor

CN20	
Pin 1	GPD
Pin 2	GPB
Pin 3	GPC
Pin 4	GPA
Pin 5	GPCOM
Pin 6	GPCOM

Main Logic Board<-->Serial Board

Main Logic Board CN22		Serial Board CN2	
Pin 1	+TXD422	Pin 12	+TXD422
Pin 2	-RXD422	Pin 11	-RXD422
Pin 3	+RXD422	Pin 10	+RXD42
Pin 4	-TXD422	Pin 9	-TXD422
Pin 5	DTR	Pin 8	DTR
Pin 6	Signal Gnd	Pin 7	Signal Gnd
Pin 7	DSR	Pin 6	DSR
Pin 8	-CTS	Pin 5	-CTS
Pin 9	RTS	Pin 4	RTS
Pin 10	RXD	Pin 3	RXD
Pin 11	TXD	Pin 2	TXD
Pin 12	SBSET	Pin 1	SBSET

Serial Board<-->Serial Cable

CN1			
Pin 1	Chassis Gnd	Pin 14	NC
Pin 2	TXD	Pin 15	-RXD422
Pin 3	RXD	Pin 16	NC
Pin 4	RTS	Pin 17	+RXD422
Pin 5	-CTS	Pin 18	NC
Pin 6	DSR	Pin 19	-TXD422
Pin 7	Signal Gnd	Pin 20	DTR
Pin 8	NC	Pin 21	NC
Pin 9	NC	Pin 22	NC
Pin 10	NC	Pin 23	NC
Pin 11	NC	Pin 24	NC
Pin 12	NC	Pin 25	+TXD422
Pin 13	NC		

Sub Logic Board<-->Printhead

CN1		CN2	
Pin 1	RH8	Pin 1	RH3
Pin 2	RH8C	Pin 2	RH3C
Pin 3	RH7	Pin 3	RH2
Pin 4	RH9C	Pin 4	RH4C
Pin 5	RH6	Pin 5	RH1
Pin 6	RH9	Pin 6	RH5C
Pin 7	RH7C	Pin 7	RH2C
Pin 8	+5 V dc	Pin 8	RH4
Pin 9	RH6C	Pin 9	RH1C
Pin 10	HDTHERMO	Pin 10	RH5
Pin 11	LH6C	Pin 11	LH1C
Pin 12	LH9	Pin 12	LH5
Pin 13	LH7C	Pin 13	LH2C
Pin 14	LH8	Pin 14	LH4
Pin 15	LH6	Pin 15	LH1
Pin 16	LH9C	Pin 16	LH5C
Pin 17	LH7	Pin 17	LH2
Pin 18	LH8C	Pin 18	LH4C
		Pin 19	LH3
		Pin 20	LH3C

Operator Panel Board<-->Ribbon Cover Sensor

CN1	
Pin 1	C-Open
Pin 2	Signal Gnd


Tractor 2 cable connectors

The Tractor 2 cable is soldered to the board at CN1.

Pin	Mode
CN1-1	+26 V dc
CN1-2	+26 V dc
CN1-3	Frame Gnd
CN1-4	Not used.
CN1-5	+5 V dc
CN1-6	Motor Common
CN1-7	D-Set (signal for Tractor 2 plugged in)
CN1-8	Signal Gnd
CN1-9	Motor Phase A; 0 V dc when Tractor 2 not in use; 0 V dc when Tractor 2 is in use.
CN1-10	Motor Phase B; +5 V dc when Tractor 2 not in use; 0 V dc when Tractor 2 is in use.
CN1-11	Not used.
CN1-12	Slider Home Sensor; +5 V dc when open, 0 V dc when closed.
CN1-13	Tractor 2; +5 V dc when open, 0 V dc when closed.

Connector block diagram

4227-300




7. Parts catalog

How to use this parts catalog

- **Similar Assemblies:** If two assemblies contain a majority of identical parts, they are shown on the same list. Common parts are shown by one index number. Parts peculiar to one or the other of the assemblies are listed separately and identified by description.
- **AR:** (As required) in the Units column indicates that the quantity is not the same for all machines.
- **NP:** (Non-procurable) in the Units column indicates that the part is non-procurable and that the individual parts or the next higher assembly should be ordered.
- **NR:** (Not recommended) in the Units column indicates that the part is procurable but not recommended for field replacement, and that the next higher assembly should be ordered.
- **R:** (restricted) in the Units column indicates that the part has a restricted availability.
- **NS:** (Not shown) in the Asm-Index column indicates that the part is procurable but is not pictured in the illustration.
- **PP:** (Parts packet) in the Description column indicates that the part is contained in a parts packet.


Assembly 1: Covers and operator panel



4227-300

Asm-Index	Part number	Description
1-1	40X3045	Cover assembly, ribbon access
2	40X3051	Cover, acoustic
3	40X3130	Paper stand
4	40X3050	Switch assembly, cover with cover switch plate
5	40X3118	Cover, rear (4227--300)
6	40X3043	Cover assembly, front (complete)
7	40X3126	Guide, paper (right)
8	40X3131	Guide, cover (front)
9	40X3106	Cover assembly with logo (top)
10	40X3094	Overlay kit, operator panel
11	40X3048	Operator panel assembly with English overlay
12	40X3049	Cable, operator panel


Assembly 2: Paper feed



4227-300

Asm- Index	Part number	Description
2-1	40X3073	Feed roller, upper
2	40X3098	Bearing kit
3	40X3075	Frame support shaft
4	40X3082	TOF & Paper Empty sensors with flags & springs
5	40X3081	Paper guide/platen assembly
6	40X3121	Bracket, Auto Gap motor
7	40X3083	Roller, feed (lower)
8	40X3132	Roller, pinch (lower)
9	40X3113	Side frame assembly (left)
10	40X3079	Sensor, Paper Select
11	40X3097	Gear kit
12	40X3074	Separator, paper
13	40X3078	Latch, ribbon
14	40X3080	Side frame assembly (right)
15	40X3096	Screw, parts packet
16	40X3099	Spring kit
17	40X3072	Plate, carrier
18	40X3052	Tractor side frame (left)
19	40X3053	Tractor side frame (right)
20	40X3097	Gear kit
21	40X3054	Tractor pair with sensors (left and right)
22	40X3055	Shaft kit, tractor
23	40X2905	Paper Guide, tractor
24	40X3120	Carrier motor cooling fan


Assembly 3: Carrier



4227-300

Asm-Index	Part number	Description
3-1	40X3071	Sensor, Auto Gap
2	40X3107	Board and bracket, sub logic
3	40X3096	Screw, parts packet
4	40X3057	Motor, paper feed assembly with bracket
5	40X3098	Bearing kit
6	40X3105	Gears, parts packet
7	40X3062	Motor, ribbon drive and gear plate assembly
9	40X3063	Plate assembly with belt tension pulley
10	40X3112	Motor, Auto Gap
11	40X3132	Roller, lower pinch
12	40X3099	Spring kit
13	40X3122	Bracket, carrier motor
14	40X3123	Motor, carrier assembly
15	40X3117	Cable, printhead and retainer
16	40X3037	Cam, release slider
17	40X3038	Cam, sub slider
18	40X3116	Printhead
19	40X3066	Roller and spring, carrier
20	40X3124	Carrier asm. with belt & head cooling gum
21	40X3065	Shaft, carrier
22	40X3070	Lever, Paper Select
23	40X3056	Gear plate (right)
24	40X3108	Cable, sub logic board
NS	40X3138	Gear cover (left)


Assembly 4: Base and electronics



4227-300

Asm-Index	Part number	Description
4-1	40X3110	Main logic board without ROM (LV)
1	40X3109	Main logic board without ROM (HV)
2	40X3119	ROM kit
3	40X3125	Power supply, 100 - 240 V ac
4	40X3990	Ground wire
5	40X3092	Bracket, tractor cable
6	40X3091	Cable, tractor
7	40X3084	Base assembly
8	40X0297	Power cord (U.S., Canada, AFE (LV), Saudi Arabia (LV), Central and South America, Mexico)
8	40X0270	Power cord (Japan)
8	40X0271	Power cord (United Kingdom, Malaysia, Singapore)
8	40X3141	Power cord (Germany, France, Spain, Norway, Finland, Netherlands, Austria, Belgium, Brazil, Greece, Luxembourg, Portugal, Sweden, Turkey, Saudi Arabia (HV), Indonesia)
8	40X0294	Power cord (Denmark)
8	40X0273	Power cord (Italy and Chile)
8	40X0275	Power cord (Israel)
8	40X2904	Power cord (Japan)
8	40X0276	Power cord (South Africa)
8	40X0274	Power cord (Switzerland)
8	40X0296	Power cord (Australia, New Zealand, Argentina, Paraguay)
8	40X1766	Power cord (Peru)
9	40X3096	Screw and clip kit
NS	40X3114	Serial port card and bracket asm.
NS	40X3111	Torroid
NS	40X3115	Serial port card to main logic board cable
NS	40X3104	Paper guide Mylar strip
NS	40X3086	Fuse, power supply
NS	40X3087	Fan, power supply
NS	40X3103	Main logic card dust cover


Assembly 5: ASF side frame/covers



4227-300

Asm-Index	Part number	Description
5-1	40X3137	Support, stacking
2	40X3033	Cover (front)
3	40X2891	Spring kit, ASF
4	40X3136	Gear and bearing kit, ASF
5	40X2892	Screw kit, ASF
6	40X3135	Cover (right)


Assembly 6: ASF roller/support



4227-300

Asm-Index	Part number	Description
6 -1	40X3040	Support, cut sheet with guides
2	40X3023	Roller, feed (upper)
3	40X3024	Roller, feed (lower)
4	40X2985	Roller, pickup (left and right)
5	40X3128	Hopper (left)
6	40X2928	Support, paper (left)
7	40X3133	Support, paper (center)
8	40X3127	Hopper (right)
9	40X2927	Support, paper (right)
10	40X3134	Cover (left)
11	40X3136	Gear and bushing kit, ASF
12	40X2891	Spring kit, ASF
13	40X2892	Screw kit, ASF
14	40X2891	Spring

Assembly 7: Tractor 2 option



4227-300

Asm-Index	Part number	Description
7 -1	40X3033	Cover (front)
2	40X2881	Paper guide, tractor
3	40X3093	Tractor and frame assembly
4	40X3095	Tractor kit (left and right) with sensors
5	40X2882	Parts packet
6	40X2959	Shaft, Support
7	40X2961	Board Asm with cable and Ferrite
8	40X3039	Cover (right)
9	40X2880	Motor

4227-300

Index

A

- Abbreviations 1-4
- Adjustments 4-2
 - Bidirectional Print 4-3
 - Printhead-to-Platen 4-2
- ASF
 - Principles of Operation 2-13

B

- Bidirectional Print Adjustment 4-3
- Buttons 1-10

C

- Component Locations 6-4
- Connector Locations 6-1, 6-5, 6-7
- Connectors
 - Main Logic Board 6-2
 - Operator Panel 6-3

D

- Diagnostic Aids 3-1
 - Button Test 3-4
 - Error Log 3-5
 - Factory Setting 3-4
 - Hex Trace Mode 3-2
 - Impact Force 3-4
 - Interface Selection 3-3
 - Jam/PSet Sensor Test 3-4
 - Log Clear 3-4
 - Other Print Tests 3-5
 - POST 3-1
 - Print Test 3-5
 - Printhead Bank Test 3-4
 - Service Menu 3-3

E

- ESD-sensitive parts 4-1

F

- Function Menus 1-6

H

- Handling ESD-sensitive parts 4-1

L

- Lights 1-11
- Lubricants 5-1
- Lubrication 5-1
- Lubrication Points 5-2

M

- Models available 1-1

O

- Operator Panel, Using 1-5
- Options 1-3

P

- Parts Catalog
 - ASF Roller/Support 7-12
 - ASF Side Frame / Covers 7-10
 - Base 7-8
 - Carrier 7-6
 - Covers 7-2
 - Electronics 7-8
 - How to use 7-1
 - Operator Panel 7-2
 - Paper Feed 7-4
 - Tractor 2 Option 7-14
- Power-On Self Test (POST) 3-1
- Preventive Maintenance 5-1
 - Lubrication 5-1
 - Lubrication Points 5-2
 - Specified Lubricants 5-1

R

- Removal Procedures 4-5
- Removals
 - ASF Gears 4-9
 - ASF Pick-up Roller 4-10
 - Auto Gap Motor 4-8

4227-300

- Carrier 4-12
- Carrier Motor Assembly 4-15
- Carrier Plate 4-16
- Jammed Label 4-16
- Label Jam 4-16
- Lower Feed Roller 4-17
- Main Logic Board 4-21
- Memory Module 4-22
- Operator Panel 4-22
- Paper Empty Sensor 4-22
- Paper Feed Motor 4-25
- Paper Guide 4-25
- Paper Guide/Platen 4-25
- Paper Select Lever 4-25
- Paper Select Sensor 4-26
- Paper Separator 4-27
- Pinch Roller (Lower) 4-21
- Power Supply 4-29
- Power Supply Fan 4-29
- Print Unit 4-29
- Printhead 4-32
- Printhead Cables 4-33
- Ribbon Drive Motor 4-34
- Right Side Frame 4-35
- Sub Logic Board 4-37
- TOF Sensor 4-22
- Top Cover 4-5
- Upper Feed Roller 4-38

S

- Safety information vi
- Service Checks 2-11
 - Abnormal Print 2-19
 - ASF Auto Sheet Feeder 2-13
 - Auto Gap 2-11
 - Auto Sheet Feeder 2-13
 - Carrier Drive 2-15
 - Intermittent Problem 2-16
 - No Print 2-19
 - Operator Panel 2-20
 - Paper Feed 2-21
 - POST 2-24
 - Power Failure 2-25
 - Print Quality 2-27

- Print Wire Drive Failure 2-28
- Ribbon Drive 2-30
- Tractor 2 2-31
- Setting Printer Functions 1-7
- Signal Connections 6-7
 - Block Diagram (4227-300) 6-16
- Main Logic Board
 - Auto Gap Motor 6-12
 - Auto Gap Sensor 6-9
 - Carrier Motor Cable #1 6-9
 - Carrier Motor Cable #2 6-11
 - Carrier Motor Cooling Fan (4227-300) 6-10
 - Operator Panel 6-11
 - Paper Empty & TOF Sensors 6-9
 - Paper Feed Motor 6-9
 - Paper Select Sensor 6-8
 - Parallel Interface Cable (4227-300) 6-7
 - Ribbon Motor 6-12
 - Serial Board (4227-300) 6-12
 - Sub Logic Board (4227-300) 6-8
 - Tractor PSet & Jam Sensors 6-11
 - Tractor 2 DIN 6-10
 - 5 V dc Power (4227-300) 6-10

- Operator Panel Board - Ribbon Cover Sensor 6-14
- Power Supply-Main & Sub Logic Board 6-7
- Serial Board - Serial Cable (4227-300) 6-13
- Sub Logic Board
 - Printhead (4227-300) 6-14
- Symptom Checks
 - Abnormal Indications 2-4
 - Abnormal Print Problems 2-4
 - ASF Problems 2-5
 - Operator Panel Problems 2-8
 - Paper Feed Problems 2-6
 - Power Problems 2-8
 - Print Quality Problems 2-9
 - 6XX Error Indications 2-5

T

Tests

Button Test 3-4

Jam / PSet Sensor Test 3-4

Print Test 3-5

Printhead Bank Test 3-4

U

Using the Operator Panel 1-5

Part number index

P/N	Description	Page
40X0270	Power cord (Japan)	7-9
40X0271	Power cord (United Kingdom, Malaysia, Singapore)	7-9
40X0273	Power cord (Italy and Chile)	7-9
40X0274	Power cord (Switzerland)	7-9
40X0275	Power cord (Israel)	7-9
40X0276	Power cord (South Africa)	7-9
40X0294	Power cord (Denmark)	7-9
40X0296	Power cord (Australia, New Zealand, Argentina, Paraguay)	7-9
40X0297	Power cord (U.S., Canada, AFE (LV), Saudi Arabia (LV), Central and South America, Mexico)	7-9
40X1766	Power cord (Peru)	7-9
40X2880	Motor	7-15
40X2881	Paper guide, tractor	7-15
40X2882	Parts packet	7-15
40X2891	Spring	7-13
40X2891	Spring kit, ASF	7-11, 7-13
40X2892	Screw kit, ASF	7-11, 7-13
40X2904	Power cord (Japan)	7-9
40X2905	Paper Guide, Tractor	7-5
40X2927	Support, paper (right)	7-13
40X2928	Support, paper (left)	7-13
40X2959	Shaft, Support	7-15
40X2961	Board Asm with cable and Ferrite	7-15
40X2985	Roller, pickup (left and right)	7-13
40X3023	Roller, feed (upper)	7-13
40X3024	Roller, feed (lower)	7-13
40X3033	Cover (front)	7-11, 7-15
40X3037	Cam, release slider	7-7
40X3038	Cam, sub slider	7-7
40X3039	Cover (right)	7-15
40X3040	Support, cut sheet with guides	7-13
40X3043	Cover assembly, front (complete)	7-3
40X3045	Cover assembly, ribbon access	7-3
40X3048	Operator panel assembly with English overlay	7-3
40X3049	Cable, operator panel	7-3
40X3050	Switch assembly, cover with cover switch plate	7-3
40X3051	Cover, acoustic	7-3
40X3052	Tractor side frame (left)	7-5
40X3053	Tractor side frame (right)	7-5
40X3054	Tractor pair with sensors (left and right)	7-5
40X3055	Shaft kit, tractor	7-5

4227-300

40X3056	Gear plate (right)	7-7
40X3057	Motor, paper feed assembly with bracket	7-7
40X3062	Motor, ribbon drive and gear plate assembly	7-7
40X3063	Plate assembly with belt tension pulley	7-7
40X3065	Shaft, carrier	7-7
40X3066	Roller and spring, carrier	7-7
40X3070	Lever, Paper Select	7-7
40X3071	Sensor, Auto Gap	7-7
40X3072	Plate, carrier	7-5
40X3073	Feed roller, upper	7-5
40X3074	Separator, paper	7-5
40X3075	Frame support shaft	7-5
40X3078	Latch, ribbon	7-5
40X3079	Sensor, Paper Select	7-5
40X3080	Side frame assembly (right)	7-5
40X3081	Paper guide/platen assembly	7-5
40X3082	TOF & Paper Empty sensors with flags & springs	7-5
40X3083	Roller, feed (lower)	7-5
40X3084	Base assembly	7-9
40X3086	Fuse, power supply	7-9
40X3087	Fan, power supply	7-9
40X3091	Cable, tractor	7-9
40X3092	Bracket, tractor cable	7-9
40X3093	Tractor and frame assembly	7-15
40X3094	Overlay kit, operator panel	7-3
40X3095	Tractor kit (left and right) with sensors	7-15
40X3096	Screw and clip kit	7-9
40X3096	Screw, parts packet	7-5, 7-7
40X3097	Gear kit	7-5
40X3098	Bearing kit	7-5, 7-7
40X3099	Spring kit	7-5, 7-7
40X3103	Main logic card dust cover	7-9
40X3104	Paper guide Mylar strip	7-9
40X3105	Gears, parts packet	7-7
40X3106	Cover assembly with logo (top)	7-3
40X3107	Board and bracket, sub logic	7-7
40X3108	Cable, sub logic board	7-7
40X3109	Main logic board without ROM (HV)	7-9
40X3110	Main logic board without ROM (LV)	7-9
40X3111	Torroid	7-9
40X3112	Motor, Auto Gap	7-7
40X3113	Side frame assembly (left)	7-5
40X3114	Serial port card and bracket asm.	7-9
40X3115	Serial port card to main logic board cable	7-9
40X3116	Printhead	7-7
40X3117	Cable, printhead and retainer	7-7
40X3118	Cover, rear (4227--300)	7-3

40X3119	ROM kit	7-9
40X3120	Carrier motor cooling fan	7-5
40X3121	Bracket, Auto Gap motor	7-5
40X3122	Bracket, carrier motor	7-7
40X3123	Motor, carrier assembly	7-7
40X3124	Carrier asm. with belt & head cooling gum	7-7
40X3125	Power supply, 100 - 240 V ac	7-9
40X3126	Guide, paper (right)	7-3
40X3127	Hopper (right)	7-13
40X3128	Hopper (left)	7-13
40X3130	Paper stand	7-3
40X3131	Guide, cover (front)	7-3
40X3132	Roller, lower pinch	7-7
40X3132	Roller, pinch (lower)	7-5
40X3133	Support, paper (center)	7-13
40X3134	Cover (left)	7-13
40X3135	Cover (right)	7-11
40X3136	Gear and bearing kit, ASF	7-11
40X3136	Gear and bushing kit, ASF	7-13
40X3137	Support, stacking	7-11
40X3138	Gear cover (left)	7-7
40X3141	Power cord (Germany, France, Spain, Norway, Finland, Netherlands, Austria, Belgium, Brazil, Greece, Luxembourg, Portugal, Sweden, Turkey, Saudi Arabia (HV), Indonesia)	7-9
40X3990	Ground wire	7-9

