

ALLEN & HEATH



WARNING – HIGH VOLTAGES

Power Supply Unit (PSU) work should only be carried out by qualified personnel.

We recommend that you use an approved Allen & Heath service centre for all power supply work.

Please contact your local Allen & Heath distributor for more details.

<http://www.allen-heath.com/>

SERVICE ACCESS

ACCESS TO MIXER CIRCUITS

To implement any User Options, you will need to gain access to the internal circuit cards, The various jumper links later defined are located on those cards. Follow the outlined procedure to safely open the Scepter mixer.

The Scepter is composed of individual glass-epoxy circuit cards secured to a silk-screened aluminum front panel. A steel rear panel is secured to the rear of the circuit cards by numerous jack nuts. This sub-assembly (i.e. Front panel, Circuit cards and Rear Panel) is then inserted into a steel chassis. Eight 6x32 front panel counter-sunk screws and eight 6x32 rear panel screws hold both assemblies together. The front carrying handles also hold the two assemblies together with four 10x32 screws.

In order to get to the jumper links, you will have to first remove the Front panel/Circuit card/Rear panel sub-assembly from the chassis and then remove the Rear panel from the Circuit cards. The jumper links will then be accessible. NOTE: If you need to change only the Master options (Mono or Stereo Out Jumpers) then the Rear panel **DOES NOT** have to be separated from the Circuit cards. Eliminate step 2 and proceed as far as step 7.

DISASSEMBLY

Perform all work on a soft surface to prevent undue scratching of the Scepter unit.


- 1 Place the Scepter face down (resting on its handles) on a soft surface
- 2 Loosen (do not remove yet) the black plastic nuts from the 1/4" jacks.
- 3 Remove the 8 panel screws securing the Rear panel to the chassis.
- 4 Turn the Scepter over and remove the 8 countersunk screws securing the Front panel to the Chassis. At this point the Handles screws are the only fasteners holding the Front panel Assembly to the Chassis.
- 5 Support the Scepter on its front, but without using the handles for support. Use a foam block or similar item 2" or greater in height to clear the handles.
- 6 Remove the 4 countersunk handle screws. Hold onto the handles when performing this step to prevent them from rotating and possibly scratching the Front panel.
- 7 Lift the Chassis off the Front panel assembly.
At this point you may make changes to the Master jumper links. The remaining steps should only be performed if you need to remove the Rear panel. (This is necessary if Input or L/R jumper links have to be changed or if servicing needs

to be carried out.

- a Free the DC power XLR-5 pin insert from its metal shell by using a small screwdriver to loosen the XLR setscrew (anti-clockwise). The insert can then be pulled out the back of the XLR shell. The DC wires to the Master card will remain attached to the insert.
- 9 Remove the loosened plastic nuts from the **1/4"** jacks.
- 10 Remove the 2 fixing screws from each XLR jack.
- 11 Lift the Rear panel off the circuit cards.

The Circuit cards are now accessible for changes to the jumper links or repair work. If the main IDC 20 way ribbon harness is removed for service, use care when it is replaced. Make sure that all pins on all Circuit cards are correctly inserted into the IDC sockets; it is easy to bend a pin or mistakenly shift over one pin when putting a socket on. When re-assembling the Scepter, follow the above steps in reverse order.

The diagram below shows a header and Jumper link arrangement.



USER CONFIGURED OPTIONS

There are a number of User options available on the Scepter mixer. They are implemented with removable jumper links that the user can move to different combinations of header pins; no soldering is necessary. (except for the left and right Stereo Return options).

To alter any of the User Configured Options you will have to gain access to the internal circuit cards. Please read the ACCESS TO MIXER CIRCUITS procedure in the SERVICE ACCESS section.

OPTION DESCRIPTIONS

Input Channel Options

Seven different options are available on each Input channel:

Direct Out	1 of 3 choices
Aux send source select	1 of 3 choices for each Aux
Pre-EQ source select	1 of 3 choices
Pre-EQ mute select	1 of 2 choices

Direct Out

Three choices are available for the Channel Direct Out. Normally the Direct Out is set to follow the Fader and Mute switch, however there may be situations when you may want the Direct Out to stay active even if the Channel is muted. This would allow you to use each input as an independent preamp. If the channel is muted, the signal would appear only at the Direct Out jack; the Aux sends and **L/R** pan feed would be cut.

1	Post-Fader/Post-Mute	The Direct Out follows the Channel fader and Mute switch. This option is factory set.
2	Post-Fader/Pre-Mute	The Direct Out follows the Channel fader but the Mute switch has no effect on the signal.
3	Pre-Fader/Pre-Mute	Neither the fader nor Mute switch affect the Direct out.

Channel Aux Send Source Select

Three choices are available for each of the four Auxiliary Sends. Aux A & B are set up as Monitor or Cue sends (Pre-EQ/Pre-Fader); Aux C & D are set as EFX sends (Post-Fader). Normally all Aux sends are muted along with the channel, but the Pre-EQ source can be set to ignore the Mute switch. (see Pre-Eq Mute/No mute section) The Pre-EQ can also be set to 1 of 3 different configurations (See Pre-EQ Source Select).

- | | | |
|---|------------|---|
| 1 | Pre-EQ | Aux Send signal follows Gain control only. Auxes A & B default factory setting. This source has 3 extra configuration options. (see Pre-Eq Source Select) |
| 2 | Pre-Fader | Aux Send follows the EQ and Mute switches; Fader level has no effect. Same signal as PFL. |
| 3 | Post-Fader | Aux Send follows Fader and Mute Switch. Used for Effect send. Auxes C & D default factory setting. |

Pre-EQ Source Select

Three choices are provided for the Pre-EQ source. Normally the Post-Insert/Post-HPF option is selected. The aux signal will be after any signal processing equipment you may have patched into the Channel Insert jack and also the channel High pass filtering. If you want the Aux send to be unaffected by the external equipment, select the Pre-Insert option. Likewise, choose the **Post-Insert/Pre-HPF** point if you want the Aux to have the effect but not have the High Pass Filtering.

- | | | |
|---|----------------------|--|
| 1 | Pre-Insert | Pre-EQ point is directly after the channel preamp section. Any external equipment will not affect the aux send signal. |
| 2 | Post Insert/Pre-HPF | Pre-EQ point follows any external equipment but is not affected by HPF switch. |
| 3 | Post Insert/Post HPF | Pre-EQ signal is after any external processing equipment and is affected by the HPF switch. This is the factory default setting. |

Pre-EQ Mute/No Mute

The Pre-EQ source (1 of 3 selected above) can be set to follow the Channel Mute switch or to ignore it. It is normally set to follow the mute. If you desire the source to be active even when the channel is muted, configure the No Mute option.

- | | | |
|---|----------------|--|
| 1 | Pre-EQ Mute | Pre-EQ source will mute with the Channel. This is the factory default setting. |
| 2 | Pre-EQ No Mute | Pre-EQ source will remain on even when the channel is muted. |

Left and Right Stereo Return Options

There are four 10k Ohm resistors (brown,black,orange) that can be set on each L/R card. These four resistors are located behind the two Aux controls. They select the source for the two Aux sends on each Stereo return. You have many variations, for each of the two Aux send sources.

If you select both a Left and Right source, the Aux will be a mono mix of the Stereo return.

- | | | |
|---|-----------------------|--|
| 1 | L-R return Pre-level | Aux sends A & B configured to follow the pre-level mono mix of left and right return. This is the factory default setting. |
| 2 | L-R return Post level | Aux sends A & B configured to follow after the post level mono mix of left and right return. |

If you want to change to Aux A Left only and Aux B Right only, remove the appropriate resistors. You may then configure the resistors for pre or post level for each aux send.

- | | | |
|---|-------------------------|---|
| 3 | Left return Pre-level | Aux sends A and/or B can be configured to follow the left return only. |
| 4 | Left return Post-Level | Aux sends A and/or B can be configured to follow just the left return after the level control and mute switch. |
| 5 | Right return Pre-level | Aux sends A and/or B can be configured to follow the right return only. |
| 6 | Right return Post-level | Aux sends A and/or B can be configured to follow just the right return after the level control and mute switch. |

Master Options

The user can choose the sources for both the Balanced MONO out XLR connector and the STEREO OUT 1/4" jack socket. These outputs are derived from some point in the main Left and Right audio path. The options are: Pre-Insert, **Post-Insert/Pre-Fader** and Post-Fader.

Normally both the Mono and Stereo outputs are set for Pre-Insert. This makes them independent of the main L & R faders and any processing equipment that is patched into the Left or Right Insert jacks.

- | | | |
|---|-----------------------|--|
| 1 | Mono Out Pre-Insert | Output is a mono mix of the main left & right pre-insert signal. This is the factory default setting. |
| 2 | Stereo Out Pre-Insert | Output is the main left & right pre-insert signal. Tip is left and Ring is right. This is the factory default setting. |

Configure the jumper links for Post Insert if you want the MONO and STEREO OUT signals to be affected by any external processing equipment patched into the L & R Inserts.

- | | | |
|---|------------------------|---|
| 3 | Mono Out Post Insert | Output is a mono mix of the main left & right post insert signal. The L & R fader levels have no effect. |
| 4 | Stereo Out Post Insert | Output is the main left & right post insert signal. Tip is left and Ring is right. The L & R fader levels have no effect. |

Configure the jumper links for Post-Fader to have both outputs follow the main L & R outputs.

- | | | |
|---|-----------------------|--|
| 5 | Mono Out Post Fader | Output is a mono mix of the main left & right post fader signal. Equivalent to a mono mix direct out. |
| 6 | Stereo Out Post Fader | Output is the main left & right post fader signal. Tip is left and Ring is right. Equivalent to a stereo direct out. |

The Mono Output header mixes the two selected sources together. The Stereo Out header routes the left source to the left out and the right source to the right out.

Two extra positions are available on the Stereo out header. These points are

brought out to holes in the circuit board allowing you to feed an Aux output or other signal to the Stereo Out. Solder a wire between the hole pad and the desired signal point and move the header to the Ext position.

OPTIONS TABLE

All the possible Scepter user options are listed in the table below with the factory defaults indicated with an X. Diagrams on the following pages show the Scepter circuit cards and where the various jumper links and default jumpers are located.

INPUT CHANNEL		L/R GROUP	
Direct Out	Post-Fader/Post-Mute X Post-Fdr/Pre-Mute Pre- Fader	Stereo Return Aux Feeds	
Aux A Source	Post-Fader Pre-Fader Pre-EQ X	Aux A Source (Mixes L & R)	Left Rtn: Post-Level Left Rtn: Pre-Level X Right Rtn: Post-Level Right Rtn: Pre-Level X
Aux B Source	Post-Fader Pre- Fader Pre-EQ X	Aux B Source (Nixes L & R)	Left Rtn: Post-Level Left Rtn: Pre-Level X Right Rtn: Post- Level Right Rtn: Pre-Level X
Aux C Source	Post-Fader X Pre-Fader Pre-EQ	MASTER	
Aux D Source	Post-Fader X Pre- Fader Pre-EQ	Mono Out (Mixes L & R)	Left: Pre-Insert X Left: Post Insert Left: Post-Fader Right: Pre-Insert X Right: Post Insert Right: Post- Fader
Pre-EQ Source	Post-Insert/Post-HPF X Post-Insert/Pre-HPF Pre-insert	Stereo Out Left	Left: Pre-Insert X Left: Post Insert Left: Post-Fader Ext PC Pad
Pre-EQ Mute	Mute With Channel X No Mute With Channel	Stereo Out Right	Right: Pre-Insert X Right: Post Insert Right: Post- Fader Ext PC Pad

CHASSIS GROUND LIFT

Normally the chassis of the Scepter is connected to the audio ground with a link on the DC Input connector.

The chassis can be lifted from the audio ground by removing this link.


This should not be confused with disconnecting the ground on an AC plug. The AC ground is a safety ground; it is there as protection from electrocution if some component should fail and cause an exposed surface to become live. The safety ground is designed to shunt this voltage to ground, causing the equipment or outlet fuse to blow. The Power supply chassis is attached to this AC ground since there are potentially hazardous voltages inside the case. The Scepter chassis and audio ground are isolated from this AC ground since the Power Supply feeds only low-voltage DC to the mixer. The Scepter chassis and audio ground are floating in respect to the AC ground; they will obtain their ground from the external equipment they are attached to.

In most rack situations, there are a number of grounds tied together via the metal rack rails. This can lead to ground loops which may cause hum in a system. These ground loops can be eliminated in many cases by isolating the equipment audio ground from this metal rail. If you need to isolate the Scepter chassis then follow the procedure outlined below:

The Scepter is also provided with Pin-1 lifts on all its Balanced outputs. In some cases lifting Pin 1 is all that is required to fix a ground loop problem.

Chassis-Audio Ground isolation procedure:


- 1 Release the DC Power connector from the rear panel by removing the 2 fixing screws
- 2 Carefully ease the connector out and locate the chassis lug (see diagram)
- 3 Locate the bare wire link that is attached to this lug (see diagram)
- 4 Cut this wire and dress it to prevent shorting.
- 5 Re-install the connector and screws.



SERVICE INFORMATION AND DIAGRAMS

MAIN RIBBON SIGNALS

TOP VIEW




VIEW ON PINS

MAIN RIBBON SIGNALS


PIN #	SIGNAL	PIN #	SIGNAL
1	AUX C MIX	2	AUX B MIX
3	AUX D MIX	4	AUX A MIX
5	PFL MIX	6	REF GROUND
7	RIGHT MIX	8	AUDIO GROUND
9	LEFT MIX	10	AUDIO GROUND
11	AUDIO GROUND	12	AUDIO GROUND
13	POWER GROUND	14	LED GROUND
15	PFL DC	16	+48 VOLTS
17	AUDIO +15 VOLTS	18	LED +15 VOLTS
19	AUDIO -15 VOLTS	20	LED -15 VOLTS


NOTE: The Silkscreen legends on the PCBs are in error (odds and evens are reversed). Pin ID locations are correct as shown above.

SCEPTER RACK MIXER - 10 RACK SPACES




MPS-8R POWER SUPPLY - 2 RACK SPACES








ALLEN & HEATH
 SCEPTER RACK BLOCK DIAGRAM ISSUE 2 OCT 89




ALLEN & HEATH
A60237 1513 95 REV 2


- INDICATES 1% MF RESISTOR
- □ INDICATES NEG CAP LEAD



SCEPTER INPUT PCB ISSUE 3 MAR 91
PARTS PLACEMENT & OPTION HEADER LOCATIONS
HEADERS SHOWN ON PCB WITH JUMPERS SET AT FACTORY DEFAULT.



DATE	COMMENTS	DRWN	CHKD
3/91	ISS 3 PCB. NEW PREAMP IC, XFORMR OPTION	JRP	JRP
10/89	ISS 2 PCB. BUFFERD PAN, NEW PAD & SIG PRSNT	JRP	JRP
11/88	ISS 1 PCB. PRODUCTION	JRP	JRP




UNIT TITLE
SCEPTER / VISION MIXER - INPUT SCHEMATIC

DRAWING TITLE
CIRCUIT DIAGRAM PCB AG0237 ISSUE 3


ALLEN & HEATH
 PROFESSIONAL AUDIO EQUIPMENT MANUFACTURERS

DRAWING NO. ISSUE



○ INDICATES NEG CAP LEAD



AUX SENDS FROM STEREO RETURN
 SELECT PRE OR POST LEFT AND RIGHT FOR EACH OF 2 SENDS
 LEFT AND RIGHT SIGNALS WILL BE MIXED FOR EACH SEND




SCPECTER LEFT/RIGHT PCB ISSUE 3 MAR 91
 PARTS PLACEMENT & OPTION HEADER LOCATIONS

HEADERS SHOWN ON PCB WITH JUMPERS SET AT FACTORY DEFAULT.

ODD RETURN IS LOCATED ON LEFT PCB
EVEN RETURN IS ON RIGHT PCB



UNLESS OTHERWISE NOTED:
ALL ELECT CAPS 25V VALUES IN UF OTHER VOLT CAPS SHOWN VALVOLTS
ALL DISC AND MYLAR CAPS RATED 50V OR HIGHER VALUES IN UF
ALL RESISTORS 1/4W 1% RES INDICATED WITH 3 DIGITS (E.G. 4K21)
ALL SWITCHES SHOWN DESELECTED
ALL DIMENSIONS IN INCHES




DATE	COMMENTS	DRWN	CHKD
MAR 81	ISS 3 PCB, NEW EBOS IC, VISION HEADERS	JFP	JFP
OCT 79	ISSUE 2, 20 WAY DUAL HEADER NEW MONO SW	JFP	JFP
AUG 79	ORIGINAL - ISSUE 1 PRODUCTION	JFP	JFP




UNIT TITLE: SCEPTER / VISION MIXER - LEFT/RIGHT SCHEMATIC
DRAWING TITLE: CIRCUIT DIAGRAM PCB AG0238 ISSUE 3

ALLEN & HEATH
PROFESSIONAL AUDIO EQUIPMENT MANUFACTURERS
DRAWING NO: ISSUE




○ INDICATES NEG CAP LEAD


MONO OUTPUT SOURCE SELECT
MIXES LEFT AND RIGHT SIGNALS TOGETHER



STEREO OUTPUT SOURCE SELECT



SCEPTER MASTER PCB ISSUE 3 MAR 91
PARTS PLACEMENT & OPTION HEADER LOCATIONS
HEADERS SHOWN ON PCB WITH JUMPERS SET AT FACTORY DEFAULT.



DC POWER IN MALE XLR-4
 1 = -15 VOLTS
 2 = 0 VOLTS
 3 = 0 VOLTS
 4 = +15 VOLTS
 5 = +48 VOLTS
 SHELL = CHASSIS

MAIN RIBBON

SUPPLY TO HDPIV AMP U1
 +VB ← 22R → +V
 VO ← 33 X 2
 -VB ← 22R → -V

POWER ON
 2K2
 0R

SUPPLY FEED TO AUDIO IC'S VIA DECOUPLING
 +VA ← 33 X 2
 -VA ← 0R → -V

INDIVIDUAL DECOUPLING NETWORKS TO U2-U10
 PIN 8 ← 22R → +VA
 PIN 4 ← 0.1 22R → -VA

+/-8V TO CMOS SWITCH U4
 PIN 16 ← 4K7 → +VA
 PIN 7 ← 0.1 10K → -VA

FFL DC BUS 2N3904
 FFL ON

FFL CONTROL

FROM MONO SUM
 100K 2K2
 33 10K

LOGIC CONTROL TO CMOS SWITCH
 0V = 0 = PFL OFF
 +6V = 1 = PFL ON

BALANCED MONO OUT
 U11
 22R 33 0.1
 10K 1K 33
 22R 33
 PIN 1 LEFT (REAR)

LEFT POST FADER
 RIGHT POST FADER

RIBBON TO/FROM LEFT & RIGHT PCB'S

MONO SOURCE SELECT
 MONO LEVEL

METER FEEDS
 1 = LEFT PRE-INSERT
 2 = RIGHT PRE-INSERT
 3 = RIGHT POST-FADER
 4 = LEFT POST-FADER
 5 = METER LEFT
 6 = METER RIGHT
 7 = METER RIGHT
 8 = RIGHT POST-INSERT
 9 = LEFT POST-INSERT
 10 = LEFT POST-INSERT

STEREO LEVEL
 STEREO SOURCE SELECT

TO MONITOR BUFFER AMPS

MONO MUTE TO EBOS
 47K X 2

AUX A AUX B AUX C AUX D MONO

MONITOR SOURCE SELECT

STEREO MUTE

STEREO OUT

MONITOR AUDIO IN
 MONITOR LEVEL

MONITOR OUT

LEFT MONITOR AUDIO
 RIGHT MONITOR AUDIO

LEFT METER FEED
 FROM PFL SUM AMP
 RIGHT METER FEED

HDPIV OUT

UNLESS OTHERWISE NOTED:
 ALL ELECT CAPS 25V. VALUES IN U.F. OTHER VOLT CAPS SHOWN VAL/VOLTS
 ALL DISC AND MYLAR CAPS RATED 50V OR HIGHER. VALUES IN U.F.
 ALL RESISTORS 1/4W 5% 1% RES INDICATED WITH 3 DIGITS (EG. 8K81)
 ALL SWITCHES SHOWN DISELECTED
 ALL DROPS 1N4148

LEGENDS

◇ 20-WAY RIBBON HDR
 Ⓢ ROTARY POT
 Ⓢ ELECT CAP
 ○ INTRA PCB CONNECTION
 S 1/4" JACK
 T COLOR
 LED
 OPTIONS HEADER



IC LOCATIONS

1 2 3 4 5 6 7 8 9 10 11

DATE	COMMENTS	DRWN	CHKD
MAR 81	ISS 3 PCB NEW EBOS IC, VISION HEADERS	JRP	JRP
OCT 89	ISS 2 PCB NO CAP AUX OUT, 20 WAY RIBBON	JRP	JRP
AUG 88	ORIGINAL - ISSUE 1 PRODUCTION	JRP	JRP

UNIT TITLE	SCEPTER / VISION - MASTER PCB SCHEMATIC
DRAWING TITLE	CIRCUIT DIAGRAM PCB AG0239 ISSUE 3


ALLEN & HEATH	
PROFESSIONAL AUDIO EQUIPMENT MANUFACTURERS	
DRAWING NO	ISSUE





COMPONENT SIDE VIEW
EBOS 2

ALL UNMARKED RESISTORS ARE 10K 2% RESISTOR NETWORK
 ALL DISC CAPS NPO CERAMIC 50 VOLT
 U1 = LF353
 U2 = NE5532

Electronically Balanced Output Stage



AC INPUT	CONNECTIONS	FUSE
USA 110-240V		500mA T A-5mm
UK 230V		1A T 1N-7%
JAPAN 100V		1A T 1N-7%



MPS8B DETAIL.

AC MAINS INPUT 50/60 HZ SEE NOTE ABOVE

REV	DESCRIPTION	CHKD	APPD	DATE
7	MPS8B - VARISTOR ADDED	J.P.	1-87	
6	MPS I (1-63V, 1A) 5.7, DC CABLE REWORKS	Q	7-76	
5	MPS8B ONLY	R	11-84	

AHB POWER SUPPLY MPS8B CIRCUITS AND GENERAL ARRANGEMENT INCLUDING PHANTOM POWER.

DRAWN	TRACED	CHECKED	APPROVED	DATE	SCALE
CP				9-982	

DRAWING No. 283 ISSUE 6