

Merits

S2/S5 series *Rhino, C40 and S-Drive* *Service Manual*

Nov.10.2006 V1

S2/S5 series- Service manual

	Page
Introduction-----	1
1.Service guide-----	1
2.Battery-----	1
2.1 When to replace the batteries-----	1
2.2 To remove the batteries-----	1
2.3 To install the batteries-----	2
2.4 Check battery charge-----	2
3. Motor, brush and Parking brake-----	2
3.1 Motor-----	2
3.2 Brushes-----	4
3.3 Parking Brake-----	5
4. Tiller Instrument-----	10
4.1 Dash board -----	11
4.2 Throttle Potentiometer-----	11
5. Examples of Electrical illustrated parts breakdown-----	13
5.1 S2353-----	13
5.2 S541-----	14
5.3 S538/S548-----	15
5.4 S534-----	16
6. Scooter troubleshooting-----	17
(Typical problems and solution)	
7. Controller(Rhino, C40 and S-drive)-----	19
7.1 Connection and wiring-----	19
7.2 Programming -----	22
7.2.1 Setup Menu(For Rhino and C40)-----	22
7.2.2 Option Menu(For Rhino and C40)-----	28
7.2.3 S-Drive programming setting-----	31
7.2.4 Common programming errors-----	32
7.3 Diagnostics and fault finding-----	33
7.3.1 Diagnose fault-----	33
7.3.2 flash code-----	36
8.Charger-----	37
8.1 Operation instruction-----	37
8.2 LED indication-----	38
8.3 Troubleshooting-----	38
9. Scooter diagnostic flow chart-----	40

Introduction

The purpose of this manual is to provide dealers and/or distributors with the product information and instructions that are required for servicing the S2/S5 series electrical scooter.

1 Service Guide

- Batteries
- Motors, Brush and brake
- Tiller instrument
- Electrical illustrated parts breakdown
- Troubleshooting
- Rhino , C40 and S-Drive controller
- Charger
- Scooter diagnostic flow chart

WARNING

Before performing any maintenance or service, turn the power off. NEVER allow tools and/or battery cable(s) to contact BOTH the battery terminal(s) or the post(s) at the same time. An electrical short may occur resulting in serious personal injury and/or damage. It is strongly recommended that battery installation and/or replacement should be done only by a qualified technician.

2 Batteries

- **Battery type: Lead-acid *2 pieces**

2.1 When to replace the batteries

The batteries may have to be replaced should one of the following conditions occurs:

- **The scooter's driving distance decreases significantly.**
- **Incomplete charge.**
- **The Charging cycle becomes significantly longer or shorter than before.**

2.2 To Remove the Batteries

(Scooter without battery box):

1. Remove the seat and shroud.
2. Disconnect the wiring harness from the batteries by removing the screws.
3. Remove the batteries from the scooter base.

(Scooter with battery box):

1. Remove the seat and battery box.
2. Follow specific scooter service manual to dismantle battery box.
3. Remove the batteries from the battery box.

2.3 To install the Batteries

(Scooter without battery box):

1. Install two new batteries into the power chair base.
2. Connect the wiring harness to the batteries.
3. Confirm the battery supply voltage. (the battery voltage to the controller should be at least 25VDC)
4. Cover the shroud and install the seat.

(Scooter with battery box):

1. Install two new batteries into the battery box.
2. Follow specific scooter service manual to install battery box.
3. Confirm the battery supply voltage. (the battery voltage to the controller should be at least 25VDC)
4. Put the battery box into scooter and install the seat.

24 Checking Battery Charge:

1. Connect the voltmeter negative probe to controller power-.
2. Connect the voltmeter positive probe to controller power+.
3. The voltmeter should measure 23-27 volts (i.e. Battery Voltage).
4. If the voltage is negative, check for correct battery wiring polarity. Ensure that batteries are connected correctly.
5. If the voltage reading is zero, check for wiring open circuits or battery wiring polarity.
6. Charge the batteries completely before driving.

3 Motor, brush and parking Brake

3.1 Motor:

The motor may have to be replaced should one of the following

conditions occurs:

- **The scooter's driving power decreases significantly.**
- **Loud noise from motor.**
- **Motor screwed up and fail.(ex: Harness, connector or case damaged)**

The 24V motors are specifically designed for use on electrical scooter. The motors incorporate a metal-cased parking brake. The parking brake assembly and brushes are protected by a metal cover. The motor frame is integral with the cast aluminum gearbox housing that forms a strong and compact unit. An easy-to-operate brake lever engages/releases the magnetic brake for manual pushing of the scooter.

Connections and Wiring

1. Each motor has four wires of two different sizes that require connection. Note that the red and blue(or black) wire connections will affect the motor orientation.
2. Upon completing all wirings the loom must be fastened to the frame to minimize strain on the connections.
3. Lift the wheels before making the battery connection and check if the drive system functions correctly.
4. Ensure that the scooter's power system is equipped with a circuit breaker or fuses.

Testing

Check the motors and control system when the installation is completed. Note the following points:

The circuit breaker or fuses must be included in the power circuitry.

- **Lift the wheels off the ground;**
- **Do not arc cables to check for power.**
- **Use a multimeter to check the voltage.**

Operation of Brake lever

When it is desired to manually push the scooter, the brake lever is easily released. Simply push/pull the lever on the magnetic brake. Labels are available for indicating the status of the brake lever.

Maintenance and Servicing

The motor is a low-maintenance-required motor and except for periodic checkup, requires no further maintenance under normal

conditions. The batteries should be disconnected during any maintenance procedure and in fact their complete removal from the scooter may help access.

- **Check system regularly.**
- **Check for loose, damaged or corroded connectors and terminals.**
- **Replace damaged cabling.**
- **Check motor mountings for tightness.**
- **Clean motor and control system components with a damp cloth.**
- **The cover may be removed to check the brush length.**
- **Check for oil or grease leaks around the seals, output shaft, and brake lever.**
- **Check motor for increased backlash or play, excessive noise or other indications of the gear wear-out.**

Warning:

Do not use the motor if there is any indication of damage or if abnormalities such as: damage to the case, grease leakage, abnormal response as well as excessive backlash or play, noise, heat, smoke and/or arcing are present.

Ensure that the motor is securely fastened to the transaxle and the wheel securely fastened to the transaxle.

3.2 Motor Brushes

The motor brushes may have to be replaced should one of the following conditions occurs:

- **The scooter's driving power decreases significantly.**
- **Loud noise from the brush.**

Each motor contains two or four carbon brushes which may require replacement after operating the scooter a long period of time. Brush replacement is a simple operation:

- **Disconnect the motor.**
- **Remove the end cover to allow access.**
- **Remove the brush.**
- **Check the commutator for excessive wear or unusual burns or erosion marks.**
- **Reverse the above processes to install the new brush, ensuring that the brush is still able to slide in the brush guide.**

- **Ensure the springs seat properly on the brush and the brush wire is placed properly.**

Note:

Ensure correct insulation between motor case and motor wires (refer ISO 7176-14).

- **Always replace all the brushes in both motors at the same time.**
- **Run brushes in for several hours in the forward direction. Ensure that the parking brake is released when operating the motor. (This reduces brush bounce which causes arcing and in turn generates RFI and audible noise.)**

3.3 Parking Brake:

The parking brake may have to be replaced should one of the following conditions occurs:

- **Poor parking brake holding ability**
- **Parking brake screwed up and fail.(ex: Harness, connector or case damaged)**

Poor parking brake holding ability indicates the need for replacing the parking brake assembly.

- **Disconnect the motor.**
- **Remove the cover to allow access.**
- **Cut/solder the wires of the parking brake. Avoid excess strain on the wires.**
- **Remove the screws that hold the parking brake assembly together.**
- **Reverse the process to install the new parking brake assembly.**
- **Check the armature which must rotate freely with the parking brake disengaged.**

Parking brake replacing procedure:

Electromagnetic brake change procedure:

1. Loose the 2 screws out of the cover.(Remember the orientation of the cover in or to place back the cover correctly)




2. Open the cover



3. Mark the position of the brake related to the motor. (Remember the orientation of the brake in order to place back new brake correctly)




4. Cut off the wires.(white and gray)



5. Release the clutch and loose the 4 screws out of the brake, then remove the brake



6. Place the new brake onto the motor. (Before placing, release the clutch first)



7. Tighten the 4 screws.



8. Solder the wires. (white wire to white wire, gray wire to gray wire)



9. Insulate the soldering point with heatshrink



10. Put the cover back and tighten the 2 screws.




4. Tiller Instrument

Tiller instrument handles all accessories of the scooter, like buzzer, switches, battery gauge, charging inlet, speed adjust, throttle potentiometer. Sometimes

the accessory problems may turn out to be caused by tiller instruments. Make sure all wires are not loose and all connector are connected firmly.

4.1 Dash Board PCB(250 Tiller):

Following picture shows function of each connector on dashboard PCB.



- 1:Main cable connector
- 2:Key switch connector
- 3:Speed POT. Connector
- 4:Charger connector
- 5:Status LED connector
- 6:Horn switch connector
- 7: Speed adjust VR. Connector
- 8: Battery gauge connector
- 9: Horn connector

4.2 Throttle Potentiometer(POT):

In some cases, scooter can not move results from POT problems. There are three typical POT problems.

1. Speed POT wire broken or short-circuited(control flash code 7)

Check if wires shorted or connector loose.

2. Speed POT out of range(control flash code 7)



Measure the resistance between “1”and “3”of the potentiometer. It must be $5K\Omega \pm 10\%$. If not, Replace the potentiometer.

- 3.Speed POT not in neutral position(control flash code 6)


Measure the resistance between “1”and “2”of the potentiometer. It must be

2.5K Ω \pm 10%. If not, recalibrate the neutral position.

Measure the resistance between “2” and “3” of the potentiometer. It must be 2.5K Ω \pm 10%. If not, recalibrate the neutral position.




Follow the wire color allocation--as picture below-- to solder the wire to the potentiometer.




5 Examples of electrical illustrated parts breakdown


5.1 S2353 scooter




5.2 S541- scooter



5.3 S538/S548- scooter



5.4 S534- scooter



6. Troubleshooting

Typical problems and solutions

Problem	Possible Causes	Solution
Scooter does not run (Scooter not moving and lights do not work using battery, but lights do work when you plug the charger into the scooter and also plug the charger into the wall outlet)	Undercharged battery	Charge the battery. A new battery should have been charged for at least 12 hours before using the vehicle for the first time and up to 8 hours after each subsequent use. Check all connectors. Make sure the charger connector is tightly plugged into the charging inlet, and that the charger is plugged into the wall. Make sure power flow to the wall outlet is on.
	Charger is not working	You may check to see if your charger is working by using a volt meter
	Burned out fuse	Replace the fuse.
Scooter does not run (Scooter not moving and lights do work using battery,)	Controller diagnostic (flashcode)	Follow controller section(Chapter 7.3.2) to see flashcode meanings and Solutions.
	Status LED fail	If status LED is dimly light or not working, replace with new one.
Scooter not moving and all lights do not work with only batteries.	Burned out fuse	Replace the fuse
	Loose wire/Connection	Check if wires/connections are tight.
Scooter was running but suddenly stopped	Controller trip	The controller will automatically shut off the power if the motor is overloaded. An excessive overload, such as too heavy a rider or too steep a hill, could cause the controller to overheat. If the scooter suddenly stops running, wait a few seconds and let the controller cool down.
	Tripped circuit breaker or burned out fuse	Check all wires and connectors to make sure they are tight. The circuit breaker or fuse will automatically shut off the power if overload or short-circuit happens. If the scooter

		suddenly stops running, push the breaker to reset the circuit or replace the fuse. Correct the conditions that caused the breaker/fuse to trip and avoid repeatedly tripping the breaker.
Short run time (less than usual per charge)	Undercharged battery Battery is old and will not accept full charge	Charge the battery. A new battery should have been charged for at least 12 hours before using the scooter for the first time and up to 8 hours after each subsequent use. Check all wires and connectors. Make sure the charger plug is tightly plugged into the charging socket, and that the charger is plugged into the wall. Make sure power flow to the wall outlet is on. Even with proper care, a rechargeable battery does not last forever. Battery life depends on scooter use and conditions. Replace the battery if necessary.
Scooter runs sluggishly	Tires are not properly inflated Scooter is overloaded Battery problem	Make sure the tires have sufficient air but this usually is not the problem. The tires are inflated when shipped, but they will lose some pressure between the point of manufacturing and delivery. Check tire pressure and properly inflate the tires. Make sure you do not overload the scooter by carrying too much weight, going up a hill or towing objects behind the scooter. If the scooter is overloaded, the controller may go into protection mode and even shut off power to the motor. Correct the driving conditions that caused the overload, wait a few seconds, and then let the controller to recovery. Avoid repeatedly overloading the scooter. Battery needs to be recharged. If after full charging the batteries, the scooter still runs sluggishly. Replace the batteries. Sometimes, it may be too cold to operate the scooter. The battery does not output much current at low temperatures (below 5 degree C). It is too cold to operate.

Sometimes the scooter doesn't run, but other times it does	Loose wires or connectors	Check all wires and all connectors to make sure they are tight.
	Switch bad	Check ON/OFF switch to make sure it is working properly.
Charger gets warm during use	Normal response to charger use	No action required. This is normal for chargers and is no cause for concern. If the charger does not get warm during use, it does not mean that it is not working properly.
Scooter can not stop on a slope	Magnetic brake are not working properly	Possibly the brake lining is worn out. Replace the magnetic brake.
Scooter takes off - will not stop	Throttle potentiometer problem	If the scooter is moving when you release the throttle , you will need to adjust the potentiometer neutral position or replace the throttle potentiometer.
After charging for 8 hours, the scooter battery gauge does not show a full charge	Charger	Charger may be bad. Replace charger. This is the most common.
	Charger connection	Charger connection on scooter is bad- usually a wire on the back of the charger socket is loose.
	Battery	Batteries are bad. Replace new ones
Scooter can move but the battery gauge does not work.	Loose wire/connection	Check if wire/connection is tight.
	Battery gauge	Battery gauge is bad. Replace new ones.

7.Controller


Rhino Controller , C40 Controller and S-Drive controller

7.1. Connections and Wiring


Controller connections are located along the front of the case. The illustration below indicates the different connectors and gives a section reference for specific installation instructions. When all wiring has been completed, it must be securely fastened to the scooter frame to ensure there is no strain on the connectors or any chance of snagging.

Before making any connections to the controller, disable the scooter by one of the following means to prevent accidental movement or arcing:


- 1) place the battery circuit breaker in the open position, or**
- 2) disconnect the batteries**



Typical Wiring Diagram for RHINO DS72K



Typical Wiring Diagram for C40



Typical Wiring Diagram for S-drive

7.2 Programming

Using a hand-held programmer, the controller settings can be modified if desired.

Programming

Warning :

Only qualified personnel should make alterations to controller programming. Incorrect or inappropriate programming of controller can put the scooter into a dangerous state. Manufacturer accepts no responsibility or liability for accidents caused by incorrect programming. On completion of programming, we recommend a drive test be carried out to ensure performance is as desired.

Note :If the scooter is turned off during programming, any changed settings are not saved and controller defaults back to the previously programmed settings.

Programmable Settings

The following settings can be modified so that a scooter can meet user's needs. Not all of these settings are available from the Scooter Programmer.

7.2.1 Setup Menu(for Rhino and C40)

These settings customize the scooter to user preferences and/or environment.

*(Rhino SETUP MENU):

Setting	Description	Values	
Acceleration	Sets the acceleration of the scooter. The higher the setting, the greater the acceleration rate. A low acceleration gives "softer" performance and a less sensitive throttle response.	1 10 3 Yes Yes	Minimum Maximum Default Dealer Prog? HHP?
Deceleration	Sets the deceleration of the scooter. The higher the setting, the greater the deceleration rate. Low settings should only be used with very low Forward Speed settings. This should be set higher than the Acceleration parameter.	1 10 7 Yes Yes	Minimum Maximum Default Dealer Prog? HHP?
Maximum Speed	Allows fine adjustment of the RHINO controller's maximum motor output, and thus of the motor's maximum speed. (Usually set to meet local regulatory requirements.)	127 255 255 No Yes	Minimum Maximum Default Dealer Prog? HHP?
Forward Speed	Sets the maximum forward speed of the scooter. The higher the setting, the higher the maximum forward speed.	1 10 10 Yes Yes	Minimum Maximum Default Dealer Prog? HHP?
Reverse Speed	Sets the maximum reverse speed of the scooter. The higher the setting, the higher the maximum reverse speed. Anti-tip wheels may be required if high Reverse Speed settings are used.	1 10 4 Yes Yes	Minimum Maximum Default Dealer Prog? HHP?

Setting	Description	Values	
Reduce Speed	Limits the maximum forward speed and maximum reverse speed of the scooter. For example, if Reduce Speed is set to 7, Forward Speed to 10 and Reverse Speed to 6, maximum forward speed will reduce to 7, but maximum reverse speed will stay at 6, as it is already lower than Reduce Speed .	1 10 5 Yes Yes	Minimum Maximum Default Dealer Prog? HHP?
Buzzer Volume	A setting of 1 turns the reversing buzzer off. Any other value enables the reversing buzzer with full volume.	1 10 10 Yes Yes	Minimum Maximum Default Dealer Prog? HHP?
Motor Resistance	Indicates the resistance of the motor to which RHINO is connected. A correct value for this setting is required to achieve good speed regulation.	5mΩ 255mΩ 60mΩ No Yes	Minimum Maximum Default Dealer Prog? HHP?
Sleep Time	Sets the length of time with no throttle movement before RHINO goes into Sleep Mode. When in Sleep Mode, the Status Light turns OFF and the scooter will not respond to commands. To exit Sleep Mode, turn the power off, then on again. Refer to Enable Sleep in the Options Menu for information about the Sleep Mode feature.	5 min. 60 min. 30 min. Yes Yes	Minimum Maximum Default Dealer Prog? HHP?
Maximum Current	Sets the maximum output current from RHINO to the motor. Lower values can affect scooter performance. The maximum useable setting corresponds with the nominal current output for the controller type i.e. 50A for the DS-52K. Higher settings than the controller is capable of have no effect on the maximum current rating.	30A 160A 70A No Yes	Minimum Maximum Default, DS72K Dealer Prog? HHP?

Setting	Description	Values	
Soft-Start Period	Can be used to soften the initial "take off" when the throttle is moved out of neutral. Set the length of time in steps of 16 milliseconds at which acceleration will be 50% of the maximum when starting from neutral. (The factory setting generally gives the best performance.)	0 200 50 No Yes	Minimum Maximum Default Dealer Prog? HHP?
Park Brake Delay	Sets the time between the scooter coming to a stop and the park brakes engaging. Too high a value can cause excessive "creep back" when stopping on a slope, too low a value can cause the scooter to lurch when stopping. The factory default generally provides the best performance. If the Check for Slope setting in the Options Menu is set to ON, this setting is ignored.	1 30 6 No Yes	Minimum Maximum Default Dealer Prog? HHP?
Pot Neutral	Sets the neutral position of the throttle. Care should be taken when changing this setting otherwise erratic operation may result if the throttle wiper becomes detached.	102 180 128 No Yes	Minimum Maximum Default Dealer Prog? HHP?
Alternative Speed Pot FSD (Full-Scale Deflection)	Sets the throttle position at which the RHINO reaches maximum speed. If set too high, the scooter will not achieve maximum speed no matter how much the throttle is deflected. If set too low, the scooter will reach maximum speed with only a small deflection of the throttle.	30 127 72 No Yes	Minimum Maximum Default Dealer Prog? HHP?
Alternative Speed Pot Dead Band	Sets the amount the throttle must be deflected before the scooter begins to drive.	5 63 20 No Yes	Minimum Maximum Default Dealer Prog? HHP?

Setting	Description	Values	
Wig-Wag Fault Threshold	Controls the threshold at which the controller will generate a fault if a short exists between the Wig-Wag potentiometer wiper and either end terminal. Use values greater than 10 if ISO resistors are fitted.	10	Minimum
		63	Maximum
		10	Default
		No	Dealer Prog?
		Yes	HHP?
Current Limit Time	If RHINO is in current limit for this amount of time driving will be disabled and a Flash Code 4 displayed. The scooter must be turned off, then on again to reset. The Current Limit Timer in the Options menu must be set to ON for this setting to have any effect.	5	Minimum
		50	Maximum
		15	Default
		No	Dealer Prog?
		Yes	HHP?
Slope Current	Sets the threshold at which the park brakes will be applied when the Check for Slope setting is set to ON.	5	Minimum
		100	Maximum
		20	Default
		No	Dealer Prog?
		Yes	HHP?
BDI Threshold	Sets the threshold at which the Battery Discharge Indicator (BDI) shows a low battery.	21.0	Minimum
		26.0	Maximum
		23.3	Default
		No	Dealer Prog?
		Yes	
Battery Saver Threshold (V)	Sets the voltage at which the Battery Saver feature becomes active. This feature protects the batteries by slowing the scooter as the voltage decreases, thereby extending battery life. Setting this to a higher value will cause the scooter to activate the Battery Saver feature earlier, providing additional battery protection but limiting scooter performance particularly on slopes. Setting this to a lower value will cause the scooter to continue to perform optimally for longer but may shorten battery life.	128	Minimum
		165	Maximum
		146	Default
		No	Dealer Prog?
		Yes	HHP?

Setting	Description	Values	
Battery Circuit Resistance (mOhm)	If the resistance of the battery circuit is entered, the controller will be able to calculate a far more accurate battery voltage used in features such as the Battery Saver.	0 50 0 No Yes	Minimum Maximum Default Dealer Prog? HHP?
Speed Limit Pot Minimum	Limits the maximum forward and reverse speed of the scooter. If Digital Pot implementation is used, the Reduce Speed setting determines the reduce speed parameters. If Analog Pot implementation is used, Speed Limit Pot = ON allows the Reduce Speed Switch to let the speed limit potentiometer control the scooter speed. Must be set to 255 if no speed reduction pot is fitted.	51 255 51 No Yes	Minimum Maximum Default Dealer Prog? HHP?
Creep Speed	Increases the amount of throttle movement required before the park brakes will disengage. Helps to prevent rollback on slopes.	0 20 20 No Yes	Minimum Maximum Default Dealer Prog? HHP?
Push Speed Limit	If RHINO is turned on and the park brakes have been electrically released using the Park Brake Release lever, the speed at which the scooter can be pushed will be limited to this value. If the Push Speed is exceeded, the scooter will execute a controlled stop.	20 100 100 No Yes	Minimum Maximum Default Dealer Prog? HHP?
Demand Curve	Defines the scooter response to throttle movement. If set to 0%, moving the throttle half of its travel will result in the scooter travelling at half its programmed speed. If set to 100%, moving the throttle half of its travel will result in the scooter travelling at around 25% of its programmed speed, increasing speed as the throttle is moved further.	0 100 80 No Yes	Minimum Maximum Default Dealer Prog? HHP?

*(C40 SETUP MENU):

Setting	Description	Value	
		Max.	Min.
Acceleration	Sets the acceleration of the scooter. A higher number gives a greater acceleration rate. A low acceleration will give 'softer' performance and give a less 'touchy' throttle response.	10	1

Deceleration	As above, but sets the deceleration of the scooter. Low values should only be used with very low Forward Speed values.	10	1
Forward Speed	The maximum forward speed of the scooter. The higher this setting, the higher the maximum speed.	10	1
Reverse Speed	As above, the maximum speed of the scooter in reverse.	10	1
Reduce Speed	Limits the maximum forward and reverse speeds of the scooter to this value. For example, if Reduce Speed is set to 7, Forward Speed to 10 and Reverse Speed to 6... - Forward Speed will reduce to 7 - Reverse Speed will stay at 6 (as it is already lower than Reduce Speed)	10	1
Buzzer Volume	A value of 1 turns the horn/buzzer off. Any other value gives full volume.	10	1
Sleep time	Sets the length of time with no throttle movement before C40 goes into Sleep Mode. The status LED will turn off and the scooter will not respond to any commands. Power must be turned off and on again to exit sleep mode See Enable sleep in the Option Menu to turn this feature ON or OFF.	30	1
Current Limit	This sets the maximum output current to the motor. Lower value may affect scooter power.	40	20
Brake Delay	The delay between the scooter coming to a rest and the park brakes engaging. A low value will minimise creep after stopping.	15	1
Motor resistor	Resistance of the motor to which C40 is connected- Required to achieve good speed regulation.	250	100

7.2.2 Options Menu(For Rhino and C40)

These settings are adjustable using a hand held programmer. Settings via the programmer can be either ON or OFF.

*(Rhino OPTION MENU)

Setting	Description	Default
Single-Ended Pot	If ON, the throttle controls speed only, and direction is selected with a forward/reverse switch. If OFF, speed and direction are controlled by the throttle. No forward/reverse switch is required. For the DS72KA, this option should be OFF otherwise the actuator function will be unavailable.	OFF
Motor Reverse	If ON, the polarity of the motor pins on the motor connector is reversed, and the motor turns in the direction opposite to normal.	OFF
Pot Reverse	If ON, the polarity of the throttle is reversed. Moving the throttle in the direction that normally causes forward movement results in reverse movement. When used with Single-Ended Pot = ON , this option will reverse the directions of the Forward/Reverse switch.	OFF
Speed Derating	Enables the Reduce Speed option on the Setup Menu.	ON
Brake Checking	Set to ON if the motor has a park brake.	ON
Load Compensation	Allows RHINO to maintain a constant speed despite changing driving conditions (for example, climbing from a flat surface on to a slope). This setting should be ON for normal operation. It uses the Motor Resistance setting in the Setup Menu.	ON
Motor Derating	This option is set to ON.	ON
Enable Sleep	If ON, Sleep Mode is enabled, and RHINO goes to 'sleep' after the Sleep Time specified with the Setup Menu.	ON
Check for Slope	If ON, stopping performance tends to be harsher than normal. The Park Brake Delay setting in the Setup Menu is bypassed when stopping on a slope.	OFF
Sleep Beep	If ON, RHINO will beep three times when it goes into Sleep mode.	ON

Setting	Description	Default
Current Limit Timer	Having this setting turned ON is a regulatory requirement in some countries. If ON, RHINO will automatically stop driving after the amount of time set in the Current Limit Time setting. Flash Code 4 is displayed and the scooter must be turned off, then on again, to reset. When set to ON, RHINO might turn off after a time under heavy load (for example, going up a long, steep hill). This will be undesirable for some users. If driving resumes before the motor cools, or if this option is turned OFF, the motor might be damaged under a heavy load.	ON
Sound Flash Codes	If ON, RHINO will also signal Flash Codes with the buzzer.	ON
Enable PB Release2	If ON, the Forward/Reverse switch can be used as an alternative park brake release switch. This parameter is not available on the DS72KA.	OFF
Turn Input Sense	If ON, when the controller senses the Mode Select switch is Open, Reduce Speed mode will be entered. If OFF, the Reduce Speed mode will be entered when the controller senses the Mode Select switch is Closed.	OFF
Enable Slam Brake	If ON, moving the throttle significantly in the opposite direction to which the scooter is currently moving causes the scooter to decelerate immediately at its maximum deceleration rate (as per the Deceleration setting).	ON
O/C P/B Drive Test	RHINO checks the park brakes for open circuits before and while driving. In some circumstances the park brake checking during driving may result in audible noise and/or incorrectly generates faults. Set to OFF only if necessary.	ON
Key-Off Slam Brake	If ON, a driving inhibit condition (typically removal of the key) will cause the scooter to decelerate immediately at its maximum deceleration rate (as per the Deceleration setting). If set to OFF, the scooter will slow at its normal deceleration rate (controlled stop).	ON
Scale Turn Speed	If ON and the scooter is in Reduce Speed mode, the speed of the scooter will operate as described in the Reduce Speed setting. If OFF and the scooter is in Reduce Speed mode, the speed (both forward and reverse) will always be limited to the Reduce Speed setting. Set to OFF if the input is from a speed limit input such as a steering sensor, slope sensor or seat position switch.	OFF

*(C40 OPTION MENU)

Setting	Description	Value		Default
Single-ended POT	If set to ON, the throttle will control speed only, with direction selected by the position of a 'Forward/Reverse' switch. If set to OFF, speed and direction are controlled by the throttle and no 'Forward/Reverse' switch is required.	ON	OFF	OFF
Brake Checking	Set to ON if the motor has a park brake.	ON	OFF	ON
Sleep mode	If set to ON, Sleep Mode will be enabled and C40 will go to 'sleep' after the sleep time specified in the Setup Menu.	ON	OFF	ON
Current limit timer	If set to ON, C40 will automatically stop driving after it has been in current limit for 15 seconds. A flash code 4 will be displayed and the scooter must be turned off and on again to reset.	ON	OFF	ON
Motor reverse	Set to ON to reverse the polarity of the motor pins on the Motor connector. The motor will turn in the opposite direction to normal.	ON	OFF	OFF
Load Compensation	Allows C40 to maintain a constant speed regardless of changing driving conditions. This should be ON for normal operation.	ON	OFF	ON

7.2.3 S-drive programming settings

Function		Range	Res.	SP1a	SP1b
Forward Acceleration		0.1 to 10s, Fast / Slow	100ms	<input type="radio"/>	<input type="radio"/>
Forward Deceleration		0.1 to 10s, Fast / Slow	100ms	<input type="radio"/>	<input type="radio"/>
Reverse Acceleration		0.1 to 10s, Fast / Slow	100ms	<input type="radio"/>	<input type="radio"/>
Reverse Deceleration		0.1 to 10s, Fast / Slow	100ms	<input type="radio"/>	<input type="radio"/>
Forward Speed		0 to 100%, Fast / Slow	1%	<input type="radio"/>	<input type="radio"/>
Reverse Speed		0 to 100%, Fast / Slow	1%	<input type="radio"/>	<input type="radio"/>
Invert Throttle Polarity		Yes / No	--	<input type="radio"/>	<input type="radio"/>
Power Down Timer	(3)	0 to 20 minutes	1 min	<input type="radio"/>	<input type="radio"/>
Help Mode		On-line help text	--	<input type="radio"/>	<input type="radio"/>
Diagnostics		Trip codes from controller	--	<input type="radio"/>	<input type="radio"/>
Read System Log	(4)	View stored diagnostic codes	--	<input type="radio"/>	<input type="radio"/>
Read Timer	(4)	View elapsed running time	--	<input type="radio"/>	<input type="radio"/>
Current Limit		20A to max rating	1A		<input type="radio"/>
Motor Compensation		0 to 1 Ω	5m Ω		<input type="radio"/>
Hold Factor		100 to 420%	4%		<input type="radio"/>
Mid Current		0 to 100%, 1 to 255s	1%, 1s		<input type="radio"/>
Brake Time		0 to 1s	10ms		<input type="radio"/>
Iso Tests	(1)	0.1 to 10s, Fast / Slow	100ms		<input type="radio"/>
Inhibit Polarity	(2)	Hi / Lo	--		<input type="radio"/>
Inhibit Mode	(3)	1 to 6	--		<input type="radio"/>
Bridge Hold Time	(1)	0 to 5s	20ms		<input type="radio"/>
Throttle Gain	(1)	0 to 1250%	5%		<input type="radio"/>
Pulse Reverse Alarm		Yes / No	--		<input type="radio"/>
Wig-wag Throttle		Yes / No	--		<input type="radio"/>
Low Battery Flash Inhibit		Yes / No	--		<input type="radio"/>
Soft-Stop	(3)	On / Off	--		<input type="radio"/>
Throttle Deadband		3 to 100%	1%		<input type="radio"/>
Output Voltage		20 to 40V	1V		<input type="radio"/>
TruCharge Cab Resistance		10 to 250m Ω	5m Ω		<input type="radio"/>
TruCharge Cal.		1 to 200	1		<input type="radio"/>
Max. Charge Amps	(3)	0 to 12A	0.1A		<input type="radio"/>
Min. Charge Amps	(3)	0 to 12A	0.1A		<input type="radio"/>
Erase System Log	(4)	Clears stored diagnostic codes	--		<input type="radio"/>
Clear Timer	(4)	Resets run timer	--		<input type="radio"/>

7.2.4 Common Programming Errors

Sometimes after changing certain parameters, in particular, when customizing the Motor Reverse and Pot Reverse settings, the scooter might not drive in the way that was intended. Following is a matrix of Motor Reverse and Pot Reverse

settings and the impact they have on the motion of the scooter.

Setting		Result	
Motor Reverse	Pot Reverse	Driving Forward	Driving Backward
OFF	OFF	Fast forward speed	Slow reverse speed with buzzer
ON	OFF	Fast reverse speed	Slow forward speed with buzzer
OFF	ON	Slow reverse speed with buzzer	Fast forward speed
ON	ON	Slow forward speed with buzzer	Fast reverse speed

7.3 Diagnostics & Fault Finding

Controller provides diagnostics information to assist technicians with diagnosing and correcting faults within the scooter system. A fault in the scooter will cause the controller Status Light to flash separated by a pause. The number of flashes in each burst, also referred to as the *flash code*, indicates the nature of the fault. Depending on the severity of the fault and its impact on user safety, controller will react differently. It can:

- Display the flash code as a warning but allow normal driving and operation.
- Display the flash code as a warning but allow limited driving and operation.
- Display the flash code, stop the scooter and prevent driving until the scooter has been turned off and then back on again.

Descriptions of what each flash code means can be obtained by plugging in the controller programmer. Detailed descriptions of what each flash code means and the probable cause and remedy for each are described in flash code table .

7.3.1 Diagnosing controller Faults

Use the following troubleshooting guide if the scooter fails to operate. The guide will help identify whether the fault exists within controller or another part of the scooter system.

Required equipment: Voltmeter

Note: Elevate the drive wheels before carrying out the following tests. Turn the key switch on before beginning any diagnostics. The voltages shown are nominal values.

Warning:

Testing should only be carried out by qualified service personnel.

**If the External Indicator Light is PERMANENTLY ON,
but the scooter does not move**

Check that the park-brake solenoid or relay is working.

Move the throttle to the full-speed position and listen carefully for the operation of the park-brake solenoid or the relay in the RHINO.

- If you can hear the solenoid or the relay, the problem is not with the throttle or the inhibit circuitry.
- If you can hear the solenoid but the motor does not turn, look for an open circuit in the motor wiring.

Check the voltages on the Throttle terminals with the throttle in neutral.

Connect a voltmeter between Battery – and the following Throttle pins:

Battery – » Throttle –	$0.5 \pm 0.1V$
Battery – » Throttle Wiper	$2.5 \pm 0.1V$
Battery – » Throttle +	$4.5 \pm 0.1V$

When the Throttle is moved in the forward and reverse directions, the voltage on Throttle Wiper should increase and decrease by 2V.

- If the throttle voltages are incorrect, an incorrect throttle potentiometer is being used and/or it is not correctly calibrated.
- If the voltage swing does not occur, check the potentiometer and wiring for open circuits.

Check the voltages on the Motor terminals.

Connect a voltmeter between Motor + and Motor –.

**The voltmeter should measure 0V when the throttle is in neutral.
The voltmeter should measure 24V as the throttle is moved out of neutral to full forward.**

- If the voltage out of neutral is above 0V but the motor is not driving, check the motor, motor wiring, and connectors.

Check the voltages on the Park Brake terminals.

Connect a voltmeter between Park Brake + and Park Brake –.

**The voltmeter should measure 0V when the throttle is in neutral.
The voltmeter should measure 24V when the throttle is out of neutral.**

- If the voltages are incorrect, check the park brake and park brake wiring.

Check inhibit status.

Connect a voltmeter between Inhibit and Battery –.

The voltmeter should measure 5V.

- If the voltage is 0V, check that an inhibit switch is not engaged (e.g., from a battery charger). When 0V is applied to this terminal, driving will be inhibited.

If the Status Light is OFF

Check whether the RHINO Programmer is plugged in.

The status light will be out, and driving is not enabled when a Programmer is plugged in to the RHINO.

Confirm that the battery supply voltage is present on the RHINO Battery +/- terminals.

Connect a voltmeter between Battery + and Battery -, negative probe on Battery -.

The voltmeter should measure between 23 and 27 volts.

- If the voltage is negative, check for correct battery wiring polarity.
- If the voltage is 0V, check the circuit breaker and for open circuit wiring.

Confirm that the key switch is on and that its wiring and fuses are intact. Confirm that the Status LED, if present, is fitted correctly.

Connect a voltmeter between the Key Switch terminal and Battery -.

The voltmeter should read at least 20 volts.

- If the voltage is 0V, use the voltmeter to check the wiring from Battery + to the key switch itself and back to the Key Switch terminal.

If the External Indicator Light is FLASHING

Count the number of flashes and refer to the following section, RHINO Flash Codes.

Plug in the RHINO Programmer to determine the cause of the fault.

7.3.2 controller Flashcodes

Flash Code/Fault	Impact on Scooter	Notes
1 Battery needs recharging	Will drive	Battery charge is running low. Recharge the batteries as soon as possible.
2 Battery voltage too low	Drive inhibited	Battery charge is empty. Recharge the batteries. If the scooter is left off for a few minutes, battery charge might recover enough to allow driving for a short time.
3 Battery voltage too high	Drive inhibited	Battery charge is too high. If a charger is plugged in, unplug it or turn the Charge/Run switch to Run. Scooters powered by RHINO charge the batteries when travelling down slopes or decelerating. Excessive charging in this manner can cause this fault. Turn the scooter power off then on again. If necessary, reduce speed when descending the slope.
4 Current limit time-out	Drive inhibited	The scooter has drawn too much current for too long, possibly because the motor has been over-worked, jammed or stalled. Turn the scooter power off, leave for a few minutes, and then turn the power back on again. The controller has detected a shorted motor. Check the loom for shorts and check the motor. Contact your service agent.
5 Brake fault	Will Drive	The Park Brake Release switch has been turned on when powering up the scooter or while driving. Check the park-brake release lever is in the engaged position. Check the Park brake Release switch is closed when powering up.

Flash Code/Fault	Impact on Scooter	Notes
5 Brake fault	Drive inhibited	The park-brake coil or wiring is faulty. Check the park-brake and wiring for open or short circuits. If necessary, unplug the motor connector and check that all pins are in the correct position. If this flash code does not appear until the throttle has been moved out of neutral, check for a short in the park-brake circuit. If this flash code appears at power-up, check for an open circuit in the park-brake circuit. Contact your service agent.

6 Out of neutral at power-up	Drive inhibited	Throttle is not in neutral position when turning key switch on. Return throttle to neutral, turn power off and back on again. Throttle may need to be adjusted (see Section 4.2.3). Check throttle wiring.
7 Speed Pot error	Drive inhibited	The throttle, speed limit pot or their wiring may be faulty. Check for open or short circuits. The throttle or speed limit pot may not be correctly set up. If no speed limit pot is fitted, the Speed Pot Limit parameter must be set to 255. Contact your service agent.
8 Motor volts error	Drive inhibited	The motor or its wiring is faulty. Check for short circuits. Contact your service agent.
9 Other internal errors	Drive inhibited	Contact your service agent.
10 Push Too Fast fault	Drive inhibited	The scooter has been pushed faster than the programmed 'Push Speed' parameter when the Park Brake Release function has been operated. The scooter has been pushed faster than the programmed 'Rollaway Speed' parameter when the Park Brake has been mechanically released. Turn the scooter off and then back on again.

8.CHARGER

8.1 Operating Instruction

- (1) To assure the charged batteries are lead acid batteries.

- (2) To unplug the AC power input before the charge circuitry and battery have been connected completely.**
- (3) To check if the output end of charger corresponds with the positive/negative pole of battery.**
- (4) After the above sequences have been finished, please plug the AC power input. When LED turns yellow, it means the charger has been under normal charging condition (If the abnormal phenomena occurs, please unplug the AC power immediately and check the 1~4 sequences repeatedly, then plug the AC power again.)**
- (5) When LED turns to green, that means the batteries have been finished for complete charge.**
- (6) Under the condition of yellow/green LED. It may have a temporary alternating phenomenon around 1~60 seconds during switching, please note this is a normal feature.**

8.2. LED Indication

RED LIGHT ON: Power On and Battery Disconnected

YELLOW LIGHT ON: Charging

GREEN LIGHT ON: Full-Charged

8.3 Troubles Shooting

(1) When the AC power plugged but no LED light up:

To check the connection of power cord

To check the connection of socket.

To check if the fuse is under normal condition.

(2) When the AC power plugged but yellow LED do not light up completely:

To check if the output wire occurs short circuit

(3) When the AC power plugged, but green LED flashes and no charging action:

To check if the output fuse has severed

To check the connection between output connector and the battery

To check if having made a correct connection for the battery polarity.

To check the battery is connected completely.

(4) If the fuse is burned-out as soon as AC power plugged and no effect at all:

After having been replaced with another new/same fuse. Please do not dismantle the charger or replace with other larger fuse by yourself.

(5) The charge time continues for a long duration(abnormal):

To check if the battery has been broken down or aged

(6) The yellow/green LED have flashed over 40 minutes during charging:

To check if the battery is broken down

(7) The battery heats(abnormal):

To stop charging and check if there are troubles occurred on the charger

Caution


(1) If there is a ground wire for the power cord of charger, for safety purpose, please be sure to make a good ground connection job.

(2) To make sure the DC output corresponding with the battery which will be charged and the voltage value, otherwise, it may cause battery explosion and hurt someone.


(3) To keep the AC power unplugged before the charge circuitry and battery have been connected completely.

(4) Do not expose the charger to the rain, water or store it at humid place.


9. Diagnostic flow Chart




1-2 Main flow chart(2)




2-2 Voltage too low




2-3 Voltage too high




2-4 Current limit time-out



2-5 Brake fault




2-6 Throttle out of neutral at power-up




2-7 POT error


Remark:
POT +: 4.4~4.8VDC
POT -: 0.2~0.6VDC




2-8 Motor volt faule




3-1 Horn failure




3-2 Head light failure



3-3 Left indicator failure



3-4 Right indicator failure



3-5 Hazard indicator failure

