

#### Dear Dinli Quad Users:

Before the delivery of each new vehicle from Dinli factory, the fuel in carburetor is drained off to ensure the excellent performance and safety of the vehicle. Therefore, when first starting a new vehicle, it is normal to take 20~30 seconds. The quality of each Dinli Quad is guaranteed. Study this manual thoroughly and enjoy your riding Dinli Quad.

# WARNING 🚹

STOP! If you have the impression that four wheels give you the stability of a car, you are wrong. If you have the impression that a quad is simple to drive and similar to those other vehicles, that you are wrong. The risks involved are at least equal to those faced when riding a motorcycle.

#### POTENTIAL HAZARD

Given the realities of sport quads and/or the limits of your own riding abilities you may lose control. The limits are impossible to be specific about because of the variation in terrain and rider ability are nearly unlimited.

#### WHAT CAN HAPPEN

You could loss control, have an accident and be severely injured, paralyzed or killed.

#### HOW TO AVOID THE HAZARD

The hazards of quad riding cannot completely avoid. They can be minimized with training, good judgment, experience, use of helmet, protective gear and development of skills in weight shifting, throttle and brake control. Reading and understanding this Owner's Manual and warning labels, and completing a quad training course are essential and can begin your learning process.



### **Experienced Riders Only**

All Dinli quads are high performance, sport and/or competition machines and should only be operated by licensed competition riders in excellent physical condition. Operators should be well-trained and experienced in the operation of high performance competition vehicles.

- This vehicle is not for beginners or the inexperienced.
- Before you ride this vehicle, read this Owner's Manual thoroughly and understand all of the instructions, warnings, cautions, and notes presented.

#### About this manual

The purpose of this manual is to provide the vehicle owner with important safety, service, maintenance, and tuning information. Read and understand this manual before operating and working on the vehicle. Keep your Owner's Manual on the vehicle while you ride.

If you lose this manual, contact an authorized Dinli dealer for a replacement.

• Read and understand the entire procedure before performing any work. If you are unfamiliar with or doubt your own abilities to complete a procedure as described, have an authorized Dinli dealer service your vehicle.

#### Addenda to this manual

Before you begin reading the manual, go to the "Addenda" section at the end of this manual. The addenda or "supplements" section provides any additional, replacement, or supplemental information for your product available at the time of shipment.

#### **COMMENTS?**

If you have any comments or suggestions about this Owner's Manual, we'd appreciate hearing from you.

Please send to:

DIN LI METAL INDUSTRIAL CO., LTD.

NO.51, Industrial 9th Rd., Tali City, Taichung 412 Taiwan, R.O.C.

Tel: 886 (04) 2491-7666 Fax: 886 (04) 2491-7166

E-mail: globalservice@dinli.com.tw



#### **NOISE REGULATION**

### TAMPERING WITH NOISE CONTROL SYSTEM PROHIBITED

The CE Directives and U.S. federal law prohibits the following acts or the causing there of;

(1) The removal or rendering inoperative by any person, other than for purposes of maintenance, repair or replacement, of any device or element of design incorporated into any new vehicle for the purpose of noise control prior to its sale or delivery to the ultimate purchaser or while it is in use; or (2) the use of the vehicle after such device or element of design has been removed or rendered inoperative by any person.

#### AMONG THOSE ACTS PRESUMED TO CONSTITUTE TAMPERING ARE THE ACTS LISTED BELOW:

- 1. Removing, puncturing, or altering of the muffler, the baffle system, header pipes, or any other component which conducts exhaust gases.
- 2. Lack of proper maintenance.
- 3. Replacing, altering, modifying any moving part of the vehicle or parts of the exhaust, intake (e.g. air filters) with parts other than those specified by the manufacturer.

#### Limitations

All information in this Owner's Manual is based upon the latest product data and specifications available at the time of printing. Dinli Metal Industrial Co., Ltd. reserves the right to make product changes and improvements which may affect illustrations, photographs and explanations contained in this Owner's Manual. No part of this publication may be reproduced, stored in a retrieval system, or transmitted in any form or by any means, (electronic mechanical photocopying, recoding or otherwise), without the prior written permission of Dinli Metal Industrial Co., Ltd. All the procedures and specifications found in this publication are subject to change with out prior notice and without Dinli Metal Industrial Co., Ltd. incurring any obligation. The illustrations in this publication are intended for reference use only and may not depict the actual model or component parts. Your model may differ.

# II. INTRODUCTION

Dear Users:

Congratulations on your purchase of DINLI ATV. It represents the result of many years of Dinli experience in the production of fine machines. You can now appreciate our craftsmanship and reliability of the masterpieces.

#### SAFTY ALTERTS

FAILURE TO FOLLOW THE WARNINGS CONTAINED IN THIS MANUAL CAN RESULT IN SERIOUS INJURY OR DEATH.

• Keep this Owner's Manual with your vehicle at all times.



# Messages with the Safety Alert Symbol ો

• Pay special attention to all messages preceded by the Safety Alert Symbol. It means ATTENTION! BECOME ALERT! YOUR SAFETY IS INVOLVED

# DANGER <u>/</u>!\

Indicates that severe personal injury or DEATH will result if instructions are not followed.

# WARNING / İ

Indicates a potential hazard that could result in serious injury or death.

## CAUTION

Indicates a potential hazard which COULD result in vehicle damage if instructions are not followed.

#### NOTE:

Provides helpful information

## III. IMPORTANT SAFETY MESSAGE

- A QUAD IS NOT A TOY AND CAN BE HAZARDOUS TO OPERATE.
- A quad handles differently from other vehicles including motorcycles and cars. A collision or rollover can occur
  quickly, even during routine maneuvers such as turning and driving on hills or over obstacles, if you fail to take
  proper precautions.
- Severe injury or Death can result if you do not follow these instructions:
- 01. Read this manual and all labels carefully and follow the operating procedures described.
- 02. Never operate a quad without proper instruction. Take a training course. Beginners should receive training from a certified instructor. Contact an authorized quad dealer to find out about the training courses nearest you.
- 03. Always follow the age recommendation: A child under 16 years old should never operate a quad with engine size greater than 90cc.
- 04. Never allow a child under age 16 to operate a quad without adult supervision, and never allow continued use of a quad by a child if he or she does not have the abilities to operate it safely.
- 06. Never operate a quad without wearing an approved helmet that fits properly. You should also wear eye protection (goggles or face shield), gloves, boots, long-sleeved shirt or jacket, and long pants.
- 07. Never consume alcohol or drugs before or while operating this quad.
- 08. Never operate at excessive speeds. Always go at a speed that is proper for the terrain, visibility, operating conditions, and your experience.
- 09. Never attempt wheelies, jumps or other stunts.
- 10. Always inspect your quad each time you use it to make sure it is in safe operating condition. Always follow the inspection and maintenance procedures and schedules described in this manual.
- 11. Always keep both hands on the handlebars and both feet on the foot pegs of the quad during operation.
- 12. Always go slowly and be extra careful when operating on unfamiliar terrain. Always be alert to changing terrain conditions when operating the quad.



- 13. Never operate on excessively rough, slippery or loose terrain until you have learned and practiced the skills necessary to control the quad on such terrain. Always be especially cautious on these kinds of terrain.
- 14. Always follow proper procedures for turning at low speeds before attempting to turn at faster speeds. Do not turn at excessive speed.
- 15. Never operate the quad on hill too steep for the quad or for your abilities. Practice on smaller hills before attempting larger hills.
- 16. Always follow proper procedures for climbing hills as described in this manual. Check the terrain carefully before you start up any hill. Never climb hills with excessively slippery or loose surfaces. Shift your weight forward. Never open the throttle suddenly or make sudden gear changes. Never go over the top of any hill at high speed.
- 17. Always follow proper procedures for going down hills and for braking on hills as described in this manual. Check the terrain carefully before you start down any hill. Shift your weight backward. Never go down a hill at high speed. Avoid going down a hill at an angle that would cause the vehicle to lean sharply to one side. Go straight down the hill where possible
- 18. Always follow proper procedures for crossing the side of a hill as described in this manual. Avoid hills with excessively slippery or loose surfaces. Shift your weight to the uphill side of the quad. Never attempt to turn the quad around in any hill until you have mastered the turning technique described in this manual on level ground. Avoid crossing the side of a steep hill if possible.
- 19. Always use proper procedures if you stall or roll backwards when climbing a hill. To avoid stalling, use the proper gear and maintain a steady speed when climbing a hill. If you stall or roll backwards, follow the special procedure for braking described in this manual.
- 20. Always check for obstacles before operating in a new area. Never attempt to operate over large obstacles, follow proper procedures when operating over obstacles as described in this manual.
- 21. Always be careful when skidding or sliding. Learn to safely control skidding or sliding by practicing at low speeds and on level, smooth terrain. On extremely slippery surfaces, such as ice, go slowly and be very cautious in order to reduce the chance of skidding out of control.

- 22. Never operate a quad in fast flowing water or in water deeper than that specified in this manual. Remember that wet brakes may have reduced stopping ability. Test you brakes after leaving water. If necessary, apply those several times to let friction dry out the linings.
- 23. Always use the size and type of tires specified in this manual. Always maintain proper tire pressure as described in this manual.
- 24. Never modify a quad through improper installation or use of accessories.
- 25. Never install a twist grip throttle on this quad.
- 26. Never exceed the stated load limits for a quad. Cargo should be properly distributed and securely attached. Reduce speed and follow instructions in this manual for carrying cargo. Allow greater distance for braking.

This vehicle complies with all applicable CE directives of Europe homologation in effect at the time of manufacture. You should check your local riding laws and regulations before operating this machine.

• When starting the engine, the battery must be installed to facilitate starting and increase the engine performance.

# When reading this manual, remember:

WARNING/!\

Indicates a potential hazard that could result in serious injury or death



# IV. CONTENTS

I. PREFACE	
II. INTRODUCTION	6
III. IMPORTANT SAFETY MESSAGE	8
IV. CONTENTS	
1. LOCATION OF THE WARNING AND SPECIFICATION LABELS	15
2. MACHINE IDENTIFICATION	18
2-1 Vehicle Identification Number (VIN)	19
2-2 Engine Serial Number	20
2-3 Key ID number	21
3. PARTS AND CONTROL FUNCTIONS	
3-1 Seat	
3-2 Main Switch	
3-3 Headlights	
3-4 Taillight	
3-5 Front Break Lever	
3-6 Parking Brake	33
3-7 Foot Brake Pedal	
3-8 Footpegs & Footboard	36
3-9 Shift Lever	
3-10 Fuel Tank Cap	
3-11 Handle Grips	
3-12 Throttle Lever	
3-13 Fuse	
3-14 Locking Steering	43

# OWNER'S MANUAL

3-15 Fuel Valve	44
3-16 Speedometer	
3-17 Fuel Tank	
3-18 Handlebar Assembly	47
3-19 Clutch Lever (manual)	50
4. SAFE OPERATION	51
4-1 Ride Sensibly	52
4-2 Crossing Through Shallow Water	53
4-3 Turning	54
4-4 Riding Down Slope	55
4-5 Climbing Hill	57
4-6 Modifications	59
5. PER-RIDE INSPECTION	60
5-1 Pre- Ride Checklist	61
6. OPERATION	62
6-1 Cold Starting	63
6-2 Starting a Warm Engine	64
6-3 Break-In	
6-4 Manual Shift	
U-4 IVIAITUAT OHIIL	

7. MAINTENANCE & ADJUSTMENT	
7-1 Work safely	72
7-2 Maintenance schedule	78
7-3 Air Filter	
7-4 Frame, Subframe, Swingarm	81
7-5 Fuel	
7-6 Engine Oil	87
7-7 Engine Cooling System	92
7-8 Brakes	
7-9 Electrical	103
7-10 Air	115
7-11 Exhaust	114
7-12 Suspension	115
7-13 Wheels	116
7-14 Tires	119
7-15 Vehicle Immersion	122
8. CLEANING	123
9. STORAGE	125
10. TRANSPORTING	126
11. TROUBLESHOOTING	127
12. MODEL SPECIFICATION	130
12-1 ENGINE	130
12-2 CHASSIS	132
12-3 BATTERY	134

# OWNER'S MANUAL

13. QUAD LIMITED WARRANTY	137
13-1 WARRANTY CONDITIONS	137
13-2 WARRANTY PERIOD	137
13-3 WARRANTY TRANSFER	137
13-4 WARRANTY EXCLUSION	137
13-5 COMPETITION MODEL EXCLUSION	137
13-6 PARTS AND LABOR COVERED BY WARRANTY	138
13-7 PARTS AND LABOR NOT COVERED BY WARRANTY	138
13-8 WARRANTY LIMITATION	140
14. MAINTENANCE RECORD	141
ADDENDA	142



# 1. LOCATION OF THE WARNING AND SPECIFICATION LABELS

Examples of all vehicle warning labels are found in this section. Read and understand the actual ones on your vehicle. The labels contain information which is important to your safety and that of anyone else who operates the quad.

- The warning labels should be considered permanent parts of vehicle, they are needed parts for any operator.
- If any label is missing, worn, damaged, or becomes unreadable, be sure to replace it.

  Dinli offers replacement labels at no charge. A label's number is printed in the lower right corner of the label and here parts number in the manual. Contact an authorized Dinli dealer for replacements.
- Label locations are shown in the following illustration. Examples of the labels are shown on the following pages.
- Always replace labels in the correct position. See the illustration for the correct location of the warning labels on your vehicle.



AWARNING

IMPRORER TIRE PRESSURE OR OVERLOADING CAN CAUSE LOSS OF CONTROL LOSS OF CONTROL CAN RESULT IN SEVERE INJURY OR DEATH.

COLD TIRE PRESSURE: Set with tires cold
• Recommended : FRONT : 50 tpa. (0.50tar) . 70ps.
REAR : : 50 tpa. (0.50tar) . 70ps.

LOADING

Maximum Veticle Load: 225 kg, (496 lbs) Inclodes weight of operator, cargo and accessories

A990235-00

4

AWARNING

Use care when refill coolant. Do not spill out coolant which may be corrosive to vehicle surface.

A990210-00

A990232-00




P/N



NEVER carry passenger on this carrier. MAXIMUM LOAD: 30 kg (66 lbs)

A990218-00







Do not consume alcohol, drugs or cigarettes before or during operating the ATV



Always stop the vehicle completely before changing from forward into reverse or vice versa.
Failure to do so may harm the gear box.



Maximum Vehicle Load: 225kg, (495 lbs) Includes weight of operator, cargo and accessories. Never load over 165kg or may cause loss of control.



Operating this ATV if you are under the age of 16 increases your chance or severe injury or death Never operate this ATV if you are under age 16.



Always wear protective clothing when driving your ATV.




Read the Owner's Manual before riding the vehicle.

# 2. MACHINE IDENTIFICATION

## NOTE:

Your vehicle may differ from those shown in the illustrations in this manual.

Record your vehicle's identification numbers in the spaces provided. Keep another record of the numbers in a safe place; you may need them for parts, service information, or theft recovery. Your vehicle's ID numbers identify it from others of the same model type.





## 2-1 VEHICLE IDENTIFICATION NUMBER (VIN)

The vehicle identification number (VIN) is etched / stamped into the right side of frame. The VIN also appears on a temporary factory applied adhesive label on the front frame

1. Etched vehicle identification number



2. Factory VIN LABEL



Write your number here

#### 2-2 ENGINE SERIAL NUMBER

The engine serial number is etched / stamped into the left crankcase of the engine.

1. Engine serial number

Write your number here





#### 2-3 KEY ID NUMBER


Key identification numbers are etched / stamped into key tag.

## NOTE:

Keep your spare key in a safe place in case you lose the primary key.

- 1. Primary key
- 2. Spare key
- 3. Tag (With Key ID number)

Write your number here



# 3. PARTS AND CONTROL FUNCTIONS

# NOTE:


Your vehicle may differ slightly from those shown in the illustrations in this manual



- 1. Clutch lever
- 2. Main switch
- 3. Parking brake lock

- 4. Rear brake lever
- 5. Throttle lever
- 6. Parking brake lever






- 1. Rear mirror
- 2. Headlight assembly
- 3. Fuel pump
- 4. Coolant recovery bottle
- 5. Radiator
- 6. Front shock absorber
- 7. Oil tank

- 8. Shift lever
- 9. Front wheel
- 10. Seat
- 11. Air filter(under seat)
- 12. Battery
- 13. Muffler
- 14. Starter motor

- 15. Footpeg & Footboard
- 16. Rear wheel



- 17. Speedometer & Indicator lights
- 18. Handlebar assembly
  Start switch
  Hazard switch
  Horn button
  Lights switch
  Turn signal switch

- 19. Tail light (stop light)
- 20. Rear turn signal lights
- 21. Rear shock absorber
- 22. Front turn signal lights
- 23. Handle grips
- 24. Fuel tank
- 25. Rear brake caliper



#### 3-1. SEAT

The entire length of the seat is required so that you can shift body weight / position while riding to maintain vehicle control and stability. Make sure the seat is in good condition and fastened securely before you ride.

- 1. To remove the seat, pull away the seat pull rod from the sub-frame.
- 2. Use your fingertips to lift up the rear of the seat slightly. Then, pull the seat back toward the rear of the vehicle and lift it off.



Pull rod

#### OWNER'S MANUAL

- 3. To install the seat, align the receiver on the seat with the catch on the frame.
- 4. Press down gently on the middle of the seat and slide the seat forward onto the catch of frame.

If correctly aligned, the rear seat pegs will slip easily.

A. Catch B. Receiver





# WARNING / N

## POTENTIAL HAZARD

Loose, damaged, or improperly installed seat

#### WHAT CAN HAPPEN

The seat can shift or come off while you are riding causing you to lose control of the vehicle, you can be severely injured or death.

#### **HOW TO AVOID THE HAZARD**

Always make sure the seat is locked into position on the mounts and secured properly with the retention bolt, Never ride the guad with a damaged seat. Have it replaced.

## CAUTION

Do not force the seat pegs through the holes in the rear fender or sub-frame buffers; you could damaged the seat


# When reading this manual, remember:

WARNING <equation-block>

Indicates a potential hazard that COULD result in serious injury or death.

#### 3-2. MAIN SWITCH

The main switch is located between the handlebars. Always remove the key from the switch to help prevent unauthorized vehicle use or theft.



Ignition switch & Switch positions



Functions of the respective switch position are as follows:

Key position	Function	Key
	The engine and lighting cannot be operated.	
"OFF"	Turning the main switch to the "OFF" position,	Removal
	will stop a running engine.	
	With the brake lever pulled in, the engine started	
	using the switch.	
"ON"	We recommend starting the engine with the	ON
ON	main switch in the "ON" position then switch to	
	the " position.	
≎	Lighting (headlights and taillight are activated)	ON

### 3-3. HEADLIGHT

Turn the main switch to the "Turn the main switch the main switch the "Turn the "T



Headlight



## 3-4. TAILLIGHT

Turn the main switch to the "Turn the main switch the "Turn the "




Taillight

#### 3-5. FRONT BRAKE LEVEL

The front brake lever is located on the right side of the handlebar. Pull it toward the handlebar to apply the front brakes. Pull the lever harder to increase braking force. Before each ride, make sure the front breaks are operating properly and can provide braking force when needed.

Roll the vehicle forward and back applying the brake to confirm that braking force is applied to the front brake discs.



Front brake level



#### **3-6. PARKING BRAKE**

The parking brake is applied with a button switch on the parking brake lever. When the parking brake is applied (locked), the front brakes temporarily prevent the vehicle from rolling.

Be sure to read the warning about using the parking brake!



Parking brake button

# WARNING !

# POTENTIAL HAZARD (s)

- 1. Quad rolling away
- Riding with the parking brake applied.

#### WHAT CAN HAPPEN

- A potential decline in fluid pressure can decrease the applied braking force allowing the quad to begin to roll.
- Brake system will overheat, cause premature wear, and damage to the brake pads. This car result in a loss of brake function to injure the rider or bystanders.

#### **HOW TO AVOID THE HAZARD**


- Always block or chock the wheels on your quad immediately after applying the parking brake Never apply the parking brake and leave the vehicle unattended.
   Always choose firm level ground on which to park your quad.
- 2. Release the parking brake before you ride.
- 1. To apply, pull the front lever against the handle grip and hold it. Press and hold the locking button with your index finger until it is fully depressed-release the lever and remove your index finger from the button.
- 2. To disengage the parking brake press down on the front brake pedal with your foot, Then, pull the front brake lever against the handle grip; the locking mechanism with automatically disengage (pop up)
- 3. Release the front brake lever slowly.



#### 3-7. FOOT BRAKE PEDAL

The foot brake pedal is located on the right side of the vehicle. When treaded, braking force is applied to the four wheels. Make sure the foot brake is operating properly before you ride.

Roll the vehicle forward and back and press the pedal to confirm that braking force is applied to the brake disc.



Foot brake pedal

#### 3-8. FOOTPEGS & FOOTBOARD

When riding always keep your feet on the footpegs. Always check the condition of the footpegs and footboard before every ride. Make sure that they are fastened securely to the vehicle.

The footpegs' teeth should be in good condition (not smooth or worn excessively). The footboard should be free of any packed soils and they should not be cracked, broken, or damaged in any way. If damage is found, install new ones.

- 1. Footpeg (right)
- 2. Footboard






#### 3-9. SHIFT LEVER

The shift lever is located on the left side of the engine in front of the left footpeg.

The vehicle has five forward and one reverse gears (Reverse, 1-down, "NEUTRAL"4-UP).


Place the vehicle on a lever surface. Before every ride, make sure the shift lever operates properly and shifts through the entire range of gears with the engine turned off; roll the vehicle forward and back as you shift through all the gears to avoid damaging the transmission.





### 3-10. FUEL TANK CAP

Make sure the fuel cap is tightly secured before every ride. Turn the fuel cap counterclockwise to remove it and clockwise to tighten it. Always make sure the breather hose is routed from the cap properly





#### 3-11. HANDEL GRIPS

Inspect both (left and right) handlebar grips before every ride. Make sure they are firmly attached and do not twist on the handlebar. Inspect the grips for wear, tears, or other damage.

Replace the grips with a new set if damage is found. Contact an authorized Dinli dealer for a replacement set.



Handle grip (right)

#### 3-12. THROTTLE LEVER

The throttle lever is located on the right side of the handlebar. When pushed, the engine speed will increase. When released, engine speed will decrease-the lever spring pressure should return the lever to the set idle (engine) speed. Check for proper operation and specified free play of the throttle before every ride.

Replace the cable if it has become worn or kinked. Lubricate the cable with lubricant to prevent premature wear or corrosion. Adjustment can be made with the adjuster beside the throttle lever. Loosen the lock nut and turn the adjuster.

## **Speed limiter**


The speed limiter is on the right handlebar.

The speed limiter keeps the throttle from fully opening, even when the throttle lever is pushed to the maximum.

Screwing in the adjuster limits the maximum engine power available and decreases the maximum speed of the vehicle.

Speed limiter

Throttle lever -





# WARNING /!\ POTENTIAL HAZARD (s

Improper adjustment of the speed limiter and throttle

### WHAT CAN HAPPEN

The throttle cable could be damaged.

Improper throttle operation could result

You could lose control, have an accident or be injured.

### **HOW TO AVOID THE HAZARD**


Do not turn the speed adjuster out more than 15 mm.

Always make sure the throttle lever free play is adjusted to 1.0~4.0 mm.

# 3-13. FUSE

The main electrical fuse is under the seat. Always replace the fuse with one of the specified rating.

1. 20A 2. 25A





#### 3-14. LOCKING STEERING

The lock insert is on the steering shaft underneath the front fender.

Sitting on the vehicle, turn the steering handlebar right to end and turn the key clockwise, the steering handlebar is locked. The key can be taken out.

Turn the key to left, the steering handlebar is released automatically. The key can be taken out.

# WARNING /!\ POTENTIAL HAZARD (s)

mproper use of the locking steering.


#### WHAT CAN HAPPEN

The vehicle could be lost of control or overturned.

#### **HOW TO AVOID THE HAZARD**

Always be sure you have released the locking steering handlebar before you begin to ride.

Never lock the steering handlebar, when the engine is starting.




#### 3-15. FUEL VALVE

The three way fuel valve is on the left side of the vehicle, which control the fuel from the fuel tank to the carburetor

**OFF**: With the lever in this position, gasoline cannot flow into the carburetor. Always turn the lever to this position when the engine is not running

ON: With the lever in this position, fuel flows from the tank to the carburetor. Normal riding is done with the lever in this position. RES: This indicates reserve. If you run out of fuel while riding, turn the lever to this position, then fill the fuel tank at the first opportunity, after refueling, return the fuel cock lever to the "ON" position.









# 3-16. SPEEDOMETER

N	Neutral
R	Reverse
$\Diamond$	Left turn
$\Rightarrow$	Right turn
<b>∃</b> D	High beam
A	Hazzard
4	Service
1.	Water temperature



• Turn signal indicator lights " □ "or" □ "

When the turn signal switch is operated, this indicator light will blink and the buzzer will sound.

• High beam indicator light " D "

This indicator light will come on when the light switch is switched to high beam and will go out when switched to low beam.

• Natural indicator light " N "

This indicator light comes on when the vehicle transmission is in neutral, always keep the vehicle in neutral if stop riding.

• Reverse indicator light "R"

This indicator light comes on when the transmission is in reverse.

• Hazard indicator light " 🚵 "

When the hazard switch is operated and turns signal lights are off, this indicator light will blink while all turn signals will blink simultaneously.

• Service light " 🔻 "

This indicator light will come on when the vehicle running mileage reach to 1000km, please have the vehicle for regular maintenance. See page141.

Water temperature light


When the main switch in "ON" if the 👢 light comes on automatically, you must stop the vehicle immediately and contact an authorized Dinli dealer.



#### 3-17. FUEL TANK

Fuel tank capacity is 12 liter including 0.8 liter in the reserve supply. Automotive gasoline with octane no.95 or higher may be used. After refueling, be sure to tighten the tank cap firmly. Do not refuel right after the engine has been running and is still hot. It is recommended to check the fuel level before you begin to ride

#### 3-18. HANDLEBAR ASSEMBLY



#### 3-18-1. LIGHT PUSH BUTTON

Push the switch to the "D" position to switch on the low beam and the taillight. Push the switch to the "D" position to switch on the high beam and the taillight.

#### 3-18-2. INDICATOR SWITCH

Use the indicator switch while turning to another direction or shifting to another lane.

The rear and front turning signal lights will wink when the switch is operated.

"

"

" for turning to the left. "

" for turning to the right.

The instrument turn signal indicator light will also blink when the switch is operated.

Pressing switch inward will cause blinkers to shut off.

### CAUTION

The turn signal light will not release automatically, be sure to push the indicator switch to release it otherwise it may affect the traffic safety.

The turn signal switch doesn't work when the main switch is "OFF"

#### **3-18-3. HORN BUTTON**

When the main switch is at the "ON" position pressing the horn button will cause the horn to sound.



#### 3-18-4. HAZARD SWITCH

- "O" At this position, all light will be turned out at the time.

# CAUTION

Turn on this switch when parking or there is special condition.

After the hazard switch is turned on, it will not rest. Be sure to push the switch to "●" to release it, other wise it may affect the traffic safety.

When the signal lights are winkling, the hazard switch does not work.

#### 3-18-5. STARTER SWITCH

The starter motor cranks the engine when this switch " 🙉 " is pressed.

#### NOTE

The headlight and taillight can be turned on only when the main switch is at the "\(\frac{\tau}{2}\)" position. The headlight and taillight can be turned on only when the engine is starting.

# CAUTION

See starting instructions prior to start engine. (Please see page 61 for details)

## 3-19. CLUTCH LEVER (MANUAL)

The clutch lever is located on the left side of the handlebar. Pull in the clutch lever (quickly) to disengage the clutch, and release the lever (slowly) to engage the clutch. Check the condition and proper operation of the clutch lever and cable before every ride. Also make sure the clutch lever free play is proper (2~4 mm)





# 4. SAFE OPERATION

When reading this manual, remember:

WARNING 🗘

Indicates a potential hazard that COULD result in serious injury or death

#### **EXPERIENCED RIDERS ONLY!**

WARNING !\
POTENTIAL HAZARD (s

### WHAT CAN HAPPEN

Dinli ATVs are high-performance machine only by operators who already have substantial skill and operating experience. Operating without substantial skill and operating experience increases the risk that you could lose control of the vehicle becoming severely injured or killed in a resulting accident.

#### **HOW TO AVOID THE HAZARD**

If you do not have substantial skill and operating experience

#### 4-1. RIDE SENSIBLY

- This quad is an ADULT vehicle only, operation is prohibited for anyone under 16 years of age.
- This quad is high performance vehicle intended for recreation and use by operators with advanced skills and substantial experience. Beginning and inexperienced riders should complete the certified training course, and should then regularly practice the skills learned in the course and the operating techniques described in this Owner's manual.
- The rider should wear the proper riding apparel which can help reduce the chance of injury in the event of an accident and make riding more comfortable.
- Riding too fast increase your chance of an accident occurring which could result in a serious injury or death. Do not ride faster than what is appropriate for your skill level and surrounding conditions.

# WARNING /!\ POTENTIAL HAZARD

Failure to follow the skill and experience recommendations for this guad.

#### WHAT CAN HAPPEN

The risk of an accident is greatly increased if the operate does not know how to operate the quad properly in different situations and on different types of terrain.

### **HOW TO AVOID THE HAZARD**

Beginning and inexperienced operators should complete the certified training course.

They should then regularly practice the skills learned in the course and the operating techniques described in this Owner's manual.

For more information about the training course, contact an authorized Dinli dealer

Riding your machine requires skills acquired through practice over a period of time.

Take the time to learn the basic techniques well before attempting more difficult maneuvers.



#### 4-2. CROSSING THROUGH SHALLOW WATER

The quad can be used to cross slow moving shallow water up to a maximum of 52 cm (20.5") in depth. Never attempt to ride any quad in deep or fast moving water, such as river or streams.

You could quickly lose control and become caught in water currents.


Never enter the water without checking out the area.

Check for any sharp drop off, rocks or other hidden obstacle and holes which may trap disable or resulting the vehicle become submerged. Travel at reduced speed.

Remember that wet brakes may have reduced stopping ability. Test your brakes after leaving water until you have regained proper braking ability.

#### 4-3. TURNING

It is essential that this skill shall be learned at first at low speed. The ride must learn to move his weight and control the throttle to allow the rear tires to get the turn. When turning, the wheel on the outside of the turn must travel a wider radius and thus a greater distance than the inside wheel. As the rear axle does not permit a differential rate of wheel rotation, it is not enough to merely steer this vehicle into a turn. To turn steer in the direction of the turn, leaning your body to the inside of the turn, while supporting your weight on the outer footrest. Use the throttle to maintain power throughout the turn. Incorrect turning may cause the front wheels to slide straight ahead. If this should occur, close the throttle and stop. Avoid barking or accelerating until you have regained directional control. Be careful to avoid skids while traveling on slippery terrain.





#### 4-4. RIDING DOWN SLOPE

When riding down slope, shift your weight back as far as possible with your arm straight.

Choose a low gear to allow the engine to do most of braking for you. Improper braking may lead to a loss of traction and vehicle control resulting in an accident.

# WARNING /!\ POTENTIAL HAZARD

Failure to use extra caution when traveling downhill improperly.

#### WHAT CAN HAPPEN

Could cause loss of control or overturn.

#### HOW TO AVOID THE HAZARD

Always be follow proper procedure for traveling down hill as described in this Owner's manual



#### NOTE:

A special technique is required when braking as you go down a slope

Always check the terrain carefully before descending any slope. Shift your weight backward.

Never travel down a slope at high speed.

Avoid traveling down a slope at an angle that would cause the vehicle to lean sharply to one side. Go straight down the slope when possible.



#### 4-5 CLIMBING HILL

Climbing hills is an advanced technique. Before attempting to climb difficult hills, practice on flat round and then smaller hills to build experience.

Never attempt a hill or slope beyond your skill level and evaluate all hills and slopes carefully to avoid terrain that may cause the quad to overturn.

WARNING !\
POTENTIAL HAZARD
Climbing hill improperly

### WHAT CAN HAPPEN

Could cause loss of control or overturn.

#### **HOW TO AVOID THE HAZARD**

Always follow proper procedure for climbing hill as described in this Owner's manual.



#### NOTE:

Always check the terrain carefully before ascending any hill.

Shift your weight forward.

Never operate the quad on hill steeper than 25

Never climb hill with excessively slippery or loose surface.

Keep both feet on the footrests, maintain steady and controlled throttle openings.



#### 4-6. MODIFICATIONS

Do not modify your quad to carry cargo.

# WARNING /! POTENTIAL HAZARD

Operating this quad with improper modifications.

#### WHAT CAN HAPPEN

Improper installation of accessories or modification of this vehicle may cause changes handing which could lead to an accident.

#### **HOW TO AVOID THE HAZARD**

Never modify this quad through improper installation or use of accessories. All parts and accessories added to this vehicle should be genuine DINLI or equivalent components designed for use on this quad and should be installed and used according to approved instructions. If you have question, consult an authorized DINLI dealer.

# **5. PRE-RIDE INSPECTION**

# WARNING /!\ POTENTIAL HAZARD

Failure to inspect vehicle before operating

#### WHAT CAN HAPPEN

Increases the possibility of equipment failure resulting in an accident.

#### **HOW TO AVOID THE HAZARD**

Always inspect this guad before you operate it.

Always follow the inspection and maintenance procedures found in this Owner's Manual. Have your vehicle serviced by an authorized Dinli dealer every 20 hours of operation, and per 1,000 Km riding.

# When reading this manual, remember:

WARNING /

Indicates a potential hazard that COULD result in serious injury or death.



#### PRE-RIDE CHECKLIST

ITEM	CHECK	PAGE
Apparel	Condition of (helmet, eye protection, boots, gloves, long-sleeved shirt and long trousers).	_
Brakes	Proper operation, fluid levels, hand break lever free-play, leaks. Fill with DOT4 brake fluid if necessary.	96 – 102
Clutch	Proper operation, condition, and lever free-play, actuating arm position	50
Coolant	Coolant level, fill with coolant if necessary.	92 – 95
Drive	Clean and lubricate the drive chain. Check drive chain slack, sprockets, swing arm buffer, rollers, and guide block.	_
Engine	*Oil level. Fill with engine oil if necessary.	87 – 91
Fuel	Fuel level. Fill with fuel if necessary.	47, 84, 85
Wheels/Tires	Wheels (for damage), tire pressures (all four) and condition. Replace if damaged. Add air required.	116 – 121
Steering	Handlebars turn freely; no binding of the cables/hoses throughout the full steering range.	43
Chassis (frame)	Inspect the frame, sub-frame, and swing arm for bending, cracks, or other damage. Don't ride if damage is found.	81 – 83
Fenders, covers, Bolts/Fasteners	Secure, tightness	_
Lights	Proper operation (headlights, taillight and turning lights).	28– 31 105, 106
Throttle	Proper operation, condition lever freeplay	40, 41, 86
Battery	Check connections	107, 108, 134 – 136

**<sup>%</sup>If you have any doubt, not understanding or difficulty in inspection or adjustment with this quad, we suggest to contact the nearby service point or a Dinli's dealer.** 

# 6. OPERATION

# WARNING (!) POTENTIAL HAZARD

Operating the quad without being familiar with all the control.

#### WHAT CAN HAPPEN

Losing control which can cause an accident where you can be severely injured or death.

#### **HOW TO AVOID THE HAZARD**

Read the owner's manual carefully and be sure you understand everything in it before operating the vehicle.

If you don't understand something, ask a Dinli dealer.

# **General Starting Tips CAUTION**

Only hold the start switch for 2-3 seconds at a time.

Since a cold engine requires more fuel, repeated and shorter cranking attempts should be used to deliver the extra fuel needed. If you crank more than 2-3 seconds you're wasting battery power.



#### 6-1. COLD STARTING

- 1. Make sure the vehicle is on level ground and the transmission is in NEUTRAL.
- 2. Lock the parking brake and make sure the fuel valve is on.
- 3. Turn the main switch to the "ON" position
- 4. Shift transmission into NEUTRAL, the indicator "N" will be visible in green light on the meter, and pull-in and hold in the rear brake lever.
- 5. Carefully take up the throttle lever free play, then take up 2 mm more

5mm throttle lever free play



- 6. Press and hold the engine start switch for no more than 2 to 3 seconds at a time. If the engine "pops" or seems to backfire you're holding the throttle open too much. 1 mm is a very fine lever movement. Back the lever off, wait briefly, and re-try.
- 7. When the engine fires, hold the throttle at a fast idle for 10 seconds or until a smooth idle is obtained.
- 8. Always wait for the engine to reach operating temperature (70°C) before riding; or at idle for 3 minutes before riding.
- 9. Release the parking brake before riding

#### 6-2. STARTING A WARM ENGINE

When starting an engine after it has reached operating temperature, do NOT open the throttle while operating the starter motor. This will make starting very difficult and possible foul the spark plug.



#### 6-3. BREAK-IN

The brake-in period is critical to the long term life and reliability of the engine. The break-in period for the engine is at least 1 hour.

When operating during this period be sure to observe the following cautions:

- Ride at low to medium engine speeds, Keep the speed below 70Km/ hr.
- Do not lug or rev the engine during the break-in period.
- Avoid full-throttle starts and rapid acceleration.
- Do not hold the throttle grip in one position for more than a few seconds. It is better to roll the throttle on and off and ride on flat terrain.
- Avoid riding up steep hills and in sand because this produces greater engine loads, possibly damaging engine components.
- 1. Ride the ATV normally for two 10-minute segments using no more than 1/2 throttle. Wait for the engine to cool completely between segments.
- 2. Next, ride three 15-minute segments using no more than 3/4 throttle, again allowing the engine to cool between rides.

#### NOTE:

During all rides, it is important to shift gears often so that high rpms are avoided and the engine is not lugged

#### OWNER'S MANUAL

- 3. After riding the vehicle, clean it thoroughly and allow it to dry. Then inspect the entire vehicle for damage or loose fasteners.
- 4. Repair or tighten any damaged or loose components and lubricate the vehicle.
- 5. If the vehicle is damaged, it is recommended that you put tape over the main switch to remind you to not start the vehicle. And write the problem on your Owner's Manual.
- 6. Complete the break-in period maintenance schedule. See "Maintenance & Adjustment" starting on page78.



#### 6-4. MANUAL SHIFT

#### 6-4-1. FORWARD

The gear shift pedal is located in front of the left footpeg. One full stroke of the pedal shift the transmission to the next gear in the shifting sequence. The pedal automatically returns to a horizontal position when released. To upshift to a higher gear, place the toe of your boot under the gear shift pedal and raise the pedal one full stroke. To downshift, place your foot on the gear shift pedal and depress the pedal one full stroke.



# WARNING /!\ POTENTIAL HAZARD

Shift without releasing the throttle and disengaging the clutch.

#### WHAT CAN HAPPEN

Could cause loss of control or vehicle overturn.

#### **HOW TO AVOID THE HAZARD**

Always release the throttle and fully squeeze the clutch lever while shifting gears.

### NOTE:

Always allow a cold engine to warm up before shift gears.

- 1. Turn the main switch to the "ON" position, the speedometer will light up.
- 2. Shift the transmission into "N", the indicator "N" will light up on the meter.
- 3. Squeeze and hold the brake lever.
- 4. Squeeze and hold the left clutch, push the start switch to start the machine
- 5. Depress the gear shift pedal one full stroke to shift into first gear. Then release the brake lever.
- 6. Gradually squeeze the throttle lever while slowly releasing the clutch lever.
- 7. As engine speed increases in first gear, simultaneously release the throttle, disengage the clutch and shift to second gear by raising the gear shift pedal one full stroke.




8. Use the same procedure to change gear pattern as recommended:

Gear	Speed Recommended for shifting gear
1 <sup>st</sup>	After start
2 <sup>nd</sup>	Approach 30km/h
3 <sup>rd</sup>	Approach 50km/h
4 <sup>th</sup>	Approach 65km/h
5 <sup>th</sup>	Approach 75km/h

9. To slow or stop the quad, release the throttle lever and apply the brakes smoothly and evenly. As the vehicle slows and engine RPM decreases, disengage the clutch and shift to a lower gear.

#### 6-4.2 REVERSE SWITCH

The reverse switch is located on speedometer cover.



Make sure the machine is at the "1st" gear, turn right the "REVERSE" switch and set down the shift lever. Simultaneously

Release the "reverse" switch and clutch lever to engage the "REVERSE" gear. The "R" indicator lights on.



# 7. MAINTENANCE & ADJUSTMENT

## **Regular Maintenance**

Periodic inspection, adjustment and lubrication of your vehicle helps keep it safe and reliable to operate. The maintenance schedule provided in this section is intended as a general guide only. Where you ride (geographic location), the weather conditions, terrain (e.g. sand, dirt, dusty, wet, etc.), and your riding style all influence how often a maintenance item should be performed. For example, if you ride in sandy conditions the time (interval) between servicing will be shortened because sand is very abrasive and will act to wear vehicle components more quickly.

# **Your Ability**

If you do not feel comfortable or in any way doubt your own abilities to perform a procedure described in this manual, don't attempt it; have an authorized Dinli dealer perform the servicing

#### 7-1. WORK SAFELY

Make sure you read and understand the warnings at the beginning of this section.

# **Carbon Monoxide**

# DANGER /!\ POTENTIAL HAZARD


Running the engine indoors. Breathing exhausts gases.

#### WHAT CAN HAPPEN

Running the engine indoors will expose you to dangerous exhaust gases.
Breathing carbon monoxide gas leads to poisoning, asphyxiation, and death.
This will happen rapidly and without notice.

#### HOW TO AVOID THE HAZARD

Never operate the vehicle indoors even for brief periods of time.





# **Hot Components**

# WARNING ! POTENTIAL HAZARD


Hot components (e.g., engine, radiator, hoses, bulbs, exhaust, brakes)

## WHAT CAN HAPPEN

The engine and other vehicle systems operate a extremely high temperatures.

# **HOW TO AVOID THE HAZARD**

Wait for the engine and vehicle systems to cool completely before starting any work. If the engine must be running work carefully and avoid hot surfaces.



# **Gasoline**

# WARNING ! POTENTIAL HAZARD

Improper care when handling fuel


## WHAT CAN HAPPEN

Fuel is highly flammable; spilling it can cause a fire or explosion.

# **HOW TO AVOID THE HAZARD**

Be sure the fuel cap is closed securely.

Work in a well-ventilated area which is free of sources that could ignite any spilled fuel accidentally (e.g. cigarettes, welders, torches, grinders, electric shop tools, etc.)





# **Protect Your Eyes**

# WARNING ! POTENTIAL HAZARD


Blindness, eye injury

## WHAT CAN HAPPEN

Anytime you work on the vehicle there is a potential that an accident involving a foreign object, vehicle component part, fluid, tool, or other maintenance related item can result in severe injury to your eyes.

# **HOW TO AVOID THE HAZARD**

Always wear safety glasses when working.



# **Moving parts**

# WARNING ! POTENTIAL HAZARD


Losing a finger, hand or limb or entanglement

# WHAT CAN HAPPEN

Moving parts can catch your clothing, fingers or hand resulting in severe injury.

# **HOW TO AVOID THE HAZARD**

Never perform maintenance procedures with the engine running.





## **Fluids**

# WARNING ! POTENTIAL HAZARD

Vehicle fluids (e.g., engine oil, brake fluid, coolant)

## WHAT CAN HAPPEN

The fluids in your vehicle are hazardous substances. Contact with your skin or eyes you can result in serious injury or irritation.


If swallowed, death can result.

# **HOW TO AVOID THE HAZARD**

Wear hand protecti9on and safety glasses when working with vehicle fluids.

If you touch a fluid, wash it off immediately with soar and water. Clean clothes or rags contaminated with engine oil.

If swallowed seek immediate medical attention



### **\*KEEP ALL VEHICLE FLUIDS AWAY FROM CHILDREN AND ANIMALS**

### 7-2. MAINTENANCE SCHEDULE

Perform a Pre-Ride inspection before every ride and a sch edule maintenance periods.

C=Clean R=Replace L=Lubricate I=Inspect, Verify, Clean, Adjust, Lubricate, Replace if necessary		Interval (whichever comes first)								
		Regular Maintenance Internal (house)							Regular Maintenance (Riding Km)	
Items	Interval	Break in (1 hour)	Initial After 10 hr	Every 1 month	Every 3 month	Every 6 month	Note	200 Km	500 Km	1000 Km
	WARNING LABELS (condition, readable)	ı	I	I	I	I	ı	ı	I	I
	FRAME (mainframe, subframe, swingarm)	1	- 1	- 1						
	FUEL SYSTEM (hoses, tank, level)	1	- 1							I
	BATTERY (terminals)			I,C				1		
•	THROTTLE OPERATION	- 1	I		I				I	_
	AIR FILTER	- 1	С			R	*	I		
	AIRBOX DRAIN TUBE		I,C		-		*	ı		_
	SPARK PLUG		- 1		R					R
0	IDLE SPEED		I		-			Adjust as required		red
•	EXHAUST (spark arrester)			С						С
	SWITCHES (engine, stop, start, tether, ignition)	I			I		*			
•	LIGHTING (headlight, tail light, turning lights)	- 1		1						
	ENGINE OIL	I	R			R	*	R		R
<b>A</b>	ENGINE OIL FILTER (s)	С	R			R	*	R		R

<sup>▲</sup>DINLI dealer service suggested servicing owners should have the proper tools, service data, and be mechanically qualified.

Operational safety involved. The service should be performed by a DINLI dealer.

<sup>★</sup>Service more frequently if operation in dusty, sandy or snowy area or conditions.

<sup>\*</sup>Change every 2 years.



C=Clean R=Replace L=Lubricate I=Inspect, Verify, Clean, Adjust, Lubricate, Replace if necessary		Interval (whichever comes first)								
		Regular Maintenance Internal (house)						Regular Maintenance (Riding Km)		
Items	Interval	Break in (1 hour)	Initial After 10 hr	Every 1 month	Every 3 month	Every 6 month	Note	200 Km	500 Km	1000 Km
	DRIVE CHAIN [sag, stretch, buffer, guide block, sprockets(condition/tightness), guard]	I	1		I		*		I	
0	BRAKE FLUID	I				I				ı
<b>A</b>	BRAKE SYSTEM (cables, discs, pads, hosed, etc.)	I			I		*	1		
	BRAKE, REAR, DISC CARRIER	I	I		I			I		
<b>A</b>	CLUTCH (lever, cable and arm position)	I	I		I					
	COOLANT (radiator, cap, hosed, level, strength)	I			-	R	*		-	
	SUSPENSION (front/rear shocks, condition, setting)	I	I							
	NUTS, BOLTS AND FASTENERS		-						- 1	
0	SEAT (condition, wear, damage)	I								
•	WHEELS/TIRES (pressure, condition, wear)	I	-							I
	SWINGARM (bearings)		I	Ī			*			
<b>A</b>	Steering assembly (fasteners, operation)						*			I
	A-ARM (BUSHINGS ball joint)			I			*		I	
	TIE ROD ENDS	I	I	I			*		I	

<sup>▲</sup>DINLI dealer service suggested servicing owners should have the proper tools, service data, and be mechanically qualified.

Operational safety involved. The service should be performed by a DINLI dealer.

<sup>★</sup>Service more frequently if operation in dusty, sandy or snowy area or conditions.

<sup>\*</sup>Change every 2 years.


# 7-3. AIR FELTER

#### NOTE

The air filter is located under the seat

Do not operate with the air filter removed. You can seriously damage the engine.

- 1. Cover of air filter
- 2. Cogs x 4
- 3. Clip





# 7-4. FRAME, SUBFRAME, SWINGARM

# **Regular Inspection**

The steel chassis components of your quad have a finite, limited useful life. The length of that life varies depending on the material used in their manufacture, the amount of use they are subjected to and the care they receive while in service. Regular inspection by a DINLI dealer is important

- Frame a main support structure for the engine, various components, and rider.
- Sub frame adds structural support.
- Swing arm- a suspension component.
- Bumper- mounted on the front of the ATV.

Use in hard and aggressive riding, riding on severe terrain, riding in severe climates and riding fast can dramatically shorten the life of the steel (frame) components. Any one and/or a combination of these condition may result in an unpredictable failure.

We recommend that you carefully inspect your quad's chassis components for cracking, bending, deep scratches and/or other damage before every ride.

If you have crashed or rolled your quad, there could be damage hidden from your view, DO NOT ride a quad with any crack, even a small one. It must be carefully inspected by an authorized DINLI dealer before it is used again. Riding a cracked frame could lead to complete frame failure. If you have any questions contact your DINLI dealer.

# WARNING !! POTENTIAL HAZARD(s)

- 1. Operating with a bent, corroded/rusted, cracked, dented, or damaged frame, subframe, swingarm or other steel components.
- Attempting to repair the frame, subframe, or swingarm on the ATV.

## WHAT CAN HAPPEN


- 1. Riding on a damaged frame can lead to a complete frame failure
- Steel frame (and components) are heat treated. Welding, drilling, or modifying the frame, subframe, or swingarm may weaken the component and result in complete failure leading to a serious accident with subsequent injury or death.

## **HOW TO AVOID THE HAZARD**

Contact an authorized DINLI dealer for servicing if either the frame, subframe or swingarm is damaged; never try to repain the frame, subframe, swingarm or other components.



- 1. Frame
- 2. Rear shock strut
- 3. Subframe
- 4. Swingarm5. Engine rail/skid plate
- 6. Bumper



## 7-5. FUEL

Always use clean high quality unleaded gasoline. (Octane 95 above is recommended)

# WARNING /!\ POTENTIAL HAZARD

Over filling the fuel tank.

## WHAT CAN HAPPEN

Fuel expands due to heat (e.g., engine, sun) and may overflow if the tank is overfilled, resulting in a fire.

## **HOW TO AVOID THE HAZARD**

Stop adding fuel when the correct level is reached.

# CAUTION

If engine "knocking" or pinging occurs, use a different brand of gasoline or a higher octane rating.

Never experiment. Other fuels or additives can severely damage the engine and its supporting components (e.g. fuel system, sensors, tank, hoses, etc...)



#### 7-5-1. ADDING FUEL


- 1. Make sure the engine is stopped.
- 2. Remove the main switch key.
- 3. Remove the fuel cap and fill the fuel tank with the specified fuel to the correct level.
- 4. Reinstall fuel tank cap and tighten it securely.
- 5. Make sure the fuel cap hose is routed correctly.

#### 7-5-2. IDLE SPEED ADJUSTMENT

The idle speed adjustment screw is located on the carburetor body. It is accessible from the left side of the vehicle. A special diagnostic tool is necessary to read (display) the engine rpm.

For this reason, idle adjust should be left to a DINLI service technician.

- 1. To adjust the idle, allow the engine to reach operating Temperature 158 $^{\circ}$ F (60 $^{\circ}$ C)
- 2. Set the idle speed by turning the adjuster (1) in direction (a) Increase idle speed, or direction (b) to decrease idle speed.
  - (1) Adjuster
  - (a) Increase (clockwise)
  - (b) Decrease (counterclockwise)




#### 7-5-3. THROTTLE LEVER ADJUSTERMENT

Loosen locknut and then turn the adjuster until the specified freeplay is reached. Tighten the locknut.

- 1. Rubber boot
- 2. Locknut
- 3. Adjuster

#### NOTE:

If the proper adjustment cannot be obtained or the throttle lever does not operate properly, the cable end at the throttle body can be adjusted; however, access to it is difficult and should be left to a qualified service technician. See your DINLI dealer for servicing.





#### 7-6. ENGINE OIL

Engine oil is a significant factor in the service life and performance of the engine.

Change the engine oil in accordance with the maintenance schedule. See "Maintenance & Adjustment" starting on page 78. Service more frequently under severe conditions.

#### 7-6-1. CHECKING ENGINE OIL

Check the oil level before each use of vehicle. The oil level screen is located in the right crankcase cover.

# CAUTION


Run the engine for 1 minute before checking or you will take an inaccurate measurement.

Add in small amounts and recheck the level between pours.

- 1. To check the level, start the engine and allow to run for 1 minute at idle speed, then turn off the engine.
- 2. Remove the dipstick.



1. Engine oil dipstick



2. Markings

- 3. Wipe the dipstick with a clean rag and screw back in completely. Then remove and inspect the level on the stick. The oil level should be between the markings on the dipstick. If low, add a sufficient amount of oil to raise it to the correct level. Do not overfill.
- 4. Reinstall the dipstick.

If the quad is used year-round, check the oil level frequently. A rising oil level could indicate the accumulation of contaminates such as water or excess fuel in the bottom of the oil tank.

Water in the bottom of the tank can lead to engine damage and must be drained.

Water accumulation increase as outside temperature decreases.




#### 7-6-2. CHANGING ENGINE OIL

Always change the oil at the intervals outlined in the "MAINTENANCE SCHEDULE" see page 78. Perform a break-in oil change after one hour of operation, or after the first tank of fuel, whichever comes first, change the oil more frequently on vehicles subjected to severe use.

# NOTE:

Have a clean shop towel handy to clean up any spilled oil.

- 1. Start the engine and wait to reach normal operating temperature 158  $^{\circ}$ F (70  $^{\circ}$ C) (it takes around 2~3 minutes). Then, turn the engine off.
- 2. Place a drain pan beneath the oil tank and remove the drain plug
  - 1. Drain plug




- 3. Allow the oil to drain completely.
- 4. Replace the sealing washer and reinstall the plug & torque to 19 Nm.


# NOTE:

The sealing surfaces on drain plugs, and crankcase should be clean and free of burrs, nicks or scratches.

5. Place a drain pan beneath the crankcase and remove the drain plug.



**Drain plug** 



1. Bolt 2. Cover 3. O-ring 4. Filter



- 6. Allow the oil to drain completely.
- 7. Replace the sealing washer and reinstall the plug & torque to 19 Nm.
- 8. Place shop towels beneath the oil filter.
- 9. Remove the three cover bolts and remove the cover.
- 10. Pull out the oil filter.
- 11. Using a clean dry cloth, clean the filter sealing surfaces.
- 12. Replace the o-ring in the cover.
- 13. Lubricate the gasket on the new filter with a film of fresh engine oil.
- 14. Reinstall the spring and install the new filter.
- 15. Install the cover and torque the bolts to 8~9 Nm.
- 16. Remove the dipstick and fill the oil tank with the recommended oil.
- 17. Place the transmission in Neutral and set the parking brake.
- 18. Prime the oil pump using the procedure on page 92. Then stop the engine and inspect for leaks.
- 19 Re-check the oil level on the dipstick and add oil as necessary to bring the level to the upper mark on the dipstick.
- 20. Dispose of the used filter, oil and shop towels properly.

# CAUTION

Do not over-tighten the drain plug. You will damage the threads of the filter housing. If the cover leaks, you may need to replace the cover O-ring or inspect the cover and housing mating surfaces for damage.

#### 7-6-3. OIL PUMP PRIMING

This priming procedure must be performed whenever the oil hose connection between the oil tank and pump inlet has been disconnected.

- 1. Clamp or pinch off the vent line approximately 2" from the oil tank.
- 2. Run the engine for 5-10 seconds at idle. Stop the engine and remove the vent line clamp.

If the line is bled properly, you should hear a rush of air, indicating that the line is properly primed and ready for operation. If you do not hear air, the line has not bled, and you'll need to repeat the priming procedure.

#### 7-7. ENGINE COOLING SYSTEM

#### 7-7-1. COOLANT LEVEL

The engine coolant recovery bottle is located on the left side of the vehicle under the front fender. Check the coolant level in the bottle when the engine is cold, the fluid level in the bottle will vary during operation. Maintain coolant at the "LEVEL" mark on the bottle when the engine is cold. We recommend a 50/50 mixture of high-quality aluminum compatible anti-freeze/coolant and distilled water.

WARNING POTENTIAL HAZARD

WHAT CAN HAPPEN

Coolant can sprayed out under high pressure if the bottle is opened while the system is hot.

**HOW TO AVOID THE HAZARD** 

Wait for the engine to cool completely before removing the cap.



- 1. Coolant bottle
- 2. Bleed hose



#### NOTE:

The coolant system on your vehicle is the self bleed type and the hose should be visible.

#### 7-7-2. CHECKING THE COOLANT LEVEL

- 1. Make sure the engine and radiator are completely cold.
- 2. Observe the coolant level in the recovery bottle without opening the cap. The level should be between "FULL" and "ADD" mark

"FULL" & "ADD" mark



#### 7-7-3. ADDING COOLANT

- 1. To add coolant, make sure the engine is cold.
- 2. Place a thick rag over the coolant bottle cap and open it very slowly to allow any residual pressure to escape. Then, remove cap and slowly add the specified coolant using a clean funnel until it reaches the "FULL" mark.
- 3. Reinstall the cap and check coolant system for leaks



#### 7-7-4. CHANGING THE COOLANT

- 1. Make sure the coolant system is completely cold and you are wearing safety glasses and protective rubber gloves. Have a few clean rags handy to wipe up any spills.
- 2. Remove the clip.
- 3. Remove coolant recovery bottle tube to allow coolant to drain completely. Reinstall the tube and clip.
- 4. Add the specified coolant at the bottle until it reaches the LEVEL mark on the bottle.

When reading this manual, remember:

WARNING /!

STOP! If you have the impression that four wheels give you the stability of a car, you are wrong. If you

### 7-8. BRAKES

#### 7-8.1 SYSTEM TEST

- Squeeze the left hand brake lever and test for proper braking. The lever should feel firm and proportional force should be applied to the discs preventing the quad from rolling.
   If the brake lever feels spongy or weak, or the vehicle is not prevented from rolling have the brakes inspected by a DINLI dealer.
- 2. Check for fluid leaks. Inspect the entire length of the hoses paying close attention to the banjo bolts, calipers, and master cylinders.
- 3. Check the right foot brake pedal for proper operation by pressing it with your foot. You should feel firm resistance when braking. As with the foot brakes, force applied to the pedal should be forward to the front and rear discs preventing the vehicle from rolling. If the foot brake operates improperly have a DINLI dealer inspect the system.
- 4. Inspect the rear brake pads for wear.
- 5. Test both brake systems at slow speed. Make sure that both systems function properly and that there is proper braking force available always.
- 6. When riding in wet conditions or after exiting a water crossing, apply the brake lightly a few times so that the heat of friction will dry the pad and discs. If water remains on the system, you will not have adequate braking power when needed



#### 7-8-2. BRAKE FLUID

# WARNING /! POTENTIAL HAZARD

Using contaminated brake fluid, using brake fluid other than DOT4, mixing brake fluid types.

## WHAT CAN HAPPEN

Brake performance can be reduced or brakes can fail resulting in a serious accident.

## **HOW TO AVOID THE HAZARD**

Use only DOT4 brake fluid from a sealed container. Fluid from an opened container, even though the cap has been returned, can absorb moisture and may be contaminated with dust and dirt.


## CAUTION

Do not spill brake fluid on painted, plastic or rubber parts or surfaces. Place a shop towel or rag over these parts when servicing the brake system.

If you do spill fluid on these parts, wash it off immediately.

#### 7-8-3. HAND BRAKE

- 1. To check the hand brake system, place vehicle on a level surface and level the handlebars.
- 2. Inspect the fluid level through the inspection window in the master cylinder reservoir. The fluid should be above the "LOWER" make on reservoir body. Add fluid if necessary.
- 3. To add, wipe any dirt or debris from the master cylinder housing and cover.
- 4. Remove the hand brake master cylinder cover screws, cover, and diaphragm
  - (1) Inspection window
  - (2) "LOWER" mark





- 5. Add the recommended brake fluid from a sealed container until the fluid level is above the "LOWER" mark on the reservoir body.
- 6. Reinstall the diaphragm, cover, and cover screws.

#### NOTE

The hand brake master cylinder reservoir is located on the left side of the vehicle handlebar. Make sure the vehicle is on a level surface and the reservoir itself is level when checking. Clean the area surrounding the reservoir before opening it to help prevent fluid contamination.

#### 7-8-4. FOOT BRAKE

- 1. To check the foot brake fluid level, place vehicle on a level surface and make sure the reservoir itself is level. The fluid level should be above the "MIN" mark. Add if necessary.
- 2. To add, clean the cap and surrounding area thoroughly before opening. Pour the specified brake fluid from a clean container until it reaches over the "MIN" mark. Reinstall the diaphragm, insert, and cap.
- 3. Be sure to check for proper brake operation before riding the vehicle




"MIN" mark



#### 7-8-5. PARKING BRAKE

When parking, squeeze each hand brake lever. While doing this, press the parking brake button on each handlebar brake set. This will result in locking the brake lever. Make sure that the brake lever is locked to ensure that the ATV will remain safely immobile while parked. Squeeze the hand brake lever one again and the parking brake will be released.

Always set the parking brake to help prevent the vehicle from moving, when it is being parked, being started or idling.



Parking brake (right side)

# WARNING /!\ POTENTIAL HAZARD

Riding with improperly operating brakes.

## WHAT CAN HAPPEN

You could lose braking ability, which could lead to an accident

## **HOW TO AVOID THE HAZARD**

Check the brake cable for kinks or signs of wear that could cause sticking or failure.

Lubricate the brake cable with a available cable lubricant to prevent premature wear or corrosion

Make sure that the brake arm, spring, rod and fasteners are in good condition.

Ask you dealer to inspect brakes when you feel some problems or have doubts.

Ask the maintenance station to replace the pads when they are almost in contact with the disc plate.



#### 7-9. ELECTRICAL

Many electrical problems are caused by faulty electrical connectors or couplers. For example, wet terminals/pins, dirty or corroded terminals/pins, or broken or bent cable pins within multi-plug couplers


#### 7-9-1. COOLANT TEMPERATURE SENSORS

The engine temperature sensor is brass, located on the left side vehicle.

If the engine temperature is too high, the "high-temp" indication located on meter will light on.

You should stop riding/using the vehicle immediately and have the vehicle inspected by authorized DINLI dealer.

Coolant temperature sensor



#### 7-9-2. FUSE

The fuse holder is located under the seat. When a fuse blows repeatedly, it usually indicates a short circuit or current overload in the electrical system. The problem could be intermittent or constant. Don't ride the vehicle in either case because an electrical fire could lead to a serious accident. If you experience frequent fuse "blows," have the vehicle inspected by an authorized DINLI dealer.

# WARNING (!\) POTENTIAL HAZARD

Electrical fire or damage to the quad electrical system

## WHAT CAN HAPPEN

A malfunctioning electrical system increases the risk that you may be seriously injured or killed while operating the vehicle. For example, an electrical fire can develop from a system overload or you could lose vehicle lighting. Using a fuse with a rating other than specified or using other materials in place of the fuse will cause damage to system.

## **HOW TO AVOID THE HAZARD**

Always use a replacement fuse of the specified rating.

Never use other mater4ials in place of the fuse.

If a fuse blows immediately after replacement have the electrical circuits checked by an authorized DINLI dealer. Always turn OFF the main switch when checking or replacing the fuse. Otherwise a short circuit may occur. Check the condition of the wiring harness and connectors before replacing a blown fuse.

Make sure the main switch is OFF.



#### 7-9-3. LIGHTING


#### NOTE:

Always wipe off a newly install bulb with alcohol-dampened clean cloth or tissue

Oils from your fingers can cause premature bulb failure

# Headlight bulb replacement

- 1. Move the rubber boot [A] & fixture [B] from the headlight housing and remove the bulb.
- 2. Install a new bulb unit into the housing.
- 3. Test for proper operation.



# Taillight bulb replacement

Push and turn the bulb mount counterclockwise to remove it from the housing

- 1. Move the rubber boot [A] and pull the bulb out from mount and install a new bulb.
- 2. Push the new bulb into mount and turn clockwise to reinstall it.
- 3. Test for proper operation.



Bulb



#### 7-9-4. BATTERY

All models use a sealed type battery therefore they do not require any maintenance other than routine charging such as during storage and cleaning. Always have the battery serviced by an authorized DINLI dealer.

# CAUTION

Never attempt to add water to a maintenance-free battery.

Never allow a battery to stand in a discharged condition

# WARNING /!\ POTENTIAL HAZARD

Attempting to open the battery, remove the cap strip or add fluids to this maintenance free battery.

# WHAT CAN HAPPEN

Could release poisonous gas and corrosive fluid which could injure you severely.

# **HOW TO AVOID THE HAZARD**

Never attempt to open the battery cap strip.

Keep sources of ignition away from the battery (e.g. cigarettes, flames, or sparks).

Keep battery terminals and connections free of corrosion. If cleaning is necessary, remove the corrosion with a stiff wire brush. Wash with a solution of one tablespoon baking soda and one cup water. Rinse well with tap water and dry off with clean shop towels. Coat the terminals with dielectric grease or petroleum jelly

# **Battery storage**

When the vehicle is placed in storage for three months or more, the battery should be removed and stored out of the sun in a cool, dry place. Test and recharge the battery monthly and before reusing.

# **Battery charging**

The most important parts if maintaining a sealed battery is keeping it fully charged. The battery included with your quad is sealed and the sealing strip cannot be removed. USE a voltmeter or multi-meter to measure DC voltage. A fully charged battery will register 14 V or higher. If the voltage is less than 14 V, recharge it

### NOTE:

Always verify battery condition before and 1-2 hours after charging.



**7-9-5. SPARK PLUG**Use NGK DCPR8E sparks.
Proper electrode gap is 0.8~0.9 mm
Spark plug torque is 250 kgf-cm.

## CAUTION

Using non-recommended spark plugs may result in serious engine damage and may void your emission-related warranty.

Spark plug condition is indicative of engine operation. The spark plug firing end condition should be read after the engine has been warmed up and the vehicle has been driven at higher speeds.

#### Normal

The normal insulator tip is gray, tan or light brown. There will be few combustion deposits.

The electrodes are not burned or eroded. This indicates the proper type an heat range for the engine and the service.

A white insulator tip indicates overheating.

#### **Wet Fouled**

The insulator tip is black. A damp oil film covers the firing end. There may be a carbon layer over the entire nose. General causes of fouling are excessive oil, use of non-recommended oil, improper use of the choke, or incorrect carburetion adjustments.

## **Removal and Replacement**

## NOTE:

Accessing the spark plug requires a moderate degree of mechanical skill and the appropriate tools

- 1. Turn off cock of fuel tank.
- 2. Remove the spark plug coil holder bolt and clip.
- 3. Clean the area surrounding the coil to prevent dirt from entering the cylinder head when the coil and spark plug are removed.
- 4. Use a spark plug socket and long extension to loosen and remove the spark plug from the cylinder head.

## NOTE:

Examining the condition of the spark and physical signs produced by various engine conditions (normal and abnormal) should be left to a qualified service technician.



- 5. Lightly coat the threads with a suitable anti-seize compound; this will allow for easier plug removal in the future.
- 6. Install the spark plug into the cylinder head and tighten to the specified torque.
- 7. Reinstall removed components



Cap

#### 7-10. AIR

## Air filter element cleaning

The air filter is located under the seat

# WARNING <u>!</u> POTENTIAL HAZARD

Fire or explosion, filter damage

## WHAT CAN HAPPEN

Using gasoline or other low flash point solvents to clean the air filter can result in a fire or explosion.

## **HOW TO AVOID THE HAZARD**

Use a non-flammable (high-flash point) solvent to clean the air filter elements


## CAUTION

Don't operate the vehicle with the air filter removed.

Unfiltered air entering the engine will cause rapid engine wear and severe damage. Always clean the area surrounding the air filter before removing it to lessen the chance of contaminating the airbox with foreign objects, water, dirt or other debris.



- 1. Remove the seat.
- 2. Release the filter retaining clip and remove it.
- 3. Push away the cog to remove the filter cover.
- 4. Remove the air filter from the air filter base plate.
  - (1) Air filter foam




- 5. Clean filter element with an air filter specific cleaning solvent. Rinse the element in warm water and allow drying.
- 6. Reinstall the removed components.

#### **7-11. EXHAUST**

#### Spark arrester cleaning

The spark arrester must be purged of carbon build up at the intervals specified in the maintenance schedule of this Owner's Manual.

- (1) Screw
- (2) Spark arrester
- Move the vehicle to a suitable outdoor location. Place the vehicle on a level surface, shift the transmission into NEUTRAL and apply the parking brake. Make sure the engine and exhaust system are completely cool.
- 2. Remove the screws of spark arrester, and take out the spark arrester.
- 3. Use a non-synthetic brush to clean the arrester screen. If necessary, blow debris from the screen with compressed air.
- 4. Inspect the screen for wear and damage, replace if necessary.
- 5. Reinstall the components securely.





#### 7-12. SUSPENSION

The front and rear suspension systems are pre-set at the factory with settings developed for an average rider (weight & skill). Choosing individual settings will depend on your skill level, weight, and riding style (preferences). The adjustability of the suspension system varies with the type of shock install.

## WARNING <u>!</u> POTENTIAL HAZARD

Unevenly adjusted front shocks

#### WHAT CAN HAPPEN

Uneven adjustment will result in pool handing and/or loss of vehicle stability. You can lose control of the quad and suffer severe injury or death in a resulting accident.

## **HOW TO AVOID THE HAZARD**

Contact DINLI's dealer or the other professional maintenance station to make adjustment when required.

## CAUTION

Do not turn the adjusters beyond the fully closed position (fully seated). Using too much force when closing the adjusters will destroy important sealing surfaces.

## **7-13. WHEELS**

# WARNING ! POTENTIAL HAZARD

- (1) Damaged cotter pins (or re-using cotter pins)
- (2) Riding on damaged wheel rims

## WHAT CAN HAPPEN

- A damaged cotter pin can become dislodged allowing the hub nut and wheel to come off suddenly causing you to lose control.
- (2) Damaged rims will allow air pressure to escape resulting in improper tire pressure. In either case above, you could be seriously injured or killed in the resulting accident.


#### **HOW TO AVOID THE HAZARD**

- (1) Inspect the condition of the cotter pins regularly and replace if damage is detected. Never re-use a cotter pin.
- (2) Inspect the condition of the wheel rims before every ride if you observe bending, deep scratches, gouging, or other damage, have the rims replaced with new ones.



#### 7-13-1. WHEEL INSPECTION

- 1. Check the wheel rims for damage.
- 2. To check the condition of the front wheel bearings, raise the front of the vehicle so that no weight is on the front wheels.
- 3. Move the top of the wheel back and front. If excessive lateral freeplay is detected, don't ride the vehicle. Excessive freeplay could be caused by worn or damaged A-arm bushings, damaged or worn wheel bearings, incorrectly adjusted or loose tie rod ends, or other damage in the steering assembly. Contact an authorized DINLI dealer and have the conditions corrected.



Lateral Freeplay Inspection

## OWNER'S MANUAL

4. Make sure the wheel axle nut cotter pins on each wheel are in good condition before every ride. Make sure the pin is not broken or damaged. It should have both tabs (or legs) and they should be bent properly.

(1) Cotter pin





#### 7-14. TIRES

The air pressure within the tires affects the quad's handing and stability. Check the air pressure and maintain the recommended tire pressure in each tire before every ride.

Ordinary automotive tire pressure gauges are not capable of accurately reading the pressure in your quad tires.

# WARNING !! POTENTIAL HAZARD

- (1) Uneven or improper tire pressure
- (2) Improper tires

#### WHAT CAN HAPPEN

The characteristics influence the handing and stability of this quad. Use of tire types/sizes other than specified (front/rear) in this Owner's Manual or improper tire pressures can adversely affect the handing and stability (operation) of this quad increasing your risk of an accident.

## **HOW TO AVOID THE HAZARD**

Maintain proper pressures in each of the tire.

Set pressures when tires are cold

Maintain equal pressure in both front tires and equal pressure in both rear tires.

Always use the type and size tires specified in the Owner's Manual for this vehicle.

The tire listed below has been homologation approved for this vehicle; other tires combinations are not recommended.

Homologation		
Max load	Front: 150 kg (330 lb) Rear: 224 kg (495 lb)	Туре
Front tires	22 x 8.00 − 10 42L ☆☆☆	Tubeless
Rear tires	22 x 12.00 − 9 56L ☆☆☆	Tubeless

#### 7-14-1. TIRE INSPECTION

Check tire pressure frequently with the air gauge pressure, tires should be inflated to the recommended pressure.

Recommended: FRONT: 50kpa, { 0.50kgf/cm<sup>2</sup>, }, 7.0 psi

Rear: 50kpa, { 0.50kgf/cm<sup>2</sup>, }, 7.0 psi



#### **7-14-2. WEAR LIMIT**

- 1. The pressure should be checked when the tires are cold before running the vehicle.
- 2. Tire pressure must be equal on both sides.
- 3. Never set tire pressure below minimum.
- 4. Higher pressure may cause the tire to burst. Inflate tires very slowly and carefully. Fast inflation could cause the tire to burst.
- 5. Inspect the tire tread wear, when decreased to 3 mm, replace the tire.



Tire wear condition

#### 7-15. VEHICLE IMMERSION

If your quad has been submerged or overturned in water deeper than the footpeg level, it's critical to dry it promptly and properly before starting the engine.

## CAUTION

Do not start the engine after a quad has been in water that exceeds the recommended depth. Tow or trailer the quad to your dealer for service.

Do not perform the following procedures if you do not feel capable completely, or if you suspect that water has entered the fuel tank. Tow or trail the quad to your dealer for immediately service

- 1. Turn the fuel valve off.
- 2. Drain water from the air box and change the air filter.
- 3. Drain the fuel/water from the carburetor for about 10 seconds.
- 4. Remove the spark plug.



# 8. CLEANING

Regular cleaning helps to maintain appearance and contributes to overall performance if the quad keeping it free of damaging dirt, soils, and grime.

- When cleaning, avoid harsh detergents and chemical solvents.
- Use an ordinary garden hose and only enough water pressure to do the job.
- Use mild solutions of ordinary dish soaps and clean water.
- The advertising claims of "power" cleaning products are no substitute for careful and deliberate attention when cleaning the quad.

## CAUTION

Don't use high-pressure (e.g., coin-operated car washes) or portable steam power washers to clean the quad. The excessive water pressure will force dirt, water, and other contaminants into important electrical connectors and devices, bearings, engine seals, wheel bearings, seals promoting rust and corrosion. Severe damage can result.

Before you start cleaning the quad take the following precautions:

- Make sure the vehicle is completely cool before cleaning it.
- Thoroughly dry the vehicle after washing it.
- Cover the rear muffler opening, brake lever and pedals, start and stop switch, throttle with plastic bags secure with strong rubber bands.
- Make sure all filter and check caps are tightened securely.

## After wishing

- Remove all plastics bags.
- Lubricate the front brake lever and rear brake pedal with clean engine oil.
- Lubricate the tie-rod ends using the grease fittings. Use high quality lithium soap-based grease.
- Test the brakes before operation. Wet brake discs and pads reduce braking efficiency.
- Start the engine and allow to run for 5 minutes.



# 9. STORAGE

When the vehicle will not be operated for an extended period of time (e.g., winter months,

45 days or more), it is necessary to perform certain procedures to guard against deterioration and make sure it is in perfect running condition when the riding season begins.

- 1. Change the engine oil and clean the filters.
- 2. Perform all necessary repairs.
- 3. Either drain the fuel tank completely or fill it with fresh fuel. Add a good quality fuel stabilizer directly to the tank. Make sure you follow the directions on the product label.
- 4. Remove the air filter and thoroughly clean the area surrounding the airbox.
- 5. Start the engine. With the engine idling spray (for 10-20 seconds) a high-quality engine fogging oil into the airbox base plate directing the spray toward the intake funnel inside the airbox.
- 6. Shut off the engine and allow to cool.
- 7. Clean, re-oil and install the air filter.
- 8. Plug the hole in the muffler with a clean shop towel and cover the towel with a clean plastic bag. Secure the bag with a rubber band.
- 9. Thoroughly clean and fry the vehicle.
- 10 .Remove the battery and store it where it will not be exposed to direct sunlight a clean, dry area.
- 11. Position the vehicle on a level surface and block the wheels to prevent the wheels from moving.
- 12. Remove the ignition key.

# 10. TRANSPORTING

It is essential to transport the vehicle in a proper position.

The proper position must be strong and firm to against the quad roll off the truck and trailer.

## WARNING<u>/!\</u> POTENTIAL HAZARD

Failure to properly secure the ATV.

#### WHAT CAN HAPPEN

Failure to properly secure the vehicle may cause an accident or damage to the vehicle.

## **HOW TO AVOID THE HAZARD**

When transporting the vehicles, lock the parking brake lever and tie down the vehicle securely with straps, rope, or some other suitable means. Use extra tie downs when you transport the vehicle in the standing position.

If you transport the vehicle by truck, you can use one of following loading methods

- Tie ropes around the front and rear carriers at four points and lift the vehicle on to the truck using a hoist, or
- Ride the ATV onto a pallet, secure the vehicle to the pallet and use a forklift to lift the pallet, or
- Using a ramp and winch mounted on the truck; hook the winch cable to the center of ATV front bumper and pull the vehicle up the ramp onto the truck.



# 11. TROUBLESHOOTING

## NOTE:

The troubleshooting items listed here are provided as a rough guide to assist in some of the more common difficulties. For more complete systems troubleshooting, consult the vehicle service manual.

PROBLEM	POSSIBLE CAUSE	SOLUTION
Engine turns over but will not start or is hard to start.	Fuel deterioration, water in fuel or	Drain fuel and replace with fresh fuel
	No fuel in tank.	Turn fuel valve to reserve, refuel
	Fouled or defective spark plug	Inspect plug, replace if necessary
	Low compression	Piston ring is worn or stuck cylinder is worn. See you Dinli dealer.
	Low battery voltage. The terminals are loose or corroded.	Charge and/or clean the battery.
	No spark to spark plug	Inspect plug, verify switch is on.
		Inspect, clean and / or replace spark plug.
Engine will not turn over.	Battery voltage is low or the terminals are loose.	Charge the battery or secure the terminals.
	Fuse blown.	Replace the blown fuse.
	Ignition is in the "OFF" position	Turn the ignition to the "ON" position

	Engine stop and start switches are faulty	Check
	Solenoid faulty.	Replace.
	Air filter clogged	Clean or replace
	Corroded battery terminal	Clean
Engine starts hard when hot	Fouled spark plug.	Replace.
	Faulty solenoid.	Test or replace
Spark plug fouls repeatedly	Fuel return line blocked	Inspect.
	Incorrect calibration file	Replace
	Corroded batter terminals	Clean
Engine lacks power	Throttle body air boots are loose or damaged.	Tighten.
	Faulty or incorrectly gapped spark plug.	Replace
	Faulty ignition coil.	Replace.
	Fuel filter clogged.	Clean or replace
	Deteriorated or contaminated fuel.	Replace.
	Faulty fuel pump.	Repair or replace
	Debris lodged in screen	Remove and clean screen
Overheating	Low coolant level	Add coolant
	Coolant leak in engine	Tighten



	Coolant bottle cap loose	Tighten.
	Fuel deterioration.	Drain, fill with fresh fuel.
	Worn or defective spark plug wire.	See your Dinli dealer
	Fouled or defective spark plug	Replace spark plug
Engine stalls.	Fuel hose clogged.	Clean or replace
	Air filter clogged	Clean or replace
	Loose ignition connections	Check all connections and tighten
	Other mechanical failure.	See your Dinli dealer.
Engine pings or knocks	Poor quality or low octane fuel	Replace with recommended fuel
	Incorrect ignition timing	See your Dinli dealer
	Incorrect spark plug gap or heat range.	Set gap to specs or replace plug
Engine backfires	Weak, fouled or defective spark plug.	Inspect, clean if necessary replace.
	Incorrect spark plug gap or heat range.	Set gap to specs or replace plug
	Incorrect installed plug wire.	See your Dinli dealer

# 12. MODEL SPECIFICATION

NOTE:

Specifications subject to change without notice

## **12-1 ENGINE**

Model	DMX 450
Engine	4-stroke, DOHC
Bore and stroke	94 mm x 64.6mm
Compression ratio	11.6 : 1
Displacement	448 cc
Coolant system	Liquid cooled
Coolant	1:1 water/ anti-freeze [ethylene glycol(containing corrosion inhibitors for aluminum engines and radiators)]
Starting system	Electric
Carburetor	Mikuni BSR42
Transmission	5-speed with reverse
Final drive	2WD/chain
Clutch type	Wet, multi-disc
Clutch plates	8 plates



Engine idle speed	<b>1600</b> ± 100 rpm		
Spark plug, standard	NGK (DCPR8E)		
Spark plug gap	0.8 – 0.9 mm		
Lubrication system	Dry sump		
Ignition system	CDI		
Compression pressure	130 psi		
Fuel filter replacement	FRAM G4 164 or equivalent		
Engine oil Recommended viscosity: 15W/40 Synthetic or semi-synthetic Classification: use only high-detergent Premium quality motor oils with the American Petroleum Institute (API) service classification SF or SG type displayed on the container.	CAUTION  Be sure to change the engine oil and clean/replace the filters in accordance with the vehicle maintenance schedule. Service more frequently when operating under severe conditions.  ENGINE OIL  TEMP.  C -30 -20 -10 0 10 20 30 40  TEMP.  T -22 -4 14 32 50 68 86 104		
Engine oil quantity (dry fill)	1800 cc		
Fuel	Premium unleaded (Anti-Knock Index 95 or higher)		

# 12-2 CHASSIS

Model	DMX 450
Frame	Steel
Overall length	1942 mm
Overall width	1129 mm
Overall height	1175.5 mm
Seat height	870 mm
Wheel base	1260 mm
Front tire	22x8-10
Rear tire	22x12-9
Recommended cold tire pressure (front/rear)	50kpa / 50kpa
Turning radius	8 ft (2.4 m)
Fuse	20A, 25A
Loading limit	220 kg
Headlight	Philips Duple 12V 35/35W
Taillight	P21 (5W)
Battery	GS, GTX14-BS
Ground clearance, unloaded	310 mm



Water crossing maximum depth	520 mm
Front suspension travel	11"
Rear suspension travel	10"
Dry weight (appx KGs)	220
Fuel tank capacity	11.5L
Throttle lever freeplay	1/8 – 5/16 in (3-8 mm)
Air filter	Foam
Brake fluid	DOT4
Brake pad thickness (MIN)	1.0 mm
Brake disc thickness (MIN)	3.5 mm
Clutch lever freeplay	2-4 mm
Drive chain type	DID 520V (O-ring type)
Drive chain slack	1.37 – 1.60 in (35 – 40mm)
Drive chain roller O.D. (STD / MIN)	34.5 mm / 30 mm

#### **12-3 BATTERY**

Warning notes and safety regulations for lead-acid battery.

- Read instructions carefully.
- Do not use at the places near fire. Hydrogen gas generated from battery may Cause fire and explosion.
- When using the battery, wear safety glasses and rubber gloves. Sulfuric acid may cause blindness or severe burn.
- Keep put of the reach of children.
- Battery solution or electrolyte is a diluted sulfuric acid solution. In case of contact with skin, rinse immediately with lots of water.
- Batteries generate flammable gases which, if exposed to flames, can cause an explosion.
- Hand in old batteries at a collection point. Never dispose of old batteries as domestic waste.



# **Battery instruction**

Note  Assure the electrolyte is the same specification for storage battery.  3. Filling battery with electrolyte.  Remove the sealed tape on even place.  Take out the bottle, put it down straightly then pour through thefunnel to the ports.	5.Remove the bottle and funnel.  Check no remaining electrolyte if not, tap softly the bottle and Funnel to clear completely. Slowly pull out the bottles and
Remove the sealed tape on even place.  Take out the bottle, put it down straightly then pour through thefunnel to the ports.	funnel.  Check no remaining electrolyte if not, tap softly the bottle and Funnel to clear completely. Slowly pull out the bottles and
put it down straightly then pour through the funnel to the ports.	If not, tap softly the bottle and Funnel to clear completely. Slowly pull out the bottles and
	Funnel.
2. Preparation for filling funnel.  4. Assurance of the filling state.	6. Installment of close plugs.
Softly inlay the filling funnel on the ports of the storage battery.  Assure every port has bubbles and the level of electrolyte should be down.	Put the close plugs on the portsand evenly press the plugs.

	CORRECT CHARGE		
TYPE OF BATTERY	NORMAL	RAPID	
GTX14-BS	1.4A x 5~ 10 H	14A x 0.5 H	

#### **DANGER**

EXPLOSIVE GASES keep sparks, flames and cigarettes away. Provide adequate ventilation when charging or using batteries in an enclosed space.

CHEMICAL HAZARD contains sulfuric acid. Contact with skin even through clothing. May cause severe burns. Wear a face shield and protective clothing. If electrolyte gets into your eyes, antidote: flush thoroughly with water for at least 15 minutes and call a physician immediately.

POISON Antidote: EXTERNAL-flush with water. INTERNAL-drink large quantities of water or milk then follow with milk of magnesia or vegetable oil.

KEEP PUT OF REACH OF CHILDREN.

## CAUTION

This battery is a sealed battery requiring no maintenance of fluid level. Do not try to remove the sealing caps to fill the battery or when charging it; you may damage the battery. To check the state of charge, use a digital voltmeter: standard voltage should be more than 12.8 V. Please wait for over 20 minutes after electrolyte is filled up. If the voltage is less than 12.8 V before using, please charge the battery complying with the instruction.



# 13. QUAD LIMITED WARRANTY

#### 13-1 WARRANTY CONDITIONS

Dinli warrants new Dinli quads that are purchased from and properly assembled, serviced for delivery, and warranty registered by an authorized Dinli Dealer, to be free from defects in materials and factory workmanship subject to the following exclusions, obligations, and limitations.

#### **13-2 WARRANTY PERIOD**

The warranty period for Dinli begins on the date of purchase and six (6) months from the date of purchase.

#### 13-3 WARRANTY TRANSFER

This warranty applies to the original purchaser and is not transferable

#### 13-4 WARRANTY EXCLUSION

Dinli quad used for commercial, rental, or law enforcement purposes are excluded from warranty coverage.

#### 13-5 COMPETITION MODEL EXCLUSION

Dinli quad used in competition or demonstration are excluded from warranty coverage.

#### 13-6 PARTS AND LABOR COVERED BY WARRANTY

The warranty coverage applies only to the main frame welded assembly, the swing arm welded assembly, engine crankcase, internal engine parts housed within the engine crankcase, cylinder head, and wiring harness, voltage regulator, starter motor, and battery.

No other components are covered by any warranty, expressed or implied and are sold" as is". Covered parts and the labor to repair or replace the covered parts will be provided at no charge to the original purchaser only when performed by an authorized DINLI dealer. Covered parts used in warranty repairs will be warranted for the balance of the warranty period. Covered parts replaced under warranty become the property of DINLI

#### 13-7 PARTS AND LABOR NOT COVERED BY WARRANTY

Warranty coverage does not apply to:

- Parts and labor required as a result of, but not limited to, transportation, collisions, misuse, negligence, improper
  or abusive operation, alterations, competition, or any other damage that is not a result of a defect in factory
  workmanship or materials.
- Parts and labor required due to insufficient or improperly performed maintenance or repairs, improper storage, use of improper fuels or lubricants, or use of other than DINLI replacement parts or accessories.
- Parts and labor required as a result of normal wear, such as, but not limited to, hoses and rubber components, clutch components, piston, rings, cylinder liner, valve guides, valve seats, valves, transmission gear engagement surfaces, seals, and bearings.
- Parts and labor required as a result of piston or cylinder seizures.
- Parts and labor required to perform routine maintenance or scheduled service.



#### **PURCHASER'S RESPONSIBILITY**

- Maintain and operate the DINLI quad in accordance with the instructions and maintenance schedule printed in the Owner's Manual.
- Keep records and receipts of the date of purchase of the DINLI quad and all scheduled maintenance performed at the intervals specified in the Owner's Manual. This will be necessary when requesting warranty repairs to prove that the DINLI quad is within the warranty period and that required scheduled maintenance was performed.
- Return the DINLI quad to an authorized DINLI dealer within five (5) days after discovery of a suspected warranty defect.
- If unable to obtain satisfactory warranty service from an authorized DINLI dealer, please contact DINLI Customer Service at

DIN LI METAL INDUSTRIAL CO., LTD.

NO.51, Industrial 9th Rd., Tali City, Taichung 412 Taiwan, R.O.C.

Tel:886 (04) 2491-7666 Fax:886 (04) 2491-7166

E-mail: globalservice@dinli.com.tw

DINLI will be glad to locate or assist to perform satisfactory warranty service. When contacting DINLI Customer Service please provide the following information:[Date purchased, model, vehicle identification number, engine identification number, number of hours or miles, description of problem, date problem occurred, dealer name, dealer personnel consulted, and purchase's name, address, and phone number.

#### 13-8 WARRANTY LIMITATION

Dinli makes no other presentations or warranties, expressed or implied, with respect to service to owners or users or to any other person or entity. No one is authorized to assume for Dinli any warranty obligation or liability in connection with the sale of Dinli quads. Dinli owns the right to change any warranty and service policy at any time without liability to any person or entity by reason of any such change.

Unless considered unenforceable under applicable law, all implied warranties, including, but not limited to, implied warranties of merchantability or fitness for a particular purpose, are hereby excluded.

Also excluded from this warranty, unless considered unenforceable under applicable law, are incidental or consequential damages, such as, but not limited to, transportation to a authorized Dinli dealer, loss of use, inconvenience, or damage to personal property.



# 14. MAINTENANCE RECORD

It is important to keep accurate records of maintenance service. This data is vital for referencing previous work or knowing what type of tuning was performed under certain conditions.

DATE	SERVICE	REMARKS

# **ADDENDA**

This section is reserved for updates, supplements, and revisions.