



Instruction manual for software & settings







What is new starting from release 1.8 :

- Option pack 1 : Diagnostic for Critical Severe Service Valves
 - Valve Signature
 - Step Response
- Option pack 2 : Improved control and diagnostic for High Dynamic Valves
 - Stability Control
 - Signal Generator for frequency analisys
 - Soft Approach to seat
- 4mA action inversion -std

What is new starting from release 1.6 :

- Feedback linearization
- Graph tool : compare function
- Graph tool : window length
- New diagnostic messages

-Increased control performances (new PID control algorithm)





INDEX

Sw installation	6
RemoteControl sw connection	6
HART interface connection :	6
TTL High speed serial connection :	6
Starting the sw	7
The Main page	
Quick Buttons	9
Download button	9
Graph button	9
Password button	9
'Tuning' & standard 'System setup' area	10
Important : to modify the parameters it needs click two times on fi	eld, in this way another windows will
open and it's possible to write the new value for that parameter.	10
Definitions :	10
Travel control :	10
Open Limit [50100 %]:	10
Close Limit [050 %]:	10
Tuning :	10
Kp [0,1 25]:	10
TH [OFF- 10 100000 ms]:	11
Tu [01000]	11
Velocity Limit [0, 655 sec]:	11
Damping Factor [0, 255]:	11
Switched ctrl err threshold[0.,100 %]:	11
Sweep pressure[010 bar]:	11
Switched control function Enabled[ON/OFF]:	11
Main yore and status	4.0
AULTUS [%] RegPos [%]:	12 12
FrrPos[%]:	12
Input [mA]:	
PI [bar]:	12
PA [bar]:	12
DP[bar]:	12
System Status :	12
Diag (button)	16
Service State / Mode :	17
CFG panel	18
Position sensor:	19
Pos. raw ADC reading (bits)	
Position sensor adjustment :	19
Digital inputs/outputs	20
Digital Input 1:	20
Digital Input 2:	20
Digital Outputs :	20
SYSTEM CALIBRATION	20
4-20mA CALIBRATION	21
Loop Current ADC 4mA	21
Loop Current ADC 20mA	21

STI S.r.I. – Via Dei Caravaggi 15, 24040 Levate (BG) – ITALY www.imi-critical.com





SPLIT RANGE INPLIT	21
Lower range value (%) :	21
Upper range value (%) :	21
Setpoint range function (enabled) :	21
INPUT CHAR.	22
Transfer Function :	22
Transfer Function Curve button :	22
Feedback linearization	23
Analog Output	24
Analog Feedback	24
HART panel	25
HART PARAMETERS	25
Tag :	25
Date :	25
Descriptor :	25
Message :	25
Polling address:	25
Dev. ID :	25
HART Protocol	25
HART Communication	25
Hart Mode :	25
ADVANCED Panel	26
Travel Control Pressures	26
Analog output DAC calibration	26
4mA calibration :	26
20mA calibration :	26
Switched CTRL function params	26
0-100% position (4mA action inversion)	27
The Granh window	28
	20
The Menu	29
Menu : File	29
Load:	29
Save :	29
Report :	29
Exit :	29
Menu : Device	29
Download	29
Upload Param	29
Upload Param + Calib data	29
Menu : Password	29
Login	29
	29
System Calibration : Self Tune	30
Starting page	30
Position sensor alignment	31
Actuator volume	32
Actuator Type	32
Booster type	33
'Only stroke' or 'full calibration'	33
Option pack 1 : Diagnostic for Critical Severe Service Valves	34
Valve Signature	34
Dynamic Error	

STI S.r.I. – Via Dei Caravaggi 15, 24040 Levate (BG) – ITALY www.imi-critical.com





Step Response	37
Disclaimer:	41
Option pack 2 :	42
Option pack 2 :	42
Improved control and diagnostic for High Dynamic Valves	42
Stability Control	42
Signal Generator for frequency analysis (Dynamic tests)	43
Soft Approach to seat	47
375 HandHeld & DD file	49
INSTALLATION	49
	50
	51
Setup Wizard	52
AMS sw interface :	53
INSTALLATION	53
	53
	53
PROCESS VARIABLES	54
CONFIGURE/SETUP	55
System Setup Manual Mode/ Position Sensor	55 56
CHANGE THE OPERATION MODE	00
	58
START THE CALIBRATION	59
DIAGNOSTIC	60
Error/Diagnostic bits in HART protocol	61
Device Status	61
Common practice command CMD48 : Read additional device status	61
Extended status byte 0 :	61
Extended status byte 1 : Extended status byte 2 :	61 61
Extended status byte 3 :	62
Selftune phases :	63
Error codes :	65





Sw installation

- Insert the CD (or download the installation file)
- Run setup.exe
- Follow the instructions on the screen.

RemoteControl sw connection

HART interface connection :

Connect your HART interface at the same cables of the 4-20mA input signal (J3).



If the 4-20mA signal generator is not HART compliant communication problems may be expected

TTL High speed serial connection :

Connect the special cable at connector J7.



The TTL High speed interface is not Intrinsically Safe. Use this type of interface only in a Safe Area or take all the necessary precautions before using.





Starting the sw

• Run the sw starting from the desktop icon or from the Windows Start menu.

The 'Select Communication' page is displayed.

• Select the right communication port



Only the available communication ports are displayed in the combo box.

- Select the Communication mode (TTL or HART)
- Disable 'AutoDownload and Refresh Vars' if you want to reduce the refresh rate (and the traffic on the communication line)
- Press the 'OK' button

ge is displayed.	Coloct Communication	VI
E		
port	Communication Port	
on ports are	COM11	
le (TTL or HART)	RS232	
fresh Vars' if you (and the traffic	Options Auto Download and Refresh Vars	
	ОК	





The Main page



- 'Main vars' and 'Status Information' are normally refreshed automatically.
- The other parameters are refreshed manually with the 'Download' command
- The refresh rate depends on the communication mode (HART or TTL)
- If the 'Autodownload and Refresh vars' option is disabled, use the 'Download' command to refresh the parameters use the 'Refresh' button (located near the 'Communication Status Led' when 'Autodownload' is disabled) to refresh the main variables.



PT

Quick Buttons

Download button



Download all the parameters from the FT positioner.

At the end of the download the values displayed on the RC sw are the same as the FT positioner

Graph button



Open the Graph window

Password button



Open the Login window In order to change the parameters or to access configuration windows, a login is required. The default standard password is : 12345





'Tuning' & standard 'System setup' area

Important : to modify the parameters it needs click two times on field, in this way another windows will open and it's possible to write the new value for that parameter.

Definitions :

Limit: when a limit is configured the Requested position is limited to this value Example : Set the Limit at 95%. Even if the signal input is 20mA and the theretical Request position is 100%, the applied Request position is 95%

CutOff : When a cutoff is configured, if the Requested and Actual position falls inside the Cutoff area the Request position is fixed at the min (or max) value.

Example : Set the cutoff at 5%. When the Request position is less of 5% and the Actual position is less of 5% a fixed pressure is applied in order to put the actual position at 0%.

Tight (open/close) pressure : this defines the pressure applied when a cutoff is active. (Advanced parameter)

Open/Close : Information related to 'Signal Fail Action' configuration.

🖑 WARNING

The signal Fail Action setting informs the Positioner about what happens when the electrical power supply fails. This behaviour is determined by the pneumatic connection and is not software configurable.

🖑 WARNING

On some type of valves it is mandatory to enable a cutoff to ensure that the valve works properly (to ensure full trust on seat)

Travel control :

Open Limit [50..100 %]:

Specify if a Limit or a CutOff is configured in the open direction (see also the Soft Approach to seat paragraph)

Close Limit [0..50 %]:

Specify if a Limit or a CutOff is configured in the close direction. (see also the Soft Approach to seat paragraph)

Tuning :



A lot of parameters are configurable with different settings for the open and close directions. This is to maximize the performance of the system. If the *Mono* flag is checked the first value of each parameter is automatically copied into the second one.

Kp [0,1 .. 25]:

Proportional gain is the multiplier of the error (difference between input signal and actuator actual position) and it is expressed in percent. It is active only for an error which is bigger than dead band value. A different gain for each stem direction can be selected.





Ti [OFF- 10 .. 100000 ms]:

Integral factor.

The integral term accelerates the movement of the process towards setpoint and eliminates the residual steady-state error that occurs with a proportional only controller. However, since the integral term is responding to accumulated errors from the past, it can cause the present value to overshoot the setpoint value. A small 'Ti' value is equal to an aggressive integral effect.

A different integral factor for each stem direction can be selected.

Td [0..1000] :

Derivative factor

The derivative term slows the rate of change of the controller output. Setting Td equal to '0' disable; the derivative factor. Increasing the value increases the derivative action.

Dead Band [0..10] :

Dead band prevents (at expense of the accuracy) that the valve, in the controlled condition, keeps continuously hunting for the target position. The dead band setting can be used to reduce continues cycling ("hunting") around the target position. Increasing the value reduces the accuracy, but can improve stability.

Velocity Limit [0..655 sec]:

Velocity limit is the value expressed in seconds of the stroking time for each direction

Damping Factor [0..255]:

Apply a damping effect at the signal rate of change. Increasing the damping factor causes a smooth effect on the signal rate of change.

(The function 'Switched Ctrl err threshold' is not standard starting from version 1.6, it is available in the ADV menu but not necessary in many cases)

Switched ctrl err threshold[0..100 %]:

When the error is greater than this threshold :

- the positioner tries to impose a fixed ΔP in order to maximize the speed.
- the Integral contribution is reset to zero.

Sweep pressure[0..10 bar]:

Fixed ΔP applied when the error is greater than 'Switched ctrl err threshold'.

Switched control function Enabled[ON/OFF]:

Turn ON/OFF the 'Switched control function'

Normally the following settings work well:

- sweep pressure equal to the line pressure
- the Switched ctrl err threshold equal to [100/min(Kp)]*['sweep pressure'/10] with a maximum of 20%





Main vars and status

This window reports information about the status of the positioner. The LED in the top-right position informs the user about the information status : YELLOW LED blinking : the communication is running RED LED : communication problem

ActPos [%] :

Actual position measured by the positioner.

ReqPos [%]:

Input signal or the request position. The source of the requested position depends on the 'service state'. While 'in service' the requested position comes from the 4-20mA input signal and the split range setting. While 'out of service' the requested position comes from the manual setpoint setting

ErrPos[%]:

ReqPos-ActPos

Input [mA]:

Current read by the 4-20mA loop current Input channel.

The user can calibrate the value displayed using the commands in the 'CFG' area

PI [bar]: Line pressure

PA [bar]:

Pressure measured at port A of the positioner.

DP[bar]:

Differential pressure measured : portB-portA

System Status :

Displays the status of the device (the same information is also available with CMD48 in the HART protocol) :

[latched] means that the error happened but it is not running now (i.e. there was a low pressure but now the pressure is good). In order to clear the latched errors the button 'Clear latched errors' must be pressed. [instantaneous] means that the error is running now

"Error [latched] - user configuration has been reset"
"Error [latched] - user configuration data failed recovery"
"Error [latched] - factory settings have been reset"
"Error [latched] - factory settings were corrupt at power on"
"Error [latched] - a watchog timeout caused the last system reset"
"Error [latched] - system has not been configured (perhaps first power on?)
"Error [latched] - system is uncalibrated"
"Error [latched] - the pot has not been linearised"





"Error [instantaneous] - too close physical limits" "Error [instantaneous] - position encoder out of range" "Error [instantaneous] - DP sensor out of range" "Error [instantaneous] - supply pres sensor out of range" "Error [instantaneous] - portA sensor out of range" "Error [instantaneous] - supply pressure < min pressure" "Error [instantaneous] - lerror|=>5% for =>10seconds"

"Error [latched] - too close physical limits" ' "Error [latched] - position encoder out of range" "Error [latched] - supply pressure sensor out of range" "Error [latched] - supply pressure sensor out of range" "Error [latched] - portA sensor out of range" "Error [latched] - supply pressure < min pressure" "Error [latched] - supply pressure < min pressure" "Error [latched] - lerror]=>5% for =>10seconds"

"Status - setpoint is being clamped (lower clamp)"

- "Status setpoint is being clamped (upper clamp)"
- "Status cut off is active"
- "Status cut off is active"
- "Status the DP clamp is active"
- "Status system not in service"
- "Status position <= limit 1"
- "Status position => limit 2"
- "Status Digital In 1 is on"
- "Status Digital In 2 is on"
- "Status Digital Out 1 is on"
- "Status Digital Out 2 is on"
- "Status digital input has activated system override"

"Communication Lost"

"Operation failed" "System calibration completed" "System calibration in progress" "System calibration failed" "Hard limits calibr.completed" "Hard limits calibr in progress" "Hard limits calibr.failed" "Loop curr.ADC 4mA calib.completed" "Loop curr.ADC 4mA calib.in progress" "Loop curr.ADC 4mA calib.failed" "Loop curr.ADC 20mA calib.completed" "Loop curr.ADC 20mA calib.in progress" "Loop curr.ADC 20mA calib.failed" "Pos.ADC 0degrees calib.completed" "Pos.ADC 0degrees calib.in progress" "Pos.ADC 0degrees calib.failed" "Pos.ADC 90degrees calib.completed" "Pos.ADC 90degrees calib.in progress" "Pos.ADC 90degrees calib.failed" "DP Press.Sens.0bar calib.completed" "DP Press.Sens.0bar calib.in progress" "DP Press.Sens.0bar calib.failed" "DP Press.Sens.6bar calib.completed" "DP Press.Sens.6bar calib.in progress" "DP Press Sens 6bar calib failed"





"PI Press.Sens.0bar calib.completed" "PI Press.Sens.0bar calib.in progress" "PI Press.Sens.0bar calib.failed" "PI Press.Sens.6bar calib.completed" "PI Press.Sens.6bar calib.in progress" "PI Press.Sens.6bar calib.failed" "PA Press.Sens.0bar calib.completed" "PA Press.Sens.0bar calib.in progress" "PA Press.Sens.0bar calib.failed" "PA Press.Sens.6bar calib.completed" "PA Press.Sens.6bar calib.in progress" "PA Press.Sens.6bar calib.failed" "Inner loop drive DAC 0bar calib.completed" "Inner loop drive DAC 0bar calib.in progress" "Inner loop drive DAC 0bar calib.failed" "Inner loop drive DAC 6bar calib.completed" "Inner loop drive DAC 6bar calib.in progress" "Inner loop drive DAC 6bar calib.failed" "Dec TE Offset by 0.1deg calib.completed" "Dec TE Offset by 0.1deg calib.in progress" "Dec TE Offset by 0.1deg failed" "Inc TE Offset by 0.1deg calib.completed" "Inc TE Offset by 0.1deg calib.in progress" "Inc TE Offset by 0.1deg calib.failed" "Analog out DAC 4mA calib.completed" "Analog out DAC 4mA calib.in progress" "Analog out DAC 4mA failed" "Analog out DAC 20mA calib.completed" "Analog out DAC 20mA calib.in progress" "Analog out DAC 20mA calib.failed" "Store RAM to user flash completed" "Store RAM to user flash in progress" "Store RAM to user flash failed" "Store RAM to factory flash completed" "Store RAM to factory flash in progress" "Store RAM to factory flash failed" "Restore to factory settings completed" "Restore to factory settings in progress" "Restore to factory settings failed" "Unknown state" "Invalid AutoConfig Request" "Limits Phase1: Encoder Out Of Range Before Stroke" "Limits Phase1: UpStepTime Max Exceeded" "Limits Phase1: DownStepWait Time Exceeded" "Limits Phase1: DownStepTime Max Exceeded" "Limits Phase1: Encoder Out Of Range During Stroke"

- "Physical Limits: Min Diff Not Met"
- "Time Phase1: StepWaitTime Exceeded UpStep"
- "Time Phase1: Invalid RiseTime"
- "Time Phase1: PostStepSettleTime Max Exceeded UpStep"
- "Time Phase1: StepWaitTime Exceeded DownStep"
- "Time Phase1: Invalid FallTime"
- "Time Phase1: PostStepSettleTime Max Exceeded DownStep"
- "Map Phase1: UpStrokeTime Max Exceeded"
- "Map Phase1: DownStrokeTime Max Exceeded"
- "Map Phase2: PreMoveWaitTime Exceeded"
- "Map Phase2: MoveTime Max Exceeded"





- "Map Phase2: SetpointErr Max Exceeded1" "Map Phase2: SetpointErr Max Exceeded2" "Map Phase3: PreMoveWaitTime Exceeded" "Map Phase3: MoveTime Max Exceeded" "Map Phase3: SetpointErr Max Exceeded1" "Map Phase3: SetpointErr Max Exceeded2" "Tune Phase1: PreStepSettleTime Max Exceeded" "Tune Phase1: StartStepWaitTime Max Exceeded" "Tune Phase1: PreStepWaitTime Max Exceeded" "Tune Phase1: PostStepSettleTime Max Exceeded" "Tune Phase1: PostStepSettleTime Max Exceeded" "Tune Phase1: Num Setpoint Incs Max Exceeded" "Tune Phase1: Num Setpoint Incs Max Exceeded" "Tune Phase1: Could Not Calculate Pid Params"
- "Digital Input Abort"
- "User Abort"
- "Feature Not Implemented"
- "Calibration in progress (step " ... ")"





Diag (button)

It is to have access to a window that summarizes the communication errors. When the button is with a RED led it means that at least an error happens. Pressing the button a window appears with the list of the communication errors.



Press 'clear' to erase the content of the Event Log window, 'OK' to close the window.

9	×
EVENT LOG	
War: 2011-05-24 17:23:40 3) TIMEOUT for CMD REFR 131 (CMDIN = -1 IDOUT =	162)
War: 2011-05-24 17:23:52 3) TIMEOUT for CMD REFR 131 (CMDIN = -1 IDOUT =	162)
War: 2011-05-24 17:23:59 3) TIMEOUT for CMD REFR 131 (CMDIN = -1 IDOUT =	162)
War: 2011-05-24 17:24:05 3) TIMEOUT for CMD REFR 131 (CMDIN = -1 IDOUT =	162)
War: 2011-05-24 17:24:11 3) TIMEOUT for CMD REFR 131 (CMDIN = -1 IDOUT =	162)
War: 2011-05-24 17:24:17 3) TIMEOUT for CMD REFR 131 (CMDIN = -1 IDOUT = War: 2011-05-24 17:24:24 3) TIMEOUT for CMD REFR 131 (CMDIN = -1 IDOUT = 2011-05-24 17:24:24 3) TIMEOUT for CMD REFR 131 (CMDIN = -1 IDOUT =	162) 162)
War: 2011-05-24 17:24:30 3) TIMEOUT for CMD REFR 131 (CMDIN = -1 IDOUT = War: 2011-05-24 17:24:36 3) TIMEOUT for CMD REFR 131 (CMDIN = -1 IDOUT = War: 2011-05-24 17:24:43 3) TIMEOUT for CMD REFR 131 (CMDIN = -1 IDOUT =	162) 162)
War: 2011-05-24 17:24:49 3) TIMEOUT for CMD REFR 131 (CMDIN = -1 IDOUT =	162)
War: 2011-05-24 17:24:55 3) TIMEOUT for CMD REFR 131 (CMDIN = -1 IDOUT = -1)	162)
War: 2011-05-24 17:25:02 3) TIMEOUT for CMD REFR 131 (CMDIN = -1 IDOUT =	162) ≡
War: 2011-05-24 17:25:08 3) TIMEOUT for CMD REFR 131 (CMDIN = -1 IDOUT =	162)
War: 2011-05-24 17:25:20 3) TIMEOUT for CMD REFR 131 [CMDIN = -1 IDOUT =	162)
War: 2011-05-24 17:25:20 3) TIMEOUT for CMD REFR 131 [CMDIN = -1 IDOUT = -1	162)
War: 2011-05-24 17:25:27 3) TIMEOUT for CMD REFR 131 [CMDIN = -1 IDOUT = -1	162)
War. 2011-05-24 17:25:33 3) TIMEOUT for CMD REFR 131 (CMDIN = -1 IDOUT =	162)
War. 2011-05-24 17:25:39 3) TIMEOUT for CMD REFR 131 (CMDIN = -1 IDOUT =	162)
War: 2011-05-24 17:25:46 3) TIMEOUT for CMD REFR 131 (CMDIN = -1 IDOUT =	162)
War: 2011-05-24 17:25:52 3) TIMEOUT for CMD REFR 131 (CMDIN = -1 IDOUT =	162)
War: 2011-05-24 17:25:58 3) TIMEOUT for CMD REFR 131 (CMDIN = -1 IDOUT =	162)
War: 2011-05-24 17:26:05 3) TIMEOUT for CMD REFR 131 (CMDIN = -1 IDOUT =	162)
War. 2011-05-24 17:26:11 3) TIMEOUT for CMD REFR 131 (CMDIN = -1 IDOUT = War: 2011-05-24 17:26:17 3) TIMEOUT for CMD REFR 131 (CMDIN = -1 IDOUT =	162)
Clear	OK





Service State / Mode :

Allow the selection of the Service State.

- In Service : the Requested Position is evaluated continually by the positioner starting from the 4-20mA signal value.
- Out Of Service (Manual) : the Requested Position comes from the manual setting in the window. When the Service Mode is set to 'Out Of Service (Manual)' the first manual setpoint is equal to the last 'Actual position' in order to minimize the movement of the system
- Out of Service : special mode selected automatically when the system is not calibrated. In this mode port B is fully pressurized and port A is depressurized

🖑 WARNING

Changing from 'Out of Service' to 'In Service' can cause the actuator to move.

When the positioner is turned ON it starts automatically in 'In Service' or 'Out of Service' based on the position sensor calibration status.





CFG panel







Position sensor:

Pos. raw ADC reading (bits)

This is the read value of the position sensor measured value before calibration.

The same value is shown in the scroll bar below.

During the mechanical linkage adjustment the user can use this scroll bar to verify the alignment : the raw ADC value must fall inside the range. The best condition is when the 50% mechanical position is near the middle value of the scroll bar (2048 +/- 500).



Important: to limit the travel of actuator it needs to find the raw ADC value in correspondence of hard limit and to set manually the raw ADC with a value desired. For example if for the lower hard limit the raw ADC read is 1000 and for the upper hard limit the raw ADC read is 3000 and it wants reduce the actuator travel of

5% on lower limit and 10% on upper limit, the raw ADC value needs set are: 1100 for lower limit and 2800 for upper limit. Then check the actual positions on end stroke and adjust if necessary.

Position sensor adjustment :

This button opens a window that helps the user to move the actuator.

The slide bar enables the user to select a safe speed to move in one direction or in the other.

Move the slide to the desired position and press 'Send'.

To increase the movement speed, move the slider far from the middle position.

🖑 WARNING

When the send button is pressed the system can move.

	Valve will mov	e !
ORT 'B'		PORT 'A
NUCK	SLOW SLOW	QUICK





Digital inputs/outputs

Refer to the 'electrical connection' for information about the use of 'Digital inputs/outputs' in Intrisically Safe area and proper connection to an IS barrier.

Digital Input 1:

Configure the action that the positioner will do when Digital Input 1 is activated.

- Shut down : the I/P is de-energized and the spool goes in the default position -> Port B is fully pressurized.
- Pressurize Port 'A': the I/P is fully energized and Port A is fully pressurized.

🖑 WARNING

The 'Pressurize Port A' option is not 'safety' : if the 4-20mA signal or air is fail, the system can move

Digital Input 2:

Same as Digital Input 1.

<i>Digital Outputs :</i> Open the Digital Outputs configuration window.	🗊 Di	igital Outputs Configuration	100		X
For each digital outputs it is possible to select the rules of activation			OUT 1	OUT 2	
		Not IN SERVICE			
Not IN SERVICE :		Position Below Limit1			
Digital output is activated when the system		Position Above Limit2			
IS NOT IN SERVICE		Pressure Fail (<min)< td=""><td></td><td></td><td></td></min)<>			
Position Below Limit 1 :		Position Error			
position is below the limit specified in 'Position Limit 1'		Loop Current Fail			
CAUTION		Position Limit 1 (%)		0,00	
safety application.		Position Limit 2 (%)		100,00	
Position Above Limit 2 : Digital output is activated when the actual position is above the limit specified in		Min Pl Pressure (bar)		2,5	
Position Limit 2'					
Don't use a virtual limit switches for a					
safety application.					
Pressure Fail :					
Digital output is activated when the	 	n Min DI Brosouro			
Don't use this is a virtual limit switches for a safety application. Position Above Limit 2 : Digital output is activated when the actual position is above the limit specified in 'Position Limit 2' CAUTION Don't use a virtual limit switches for a safety application. Pressure Fail : Digital output is activated when the pressure of the line (PI) is below the limit specified in the pressure of the line (PI) is below the limit specified when the pressure of the line (PI) is below the limit specified in the pressure of the line (PI) is below the limit specified in the pressure of the line (PI) is below the limit specified in the pressure of the lime (PI) is below the limit specified in the pressure of the limit specified in the pressure of the lime (PI) is below the limit specified in the pressure of the lime (PI) is below the limit specified in the pressure of the lime (PI) is below the limit specified in the pressure of t	ecified i	Position Limit 2 (%) Min PI Pressure (bar)		100,00 2,5	

Position error :

Digital output is activated when the system is IN SERVICE and the position error is >= 5% for at least 10 sec.

Loop current Fail :

Digital output 1 is used with a piezo valve in order to implement the '[Loop current] Fail Freeze' function. The option requires not only a sw activation but also a piezo valve and pneumatic valves. When this option is selected only the 'pressure fail' option is also available in order to implement the '[Low Pressure] Fail Freeze'. Digital Outputs are not available for the customer when this option is used.

SYSTEM CALIBRATION

Starts the calibration and self-tuning procedure.

STI S.r.I. – Via Dei Caravaggi 15, 24040 Levate (BG) – ITALY





The 'Only HARD LIMITS' option allows the calibration of the travel without performing self tuning.

🖑 WARNING

When the 'Start Calibration' button is pressed the system will move.

4-20mA CALIBRATION

Start the calibration of the selected option :

Be sure that you are supplying the positioner with a stable, accurate 4mA and 20 mA reference.

Loop Current ADC 4mA

Reads the actual value of the input current and calibrate the internal system to always read this value as 4mA.

Loop Current ADC 20mA

Reads the actual value of the input current and calibrates the internal system to always read this value as 20mA.

SPLIT RANGE INPUT

Enables the split range function.

The values in Lower range value and Upper range value are referred to the 4-20mA input.

A minimum distance of 20% is required between Lower and Upper value, so up to 5 split range area can be configured in different concatenated positioners.

The result of the split range is then evaluated by the 'Transfer Function Curve'.

If the Low range value is equal to 0% and Upper range value is equal to 100% the positioner interprets 4mA as the 0% Request position and the 20mA as 100%.

If the Low range value is equal to 0% and Upper range value is equal to 50% the positioner interprets 4mA as the 0% Request position and the 12mA as 100%.

Lower range value (%) :

Specifies the Lower range value.

Upper range value (%) :

Specifies the Upper range value.

Setpoint range function (enabled) :

Enable or disable the split range function



The 'Transfer Function Curve' shows the effect of Split Range Function in a graphical way.





INPUT CHAR

The Characterization specifies the relationship between the Input signal and the Requested Position.

Transfer Function :

Select one of this characterization :

- Linear
 - Standard 1-50 : equipercentage 1:50
 - Standard 50-1 : inverse equal percentage 1:50
 - User : user defined
- Standard 1-25 : equipercentage 1:25
- Standard 25-1 : inverse equal percentage 1:25
- Standard 1-30 : equipercentage 1:30
- Standard 30-1 : inverse equal percentage 1:30

Transfer Function Curve button :

Open the Transfer Function Curve window



- The 'Close' and 'Open' label in the 'Requested position' axis shows the effect of the 'Signal Fail Action' selection.
- The '4.0mA' and '20.0mA' in the 'Signal Position' show the effect of the 'Split Range' setup.
- The effect of 'Limit' and 'CutOff' are showed on the graph,
- Only the 'User Curve' can be modified, the other curves are fixed → if you want to start from a standard curve and generate a user curve you can :
 - Select the starting curve • Save the Table (File \rightarrow
 - Save Table).
 - Select 'User Curve'
 - Load the saved Table
 - Modify the table
- To 'Send' a 'User Curve' to the Positioner press the 'Send' button.
- The Signal Position steps are fixed, you can only change the Requested position value
- You can change a value in the table or click_&_drag the dot in the graph
- If you hold down the shift key and click on two dots, the system will auto



click on two dots, the system will automatically do a linear interpolation between these two points.





Feedback linearization

The transfer function has the option 'Feedback Linearization'.

With this feature it is possible to 'compensate' the position error that comes from the mechanical linkage and/or from the sensor.

Choosing 'Feedback linearization', all the other characteristic options are disabled (the Feedback linearization is applied to a 'linear' transfer curve).

In order to activate the Feedback Linearization , select 'Feedback Linearization' in 'Transfer function'.

INPUT CHAR. Transfer Function Feedback Linearization
Transfer Function Curve

Pressing the 'Transfer Function Curve' button the input panel appears :

X axis : external reference scale (gauge or meter that must be used to have a secure reference)

Y axis : actual position seen by the FT

FB Lin Wizard button : button to start the wizard that help you to align your external reference

Manual SetPoint : if the 'Service State' is 'Out Of Service (Manual) ' it is possible to move the valve manually using this tool.

Probe value : shows the 'actual position' of the system that must be used for the linearization (this value is not affected by the 'Feedback linearization' effect)

Send : send the Feedback curve to the positioner.

Example of Feedback linearization :



- 1) Apply a gauge or meter on the actuator/valve in order to have a secure position reference
- 2) Be sure to have 'Service State' = 'Out Of Service (Manual) ' and 'Transfer function = Feedback Linearization'
- 3) Press 'FB Lin Wizard' and insert the value on the gauge when you are in the 0% position and in the 100% position (for example 120mm and 30mm)
- 4) The 'Usr' row is filled with the gauge value at different points based on your input

- Curve Da	ata —															
Χ%	0,00	6,67	13,33	20,00	26,67	33,33	40,00	46,67	53,33	60,00	66,67	73,33	80,00	86,67	93,33	100,00
Υ %	0,0	6,67	13,33	20,00	26,67	33,33	40,00	46,67	53,33	60,00	66,67	73,33	80,00	86,67	93,33	100,0
Usr	120,00	114,00	108,00	102,00	96,00	90,00	84,00	78,00	72,00	66,00	60,00	54,00	48,00	42,00	36,00	30,00

- 5) Move the 'Manual Setpoint' until you read on the gauge (with reference to the example) 102mm
- 6) Copy the value in 'Probe value' in Y%[20] (below X%=20)
- 7) The point in the graph related to X%[20]is moved in X=20 Y = value and now it appears in 'bold'
- 8) Move the 'Manual Setpoint' until you read on the gauge (with reference to the example) 84mm
- 9) Copy the value in 'Probe value' in Y%[40] (below X%=40)
- 10) The point in the graph related to X%[40]is moved in X=40 Y = 'value' and now it appears in 'bold'





- 11) Repeat the last 3 steps for a subset (or all) the points in the table
- 12) If some points are missing you can linearize them with reference to the 'known' ones (keep 'SHIFT' pressed and click of the two [known] points around the one that is 'missing')
- 13) Press 'Send' in order to store the linearization curve in the positioner

Take in account that :

- a) The linearization can be performed on much more points (up to 16)
- b) The linearization consider 'linear' the error between two consecutive points
- c) The linearization cannot affect resolution of the actuator/valve

Analog Output

Analog Feedback

Selects the Analog Output (4-20mA signal out) report the 'Actuator position' or the 'Reverse Actuator Position'





HART panel

HART PARAMETERS

Tag :

- The Tag is a 8 character label assigned by the end user based on the location and use of the field device. It's a 8 character (6 byte) Packed ASCII string used to identify the field device. The term originated when physical tags were attached to instruments for this purpose.

Date :

- The date is represented by three 8-bit binary unsigned integers representing, respectively, the day, month and year

HART PARAMETERS	HART COMMUNICATION
Fag STID8FT Date 01/01/200 Descriptor	0 HART Mode Time Management
Polling Address Dev. ID	
HART PROTOCOL	-
Command: 33 Response Code: 00	-
Error Code: 00 Device Status: 40	1

(minus 1900). It's a date code, used by the Master for record keeping (e.g. last or next calibration date).

Descriptor :

- The Descriptor is a 16 character (12 byte) Packed ASCII string used by the Master for record keeping.
- The default value is a blanked string, 16 bytes long.

Message :

- The Message is a 32 character (24 byte) Packed ASCII string used by the Master for record keeping.
- The default value is a blanked string, 32 bytes long.

Polling address:

In the HART Protocol, the polling address is an integer used to identify the field device. It is used to construct the Short Frame Address. The Polling Address is set to 0 in point to point installations.

Dev. ID :

This number is different for every device manufactured with a given Manufacturer ID and Device Type, it corresponds to serial number (see page 7).

HART Protocol

- Show some communication parameters which may be useful for debugging communication problem.

HART Communication

Hart Mode :

'Time management' and *'Time management (performance)'* are two different way to manage the Hart modem. If you experience of communication problems try changing this option.





ADVANCED Panel

(only for advanced users)

Travel Control Pressures

It allows to set the pressure that isused when in fully open/close position with CUTOFF enabled. The default value is 10bar, it means that all the pressure available in the line is used.

In order to speedup the movement of the valve from the fully close (open) position could be useful to reduce the pressure used.

🖑 WARNING

Reducing the pressure could be that the valve is not fully closed and some leakage appears : the valve can be damaged.

🖑 WARNING

The pressure limitation is valid only when the positioner is working. Removing the power supply

(4-20mA loop) the output from the positioner is equal to the line : actuator and valve must be able to manage the full pressure.

Analog output DAC calibration

The analog output (4-20mA passive loop) is calibrated during the production. If some adjustment is required it can be done in this window.

In order to 'invert' the output a specific function is provided in the 'CFG' window (see 'Analog Feedback'), this calibration must not be used.

4mA calibration :

Move the actuator in the 4mA position , check that CUTOFF is active in this position in order to have a 'stable' signal.

If the measured output is different from 4mA, change the value of the DAC calibration ('32' in the picture). Increase the value is the measured output is less than 4mA or decrease the value. When you are satisfied press the 'Start Calibration 4mA' button

20mA calibration :

Move the actuator in the 20mA position , check that CUTOFF is active in this position in order to have a 'stable' signal.

If the measured output is different from 20mA, change the value of the DAC calibration ('576' in the picture). Increase the value is the measured output is less than 20mA or decrease the value.

When you are satisfied press the 'Start Calibration 20mA' button

Switched CTRL function params

This is a function used in the previous sw release (before 1.6) but available in case it is necessary. This function is not used by default.







0-100% position (4mA action inversion)

The '0-100% Position' panel is useful to set the relationship between the 4mA value and the valve status ('Close' or 'Open').

The basic rule is that by design the FasTrak positioner when the power is removed (4-20mA signal) has :

- Port 'A' connected to the atmosphere
- Port 'B' fully pressurized

So the position of the valve when the power is removed depend on the pneumatic connection.

(an exception to the above rule is when the 'Fail Freeze' option devices is used, in this case –by a special electronic and 3 way valves – the position when the signal is lost is the last valid)

By default we have that the '4mA position' is the same of the power fail position.

During the 'SelfTune' phase the sw ask if the valve is 'close' or 'open' when the power is removed, this is to make a relationship between

	SERVICE STATE Out Of Service (Manual)	tt	Clear lat
	Warning: 4mA F Fail -> below 3 Position	Position is reverse to Signal .6 mA Actuator junps to Fail	
5	0-100	% POSITION	
50	4mA Position	Close	
	STI	CFG	HART

the parameter used for the tuning and the effect on the valve : it is not a way to adjust the movement direction because this depend from the pneumatic connection.

The 'Fail Position' field shows what was selected during the Selftune, if required it can be changed.

The '4mA Position' field allows to change the '4mA position' vs 'Fail Position'.

🖑 WARNING

Set '4mA Position' different from 'Fail position' can be dangerous : you can have for example that with 4mA the valve is fully open, when the signal go below the minimum threshold the valve moves in the fully close position. If the signal is instable and close to the minimum value may happens that the valve continuously moves between the close and the open position.





The Graph window

This feature allows user to record set point and position signal waveforms for 10 seconds. Moreover, it comes with some tools to analyze the acquired waveforms. This feature is only available on the *"Remotectrl"* program with a TTL connection.



Using the up/down and right/left arrows on the keyboard it is possible to move in the graph's window. It's also possible to *"zoom in"*:hold the left mouse button, define the window to be zoomed in, release the left mouse button.

File	
	Save Image
	Save Values
	Load Values
	Graph Compare

File-> Save Image : The graph is saved like a bitmap picture

File->Save Values : The graph is saved like a 'collection of data'. It can be useful in order to reload it in a second time.

File->Load Values : Load a graph saved with 'Save values'

File->Graph Compare : Load a second graph to make a comparison with the actual one (the actual can be a new graph or loaded with 'Load values'. In order to 'align' the two images keep 'SHIFT' pressed, the mouse 'right button' pressed and move in the graph area left right) (or





The Menu

Menu : File Load: Load a saved set of parameters into the RC interface Save : Save the current set of parameters in a .qtp file

Report :

Create a document in .rtf format with the actual parameters (similar to the Save command but the file format is compatible with text editing software)

Exit : Close the application.

Menu : Device Download Performs the same function as the quick button.



Upload Param Sends the displayed parameters to the positioner.

Upload Param + Calib data

The same as the Upload Param command but additionally sends information about the calibration.

Menu : Password

Login Performs the same function as quick button

Change Changes the password







System Calibration : Self Tune

The 'self tune' wizard can be started by pressing the 'start system calibration' button. You can find more information about this procedure in the specific 'Installation Instruction Manual'

Starting page

🗐 Set	-up Wizard	×
	Welcome to the set-up wizard.	
	This step by step sequence will help you to set up your positioner. It should take less than a few minutes to complete.	
?	0% signal or signal fail valve open or close ? Open]
	Note : This is NOT a software option. 0% signal action is actuator-tubing-valve related. See inst. manual.	_
	Click next to confirm selection and to continue.	
	< Previous Cancel	

You must specify what happens when the 4-20mA signal is removed (with the air present). Based on the pneumatic connection the actuator moves in one direction or in the other (when the 4-20mA signal is removed, portB is fully pressurized).

🖑 WARNING

This panel is to inform the positioner about the action and is not to specify the user desired behaviour. The positioner is not able to change the mechanical default piston by itself.





Position sensor alignment

Set-up Wizard			
Set up Position Sensor			
Actual sensor pos. reading]	
Sensor pos. lower limit MIN 100 MAX 4000]	
Sensor pos. upper limit MIN 100 MAX 4000	[
Position Sensor Adjusteme	ent	1	
Click next to continue.			
	< Previous	Next >	Cancel

This page helps you align the position sensor.

Pressing the 'Position sensor adjustment' button opens a window where you can find a tool that allows you to move the valve.

<u>.</u>	Valve will move	e l
PORT 'B'		PORT 'A'
QUICK	SLOW SLOW	QUICK
Send		Close





Actuator volume

Specify the size of the actuator

🗓 Set-up Wizard	l.			D
			UM size is a	about 10 lt
Select A	ctuator Vol	ume		
less than 2 It	SMALL	MEDIUM	LARGE	more than 100 lt
		🗆 Don't know		
Click next	t to continue.			
		< Previous	Next >	Cancel

Actuator Type

Specify the type of actuator. Remember to check the position of the 'Mode select plate' inside the positioner.







Booster type

Dooe	the actuator have honetore	7	
or qu	ick exhaust fitted ?		
Θr	No		
0.5	íes 🛛		

'Only stroke' or 'full calibration'

Select 'Control parameters and stroke' if you want to perform a full SelfTune procedure.	Set-up Wizard			
Select 'Only stroke' if you want only to update the hardware limits of your valve.	Self Tune © Control parameter © Only stroke	rs and stroke		
Press 'Start' the perform the SelfTune.	0%		100%	
The progress bar informs you about the 'SelfTune' status.	078	ABORT	10078	
		< Previous	Start	Cancel





Option pack 1 : Diagnostic for Critical Severe Service Valves

This option pack add important diagnostic features.

To activate option 1 a specific key must be typed on main menu Password → Key



Valve Signature

The ValveSignature option allow to check the status of the valve.

The valve is moved in a configurable stroke range, data are collected and the report shows the deltaPressure (trust) vs position.



●^{**}DANGER

The ValveSignature move the valve regardless the 4-20mA setpoint.

This action can be dangerous for peoples or for the process.

Before to start a ValveSignature doublecheck that all the safety requirements are satisfied.





In order to start the ValveSignature procedure press the button in the main page :



The ValveSignature configuration window appears :

D Valve Diagnostic	
Inputs	General
Input Start [-5,0] Input End [105,0] vel. limit (s/100%) Dead Band	
Image: 12/01/2012 16:22:48: Waiting Actualor 12/01/2012 16:22:48: Actualor Arrived 12/01/2012 16:22:48: Waiting	rin Start Position (0,00%)

	Open a saved 'ValveSignature' test.		Save the actual 'ValveSignature' results
	Create a report with the results	13	See in a graphical way the collected data (also when the test is running)
O	START the ValveSignature	×	STOP a running ValveSignature
	See the details about the 'ValveSignature' process status	-	Exit





Input Start :

Specify the starting point for the test

Input End :

Specify the final point for the test

Velocity Limit :

Specify the stroke speed that must be used for the test. Usually for a good investigation a long time is required.

In order to start the test the FasTrak must be in 'Manual' mode. If it is in 'InService' the sw is able to change the status, a specific panel ask for it.

During the ValveSignature it is possible to see what happens (actual position, DeltaP).

The DeltaP appears with two different colours, one for the UP movement, the other for the down movement. In this phase the Graph shows the data (position, pressure) versus the time.



Police Graph Ter

When the ValveSignature is completed the Graph appears with DeltaPressure versus position.

With the buttons 'Time view', 'VS view', it is possible to change the visualization.

It is possible load another ValveSignature to make a comparison,

Dynamic Error

The button 'Err view' is used to show the dynamic error (error during the movement at the different positions).






Step Response

The StepResponse option allow to stroke the valve in different position based on a list of endpoints.



The StepResponse moves the valve regardless the 4-20mA setpoint. This action can be dangerous for peoples or for the process. Before to start a StepResponse doublecheck that all the safety requirements are satisfied.







In order to start the StepResponse procedure press the button in the main page :



The StepResponse configuration window appears :

D Step Response Diagnostic		
1		
Inputs	Analysis	General
End Point [2] Ramp	Time [sec] Collection Time [sec]	Dead Band
0		



Step Response Wizard

	Open a saved 'StepResponse' test.		Save the actual 'StepResponse' results
	Create a report with the results	13	See in a graphical way the collected data (also when the test is running)
Û	START the StepResponse	×	STOP a running StepResponse
	See the details about the 'StepResponse' process status	A	Exit



100000

End Point [%

22

C. Automatic Step Generation

Number of Steps

Step Ramp Time [sec]

Collection Time [sec]

Start Point

End Point

Up and Down

12/01/2012 16:30:51: Moving to step 3 12/01/2012 16:30:51: Moving to step 4 12/01/2012 16:30:52: Moving to step 5 Analysis

0,00

5

100,00

0.00

5,00

Generate

î 🔍

•

🔟 Step Response Diagnostic

Start Pos.

Step 1

Step 2 Step 3

Step 4

Step 5

Step 6

Step 7 Step 8

Step 9

Step 10

0

14



General

Dead Band

3

Pressing the 'Step Response Wizard' button the 'Automatic Step Generation' window appears and help the step table generation :

Start Point : First Position for the test

Number of Steps : Number of points in the table

End Point : Final position

Step Ramp Time [sec]:

Stroke time applied for the specific step

Collection Time [sec] :

Time after the step execution

Up and Down flag :

If this option is selected the table has 2 x 'Number of Steps' and the table has step in the UP direction and in the DOWN direction

The '**Generate'** button starts the creation of the table.

It is possible to change the values in the table.

It is also possible to remove or add a new line in the table (to do it, with the mouse pointer on the table, press the right button and a specific menu appears)

and a state of the	Bamp Time [sec]	Collection Time [sec]		Dead E	and
0.00		Concertaint Line [cool	0		
20.00	0		0		
40.00	0		0		
60,00	0		0		
80,00	0		0		
100,00	0		0		
80,00	0		0		
60,00	0		0		
40,00	0		0		
20,00	0		0		
0,00	0		0		
	0,00 20,00 40,00 80,00 100,00 80,00 60,00 40,00 20,00 0,00	0.00 20.00 0 40.00 0 60.00 0 80.00 0 80.00 0 80.00 0 80.00 0 80.00 0 80.00 0 80.00 0 80.00 0 80.00 0 60.00 0 40.00 0 0.00 0	0.00 20.00 0 40.00 0 60.00 0 80.00 0 80.00 0 80.00 0 80.00 0 80.00 0 80.00 0 80.00 0 80.00 0 80.00 0 60.00 0 40.00 0 0.00 0	0.00 0 20.00 0 0 40.00 0 0 60.00 0 0 80.00 0 0 90.00 0 0 80.00 0 0 80.00 0 0 80.00 0 0 80.00 0 0 80.00 0 0 80.00 0 0 90.00 0 0 90.00 0 0 90.00 0 0	0.00 0 20.00 0 0 40.00 0 0 60.00 0 0 80.00 0 0 90.00 0 0 80.00 0 0 80.00 0 0 80.00 0 0 80.00 0 0 80.00 0 0 80.00 0 0 90.00 0 0 0.00 0 0

	E 15 1 184			1	 Dead Band
Charl Doo	End Point [%]	Hamp Time (sec)	Lollection I me [sec]	5	
Step 1	20.00	0		5	
Step 2	40.00	0		5	
Step 3	60.00	0		5	
Step 4	80,00	0		5	
Step 5	100,00	0		5	
Step 6	80,00	0		5	
Step 7	60,00	0	2	5	
Step 8	40,00	0		5	
Step		0		5	
Step	Insert	0		5	
	Delete				





In order to start the test the FasTrak must be in 'Manual' mode. If it is in 'InService' the sw is able to change the status, a specific panel ask for it.



Press the 'Start' button to initiate the test.

Pressing the 'Graph' button it is possible to see the test in the while it is running.







At the end of the test it is possible to see the details of the test with information about the dead time, the T63 and T86 of the specific step, the overshoot (with % of the overshoot related to the specific step).

	End Point [%]	Dead Time (sec)	Iceel CaT	T96 (sec)	TStep [%]	QuerShoot [%]	Error [%]
Step 1	20.0	Dead Time [sec]	0.50	0.68	15(ep [/s] 254	0.00	0.01
Step 7	40.0	0,01	0,00	0,00	2,04	0,00	0,07
Step 3	60.0	0.09	0,22	0.25	1.71	0.00	0.03
Step 4	80,0	0,09	0,19	0,25	1,74	0,00	0,08
Step 5	100,0	0,09	0,19	0,22	0,25	0,00	0,13
Step 6	80,0	0,25	0,40	0,53	3,35	0,00	0,09
Step 7	60,0	0,09	0,19	0,22	2,85	0,00	0,01
Step 8	40,0	0,06	0,16	0,19	3,26	0,00	0,11
Step 9	20,0	0,06	0,16	0,22	2,54	0,00	0,03
Step 10	0,0			27		0,00	-0,01

Pressing the 'Create Report' button a detailed report is generated with all the results and the details of each step.

Disclaimer:

The automatic output data analysis can be affected by imprecision generated from different causes ex noise on signal, multiple overshoot ...

Any data can be verified on graph record.





Option pack 2 : Improved control and diagnostic for High Dynamic Valves

To activate option 2 a specific key must typed on in the main menu Password \rightarrow Key. Inserting the qualification key for 'option pack 2' also the features of 'option pack 1' are activated.



Stability Control

This feature turn on a special algorithm able to control the valve when an instability appears. The benefit of this special function is that the damping action is performed only when an instability appears.

In the TUNING window a parameter called 'Stability control factor' is available to turn on and adjust this feature.

This parameter can assume the values :

- '0' (zero) : turn OFF the functionality
- 5-200 : (low values activate the stability control only for high frequency oscillations, big values activate the stability control also for low frequency oscillations)



Details : The 'stability control' algorithm works damping the positioner output in order to stabilize the system. The algorithm is effective only when an instability is measured on the actual position and terminate the effect when the actual position is stable and also the setpoint is not oscillating.

Examples :







Signal Generator for frequency analysis (Dynamic tests)

This tool automatically generate a sinusoidal setpoint in order to evaluate the valve performances.



The Signal generator moves the valve regardless the 4-20mA setpoint.

This action can be dangerous for peoples or for the process.

Before to start a Signal Generator doublecheck that all the safety requirements are satisfied.

100,00%							10,00bar
90,00%							Cu/Off 9,00bar
90,00%							8,00bar
70,00%							7,00ber
60.00%		10 10	(n) (n)				6,00ber
50.00%		1	RARA	_	_	_	5,00bar
40.00%		y W					4.00bar
30,00%							3.00bar
20.00%							2.00bar
10.00%							1.00bar
0.007: 0.00 2.00	4.00	6,00	8.00	10.00	12,00	14,00	16.00 0.00bar
e (s)	- 1	T 11 1 10			o a Greenel	0.100-	
Start Move C			View En View		CURSOR	41.56%	Press •
50,26 50,00	6,40	3,50 -0	.03	Position •			-





In order to start the SignaGenerator press the button in the main page :

🔟 SΠ - FT	Positioner	System -	Remote Co	ntrol (P	wd Level:
File Devi	ce Passwe	ord Da	ta Recording	g Grap	h Test
	~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~	<b>#</b> 0	0	7	w
					_lh_
					8. J

The SignalGenerator configuration window appears :

Frequency Test           Image: Constraint of the second se		r	General	
Frequency [Hz] Amplitude [%] Cycles Nr. Offset [%] Starting Delay [sec] Dead Band	1.0     0.1 → 10       10     1.100       4     1.100       50     0.100       5     0.100			
0				<b>A</b>

	Open a saved 'Frequency' test.		Save the actual 'Frequency test' results
Constant of the second	Create a report with the results	13	See in a graphical way the collected data (also when the test is running)
Û	START	×	STOP a running test
		<b>A</b>	Exit





**Frequency** [Hz]: 0,1-10 Specify the frequency of the sinusoid that must be generated from 0,1 to 10Hz

Amplitude [%]: 1-100 Amplitude of the sinusoid

**Cycles Nr**.:1-100 Number of sinusoid cycles

**Offset** [%] :0-100 Offset value of the sinusoid

#### Starting Delay [sec] : [0-100]

The actuator is moved at the Offset position, the delay is applied at this moment before to start with the sinusoid



Press the 'Start' button to initiate the test.

Pressing the 'Graph' button it is possible to see the test in the while it is running.







#### Signal Generator result analysis :

The main parameters are :

- The phase shift (absolute value).
- The gain amplification/attenuation.

Using the right button of the mouse it is possible to measure the results of the test.

The feature allows to select any two points on the graph.

- The difference on x axis of the two chosen points is the time between the points and it is used to calculate the phase shift compared to period of input signal. The phase shift is shown on x label [deg] unit.
- The difference on y axis of the two chosen points is the Ao value and it is used to calculate the gain compared to signal amplitude (Ai). The gain is shown on y label [db] unit. (see pag. 48).

#### Phase shift :

With the right button draw a segment between the starting point of the setpoint and the equivalent starting point of the actual position. The system know the frequency of the setpoint and it is able to evaluate the phase delay, shown on the hatched line.

In the picture is showed the phase lag  $95,2^{\circ}$  between setpoint (at 50%) and actual position (at 50%), calculated using the frequency = 1 sec⁻¹ and delay = 2,2644 sec

The formula is: phase lag =  $360/1 \cdot 0,2644 = 95,2^{\circ}$ 







#### Gain :

With the right button draw a segment between the two peaks of the actual position (Ao). The software measure its value and using the amplitude of the setpoint (Ai) is able to calculate the gain, shown on the the vertical side of the hatched triangle.

In the picture is showed the gain -7,6 db, calculated using Ao = 8,32 and Ai = 20. The other value of 188,7° shown on the horizontal side of the hatched triangle is not relevant (It is the phase shift between the two measurement).

The formula is: gain = 20log (Ao/Ai) = 20log (8,32/20) = -7,6 db







#### Soft Approach to seat

This option allows to set a CUTOFF with a reduced risk to hit the seat with the full energy accumulated. Even if valve is moved at the maximum speed and the plug is heavy the control algorithm works to reduce the speed in the last part of the movement reducing (or avoiding) the impact on the seat.

This option can be turned on in the 'travel control' window selecting 'Soft CutOff' and defining the cutoff threshold.

The result of this option is that the positioner moves the valve in the CutOff direction with the maximum speed until the threshold is reached, the last part of the movement happens with a limited speed. At the end the full pressure is applied in order to grant the cutoff feature (full thrust on seat)

The picture shows what happens with a softcutoff set at 2%.







## 375 HandHeld & DD file

#### INSTALLATION

375 Easy Upgrade Programming Utility is required to upload and download files to the 375 Field Communicator. The Programming Utility communicates with the Field Communicator and permits file movement between a PC and a 375.

- Start the Programming Utility

- Verify that the 375 is up-to-date, checking and updating the HART Application for 375 if it's necessary.

Refer to the 375 Field Communicator User's Manual for reference.

General	System Software	🗘 DDs	🔆 User Data	C Event Capture File
375 to PC Database Co	mparison Results	1	_	
Your 375 is out-of-d	ate in the following ways:		HART Enabled FF Enabled Easy Upgrade	Sys Software: 1.4 HART App: 1.0 FF App: 0.2
Check for Updates	Upgrade 375	Detect 275 Disc	System Card:	Memory Usage Free 74.0MB 15.6MB
Click here to check if up	dates are available on the Internet.		Γ	Free Space
			1	constant All Connect





#### - Select File/Import DDs from Local Source

iliport Dos from Cocal Source	m Software	O DDs	User Data	🔆 Event Captur	re F
pgrade 375 ransfer All Jefresh Attached Unit	sults		1		
xit			S	iys Software:	
				FF App:	
				10 million (1997)	
	Upgrade 37		Me Sustem Card	emory Usage F	Free
Check for Updates	Upgrade 37	5 Detect 375 Discon	Me System Card:	emory Usage F	Free
Check for Updates Click here to check if updates are	Upgrade 37	5 Detect 375 Discon	Me System Card:	emory Usage F	Free

- In the Select Path to DD Files dialog, browse to the location of the DDP (directory \375 on the FT installation CD).

- Each DDP (Device Driver Package) consists of two files. A DD binary has an .hdd file extension, and a corresponding binary header has an .hhd file extension.

- Select OK after the desired DDP(s) have been found. The Programming Utility adds the selected DDP(s) into its database.

#### CONNECTION

- Connect the FT device to the 375 (refer to the 375 Field Communicator User's Manual if you need instructions).

- Turn on the 375 Field Communicator. The 375 Main Menu is displayed with HART as the default application.

- Double HART application to run the HART application.

On startup, the HART application will automatically poll for devices.

If a live HART device is connected to the 375 Field Communicator, the HART Application main menu will be displayed automatically with key parameters from the connected device.





#### MENU

1	Main Vars
2	2 System Status
3	3 System Setup
2	Manual Mode
5	5 Position Sensor
6	6 Calibration
7	Communication

1 Main Vars	1 ActPos       100.00%         2 ReqPos       0.99%         3 Input       4.00mA         4 PI       6.00bar         5 PA       6.00bar         6 DP       6.00bar         7 TE       13.70 °C		Set	1 In Service 2 Out Service - Manual	
2 System Status	2 Operation Mode In Service 2 Status 3 Calib.progr./err. 4 Progr./err. Details 5 Data source		2.1 S Ope	1 Open cutoff/limit 2 Open mode	95% CutOff
3 System	1 Travel Control 2 Tuning		3.1 Travel Control	3 Close cutoff/limit 4 Close mode	5% CutOff
4 Manual mode	1 ActPos 2 ReqPos 3 Manual Setpoint 0.00%			1 Kp opening 2 Kp closing 3 Ti opening 4 Ti closing 5 Td opening	1.0 1.0 0 msec 0 msec 0 msec
5 Position	1 Sens. pos. reading4512 Sens. pos. lower lim3 Sens. pos. upper lim.4095			6 Td closing 7 Dead band 8 Open velocity limit 9 Open vel.lim.funct. 10 Close velocity limit	0 msec .20% 10.00s/100% Disabled 10.00s/100%
6 Calibration	1 System Calibration2 0%/fail signal pos.3 Actuator Volume4 Actuator type5 Booster or QE6 Pl7 Norm.supply press.8 Status9 Calib.progr./err.10 Progr./err. Details	w	3.2 Tuning	<ul> <li>11 Close vel.lim</li> <li>12 Damping open</li> <li>13 Damping close</li> <li>14 Switched ctrl err</li> <li>15 Sweep pressure</li> <li>16 Switched ctrl funct.</li> </ul>	Disabled 0 25% 10.0bar Enabled
7 Communication	1 Manufacturer 2 Model 3 Dev id 4 Write protect 5 Tag 6 Descriptor 7 Message 8 Date 9 Hart revision 10 Fld dev rev 11 Software version 12 Poll addr 13 Num req preamms				





#### **Setup Wizard**







## AMS sw interface :

AMS Software is the configuration, calibration, and diagnostic tool. It allows maintenance and operations personnel to monitor control valve health and performance on-line and improve reliability by spotting problems before they affect the process.

#### INSTALLATION

Close AMS if it is running. Disconnect any devices from the system running AMS.

- Select START > Programs > AMS > Add Device Type Manually to open the device installation program.
- Follow the directions on the screen to install the device.
- Once the installation is complete, you're ready to connect your device.

#### CONNECTION

- Once your device has been connected (refer to AMS Installation Guide for information on how to connect a device to AMS) start AMS (refer to the AMS User's Guide if you need instructions).

- Open the Device Connection view, if it is not already open (View > Device Connection View).

After a short delay, you should see the FT device attached to the modem.

le Edit Vie	w Tools Wir	ndow Help	in Disease	SAUTHERSTOT
	6 6 🛛	<u>r   5  1</u>	10 m 0	<b>k?</b>
		1		
	AMS Device	Manager		
5		65		
Plant Data	base 👡	HART Moden	n 1	

#### **DEVICE CONTEXT MENU**

The device context menu appears when you click the right mouse button on the device in either the AMS Device Connection View or the AMS Explorer.

🍰 AMS Suite: Intelligent Device	Manager - [Device Connection
🛉 File Edit View Tools Window	Help
	🗘 🛍 🦗 🔍 🧐
AMS Device Mana	ager T Modem 1
	Configure/Setup Configure/Setup Compare Clear Offline Device Diagnostics
	Process Variables
	Scan Device
	Calibration Management 🕨 Methods
	Rename Unassign Replace
	Audit Trail Record Manual Event Drawings/Notes Help





#### **PROCESS VARIABLES**

Selecting Process Variables... from the device's context menu displays the device's Process Variables screen, i.e., the faceplate. The faceplate reports summary information for the FT device (primary variables, system status, errors,...).

You can also double-click the FT device icon from the Device Connection view to open the FT faceplate and display the process variables.

Process Variables of 10/12/20	09 11:51:02.500 [FT Smart Positioner Rev. 1]	
File Actions Help		
ACTPOS REQPOS 24,95 25,01 24,95 25,01 24,95 25,01 24,95 00,00 100,00 URV URV URV URV URV URV URV URV	SERVICE STATE Operation mode In Service CALIBRATION STATUS Status Calib.progr./err. Calib.progr./err. Data source Field calibrated by user SYSTEM INFO Software Version REV313*D HART Revision FId dev rev 1	SMART POSITIONER
Pl 6,72 bar Obar 10bar	PA 4,54 bar C Obar 10bar HABT Polladdr	0P 0,18 bar Obar 10bar
Tag Message TEST ACTU, Synchronized 75 of 105 Parameters	Descriptor FT POSITIONER	0801000 Help





#### **CONFIGURE/SETUP**

Selecting Configure/Setup from the device's context menu, displays the Configuration Properties screen.

#### System Setup

This window shows the tuning parameters that are part of 'Tuning' & standard 'System setup' area of the standard RemoteControl interface (refer to the FT IOM for explanation of the parameters).

In order to change the parameters the FT must not be in 'INSERVICE' mode ( see 'change the Operation Mode').

🔀 Configure/Setup	of 10/12/2009 11:51	:02.500 [	FT Smart Po	sitioner R	tev. 1]	
File Actions Help						
5 B R						
System Setup Manu	ual Mode/Position Sensor	Calibration	Data Commu	inication		
Travel Control					1	· · · · · · · · · · · · · · · · · · ·
Close cutoff/limit	98,0	%	Off	*		FI
Open cutoff/limit	2,0	%	Off	~		
Tuning					J T	
Kp closing	10,0					
Kp opening	10,0					
Ti closing	400	msec				
Ti opening	400	msec				
Td closing	650	msec				
Td opening	650	msec				
Dead band	0,15	%				
Close velocity limit	200,00	s/100%	Disabled	Ŧ		
Open velocity limit	200,00	s/100%	Disabled	Ţ.		
Damping close	0					
Damping open	0					
Switched ctrl err	25,00	%	Disabled			
Sweep pressure	10,0	bar				
Time Current	-	Г				1
			OK	Cancel	Apply	Help
Synchronized 62 of 105 Pa	arameters					





#### Manual Mode/ Position Sensor

This window is designed to :

Allow to move the actuator in manual mode inserting the target position

If the Operation Mode is 'Out of service : manual' it is possible to specify the target position in the 'Manual setpoint' field. Clicking on the 'Apply' button the positioner move the actuator to the specified position.

Check the position sensor alignement

Refer to the MECHANICAL FEEDBACK LINKAGE MOUNTING paragraph in the FT IOM

Configure/Setup of 10/12/2009 11:51:02.500 [FT Sn	nart Positioner Rev. 1]
File Actions Help	
System Setup Manual Mode/Position Sensor Calibration Data	Communication
Manual Mode	
	FI
Manual setpoint 0,00	2
PWM Fixed Out	bits
1	
25.04	
	*
REQPOS 25,01	%
Posiiton Sensor	
MAX 4000	
Sens.pos.upper lim 862	
Sens.pos.lower lim 3082	
MIN 100	
Sens.pos. reading 2526	
,	
2	
Time Current	
	Lancel Apply Help
Device Last Synchronized: 10/12/2009 16.06.46	1



PT /	

#### CHANGE THE OPERATION MODE

From the Device Context Menù it is possible change the operation mode selecting from

- 'INSERVICE' : the Request Position come from the 4-20mA input
- 'Out of Service : Manual' : the Request Position can be assigned manually, it is possible to change the parameters and configure the positioner.

ِ AMS Suite: Intelligent Device Manage	r - [Device Connection Vi	ew]	
🕎 File Edit View Tools Window Help			
<u>al XB</u> (* * *	¥a  ĵ⊅  №2		
AMS Device Manager	1		
III/12 ²	Configure/Setup Compare Clear Offline Device Diagnostics Process Variables Scan Device		
	Calibration Management		
	Methods 🔹 🕨	Diagnostics	<u>}</u>
	Rename Unassign Replace	Operation Mode Calibrate	Change Mode
	Audit Trail Record Manual Event Drawings/Notes Help		





#### **EDIT A CONFIGURATION PARAMETER**

In order to change the setting of the FT positioner is possible to change the value of one of the field showed in the window.

To send the new value to the
positioner click on the 'Apply'
button.

A confirmation window appear, click on YES to apply the changes.

stem Setup   Manual M	ode/Position Sensor	Calibration	n Data   Commu	nication	
I ravel Control					
Close cutoff/limit	98,0	%	Off	-	FT
Open cutoff/limit	2,0	%	Off	•	••
Tuning					
Kp closing	10				
Kp opening	10,0				
Ti closing	400	msec			
Ti opening	400	msec			
Td closing	650	msec			
Td opening	650	msec			
Dead band	0,15	%			
Close velocity limit	200,00	s/100%	Disabled		
Open velocity limit	200,00	s/100%	Disabled	-	
Damping close	0				
Damping open	0				
Switched ctrl err	25,00	%	Disabled	•	
Sweep pressure	10,0	bar			

zed: 10/12/2009 16.1

Confirm Device (	Configuration Change	? 🔀
	Process control COULD be affected.	
Changing de control of you	vice parameters COULD adversely affect the ur processes.	
Click on the '	'Details'' button Details >>	
Service Reason	Routine Service	•
	Are you sure you want to apply the changes?	
	Yes No	





#### START THE CALIBRATION

From the device context menu select Methods → Calibrate → Actuator in order to start the SelfTuning Wizard.







#### DIAGNOSTIC

From the device context menu it is possible to have access to the diagnostic information panel.

Three window (Overview, critical, Informational) are available with different flags that show the status of the positioner.

Pevice Status	System Status - Device Information
Primary variable out of limits	Setpoint clamped-low
	Setpoint clamped-upp
Non-primary variable out of limits	
Primary variable analog output saturated	Ut off is active 2
	OP clamp is active
Primary variable analog output fixed	System not in service
	Position <= limit 1
More status available	O Position => limit 2
Cold start	Ugital In 1 is on
	Digital In 2 is on
Configuration changed	Digital Out 1 is on
	Digital Out 2 is on
Field device malfunction	Syst.override actived

Device Diagnostics of 10/12/2009 11:51:02.500 [FT Smart Positioner Rev. 1]	🔀 Device Diagnostics of 10/12/2009 11:51:02.500 [FT Smart Positioner Rev. 1]
File Actions Help	File Actions Help
Overview Critical Informational	Overview Critical Informational
System Status - Latched Errors     System Status - Instantaneous Errors       Configuration reset     Too close phys limits       Poscenc.out of range     Poscenc.out of range       Fact settings reset     On failed recovery       Valchog timeout     P As ens.out of range       System to onfigured     PI press.       System to onfigured     PI press.	Operation mode In Service
Pot not linearised         (Entypot of a + 100           Too close physikinits         Pos.enc. out of range           DP sens.out of range         P1 sens.out of range           P1 sens.out of range         P1 sens.out of range           P1 press. (min press.)         (Err)=>5% for =>10s	Calibration Status Status Calib progr./err. Data source Field calibrated by user
Close Help	Close Help





## **Error/Diagnostic bits in HART protocol**

With HART protocol is possible to get different information about error and diagnostic. The HART protocol uses different ways to provide this information.

#### **Device Status**

This byte is part of any answer. Bit [0]= Primary variable Out of limits Bit [1]= Non Primary variable Out of limits Bit [2]= Loop Current saturated Bit [3]= Loop Current Fixed Bit [4]= More status available Bit [5]= Cold Start Bit [6]= Configuration changed Bit [7]= Device Malfunction

Not implemented Not implemented Not implemented

Implemented starting from rel. 1.4.2

#### Common practice command CMD48 : Read additional device status

It is a special command that provide and 'extended status'

[0]= Response command [1]=Device status [2]=Extended status byte0 [3]=Extended status byte1

[4]=Extended status byte2

[5]=Extended status byte3_(bits 8..15)

[6]=Extended status byte3_(bits 0..7)

#### Extended status byte 0 :

[0]	"Configuration reset",	Error [latched] - user configuration has been reset
[1]	"Conf.failed recovery",	"Error [latched] - user configuration data failed recovery"}, // (bad)
[2]	"Fact.settings reset",	"Error [latched] - factory settings have been reset"}, // (bad)
[3]	"Fact.sett.corrupted",	"Error [latched] - factory settings were corrupt at power on"}, // (bad)
[4]	"Watchog timeout",	"Error [latched] - a watchog timeout caused the last system reset"}, // (bad)
[5]	"Syst.not configured",	"Error [latched] - system has not been configured (perhaps first power
on?	?)"}, //	
[6]	"System uncalibrated",	"Error [latched] - system is uncalibrated"}, // (bad)
[7]	"Pot not linearised",	"Error [latched] - the pot has not been linearised"} // [latched]

Bits 0,1,2,3,4,5,6 change the 'More status available' bit

#### Extended status byte 1 :

<ul> <li>[0] "Too close phys.limits",</li> <li>[1] "Pos.enc.out of range",</li> <li>[2] "DP sens.out of range",</li> <li>[3] "PI sens.out of range",</li> <li>[4] "PA sens.out of range",</li> <li>[5] "PI press.&lt; min press.",</li> <li>[6] "(Err)=&gt;5% for =&gt;10s",</li> <li>Bit 1 change the 'More status average</li> </ul>	<ul> <li>"Error [instantaneous] - too close physical limits"},</li> <li>"Error [instantaneous] - position encoder out of range"},</li> <li>"Error [instantaneous] - DP sensor out of range"},</li> <li>"Error [instantaneous] - supply pres sensor out of range"},</li> <li>"Error [instantaneous] - portA sensor out of range"},</li> <li>"Error [instantaneous] - supply pressure &lt; min pressure" }.</li> <li>"Error [instantaneous] - (error)=&gt;5% for =&gt;10seconds"}</li> <li>vailable' bit</li> </ul>
Extended status byte 2	· ·

#### θα διαίμο μγ

[0] '	Too close phys.limits",	"Error [latched] - too close physical limits"},
[1]	"Pos.enc.out of range",	"Error [latched] - position encoder out of range"},
[2]	"DP sens.out of range",	"Error [latched] - DP sensor out of range"},
[3]	"PI sens.out of range",	"Error [latched] - supply pres sensor out of range"},



[6]

#### **INSTRUCTION MANUAL FASTRAK**[™] (software & settings)



- [4] "PA sens.out of range", "Error [latched] - portA sensor out of range"},
- "PI press.< min press.", [5]
- - "Error [latched] supply pressure < min pressure" },
  - "Error [latched] (error)=>5% for =>10seconds"}

#### Extended status byte 3 :

"(Err)=>5% for =>10s",

[0] "Setpoint clamped-low", "Status - setpoint is being clamped (lower clamp)"},

- "Setpoint clamped-upp", "Status setpoint is being clamped (upper clamp)"}, [1]
- [2]
- [3]
- "Cut off is active 1", "Status cut off is active"}, "Cut off is active 2", "Status cut off is active"}, "DP clamp is active", "Status the DP clamp is active"}, [4]
- "System not in service", "Status system not in service"}, [5]

- [5] "System not in service", 'Status system not in service },
  [6] "Position <= limit 1", "Status position <= limit 1"},</li>
  [7] "Position => limit 2", "Status position => limit 2"},
  [8] "Digital In 1 is on", "Status Digital In 1 is on"},
  [9] "Digital In 2 is on", "Status Digital In 2 is on"},
  [10] "Digital Out 1 is on", "Status Digital Out 1 is on"},
  [11] "Digital Out 2 is on", "Status Digital Out 2 is on"},
  [12] "Syst.override actived", "Status digital input has activated system override"}

Bits 10 and 11 change the 'More status available' bit

## Selftune phases :

110	Finding valve limits	The system is in fixed DP mode in the 'up' direction, and is waiting for the
120		The system has begun moving in the up direction in fixed DP
120		mode, and is waiting for the actuator to stop moving
130		The system has stopped moving in the up direction, and is now applying
100		full +DP for a set 'dwell time' at the end stop.
140	•	The system is in fixed DP mode in the down direction, and
		self tune is waiting for the position to start moving.
150		The actuator has started moving in the down direction, in fixed DP
		mode.
160		The actuator has stopped moving, and is assumed to be at the end stop. Self tune is waiting for a pre-set dwell time, with full -DP.
170	Finished finding	The result of the mechanical limits search is being processed and
	actuator limits.	assigned to storage variables.
		This is really just a dummy state which is exited after one cycle.
176	Calibrating the system.	The system is in open loop fixed DP mode, moving up, and self tune is waiting for the position to cross a high threshold.
178	- cyclonini	The system is in open loop fixed DP mode, and is approaching the end
		stop, waiting for the position to stop moving.
180		The system has applied a PWM setting to the output port and is waiting
		for the DP to either come close to a threshold (first loop) or
400		cross a threshold (subsequent loops).
182		I he system has applied a fixed -ve DP value and is waiting for the
184		The actuator has crossed the required low threshold, and the system
104		is now waiting for the actuator to stop moving
186	•	The system has applied a PWM value, and is waiting a fixed period
		of time for the pressure to settle before continuing.
		The length of time of between each change is different depending on
		whether this is the first change.
210	Measuring the stroke	The system has applied a +10bar DP, and is waiting for the actuator
220	time	to cross a high position threshold
220		to stop moving at the high end stop.
230		The system has applied a -10bar DP, and is waiting for the actuator
		to cross a low position threshold.
240	Finished measuring	The system is calculating the fall time, and waiting for the
0.4.0	stroke time.	actuator to stop moving at the low end stop.
310	Characterizing	The temporary friction/DP offset maps have been cleared, and the
	actuator	system has been put into closed loop velocity mode, with a slow
		velocity) just before each 10% marker, and measure the DP at each
		point Self tune continues like this until the position crosses
		95%.
320		The same procedure as in the previous step, except the target
		velocity is in the down direction. Self tune continues until the
		actuator reaches 5%.
330	Measuring friction	To check the previous friction reading, self tune is measuring
		the friction at the valve midpoint. P only control is used, and
		the target position is set to 50%. Waiting for the actuator to
340	1	The actuator has started moving, self tune is now waiting for it to
		settle at a point.
350		The actuator has stopped moving, self tune is now waiting for a pre-set
		time before incrementing/decrementing the setpoint towards the target.
		After each change of the setpoint, self tune watches to see when
000		the position crosses the target (50%).
360		The threshold has been crossed in one direction. Self tune is now

		adjusting the setpoint in the other direction	
370	Finished characterizing	The measurements have finished, and calculations are being performed	
	actuator.	on the results.	
		This is a state which should be immediately exited.	
375	Detailed	This state is only used during transition. It is the start of the	
	characterization	DP/friction mapping phase 3, using break-away pressures at 10%	
		intervals along the stroke.	
380	Detailed	The system is trying to move the actuator to a start position, and is	
	characterization	waiting for the actuator to start moving.	
385		The system is trying to move the actuator to a start position, and is	
		waiting for the actuator to stop moving.	
390		The system is gradually changing the setpoint and waiting for the	
		actuator to cross a threshold	
395		The actuator has now crossed a threshold, and the system is waiting	
		for the actuator to cross another threshold a short distance away.	
		It continues increasing the setpoint to achieve this.	
396		The first crossing has been done, and the system is going back to	
		measure the crossing in the other direction, or it has done both	
		directions, and is now calculating the results.	
		When the very last crossing has been done in both directions,	
		this state is also the place where the full DP offset map is calculated.	
410	Tuning test	The system has set up the PID with default tuning parameters, put the	
		system into closed loop control mode, and is now waiting for the	
	_	actuator to stop moving at a target start point.	
415		The actuator has now slowed down, and the system is waiting for	
		the actuator to stop moving completely.	
420		The system is now making micro adjustments to the setpoint	
		to get the actuator into a known start position for a step test.	
425		The system has now been put into fixed DP mode, and a drive DP has	
		been applied. The reaction rate of the system will be used to	
		tune the PID. In this state, we are waiting for the actuator to move	
430		The system is now waiting for the actuator to cross 60%.	
440	Tuning test complete.	The system is now calculating the PID tuning parameters besed on	
		the ZeiglerNichols reaction rate method.	
1000	Self tune complete!	The self tune completed successfully with no errors	

## Error codes :

111	Position sensor out of range.	The position sensor is not within its measurable range. Please check the alignment of the position sensor to the actuator travel
		Other possible reasons:
		The position oncoder is electrically disconnected
		• The position encoder is feethcally disconnected.
101		• The position encoder is faulty.
121	Movement took too long.	I he actuator did not move quickly enough in the positive
		direction
		Possible reasons:
		<ul> <li>The actuator is too big for the positioner to control</li> </ul>
		directly.
		<ul> <li>When trying to find the actuator limits, the actuator</li> </ul>
		exceeded the maximum allowed up-step time. This
		usually happens when the actuator doesn't move at
		all.
131	Movement timed out	The actuator did not move away from it's positive end stop.
		Possible reasons:
		<ul> <li>The position sensor is mechanically disconnected.</li> </ul>
		<ul> <li>The position sensor is electrically disconnected.</li> </ul>
		<ul> <li>The air supply failed during the test.</li> </ul>
		A fault occurred with the positioner.
		While trying to find the actuator limits, the actuator
		reached.
		<ul> <li>the upper end stop, but then didn't move away from</li> </ul>
		the upper end stop.
141	Movement took too long.	The actuator did not move quickly enough in the negative
	C C	direction
		Possible reasons:
		The air supply failed during the test.
		An external force is causing abnormal movement of
		the actuator.
151	Position sensor out of range!	The position sensor went out of range during the self
	5	tuning.
		Possible reasons:
		<ul> <li>The position sensor is not correctly aligned for the</li> </ul>
		actuator and linkage. The sensor must be within its
		active range for the full stroke of the actuator, and
		this means the start point must be set to allow the full
		travel to be sensed. Please turn off the air supply
		and adjust the potentiometer rotation.
		The position sensor became electrically disconnected
		during the
		test. Please check the electrical connections before
		continuing.
152	Position sensor stroke range too	The position stroke range was too small. For correct
	small!	functioning of
		the positioner, the system requires good resolution on the
		position
		sensor, which requires a minimum difference between the
		min and may travel points of at least 15 degrees. Please adjust or
		change
		the linkage to give more rotation of the sensor, and aim for
		degrees or more for best results
174	The pneumatic system is	With the factory configuration the pneumatic system can
	unstable on this actuator	oscillate on small actuators or seture with narrow hore nines
		To solve this
		problem, turn the PCB trimmer labeled 'SEN.'. one turn
	•	, , , , , , , , , , , , , , , , , , , ,

		clockwise. This reduces the sensitivity of the pneumatic system. Turn an additional revolution if the problem persists. You can reset to factory settings by turning the 'SEN.' trimmer multiple turns anticlockwise, the total range is 11 full revolutions, and there is no hard stop at the end of the range. Never adjust the potentiometer marked 'SPL NULL'. This problem can also occur if there if there is a power supply fault, e.g. voltage supply instead of current supply. If we get here, the DP oscillation detection was triggered during the self tune. We need to give the user practical advice on what to do.
176	Actuator movement took too long.	<ul> <li>The actuator did not move quickly enough in the positive direction,</li> <li>or stopped before it had reached its end stop.</li> <li>Possible reasons: <ul> <li>The actuator air supply failed during the test.</li> <li>The actuator is single acting, and but the single/double acting selector plate on the circuit board is in double acting mode.</li> </ul> </li> </ul>
178	Actuator did not stop at end stop.	<ul> <li>The actuator came close to reaching the travel limit but did not stop.</li> <li>Possible reasons: <ul> <li>There is too much noise in the system.</li> <li>The air supply is unstable.</li> <li>An external force is moving the actuator.</li> </ul> </li> </ul>
180	Internal calibration failed.	The self calibration of the system failed. Please contact your customer support contact to arrange for the unit to be returned. If we get to here, then it means that the pilot has either drifted too far out of calibration, or it is broken/intermittent. In both cases, we want the unit back in the lab to investigate.
182	Actuator movement took too long.	The actuator did not move quickly enough in the negative direction, or stopped before it had reached its end stop. Possible reasons: • The actuator air supply failed during the test.
184	Actuator did not stop at end stop.	<ul> <li>The actuator came close to reaching the travel limit but did not stop.</li> <li>Possible reasons: <ul> <li>There is too much noise in the system.</li> <li>The air supply is unstable."</li> <li>An external force is moving the actuator.</li> </ul> </li> </ul>
186	Internal calibration failed.	The self calibration of the system failed. Please contact your customer support contact to arrange for the unit to be returned. If we get to here, then it means that the pilot has either drifted too far out of calibration, or it is broken/intermittent. In both cases, we want the unit back in the lab to investigate.
206	Actuator took too long or did not move.	<ul> <li>The actuator did not return to 0% within in the required time.</li> <li>Possible reasons: <ul> <li>The actuator volume is too large for the system to control "directly."</li> <li>The position sensor linkage is faulty or has become disconnected.</li> <li>There is a fault with the position sensor.</li> </ul> </li> <li>The state here is just to allow the actuator to move back to the start of its travel, if the previous self tune step left the actuator in a strange place. We wait the full stroke time allowance,</li> </ul>

r		
		before timing out
211	Actuator took too long or did not	The actuator did not reach the required threshold in the
211		rine actuator did not reach the required threshold in the
	move.	
		Possible reasons:
		<ul> <li>I he actuator is single acting, but the system is configured as "double acting."</li> </ul>
		<ul> <li>The actuator volume is too large for the system to</li> </ul>
		control "directly."
221	Error calculating rise-time	An error occurred while calculating the rise time of the
		actuator.
		Please retry. If this error repeats, please contact your
		technical
		support representative.
222	Actuator did not settle.	The actuator did not stop moving after an up step.
		Possible reasons:
		<ul> <li>There is a fault with the position sensor.</li> </ul>
		<ul> <li>An external force is moving the actuator.</li> </ul>
231	Actuator took too long or did not	The actuator did not reach the required threshold in the
	move.	required time
		Possible reasons:
		<ul> <li>The actuator is single acting, but the system is</li> </ul>
		configured as double acting.
		<ul> <li>The actuator volume is too large for the system to</li> </ul>
		control directly
241	Error calculating fall-time	An error occurred while calculating the fall time of the
		actuator.
		Please retry. If this error repeats, please contact your
		technical
		support representative.
242	Actuator did not settle.	The actuator did not stop moving after a down step.
		Possible reasons:
		• There is a fault with the position sensor.
		An external force is moving the actuator.
311	Actuator movement took too	The actuator took too long to move when doing a controlled
	long.	sweep of the actuator travel in the positive direction.
		Possible reasons:
		<ul> <li>The position sensor linkage is faulty or has become</li> </ul>
		disconnected.
		<ul> <li>I nere is a fault with the position sensor.</li> </ul>
010		An external force is moving the actuator.
312	Unstable movement during self	I ne actuator did not move correctly with automatically
	tune.	
		Supply pressure is inconsistent during the test
		• This type of actuator is not supported by the self tune,
		please record details of the actuator type, supply
		pressure and pneumatic configuration, this error
		code, and contact your technical support
204	Actuator may amont tools too	The actuator took too long to may a when doing a controlled
321	Actuator movement took too	The actuator took too long to move when doing a controlled
		Sweep of the actuator travel in the negative direction.
		The position concor linkage is foulty or has become
		<ul> <li>The position sensor linkage is faulty of has become disconnected</li> </ul>
		<ul> <li>There is a fault with the nosition consor</li> </ul>
		• An external force is moving the actuator
331	Actuator failed to move	The actuator failed to move during a critical point of the self
001		
		Possible reasons

		The position sensor linkage is faulty or has become disconnected.
		There is a fault with the position sensor.
341	The actuator did not settle correctly.	The actuator did not settle at when trying to move to a fixed point.
		Possible reasons:
		<ul> <li>The actuator is too small for the system to control."</li> </ul>
		The inner loop gain is too high. Contact your
054		technical support representative.
351	Could not move actuator.	actuator friction
		Possible reasons
		The position sensor linkage is faulty or has become
		disconnected.
		The friction of the actuator is too great for automatic
		tuning.
		<ul> <li>An external force is jaining the actuator.</li> <li>The air supply failed during the test</li> </ul>
361	Could not move actuator	The actuator could not be moved while trying to measure the
001		actuator friction.
		Possible reasons:
		The position sensor linkage is faulty or has become
		disconnected.
		The friction of the actuator is too great for automatic
		An external force is jamming the actuator
		The air supply failed during the test
381	Actuator did not move	The actuator did not move correctly to the start of a
		characterization test.
		Possible reasons:
		The position sensor linkage is faulty or has become
		disconnected.
386	Actuator did pot sottle	I ne air supply failed during the test.      The actuator did not settle while moving to the start of a
500	Actuator did not settle.	characterization test.
		Possible reasons:
		The actuator is too small for the system to control.
		The air supply is unstable.
391	Could not move actuator.	The actuator could not be moved while trying to measure the
		actuator friction.
		The position sensor linkage is faulty or has become
		disconnected.
		The friction of the actuator is too great for automatic
		tuning.
		An external force is jamming the actuator.
200		• The air supply failed during the test.
396	Could not move actuator.	I he actuator could not be moved while trying to measure the
		Possible reasons:
		The position sensor linkage is faulty or has become
		disconnected.
		The friction of the actuator is too great for automatic tuning.
		An external force is jamming the actuator.
411	Actuator did not settle	The actuator did not settle correctly at the start of a tuning
		test.
		Possible reasons:
		The actuator is too small for the system to control.
		The air supply is unstable.

422       Could not move actuator.       The actuator could not be moved close enough to the star point of a tuning test.         422       Could not move actuator.       The actuator could not be moved close enough to the star point of a tuning test.         426       Actuator failed to move.       The actuator is too small for automatic tuning (tune manually).         426       Actuator failed to move.       The actuator is too large/slow for automatic tuning.         431       Actuator did not settle.       The actuator is too large/slow for automatic tuning.         431       Actuator did not settle.       The actuator is too large/slow for automatic tuning.         432       Insufficient actuator movement.       The actuator is too small for the system to control.         432       Insufficient actuator movement.       The actuator is too large/slow for automatic tuning.         432       Insufficient actuator movement.       The actuator is too small for the system to control.         432       Insufficient actuator movement.       The actuator is too small for the system to control.         433       Actuator did not settle.       The actuator did not move enough during a tuning test.         434       Possible reasons:       The actuator is too small for the system to control.         435       The actuator did not move enough during a tuning test.       Possible reasons:         436       The actuator	ns: uator is too small for the system to control. <u>supply is unstable.</u> puld not be moved close enough to the start test. ns: uator is too small for automatic tuning (tune ly). <u>supply failed during the test.</u> d not move during a tuning test. ns: uator is too large/slow for automatic tuning. sition sensor linkage is faulty or has become lected. <u>supply failed during the test.</u> d not settle during a tuning test. ns: uator is too large/slow for automatic tuning. sition sensor linkage is faulty or has become lected. uator is too large/slow for automatic tuning. sition sensor linkage is faulty or has become ected. uator is too small for the system to control.
422       Could not move actuator. <ul> <li>The actuator is too small for the system to control.</li> <li>The air supply is unstable.</li> </ul> 422       Could not move actuator.       The actuator could not be moved close enough to the star point of a tuning test.         426       Actuator failed to move.       The actuator is too small for automatic tuning (tune manually).         426       Actuator failed to move.       The actuator did not move during a tuning test.         426       Actuator failed to move.       The actuator did not move during a tuning test.         426       Actuator failed to move.       The actuator did not move during a tuning test.         427       Possible reasons: <ul> <li>The actuator did not settle during the test.</li> <li>The actuator did not settle during the test.</li> <li>The actuator did not settle during the test.</li> <li>The actuator is too large/slow for automatic tuning.</li> <li>The actuator is too large/slow for automatic tuning.</li> <li>The actuator is too large/slow for automatic tuning.</li> <li>The actuator is too small for the system to control.</li> <li>The actuator is too small for the system to control.</li> <li>The actuator did not move enough during a tuning test.</li> <li>Possible reasons:</li> <li>The actuator is single acting, but the system is configured for double acting actuators.</li> <li>The actuator is too large/slow for automatic tuning.</li> <li>The actuator is too large/slow for automatic tuning.</li> <li>The actuator is too large/slow for automatic tuning.</li> <li>The act</li></ul>	ns: uator is too small for the system to control. <u>supply is unstable.</u> build not be moved close enough to the start i test. ns: uator is too small for automatic tuning (tune ly). <u>supply failed during the test.</u> d not move during a tuning test. ns: uator is too large/slow for automatic tuning. sition sensor linkage is faulty or has become lected. <u>supply failed during the test.</u> d not settle during a tuning test. ns: uator is too large/slow for automatic tuning. sition sensor linkage is faulty or has become ected. uator is too large/slow for automatic tuning. sition sensor linkage is faulty or has become ected. uator is too small for the system to control.
<ul> <li>The actuator is too small for the system to control.</li> <li>The air supply is unstable.</li> <li>Could not move actuator.</li> <li>The actuator could not be moved close enough to the star point of a tuning test.</li> <li>Possible reasons:         <ul> <li>The actuator is too small for automatic tuning (tune manually).</li> <li>The actuator did not move during a tuning test.</li> </ul> </li> <li>Actuator failed to move.</li> <li>The actuator did not move during a tuning test.</li> <li>Possible reasons:         <ul> <li>The actuator is too large/slow for automatic tuning.</li> <li>The actuator did not settle.</li> </ul> </li> <li>Actuator did not settle.</li> <li>The actuator is too large/slow for automatic tuning.</li> <li>The actuator did not settle during the test.</li> <li>The actuator did not settle during test.</li> <li>Possible reasons:         <ul> <li>The actuator did not settle during the test.</li> </ul> </li> <li>Actuator did not settle.</li> <li>The actuator is too large/slow for automatic tuning.</li> <li>The actuator did not settle during a tuning test.</li> <li>Possible reasons:         <ul> <li>The actuator is too small for the system to control.</li> <li>The actuator is too small for the system to control.</li> <li>The actuator is too small for the system to control.</li> <li>The actuator is too small for the system to control.</li> <li>The actuator did not move enough during a tuning test.</li> <li>Possible reasons:                 <ul> <li>The actuator is on large/slow for automatic tuning.</li> <li>The actuator did not move enough during a tuning test.</li> <li>Possible reasons:                 <ul> <li>The actuator did not move enough during a tuning test.</li> <li>Possible r</li></ul></li></ul></li></ul></li></ul>	uator is too small for the system to control. <u>supply is unstable.</u> puld not be moved close enough to the start test. ns: uator is too small for automatic tuning (tune ly). <u>supply failed during the test.</u> d not move during a tuning test. ns: uator is too large/slow for automatic tuning. sition sensor linkage is faulty or has become lected. <u>supply failed during the test.</u> d not settle during a tuning test. ns: uator is too large/slow for automatic tuning. sition sensor linkage is faulty or has become lected. uator is too large/slow for automatic tuning. sition sensor linkage is faulty or has become ected. uator is too small for the system to control.
422       Could not move actuator. <ul> <li>The actuator could not be moved close enough to the star point of a tuning test. Possible reasons:                 <ul> <li>The actuator is too small for automatic tuning (tune manually).</li> <li>The actuator did not move.</li> <li>The actuator is too large/slow for automatic tuning.</li> <li>The actuator is too large/slow for automatic tuning.</li></ul></li></ul>	supply is unstable. puld not be moved close enough to the start test. ns: uator is too small for automatic tuning (tune ly). supply failed during the test. d not move during a tuning test. ns: uator is too large/slow for automatic tuning. sition sensor linkage is faulty or has become lected. supply failed during the test. d not settle during a tuning test. ns: uator is too large/slow for automatic tuning. sition sensor linkage is faulty or has become ected. uator is too large/slow for automatic tuning. sition sensor linkage is faulty or has become ected. uator is too small for the system to control.
422       Could not move actuator.       The actuator could not be moved close enough to the star point of a tuning test. Possible reasons:         426       Actuator failed to move.       The actuator is too small for automatic tuning (tune manually).         426       Actuator failed to move.       The actuator did not move during a tuning test. Possible reasons:         426       Actuator failed to move.       The actuator is too large/slow for automatic tuning.         431       Actuator did not settle.       The actuator did not settle during a tuning test. Possible reasons:         431       Actuator did not settle.       The actuator is too large/slow for automatic tuning.         431       Actuator did not settle.       The actuator is too large/slow for automatic tuning.         431       Actuator did not settle.       The actuator is too large/slow for automatic tuning.         432       Insufficient actuator movement.       The actuator is too small for the system to control.         432       Insufficient actuator movement.       The actuator is single acting, but the system is configured for double acting actuators.         432       Insufficient actuator movement.       The actuator is too large/slow for automatic tuning test. Possible reasons:         432       Insufficient actuator movement.       The actuator is single acting, but the system is configured for double acting actuators. • The actuator is too large/slow for automatic tuning.	build not be moved close enough to the start g test. ns: uator is too small for automatic tuning (tune ly). <u>supply failed during the test.</u> d not move during a tuning test. ns: uator is too large/slow for automatic tuning. sition sensor linkage is faulty or has become lected. <u>supply failed during the test.</u> d not settle during a tuning test. ns: uator is too large/slow for automatic tuning. sition sensor linkage is faulty or has become ected. uator is too small for the system to control.
426       Actuator failed to move.       The actuator is too small for automatic tuning (tune manually).         426       Actuator failed to move.       The actuator is too small for automatic tuning test.         426       Actuator failed to move.       The actuator did not move during a tuning test.         426       Actuator failed to move.       The actuator is too large/slow for automatic tuning.         427       The actuator did not move during a tuning test.         90510       Possible reasons:         •       The actuator is too large/slow for automatic tuning.         •       The actuator did not move during a tuning test.         90510       Possible reasons:         •       The actuator did not settle.         431       Actuator did not settle.         431       Actuator did not settle.         431       Actuator did not settle.         432       The actuator did not settle.         433       The actuator movement.         434       The actuator movement.         435       Insufficient actuator movement.         436       The actuator is single acting, but the system is configured for double acting actuators.         437       Insufficient actuator movement.         438       Insufficient actuator movement.         439       The actuato	g test. ns: uator is too small for automatic tuning (tune ly). <u>supply failed during the test.</u> d not move during a tuning test. ns: uator is too large/slow for automatic tuning. sition sensor linkage is faulty or has become lected. <u>supply failed during the test.</u> d not settle during a tuning test. ns: uator is too large/slow for automatic tuning. sition sensor linkage is faulty or has become ected. uator is too small for the system to control.
426       Actuator failed to move. <ul> <li>The actuator is too small for automatic tuning (tune manually).</li> <li>The air supply failed during the test.</li> </ul> 426         Actuator failed to move.              The actuator did not move during a tuning test. <ul> <li>Possible reasons:</li> <li>The actuator is too large/slow for automatic tuning.</li> <li>The position sensor linkage is faulty or has become disconnected.</li> <li>The actuator did not settle.</li> </ul> 431         Actuator did not settle. <ul> <li>The actuator is too large/slow for automatic tuning.</li> <li>The actuator did not settle during a tuning test.</li> <li>Possible reasons:                 <ul> <li>The actuator is too large/slow for automatic tuning.</li> <li>The actuator is too large/slow for automatic tuning.</li> <li>The actuator is too large/slow for automatic tuning.</li> <li>The actuator is too small for the system to control.</li> <li>The actuator is too small for the system to control.</li> <li>The actuator is ingle acting, but the system is configured for double acting actuators.</li> <li>The actuator is too large/slow for automatic tuning.</li> <li>The actuator is too large/slow for automatic tuning.</li> <li>The actuator is ingle acting, but the system is configured for double acting actuators.</li> <li>The actuator is too large/slow for automatic tuning.</li> <li>The actuator is too large/slow for automatic tuning.</li> <li>The</li></ul></li></ul>	ns: uator is too small for automatic tuning (tune ly). <u>supply failed during the test.</u> d not move during a tuning test. ns: uator is too large/slow for automatic tuning. sition sensor linkage is faulty or has become lected. <u>supply failed during the test.</u> d not settle during a tuning test. ns: uator is too large/slow for automatic tuning. sition sensor linkage is faulty or has become ected. uator is too small for the system to control.
<ul> <li>The actuator is too small for automatic tuning (tune manually).</li> <li>The air supply failed during the test.</li> <li>Actuator failed to move.</li> <li>The actuator did not move during a tuning test.</li> <li>Possible reasons:         <ul> <li>The actuator is too large/slow for automatic tuning.</li> <li>The actuator is too large/slow for automatic tuning.</li> <li>The actuator did not settle.</li> </ul> </li> <li>Actuator did not settle.</li> <li>The actuator did not settle during the test.</li> <li>The actuator did not settle.</li> <li>The actuator is too large/slow for automatic tuning.</li> <li>The actuator is too sensor linkage is faulty or has become disconnected.</li> <li>The actuator is too sensor linkage is faulty or has become disconnected.</li> <li>The actuator is too small for the system to control.</li> <li>The actuator did not move enough during a tuning test.</li> <li>Possible reasons:</li> <li>The actuator did not move enough during a tuning test.</li> <li>Possible reasons:</li> <li>The actuator is single acting, but the system is configured for double acting actuators.</li> <li>The actuator is too large/slow for automatic tuning.</li> </ul>	uator is too small for automatic tuning (tune ly). supply failed during the test. d not move during a tuning test. ns: uator is too large/slow for automatic tuning. sition sensor linkage is faulty or has become lected. supply failed during the test. d not settle during a tuning test. ns: uator is too large/slow for automatic tuning. sition sensor linkage is faulty or has become ected. uator is too small for the system to control.
Manually).The air supply failed during the test.426Actuator failed to move.The actuator did not move during a tuning test. Possible reasons: • The actuator is too large/slow for automatic tuning. • The position sensor linkage is faulty or has become disconnected. • The air supply failed during the test.431Actuator did not settle.The actuator did not settle during a tuning test. Possible reasons: • The actuator is too large/slow for automatic tuning. • The actuator is too large/slow for automatic tuning. • The actuator is too large/slow for automatic tuning.431Actuator did not settle.The actuator is too large/slow for automatic tuning. • The actuator is too large/slow for automatic tuning. • The position sensor linkage is faulty or has become disconnected. • The actuator is too small for the system to control. • The air supply is unstable.432Insufficient actuator movement.The actuator did not move enough during a tuning test. Possible reasons: • The actuator is single acting, but the system is configured for double acting actuators. • The actuator is too large/slow for automatic tuning.	ly). supply failed during the test. d not move during a tuning test. ns: uator is too large/slow for automatic tuning. sition sensor linkage is faulty or has become lected. <u>supply failed during the test.</u> d not settle during a tuning test. ns: uator is too large/slow for automatic tuning. sition sensor linkage is faulty or has become ected. uator is too small for the system to control.
<ul> <li>The air supply failed during the test.</li> <li>426</li> <li>Actuator failed to move.</li> <li>The actuator did not move during a tuning test. Possible reasons:         <ul> <li>The actuator is too large/slow for automatic tuning.</li> <li>The position sensor linkage is faulty or has become disconnected.</li> <li>The actuator did not settle.</li> </ul> </li> <li>431</li> <li>Actuator did not settle.</li> <li>The actuator is too large/slow for automatic tuning.</li> <li>The actuator did not settle during the test.</li> <li>Possible reasons:         <ul> <li>The actuator is too large/slow for automatic tuning.</li> </ul> </li> <li>432</li> <li>Insufficient actuator movement.</li> <li>The actuator did not move enough during a tuning test.</li> <li>Possible reasons:         <ul> <li>The actuator did not move enough during a tuning test.</li> <li>Possible reasons:                 <ul> <li>The actuator did not move enough during a tuning test.</li> <li>Possible reasons:                         <ul> <li>The actuator did not move enough during a tuning test.</li> <li>Possible reasons:</li></ul></li></ul></li></ul></li></ul>	supply failed during the test. d not move during a tuning test. ns: uator is too large/slow for automatic tuning. sition sensor linkage is faulty or has become lected. supply failed during the test. d not settle during a tuning test. ns: uator is too large/slow for automatic tuning. sition sensor linkage is faulty or has become ected. uator is too small for the system to control.
<ul> <li>426 Actuator failed to move.</li> <li>426 The actuator did not move during a tuning test. Possible reasons: <ul> <li>The actuator is too large/slow for automatic tuning.</li> <li>The position sensor linkage is faulty or has become disconnected.</li> <li>The air supply failed during the test.</li> </ul> </li> <li>431 Actuator did not settle.</li> <li>431 Actuator did not settle.</li> <li>431 The actuator did not settle.</li> <li>The actuator did not settle during a tuning test. Possible reasons: <ul> <li>The actuator did not settle during a tuning test.</li> <li>Possible reasons:</li> <li>The actuator is too large/slow for automatic tuning.</li> <li>The position sensor linkage is faulty or has become disconnected.</li> <li>The position sensor linkage is faulty or has become disconnected.</li> <li>The actuator is too small for the system to control.</li> <li>The air supply is unstable.</li> </ul> </li> <li>432 Insufficient actuator movement.</li> <li>The actuator did not move enough during a tuning test. Possible reasons: <ul> <li>The actuator did not move enough during a tuning test.</li> <li>Possible reasons:</li> <li>The actuator did not move enough during a tuning test.</li> <li>Possible reasons:</li> <li>The actuator is single acting, but the system is configured for double acting actuators.</li> <li>The actuator is too large/slow for automatic tuning.</li> </ul> </li> </ul>	d not move during a tuning test. ns: uator is too large/slow for automatic tuning. sition sensor linkage is faulty or has become lected. <u>supply failed during the test.</u> d not settle during a tuning test. ns: uator is too large/slow for automatic tuning. sition sensor linkage is faulty or has become ected. uator is too small for the system to control.
<ul> <li>Possible reasons:         <ul> <li>The actuator is too large/slow for automatic tuning.</li> <li>The position sensor linkage is faulty or has become disconnected.</li> <li>The air supply failed during the test.</li> </ul> </li> <li>431 Actuator did not settle.</li> <li>The actuator did not settle during a tuning test.</li> <li>Possible reasons:         <ul> <li>The actuator is too large/slow for automatic tuning.</li> <li>The actuator is too large/slow for automatic tuning.</li> <li>The actuator is too large/slow for automatic tuning.</li> <li>The position sensor linkage is faulty or has become disconnected.</li> <li>The actuator is too small for the system to control.</li> <li>The actuator did not move enough during a tuning test.</li> </ul> <li>Possible reasons:         <ul> <li>The actuator did not move enough during a tuning test.</li> <li>Possible reasons:                 <ul> <li>The actuator did not move enough during a tuning test.</li> <li>Possible reasons:                         <ul> <li>The actuator is single acting, but the system is configured for double acting actuators.</li> <li>The actuator is too large/slow for automatic tuning.</li></ul></li></ul></li></ul></li></li></ul>	ns: uator is too large/slow for automatic tuning. sition sensor linkage is faulty or has become lected. <u>supply failed during the test.</u> d not settle during a tuning test. ns: uator is too large/slow for automatic tuning. sition sensor linkage is faulty or has become lected. uator is too small for the system to control.
<ul> <li>Actuator did not settle.</li> <li>Actuator did not settle.</li> <li>The actuator did not settle.</li> <li>The actuator did not settle.</li> <li>The actuator did not settle during the test.</li> <li>The actuator did not settle during a tuning test.</li> <li>Possible reasons:         <ul> <li>The actuator is too large/slow for automatic tuning.</li> <li>The actuator did not settle during a tuning test.</li> <li>Possible reasons:                <ul> <li>The actuator is too large/slow for automatic tuning.</li> <li>The actuator is too large/slow for automatic tuning.</li> <li>The actuator is too sensor linkage is faulty or has become disconnected.</li> <li>The actuator is too small for the system to control.</li> <li>The actuator did not move enough during a tuning test.</li> <li>Possible reasons:</li></ul></li></ul></li></ul>	uator is too large/slow for automatic tuning. sition sensor linkage is faulty or has become lected. <u>supply failed during the test.</u> d not settle during a tuning test. ns: uator is too large/slow for automatic tuning. sition sensor linkage is faulty or has become lected. uator is too small for the system to control.
<ul> <li>Actuator did not settle.</li> <li>Actuator did not settle.</li> <li>The actuator did not settle during a tuning test.</li> <li>Possible reasons:         <ul> <li>The actuator is too large/slow for automatic tuning.</li> <li>The actuator is too small for the system to control.</li> <li>The actuator did not move enough during a tuning test.</li> </ul> </li> <li>Insufficient actuator movement.</li> <li>Insufficient actuator movement.</li> <li>The actuator is single acting, but the system is configured for double acting actuators.</li> <li>The actuator is too large/slow for automatic tuning.</li> </ul>	sition sensor linkage is faulty or has become nected. <u>supply failed during the test.</u> d not settle during a tuning test. ns: uator is too large/slow for automatic tuning. sition sensor linkage is faulty or has become nected. uator is too small for the system to control.
disconnected.431Actuator did not settle.The air supply failed during the test.431Actuator did not settle.The actuator did not settle during a tuning test. Possible reasons: • The actuator is too large/slow for automatic tuning. • The position sensor linkage is faulty or has become disconnected. • The actuator is too small for the system to control. • The air supply is unstable.432Insufficient actuator movement.The actuator did not move enough during a tuning test. Possible reasons: • The actuator is single acting, but the system is configured for double acting actuators. • The actuator is too large/slow for automatic tuning.	supply failed during the test. a not settle during a tuning test. ns: uator is too large/slow for automatic tuning. sition sensor linkage is faulty or has become lected. uator is too small for the system to control.
<ul> <li>431</li> <li>Actuator did not settle.</li> <li>431</li> <li>Actuator did not settle.</li> <li>The actuator did not settle during a tuning test. Possible reasons:         <ul> <li>The actuator is too large/slow for automatic tuning.</li> <li>The position sensor linkage is faulty or has become disconnected.</li> <li>The actuator is too small for the system to control.</li> <li>The actuator did not move enough during a tuning test.</li> </ul> </li> <li>432</li> <li>Insufficient actuator movement.</li> <li>The actuator is single acting, but the system is configured for double acting actuators.</li> <li>The actuator is too large/slow for automatic tuning.</li> </ul>	supply failed during the test. d not settle during a tuning test. ns: uator is too large/slow for automatic tuning. sition sensor linkage is faulty or has become lected. uator is too small for the system to control.
<ul> <li>431 Actuator did not settle.</li> <li>431 Actuator did not settle.</li> <li>1 he actuator did not settle during a tuning test.</li> <li>Possible reasons:         <ul> <li>The actuator is too large/slow for automatic tuning.</li> <li>The position sensor linkage is faulty or has become disconnected.</li> <li>The actuator is too small for the system to control.</li> <li>The air supply is unstable.</li> </ul> </li> <li>432 Insufficient actuator movement.</li> <li>The actuator did not settle during a tuning test.</li> <li>Possible reasons:         <ul> <li>The actuator is too small for the system to control.</li> <li>The air supply is unstable.</li> </ul> </li> <li>432 Insufficient actuator movement.</li> <li>The actuator did not move enough during a tuning test.</li> <li>Possible reasons:         <ul> <li>The actuator is single acting, but the system is configured for double acting actuators.</li> <li>The actuator is too large/slow for automatic tuning.</li> </ul> </li> </ul>	a not settle during a tuning test. ns: uator is too large/slow for automatic tuning. sition sensor linkage is faulty or has become lected. uator is too small for the system to control.
<ul> <li>432</li> <li>Insufficient actuator movement.</li> <li>The actuator is too large/slow for automatic tuning.</li> <li>The position sensor linkage is faulty or has become disconnected.</li> <li>The actuator is too small for the system to control.</li> <li>The air supply is unstable.</li> <li>The actuator did not move enough during a tuning test.</li> <li>Possible reasons:         <ul> <li>The actuator is single acting, but the system is configured for double acting actuators.</li> <li>The actuator is too large/slow for automatic tuning.</li> </ul> </li> </ul>	uator is too large/slow for automatic tuning. sition sensor linkage is faulty or has become ected. uator is too small for the system to control.
<ul> <li>The actuator is too large/slow for automatic tuning.</li> <li>The position sensor linkage is faulty or has become disconnected.</li> <li>The actuator is too small for the system to control.</li> <li>The air supply is unstable.</li> <li>A32 Insufficient actuator movement.</li> <li>The actuator did not move enough during a tuning test.</li> <li>Possible reasons:         <ul> <li>The actuator is single acting, but the system is configured for double acting actuators.</li> <li>The actuator is too large/slow for automatic tuning.</li> </ul> </li> </ul>	sition sensor linkage is faulty or has become lected. uator is too small for the system to control.
<ul> <li>432 Insufficient actuator movement.</li> <li>432 Insufficient actuator movement.</li> <li>433 The actuator did not move enough during a tuning test. Possible reasons:</li> <li>434 The actuator is single acting, but the system is configured for double acting actuators.</li> <li>435 The actuator is too large/slow for automatic tuning.</li> </ul>	ected. uator is too small for the system to control.
<ul> <li>The actuator is too small for the system to control.</li> <li>The air supply is unstable.</li> <li>432 Insufficient actuator movement.</li> <li>The actuator did not move enough during a tuning test. Possible reasons:         <ul> <li>The actuator is single acting, but the system is configured for double acting actuators.</li> <li>The actuator is too large/slow for automatic tuning.</li> </ul> </li> </ul>	uator is too small for the system to control.
<ul> <li>432</li> <li>432</li> <li>Insufficient actuator movement.</li> <li>The actuator did not move enough during a tuning test. Possible reasons:         <ul> <li>The actuator is single acting, but the system is configured for double acting actuators.</li> <li>The actuator is too large/slow for automatic tuning.</li> </ul> </li> </ul>	
<ul> <li>432 Insufficient actuator movement.</li> <li>432 The actuator did not move enough during a tuning test.</li> <li>432 Possible reasons:         <ul> <li>The actuator is single acting, but the system is configured for double acting actuators.</li> <li>The actuator is too large/slow for automatic tuning.</li> </ul> </li> </ul>	
Possible reasons: • The actuator is single acting, but the system is configured for double acting actuators. • The actuator is too large/slow for automatic tuning.	1 not move enough during a tuning test
<ul> <li>The actuator is single acting, but the system is configured for double acting actuators.</li> <li>The actuator is too large/slow for automatic tuning.</li> </ul>	ns:
<ul> <li>configured for double acting actuators.</li> <li>The actuator is too large/slow for automatic tuning.</li> </ul>	uator is single acting but the system is
The actuator is too large/slow for automatic tuning.	red for double acting actuators.
	uator is too large/slow for automatic tuning.
The air supply failed during the test	supply failed during the test
An external force is jamming the actuator	rnal force is jamming the actuator
441 Error calculating PID An error occurred while calculating the PID parameters.	ed while calculating the PID parameters.
parameters. Please retry and if the problem repeats, contact your	d if the problem repeats, contact your
technical support	rt i i i i i i i i i i i i i i i i i i i
representative. As an interim solution, please manually	As an interim solution, please manually
choose appropriate PID tuning parameters.	iate PID tuning parameters.
995 Unexpected software error. An unexpected software error occurred, please record the	software error occurred, please record the
following and pass them to your customer support	ass them to your customer support
representative:	
What type of actuator you are using.	and a set of the set o
Whether you have any boosters fitted in the supply	pe of actuator you are using.
lines.	pe of actuator you are using. r you have any boosters fitted in the supply
The progress indicator value	rpe of actuator you are using. r you have any boosters fitted in the supply
Any other details about the application	pe or actuator you are using. r you have any boosters fitted in the supply gress indicator value
An un-trapped software error has occurred, and the system	pe of actuator you are using. If you have any boosters fitted in the supply gress indicator value er details about the application
has reached an unexpected state. This probably indicates	pe of actuator you are using. If you have any boosters fitted in the supply gress indicator value er details about the application software error has occurred, and the system
soltware bug, so we need to get as much information about	pe of actuator you are using. Fryou have any boosters fitted in the supply ogress indicator value er details about the application software error has occurred, and the system unexpected state. This probably indicates a
Ine application and fault as possible.	pe of actuator you are using. er you have any boosters fitted in the supply ogress indicator value er details about the application software error has occurred, and the system unexpected state. This probably indicates a b we need to get as much information about
An unexpected software error An unexpected software error occurred, please record the following and pass them to your customer support	pe of actuator you are using. er you have any boosters fitted in the supply ogress indicator value er details about the application software error has occurred, and the system unexpected state. This probably indicates a p we need to get as much information about and fault as possible.
representative:	pe or actuator you are using. er you have any boosters fitted in the supply ogress indicator value er details about the application software error has occurred, and the system unexpected state. This probably indicates a p we need to get as much information about and fault as possible. software error occurred, please record the uses them to your customer support
Toprosonitairo.	pe of actuator you are using. er you have any boosters fitted in the supply orgress indicator value er details about the application software error has occurred, and the system unexpected state. This probably indicates a p we need to get as much information about and fault as possible. software error occurred, please record the iss them to your customer support
What type of actuator you are using	pe of actuator you are using. er you have any boosters fitted in the supply agress indicator value er details about the application software error has occurred, and the system unexpected state. This probably indicates a b we need to get as much information about and fault as possible. software error occurred, please record the ass them to your customer support
<ul> <li>What type of actuator you are using.</li> <li>Whether you have any boosters fitted in the supply</li> </ul>	pe of actuator you are using. r you have any boosters fitted in the supply gress indicator value er details about the application software error has occurred, and the system unexpected state. This probably indicates a b we need to get as much information about and fault as possible. software error occurred, please record the ass them to your customer support pe of actuator you are using. r you have any boosters fitted in the supply
<ul> <li>What type of actuator you are using.</li> <li>Whether you have any boosters fitted in the supply lines</li> </ul>	pe of actuator you are using. er you have any boosters fitted in the supply ogress indicator value er details about the application software error has occurred, and the system unexpected state. This probably indicates a powe need to get as much information about and fault as possible. software error occurred, please record the ass them to your customer support pe of actuator you are using. r you have any boosters fitted in the supply
<ul> <li>What type of actuator you are using.</li> <li>Whether you have any boosters fitted in the supply lines.</li> <li>The progress indicator value</li> </ul>	pe of actuator you are using. er you have any boosters fitted in the supply ogress indicator value er details about the application software error has occurred, and the system unexpected state. This probably indicates a to we need to get as much information about and fault as possible. software error occurred, please record the ass them to your customer support pe of actuator you are using. r you have any boosters fitted in the supply gress indicator value
<ul> <li>What type of actuator you are using.</li> <li>Whether you have any boosters fitted in the supply lines.</li> <li>The progress indicator value</li> <li>Any other details about the application</li> </ul>	pe of actuator you are using. er you have any boosters fitted in the supply agress indicator value er details about the application software error has occurred, and the system unexpected state. This probably indicates a to we need to get as much information about and fault as possible. software error occurred, please record the ass them to your customer support pe of actuator you are using. r you have any boosters fitted in the supply gress indicator value er details about the application
<ul> <li>What type of actuator you are using.</li> <li>Whether you have any boosters fitted in the supply lines.</li> <li>The progress indicator value</li> <li>Any other details about the application</li> </ul>	pe of actuator you are using. er you have any boosters fitted in the supply agress indicator value er details about the application software error has occurred, and the system unexpected state. This probably indicates a powe need to get as much information about and fault as possible. software error occurred, please record the ass them to your customer support pe of actuator you are using. er you have any boosters fitted in the supply gress indicator value er details about the application oftware error has occurred, and the system
<ul> <li>What type of actuator you are using.</li> <li>Whether you have any boosters fitted in the supply lines.</li> <li>The progress indicator value</li> <li>Any other details about the application</li> <li>An un-trapped software error has occurred, and the system has reached an unexpected state. This probably indicates</li> </ul>	pe of actuator you are using. er you have any boosters fitted in the supply agress indicator value er details about the application software error has occurred, and the system unexpected state. This probably indicates a powe need to get as much information about and fault as possible. software error occurred, please record the ass them to your customer support pe of actuator you are using. er you have any boosters fitted in the supply gress indicator value er details about the application oftware error has occurred, and the system unexpected state. This probably indicates a
<ul> <li>What type of actuator you are using.</li> <li>Whether you have any boosters fitted in the supply lines.</li> <li>The progress indicator value</li> <li>Any other details about the application</li> <li>An un-trapped software error has occurred, and the system has reached an unexpected state. This probably indicates software bug, so we need to get as much information about</li> </ul>	pe of actuator you are using. er you have any boosters fitted in the supply agress indicator value er details about the application software error has occurred, and the system unexpected state. This probably indicates a powe need to get as much information about and fault as possible. software error occurred, please record the ass them to your customer support pe of actuator you are using. r you have any boosters fitted in the supply gress indicator value er details about the application software error has occurred, and the system unexpected state. This probably indicates a p we need to get as much information about

997	Digital input triggered abort.	The self tune procedure was aborted because a digital input was previously configured to put the valve into a safe state, and this digital input triggered during the sequence. Please check the equipment connected to the digital inputs, to ensure that it will not fire during the self tuning, or alternatively, disable the digital input override setting in the control interface.
998	Self tune aborted by user.	The self tune was aborted at the request of the user. Please restart the self tune when ready.
999	Feature not implemented	The self tuning procedure was attempted on a setup that the system is not currently capable of handling automatically. Please perform limits only tuning, and then tune the parameters manually.

Information in this manual is protected by copyright. All rights are reserved. No part of this manual and relevant mentioned and/or enclosed documentation may be reproduced without written authorization by STI S.r.I. STI S.r.I. is not responsible for possible damage to people, equipment or data which might arise from incorrect use of the product to

which the manual is referred.

Information in this document may be modified at any time without notice.





# Instruction manual for field barrier ID series





### INSTRUCTION MANUAL FASTRAK™ (field barrier)



#### INDEX

1.		Generalità	General prescription	3
	1.1	Dati identificazione del fabbricante	Manufacturer's identification data	3
	1.2	Avvertenze generali di sicurezza	General safety instruction	3
	1.3	Immagazzinamento	Storage	4
	1.4	Manutenzione	Maintenance	4
2.	-	Barriera	Field barrier	4
	2.1	Generalità	General features	4
	2.2	Caratteristiche tecniche	Technical features	5
	2.3	Installazione	Installation	5
	2.4	Descrizione prodotto	Product description	7
	2.5	Certificato ATEX / IECEX	ATEX / IECEX certificate	Annex




#### 1. GENERALITA'

La barriera mod. ID è stata studiata e deve essere utilizzata solo montata sul posizionatore STI serie FT al fine di garantirne l'utilizzo in area classificata a rischio di esplosione con metodo di protezione Ex "d". Per le caratteristiche tecniche della barriera montata direttamente sul posizionatore FT, vedere manuale d'istruzioni 4028.



1.1

#### DATI DI IDENTIFICAZIONE DEL FABBRICANTE

Ogni barriera modello ID è provvisto di un'apposita targa con il numero di matricola.



E' vietato asportare la targa e/o sostituirla con altre targhe.

1. GENERAL PRESCRIPTIONS

Field barrier mod.ID was designed and has to be used only mounted on STI positioned series FT in order to allow its use in explosion hazard risk classified area with protection method Ex "d". For technical information concerning field barrier mounted directly on the FT positioner, see FT instruction manual 4028.

# 1.1 MANUFACTURER'S IDENTIFICATION DATA

Every field barrier mod.ID is provided with a name plate with its serial number.

Do not remove it and/or replace it with other name plates

STI srl Via Dei Caravaggi 15 FIELD BARRIER ID Year of 1	24040–Levate(BG)ITALY Manufacture
<b>(E</b> 0359 Serial N [*]	
○ < <u>Ex</u> ll2(1)G Ex d[ia Ga]IIC T5/T6 Gb	Baseefa 11ATEX0158X IECEX BAS 11.0080X
Um=254V	Ta: -40°C to 80°C/60°C
Uo=27,45V lo=87mA Po=0,597	W Co=86nF Lo=4,2mH
Cable entry may exce Do not open when a flammable a	tmosphere may be present

Nella versione antideflagrante il dispositivo è progettato per operare in area potenzialmente esplosiva classificata:

## II 2(1)G Ex d [ia Ga] IIC T5/T6 Gb

Apparecchio gruppo II per industrie di superficie, categoria 2 per utilizzo, zona 1 con atmosfere esplosive causate da gas, vapori o nebbie. Conforme ai tipi di protezione secondo EN 60079-0 ed EN60079-1. La massima temperatura sulla superficie non deve superare i 100°C in ambiente con temperatura di 80°C ed è adatto all'utilizzo in ambienti con gas con classe di temperatura T5.

#### 1.2 AVVERTENZE GENERALI DI SICUREZZA



- 1.2.1 Prima di effettuare qualsiasi intervento, gli operatori hanno il dovere di leggere il presente manuale, adottando le prescrizioni specifiche di sicurezza previste dalla legislazione della nazione di destinazione.
- 1.2.2 Gli interventi e le manutenzioni devono essere effettuate da operatori qualificati.
- 1.2.3 E' severamente vietato al cliente o a terzi (escluso personale della Società STI debitamente autorizzato) apportare modifiche

The explosion proof version the equipment is designed to operate in potentially explosive atmosphere classified as:

#### II 2(1)G Ex d [ia Ga] IIC T5/T6 Gb

Equipment group II surface industry, category 2 for use in zone 1 with explosive atmospheres caused by gases, vapours or mists. In conformity to types of protection standardized EN 60079-0 with flameproof enclosure EN 60079-1t The maximum surface temperature will not exceed 100C in an 80C ambient and is suitable where the hazardous gas has a Temperature Class T5.

#### 1.2 GENERAL SAFETY INSTRUCTIONS

- 1.2.1 Before any operation is made, operators shall follow instructions of this manual and adopt the safety precautions by the country where the product is installed.
- 1.2.2 Operation and maintenance shall be carried out only by skilled staff.
- 1.2.3 It is strictly forbidden to customers (except for STI duly authorized staff) to modify the characteristics of field barrier.
- 1.2.4 The apparatus has to be operated according to

STI S.r.I. – Via Dei Caravaggi 15, 24040 Levate (BG) – ITALY





di qualunque genere alla barriera.

- 1.2.4 L'apparecchio deve essere utilizzato secondo quanto riportato in questo manuale e relativa specifica tecnica.
- 1.2.5 Quando utilizzato in zone potenzialmente esplosive la custodia deve essere cablata mediante cavi, pressacavi certificati secondo la direttiva 94/9/CE, e le norme EN 60079-0 ed EN 60079-1 per temperature tra -40°C e 80°C.

ATTENZIONE: Le connessioni elettriche devono essere eseguite in accordo ai dati di targa, schema e direttiva 94/9/CE (anche per i raccordi, cavi e pressacavi utilizzati)

## 1.3 CONDIZIONI PER L'IMMAGAZZINAMENTO

- 1.3.1 Conservare la barriera modello ID in luoghi asciutti e puliti, avendo cura di prendere quelle precauzioni necessarie per impedirne il contatto con polveri, sporcizia ed umidità durante le fasi di immagazzinamento.
- 1.3.2 Non dovranno essere rimosse le protezioni delle varie connessioni nonché eventuali fermi meccanici.

# 1.4 MANUTENZIONE



- 1.4.1 Nessun cambiamento può essere fatto su apparecchi che funzionano in atmosfera potenzialmente esplosiva.
- 1.4.2 Togliere tensione prima di aprire la custodia.
- 1.4.3 Deve essere eseguita da personale istruito per operare in zone potenzialmente esplosive.
- 1.4.4 Equipaggiamenti ed utensili devono essere adatti all'utilizzo in zone potenzialmente esplosive.
- 1.4.5 Pulire solo con uno straccio umido.
- 1.4.6 Il grasso utilizzato deve essere secondo le prescrizioni del costruttore, e comunque avere un punto di infiammabilità > 140°C.

## 2. BARRIERA

## 2.1 GENERALITA'

La barriera modello ID è utilizzata sia sui posizionatori standard che sui posizionatori smart con comunicazione HART®. L'installazione della barriera a monte a dispositivi a sicurezza intrinseca consente il collegamento a circuiti di input e output che non sono a sicurezza intrinseca. In questo modo si conservano i vantaggi della sicurezza intrinseca come la messa in servizio quando il dispositivo è alimentato in una zona potenzialmente esplosiva. Il cavo di collegamento del circuito a non sicurezza intrinseca deve essere collegato alla custodia della barriera attraverso un tubo oppure un condotto certificato oppure un cavo armato. Un ingresso filettato 1/2" NPT consente la the appropriate data in the data sheet and in this manual.

1.2.5 When mounting in the hazardous area, the explosion proof housing must be provided with cables, cable entries and filler plugs which are at least certified according to directive 94/9/CE, EN 60079-0 ,EN 60079-1 and suitable for -40°C e 80°C..

CAUTION: The electrical connections must be done according to the diagram, label and 94/9/EC directive (also for used fitting, cable and cable gland)

# 1.3 STORAGE

- 1.3.1 Store the Field Barrier ID series in dry and clean places and take all necessary measures to avoid its contact with dust, dirt and humidity during storage.
- 1.3.2 Do not remove connections, protections and/or mechanical locks.

# 1.4 MAINTENANCE

- 1.4.1 No changes can be made to the apparatus , which are operated in hazardous area.
- 1.4.2 Disconnect supply circuit before enclosure opening.
- 1.4.3 Must be done by qualified person who is trained to operate into potentially explosive atmosphere.
- 1.4.4 Tools and equipment must be suitable for potentially explosive atmosphere where the actuator is installed.
- 1.4.5 Cleaning must be done with a humid cloth.
- 1.4.6 Greases must be used according to the manufacturer's instructions, however their flammability point must be > 140°C.

## 2. FIELD BARRIER

## 2.1 GENERAL FEATURES

The ID model field barrier is suitable for operating positioners, smart positioners with HART® communication. Upstream connection and direct attachment to intrinsically safe field devices enable the intrinsically safe circuits of these devices to be connected with the circuits of upstream input and output units that are not intrinsically safe. In this way, the advantages of intrinsic safety, such as commissioning and operation when connected to a voltage source, are still in effect within the hazardous area. The connecting cable of the non-intrinsically safe circuits introduced in the housing of the field barrier either via pipeline systems or via design certified cable or conduit entries or armored cable. An 1/2" NPT adapter allows for a direct

STI S.r.I. – Via Dei Caravaggi 15, 24040 Levate (BG) – ITALY





connessione diretta alla barriera.

# 2.2 CARATTERISTICHE TECNICHE

Per le caratteristiche tecniche della barriera montata direttamente sul posizionatore FT, vedere manuale d'istruzioni 4028. connection through the cable entry of the field devices.

## 2.2 TECHNICAL FEATURES

For technical information concerning field barrier mounted directly on the FT positioner, see FT instruction manual 4028.

Materials						
Housing, cover	Aluminum A356 T6					
Technical features						
Nominal voltage	24 V					
Ambient temperature	-40°C ÷ +80°C / 60°C					
Safety Parameter						
U _m	250 V					
U _o	27,45 V					
l _o	87 mA					
Po	0,597 W					
Co	86 nF					
Lo	4.2 mH					

#### 2.3 INSTALLAZIONE

Il dispositivo deve essere utilizzato montato sulla scatola del posizionatore STI modello FT.

#### ATTENZIONE:

- La connessione di ingresso è ½" NPT.
- I cavi in ingresso possono superare i 70°C.
- Non aprire in presenza di atmosfera esplosiva.
- 2.3.1 Collegare i cavi del segnale 4÷20 mA ai morsetti J2/1 (-) e J2/3 (+) e nel caso sia necessario i cavi del trasmettitore di posizione ai morsetti J1/3 (-) e J1/1 (+).

#### 2.3 INSTALLATION

The device has to be used mounted on the STI positioned model FT housing.

#### CAUTION:

- Entry cable connection is 1/2" NPT.
- Cable entry may exceed 70°C.
- Do not open when a flammable atmosphere may be present.
- 2.3.1 Connect the signal wires to the terminals J2/1 (-) e J2/3 (+) and if needed the analog feedback wires to the terminals J1/3 (-) e J1/1 (+).

J1.3	analog FB -		
J1.2	ground 🛨		
J1.1	analog FB +		
STI FIELD BARIER mod.ID			
J2.3	4-20mA +		
J2.2	ground 🛨		
12.1	4-20mA -		

2.3.2 La barriera deve essere connessa alla messa a terra affinché funzioni correttamente. Mediante il morsetto di terra pos. 10 della figura seguente.

The zener barrier must be connected to the earth path in order to work properly. By fixing the earth wire to the earth terminal pos. 10 of following picture.





I.TY	DESCRIPTION	DRAW ING N*	MATERIAL	DIMENSION	SURF. TREATMENT	NOTES
1	Exd BOX	FD27320	A256 T6 A5TH 826,3909	-	CHROMATING	
1	ELECTRIC BOARD	ZD26159		-	-	-
1	Exd PLUG	FD27321	A256 T6 ASTN 826-2909	-	CHROMATING	
1	SEALING RING OR 3262	-	SEE NOTE 1	Di.66.35 C.2.62	-	•
5	LOCK WASHER/ROSETTA ELASTICA	-	d.#L	Di5.1xDe9.2sp.1.2 UNI 1751		
1	SCREW TCEI	-	d.#4.70	M5x12 UNI 5931/ISO 4762		
4	SCREW TCEI	-	el.44.70	M5x25 UNI 5931/150 4762		
1	LABEL	FD31778	AIS1 3%			
1	RESIN (MFR ELANTRAS)		Elan-Inve IIC 62/W 363			
1	CLIP OF GROUNDING GA10		S.S./Nichel plated copper alloy			
1	FLAT WASHER	-	d.#L	Di4.3xDe9 sp.0.8 UNI 6592	-	
1	LOCK WASHER	-	*	Di4.1xDe7.6sp.0.9 UNI 1751	-	
1	SCREW TCEI	-	ci.44.70	M4x10 UNI 5931/ISO 4762		
2	RIVET	-	AISI 304	D.1.9x5 UNI 7346		
1	FLAT WASHER	-	*	Di3.2xDe7 sp.0.5 UNI 6592		
1	SCREW TCEI	-	ci.A4.70	M3x6 UNI 5931 UNI 5931/ISO 4762		
1	INTERNAL LABEL	FD30343	PRIMESTER	30X40		
)				2 15 16	4)	
	1 1 1 1 5 1 4 1 1 1 1 1 1 1 1 1 1 1 1 1	LEA BUX LABEL LABEL LABEL LABEL LABEL LOCK WASHER LANTRASI LUCY OF GROUNDING QAYO LOCK WASHER LOCK WASHER LOCK WASHER LOCK WASHER SCREW TCEI INTERNAL LABEL LABEL SCREW TCEI SCREW TCEI INTERNAL LABEL SCREW TCEI INTERNAL LABEL	1     LEG BUX     PU27320       1     ELECTRIC BOARD     ZD2659       1     ELECTRIC BOARD     ZD2659       1     SEALING RING OR 3262     -       5     LOCK WASHER/ROSETTA ELASTICA     -       1     SCREW TCEI     -       4     SCREW TCEI     -       1     RESIN UMER ELANTRASI     1       1     RESIN UMER ELANTRASI     -       1     LOCK WASHER     -       1     SCREW TCEI     -       2     RIVET     -       1     SCREW TCEI     -       1     SCREW TCEI     -       1     SCREW TCEI     -       1     SCREW TCEI     -       1     INTERNAL LABEL     F030343       1=MATERIAL : NBR;FKM;EPDM,SILICON	I     Los BUX     PU27320     Add to BUX       1     ELECTRIC BOARD     ZD2659     -       1     End PLUG     PD27321     Add to Bux       1     SEALING RING OR 3262     -     SZE WTE 1       5     LOCK W ASHER-ROSETTA ELASTICA     -     d.A.       1     SSERW TCEI     -     d.A.       1     SSERW TCEI     -     d.A.       1     LABEL     FD31778     Add to Bux       1     LOCK W ASHER     -     d.A.       1     FLAT W ASHER     -     d.A.	IDE BUX     FUZ7120     ADD     FUZ7120     FUZ7120	1     D22 BUX     P02/22/0     Add is at the Backer     -     -     CURONAITING       1     ELCTRIC BOARD     2020/25/9     -     -     -     -     -     -     -     -     -     -     -     -     -     -     -     -     -     -     -     -     -     -     -     -     -     -     -     -     -     -     -     -     -     -     -     -     -     -     -     -     -     -     -     -     -     -     -     -     -     -     -     -     -     -     -     -     -     -     -     -     -     -     -     -     -     -     -     -     -     -     -     -     -     -     -     -     -     -     -     -     -     -     -     -     -     -     -     -     -     -     -     -     -

Non rimuovere i 2 cavi giallo/verde (che sono interconnessi tra loro) ai pin J1/2 e J2/2.



# ATTENZIONE: I cavi di terra devono avere sezione minima di 4 mm²

2.3.3 Condizioni speciali d'utilizzo::



La connessione esterna di terra della barriera di tipo ID deve essere dotata di collegamento con cavo equivalente ad un cavo di rame di sezione 4 mm² con una resistenza inferiore a 1 ohm per alimentazione a centro indipendentemente dal tipo di spina e presa connessioni.

La custodia metallica è direttamente collegata a terra e quindi i circuiti elettrici non sono in grado di sopportare il test d'isolamento a terra a 500V, requisito della normativa EN60079-11. Questo deve essere preso in considerazione in ogni installazione. I cavi di uscita rosso, nero, marrone e giallo deve essere inseriti in una custodia con grado di protezione almeno IP20 (se montato a Do not remove the two yellow/green wires (that are connected to the enclosure) in pins J1/2 and J2/2.

# CAUTION: Minimun earth section cable is $4 \text{ mm}^2$

2.3.3 Special condition for safe use:

The field barrier type ID external earth terminal must be provided with a high integrity insulated earth connection equivalent to a 4  $mm^2$  copper conductor, which has a resistance of less than 1 ohm to the supply star point and which must not rely on any plug and socket connections.

The metallic enclosure is directly connected to earth and therefore the electrical circuits are not capable of withstanding the 500V insulation to earth or frame requirement of EN60079-11. This must be taken into account in any installation.

The output wires red, black, brown and yellow must be terminated within an

STI S.r.l. – Via Dei Caravaggi 15, 24040 Levate (BG) – ITALY





bordo di un FT posizionato questo è conforme). La divisione tra le due sezioni identiche deve essere mantenuta come due circuiti separati a sicurezza intrinseca a meno che la combinazione delle due sezioni sia stata considerata.

# 2.4 DESCRIZIONE PRODOTTO

La barriera previene il trasferimento di energia da una zona sicura ad una zona a rischio esplosione. I diodi Zener all'interno della barriera sono collegati in maniera inversa. La tensione di rottura non viene superata nelle normali operazioni. Se questa tensione viene superata per via di un guasto nella zona sicura, i diodi cominciano a condurre causando la fusione del fusibile. La barriera ha una polarità positiva e gli anodi dei diodi Zener sono collegati a massa. I diodi di ritorno impediscono alla corrente di entrare in zona pericolosa. Per i parametri dettagliati fare riferimento al certificato della barriera. Un esempio di applicazione può essere sul posizionatore smart FT series.

enclosure which provides a degree of protection at least IP20 (if mounted on board of a FT positioned this is compliant). The segregation between the two identical sections must be maintained as two separate intrinsically safe circuit unless the combination of the two sections has been considered.

#### 2.4 PRODUCT DESCRIPTION

The Field Barrier prevents the transfer of unacceptably high energy from the safe area into the hazardous area. The Zener diodes in the Field Barrier are connected in the reverse direction. The breakdown voltage of the diodes is not exceeded in normal operation. If this voltage is exceeded, due to a fault in the safe area, the diodes start to conduct, causing the fuse to blow. The Field Barrier has a positive polarity, i.e. the anodes of the Zener diodes are grounded. The diodes of diode return prevent a current into the hazardous area. For the detailed parameters refer to the Field Barrier certificate. Application examples can be found in the FT positioner.



Le informazioni riportate sul seguente manuale sono coperte da copyright. Tutti i diritti sono riservati. Nessuna parte di questo manuale e della relativa documentazione citata e/o allegata può essere riprodotta senza il preventivo consenso scritto della **STI s.r.l. STI s.r.l.** non si assume alcuna responsabilità per eventuali danni a persone, apparecchiature o dati conseguenti all'uso improprio del prodotto a cui il manuale si riferisce.

Le informazioni contenute in questo documento sono soggette a modifiche senza preavviso.

Information in this manual is protected by copyright. All rights are reserved. No part of this manual and relevant mentioned and/or enclosed documentation may be reproduced without written authorization by STI s.r.l.

STI s.r.l. is not responsible for possible damage to people, equipment or data which might arise from incorrect use of the product to which the manual is referred.

Information in this document may be modified at any time without notice.

STI S.r.I. – Via Dei Caravaggi 15, 24040 Levate (BG) – ITALY www.imi-critical.com