

HDI PUMP



SERVICE and MAINTENANCE MANUAL for INTERLUBE LUBRICATION SYSTEM

SAFETY

As with all equipment, all due care must be used when servicing the HDI lubrication system.

Throughout this manual there will be information provided which requires special attention. This information will be displayed under the headings of **WARNING**, **CAUTION**, or **NOTE**.

UK Headquarters:

Interlube Systems Ltd

St Modwen Road, Parkway Industrial Estate,

Plymouth, Devon, England PL6 8LH

Tel: +44 (0)1752 676000

Fax: +44 (0)1752 676001

e-mail: info@interlubesystems.com

Web Site: www.interlubesystems.com

USA Headquarters:

Interlube Systems Inc

4696 Wadsworth Road, Dayton, Ohio, 45414, USA

Tel: + 1 937 276 4507 Fax: + 1 937 276 4518

e-mail: nmackay@interlubeusa.com

Interlube Systems (Malaysia) Sdn.

30, Jalan Appollo U5/189, Bandar Pinggiran Subang Sesyen,

40150 Shah Alam, Selangor, Malaysia.

Tel: (603) 7845 5377 Fax: (603) 7845 5977

Email: acllube@streamyx.com

TABLE OF CONTENTS

1. INTRODUCTION	3
2. GENERAL DESCRIPTION	3
3. COMPONENT OPERATION	4
3.1. Pumping Units	4
3.1. Pump Operation	4/5
3.3. Relief Valves	5
4. WIRING	6,7,8
4.1. Wiring with Controls	6
4.2. Wiring without Controls	6
4.3. Alarm Functions	7
4.4. Remote Alarm	7
4.5. Low Level	8
4.6. Pump Connectors	8
5. PROGRAMMING	9
6. PUMP DIMENSIONS	10
7. TECHNICAL DATA	10
8. PUMP FILLING	11
9. TROUBLESHOOTING	12
10. SERVICE PROCEDURES	13
10.1. Lid Replacement all Models	13
10.2. Reservoir Replacement all Models	13
10.3. Paddle Blade Replacement all Models	13
10.4. PCB Replacement all Models	13
10.5. Pump Element Replacement	13
11. PUMP EXPLODED VIEW (Moulded)	14
11.1. Parts List (Moulded)	15
12. PUMP EXPLODED VIEW	
(Standard 3,6,9 & 15Kg)	16
12.1. Parts List	17
13.HDI PROGRESSIVE SYSTEM EXAMPLES	18
13.1. Divider Valves	19
13.2. Divider Valve Accessories	19



INTERLUBE
A **TIMKEN** Brand

1. INTRODUCTION

This manual gives instructions for operating, maintaining, and servicing the Interlube HDI Pump & Distribution systems. Because of the importance of providing the correct lubricant amount to the moving parts of the equipment, read this manual to become familiar with your HDI pump and system.

Review and follow the procedures given before attempting maintenance or service. Illustrations are provided to aid in disassembly and reassembly.


If there are any questions not answered by this manual, contact Interlube Systems.

2. GENERAL DESCRIPTION

A typical HDI lubrication system includes the following components (see fig 1):

- Pump with integral controls and reservoir
- Pumping Units
- Divider Valves
- Tubing to the lubrication points
- Fittings at the lubrication points

Fig 1



Pumps are available with 3, 6, 9 and 15 litre reservoirs. Fig 2 shows 6 litre version. There is a specific version for the USA with push/pull style pumping units


Fig 2



The HDI pumps are electrically operated (12/24v DC) piston pumps able to accept up to 3 pumping units.

These pumping units (either fixed or adjustable output, fixed pumping elements are fitted as standard) feed lubricant to the primary divider valve which in turn feeds (where applicable) further secondary divider valves. The bearings on the machine/plant are connected to the secondary divider valves by hose or tube, bearings can also be fed direct from the pump.

Ordering Method



All pumps have dual fill options, quick fill and grease nipple.

3. COMPONENT OPERATION

3.1 HDI Pump Outputs

All HDI Pumps are supplied with one pump element as standard. Up to three pump elements can be fitted into one HDI pump

Fig 3





Fig 4



Operation

The electric motor drives an eccentric cam during the pumps operating time.

Pumping Unit Spares


Pump Elements Standard Pump

Spring Return

Element

PU 300-350

PU 400-350




Pump Elements - USA Pumps

Push Pull Element

PU 300-350-A

PU 400-350-A



The pump element piston sucks the grease from the reservoir and then dispenses an accurate precise amount of lubricant to the connected metering device.

Pump Output

Standard HDI pump operates at 19/23revs/min					
Part No	Max output/min pressure (BAR/PSI)	Output/min (cc)	Volume (cu in)	Pump Element Outlet Size	Relief Valve Setting 350 BAR 5145 PSI
PU 300-350	400 (5880)	3.2	(0.20)	6mm O.D	
PU 300-350-A	400 (5880)	3.2-1.4	(0.20-0.08)	6mm O.D	
PU 400-350	400 (5880)	3.2	(0.20)	6mm O,D	
PU 400-350-A	400 (5880)	3.2- 1.4	(0.20-0.08)	6mm O.D	
Operation conditions +40C° to - 30C°					


The grease output figures were based on NLGI 2 Grease at ambient conditions, the output volume may vary depending on lubricant specification and temperature

(USA Version) Fig 4



USA Version

3.3 Relief Valve Settings



PU 300-350

Pumping unit replacement

Using a 27mm AF spanner loosen pumping unit body (1) and unscrew until the thread is clear of the pump body (2). Tilt the pumping unit body (1) to lift the piston (3) clear of the cam ring (4) and then remove. Ensure the piston does not remain in the pump body.

To replace unit pull out the piston (3) from the body (1) of the new pumping unit to the end of it's stroke. Ensure the copper washer (5) is in position and insert the pumping unit body (1) into the pump body (2). This should be done with the pumping unit body (1) tilted upwards. When the piston (3) touches the cam ring (6) the pumping unit body (1) should be moved to a horizontal position. This should now seat the piston (3) into the cam ring (4). Tighten the pumping unit body (1) using the 27mm AF spanner.

The relief valve is a fixture of the pump elements, both spring return and push pull type.

The relief valves are factory set to 350 Bar to protect the pump from damage should a blockage occur in the system.

The relief valve can be adjusted manually to vent at lower pressure. this can be adjusted on-site using a standard spanner.

4. WIRING



Pump supplied with power/push button plug with 10m of 7 core cable

Note:
Terminal 5 is connected to the ignition of the vehicle or mobile plant. If terminal 1 is connected to the Battery + then the pump will operate without the ignition on.


Push Button




12V HDI - 36070-5
24V HDI - 36070-6

4.1 WIRING DETAILS


Wiring Diagram for HDI Pump (With Controls)




4.2 Wiring Diagram for HDI (Without Controls)



Push Button Wiring diagram



4.3. ALARM FUNCTIONS



1. Pump elements (see page 4 & 5)
2. Low level connection (not supplied as standard on base models)
3. Power cable (30ft) and 7 pin connector supplied as standard with all models (see details on page 8 and wiring diagram on page 6)
4. End of line or primary flow proximity sensor alarm connection (not supplied as standard on base models)


4.4. Remote Alarm Functions

The HDI Pump can be supplied with or without an internal controller (PCB).


The pump without control facility is fitted with an internal reed switch; this can be used to monitor the pumps internal cam rotation.

The pump with control facility has an in-built alarm function, which can be connected to an external alarm relay as an option. In general the HDI is connected to progressive divider valves as illustrated. The progressive divider valves are designed to feed a positive set amount of grease to each connected point in turn, without missing a point out. The primary divider valve is fitted with a proximity flow indicator switch, which will signal positive flow back to the HDI PCB. Should the pump operate and the PCB not receive a flow signal the pump would alarm. This alarm signal could be connected to an external remote audio or visual alarm on the machine or alternatively connected to the machines PLC. The PLC could be programmed to stop the machine from operating should the lubrication system fail to operate correctly.

Wiring for Alarm Switch



Flow Alarm





4.5. Low Level Sensors

These highly reliable capacitive sensors are fully sealed and encapsulated to operate in the most arduous conditions with NLGI 2 grease.

Fig 6 shows pictorial view and Fig 7 the version for a 3 litre pump. (Extensions are used for larger capacity reservoirs).




Low Level Kit

Part No	Description
HDI/SP9/3P	3 Ltr Moulded Kit
HDI/SP9/6	6 KG Standard Kit
HDI/SP9/9	9 KG Standard Kit
HDI/SP9/15	15 KG Standard Kit

Kit comprises of pump connector, low level and plug


4.6 Proximity sensor Conversion kit

Proximity alarm plug A plus pump plug with internal loom to PCB



Part No	Description
HDI/SP9	Low level External Alarm Facility (B+C)
HDI/SP4	Power/push button plug with 10m cable (A)
HDI/SP8	Proximity alarm plug (B+C)

Control Card 12/24V (HDI/SP15)



HDI/SP15

5. HDI PROGRAMME SETTING

Programming the HDI Controller

Programming is carried out using the select and enter buttons as shown in the picture.



The setting details are shown on the digital display at each stage.

Pump Run Time Options

With Time "ON" Mode (t) from 1 min to 99 mins.

Pump Delay Time

Variable from 1 min to 99 hours 59 mins.

Time "ON"/Time "OFF" mode

Press select and enter buttons together for 5 seconds to enter programme mode.

- 1) Display will show "S1" (Run time) Press enter button then select button to set run time in minutes from "01" to "99" (for example 05 gives a run time of 5 mins). Will provide run time from 1 min to 99 mins Press enter to accept
- 2) Display will show "S2" (Delay time) Press enter button, for example to set a delay time of 1 hour 20 mins, press select button to display "01" then enter to accept, then select button to display "20". Press enter to accept.
- 3) Display will show "S3" (End of line switch setting) Press enter button, display shows "EL" press select to choose between a) When "EL" is flashing end of line sensing is "OFF" or b) When "EL" is continuously lit end of line sensing is "ON" Press enter to accept. If end of line switch is "ON" next display will show "01" Select between "01" to "10" for the number of cycles of the lubrication system Press enter to accept.
- 4) Display will show "S4" (low level option) Press enter button, display shows "LL" press select to choose between a) When "LL" is flashing low level sensing is "OFF" or b) When "LL" is continuously lit low level sensing is "ON" Press enter to accept
- 5) Display shows "PC" (Programming complete) After 10 seconds return to run mode.

- 3) After making the change press enter to accept
- 4) Press select button until display shows 'PC' "Programme complete"

PC


Notes: -

To view current programmed settings

- a) press the "select" button for 10 seconds this will activate the programme view mode displaying the setting of each step for 3 seconds. After showing "PC" for 3 seconds the pump will return to run mode.

Low level warning

- b) If a low level alarm is triggered the pump will continue operating and any alarm warnings will continue until the reservoir is re-filled.



CHANGING PROGRAMME

Press select and enter buttons together for 5 Secs to enter programming mode

- 1) Display will show
- 2) Press select button to choose the setting you want to change S2,S3 etc then press enter

S1

To prime the system



- c) set the delay time to "00" hours and "00" minutes. Please note this time setting is not intended as an operating mode.

Note:-

The manual override button on the pump can be operated at any time without the need for the ignition circuit to be on, a positive safety benefit. Operating the manual override will start one cycle of the pre-set run time.

6. PUMP DIMENSIONS

Diagram shows a standard HDI pump




Pump Dimensions


Reservoir Size	A		B		C	
3 Ltr Moulded	340mm	13 1/2"	260mm	10"	270mm	10 1/2"
3 Ltr Standard	300mm	12"	260mm	10"	270mm	10 1/2"
6 Ltr Standard	400mm	16"	260mm	10"	270mm	10 1/2"
9 Ltr Standard	490mm	19 1/2"	260mm	10"	270mm	10 1/2"
15 Ltr Standard	700mm	27 1/2"	260mm	10"	270mm	10 1/2"

Mounting Positions of the HDI Pump

Standard HDI 3, 6, 9, 15 Ltr



HDI 3Ltr (Moulded Reservoir Model)



7. TECHNICAL DATA

7.1. Pump with integral controls

- Available with 3, 6, 9 or 15 litre reservoirs
- Supplied in either 12 or 24v DC. Output speed 19/23 RPM.

12v DC max running current 5A

24v DC max running current 5A

Start up current 10A

- PCB dual voltage & EMC compliant
- Built in memory, recommencing either run or delay cycle on power up.
- Transient protection to ISO 7637 Road Vehicles.
- Dual LED digital display used for programming & run information
- IP65 protected
- Uses lubricants from SAE 80 oil up to & including NLGI 2 Grease.
- Operating temperature +40°C to - 30°C (using low temperature grease)
- 2 fill options - quick fill or grease nipple
- Can be used with divider valves
- Maximum of 3 pumping units per pump.
- Low level sensor an option

8. PUMP FILLING
HDI FILLING METHODS
HDI Dual Fill



All HDI models are supplied with dual fill

(A) standard grease nipple use air operated grease pump to fill the reservoir.


(B) quick release coupling use a hand operated volume bucket pump.

(C) Or alternatively fit the pump with a quick fill adapter and use a quick fill gun to fill the reservoirs.

Quick Fill Gun

Hand operated quick fill gun

Part No.	Description
HDI - 57549-1	Quick fill gun
HDI - 36763-1	Straight adapter for the pump
HDI - 36763-2	90°adapter



Bucket Pump

Hand operated bulk fill pump complete with:
1.5m hose, female quick release coupling to fit directly onto the Interlube quick connect fitting fitted to the pump. Ideal for use with NLGI 1 or 2 greases.



Part No	Description
IL-108501	European Pump (12.5-18 KG), cover 265mm to 310mm
IL-108502	USA Pump (35lb) cover 285mm to 330mm
IL-417001	Grease follower plate 260mm to 298mm
IL-417003	Grease follower plate 300mm to 340mm

9. TROUBLESHOOTING

PROBLEM	POSSIBLE CAUSE	REMEDY
A. All lubrication points appear dry.	<ol style="list-style-type: none"> 1. Empty reservoir 2. Inoperative pump 3. Time between lube cycle is too long. 4. Reservoir has been filled with an unsuitable lubricant. 5. Inoperative Pumping Unit 6. Pumping unit not “sitting” in cam ring (USA Version) 7. Main Pressure Line damaged/broken. 8. Reservoir vent blocked from over filling. 	<ol style="list-style-type: none"> 1. Refill the reservoir, using the correct lubricant. 2. Refer to PROBLEM “E”. 3. Adjust pump CYCLE TIME setting. 4. Remove the lubricant and replace with correct grade of lubricant. 5. Replace Pumping Unit 6. Remove & refit correctly. 7. Find breakage & replace with new hose. 8. Clear vent and only fill to max level.
B. One or more lubrication point appears dry while others receive sufficient lubrication.	<ol style="list-style-type: none"> 1. Broken or severed secondary grease lines. 2. Incorrect specification of divider valves. 	<ol style="list-style-type: none"> 1. Determine cause, and if necessary, re-route. 3. Re-configure divider valve specification to higher output.
C. All lubrication points are over-lubricated.	<ol style="list-style-type: none"> 1. Incorrect setting of “on-time” or “Delay Time”. 	<ol style="list-style-type: none"> 1. Reduce “On Time” or increase “Delay Time”, or both.
D. One or more lubrication points are over-lubricated.	<ol style="list-style-type: none"> 1. Incorrect specification of divider valves. 	<ol style="list-style-type: none"> 1. Re-configure divider valve specification to lower output.
E. Inoperative pump.	<ol style="list-style-type: none"> 1. No input power. 2. Fuse is blown. 3. Loose wire connection inside the pump. 4. Defective PCB. 5. Defective Motor. 	<ol style="list-style-type: none"> 1. Check for power to the pump. and controller. 2. Check in-line fuse. Replace if necessary. 3. Check all wires and connections in the pump. 4. Replace PCB. 5. Replace Motor.
F. Inoperative Pumping Unit.	<ol style="list-style-type: none"> 1. Pumping Unit not “sitting” in cam ring. (USA Version) 2. Inoperative Pump 3. No Grease flow 	<ol style="list-style-type: none"> 1. See Section 7.5 2. Refer to PROBLEM “E”. 3. Replace pumping unit
G. Grease flowing from Pumping Unit Relief Valve.	<ol style="list-style-type: none"> 1. One or more lubrication points are blocked, and will not accept grease. 2. Fault in Divider valve assembly. 	<ol style="list-style-type: none"> 1. Remove pipe from fitting and flush bearing through with grease gun. 2. Replace the faulty Divider valve

10. SERVICE PROCEDURES

The rugged design and simple construction of the HDI lubrication system assures the operator of a long and trouble free service. If service is necessary use the following procedures to ensure correct replacement of parts.

10.1. Lid Replacement - All models (does not apply to moulded reservoir pumps)

- 10.1.1. Remove 3 nuts (5) holding lid to tie rods (6)
- 10.1.2. Remove lid (7) and 'O' ring (8)
- 10.1.3. Replace with new lid (7) and 'O' ring (8)
position on reservoir (3) and tie rods (6) tighten nuts (5)

10.2. Reservoir replacement - (Clear models)

- 10.2.1. Remove lid as in 7.1
- 10.2.2. Withdraw reservoir (3) and lower 'O' ring (9)
- 10.2.3. Clean around area where new reservoir will be fitted. Position 'O' Ring (9) and replace reservoir between tie rods
- 10.2.4. Replace lid as in 7.1.3.

(3 Litre moulded version)

- 10.2.5. Remove the 3 screws holding the reservoir in position on the pump body
- 10.2.6. Remove reservoir and 'O' Ring
- 10.2.7. Position new 'O' ring on new reservoir
- 10.2.8. Re-assemble reservoir to pump body ensuring the breather tube is closest to the mounting bracket
- 10.2.9. Insert & tighten screws to torque 3Nm, be careful not to overtighten screws.

10.3. Paddle Assy Replacement - All models

- 10.3.1. Remove lid and reservoir as in 7.1 and 7.2
- 10.3.2. Remove nut (10) and washer (11) then remove paddle (16)
- 10.3.3. Replace new paddle (12) then washer (11) and nut (10). Tighten to 6.5Nm
- 10.3.4. Replace Reservoir and lid as in 7.1.3 and 7.2.3


10.4. Replace PCB - All models.

- 10.4.1. Remove 8 screws (13) securing the bottom cover (4) and 'O' ring (15)
- 10.4.2. Slide out PCB (18) from housing (19) and remove all the electric connectors
- 10.4.3. Replace all connectors on new PCB (18) and slide back into housing (19)
- 10.4.4. Replace cover (14) and 'O' ring (15) securing with 8 screws (13). Tighten to 0.6Nm

10.5 Pumping unit replacement spring return version (Fig 9)

- 10.5.1. Using a 27mm AF spanner loosen pumping unit body. Remove spring loaded pumping unit. Ensure there is no loose dirt around the pumping unit aperture then screw in the new pumping unit tightening with a 27mm AF spanner.


11 Pump - Exploded View 3Ltr Moulded



11.1 Parts List

Item	Part No	Description	QTY	Notes
1	HDI SP7/3P	3 LT Reservoir	1	O Ring (SP10/P) and Screws Incl
2	HDI SP13/P	Restrictor Plate	1	
3	HDI SP4 HDI SP4/A	Cam Assy & Seals	1	Cam for spring return pump element Cam for push-pull pump element
4	HDI SP28	Blanking Plug	2	
5	HDI SP8	Proximity Alarm Plug Conversion Kit with Internal Loom	1	Gaskets, Connector Base, Screws & Din Connector Incl
6	HDI 2P12/12-24	7 Way Connector Assy & PCB Internal Loom 12/24V	1	Gasket, 7 Way Connector, Screws and 7 Pin Hirschmann CNCTR Incl.
7	HDI SP9/3P	Low Level Conversion Kit with Internal Loom + Low Level sensor	1	Gaskets, Connector Base, Screws & Din Connector Incl.
8	HDI SP24	Bottom Cover Assy	1	Screws, Seal & Vent Incl.
9	HDI SP25	Bottom Cover Fixing Screws (BULK)		
10	HDI SP1 HDI SP2	Spare HDI 12V Motor Spare HDI 24V Motor		
11	HDI SP26	Bottom Cover O Ring (BULK)	1	
12	HDI SP14	Motor to PCB Loom	1	
13	HDI SP15	12-24V Standard PCB CNTRL Board	1	
14	HDI SP18 HDI SP19	Housing W/O Controls Housing with Controls	1	Gasket Included
15	HDI SP27	Grease Nipple with Adaptor	1	
16	HDI SP3	Quick Fill Adaptor (MALE)	1	
17	PU300/350 PU300/350/A	Pump Element with PRV (UNIT) 350BAR	1	Spring Return Pump Element Push-Pull Pump Element
18	HDI SP11/3P	Paddle Blade Assy	1	Nut Included
19	HDI SP10P	Reservoir Seal 3LTR Moulded	1	
20	HDI SP5/3P	Spare Low Level Sensor 3LTR	1	Lead, Nut & Washers Incl.
21	HDI SP29	Reed Switch	1	Supplied with no Control Version HDI


12. Pump - Exploded View 3, 6, 9 & 15 Litre Standard



12.1 Parts List

Item	Part No	Description	QTY	Notes
1	HDI SP7/3 HDI SP7/6 HDI SP7/9 HDI SP7/15	3 LT Reservoir 6 LT Reservoir 9 LT Reservoir 15 LT Reservoir	1 1 1 1	Tie Rods, Nuts and O Ring Incl.
2	HDI SP6	Cast Lid Assy with Breather		
3	HDI SP13/C	Internal Plate		
4	HDI SP4 HDI SP4/A	Cam Assy & Seals	1	Seals Incl.
5	PU300/350 PU300/350A	Pump Element with PRV (UNIT) 350 Bar	1	Spring Return Pump Element Push-Pull Pump Element
6	HDI SP8	Proximity Alarm Plug Conversion Kit with Internal Loom	1	Gaskets, Connector Base, Screws & Din Connector Incl
7	HDI SP12/12-24	7 Way Connector Assy & PCB Internal Loom 12/24V	1	Gasket, 7 Way Connector, Screws and 7 Pin Hirschmann CNCTR Incl.
8	HDI SP9/3 HDI SP9/6 HDI SP9/9 HDI SP9/15	Low Level Conversion Kit with Internal Loom + Low Level sensor	1	Gaskets, Connector Base, Screws & Din Connector Incl.
9	HDI SP24	Bottom Cover Assy	1	Screws, Seal & Vent Incl.
10	HDI SP25	Bottom Cover Fixing Screws (BULK)	1	
11	HDI SP1 HDI SP2	Spare HDI 12V Motor Spare HDI 24V Motor	1	
12	HDI SP26	Bottom Cover O Ring (BULK)	1	
13	HDI SP14	Motor to PCB Loom	1	
14	HDI SP15	12-24V Standard PCB CNTRL Board	1	
15	HDI SP18 HDI SP19	Housing W/O Controls Housing with Controls	1	Gasket Included
16	HDI SP27	Grease Nipple with Adaptor	1	
17	HDI SP3	Quick Fill Adaptor (MALE)	1	
18	HDI SP28	Blanking Plug	2	
19	HDI SP10/C	Standard Reservoir Seal	1	
20	HDI SP11/3 HDI SP11/6 HDI SP11/9 HDI SP11/15	Paddle Blade Assy for 3Ltr Reservoir Paddle Blade Assy for 6Ltr Reservoir Paddle Blade Assy for 9Ltr Reservoir Paddle Blade Assy for 15Ltr Reservoir	1 1 1 1	Nut Included
21	HDI SP5/3 HDI SP5/6 HDI SP5/9 HDI SP5/15	Spare Low Level Sensor 3LTR Spare Low Level Sensor 6LTR Spare Low Level Sensor 9LTR Spare Low Level Sensor 15LTR	1 1 1 1	Lead, Nut & Washers Incl.
22	HDI SP29	Reed Switch	1	Supplied with no Control Version HDI

13. HDI PROGRESSIVE SYSTEM EXAMPLES USING INTERLUBE SPL VALVES.




Specification and outlet combinations for the lubricant divider valves

Since the divider valves are positive progressive piston displacement devices, it means that whatever quantity of lubricant is continuously supplied to the inlet port, it is positively divided in relation to the outlet port combinations and equals the sum total of the output quantities.

Delivery sequence


The commencement of the delivery sequence depends on the position of the delivery pistons. In each case the lubricant divider valves operate until all the lubricant which has been supplied, is completely delivered. If the lubricant supply is interrupted by a pause in the lubrication, then, after supply is resumed, the delivery sequence will be continued where it was stopped.



Outlet combinations


When an outlet is closed with one of the closure plugs, the lubricant is automatically redirected internally to the next adjacent outlet in descending numerical order

Note: Outlets 1 and 2 must never be closed.



13.1 DIVIDER VALVES

Standard Progressive Divider Valves



Part No	Number of outlets	Monitoring	Max flow per min
SPL-06	6		200 cc
SPL-06K	6	Indicator Pin	200 cc
SPL-08	8		600 cc
SPL-08K	8	Indicator Pin	600 cc
SPL-10	10		700 cc
SPL-10K	10	Indicator Pin	700 cc
SPL-12	12		800 cc
SPL-12K	12	Indicator Pin	800 cc
SPL-14	14		900 cc
SPL-14K	14	Indicator Pin	900 cc

13.2 DIVIDER VALVE ACCESSORIES


Proximity Switch



Proximity Adapters



Check Valve Outlet Fittings



SPL-30364-4 M10x1 Check Valve
SPL-12374-9 6mm Nut
SPL-12295-2 6mm Olive

Closure Plug



Divider Valves

- Monobloc design with number of outlets from 6 to 14
- Each outlet delivers 0.20ccs/cycle
- Crossporting and single outlets possible
- Available with cyclic indicator pins
- Max operating pressure 350bar
- Operating temperature -30°C to 100°C
- Outlets Tapped M10 x 1
- Inlet Tapped 1/8 BSP
- Proximity sensor an option

IMPORTANT

AII SPL DIVIDER VALVE OUTLETS MUST BE FITTED WITH SPL CHECK VALVES OR BLANKED OFF WITH SPL CLOSURE PLUGS. NEVER BLANK PORTS 1 & 2 ON A SPL VALVE

Plymouth Factory UK



For all Accessories refer to our Catalogue
request from Interlube Systems Ltd or look on
our website: www.interlubesystems.com



Interlube Systems Ltd

St Modwen Road, Parkway Industrial Estate,
Plymouth, Devon, England PL6 8LH

Tel: +44 (0)1752 676000 Fax: +44 (0)1752 676001

e-mail: info@interlubesystems.com

Web Site: www.interlubesystems.com

USA Headquarters:

Interlube Systems Inc

4696 Wadsworth Road, Dayton, Ohio, 45414, USA

Tel: +1 (937) 276 4507 Fax: +1 (937) 276 4518

e-mail: nmackay@interlubeusa.com

Interlube Systems (Malaysia) Sdn.

30, Jalan Appollo U5/189, Bandar Pinggiran Subang Sesyen,
40150 Shah Alam, Selangor, Malaysia.

Tel: (603) 7845 5377 Fax: (603) 7845 5977

Email: acllube@streamyx.com