


Agilent 43521A Downconverter Unit

Service Manual

First Edition

SERIAL NUMBERS

This manual applies directly to instruments that have the serial number JP1KG 143/146, and JP1KG00150 or above. For additional important information about serial numbers, see Appendix A.



Agilent Technologies

Part No. 43521-90100

February 2000

Printed in Japan

Notices

The information contained in this document is subject to change without notice.

This document contains proprietary information that is protected by copyright. All rights are reserved. No part of this document may be photocopied, reproduced, or translated into another language without the prior written consent of Agilent Technologies.

Agilent Technologies Japan, Ltd.

Component Test PGU-Kobe

1-3-2, Murotani, Nishi-Ku, Kobe-shi, Hyogo, 651-2241 Japan

Copyright © Agilent Technologies Japan, Ltd. 2000

Manual Printing History

The manual's printing date and part number indicate its current edition. The printing date changes when a new edition is printed. (Minor corrections and updates incorporated in reprints do not necessitate a new printing date.) The manual part number changes when extensive technical changes are incorporated.

Feb. 2000 First Edition

Safety Summary

The following general safety precautions must be observed during all phases of operation, service, and repair of this instrument. Failure to comply with these precautions or with specific WARNINGS elsewhere in this manual may impair the protection provided by the equipment. Such noncompliance would also violate safety standards of design, manufacture, and intended use of the instrument.

The Agilent Technologies assumes no liability for the customer's failure to comply with these requirements.

NOTE

The Agilent 43521A complies with INSTALLATION CATEGORY II and POLLUTION DEGREE 2 in IEC61010-1. The Agilent 43521A is an INDOOR USE product.

NOTE

LEDs in the Agilent 43521A are Class 1 in accordance with IEC60825-1, CLASS 1 LED PRODUCT.

- Ground the Instrument

To avoid electric shock, the instrument chassis and cabinet must be grounded with the supplied power cable's grounding prong.

- **DO NOT Operate in an Explosive Atmosphere**
Do not operate the instrument in the presence of inflammable gasses or fumes. Operation of any electrical instrument in such an environment clearly constitutes a safety hazard.
- **Keep Away from Live Circuits**
Operators must not remove instrument covers. Component replacement and internal adjustments must be made by qualified maintenance personnel. Do not replace components with the power cable connected. Under certain conditions, dangerous voltage levels may exist even with the power cable removed. To avoid injuries, always disconnect the power and discharge circuits before touching them.
- **DO NOT Service or Adjust Alone**
Do not attempt internal service or adjustment unless another person, capable of rendering first aid and resuscitation, is present.
- **DO NOT Substitute Parts or Modify the Instrument**
To avoid the danger of introducing additional hazards, do not install substitute parts or perform unauthorized modifications to the instrument. Return the instrument to an Agilent Technologies Sales and Service Office for service and repair to ensure that safety features are maintained in operational condition.
- **Dangerous Procedure Warnings**
Warnings, such as the example below, precede potentially dangerous procedures throughout this manual. Instructions contained in the warnings must be followed.

WARNING

Dangerous voltage levels, capable of causing death, are present in this instrument. Use extreme caution when handling, testing, or adjusting this instrument.

Safety Symbols

General definitions of safety symbols used on the instrument or in manuals are listed below.

-  Instruction Manual symbol: the product is marked with this symbol when it is necessary for the user to refer to the instrument manual.
-  Alternating current.
-  Direct current.
-  On (Supply).
-  Off (Supply).
-  In-position of push-button switch.
-  Out-position of push-button switch.
-  Frame (or chassis) terminal. A connection to the frame (chassis) of the equipment, which normally include all exposed metal structure.

WARNING	This warning sign denotes a hazard. It calls attention to a procedure, practice, or condition that, if not correctly performed or adhered to, could result in injury or death to personnel.
CAUTION	This Caution sign denotes a hazard. It calls attention to a procedure, practice, or condition that, if not correctly performed or adhered to, could result in damage to or destruction of part or all of the product.
NOTE	This Note sign denotes important information. It calls attention to a procedure, practice, or condition that is essential for the user to understand.

Certification

Agilent Technologies certifies that this product met its published specifications at the time of shipment from the factory. Agilent Technologies further certifies that its calibration measurements are traceable to the United States National Institute of Standards and Technology, to the extent allowed by the Institution's calibration facility or by the calibration facilities of other International Standards Organization members.

Warranty

This Agilent Technologies instrument product is warranted against defects in material and workmanship for a period corresponding to the individual warranty periods of its component products. Instruments are warranted for a period of one year. Fixtures and adapters are warranted for a period of 90 days. During the warranty period, Agilent Technologies will, at its option, either repair or replace products that prove to be defective.

For warranty service or repair, this product must be returned to a service facility designated by Agilent Technologies. Buyer shall prepay shipping charges to Agilent Technologies and Agilent Technologies shall pay shipping charges to return the product to Buyer. However, Buyer shall pay all shipping charges, duties, and taxes for products returned to Agilent Technologies from another country.

Agilent Technologies warrants that its software and firmware designated by Agilent Technologies for use with an instrument will execute its programming instruction when properly installed on that instrument. Agilent Technologies does not warrant that the operation of the instrument, or software, or firmware will be uninterrupted or error free.

Limitation of Warranty

The foregoing warranty shall not apply to defects resulting from improper or inadequate maintenance by Buyer, Buyer-supplied software or interfacing, unauthorized modification or misuse, operation outside the environmental specifications for the product, or improper site preparation or maintenance.

IMPORTANT

No other warranty is expressed or implied. Agilent Technologies specifically disclaims the implied warranties of merchantability and fitness for a particular purpose.

Exclusive Remedies

The remedies provided herein are Buyer's sole and exclusive remedies. Agilent Technologies shall not be liable for any direct, indirect, special, incidental, or consequential damages, whether based on contract, tort, or any other legal theory.

Assistance

Product maintenance agreements and other customer assistance agreements are available for Agilent Technologies products.

For any assistance, contact your nearest Agilent Technologies Sales and Service Office. Addresses are provided at the back of this manual.

Typeface Conventions

Bold	Boldface type is used when a term is defined. For example: icons are symbols.
<i>Italic</i>	Italic type is used for emphasis and for titles of manuals and other publications.
[Hardkey]	Indicates a hardkey labeled "Hardkey."
Softkey	Indicates a softkey labeled "Softkey."
[Hardkey] - Softkey1 - Softkey2	Indicates keystrokes [Hardkey] - Softkey1 - Softkey2 .

1. General Information

Organization of Service Manual	12
Instruments Covered by This Manual	13
Require Equipment	14

2. Performance Test

Performance Test	18
Introduction	18
RF Power Measurement Accuracy Test	19
Input VSWR Test	23
Function Test	26
Introduction	26
Warm Up Time	26
Ambient Condition	26
600 MHz SAW OSC Phase Noise Test	27
System Phase Noise Test	29
Calculation Sheet	32
Performance Test	32
Function Test	34
Performance Test Record	35
RF Power Measurement Accuracy Test	35
Input VSWR Test	36
Function Test Record	36
600 MHz SAW OSC Phase Noise Test	36
System Phase Noise Test	36

3. Adjustment

Safety Considerations	38
Required Controller	38
Warm-up for Adjustment	38
Required Equipment	38
Order of Adjustment	39
Preparation for using the Adjustment Program	40
Installing a GPIB Card (82340B, 82341C/D or 82350A)	40
Installing HP VEE for Personal Computer	40
Installing Adjustment Program into Your PC (preliminary)	40
Equipment Setup	40
Running the Adjustment Program	42
600 MHz SAW Oscillator Frequency Adjustment	43
Required Equipment	43
Manual Procedure	43
Writing Default Correction Constant	45
Required Equipment	45
Procedure	45
RF Power Linearity Correction Constants	46
Required Equipment	46
Procedure	47
RF Power Frequency Response Correction Constants	48

Contents

Required Equipment	48
Procedure	49
4. Troubleshooting	
TROUBLESHOOTING SUMMARY	52
Check Procedure	54
Check LED (Front)	54
Check Fan	54
Check 600 MHz Output	54
Check Power Measurement Function	55
Check Heterodyne Path	55
Check Local Doubler Path	57
Power Supply Troubleshooting	59
Check the Line Voltage, and Fuse	59
Check the Power Supply Unit Output	59
Check the Power Supply on the A1 board	60
600 MHz OSC Troubleshooting	62
Check the 600 MHz Output on the A1 board	62
Power Measurement Function Troubleshooting	64
Heterodyne Path Troubleshooting	66
Local Doubler Path Troubleshooting	69
Performance/Function Tests Failure Troubleshooting	71
Perform Adjustments and Correction Constants	71
5. Theory of Operation	
OVERALL OPERATION	74
43521A BLOCK DIAGRAM	75
Power Supply Section	77
Sequencer & I/O (Digital Control) Section	77
Power Measurement Section	77
Heterodyne Section	78
Local Drive Section	78
600 MHz OSC Section	78
6. Parts Replacement	
Replaceable Part List	80
Ordering Information	80
.	80
Parts List	81
Replacement Procedure	105
Top Cover Removal	105
Bottom Cover Removal	105
Side Cover Removal	105
Front Panel Removal	106
Rear Panel Removal	106
Step Attenuator Replacement	107
U-WAVE AMP 18 GHz Replacement	107
U-WAVE MXR 26.5 GHz Replacement	108

U-WAVE AMP 20 GHz Replacement	108
U-WAVE FREQ DBLR Replacement	109
U-WAVE AMP 700 MHz Replacement	109
7. Post Repair Procedures	
POST REPAIR PROCEDURES	112
A. Manual Changes	
Manual Changes	116
Change 1	117
Page 57, Check Heterodyne Path	117
Page 57, Check Local Doubler Path	117
Page 64, Figure 4-7 Power Measurement Section Simplified Block Diagram	118
Page 66, Figure 4-9 Heterodyne Path Simplified Block Diagram	119
Page 68, Heterodyne Path Troubleshooting	119
Page 70, Local Doubler Path Troubleshooting	120
Page 76, Figure 5-2 43521A Block Diagram	121
Page 82, Figure 6-2 Top View (Major Assemblies)	122
Page 83, Table 6-1 Top View (Major Assemblies)	123
Page 84, Figure 6-3 Top View (Cables and Wires 1/2)	124
Page 85, Table 6-2 Top View (Cables and Wires 1/2)	125
Page 86, Figure 6-4 Top View (Cables and Wires 2/2)	126
Page 87, Table 6-3 Top View (Cables and Wires 2/2)	127
Page 97, Figure 6-12 Step Attenuator Assembly	128
Page 97, Table 6-11 Step Attenuator Assembly	128
Page 103, Figure 6-18 DETECTOR Assembly	129
Page 103, Table 6-17 DETECTOR Assembly	129
Page 107, Step Attenuator Replacement	130
Page 107, U-WAVE AMP 18 GHz Replacement	131
Pages 112, Table 7-1 Post Repair Procedures	132
B. Power Requirement	
Replacing Fuse	136
Fuse Selection	136
Power Requirements	137
Power Cable	137

1 **General Information**

The Service Manual is a guide to servicing the 43521A Downconverter Unit. The manual contains informatoin required to performance test, adjust, troubleshoot, and repair the Downconverter unit

Organization of Service Manual

The 43521A is used as part of the 4352S VCO/PLL Signal Test System. Using the 43521A expands the maximum frequency of the 4352S to 12.6 GHz.

This manual consists of the chapters and appendices listed below. This section lists the names of the chapters and the describes content of each chapter and the appendices.

- *Performance Test* provides the procedures required to performance test for the 43521A.
- *Adjustment* provides procedures for adjusting the 43521A after repair or replacement of a part. Most of the adjustments update the correction constants data stored in the EEPROM on the A1 board assembly. The correction constants data is updated by using the adjustment program.
- *Troubleshooting* outlines the 43521A troubleshooting, and provides troubleshooting procedures to isolate the faulty part.
- *Theory of Operation* explains the overall operation of the 43521A.
- *Parts Replacement* provides the replaceable part list and the procedure to replace its assemblies.
- *Post Repair Procedures* contains the table of related service procedures. It is a table of adjustments and verification procedures to be performed after repair or replacement of each part.
- *Appendices* contains manual change information (required to make this manual compatible with earlier shipment configurations of the 43521A), and power requirements of the 43521A.

Instruments Covered by This Manual

Agilent Technologies uses a two-part, ten-character serial number label (See Figure 1-1) attached to the instrument's rear panel. The first five characters are the serial prefix and the last five digits are the suffix.

Figure 1-1

Serial Number Label



An instrument manufactured after the printing date of this manual may have serial number prefix that is not listed on the title page. This unlisted serial number prefix indicates the instrument is different from those described in this manual. The manual for this new instrument may be accompanied by a yellow Manual Changes supplement or have a different manual part number. This sheet contains “change information” that explains how to adapt the manual to the newer instrument.

In addition to change information, the supplement may contain information for correcting errors (Errata) in the manual. To keep this manual as current and accurate as possible, Agilent Technologies recommends that you periodically request the latest Manual Changes supplement. The supplement for this manual is identified by this manual's printing data and is available from Agilent Technologies. If the serial prefix or number of an instrument is lower than that on the title page of this manual, see Appendix A, Manual Changes. For information concerning a serial number prefix that is not listed on the title page or in the Manual change supplement, contact the nearest Agilent Technologies office.

Require Equipment

Table 1-1 lists the recommended equipment for performing maintenance on the 43521A.

Table 1-1 Recommended Test Equipment

Equipment	Critical Specifications	Recommended Model	Qty.	Use* ¹
VCO/PLL Signal Analyzer	No substitute	4352B	1	P,A, T
Signal Generator	Freq.Range 10 MHz to 6 GHz Power: ≥ 10 dBm	8665B Opt.004 or 8360B series	1	P,A, T
Signal Generator	Freq Range 10 MHz to 3 GHz Power:	8664A Opt.004 8665A/B Opt.004 or 8642B	1	P
Signal Generator	Freq Rang 3 GHz to 12 GHz	83711B or 8360B series	1	P,A, T
Power Meter	No substitute	437B, 438A, E4418A/B or E4419A/B	1	P,A
Power Meter	No substitute	E4419A/B	1	A
Power Sensor	Freq. Range: 3 GHz to 12 GHz, Power: +15 dBm to -15 dBm	8481A	2	P,A
Power Sensor	No substitute	E4412A	1	A
Power Amplifier	Gain: 35 dB Freq. Range: 3 GHz to 12 GHz	83020A	1	P,A
DC Power Supply	No substitute	87422A (for 83020A)	1	P,A
Network Analyzer	Freq: 2 GHz to 13 GHz	8719D, 8720D or 8722D	1	P
Calibration Kit	Freq: 2 GHz to 13 GHz	85054D or 85054B	1	P
Step Attenuator	Attenuation Range: 0 dB to 70 dB, Step: 10 dB, Freq.Range: 3 GHz to 12 GHz	8495H	1	P,A
Step Attenuator	Attenuation Range: 0 dB to 11 dB, Step: 1 dB, Freq.Range: 3 GHz to 12 GHz	8494H	1	P,A
Att. Switch Driver	No substitute	11713A	1	P,A
Power Splitter	Freq. Range: 3 GHz to 12 GHz 2-Way, 50 Ω	11667A	1	P,A
2 GHz Lowpass Filter	Insertion Loss: 0.5 dB, VSWR < 1.24	p/n 0955-0634	1	A

Table 1-1 Recommended Test Equipment

Equipment	Critical Specifications	Recommended Model	Qty.	Use ^{*1}
Attenuator Pad	Impedance 50 Ω, 7mm(m)-7mm(f), 6 dB, 3 GHz to 12 GHz	8493B Opt.006	1	P,A
Blocking Capacitor	No substitute	11742A	1	P,A
Spectrum Analyzer	Freq. Range: 100 MHz to 5 GHz	8595E	1	T
Cable	N(m)-N(m),18 cm	8120-4387	2	P,A, T
	N(m)-N(m),61 cm	11500B	1	P,A, T
	BNC(m)-BNC(m),61 cm	8120-1839	2	P,A, T
	BNC(m)-BNC(m),122 cm	8120-1840	1	P,A, T
	Precision N(m)-Precision N(m),61cm	11500C	2	P,A, T
	3.5mm(m)-3.5mm(m) Cable,61cm	11500E	1	P,A, T
Adapter	N(m)-N(m) Adapter	1250-1475	1	P
	SMA(f)-SMA(f) Adapter	1250-1158	1	T
	SMA right angle(m)(f) Adapter	1250-1249	2	T
	3.5mm(f)-Precision N(m) Adapter	1250-1744	2	P,A, T
	3.5mm(m)-Precision N(f) Adapter	1250-1750	1	A
	3.5mm(m)-N(m) Adapter	1250-1743	1	A
	3.5mm(f) ^{*2} -N(f) Adapter	part of 85130C ^{*3}	1	P

*1.P: Performance Test, A: Adjustment and Correction Constants, T: Troubleshooting

*2.Special rugged female connector specifically for connecting to the network analyzer test port, but does not mate with a standard male connector.

*3.If the 8722D is used, use 87130E+ 11524A for a substitute.

General Information
Require Equipment

2 **Performance Test**

This chapter provides the Performance Test Procedure for the 43521A Downconverter Unit. These performance tests are used to verify that the analyzer's performance meets its specifications.

Performance Test

Introduction

This section provides the test procedures used to verify that the 43521A's specifications are met. The performance tests can also be used for incoming inspection, and for verification after troubleshooting or adjustment. If the performance tests indicate that the 43521A is *NOT* operating within the specified limits, check your test setup, then proceed with troubleshooting if necessary.

Warm Up Time

Allow the 43521A to warm up for at least 30 minutes before you execute any of the performance tests.

Ambient Conditions

Perform all performance tests in ambient conditions of $23\text{ }^{\circ}\text{C} \pm 5\text{ }^{\circ}\text{C}$, $\leq 70\%$ RH.

Performance Test Interval

The performance test should be performed periodically. The recommended test interval is 12 months.

NOTE

The test interval depends on maintenance of use and the environmental conditions under which the instrument is used. You may find that the test interval could be shortened or lengthened; however, such a decision should be based on substantial quantitative data.

Performance Test Record and Calculation Sheet

Performance test record lists all test points, acceptable test limits, test result entry columns, and measurement uncertainties. The listed measurement uncertainties are valid only when the recommended test equipment is used.

The calculation sheet is used as an aid for recording raw measurement data, and for calculating the performance test results.

The procedure for using the calculation sheet and performance test record is;

1. Photo copy the calculation sheet.
2. Follow the performance test procedure and record the measurement values, etc., in the specified column on the calculation sheet.
3. Calculate the test result using the appropriate equation given on the calculation sheet, and record the test result into the Test Result column of the performance test record.

RF Power Measurement Accuracy Test

This test checks the RF power measurement accuracy.

Specification

RF Power Measurement Accuracy

		Frequency		
Level (Attenuator)	Temperature	≥2.4 GHz, ≤4 GHz	> 4 GHz, ≤8 GHz	> 8 GHz, ≤ 12 GHz
≤ 0 dBm (0 dB)	23±10 °C	±1.5 dB	±2.0 dB	±2.5 dB
≤ 15 dBm (> 0dB)	0 to 40 °C	±1.5 dB	±2.0 dB	±2.5 dB


Test Equipment

Description	Recommended Model
Signal Generator (for RF IN)	83711B or 8360B series
Signal Generator (for LO IN)	8665B or 8360B series
Power Amplifier	83020A
DC Power Supply	87422A
Power Splitter	11667A
Power Meter	E4418A/B,437B,or 438A
Power Sensor	8481A
VCO/PLL Signal Analyzer	4352B
Step Attenuator	8495H
Step Attenuator	8494H
Attenuator Pad	8493B Opt.006
Blocking Capacitor	11742A
RF Cable N(m)-N(m), 61 cm	p/n 8120-1839,2ea
RF Cable N(m)-N(m), 122 cm	p/n 8120-1840
N(m)-N(m) Cable,18cm	p/n 8120-4387,2ea
N(m)-N(m) Cable, 61cm	11500B or part of 11851B
Precision N(m)-Precision N(m) Cable, 61 cm	11500C or part of 11851B, 2ea
3.5mm(m)-3.5mm(m) Cable,61 cm	11500E
N(m)-N(m) Adapter	1250-1475
3.5mm(m)-Precision N(f) Adapter	1250-1744

Performance Test
Performance Test

Procedure

Figure 2-1 Power Measurement Accuracy Test Setup



43521ase001

1. Perform the zero adjustment and the calibration for the power meter.
2. Connect the equipment as shown in Figure 2-1.
3. Press **[Preset]** to initialize the 4352B. Then set the controls as follows.

Setting	Operation
Instrument type: VCO Tester	[Meas] - INST TYPE - VCO TESTER
Measurement mode: RF Power	[Meas] - RF POWER
Down converter control: ON	[RF/LO] - DOWNCONV ON off
LO control: Auto ^{*1}	[RF/LO] - LO CONTROL AUTO man
Signal generator type: 1 ^{*2}	[RF/LO] - SG TYPE - [1]
Signal generator max. freq.: 6 GHz	[RF/LO] - SG MAX FREQ - [6] - [G/n]
Frequency Band: 2.4 GHz-6.6 GHz	[Meas] - FREQ BAND - 2.4-6.6G
Nominal Frequency: 4 GHz	[Meas] - FREQ BAND - NOMINAL FREQ - [4] - [G/n]
43521A RF Attenuator: 20 dB	[Sense Range] - RF ATTEN - [2] - [0] - [×1]

*1.If the signal generator for the LO IN port is NOT the 8665B, set the LO control to Manual.

*2.If the LO control is set to Manual, this operation is not required.

- Set the other instruments' control as follows.

Instrument	Setting
RF signal generator	Freq: 4 GHz, Power: 0 dBm
LO signal generator ^{*1}	Freq: 4.624 GHz, Power: 10 dBm
Step Attenuator	0 dB

*1.If the LO control is set to Auto, this operation is NOT required.

- Adjust the RF signal generator output power to make the power meter reading between (15±0.2) dBm.
- Record the 4352B reading and the power meter reading in the calculation sheet.
- Calculate the test result according to the calculation sheet, then record it in the performance test record.
- Repeat Step 6 for all setting in Table 2-1

Table 2-1 Power Measurement Accuracy Test Setting

RF Att.	Power Meter Reading	RF SG Freq.	Step Att.	LO SG Freq. ^{*1}	Freq. Band
20 dB	15±0.2 dBm	4 GHz	0 dB	4.624 GHz	2.4 to 6.6 GHz
		8 GHz	0 dB	3.688 GHz	5.4 to 12.6 GHz
		12 GHz	0 dB	5.688 GHz	5.4 to 12.6 GHz
	5±0.2 dBm	4 GHz	10 dB	4.624 GHz	2.4 to 6.6 GHz
		8 GHz	10 dB	3.688 GHz	5.4 to 12.6 GHz
		12 GHz	10 dB	5.688 GHz	5.4 to 12.6 GHz
	0±0.2 dBm	3 GHz	15 dB	3.624 GHz	2.4 to 6.6 GHz
		4 GHz	15 dB	4.624 GHz	2.4 to 6.6 GHz
		5 GHz	15 dB	5.624 GHz	2.4 to 6.6 GHz
		6 GHz	15 dB	2.688 GHz	5.4 to 12.6 GHz
		7 GHz	15 dB	3.188 GHz	5.4 to 12.6 GHz
		8 GHz	15 dB	3.688 GHz	5.4 to 12.6 GHz
		9 GHz	15 dB	4.188 GHz	5.4 to 12.6 GHz
		10 GHz	15 dB	4.688 GHz	5.4 to 12.6 GHz
		11 GHz	15 dB	5.188 GHz	5.4 to 12.6 GHz
		12 GHz	15 dB	5.688 GHz	5.4 to 12.6 GHz
	-5±0.2 dBm	4 GHz	20 dB	4.624 GHz	2.4 to 6.6 GHz
		8 GHz	20 dB	3.688 GHz	5.4 to 12.6 GHz
		12 GHz	20 dB	5.688 GHz	5.4 to 12.6 GHz
	-15±0.2 dBm	4 GHz	30 dB	4.624 GHz	2.4 to 6.6 GHz
		8 GHz	30 dB	3.688 GHz	5.4 to 12.6 GHz
12 GHz		30 dB	5.688 GHz	5.4 to 12.6 GHz	
0 dBm	-5±0.2 dBm	4 GHz	20 dB	4.624 GHz	2.4 to 6.6 GHz
		8 GHz	20 dB	3.688 GHz	5.4 to 12.6 GHz
		12 GHz	20 dB	5.688 GHz	5.4 to 12.6 GHz
	-15±0.2 dBm	4 GHz	30 dB	4.624 GHz	2.4 to 6.6 GHz
		8 GHz	30 dB	3.688 GHz	5.4 to 12.6 GHz
		12 GHz	30 dB	5.688 GHz	5.4 to 12.6 GHz

*1. If the LO control is set to “Auto”, this setting is not required.

Input VSWR Test

This test checks the return loss of the RF-IN port.

Specification

VSWR < 1.5

Required Equipment

Description	Recommended Model
Network Analyzer	8719D, 8720D or 8722D
VCO/PLL Signal Analyzer	4352B
Calibration Kit	85054D or 85054B
N(m)-N(m) Cable, 18 cm	p/n 8120-4387, 2ea
Precision N(m)-Precision N(m) Cable, 61 cm	11500C or part of 11851B
3.5 mm(f) ^{*1} -N(f) Adapter	part of 83130C ^{*2}

*1. Special rugged female connector specifically for connecting to the network analyzer test port, but does not mate with a standard male connector.

*2. If the 8722D is used, use 87130E+ 11524A for a substitute.

Procedure


1. Preset the network analyzer, then setup as follows.

Parameter	Value
Measurement mode	SWR ^{*1}
Source Power	0 dBm
Sweep Mode	Liner
Start Frequency	2 GHz
Stop Frequency	13 GHz
Number of points	61 or larger

*1. If SWR is NOT included in the available measurement mode, select the return loss or the reflection coefficient for a substitute.

2. Make a S11 1-port calibration using the calibration kit.
3. Connect the equipment as shown in Figure 2-2.

Figure 2-2 Input VSWR Test Setup



43521ase002

- Press **[Preset]** to initialize the 4352B, then set the control as follows

Setting	Operation
Down converter control: ON	[RF/LO] - DOWNCONV ON off
Signal generator max freq: 6 GHz	[RF/LO] - SG MAX FREQ - [6] - [G/n]
Frequency Band: 5.4 GHz to 12.6 GHz	[Meas] - FREQ BAND - 5.4-12.6G
43521A RF attenuator: 20 dB	[Sense Range] - RF ATTEN - [2] - [0] - [×1]

- Make the single sweep measurement for the network analyzer.
- Record the maximum value to the performance test record.

NOTE

If the measurement mode is set to Return Loss or Reflection Coefficient at Step 1, perform the following procedure instead of Step 6.

- Record either of the following values to the calculation sheet.
 - the minimum value of the return loss
 - the maximum value of the reflection coefficient
- Calculate the test result according to the calculation sheet, then record it in the performance test record.

- Set the 43521A RF attenuator to 0 dB

8. Repeat the Step 5 and 6.

Function Test

Introduction

This section provides the test procedures used to verify the 43521A's performance characteristics and functions. The function test is recommended to be performed with the 43521A performance test.

Warm Up Time

Allow the 43521A to warm up for at least 30 minutes before you execute any of the function tests.

Ambient Condition

Perform all performance tests in ambient conditions of $23\text{ }^{\circ}\text{C} \pm 5\text{ }^{\circ}\text{C}$, $\leq 70\%$ RH.

600 MHz SAW OSC Phase Noise Test

This test checks the phase noise of the 600 MHz SAW oscillator using the 4352B.

Performance Characteristic


1 kHz Offset	≤ -105 dBc
10 kHz Offset	≤ -130 dBc
100 kHz Offset	≤ -140 dBc
1 MHz Offset	≤ -148 dBc

Required Equipment

Description	Recommended Model
VCO/PLL Signal Analyzer	4352B
Signal Generator	8664A or 8665A/B
N(m)-N(m) Cable, 61 cm	11500B or part of 11851B, 2ea
BNC(m)-BNC(m) Cable, 61 cm	p/n 8120-1839

Procedure

Figure 2-3 600 MHz SAW OSC Phase Noise Test Setup



43521ase004

Performance Test
Function Test

1. Connect the equipment as shown in Figure 2-3.
2. Press **[Preset]** to initialize the 4352B, then set the control as follows.

Setting	Operation
Instrument type: VCO Analyzer	[Meas] - INST TYPE - VCO ANALY
Measurement mode: Phase Noise	[Meas] - PHASE NOISE
Down converter control: ON	[RF/LO] - DOWNCONV ON off
LO control: Manual	[RF/LO] - LO CONTROL auto MAN
Frequency Band: except 10 MHz-3 GHz	[Meas] - FREQ BAND - except 10M-3G
43521A RF Attenuator: 5 dB	[Sense Range] - RF ATTEN - [5] - [×1]
43521A Noise Attenuator: 0 dB	[Sense Range] - NOISE ATTEN - [0] - [×1]
Averaging: On	[Bw/Avg] - AVERAGING ON off

3. Set the frequency of the signal generator's output to 576.1 MHz, and the power to 10 dBm.
4. Press **[Trigger] - SINGLE** to make a measurement.
5. Press **[Menu] - MARKER** to indicate the maker.
6. Press **[1] - [k/m]** to show the phase noise at 1 kHz offset.
7. Record the reading into the calculation sheet.
8. Perform Step 7 at all offset in the following table.

Offset
1 kHz
10 kHz
100 kHz
1 MHz

9. Record the test result in the performance test record according to the calculation sheet.

System Phase Noise Test

This test checks the phase noise of the 4352S with 43521A.

Performance Characteristic

9 MHz Offset ≤ -133 dBc (Freq. Band: 2.4 to 6.6 GHz)
 ≤ -132 dBc (Freq. Band: 5.4 to 12.6 GHz)

Required Equipment

Description	Recommended Model
VCO/PLL Signal Analyzer	4352B
LO Signal generator	8664A, 8665A/B or 8642B
RF Signal generator	8664A or 8665A/B
N(m)-N(m) Cable, 18 cm	p/n 8120-4387,2ea
N(m)-N(m) Cable, 61 cm	11500B or part of the 11851B, 2ea
BNC(m)-BNC(m) Cable, 61 cm	p/n 8120-1839. 2ea


NOTE

The message “**CAUTION: Set RF ATT 5dB Less**” could be displayed on the 4352B’s display during performing this test. In this test, the corrective action of the message is not needed.

Performance Test
Function Test

Procedure

Figure 2-4 System Phase Noise Test Setup



43521ase003

1. Connect the equipment as shown in Figure 2-4
2. Press **[Preset]** to initialize the 4352B, then set the control as follows

Setting

Instrument type: VCO Analyzer
 Measurement mode: Phase Noise
 Down converter control: ON
 LO control: Manual
 Maximum SG Frequency: 6 GHz
 Frequency Band: 2.4 to 6.6 GHz
 43521A RF Attenuator: 20 dB
 43521A Noise Attenuator: 0 dB
 Averaging: ON

Operation

[Meas] - INST TYPE - VCO ANALY
[Meas] - PHASE NOISE
[RF/LO] - DOWNCONV ON off
[RF/LO] - LO CONTROL auto MAN
[RF/LO] - SG MAX FREQ - [6] - [G/n]
[Meas] - FREQ BAND - 2.4-6.6G
[Sense Range] - RF ATTEN - [2] - [0] - [×1]
[Sense Range] - NOISE ATTEN - [0] - [×1]
[Bw/Avg] - AVERAGING ON off

3. Set the control of each signal generator as follows.

Signal Generator	Frequency	Power
LO Signal Generator	2.1 GHz	+10 dBm
RF Signal Generator	2.724 GHz	0 dBm

4. Press **[Trigger]** - **SINGLE** to make a measurement.
 5. Press **[Menu]** - **MARKER** to indicate the maker.
 6. Press **[9]** - **[M/μ]** to show the phase noise at the 9 MHz offset.
 7. Record the reading in the calculation sheet.
 8. Press **[Meas]** - **FREQ BAND - 5.4-12.6G** to change the frequency range.
 9. Set the control of each signal generator as follows.

Signal Generator	Frequency	Power
LO Signal Generator	1.811 GHz	+10 dBm
RF Signal Generator	2.998 GHz	0 dBm

10. Perform Step 4 to Step 7.
 11. Record the test result into the performance test record according to the calculation sheet.

Calculation Sheet

Performance Test

RF Power measurement Accuracy Test

RF Attenuator: 20 dB

Level	Frequency	Power Meter Reading [a]	4352B Reading [b]	Test Result [a – b]
15 dBm	4 GHz	dBm	dBm	dB
	8 GHz	dBm	dBm	dB
	12 GHz	dBm	dBm	dB
5 dBm	4 GHz	dBm	dBm	dB
	8 GHz	dBm	dBm	dB
	12 GHz	dBm	dBm	dB
0 dBm	3 GHz	dBm	dBm	dB
	4 GHz	dBm	dBm	dB
	5 GHz	dBm	dBm	dB
	6 GHz	dBm	dBm	dB
	7 GHz	dBm	dBm	dB
	8 GHz	dBm	dBm	dB
	9 GHz	dBm	dBm	dB
	10 GHz	dBm	dBm	dB
	11 GHz	dBm	dBm	dB
	12 GHz	dBm	dBm	dB
-5 dBm	4 GHz	dBm	dBm	dB
	8 GHz	dBm	dBm	dB
	12 GHz	dBm	dBm	dB
-15 dBm	4 GHz	dBm	dBm	dB
	8 GHz	dBm	dBm	dB
	12 GHz	dBm	dBm	dB

RF Attenuator: 0 dB

Level	Frequency	Power Meter Reading [a]	4352B Reading [b]	Test Result [a – b]
-5 dBm	4 GHz	dBm	dBm	dB
	8 GHz	dBm	dBm	dB
	12 GHz	dBm	dBm	dB
-15 dBm	4 GHz	dBm	dBm	dB
	8 GHz	dBm	dBm	dB
	12 GHz	dBm	dBm	dB

Input VSWR Test

RF Attenuator	Return loss Minimum Value [a]	Maximum value Reflection Coefficient [b]	Test Result $[1+a/1-a]$ or $[1+10^{-b/20}/1-10^{-b/20}]$
20 dB	dB		
0 dB	dB		

Function Test

600 MHz SAW OSC Phase Noise Test

Offset	4352B reading	Performance Characteristic
1 kHz	dBc	≤ -105 dBc
10 kHz	dBc	≤ -130 dBc
100 kHz	dBc	≤ -140 dBc
1 MHz	dBc	≤ -148 dBc

NOTE This test fails if the reading is above the performance characteristic in any test point.

System Phase Noise Test

Frequency Band	4352B Reading	Performance Characteristic
2.4 to 6.6 GHz		≤ -133 dBc
5.4 to 12.6 GHz		≤ -132 dBc

NOTE This test fails if the reading is above the performance characteristic in any test point.

Performance Test Record

Agilent Technologies 43521A Downconverter Unit

Serial Number: _____ Options: _____

Temperature: _____ °C Date: _____

Humidity: _____ %RH Tested by: _____

RF Power Measurement Accuracy Test

RF Attenuator: 20 dB

Level	Frequency	Test Limit	Test Result	Measurement Uncertainty
15 dBm	4 GHz	± 1.5 dB	dB	±0.36 dB
	8 GHz	± 2.0 dB	dB	±0.46 dB
	12 GHz	± 2.5 dB	dB	±0.65 dB
5 dBm	4 GHz	± 1.5 dB	dB	±0.29 dB
	8 GHz	± 2.0 dB	dB	±0.41 dB
	12 GHz	± 2.5 dB	dB	±0.61 dB
0 dBm	3 GHz	± 1.5 dB	dB	±0.29 dB
	4 GHz	± 1.5 dB	dB	±0.29 dB
	5 GHz	± 2.0 dB	dB	±0.41 dB
	6 GHz	± 2.0 dB	dB	±0.41 dB
	7 GHz	± 2.0 dB	dB	±0.41 dB
	8 GHz	± 2.0 dB	dB	±0.41 dB
	9 GHz	± 2.5 dB	dB	±0.61 dB
	10 GHz	± 2.5 dB	dB	±0.61 dB
	11 GHz	± 2.5 dB	dB	±0.61 dB
	12 GHz	± 2.5 dB	dB	±0.61 dB
-5 dBm	4 GHz	± 1.5 dB	dB	±0.29 dB
	8 GHz	± 2.0 dB	dB	±0.41 dB
	12 GHz	± 2.5 dB	dB	±0.61 dB
-15 dBm	4 GHz	± 1.5 dB	dB	±0.29 dB
	8 GHz	± 2.0 dB	dB	±0.41 dB
	12 GHz	± 2.5 dB	dB	±0.61 dB

Performance Test
Performance Test Record

RF Attenuator: 0 dB

Level	Frequency	Test Limit	Test Result	Measurement Uncertainty
-5 dBm	4 GHz	± 1.5 dB	dB	±0.29 dB
	8 GHz	± 2.0 dB	dB	±0.41 dB
	12 GHz	± 2.5 dB	dB	±0.61 dB
-15 dBm	4 GHz	± 1.5 dB	dB	±0.29 dB
	8 GHz	± 2.0 dB	dB	±0.41 dB
	12 GHz	± 2.5 dB	dB	±0.61 dB

Input VSWR Test

RF Attenuator	Test Limit	Test Result	Measurement Uncertainty
20 dB	<1.5		±0.1
0 dB	<1.5		±0.1

Function Test Record

600 MHz SAW OSC Phase Noise Test

Pass Fail

System Phase Noise Test

Pass Fail

3 **Adjustment**

This chapter provides the adjustment procedure for the 43521A Downconverter Unit to ensure that the 43521A Downconverter Unit is within its specifications.

Safety Considerations

This manual contains NOTES, CAUTIONs, and WARNINGs that must be followed to ensure the safety of the operator and to keep the instrument in a safe and serviceable condition. The Adjustment must be performed by qualified service personnel.

WARNING

Any interruption of the protective ground conductor (inside or outside the analyzer) or disconnection of the protective ground terminal can make the instrument dangerous. Intentional interruption of the protective ground system for any reason is prohibited.

Required Controller

The following controller system is required to run the adjustment program.

Windows PC	PC-AT Compatible, RAM:≥64MBytes, CPU Pentium 200 MHz or faster
OS	Microsoft® Windows NT® (≥4.0), Windows 95®, Windows 98®
Software	HP VEE (≥4.0)
GPIB Card	82350A, 82340B, 82341C/D

Warm-up for Adjustment

Warm-up the 43521A for at least 30 minute before performing any of the following Adjustment procedures to ensure procedures to ensure proper results and correct instrument operation.

Required Equipment

Table 1-1 lists the equipment required to perform the Adjustment procedures described in this chapter. Use only calibrated test equipment when adjusting the 43521A.

Order of Adjustment

When performing more than one Adjustment, perform them in the order they appear in this chapter. The procedures are presented in the following order.

- 600 MHz SAW Oscillator Frequency Adjustment
- RF Power Linearity Correction Constants
- RF Power Frequency Response Correction Constants
- RF IN Direct Path Insertion Loss Correction Constants
- Correction Constant Checksum

Preparation for using the Adjustment Program

To use the Adjustment Program, some preparation is required. This section describes how to its procedure.

Installing a GPIB Card (82340B, 82341C/D or 82350A)

Install a GPIB Card into your computer (see the GPIB Card manual). The select code of the GPIB Card should be set to “7”.

Installing HP VEE for Personal Computer

Install the HP VEE into your computer (see the HP VEE for Windows[®]).


Installing Adjustment Program into Your PC (preliminary)

1. Make a copy of the 43521A adjustment program named `ADJ43521A.EXE` in a directory of your hard disk drive.
2. Double-click the filename on the Windows' Explorer to start extracting the self-extracting archive.
3. You will be prompted to enter directory name for installing the program files. Click `Unzip` to use default directory (`C:\ADJ43521A`).
4. Confirm the message that you successfully extract the files and click `OK` and `Close`.

Equipment Setup

Performing adjustments requires the system described in this section. The Hardware Setup is shown in Figure 3-1.

Figure 3-1 Adjustment Hardware Setup




43521ase040

Running the Adjustment Program

1. Start the HP VEE.
2. Load the adjustment program file into the HP VEE as follows.
 - a. Pull down the File menu from the HP VEE window and select Open.
 - b. Select the file C:\ADJ43521A\ADJ43521A.VEE and click Open.
3. You may be asked to add drivers for the equipment during the program loading. Click on OK and the GPIB address for each equipment. Enter 0 as the address for the equipment which are not used for the adjustment. (See Figure 3-2).

Figure 3-2

Direct I/O configuration



4. Click START button on the HP VEE Screen.
5. Follow the instruction shown on the display.

600 MHz SAW Oscillator Frequency Adjustment

The purpose of this procedure is to adjust the 600 MHz SAW Oscillator.

Required Equipment

Description	Recommended Model
VCO/PLL Signal Analyzer	4352B
Signal Generator	8664A, 8665A/B or 8360B series *1
N(m)-N(m) Cable, 61 cm	11500B or part of 11851B, 2ea
BNC(m)-BNC(m) Cable, 61 cm	p/n 8120-1839, 2ea

*1.83622B or 83624B cannot be used in this adjustment.


Manual Procedure

NOTE

This adjustment can be performed with the adjustment program. In this case, choose the Adj_Freq and follow the program instruction.

1. Connect the equipment as shown in Figure 3-3.

Figure 3-3 600 MHz SAW OSC Frequency Adjustment Setup



43521ase004


Adjustment

600 MHz SAW Oscillator Frequency Adjustment

2. Remove the plug hole cap for the 600 MHz ADJ on the rear panel. The location of the 600 MHz ADJ is shown in Figure 3-4.

Figure 3-4

600 MHz ADJ Location



43521ase026

3. Connect a 15-pin D-Sub cable (furnished with the 43521A) between the I/O PORT connector of the 43521A and the I/O PORT connector of the 4352B.
4. Press **[RF/LO]** and then **DOWNCONV ON OFF** to toggle it **DOWNCONV ON off**. (The 43521A outputs the 600 MHz signal.)
5. Press **[Meas]** and **FREQ BAND [xx-xx]** in this order, and then press a key other than **FREQ BAND 10M-3G** on the frequency band menu. The selected frequency band softkey is underlined.
6. Press **[RF/LO]** and then **DOWNCONV ON off** to toggle it **DOWNCONV on OFF**. (While keeping to 600 MHz signal from the 43521A, you can use the measurement functions of the 4352B.)
7. Press **[Meas]**, **INST TYPE**, **INST TYPE: VCO TESTER**, and **FREQUENCY** in this order. And then press **[Sense Range]**, **FREQ RES: 1kHz**.
8. Rotate the 600 MHz ADJ clockwise until the 4352B reading is less than 599.976 MHz.
9. Connect a BNC cable between the 40 MHz Input of the 43521A and the 40 MHz Output of the 4352B. Then confirm that the 4352B reading is within 600 MHz \pm 1 kHz.
10. Disconnect the BNC cable between the 40 MHz Input of the of the 43521A and the 40 MHz Output of the 4352B. Then rotate the 600 MHz ADJ counterclockwise until the 4352B reading is within 600 MHz \pm 6 kHz
11. Press **[MEAS]**, **RF POWER**, and then check that the 4352B reading is 8 dBm or more.

Writing Default Correction Constant

The purpose of this procedure is to writing default data. This adjustment is required only when the A1 Board is replaced.

Required Equipment

Description	Recommended Model
VCO/PLL Signal Analyzer	4352B

Procedure

1. Run the adjustment program.
2. Choose the CC_WriteDef.
3. Follow the adjustment program instruction to update the correction constants.

RF Power Linearity Correction Constants

The purpose of this procedure is to adjust the power linearity and the power temperature characteristic.


Required Equipment

Description	Recommended Model
Signal Generator (for RF IN)	83711B, 8360B series
Signal Generator (for LO IN)	8665B, 8360B series
Power Amplifier	83020A
DC Power Supply	87422A
Power Splitter	11667A
Power Meter	E4419A/B
Power Sensor	E4412A
VCO/PLL Signal Analyzer	4352B
80 dB Step Attenuator	8495H
10 dB Step Attenuator	8494H
Attenuator/Switch Driver	11713A
Attenuator Pad	8493B Opt.006
Blocking Capacitor	11742A
2 GHz Lowpass Filter	p/n 0955-0634
RF Cable N(m)-N(m), 61 cm	p/n 8120-1839,2ea
RF Cable N(m)-N(m), 122 cm	p/n 8120-1840
N(m)-N(m) Cable,18cm	p/n 8120-4387,2ea
N(m)-N(m) Cable, 61cm	11500B or part of 11851B
Precision N(m)-Precision N(m) Cable 61 cm	11500C or part of 11851B, 2ea
3.5mm(m)-3.5mm(m) Cable, 61 cm	11500E
N(m)-N(m) Adapter	p/n 1250-1475
3.5mm(f)-Precision N(m) Adapter	p/n 1250-1744
3.5mm(m)-Precision N(f) Adapter	p/n 1250-1750

Procedure

1. Run the adjustment program.
2. Choose the CC_RFPowLin.
3. Connect the equipment as shown in Figure 3-5

Figure 3-5 RF Power Linearity Correction Constants Setup



43521ase011

4. Follow the adjustment program instruction to update the correction constants.

RF Power Frequency Response Correction Constants

The purpose of this procedure is to adjust the power and the power temperature characteristic.


Required Equipment

Description	Recommended Model
Signal Generator (for RF IN)	83711B, 8360B series
Signal Generator (for LO IN)	8665B, 8360B series
Power Splitter	11667A
Power Meter 1	E4419A/B
Power Sensor 1	8481A
Power Meter 2	437B,438A,E4418A/B or E4419A/B
Power Sensor 2	8481A
VCO/PLL Signal Analyzer	4352B
RF Cable N(m)-N(m), 61 cm	p/n 8120-1839,2ea
RF Cable N(m)-N(m), 122 cm	p/n 8120-1840
N(m)-N(m) Cable,18cm	p/n 8120-4387,2ea
N(m)-N(m) Cable, 61cm	11500B or part of 11851B
Precision N(m)-Precision N(m) Cable, 61 cm	11500C or part of 11851B
N(m)-N(m) Adapter	p/n 1250-1475
3.5mm(m)-Precision N(m) Adapter	p/n 1250-1743

Procedure

1. Run the adjustment program.
2. Choose the CC_RFPowF_Resp.
3. Connect the equipment as shown in Figure 3-6

Figure 3-6 Power Sensor Tracking Calibration Setup



43521ase052

4. Follow the program instruction to perform the power sensor tracking calibration.
5. Connect the equipment as shown in Figure 3-7

4 Troubleshooting

This chapter describes troubleshooting flow and provides the procedure to determine which assembly/part is faulty and should be checked.

TROUBLESHOOTING SUMMARY


The troubleshooting strategy of this manual is based on a verification (rather than symptomatic) approach. This chapter describes typical troubleshooting procedure step by step and you can identify a faulty part by following the troubleshooting steps sequentially.

Figure 4-1 diagrams the troubleshooting organization.

A faulty part is replaced according to Chapter 6. Chapter 6 lists the replaceable parts and gives replacement procedures for the major parts.

The procedures required after part replacement, such as adjustments and performance tests, are given in Chapter 7.

Figure 4-1 Troubleshooting Organization



43521ase008

Check Procedure

To verify the operation of the 43521A alone, perform the following procedures.

- Check LED (Front)
- Check Fan
- Check 600 MHz Output
- Check Power Measurement Function
- Check Heterodyne Path
- Check Local Doubler Path

NOTE

All check procedures except the check LED and Fan needs the 4352B to control the 43521A.

If the 43521A has passed all of the checks but it still making incorrect measurements or unexpected operations, suspect the 4352B. Refer to the 4352B Service Manual.

Check LED (Front)

Turn the 43521A power on and watch the LED on the front panel. The LED should be lit. If case of unexpected results, continue with the *Power Supply Troubleshooting* section.

Check Fan

Turn the 43521A power on and inspect the fan on the rear panel. The fan should be rotating and audible. If case of unexpected results, continue with the *Power Supply Troubleshooting* section.

Check 600 MHz Output

1. Connect an N(m)-N(m) cable between the LO OUT connector of the 43521A and the RF IN connector of the 4352B. Connect a BNC cable between the 40 MHz Input of the 43521A and the 40 MHz Output of the 4352B. Connect a 15-pin D-Sub cable (furnished with the 43521A) between the I/O PORT connector of the 43521A and the I/O PORT connector of the 4352B.
2. Press **[RF/LO]** and then **DOWNCONV on OFF** to toggle it **DOWNCONV ON off**. (The 43521A outputs the 600 MHz signal.)
3. Press **[Meas]** and **FREQ BAND [xx-xx]** in this order, and then press a key other than **FREQ BAND 10M-3G** on the frequency band menu. The selected frequency band softkey is underlined.
4. Press **[RF/LO]** and then **DOWNCONV ON off** to toggle it **DOWNCONV on OFF**. (While keeping to 600 MHz signal from the 43521A, you can use the measurement functions of the 4352B.)
5. Press **[Meas]**, **INST TYPE**, **INST TYPE: VCO TESTER**, and **FREQUENCY** in this order. **FREQUENCY** is underlined, which indicates that the frequency measurement in the tester mode is selected.

6. Check that the measured value on the 4352B's screen is $600\text{ MHz} \pm 64\text{ kHz}$.
7. Press **[MEAS], RF POWER**.
8. Check that the measured value on the 4352B's screen is 8 dBm or more.
 - If the measured values (frequency and power) are not within these limits, continue with *600 MHz OSC Troubleshooting*.
 - If the measured values (frequency and power) are within these limits, the 600 MHz OSC is verified.
9. Record this value as Pb. The difference between this Pb and Pa described by *Check Power Measurement Function* is used to diagnose faults.

Check Power Measurement Function

1. Connect an N(m)-N(m) cable between the LO OUT connector and the RF IN connector of the 43521A. Connect a 15-pin D-Sub cable (furnished with the 43521A) between the I/O PORT connector of the 43521A and the I/O PORT of the 4352B.
2. Press **[RF/LO]** and then **DOWNCONV on OFF** to toggle it **DOWNCONV ON off**.
3. Press **[Meas]** and **FREQ BAND [xx-xx]** in this order, and then press a key other than **FREQ BAND 10M-3G** on the frequency band menu. The selected frequency band softkey is underlined.
4. Press **[Sens Range]** and **RF ATTEN** in this order. Use **[↑]** and **[↓]** or the rotary knob to set the attenuator to 20 dB.
5. Press **[System], SERVICE MENU**, and **SERVICE MODES** in this order. (The 4352B enters into the service mode and displays the measured power value. The value measured with the power measurement function of the 43521A is displayed.)
6. Use the power value measured with the 4352B as Pa.
7. Check that the difference between Pb recorded in the *Check 600 MHz Output* section and Pa is 2 dB or less.
 - If the difference is not within the limit, continue with *Power Measurement Function Troubleshooting*.
 - If the difference is within the limit, the power measurement function is verified.


Check Heterodyne Path

NOTE

The message “**CAUTION: Set RF ATT 5dB Less**” could be displayed on the 4352B's display during performing this check. In this check, the corrective action of the message is not needed.

1. Connect the equipment as shown in Figure 4-2, and connect a 15-pin D-Sub cable (furnished with the 43521A) between the I/O PORT connector of the 43521A and the I/O PORT connector of the 4352B.

Figure 4-2 Heterodyne Path / Local Doubler Path Check Setup



43521ase003

- Press **[Preset]** to initialize the 4352B, then set the 43521A/4352B as follows.

Setting	Operation
Instrument type: VCO Tester	[Meas] - INST TYPE - VCO TESTER
Measurement mode: FREQUENCY	[Meas] - FREQUENCY
Down converter control: ON	[RF/LO] - DOWNCONV ON off
Signal Generator max freq: 3 GHz	[RF/LO] - SG MAX FREQ - [3] - [G/n]
Frequency Band: 2.5 - 3.6 GHz	[Meas] - FREQ BAND - 2.5-3.6G
LO control: Manual	[RF/LO] - LO CONTROL auto MAN
43521A RF Attenuator: 20 dB	[Sense Range] - RF ATTEN - [2] - [0] - [x1]

- Set signal generators as follows.

Instrument	Setting
RF signal generator	Freq: 3 GHz, Power: 0 dBm
LO signal generator	Freq: 2.376 GHz, Power: 10 dBm

4. Press **[Meas] - FREQ BAND - NOMINAL FREQ - [3] - [G/n] - [x1]**.
 - If the 4352B reading is not 3 GHz, change the frequency of the LO signal generator to the LO#'s frequency which is displayed on the left bottom of the 4352B display. Then, confirm that the 4352B reading is 3 GHz.
5. Press **[RF/LO]** and then **DOWNCONV ON off** to toggle it **DOWNCONV on OFF** and press **[Meas] - RF POWER**, then check that the 4352B reading is more than -7 dBm.
 - If the 4352B reading is not within the limit, continue with *Heterodyne Path Troubleshooting*.
 - If the 4352B reading is within the limit, the heterodyne path is verified.

Check Local Doubler Path

NOTE

The message “CAUTION: Set RF ATT 5dB Less” could be displayed on the 4352B's display during performing this check. In this check, the corrective action of the message is not needed.

1. Connect the equipment as shown in Figure 4-2, and connect a 15-pin D-Sub cable (furnished with the 43521A) between the I/O PORT connector of the 43521A and the I/O PORT connector of the 4352B.
2. Press **[Preset]** to initialize the 4352B, then set the 43521A/4352B as follows.

Setting	Operation
Instrument type: VCO Tester	[Meas] - INST TYPE - VCO TESTER
Measurement mode: FREQUENCY	[Meas] - FREQUENCY
Down converter control: ON	[RF/LO] - DOWNCONV ON off
Signal Generator max freq: 3 GHz	[RF/LO] - SG MAX FREQ - [3] - [G/n]
Frequency Band: 3.1 - 6.6 GHz	[Meas] - FREQ BAND - 3.1-6.6G
LO control: Manual	[RF/LO] - LO CONTROL auto MAN
43521A RF Attenuator: 20 dB	[Sense Range] - RF ATTEN - [2] - [0] - [x1]

3. Set signal generators as follows.

Instrument	Setting
RF signal generator	Freq: 4.6 GHz, Power: 0 dBm
LO signal generator	Freq: 1.988 GHz, Power: 10 dBm

4. Press **[Meas] - FREQ BAND - NOMINAL FREQ - [4] - [.] - [6] - [G/n] - [x1]**.
 - If the 4352B reading is not 4.6 GHz, change the frequency of the LO signal generator to the LO#'s frequency which is displayed on the left bottom of the 4352B display. Then, confirm that the 4352B reading is 4.6 GHz.
5. Press **[RF/LO]** and then **DOWNCONV ON off** to toggle it **DOWNCONV on OFF** and

Troubleshooting
Check Procedure

press **[Meas] - RF POWER**, then check that the 4352B reading is more than -7 dBm.

- If the 4352B reading is not within the limit, continue with *Local Doubler Path Troubleshooting*.
- If the 4352B reading is within the limit, the local doubler path is verified.

Power Supply Troubleshooting


Check the Line Voltage, and Fuse

Check the main power line cord, line fuse, actual line voltage to see that they are all correct. For more information about the line cord and line fuse, see the *Power Requirements* in Appendix B.

Check the Power Supply Unit Output

1. Remove the 43521A's top cover.
2. Turn the 43521A power on.
3. Measure the output voltages (+5,+15,-15V) of the power supply unit using a voltmeter with a small probe. The voltages locations on the A1 board are shown in Figure 4-3.

Figure 4-3 Voltage Location



43521ase018

- If the voltmeter reading is not within the following limits, replace the power supply

unit.

Table 4-1 Power Supply Unit Output


supply	Range
+ 5 V	+ 4.75 to + 5.25
+ 15 V	+ 14.25 to 15.75
- 15 V	- 14.75 to -15.75

- If the voltmeter reading is within the limits, the power supply is verified.

Check the Power Supply on the A1 board

1. Disconnect the cables from the A1 board's connector, J6, J7, J8, J9, J10, J11, J12, J13, J14, and J15. The connector locations are shown in Figure 4-4.

Figure 4-4 A1 Connector Location



43521ase009

2. Measure the DC voltages on the A1 using a voltmeter with a small probe. See Table 4-2

for power lines, connector pins, and limits.

Table 4-2 **A1 Power Supplies**

Supply	Connector Pin	Range
+ 12 V	J6 P3 (for Thermo.)	+ 10.8 to + 13.2
+ 5 V	J7 P3 (for LED)	+ 4.5 to + 5.5
+ 5 V	J8 P3 (for FAN)	+ 4.5 to + 5.5
+ 5 V	J9 P2 (for Coax. SW)	+ 4.5 to + 5.5
+ 5 V	J10 P2 (for Coax. SW)	+ 4.5 to + 5.5
+ 5 V	J11 P2 (for Coax. SW)	+ 4.5 to + 5.5
+ 15 V	J12 P1 (for Amp.)	+ 13.5 to + 16.5
+ 15 V	J13 P1 (for Amp.)	+ 13.5 to + 16.5
+ 15 V	J14 P1 (for Amp.)	+ 13.5 to + 16.5
+ 5 V	J15 P6 (for Step Att.)	+ 4.5 to + 5.5


- If any of the voltages are not within these limits, replace the A1.
- If the all voltages are good, the A1 is verified.

600 MHz OSC Troubleshooting

Check the 600 MHz Output on the A1 board


The 600 MHz Output path is shown in Figure 4-5.

Figure 4-5 600 MHz OSC section simplified Block Diagram



1. Turn the 43521A power off and disconnect the RF cable from the A1 connector J4. The connector location is shown in Figure 4-6.

Figure 4-6 A1 connector J4 Location




43521ase016

2. Connect a 3.5mm(m)-3.5mm(m) cable (+ 3.5mm(f)-N(m) adapter) between the J4 connector of the A1 and the RF IN connector of the 4352B. Connect a BNC Cable between the 40 MHz Input of the 43521A and the 40 MHz Output of the 4352B.
3. Turn the 43521A power on, and press **[RF/LO]** and then confirm that the 43521A is not connected (**DOWNCONV on OFF**).
4. Press **[Meas]**, **INST TYPE**, **INST TYPE: VCO TESTER**, and **FREQUENCY** in this order. **FREQUENCY** is underlined, which indicates that the frequency measurement in the tester mode is selected.
5. Check that the measured value on the 4352B's screen is 600 MHz \pm 64 kHz.
6. Press **[MEAS]**, **RF POWER**.
7. Check that the measured value on the 4352B's screen is 8 dBm or more.
 - If the measured values (frequency and power) are not within these limits, replace the A1 board.
 - If the measured values (frequency and power) are within these limits, check the signal path between the J4 of the A1 and the LO OUT (Front) connector. The path consists of the RF cable, the coaxial switch and the RF cable.

Power Measurement Function Troubleshooting


The power measurement function is shown in Figure 4-7.

Figure 4-7 Power Measurement Section Simplified Block Diagram



1. Turn the 43521A power off and disconnect the RF cable from the A1 connector J5. The connector location is shown in Figure 4-8.

Figure 4-8 A1 connector J5 Location




43521ase017

2. Connect a N-N cable between the LO OUT connector and the RF IN connector of the 43521A. Connect a 15-pin D-Sub cable (furnished with the 43521A) between the I/O PORT connector of the 43521A and the I/O PORT connector of the 4352B.
3. Turn the 43521A power on, and press **[RF/LO]** and then **DOWNCONV on OFF** to toggle it **DOWNCONV ON off**.
4. Press **[Meas]** and **FREQ BAND [xx-xx]** in this order, and then press **2.5-3.6G** on the frequency band menu. The selected frequency band softkey is underlined.
5. Press **[Sens Range]** and **RF ATTEN** in this order. Use **[↑]** and **[↓]** or the rotary knob to set the attenuator to 20 dB.
6. Check that the output voltage (DC, negative polarity) from the 8474C is -100 mV or more using a voltmeter. (ex. -110 mV is good.)
 - If the voltmeter reading is within the limit, replace the A1 board. (The A1 board can not detect the output voltage.)
 - If the voltmeter reading is not within the limit above, check the signal path between the J5 of the A1 and RF IN (Front) connector.
(Normally, the output power from the 11742A Blocking Capacitor is about -3 dBm when steps 1 through 5 are performed.)

Heterodyne Path Troubleshooting

The heterodyne path is shown in Figure 4-9.

Figure 4-9 Heterodyne Path Simplified Block Diagram




1. Turn the 43521A power off, and disconnect a RF semirigid cable from the mixer (PN: 0955-0665) IF output connector. The connector location is shown in Figure 4-10.

NOTE

Remove the two screws that secure the LPF (Low Pass Filter) before the semirigid cable is disconnected from the mixer IF output.

Figure 4-10 Mixer IF OUTPUT connector location



43521ase020

2. Connect the equipment as shown in Figure 4-2, and connect a 15-pin D-Sub cable (furnished with the 43521A) between the I/O PORT connector of the 43521A and the I/O PORT connector of the 4352B.
3. Turn the 43521A power on, and press **[Preset]** to initialize the 4352B, then set the 43521A/4352B as follows.

Setting

Instrument type: VCO Tester

Measurement mode: FREQUENCY

Down converter control: ON

Signal Generator max freq: 3 GHz

Frequency Band: 2.5 - 3.6 GHz

LO control: Manual

43521A RF Attenuator: 20 dB

Operation

[Meas] - INST TYPE - VCO TESTER

[Meas] - FREQUENCY

[RF/LO] - DOWNCONV ON off

[RF/LO] - SG MAX FREQ - [3] - [G/n]

[Meas] - FREQ BAND - 2.5-3.6G

[RF/LO] - LO CONTROL auto MAN

[Sense Range] - RF ATTEN - [2] - [0] - [x1]

Troubleshooting
Heterodyne Path Troubleshooting

4. Set signal generators as follows.

Instrument	Setting
RF signal generator	Freq: 3 GHz, Power: 0 dBm
LO signal generator	Freq: 2.376 GHz, Power: 10 dBm


5. Check signals from the mixer IF output using a spectrum analyzer.

- If three spectrums (RF, LO, and RF-LO) are traced on the analyzer's display but the result of the Check Heterodyne Path fails, check the path between the mixer IF output and RF OUT (Front) connector.
(Normally, the signal RF - LO goes through the LPF and the signal is amplified by the 0955-0689 Amp(gain 19 dB) when steps 1 through 4 are performed.)
- If the LO and RF-LO signals are not traced, check the path between the mixer LO connector and LO IN (Front) connector.
(Normally, the LO signal applied to the mixer LO connector is about 8 dBm when steps 1 through 4 are performed.)
- If the RF and RF-LO signals are not traced, check the path between the mixer RF connector and RF IN (Front) connector.
(Normally, the RF signal applied to the mixer RF connector is more than -18 dBm when steps 1 through 4 are performed.)

Local Doubler Path Troubleshooting

The local doubler path is shown in Figure 4-11.

Figure 4-11 Local Doubler Path Simplified Block Diagram



43521ase012

1. Turn the 43521A power off, disconnect the RF cable from the mixer (PN: 0955-0665) IF output connector. The connector location is shown in Figure 4-10.
2. Connect the equipment as shown in Figure 4-2, and connect a 15-pin D-Sub cable (furnished with the 43521A) between the I/O PORT connector of the 43521A and the I/O PORT connector of the 4352B.
3. Turn the 43521A power on, and press **[Preset]** to initialize the 4352B, then set the 43521A/4352B as follows.

Setting

Instrument type: VCO Tester

Measurement mode: FREQUENCY

Down converter control: ON

Signal Generator max freq: 3 GHz

Frequency Band: 2.5 - 3.6 GHz

LO control: Manual

43521A RF Attenuator: 20 dB

Operation

[Meas] - INST TYPE - VCO TESTER

[Meas] - FREQUENCY

[RF/LO] - DOWNCONV ON off

[RF/LO] - SG MAX FREQ - [3] - [G/n]

[Meas] - FREQ BAND - 3.1-6.6G

[RF/LO] - LO CONTROL auto MAN

[Sense Range] - RF ATTEN - [2] - [0] - [x1]

4. Set signal generators as follows.

Instrument	Setting
RF signal generator	Freq: 4.6 GHz, Power: 0 dBm
LO signal generator	Freq: 1.988 GHz, Power: 10 dBm

5. Check signals from the mixer IF output using a spectrum analyzer.

- If three spectrums (RF, LOx2, and RF-LOx2) are traced on the analyzer's display but the result of the Check Local Doubler Path fails, check the path between the mixer IF connector and RF OUT (Front) connector.
(Normally, the signal RF - LOx2 goes through the LPF and the signal is amplified by the 0955-0689 Amp(gain 19 dB) when steps 1 through 4 are performed.)
- If the LOx2 and RF-LOx2 signals are not traced, check the doubler path.
(Normally, the LOx2 signal applied to the mixer LO connector is about 8 dBm when steps 1 through 4 are performed.)
- If the RF and RF-LOx2 signals are not traced, check the path between the mixer RF connector and RF IN (Front) connector.
(Normally, the RF signal applied to the mixer RF connector is more than -18 dBm when steps 1 through 4 are performed.)

Performance/Function Tests Failure Troubleshooting

Perform the following procedure sequentially when any performance/function tests fail.

Perform Adjustments and Correction Constants

Table 4-3 gives the recommended adjustments and correction constants data when a performance/function test fails. If a performance/function test fails, you should perform the corresponding adjustments or correction constants function as shown in Table 4-3. If the tests still fail, refer to Table 4-4 and check the probable faulty assembly or section.

Note that this table lists some typical cases. In a few cases, other assemblies or parts may actually be faulty.

Table 4-3 Troubleshooting Information for Performance/Function Tests Failure 1

First Failed Test	Adjustments Correction Constants (CC)
RF Power Measurement Accuracy	RF Power Linearity CC RF Power Frequency CC
Input VSWR	None
600 MHz OSC Phase Noise	None
System Phase Noise	None

Table 4-4 Troubleshooting Information for Performance/Function Tests Failure 2

Failed Test	Probable Faulty assembly/section
RF Power Measurement Accuracy	A1 board assembly RF Power Measurement section Thermometer
Input VSWR	Path between RF IN and Input connector of Amp (PN: 0955-1115) Path between RF IN and 8474C.
600 MHz OSC Phase Noise	A1 board assembly
System Phase Noise	Amplifier of Heterodyne Path (PN: 0955-1115 or 0955-0689) Amplifier of Doubler Path (PN: 0955-1114)

Troubleshooting

Performance/Function Tests Failure Troubleshooting


5 **Theory of Operation**

This chapter describes the general overall operation of the 43521A. Detailed component-level circuit theory is not provided in this manual.

OVERALL OPERATION

The 43521A is used as part of the 4352S VCO/PLL Signal Test System. Figure 5-1 is a simplified block diagram of the VCO/PLL Signal Test System including the 43521A. Using the 43521A expands the maximum frequency of the VCO/PLL Signal Test system to 12.6 GHz.

Figure 5-1 VCO/PLL Signal Test System simplified block diagram



43521ase019

The 43521A has two signal paths. One is the direct path that is from the RF IN port of the 43521A to the RF IN port of the 4352B directly. The other is the heterodyne path which downconverts the RF input signal to the proper signal for the input of the 4352B. Since the level loss between the RF IN port and RF OUT port of the 43521A is calibrated, the power level related measurement such as RF power measurement can be performed properly. When the heterodyne path is selected, the external signal generator (SG) is used as the local signal generator for downconversion. The frequency doubler in the 43521A doubles the local signal from the SG so that the double frequency of the SG is maximum as the local signal. Then the built-in 600 MHz oscillator in the 43521A offers the local signal of the 4352B so that the VCO/PLL Signal Test system can perform the 12.6 GHz evaluation by using only one 6 GHz SG.

43521A BLOCK DIAGRAM


The 43521A consists of the following sections.

- Power Supply
- Sequencer & I/O (Digital Control)
- Power Measurement
- Heterodyne
- Local Drive
- 600 MHz OSC

Figure 5-2 shows the block diagram of the 43521A.

Theory of Operation
OVERALL OPERATION


Figure 5-2 43521A Block Diagram



Power Supply Section

The power supply section block diagram is shown in Figure 5-3.

Figure 5-3 Power Supply Section Block Diagram



43521ase007

The power supply unit (PN: 0950-3642) produces approximately +5Vdc, +15Vdc, and -15Vdc. These dc voltages are applied to the A1 board assembly (PN: 43521-66501). The +5Vdc is supplied to the digital section of the A1 board, and is supplied to the LED, FAN, Coaxial Switches, and the step attenuator through the A1. The +15 Vdc is supplied to the A1 to produce regulated +12 V and +5 V for the A/D converter section and the 600 MHz OSC section of the A1. The +15 Vdc is also supplied to the three amplifiers in the 43521A through the A1 board. The -15 Vdc is supplied to the A1 to produce regulated -12V and -5V for the A/D converter section and the 600MHz OSC section of the A1.

Sequencer & I/O (Digital Control) Section

This section provides digital control for the 43521A. It communicates with the 4352B via the I/O PORT, in order to control the switches, the step attenuator in the 43521A, and transfer the measurement data (raw data) in the 43521A to the 4352B for RF power measurement. This section has EEPROM which stores the correction constants data for the 43521A. The correction constants data is also transferred to the 4352B via the I/O port, and is used for the RF power measurement. All operations of the 43521A are controlled by the 4352B via the I/O section.

Power Measurement Section

This section measures the RF input power level for RF Power Measurement. It has Peak Detector (8474C) which converts the RF power into DC voltage (negative polarity). The DC voltage is supplied to the A/D converter of the A1 board. The A/D converter converts the DC voltage into digital data. This section also has the Thermometer which is used to

measure the temperature around the Peak Detector, and to compensate the RF power value of the Peak Detector with the Thermometer reading value.

Heterodyne Section

This section converts the RF signal from the RF IN (Front) of the 43521A into the IF signal (624 MHz). To convert the RF signal into the IF signal, a local signal source is required. The frequency of the local signal for mixing the 624 MHz IF signal depends on the RF signal, and is detected by the 4352B. The mixer (0955-0665) of the heterodyne section outputs the 624 MHz signal and other frequency signals, and these signals are applied to the next low pass filter (PN: 9135-0229, cut-off frequency is 800 MHz). Then only 624 MHz IF signal passes the low pass filter, and the signal is supplied to the RF OUT of the 43521A.

Local Drive Section

This section supplies the local signal to the mixer (0955-0665) of the heterodyne section. It has two signal paths. One is the direct path that is from the LO IN of the 43521A to the input port of the mixer directly. The other is doubler path which doubles the frequency of the local signal from the LO IN. The heterodyne section can convert the RF signal (up to 12.6 GHz) to the IF signal (624 MHz) with only one SG (up to 6 GHz) by using the doubler path.

600 MHz OSC Section

This section produces the 600 MHz signal for the 4352B Local signal. The signal is a low phase noise signal. To improve the frequency accuracy of the 600 MHz signal, the 40 MHz signal from the rear panel of the 4352B is inputted. It provides phase locking for synchronizing the 600 MHz signal to the 40 MHz signal.

6 **Parts Replacement**

This chapter contains the 43521A's replaceable parts list and the procedure to replace its assemblies.

Replaceable Part List

Ordering Information

To order part listed in the replaceable part lists, quote the Agilent Technologies part number (with a check digit), indicate the quantity required, and address the order to the nearest Agilent Technologies office. The check digit will ensure accurate and timely processing of the order.

To order a part not listed in the replaceable part table, include the instrument model number, the description and function of the part, and the quantity of parts required. Address the order to the nearest Agilent Technologies office.

Direct Mail Order System

Within the USA, Agilent Technologies can supply parts through a direct mail order system. There are several advantages to this system:






- Direct ordering and shipping from the Agilent Technologies Parts Center in Mountain View, California.
- No maximum or minimum on any mail order (there is a minimum order amount for parts ordered through a local Agilent Technologies office when the orders require billing and invoicing)
- Prepaid transportation (there is a small handling charge for each order).
- No invoices.

In order for Agilent Technologies to provide these advantages, please send a check or money order with each order.

Mail order forms and specific ordering information are available through your local Agilent Technologies sales office. Addresses and telephone numbers are located in a separate document shipped with the manuals.


Parts List

Figure 6-1 Power Cables and Plug Configurations

<p>OPTION 900</p>  <p>United Kingdom</p> <p>Plug : BS 1363/A, 250V, 10A Cable: 8120-1351</p>	<p>OPTION 901</p>  <p>Australia/ New Zealand</p> <p>Plug : AS 3112, 250V, 10A Cable: 8120-1369</p>
<p>OPTION 902</p>  <p>Continental Europe</p> <p>Plug : CEE 7 Standard Sheet VII, 250V, 10A Cable: 8120-1689</p>	<p>OPTION 903</p>  <p>U.S./ Canada</p> <p>Plug : NEMA 5-15P, 125V, 10A Cable: 8120-1378</p>
<p>OPTION 904</p>  <p>U.S./ Canada</p> <p>Plug : NEMA 6-15P, 250V, 6A Cable: 8120-0698</p>	<p>OPTION 906</p>  <p>Switzerland</p> <p>Plug : SEV Type 12, 250V, 10A Cable: 8120-2104</p>
<p>OPTION 912</p>  <p>Denmark</p> <p>Plug : SR 107-2-D, 250V, 10A Cable: 8120-2956</p>	<p>OPTION 917</p>  <p>India/ Republic of S.Africa</p> <p>Plug : IEC 83-B1, 250V, 10A Cable: 8120-4211</p>
<p>OPTION 918</p>  <p>Japan</p> <p>Plug : JIS C 8303, 125V, 12A Cable: 8120-4753</p>	<p>OPTION 920</p>  <p>Argentina</p> <p>Plug : Argentine Resolution 63, Annex IV, 250V, 10A Cable: 8120-6870</p>
<p>OPTION 921</p>  <p>Chile</p> <p>Plug : CEI 23-16, 250V, 10A Cable: 8120-6978</p>	<p>OPTION 922</p>  <p>China</p> <p>Plug : GB 1002, 250V, 10A Cable: 8120-8376</p>
<p>NOTE: Each option number includes a 'family' of cords and connectors of various materials and plug body configurations (straight, 90° etc.).</p>	

OPT9XXE_agi

Figure 6-2 Top View (Major Assemblies)




43521ase027

Table 6-1 Top View (Major Assemblies)

Reference Designation	Agilent Part Number	Check Digit	Qty.	Description
1	43521-66501	0	1	A1 Board
2	0950-3642	7	1	Power Supply
3	33321-60059	8	1	Step ATT
4	5088-7049	2	1	LIMITER 26.5 GHz
5	0955-1115	5	1	U-WAVE AMP 18 GHz
6	1250-1159	4	2	Adapter- Coaxial
7	8493B#003	8	3	Attenuator 3dB
8	0955-0665	8	1	U-WAVE MXR 26.5 GHz
9	0955-1114	4	1	U-WAVE AMP 20 GHz
10	0955-0693	2	1	U-WAVE FREQ DBLR
11	33312-60005	3	3	COAX IAL SWITCH
	0515-1057	2	6	Screw
12	9135-0229	1	1	U-WAVE LPF
13	8474C	6	1	DETECTOR
14	11742A	8	1	BLOCKING CAP
15	11636B	1	1	POWER DIVIDER
16	0955-0689	6	1	U-WAVE AMP 700MHz

Parts Replacement
Replaceable Part List

Figure 6-3 Top View (Cables and Wires 1/2)




43521ase028

Table 6-2 Top View (Cables and Wires 1/2)

Reference Designation	Agilent Part Number	Check Digit	Qty.	Description
J1	43521-61620	4	1	WIRE ASSY
J3	43521-61622	6	1	RF CABLE ASSY
J4	43521-61623	7	1	RF CABLE ASSY
J5	43521-61624	8	1	RF CABLE ASSY
J6	43521-61625	9	1	WIRE ASSY
J7	43521-61626	0	1	WIRE ASSY
J9	43521-61648	6	1	WIRE ASSY (Yellow)
J10	43521-61629	3	1	WIRE ASSY (Green)
J11	43521-61630	6	1	WIRE ASSY (Blue)
J12	43521-61633	9	1	WIRE ASSY
J13	43521-61631	7	1	WIRE ASSY
J14	43521-61632	8	1	WIRE ASSY

Figure 6-4 Top View (Cables and Wires 2/2)




43521ase029

Table 6-3 Top View (Cables and Wires 2/2)

Reference Designation	Agilent Part Number	Check Digit	Qty.	Description
1	43521-61635	1	2	RF CABLE ASSY
2	43521-61645	3	1	RF CABLE ASSY SRGD (Divider - Switch)
3	43521-61643	1	1	RF CABLE ASSY SRGD (RF IN - Switch)
4	43521-61604	4	1	RF CABLE ASSY SRGD (RF OUT - Switch)
5	43521-61606	6	1	RF CABLE ASSY SRGD (Mixer - LPF)
6	43521-61607	7	1	RF CABLE ASSY SRGD (Switch - Switch)
7	43521-61601	1	1	RF CABLE ASSY SRGD (LO IN - Switch)
8	43521-61602	2	1	RF CABLE ASSY SRGD (LO OUT - Switch)
9	43521-61608	8	1	RF CABLE ASSY SRGD (DBLR - Switch)
10	43521-61609	9	1	RF CABLE ASSY SRGD (AMP - DBLR)
11	43521-61610	2	1	RF CABLE ASSY SRGD (AMP- Switch)
12	43521-61611	3	1	RF CABLE ASSY SRGD (Mixer - Switch)

Parts Replacement
Replaceable Part List

Figure 6-5 Top View (Miscellaneous Parts)




43521ase030

Table 6-4 Top View (Miscellaneous Parts)

Reference Designation	Agilent Part Number	Check Digit	Qty.	Description
1	43521-61637	3	1	Wire Assy with Power SW
	0515-0905	7	2	Screw
	2190-0583	9	2	Spring Washer
2	43521-01209	9	1	Angle (for Wire Assy)
	0515-1550	0	2	Screw
3	04192-40002	1	1	Coupler
4	0400-0064	6	2	Bushing
5	43521-25001	9	1	Rod
6	43521-00101	8	1	Chassis
7	43521-00102	9	1	Chassis Sub
8	5041-0564	4	1	Key Cap
9	0515-0889	6	4	Screw
10	0363-0125	0	2	Shield Gasket (152 mm)
11	0515-1550	0	6	Screw
12	0515-1550	0	9	Screw
13	0515-2079	0	4	Screw
14	0515-1550	0	4	Screw

Parts Replacement
Replaceable Part List

Figure 6-6 Bottom View (Miscellaneous Parts)




43521ase036

Table 6-5 Bottom View (Miscellaneous Parts)

Reference Designation	Agilent Part Number	Check Digit	Qty.	Description
1	0363-0125	0	2	Shield Gasket (152 mm)
2	0515-0889	6	4	Screw
3	0515-2079	0	4	Screw

Figure 6-7 FRONT Assembly




43521ase032

Table 6-6 FRONT Assembly

Reference Designation	Agilent Part Number	Check Digit	Qty.	Description
1	43521-00202	0	1	Panel Front Sub (Hidden)
2	5061-5386	0	4	Connector Type-N
	2190-0104	0	4	WSHR-LK INTL T
	2950-0132	6	4	NUT-HEX-DUB-CHAM
3	42841-66575	3	1	PC BD ASSY DSPL (with LED) (Hidden)
4	43521-00201	9	1	Panel Front

Parts Replacement
Replaceable Part List

Figure 6-8 REAR Assembly




43521ase031

Table 6-7 REAR Assembly

Reference Designation	Agilent Part Number	Check Digit	Qty.	Description
1	43521-00203	1	1	Panel Rear
2	6960-0081	9	1	Plug Hole
3	1250-0102	5	1	Connector RF BNC
	2190-0054	9	1	WSHR-LK INTL T
	2950-0054	1	1	NUT-HEX-DBL-CHAM
4	43521-61621	5	1	FLAT CBL ASSY
	1251-5436	0	2	SCREW LOCK KIT
5	43521-61627	1	1	FAN CABLE ASSY
	2190-0584	0	4	WSHR-LK HLCL
	0515-3149	7	4	SCREW-MACH M3 L33
6	1252-6951	8	1	AC INLET
	2110-0381	7	1	FUSE 3A 250V
	2110-1134	0	1	FUSE DRAWER

Figure 6-9 Cover (Top/Bottom)




43521ase039

Table 6-8 Cover (Top/Bottom)

Reference Designation	Agilent Part Number	Check Digit	Qty.	Description
1	5021-5832	0	4	Shield Gasket (152 mm)
2	5002-1047	8	1	Cover Top
3	5002-1088	7	1	Cover Bottom

Figure 6-10 Chassis Parts




43521ase038

Table 6-9 Chassis Parts

Reference Designation	Agilent Part Number	Check Digit	Qty.	Description
1	5002-3736	6	1	Side Cover
2	08751-07001	5	4	Gasket
3	5063-9210	1	1	Strap Handle
4	5041-9186	4	1	Front Cap
5	5041-9187	5	1	Rear Cap
6	0515-1132	4	2	Screw M5
7	5002-3959	5	1	Side Cover
8	5041-9167	1	4	Foot
9	1460-1345	5	2	Wire Form
10	5041-9188	6	4	Standoff
11	0515-1232	5	4	Screw M3.5

Figure 6-11 Chassis Parts




43521ase037

Table 6-10 Chassis Parts

Reference Designation	Agilent Part Number	Check Digit	Qty.	Description
1	5021-5832	7	2	Side Strut
2	5021-5802	1	1	Rear Frame
3	0515-1668	1	8	Screw
4	5022-1187	9	1	Front Frame

Figure 6-12 Step Attenuator Assembly




43521ase049

Table 6-11 Step Attenuator Assembly

Reference Designation	Agilent Part Number	Check Digit	Qty.	Description
1	33321-60059	8	1	Step ATT
2	43521-00607	9	1	Plate (for Step ATT)
3	2200-0142	0	2	Screw
4	0515-1550	0	2	Screw M3
5	3050-0891	7	2	Washer

Figure 6-13 U-WAVE AMP 18 GHz Assembly




43521ase045

Table 6-12 U-WAVE AMP 18 GHz Assembly

Reference Designation	Agilent Part Number	Check Digit	Qty.	Description
1	0955-1115	5	1	U-WAVE AMP 18 GHz
2	0180-3597	8	1	CAP 47uF
3	43521-01201	1	1	Angle (for AMP)
4	0520-0173	2	2	Screw
5	0515-1550	0	4	Screw M3
6	43521-25002	0	1	Insulator

Figure 6-14 U-WAVE MXR 26.5 GHz Assembly




43521ase044

Table 6-13 U-WAVE MXR 26.5 GHz Assembly

Reference Designation	Agilent Part Number	Check Digit	Qty.	Description
1	0955-0665	8	1	U-WAVE MXR 26.5 GHz
2	0460-0751	4	1	TAPE-INDL (40 mm x 25 mm x 2)
3	43521-00606	8	1	Plate (for MXR)
4	0515-1550	0	2	Screw

Figure 6-15 U-WAVE AMP 20 GHz Assembly




43521ase042

Table 6-14 U-WAVE AMP 20 GHz Assembly

Reference Designation	Agilent Part Number	Check Digit	Qty.	Description
1	0955-1114	4	1	U-WAVE AMP 20 GHz
2	0180-3597	8	1	CAP 47uF
3	43521-01207	7	1	Angle (for AMP)
4	0520-0173	2	1	Screw
5	0520-0174	3	1	Screw
6	0515-1550	0	2	Screw M3
7	43521-25002	0	1	Insulator

Figure 6-16 U-WAVE FREQ DBLR Assembly




43521ase043

Table 6-15 U-WAVE FREQ DBLR Assembly

Reference Designation	Agilent Part Number	Check Digit	Qty.	Description
1	0955-0693	2	1	U-WAVE FREQ DBLR
2	43521-01202	2	1	Angle (for DBLR)
3	0515-1057	2	2	Screw M2.5
4	0515-1550	2	4	Screw

Figure 6-17 U-WAVE LPF Assembly




43521ase046

Table 6-16 U-WAVE LPF Assembly

Reference Designation	Agilent Part Number	Check Digit	Qty.	Description
1	9135-0229	1	1	U-WAVE LPF
2	1400-2299	4	2	CLAMP HOLDER
3	0380-1795	8	2	STAND-OFF
4	0515-1087	8	2	Screw

Figure 6-18 **DETECTOR Assembly**




43521ase050

Table 6-17 **DETECTOR Assembly**

Reference Designation	Agilent Part Number	Check Digit	Qty.	Description
1	8474C	6	1	DETECTOR
2	43521-61625	9	1	Wire Assy
3	43521-01210	1	1	Angle (for DETECTOR)
4	0515-1550	0	2	Screw
5	3050-0891	7	2	Washer

Figure 6-19 U-WAVE AMP 700 MHz Assembly



43521ase048

Table 6-18 U-WAVE AMP 700 MHz Assembly

Reference Designation	Agilent Part Number	Check Digit	Qty.	Description
1	0955-0689	6	1	U-WAVE AMP 700 MHz
2	0180-3597	8	1	CAP 47 uF
3	0515-1426	9	2	Screw
4	3050-0229	5	2	Washer
5	43521-25002	0	1	Insulator

Replacement Procedure

This Chapter describes how to replace the 43521A major assemblies. The cover and panel removal procedures that are required for some assembly replacements are described first. Then the replacement procedures for each major assembly are described.

Top Cover Removal

Tools Required

- Torx screwdriver, T15
- Pozidriv Screwdriver, pt size #2 (medium)

Procedure

1. Disconnect the power cable from the 43521A.
2. Remove the two rear feet behind the top cover.
3. Loosen the top cover rear screw.
4. Slide the top cover toward the rear and lift it off.

Bottom Cover Removal

Tools Required

- Torx screwdriver, T15
- Pozidriv Screwdriver, pt size #2 (medium)

Procedure

1. Disconnect the power cable from the 43521A.
2. Place the 43521A upside down.
3. Remove the two rear feet behind the bottom cover.
4. Loosen the bottom cover rear screw.
5. Slide the bottom cover toward the rear and lift it off.

Side Cover Removal

Tools Required

- Torx screwdriver, T15
- Pozidriv Screwdriver, pt size #2 (medium)

Procedure (for right side cover)

1. Remove the top cover and the bottom cover as described in the “Top Cover Removal” and “Bottom Cover Removal” procedures.

Parts Replacement Replacement Procedure

2. Remove the screw at the rear frame.
3. Slide off the side cover toward the rear.

Procedure (for left side cover)

1. Remove the top cover and the bottom cover as described in the “Top Cover Removal” and “Bottom Cover Removal” procedures.
2. Remove the two screws at the side strap handle caps to remove the strap.
3. Slide off the side cover toward the rear.

Front Panel Removal

Tools Required

- Torx screwdriver, T15
- Pozidriv Screwdriver, pt size #2 (medium)
- Flat bladed screwdriver.

Procedure

1. Disconnect the power cable from the 43521A.
2. Place the 43521A upside down.
3. Remove the four screws from the bottom of the front frame.
4. Turn the 43521A over into the correct position.
5. Remove the top trim strip from the front frame by prying the strip up with a flat screwdriver.
6. Remove the four screws from the top of the front frame.
7. Remove the top cover as described in the “Top Cover Removal” procedure.
8. Disconnect the cables connecting the front panel.
9. Gradually press the front panel assembly from the inside, and remove the front panel.

Rear Panel Removal

Tools Required

- Torx screwdriver, T15
- Pozidriv Screwdriver, pt size #1 (small), #2 (medium)

Procedure

1. Remove the top, bottom, and side covers as described in the “Top Cover Removal”, “Bottom Cover Removal” and “Side Cover Removal” procedures.
2. Place the 43521A upside down.
3. Remove the four screws from the bottom of the rear frame.

4. Turn over the 43521A into the correct position.
5. Remove the four screws from the top of the rear frame.
6. Gradually pull the rear panel assembly out from the rear frame.

Step Attenuator Replacement

Tools Required

- Torx screwdriver, T15
- Pozidriv Screwdriver, pt size #1 (small), #2 (medium)
- Open-end wrench, 5/16-inch
Open-end torque wrench, 5/16-inch (set to 10 in-lb) (for reconnecting SMA connector)
- Adjustable Wrench (for Coaxial Connector)

Removal Procedure

1. Remove the top cover as described in the “Top Cover Removal” procedure.
2. Remove the two screws that secure the plate (for Step Att) to the Chassis Sub.
3. Disconnect the SMA connector of the 1250-1159 Adapter and the SMA connector of the 5088-7049 Limiter from the step attenuator’s connectors (female). To loosen the SMA connector, grip flat faces of the part (Adapter or Limiter) with the adjustable wrench to keep the part steady.
4. Disconnect the ribbon cable for the step attenuator from the A1 J15 connector.
5. Remove the two screws that secure the step attenuator to the plate (for Step Att).

U-WAVE AMP 18 GHz Replacement

Tools Required

- Torx screwdriver, T15
- Pozidriv Screwdriver, pt size #1 (small), #2 (medium)
- Open-end wrench, 5/16-inch
Open-end torque wrench, 5/16-inch (set to 10 in-lb) (for reconnecting SMA connector)
- Adjustable Wrench (for Coaxial Connector)

Removal Procedure

1. Remove the top cover as described in the “Top Cover Removal” procedure.
2. Remove the two screws that secure the plate (for Step Att) to the Chassis Sub.
3. Disconnect the SMA connector of the 5088-7049 Limiter from the U-Wave amplifier’s connector (IN side) and the SMA connector of the 1250-1159 Adapter from the 11636B Power Divider’s connector. To loosen the SMA connector, grip flat faces of the part (Adapter or Limiter) with the adjustable wrench to keep the part steady.
4. Remove the four screws that secure the angle (for AMP) to the Chassis Sub.
5. Disconnect the SMA connector of the 1250-1159 Adapter from the U-Wave

Parts Replacement Replacement Procedure

amplifier's connector (OUT side). To loosen the SMA connector, grip the flat faces of the adapter with the adjustable wrench to keep the adapter steady.

6. Disconnect the WIRE Assy for the amplifier from the A1 J12 connector.
7. Remove the two screws that secure the amplifier to the angle (for AMP).

U-WAVE MXR 26.5 GHz Replacement

Tools Required

- Torx screwdriver, T15
- Pozidriv Screwdriver, pt size #1 (small), #2 (medium)
- Open-end wrench, 5/16-inch
Open-end torque wrench, 5/16-inch (set to 10 in-lb) (for reconnecting SMA connector)
- Adjustable Wrench (for Coaxial Connector)

Removal Procedure

1. Remove the top cover as described in the "Top Cover Removal" procedure.
2. Disconnect the RF Cable 43521-61610 (AMP - Switch) from the Coaxial Switch.
3. Disconnect the RF Cable 43521-61611 (Mixer - Switch) from the mixer's connector (LO side).
4. Remove the two screws that secure the LPF to the Chassis Sub.
5. Disconnect the RF Cable 43521-61606 (Mixer - LPF) from the mixer's connector (IF side).
6. Remove the two screws that secure the mixer to the Chassis Sub.
7. Disconnect the SMA connector of the 8493B Fixed Attenuator from the mixer's connector (RF side). To loosen the SMA connector, grip flat faces of the fixed attenuator with the adjustable wrench to keep the fixed attenuator steady.

U-WAVE AMP 20 GHz Replacement

Tools Required

- Torx screwdriver, T15
- Pozidriv Screwdriver, pt size #1 (small), #2 (medium)
- Open-end wrench, 5/16-inch
Open-end torque wrench, 5/16-inch (set to 10 in-lb) (for reconnecting SMA connector)

Removal Procedure

1. Remove the top cover as described in the "Top Cover Removal" procedure.
2. Remove the two screws that secure the angle (for AMP) to the Chassis Sub.
3. Disconnect the RF Cable 43521-61610 (AMP - Switch) from the amplifier's connector (OUT side).
4. Disconnect the RF Cable 43521-61609 (AMP - DBLR) from the amplifier's connector

(IN side).

5. Disconnect the WIRE Assy for the amplifier from the A1 J14 connector
6. Remove the screw (S side) and screw (L side) that secure the amplifier to the angle (for AMP).

U-WAVE FREQ DBLR Replacement

Tools Required

- Torx screwdriver, T15
- Pozidriv Screwdriver, pt size #1 (small), #2 (medium)
- Open-end wrench, 5/16-inch
Open-end torque wrench, 5/16-inch (set to 10 in-lb) (for reconnecting SMA connector)

Removal Procedure

1. Remove the top cover as described in the “Top Cover Removal” procedure.
2. Remove the two screws that secure the angle (for AMP 20 GHz) to the Chassis Sub.
3. Disconnect the RF Cable 43521-61609 (AMP - DBLR) from the doubler’s connector (OUT side).
4. Disconnect the RF Cable 43521-61608 (DBLR - Switch) from the doubler’s connector (IN side)
5. Remove the two screws that secure the doubler to the angle (for DBLR).

U-WAVE AMP 700 MHz Replacement

Tools Required

- Torx screwdriver, T15
- Pozidriv Screwdriver, pt size #1 (small), #2 (medium)
- Open-end wrench, 5/16-inch
Open-end torque wrench, 5/16-inch (set to 10 in-lb) (for reconnecting SMA connector)

Removal Procedure

1. Remove the top cover as described in the “Top Cover Removal” procedure.
2. Disconnect the RF Cable 43521-61635 (AMP - LPF) from the amplifier’s connector (IN side).
3. Disconnect the RF Cable 43521-61635 (AMP - Switch) from the amplifier’s connector (OUT side)
4. Disconnect the WIRE Assy for the amplifier from the A1 J13 connector.
5. Remove the two screws and washers that secure the amplifier to the Chassis Sub.

Parts Replacement
Replacement Procedure

POST REPAIR PROCEDURES

Table 7-1 *Post Repair Procedures* lists the required procedures that must be performed after the replacement of an assembly or a part. These are the recommended minimum procedures to ensure that the replacement is successfully completed.

When you replace an assembly or a part, perform the adjustments and updating correction constants (CC) in Table 7-1 sequentially. Then perform the operational verifications and performance verifications listed in Table 7-1.

For the detailed procedure of the adjustments and updating correction constants, see *Adjustments* Chapter. For the detailed operational verification procedures, see this manual's chapter specified in Table 7-1. For detailed performance verification procedures, see *Performance Test* or *Troubleshooting* Chapter in this manual.

Table 7-1 Post Repair Procedures

Replaced Assembly or Part	Adjustments Correction Constants (CC)	Verification
A1 board	600 MHz SAW OSC Frequency Writing Default CC RF Power Linearity CC RF Power Frequency CC	Check 600 MHz Output ^{*1} RF Power Measurement Accuracy Test 600 MHz OSC Phase Noise Test System Phase Noise
43521-61625 (Thermometer)	RF Power Linearity CC RF Power Frequency CC	RF Power Measurement Accuracy Test
8474C (Power Detector)	RF Power Linearity CC RF Power Frequency CC	Check Power Measurement Function ^{*1} RF Power Measurement Accuracy Test Input VSWR Test
11742A (Blocking Capacitor)	RF Power Linearity CC RF Power Frequency CC	Check Power Measurement Function ^{*1} RF Power Measurement Accuracy Test Input VSWR Test
8493B(between 11742A and 11636B) (Fixed Att. 3dB)	RF Power Linearity CC RF Power Frequency CC	Check Power Measurement Function ^{*1} RF Power Measurement Accuracy Test Input VSWR Test
8493B(between 11636B and SW1) (Fixed Att. 3dB)	RF Power Linearity CC RF Power Frequency CC	Check Power Measurement Function ^{*1} RF Power Measurement Accuracy Test Input VSWR Test
11636B (Power Divider)	RF Power Linearity CC RF Power Frequency CC	Check Power Measurement Function ^{*1} Check Heterodyne Path ^{*1} RF Power Measurement Accuracy Test Input VSWR Test
33321-60059 (Step Att.)	RF Power Linearity CC RF Power Frequency CC	Check Heterodyne Path ^{*1} RF Power Measurement Accuracy Test Input VSWR Test

Table 7-1 Post Repair Procedures

Replaced Assembly or Part	Adjustments Correction Constants (CC)	Verification
5088-7049 (Limiter)	RF Power Linearity CC RF Power Frequency CC	Check Heterodyne Path ^{*1} RF Power Measurement Accuracy Test Input VSWR Test
0955-1115 (Amplifier)	RF Power Linearity CC RF Power Frequency CC	Check Heterodyne Path ^{*1} RF Power Measurement Accuracy Test Input VSWR Test System Phase Noise Test
8493B(between Amp. and Mixer) (Fixed Att. 3dB)	RF Power Frequency CC	Check Heterodyne Path ^{*1}
0955-0665 (Mixer)	RF Power Frequency CC	Check Heterodyne Path ^{*1}
9135-0229 (Low Pass Filter)	RF Power Frequency CC	Check Heterodyne Path ^{*1}
0955-0689 (Amplifier)	RF Power Frequency CC	Check Heterodyne Path ^{*1} System Phase Noise Test
0955-1114 (Amplifier)	RF Power Frequency CC	Check Local Doubler Path ^{*1} System Phase Noise Test
0955-0693 (Doubler)	RF Power Frequency CC	Check Local Doubler Path ^{*1} System Phase Noise Test
33312-60005 (SW1) (Coaxial Switch)	RF Power Linearity CC RF Power Frequency CC	Check Power Measurement Function ^{*1} RF Power Measurement Accuracy Test Input VSWR Test
33312-60005 (SW2) (Coaxial Switch)	600 MHz SAW OSC Frequency	Check 600 MHz Output ^{*1}
33312-60005 (SW3) (Coaxial Switch)	RF Power Frequency CC	Check Heterodyne Path ^{*1} Check Local Doubler Path ^{*1} System Phase Noise Test

*1. See the Troubleshooting chapter.

Post Repair Procedures
POST REPAIR PROCEDURES

Manual Changes

To adapt this manual to your 43521A, refer to Table A-1.

Table A-1 Manual Changes by Serial Number

Serial Prefix or Number	Make Manual Changes
JP1KG00149 or below except JP1KG143/146	Change 1

Agilent Technologies uses a two-part, ten-character serial number that is stamped on the serial number plate (see Figure A-1). The first five characters are the serial prefix and the last five digits are the suffix.

Figure A-1 Serial Number Plate



CD000A01

Change 1

Change the description according to pages 112 through 133.

Page 57, Check Heterodyne Path

Replace the description for the step 5 with the following description:

5. Press **[RF/LO]** and then **DOWNCONV ON off** to toggle it **DOWNCONV on OFF** and press **[Meas] - RF POWER**, then check that the 4352B reading is more than -2 dBm.
 - If the 4352B reading is not within the limit, continue with *Heterodyne Path Troubleshooting*.
 - If the 4352B reading is within the limit, the heterodyne path is verified.

Page 57, Check Local Doubler Path


Replace the description for the step 5 with the following description:

5. Press **[RF/LO]** and then **DOWNCONV ON off** to toggle it **DOWNCONV on OFF** and press **[Meas] - RF POWER**, then check that the 4352B reading is more than -2 dBm.
 - If the 4352B reading is not within the limit, continue with *Local Doubler Path Troubleshooting*.
 - If the 4352B reading is within the limit, the local doubler path is verified.

Page 64, Figure 4-7 Power Measurement Section Simplified Block Diagram

Replace the figure with the following figure:


Figure A-2 Power Measurement Section Simplified Block Diagram



Page 66, Figure 4-9 Heterodyne Path Simplified Block Diagram

Replace the figure with the following figure:

Figure A-3 Heterodyne Path Simplified Block Diagram



43521ase025

Page 68, Heterodyne Path Troubleshooting

Replace the description for the step 5 with the following description:

5. Check signals from the mixer IF output using a spectrum analyzer.

- If three spectrums (RF, LO, and RF-LO) are traced on the analyzer's display but the result of the Check Heterodyne Path fails, check the path between the mixer IF output and RF OUT (Front) connector.
(Normally, the signal RF - LO goes through the LPF and the signal is amplified by the 0955-0689 Amp(gain 19 dB) when steps 1 through 4 are performed.)
- If the LO and RF-LO signals are not traced, check the path between the mixer LO connector and LO IN (Front) connector.
(Normally, the LO signal applied to the mixer LO connector is about 8 dBm when steps 1 through 4 are performed.)
- If the RF and RF-LO signals are not traced, check the path between the mixer RF connector and RF IN (Front) connector.
(Normally, the RF signal applied to the mixer RF connector is more than -13 dBm when steps 1 through 4 are performed.)

Page 70, Local Doubler Path Troubleshooting


Replace the description for the step 5 with the following description:

5. Check signals from the mixer IF output using a spectrum analyzer.
 - If three spectrums (RF, LOx2, and RF-LOx2) are traced on the analyzer's display but the result of the Check Local Doubler Path fails, check the path between the mixer IF connector and RF OUT (Front) connector.
(Normally, the signal RF - LOx2 goes through the LPF and the signal is amplified by the 0955-0689 Amp(gain 19 dB) when steps 1 through 4 are performed.)
 - If the LOx2 and RF-LOx2 signals are not traced, check the doubler path.
(Normally, the LOx2 signal applied to the mixer LO connector is about 8 dBm when steps 1 through 4 are performed.)
 - If the RF and RF-LOx2 signals are not traced, check the path between the mixer RF connector and RF IN (Front) connector.
(Normally, the RF signal applied to the mixer RF connector is more than -13 dBm when steps 1 through 4 are performed.)

Page 76, Figure 5-2 43521A Block Diagram

Replace the figure with the following figure:

Figure A-4 43521A Block Diagram




43521ase005

Page 82, Figure 6-2 Top View (Major Assemblies)

Replace the figure with the following figure:

Figure A-5 Top View (Major Assemblies)



43521ase034

Page 83, Table 6-1 Top View (Major Assemblies)

Change the table as follows:

Table A-2 Top View (Major Assemblies)


Reference Designation	Agilent Part Number	Check Digit	Qty.	Description
1	43521-66501	0	1	A1 Board
2	0950-3642	7	1	Power Supply
3	33321-60059	8	1	Step ATT
4	8493B#003	8	1	Attenuator 3dB
5	0955-1115	5	1	U-WAVE AMP 18 GHz
6	1250-1159	4	3	Adapter- Coaxial
7	8493B#006	7	1	Attenuator 6dB
8	0955-0665	8	1	U-WAVE MXR 26.5 GHz
9	0955-1114	4	1	U-WAVE AMP 20 GHz
10	0955-0693	2	1	U-WAVE FREQ DBLR
11	33312-60005	3	3	COAX IAL SWITCH
12	9135-0229	1	1	U-WAVE LPF
13	8474C	6	1	DETECTOR
14	11742A	8	1	BLOCKING CAP
15	11636B	1	1	POWER DIVIDER
16	0955-0689	6	1	U-WAVE AMP 700MHz

Manual Changes
Change 1

Page 84, Figure 6-3 Top View (Cables and Wires 1/2)

Replace the figure with the following figure:

Figure A-6 Top View (Cables and Wires 1/2)



43521ase035

Page 85, Table 6-2 Top View (Cables and Wires 1/2)

Change the table as follows:

Table A-3 Top View (Cables and Wires 1/2)


Reference Designation	Agilent Part Number	Check Digit	Qty.	Description
J1	43521-61620	4	1	WIRE ASSY
J3	43521-61622	6	1	RF CABLE ASSY
J4	43521-61623	7	1	RF CABLE ASSY
J5	43521-61624	8	1	RF CABLE ASSY
J6	43521-61625	9	1	WIRE ASSY
J7	43521-61626	0	1	WIRE ASSY
J9	43521-61628	2	1	WIRE ASSY (Yellow)
J10	43521-61629	3	1	WIRE ASSY (Green)
J11	43521-61630	6	1	WIRE ASSY (Blue)
J12	43521-61633	9	1	WIRE ASSY
J13	43521-61631	7	1	WIRE ASSY
J14	43521-61632	8	1	WIRE ASSY

Manual Changes
Change 1

Page 86, Figure 6-4 Top View (Cables and Wires 2/2)

Replace the figure with the following figure:

Figure A-7 Top View (Cables and Wires 2/2)



43521ase033

Page 87, Table 6-3 Top View (Cables and Wires 2/2)

Change the table as follows:


Table A-4 Top View (Cables and Wires 2/2)

Reference Designation	Agilent Part Number	Check Digit	Qty.	Description
1	43521-61635	1	2	RF CABLE ASSY
2	43521-61603	3	1	RF CABLE ASSY SRGD (Divider - Switch)
3	43521-61605	5	1	RF CABLE ASSY SRGD (RF IN - Switch)
4	43521-61604	4	1	RF CABLE ASSY SRGD (RF OUT - Switch)
5	43521-61606	6	1	RF CABLE ASSY SRGD (Mixer - LPF)
6	43521-61607	7	1	RF CABLE ASSY SRGD (Switch - Switch)
7	43521-61601	1	1	RF CABLE ASSY SRGD (LO IN - Switch)
8	43521-61602	2	1	RF CABLE ASSY SRGD (LO OUT - Switch)
9	43521-61608	8	1	RF CABLE ASSY SRGD (DBLR - Switch)
10	43521-61609	9	1	RF CABLE ASSY SRGD (DBLR - AMP)
11	43521-61610	2	1	RF CABLE ASSY SRGD (AMP- Switch)
12	43521-61611	3	1	RF CABLE ASSY SRGD (Mixer - Switch)

Page 97, Figure 6-12 Step Attenuator Assembly

Replace the figure with the following figure.

Figure A-8 Step Attenuator Assembly



Page 97, Table 6-11 Step Attenuator Assembly

Change the table as follows:


Table A-5 Step Attenuator Assembly

Reference Designation	Agilent Part Number	Check Digit	Qty.	Description
1	33321-60059	8	1	Step ATT
2	43521-00604	6	1	Plate (for Step ATT)
3	2200-0142	0	2	Screw
4	0515-1550	0	2	Screw M3

Page 103, Figure 6-18 DETECTOR Assembly

Replace the figure with the following figure.

Figure A-9 DETECTOR Assembly



43521ase047

Page 103, Table 6-17 DETECTOR Assembly

Change the table as follows:

Table A-6 DETECTOR Assembly

Reference Designation	Agilent Part Number	Check Digit	Qty.	Description
1	8474C	6	1	DETECTOR
2	43521-61625	9	1	Wire Assy
3	43521-01208	8	1	Angle (for DETECTOR)
4	0515-1550	0	2	Screw
5	3050-0891	7	2	Washer

Page 107, Step Attenuator Replacement

Replace the description with the following description.

Step Attenuator Replacement

Tools Required

- Torx screwdriver, T15
- Pozidriv Screwdriver, pt size #1 (small), #2 (medium)
- Open-end wrench, 5/16-inch
Open-end torque wrench, 5/16-inch (set to 10 in-lb) (for reconnecting SMA connector)
- Adjustable Wrench (for Coaxial Connector)

Removal Procedure

1. Remove the top cover as described in the “Top Cover Removal” procedure.
2. Remove the two screws that secure the plate (for Step Att) to the Chassis Sub.
3. Disconnect the SMA connectors of the 1250-1159 Adapters from the step attenuator’s connectors (female). To loosen the SMA connector, grip the flat faces of the adapter with the adjustable wrench to keep the adapter steady.
4. Disconnect the ribbon cable for the step attenuator from the A1 J15 connector.
5. Remove the two screws that secure the step attenuator to the plate (for Step Att).

Page 107, U-WAVE AMP 18 GHz Replacement

U-WAVE AMP 18 GHz Replacement

Tools Required

- Torx screwdriver, T15
- Pozidriv Screwdriver, pt size #1 (small), #2 (medium)
- Open-end wrench, 5/16-inch
Open-end torque wrench, 5/16-inch (set to 10 in-lb) (for reconnecting SMA connector)
- Adjustable Wrench (for Coaxial Connector)

Removal Procedure

1. Remove the top cover as described in the “Top Cover Removal” procedure.
2. Remove the two screws that secure the plate (for Step Att) to the Chassis Sub.
3. Disconnect the SMA connector of the 1250-1159 Adapter from the U-Wave amplifier’s connector (IN side) and the SMA connector of the 1250-1159 Adapter from the 11636B Power Divider’s connector. To loosen the SMA connector, grip the flat faces of the adapter with the adjustable wrench to keep the adapter steady.
4. Remove the four screws that secure the angle (for AMP) to the Chassis Sub.
5. Disconnect the SMA connector of the 1250-1159 Adapter from the U-Wave amplifier’s connector (OUT side). To loosen the SMA connector, grip the flat faces of the adapter with the adjustable wrench to keep the adapter steady.
6. Disconnect the WIRE Assy for the amplifier from the A1 J12 connector.
7. Remove the two screws that secure the amplifier to the angle (for AMP).

Manual Changes
Change 1

Pages 112, Table 7-1 Post Repair Procedures

Change the table as follows:

Table A-7 Post Repair Procedures

Replaced Assembly or Part	Adjustments Correction Constants (CC)	Verification
A1 board	600 MHz SAW OSC Frequency RF Power Linearity CC RF Power Frequency CC RF IN Direct Path Insertion Loss CC	Check 600 MHz Output ^{*1} RF Power Measurement Accuracy Test 600 MHz OSC Phase Noise Test System Phase Noise Test
43521-61625 (Thermometer)	RF Power Linearity CC RF Power Frequency CC	RF Power Measurement Accuracy Test
8474C (Power Detector)	RF Power Linearity CC RF Power Frequency CC	Check Power Measurement Function ^{*1} RF Power Measurement Accuracy Test Input VSWR Test
11742A (Blocking Capacitor)	RF Power Linearity CC RF Power Frequency CC	Check Power Measurement Function ^{*1} RF Power Measurement Accuracy Test Input VSWR Test
8493B(between 11742A and 11636B) (Fixed Att. 6dB)	RF Power Linearity CC RF Power Frequency CC	Check Power Measurement Function ^{*1} RF Power Measurement Accuracy Test Input VSWR Test
11636B (Power Divider)	RF Power Linearity CC RF Power Frequency CC	Check Power Measurement Function ^{*1} Check Heterodyne Path ^{*1} RF Power Measurement Accuracy Test Input VSWR Test
33321-60059 (Step Att.)	RF Power Linearity CC RF Power Frequency CC	Check Heterodyne Path ^{*1} RF Power Measurement Accuracy Test Input VSWR Test
0955-1115 (Amplifier)	RF Power Linearity CC RF Power Frequency CC	Check Heterodyne Path ^{*1} RF Power Measurement Accuracy Test Input VSWR Test System Phase Noise Test
8493B(between Amp. and Mixer) (Fixed Att. 3dB)	RF Power Frequency CC	Check Heterodyne Path ^{*1}
0955-0665 (Mixer)	RF Power Frequency CC	Check Heterodyne Path ^{*1}
9135-0229 (Low Pass Filter)	RF Power Frequency CC	Check Heterodyne Path ^{*1}
0955-0689 (Amplifier)	RF Power Frequency CC	Check Heterodyne Path ^{*1} System Phase Noise Test
0955-1114 (Amplifier)	RF Power Frequency CC	Check Local Doubler Path ^{*1} System Phase Noise Test

Table A-7 Post Repair Procedures

Replaced Assembly or Part	Adjustments Correction Constants (CC)	Verification
0955-0693 (Doubler)	RF Power Frequency CC	Check Local Doubler Path *1 System Phase Noise Test
33312-60005 (SW1) (Coaxial Switch)	RF Power Linearity CC RF Power Frequency CC	Check Power Measurement Function *1 RF Power Measurement Accuracy Test Input VSWR Test
33312-60005 (SW2) (Coaxial Switch)	600 MHz SAW OSC Frequency	Check 600 MHz Output *1
33312-60005 (SW3) (Coaxial Switch)	RF Power Frequency CC	Check Heterodyne Path *1 Check Local Doubler Path *1 System Phase Noise Test

*1. See the Troubleshooting chapter.

Manual Changes
Change 1

B **Power Requirement**

Replacing Fuse

Fuse Selection


Select proper fuse according to the Table B-1.

Table B-1 Fuse Selection


Fuse Rating/Type	Fuse Part Number
3A 250Vac UL/CSA type Time Delay	2110-0381

For ordering the fuse, contact your nearest Agilent Technologies Sales and Service Office.

43521ase021



Level a small minus screwdriver to dismount the fuse holder next to the AC line receptacle on the rear panel.



Replace the fuse in the fuse holder.

Power Requirements

The 43521A requires the following power source:

Voltage : 90 to 132 Vac, 198 to 264 Vac
Frequency : 47 to 63 Hz
Power : 100 VA maximum

Power Cable

In accordance with international safety standards, this instrument is equipped with a three-wire power cable. When connected to an appropriate ac power outlet, this cable grounds the instrument frame.

The type of power cable shipped with each instrument depends on the country of destination. Refer to Figure B-1 for the part numbers of the power cables available.








WARNING

For protection from electrical shock, the power cable ground must not be defeated.

The power plug must be plugged into an outlet that provides a protective earth ground connection.

Power Requirement
Power Requirements

Figure B-1 Power Cable Supplied

<p>OPTION 900</p>  <p>United Kingdom</p> <p>Plug : BS 1363/A, 250V, 10A Cable: 8120-1351</p>	<p>OPTION 901</p>  <p>Australia/ New Zealand</p> <p>Plug : AS 3112, 250V, 10A Cable: 8120-1369</p>
<p>OPTION 902</p>  <p>Continental Europe</p> <p>Plug : CEE 7 Standard Sheet VII, 250V, 10A Cable: 8120-1689</p>	<p>OPTION 903</p>  <p>U.S./ Canada</p> <p>Plug : NEMA 5-15P, 125V, 10A Cable: 8120-1378</p>
<p>OPTION 904</p>  <p>U.S./ Canada</p> <p>Plug : NEMA 6-15P, 250V, 6A Cable: 8120-0698</p>	<p>OPTION 906</p>  <p>Switzerland</p> <p>Plug : SEV Type 12, 250V, 10A Cable: 8120-2104</p>
<p>OPTION 912</p>  <p>Denmark</p> <p>Plug : SR 107-2-D, 250V, 10A Cable: 8120-2956</p>	<p>OPTION 917</p>  <p>India/ Republic of S.Africa</p> <p>Plug : IEC 83-B1, 250V, 10A Cable: 8120-4211</p>
<p>OPTION 918</p>  <p>Japan</p> <p>Plug : JIS C 8303, 125V, 12A Cable: 8120-4753</p>	<p>OPTION 920</p>  <p>Argentina</p> <p>Plug : Argentine Resolution 63, Annex IV, 250V, 10A Cable: 8120-6870</p>
<p>OPTION 921</p>  <p>Chile</p> <p>Plug : CEI 23-16, 250V, 10A Cable: 8120-6978</p>	<p>OPTION 922</p>  <p>China</p> <p>Plug : GB 1002, 250V, 10A Cable: 8120-8376</p>

NOTE: Each option number includes a 'family' of cords and connectors of various materials and plug body configurations (straight, 90° etc.).

OPT9XXE_agi