

A3EE BLUE BIRD ALL AMERICAN A3RE

D R I V E R S H A N D B O O K

2010





ALL AMERICAN

© 2007 Blue Bird Corporation. All rights reserved.

All Blue Bird products sold for use in the United States of America and its insular areas comply with all applicable Federal Motor Vehicle Safety Standards (FMVSS) and applicable Federal ADA requirements.

Many of the components of Blue Bird buses are obtained from outside suppliers. Where maintenance and/or service information conflicts with the component manufacturer's documentation, the manufacturer's documentation prevails.

In the event of any conflict between the requirements of this publication and any applicable legal requirement, the legal requirement prevails. Technical requirements that exceed the legal requirements are not considered to conflict.

Blue Bird Corporation continually endeavors to improve its products and reserves the right to change without notice. Text, illustrations, and specifications in this manual are based on information available at the time of printing.



CONTENTS

INTRODUCTION

- About This Manual / 7
- Reporting Safety Defects / 9
- Noise Emissions Warranty / 9
- About 2007 Emissions Standards / 10
- Regarding Modifications / 11
- Before Placing the Bus in Service / 12

ORIENTATION

- Vehicle Identification / 13

ENTRANCE AND EXIT

- Outward Opening Door / 14
- Outward Opening (Air Door) / 14
- Power Doors / 14
- Emergency Pneumatic Power Door Release / 14
- Electric Outward Opening Door / 15
- Emergency Electric Power Door Release / 15
- Entrance Door Security Lock / 15
- Security Lock (Outward Opening Door) / 16
- Emergency Door Vandal Lock / 16
- Sliding Bolt Vandal Lock / 16
- Wheelchair Lifts / 17

DRIVER'S AREA

- Driver's Compartment / 18
- Dash And Instrument Panel / 19
- Warning Bank / 20
- Tilt And Telescopic Steering / 21
- Switch Panel / 21
- Mirrors And Adjustment / 22

SEATING

- Standard Driver's Seat / 24
- Deluxe Driver's Seat / 24
- Driver's Seat Belt Operation / 25
- Driver's Seat Belt With Shoulder Harness (Optional) / 25
- Passenger Seat Belts (Optional) / 25

COMPARTMENTS & ACCESS PANELS

- All American Front Engine / 26
- All American RE / 26
- Engine Access; All American Front Engine / 27
- Engine Access; All American Rear Engine / 27
- Rear Side Engine Compartment Doors / 27

ENROUTE EMERGENCIES

EMERGENCY EXITS

- Transpec™ Safety Vent / 30

EMERGENCY EQUIPMENT

- Fire Extinguisher / 32
- First Aid Kit / 32
- Body Fluid Cleanup Kit / 32
- Fire Axe/Crowbar / 32
- Flare Kit / 33
- Triangular Warning Devices / 33

TIRE / WHEEL EMERGENCIES

- Spare Tire Location And Removal / 34
- Damaged Tires / 35
- Wheel And Rim Safety / 36
- Jacking Instructions / 37
- Changing a Flat Tire / 38
- Schrader Valve / 39
- Releasing Spring Brake Manually / 39
- Towing Or Pushing / 40

ROUTINE OPERATION

PRE-ROUTE INSPECTION

Weekly Inspection / 43

ENGINE OPERATION

Engine Exhaust Caution (Carbon Monoxide) / 44

Diesel Fuel / 44

Diesel Engine Starting Procedure / 45

Starting With Boost Cables / 45

Using The Engine As A Brake / 46

Engine Warning System / 46

Exhaust System / 47

DPF Regeneration In Blue Bird Buses / 48

Levels of Notification / 49

Stationary Regeneration Precautions / 52

COMPRESSED NATURAL GAS

Owner / Operator Responsibilities / 54

National Fire Protection / 54

Fuel System Description / 55

Safety Cautions And Warnings / 56

Compressed Natural Gas Fuel / 58

Compressed Natural Gas Filters / 58

Refueling / 59

Specific Gravity / 60

Fuel Toxicity And Safety / 60

Flammability / 60

Antiknock Properties / 61

Energy Conversions / 61

Vehicle Performance And Emissions / 61

Starting Procedure / 61

Cold Start / 62

Operation And Maintenance Of CNG Vehicle Components
/ 62

TRANSMISSIONS

Allison Automatic Transmission / 64

Allison Model 3000 Bus Series Transmission / 64

Allison Model 2000 Bus Series Transmission / 65

Range Inhibited Light / 67

Check Transmission Light / 67

Allison Automatic Transmission Driving Tips / 68

Electric Retarder (If Equipped) / 69

Transmission Indicators / 70

BRAKING

Antilock Braking System (ABS) / 71

Hydraulic Brakes / 71

Air Brakes / 74

HEATERS

Heater Operation / 75

Control Panel Outlet Locations / 75

Defrosting / 76

Heater Defroster Location / 76

Driver / Passenger Comfort / 76

Standard Heater Cut Off Valves / 77

CARE & MAINTENANCE

ELECTRICAL

- Interior Lights / 82
- Exterior Lights / 82
- Doran Warning Light Monitor / 83
- Circuit Breakers / 85

DOOR ADJUSTMENT & LUBRICATION

- Outward Opening Door Adjustment / 86
- Outward Opening (Air Powered) Adjustment / 86
- Jackknife Door Adjustment / 87
- Power Jackknife Door Adjustment / 88
- Sliding Bolt Vandal Lock / 89
- Security Lock Lubrication (Outward Opening Door) / 89
- Access Doors / 89

SEATING CARE

- Seat Belt Inspection And Maintenance / 90
- Seat Inspection And Maintenance / 90

SIGNS & SIGNALS

- Stop Arms / 94
- Destination Signs / 95

ENGINE & RUNNING GEAR

- Air Intake System Inspection / 96
- Engine Cooling System / 97
- Shutters / 99
- Transmission / 100
- Rear Axle / 101
- Hydraulic Brakes / 101

WINDSHIELD WIPERS

- Washer Solution Reservoir / 102
- Wiper Assembly Replacement / 102
- Wiper Refill Replacement / 102

CLEANING

- Exterior Cleaning / 103
- Floor Cleaning / 103

HEATER CARE

- Filter / 104
- Annual Maintenance / 104
- Cleaning Auxiliary Fans / 105

MAINTENANCE SCHEDULE

- Maintenance Task Schedule, A3FE / 106
- Maintenance Task Schedule, A3RE / 121
- Maintenance Locations / 135
- General Data / 136



INTRODUCTION

Thank you for selecting the Blue Bird All American. The All American is the culmination of almost a century of Blue Bird heritage in student and public transportation which began in 1927. As always, the design and construction of the All American reflects Blue Bird's concern for safety, efficiency, and quality.

About This Manual

This Drivers Handbook has been prepared to acquaint you with the operation of the Blue Bird All American, and should be read by all Drivers before operating the unit. Familiarity with automotive operation and control is assumed to be common knowledge to all who will be operating this bus. This book does not address all driving situations which may arise, and it is not a substitute for proper driver training. It will, however, enable a School Bus driver to more quickly feel at home in this model All American.

Your Blue Bird All American may not have all of the equipment described in this manual. You may find information on optional equipment not installed on your bus. You are encouraged to contact your Blue Bird distributor if additional information or assistance is needed.

For use as a convenient reference, this Handbook also contains some general maintenance information. Although the Driver will not likely be performing service procedures, this information nonetheless serves to further familiarize the Driver with the bus. The maintenance information contained herein is provided as a reference for systems and components that require periodic service. The intervals given are component manufacturers' recommendations and should be considered maximum intervals; that is, the very minimum maintenance schedules that will afford reasonable care of this vehicle. Service technicians should refer to the Service Manual for more complete service information. If this manual does not address your specific questions or concerns, please contact your Blue Bird distributor. The distributor will answer your questions or put you in contact with the proper factory personnel.

Throughout this manual are precautions labeled Warnings and Cautions, and set in the style shown here:

WARNING *The Warning designation is generally used for precautions which, if not properly observed while performing the related procedures or handling materials, could result in serious personal injury or death.*

CAUTION *The Caution designation is generally used for precautions which, if not properly observed while performing the related procedures or handling materials, could result in damage to the bus or its equipment.*

Blue Bird Corporation offers many items as standard and optional equipment to meet federal, state, and local specifications and individual customer requirements. This includes, but is not necessarily limited to, stop arms, crossing guards, warning lights, warning light monitors, mirrors, first aid kits, fire extinguishers, warning reflectors, fuses, directional and brake lights, warning buzzers, security/vandal locks, emergency exits, and seat belts.

Emergency equipment must be checked for proper operation daily. It is the driver's responsibility to report any damage to qualified service technicians, and that the condition be corrected before transporting passengers.

WARNING *Vehicle alterations, which may cause non-conformance with the Emission Control and/or Federal Motor Vehicle Safety Standards (FMVSS), are expressly not authorized by Blue Bird Body Company. It is the responsibility of the entity undertaking the modification of this product to ascertain compliance with all applicable regulations. Modification must be accomplished in accordance with strict government standards. The entity completing modification of this product must certify that all applicable regulations are met. To certify a modified vehicle, the upfitter must be a licensed vehicle manufacturer, or obtain the services of a licensed vehicle manufacturer for that purpose. Specifically, Blue Bird does not authorize the following modifications.*

- Do not modify the front or rear suspension.
- Do not change the wheel base length.
- Do not remove any chassis, or body, cross members.
- Do not cut or drill the flange of the frame rails.
- Do not weld on the engine, radiator, fuel tank/s, transmission, or any component on the engine, radiator, fuel tank/s or transmission.
- Do not modify any body or frame cross member without prior approval of the Blue Bird Body Company.
- Do not install any equipment or component that will obstruct the flow of air into, around, or from the cooling system.
- Do not install equipment or components nearer than 2 inches (51 mm) to the fuel tank/s, rotating components or “jounce” movement of driveline components.
- Do not install any equipment, components, including flooring and/or carpeting, which will obstruct the functioning of the brake and accelerator pedals.

For the terms of the Limited Warranty of this Blue Bird product, refer to the Warranty certificate provided in the owner’s documents that came with the vehicle.

In addition to the safety issues involved in the modification of the unit, any “unauthorized” modification may adversely affect the warranty of this product by Blue Bird Body Company.

CAUTION *All Blue Bird products are certified to meet or exceed all applicable motor vehicle regulations and standards in the “as purchased” configuration. Any modifications are the responsibility of the entity making those modifications. Blue Bird engineering does not authorize any modification that affects the basic design.*

The complete line of Blue Bird Service Parts is available from your Blue Bird distributor. The use of original Blue Bird replacement parts and components will help ensure that your All American remains true to its original design, best preserving performance, efficiency, and safety.

For replacement parts...

Contact your Blue Bird distributor or Parts Sales at Blue Bird Body Company.



This manual provides you with the most current operation information available. We welcome your comments and suggestions regarding this manual. Please direct all correspondence to:

*Blue Bird Body Company
Attn: TECHNICAL PUBLICATIONS
P.O. Box 937
Fort Valley, GA 31030*

Reporting Safety Defects

If you believe that your vehicle has a defect which could cause a crash or could cause injury or death, you should immediately inform the National Highway Traffic Safety Administration (NHTSA) in addition to notifying Blue Bird.

If NHTSA receives similar complaints, it may open an investigation and, if it finds that a safety defect exists in a group of vehicles, it may order a recall and remedy campaign. However, NHTSA cannot become involved in individual problems between you, your dealer, or Blue Bird Corporation.

To contact NHTSA, you may call the Vehicle Safety Hotline toll-free at:

1-888-327-4236 (TTY: 1-800-424-9153)

or go to:

<http://www.safercar.gov>

or write to:

*Administrator, NHTSA,
400 Seventh
Street, SW., Washington, DC 20590*

You can also obtain other information about motor vehicle safety from:

<http://www.safercar.gov>.

Noise Emissions Warranty

Blue Bird Body Company warrants to the first person who purchases this vehicle for purposes other than resale, and to each subsequent purchaser, that this vehicle, as manufactured by Blue Bird, was designed, built, and equipped to conform to all applicable United States Environmental Protection Agency Noise Control Regulations.

This warranty covers the vehicle as it was designed, built, and equipped by Blue Bird, and is not limited to any particular part, component, or system of the vehicle manufactured by Blue Bird. Defects in design or in assembly, or in any part, component, or system of the vehicle as manufactured by Blue Bird, which at the time it left Blue Bird's control caused noise emissions to exceed Federal standards, are covered by this warranty for the life of the vehicle.

About 2007 Emissions Standards

Buses equipped with 2007 engines are designed to conform to new and stringent federal emissions standards. These standards affect both the equipment installed at the factory and the fuel at the pump.

Buses powered by 2007 emissions standards engines are equipped with special exhaust systems to reduce emissions. The technical details of the systems employed by various engine manufacturers differ, but share common general principles. The exhaust muffler is a particulate filter which traps and burns microscopic particles in a process referred to as "regeneration." When heat in the exhaust is insufficient to fully burn the particulates, the system enters an "active" regeneration mode so the necessary catalytic reaction can take place. During active regeneration events, exhaust temperatures are elevated, and an indicator light on the instrument panel illuminates to notify the Driver that regeneration is active. This regeneration mode is automatic and normal, and requires no special action on the part of the Driver.

As part of the 2007 emissions standards, effective October 15, 2006, the EPA has required fuel retailers to sell lower-emission fuel, designated "ultra-low-sulfur diesel". After that date, all commercially-available number 1 and number 2 highway diesel fuels are Ultra-low-sulfur diesel. This fuel must be used in all 2008 model buses powered by a 2007 emission standards diesel engine, as indicated by a decal located near the fuel filler door, reading:

The engine in this vehicle must be operated only with low ash engine oil and ultra low sulfur diesel fuel (meeting EPA specifications for highway diesel fuel, including a 15 ppm sulfur cap).

For detailed information on recommended fuels and other fluids, always follow your engine manufacturer's guidelines.



Regarding Modifications

Blue Bird Corporation offers many items as standard and optional equipment to meet federal, state, and local specifications and individual customer requirements.

Those interested in modification of this vehicle should consult the Service Manual and Blue Bird Engineering Department for a more complete understanding of the vehicle.

Vehicle modifications which may cause non-conformance with the emission control and/or Federal Motor Vehicle Safety Standards ((FMVSS), are expressly not authorized by Blue Bird Corporation.

It is the responsibility of the entity undertaking the modification to ascertain compliance of the modified vehicle with any and all applicable regulations. The entity performing modification of this product must certify that all applicable regulations are met. In order to certify a modified vehicle, the upfitter or other entity performing the modification must be a licensed vehicle manufacturer or must obtain the services of a licensed vehicle manufacturer for that purpose.

Specifically, Blue Bird Corporation does not authorize any modifications to or such as the following:

- Front or rear suspension
- Wheelbase length
- Body or chassis crossmembers
- Frame rail flanges
- Welding on the engine, radiator, fuel tank(s), transmission or any component of those items
- Cooling system
- Addition of any equipment or component nearer than 2 inches (51mm) to the fuel tank(s), rotating components or "jounce" movement of driveline components

Before Placing the Bus in Service

It is the responsibility of the bus Owner/Operator to ensure compliance with all federal, state, and local regulations for school bus operation and equipment. As part of a daily pre-trip inspection, the Driver should consider it his/her responsibility to verify that the vehicle is in satisfactory working order and that all emergency equipment is in place, fully stocked (First Aid Kit), up-to-date (Fire Extinguisher), and in proper working condition.

- Check the suspension U-bolt torque.
- Check the service brake adjustment.
- Check the park brake adjustment on units equipped with hydraulic brake systems.
- Check the torque on all the body “tie-down” capscrews.
- Check the engine oil level.
- Check the transmission fluid level.
- Check the engine coolant level.
- Check the air pressure in all the tires.
- Check the torque on the driveline universal joint straps.

Inspection guidelines from individual state inspection manuals (such as Commercial Driver’s License pre-trip inspection procedures) take precedence over those found in this manual. Guidelines found herein are in addition to those in your state’s inspection requirements.

The Driver is responsible for determining that the loading area is clear before stopping to load passengers. The Driver must ensure that all unloaded passengers are clear before moving the bus.

WARNING *Emergency equipment must be checked for proper operation daily. It is the Driver’s responsibility to report any damage to qualified Service Technicians and to ensure that the condition is corrected before transporting passengers.*

ORIENTATION

This section is to familiarize the Blue Bird All American Driver with the locations of controls and other bus features with which he will interact daily.

Vehicle Identification

The **Vehicle Certification Plate** certifies that the vehicle conforms to all applicable Federal Motor Vehicle Safety Standards in effect at the date of manufacture. Do not remove or deface this plate.

The **Body Serial and Service Number Plate** is located on the front upper inner panel above the windshield. Refer to the data on this plate for registration purposes or for replacement part information.

The **Axle Record and Chassis Service Number Plate** is located on the front upper inner panel above the windshield. Refer to the data on these plates for registration purposes or for replacement part information.

MANUFACTURED BY	
BLUE BIRD BODY COMP ANY	
DATE OF MFR. _____	
INC. VEH. MFG. BY _____	DATE _____
SUITABLE TIRE - RIM CHOICE	
GVWR _____	
GVWR : FRONT _____	WITH _____ TIRES
_____ RIMS, AT _____	PSI COLD SINGLE
GVWR : REAR _____	WITH _____ TIRES
_____ RIMS, AT _____	PSI COLD DUAL
THIS VEHICLE CONFORMS TO ALL APPLICABLE FEDERAL	
MOTOR VEHICLE SAFETY STANDARDS IN EFFECT IN _____	
V.I.N. _____	CLASSIFICATION _____

 BLUE BIRD	<h2 style="margin: 0;">BLUE BIRD FORT VALLEY</h2> <p style="margin: 0;">FORT VALLEY, GEORGIA</p>													
	<table border="0" style="width: 100%;"> <tr><td>BODY NO.</td><td>_____</td></tr> <tr><td>MODEL YEAR</td><td>_____</td></tr> <tr><td>MFG. BODY DATE</td><td>_____</td></tr> <tr><td>STATE / PROVINCE</td><td>_____</td></tr> <tr><td>EQUIPPED CAPACITY</td><td>_____</td></tr> <tr><td>SPECIFICATION YEAR</td><td>_____</td></tr> <tr><td>MAX. DESIGN CAPACITY</td><td>_____</td></tr> </table>	BODY NO.	_____	MODEL YEAR	_____	MFG. BODY DATE	_____	STATE / PROVINCE	_____	EQUIPPED CAPACITY	_____	SPECIFICATION YEAR	_____	MAX. DESIGN CAPACITY
BODY NO.	_____													
MODEL YEAR	_____													
MFG. BODY DATE	_____													
STATE / PROVINCE	_____													
EQUIPPED CAPACITY	_____													
SPECIFICATION YEAR	_____													
MAX. DESIGN CAPACITY	_____													
BODY SERVICE NO. _____														

FURNISH INFORMATION BELOW WHEN ORDERING AXLE PARTS	
CHASSIS SERIAL _____	ENGINE SERIAL _____
FRONT AXLE _____	BRAKE LINING FMSI NO. & FRICTION CODE _____
BRAKE DRUM _____	
REAR AXLE _____	BRAKE LINING FMSI NO. & FRICTION CODE _____
BRAKE DRUM _____	
REAR AXLE RATIO _____	
CHASSIS SERVICE NO. _____	

ENTRANCE AND EXIT

Outward Opening Door

Outward Opening Doors are mounted in a prefabricated framework, which eliminates the effect of body construction variations on door and seal operation. Doors are suspended completely on sealed ball bearings located at the top corners of the framework, inside the body. The interlink connection between the doors is a single assembly with oppositely threaded, spherical bearing rod end connectors at each end, providing simple link length adjustment without disassembly. The geometry of the mechanical link between the doors causes the rear door to close well ahead of the front door, so that the front nosing seal rubber always overlaps the rear. Oil impregnated bronze bearings in the lower corners of the framework serve as pivots (not supports). All controls and mechanisms and the complete lower step tread are sealed inside the bus and out of the weather when the door is closed.

The manual control is the Blue Bird over center locking type with built in Saf Latch. The door's ease of operation allows use of a short handle arm, so the handle is six inches closer to the driver in the open position than with the jack-knife door.

Your bus's outward opening door may be actuated by an optional electric control connected to a lever on the front door panel. Mechanically operated switches control automatic stop positions as well as stepwell and warning lights.

Outward Opening (Air Door)

The pneumatic actuator is a cylinder connected to a lever on each door, located inside the header cover. An interconnecting link between the doors controls the operation sequence. A safety release valve is located over the door. Air switches inside the header cover operate Stepwell lights. A three position spring loaded switch signals a valve controlling the flow of air to open or close the doors. Air pressure holds the door either open or closed. The operation speed is adjustable by use of flow control valves located on the actuator.

Power Doors

Power doors have an air cylinder in the header, for operation of jackknife entrance and exit doors. The door operates with an air, push/pull valve, located in the switch panel area.

Emergency Pneumatic Power Door Release


An emergency release valve is located above the door in the header cover. To use the emergency release, push the lever in the direction of the arrow. This valve exhausts air pressure in the door cylinder, allowing the door to be opened and closed manually.





Electric Outward Opening Door


The electrically operated outward opening door has a linear actuator that moves a lever attached to the front door. To open the door, hold the spring-loaded switch in the driver's area in the "OPEN" position until the door stops moving. An automatic switch stops the action of the door. To close the door, move the switch to the "CLOSE" position; the door will stop automatically when fully closed. There is a keyed switch on the outside of the body, on the cowl panel by the door, which operates the door from outside the bus.



Manual Security Lock (exterior)

Emergency Electric Power Door Release

With the door in the fully closed position, pull the release lever in the header panel toward OPEN as far as possible. The linkage will release and the lever will "snap" into a "park" position so it will not return forward when released. Push the door open to exit the bus. To reset the release mechanism, move the lever to its forward position, and hold the driver operated spring-loaded switch in the "open" position until it clearly engages, or until door is in the fully open position.




Manual Security Lock (interior)

Entrance Door Security Lock

To activate the optional electric entrance door security lock, pull the door to a fully closed position from outside the vehicle. When this is done, the security lock is activated. To unlock, insert the key into the lock, forward of the door. While turning the key, press against the center section of the door to open.

The manual security lock release handle is located in the lower kick panel of the entrance door. It rotates in a counter clockwise direction to latch. It can be locked in the latched position or in the unlatched position. To use the vandal/security lock, the hinged stop on the door control cover must be down to prevent the door control arm traveling over center when closing the door.



Manual Security Lock (interior)

Security Lock (Outward Opening Door)

Outward opening doors have an optional key locking mechanism, accessible from outside the bus. A key operated bolt slides into a hole in the header when the door is in the closed position and locked. This option also requires use of the hinged stop on the door control.

Emergency Door Vandal Lock

The emergency door and the rear emergency window may have an optional vandal lock feature, which prevents entry through the emergency door. When the vandal lock cylinder is in the lock position, the engine cannot be started. To start the bus, the cylinder must be removed from the lock and placed in the receptacle at the side of the door.

Sliding Bolt Vandal Lock

The sliding bolt vandal lock (for the emergency door and rear emergency window) is an interior latch that prevents the door from being opened from the outside. The bolt is connected to an interlock assembly, which prevents the engine from starting when the door is locked. If the lock is activated after the engine is running, an alarm sounds in the driver's area.

WARNING *The bus must not be operated with the emergency exit locked.*



Wheelchair Lifts

Blue Bird All American school buses may be fitted with lifting platforms designed to aid in loading and unloading passengers. There are two optional wheelchair lifts available. The units available are the Ricon™ Model S5010 and the Braun™ Model L919FIB. Both offer a maximum of 48 inches (122 cm) lift from the ground to the level of the bus floor. For the correct operation and maintenance of the wheelchair lift on your bus, please refer to the operator's manual supplied by the OEM.

WARNING *Operators should familiarize themselves with the lift manufacturer's operator's manual prior to loading passengers on the lift. All lifts have maximum weight limits that should never be exceeded.*

These lifts are operated by an independent, electro-hydraulic power system and are controlled by the operator from outside the bus. There is a master switch located in the driver's area that must be activated as well.


The bus electrical system powers a hydraulic pump, internal to the lift, which moves the lift up. The "down" function is gravity type and is controlled by pressure release valves. Manual operation of the "down" function requires that the operator manually control the pressure release valves. To provide for the manual "up" function, the lift is fitted with a hand operated hydraulic jack, located on the right-hand (from inside the bus) side of the lift assembly.

A buzzer sounds when the door is unlatched or partially opened. The buzzer stops if the door is completely open.

DRIVER'S AREA



- ①
- ②
- ③
- ④



- ⑤
- ⑥
- ⑦
- ⑧
- ⑨
- ⑩
- ⑪
- ⑫
- ⑬
- ⑭
- ⑮
- ⑯
- ⑰


Driver's Compartment

1. Auxiliary fans.
2. Radio.
3. Interior mirror.
4. Emergency equipment compartment.
5. Switch panel.
6. PA system.
7. Horn button—sounds electric horn.
8. Instrument panel.
9. Automatic transmission shift control range selector or electronic push button pad location.
10. Warning light, door, and stop arm controls.
11. Hazard light flasher switch.
12. Tilt/telescopic steering lever.
13. Parking brake.
14. Ignition.
15. Brake pedal or air treadle—applies service brakes.
16. Accelerator pedal—controls engine speed.
17. Heater and defroster controls.




Dash And Instrument Panel

1. **4 in 1 Gauge.** Consist of the following clockwise from left to right:
Fuel Gauge. Indicates fuel level in tank.
Voltmeter. Indicates electrical system voltage.
Coolant Temperature Gauge. Indicates engine coolant temperature.
Oil Pressure. Indicates engine oil pressure.
2. **Front Air Gauge.** Indicates air pressure in front brake reservoir.
3. **Rear Air Gauge.** Indicates air pressure in rear brake reservoir.
4. **Speedometer.** Indicates vehicle speed.
5. **Tachometer.** Indicates engine speed.
6. **Transmission Oil Temperature.** Indicates transmission fluid temperature.
7. **Ammeter.** Indicates battery charge condition.
8. **Headlight Switch.** First position activates front park lights and rear taillights. Second position activates front park lights, rear taillights, and headlights.
9. **Dimmer Switch.** Adjusts light level on instrument panel.
10. **High Idle Switch.** Sets engine at high idle speed.
11. **Diagnostic Switch.** For use by qualified service personnel for diagnostic purposes only.
12. **Tire Chains Switch.** Activates on-spot automatic tire chain device.
13. **Adjust Pedal.** Two position momentary switch adjusts accelerator pedal to desired position.
14. **Cruise Control On/Off.** Activates or inactivates the cruise standby mode.
15. **Cruise Control Set/Resume.** At the desired cruise speed, set speed by depressing the SET switch. When the brake pedal is depressed, the cruise returns to standby mode. To reactivate to preset speed, depress the RESUME switch after reaching at least 30 mph.
16. **Exhaust Brake.** Activates the exhaust brake to help slow the bus during deceleration.
17. **Warning Bank.** Cluster of indicator lamps. See next page.
18. **Message Display Center.** Displays additional information to the vehicle operator.



Warning Bank

1. **Left Turn.** Flashes with left turn signal.
2. **Brake System.** Indicates a brake system failure. Stop the vehicle and call for assistance.
3. **ABS.** Indicates fault in the anti-lock brakes system. Service as soon as possible.
4. **High Beam.** Headlights are in high beam.
5. **Stop Engine.** The engine ECU has detected a problem which can lead to engine damage. Stop the engine and call for assistance.
6. **Right Turn.** Flashes with right turn signal.
7. **Check Trans.** The transmission needs service.
8. **Trans Temp.** The transmission temperature is beyond normal operating range.
9. **Hydraulic Fluid Temperature.** The hydraulic fluid temperature is beyond normal operating range.
10. **Engine Retard.** The engine retarder is engaged.
11. **Park.** Parking brake is applied.
12. **Low Coolant Level.** Engine coolant is low.
13. **Service Brake.** Lights when service brakes are applied.
14. **Range Inhibit.** The transmission ECU is restricting shifts.
15. **Engine Warn.** The engine needs service.
16. **HEST.** High Exhaust System Temperature.
17. **MIL.** Maintenance Indicator Light.
18. **Wait to Start.** Indicates engine preheating. Wait until indicator goes off before starting engine.





Switch Panel

1. Front Dome Lights
2. Rear Dome Lights
3. Driver's Dome Light
4. Fan, Hi-Off-Lo
5. Fan, Hi-Off-Lo
6. Warning Light Master Switch
7. Defroster
8. Master Heater Switch

Note

The function of the Master Heater Switch is to turn off all heaters and radio to allow the driver to hear sounds outside the bus; for instance, at a railroad crossing. When the switch is in the up position, heater blowers and the radio will not operate. When the switch is down (see illustration), these devices will function in a normal manner.


Tilt And Telescopic Steering

To adjust steering wheel position, use the tilting lever located on the left side of steering column. Press lever downward to tilt column into desired position.

To raise or lower the steering wheel position, pull up on the tilting lever. This will enable you to raise or lower the steering wheel to the desired position.

Mirrors And Adjustment

WARNING *The vehicle's mirror system has been designed to comply with all field-of-view requirements, but it is the operator's responsibility to adjust the mirrors properly before placing the vehicle in service and to maintain the adjustment during the service life of the vehicle. Mirrors provide additional driver visibility on buses. To be used effectively, mirrors must be properly adjusted for each driver, and the driver must be aware of the limitations on viewing area that exist even when mirrors are properly used. Mirrors are not a substitute for proper driver training and care that should be exercised when operating the vehicle and loading or unloading passengers. Do not move the bus until you have accounted for each passenger that has disembarked and have confirmed that all passengers are clear of the bus. Failure to follow these procedures could cause serious injury or death.*



Interior Mirrors

Inside rearview mirrors can be adjusted by loosening the bolts and nuts in slotted holes. Adjust the mirror to give the operator a clear view of the bus interior and the roadway to the rear.

WARNING *After unloading passengers, do not move the bus until you have confirmed the location of each disembarked passenger, and you are confident all of them are clear of the bus.*

Exterior Rearview

Standard equipment on all school buses includes four outside rearview driving mirrors (two per side), and two elliptical cross view mirrors (one per side). The outside rearview driving mirrors include one flat and one convex on each side. The outside rearview driving mirrors are designed to provide the seated driver a view of the roadway to the rear and to the sides of the bus. The elliptical cross view mirrors are designed to allow a seated driver to view all areas around the front of the bus not directly visible. The elliptical cross view mirrors are designed to be used to view pedestrians while the bus is stopped.

WARNING *Do not use the elliptical cross view mirrors to observe traffic while the bus is moving.*


CAUTION *A convex mirror is designed to provide a wide view with minimum distortion. However, persons or objects seen in a convex mirror will appear farther away than when seen in a flat mirror or viewed directly. Use care judging the size or distance of objects seen in a convex mirror.*





Proper adjustment is necessary for any mirror system to perform as designed. The following adjustment sequence should be used to allow the driver maximum viewing area with the mirror system.

1. Adjust the driver's seat to the desired position.
2. Adjust the right-side, flat, driving mirror so that the tops of the side windows are visible in the upper edge of the mirror, and the right side of the bus body is visible in the inside edge of the mirror.
3. Adjust the right-side, convex, driving mirror so that the view in the top of the mirror overlaps the view provided by the right-side flat driving mirror, and the right side of the bus body is visible in the inside edge of the right-side convex mirror.
4. Adjust the left-side, flat, driving mirror and the left-side, convex, driving mirrors using the same procedures described for the right-side mirrors. Refer to Steps 2 and 3 above.
5. Adjust the elliptical cross view mirrors by positioning each mirror head so that the center of its field of view is aimed at the eyes of the driver.
6. Make a final adjustment to the mirror system so that the seated driver can view the areas required by Federal Motor Vehicle Safety Standard 111 — including the entire top surface of cylinders M and N when located as illustrated, and rearward a minimum of 200 feet (measured from the mirror surface) — using the outside rearview driving mirrors. The elliptical cross view mirrors should be adjusted to provide the seated driver a view of the entire surface of any cylinder A thru P (when located as illustrated) not visible by direct view of the driver. The view provided by the elliptical cross view mirrors must overlap the view provided by the outside rearview driving mirror system.



All mirrors should be cleaned once a week (or more if needed), preferably with an ammonia solution. Keep the mounting fasteners tight so that mirrors will not vibrate. Check weekly and tighten, if necessary.


SEATING

Standard Driver's Seat

To adjust seat position forward or backward, hold lever (A) to the left. To adjust the height:



1. Loosen handle in front (B).
2. Lift height adjust handle on side.
3. Slowly sit or stand to position seat at desired height.
4. Release height adjust handle prior to applying full weight.
5. Tighten handle in front.
6. Fasten and adjust seat belt.

To adjust the back angle, lean forward slightly to remove pressure from seat back. Hold the handle (C) rearward to adjust to any position within the seat's range.



Deluxe Driver's Seat

1. Weight and Height Adjustment—to adjust, push in valve knob to raise seat and pull out to lower. When adjusted properly, the seat will not rest against the top, or bottom, limits of vertical motion under normal driving conditions. Adjustment position should also provide for driving visibility and vehicle control.
2. Fore and Aft Adjustment—Hold lever to the left to adjust seat position forward or backward.
3. Back Angle Adjustment—Lean forward slightly to remove pressure from seat back. Hold handle rearward to adjust to any position within range.
4. Cushion Tilt Adjustment—Rotate seat tilt knob to decrease or to increase seat tilt.
5. Lumbar Adjustment—Rotate knob forward to increase, or rearward to decrease, the support in the lumbar area.



WARNING Do not attempt to adjust the driver's seat, while the vehicle is in motion. Do not adjust height while sitting in the driver's seat. Keep feet and other items away from height adjustment handles and pedals while vehicle is in motion.



Driver's Seat Belt Operation

The driver's seat belt should be worn at all times when the vehicle is being driven. Blue Bird driver's seat belts feature automatic locking retractors, which are self adjusting. They feature an anti-cinch device which helps prevent uncomfortable tightening of the belt as you drive. To use, withdraw an adequate length of belt from the retractor or retractors to allow the buckle to connect. After engaging the buckle, allow the retractor to withdraw the belt to a snug fit. Verify that the automatic locking mechanism is working properly by pulling the belt sharply against the retractor, which should resist. The buckle is released by pushing the button in its center.

Driver's Seat Belt With Shoulder Harness (Optional)

The driver's seat belt should be worn at all times when the vehicle is being driven. The driver's shoulder harness locks during emergency stops; the lap belt may be either emergency locking or automatic locking, depending on the option chosen. The emergency locking retractor used for all shoulder harnesses and specified lap belts is dual sensitive. The emergency locking retractor engages when the vehicle tips 15° or if belt payout speed exceeds a preset rate. Automatic locking retractors for specified lap belts are self adjusting. Adjust the shoulder belt bracket for driver comfort.

To use, withdraw an adequate length of belt from the retractor or retractors to allow the buckle. After engaging the buckle halves, let the retractor withdraw the belt to a snug fit. The buckle can be released by pushing the button in its center.

Passenger Seat Belts (Optional)

Individual lap belts for passengers are retractable or non-retractable depending on option ordered. Insert the catch into the buckle, test for positive latch, and pull the loose end of strap until the belt fits snugly across the lower hips. The buckle can be released by pushing the button in its center. The adjustable end can be moved outward on its strap by turning 90° to the strap and pulling.

WARNING *Be sure the lap belt is fitted snugly around the hips, not the waist. Failure to do so may increase the chance of injury in the event of a collision. Do not bleach or dye the webbing, because such processing may severely weaken the assembly.*

COMPARTMENTS & ACCESS PANELS


All American Front Engine

Release the latches on the center panel and allow it to open downward for access to the heater bleeding valve, radiator fill cap, and to view to the radiator sight glass.

Release press button latches on front access doors to the left and right of the center panel for access to windshield wiper motors, windshield wash reservoir (located on the entrance door side), and power steering fluid reservoir (located on driver's side).

All American RE

On the Rear Engine models, this allows access to windshield wiper motors, windshield wash reservoir, etc. After closing, press in the larger portion of the latch until it snaps to lock into position.





Engine Access; All American Front Engine


To open the hood, disengage the latch mechanism located in two places on the engine cover. Lift the access cover and allow it to rest fully open on the forward portion of the hood assembly. This will allow access to engine components, such as the oil dipstick, engine oil fill, transmission fluid dipstick, etc.

To remove engine cover assembly for better access to the engine components, loosen the screw type latch mechanisms located at the upper front wall of the engine hood assembly. Open the hood and locate three latches on the inner wall perimeter of the hood assembly. One is located at the rear center and one is located on each side. Releasing these latches will then allow entire hood assembly to be removed for mechanics access.

CAUTION Engine and components can be very hot. If the engine has been running, be careful to avoid burns during engine access and removal process.



Engine Access; All American Rear Engine

To open, press the release button on the latches located at the edges of the door (right side shown). Press the upper portion of the handle, located in the lower center of the door for handle access. When the handle swings around, grip and pull to open door. After closing, press in the larger portion of the latch until it snaps to lock into position.



Rear Side Engine Compartment Doors

To open, press release button latches on the top and the bottom of the rear side access doors. Opening the left side door gives access to the outside of the radiator. Opening the right side door gives access to the right side of the engine. After closing, press in the larger portion of the latch until it snaps, to lock into position.





ENROUTE EMERGENCIES

Passenger safety is the bus driver's first priority. In the event of enroute emergency or roadside hazard, the driver must be confidently familiar with the location and use of safety devices, emergency equipment and roadside procedures in order to maintain order, guide passengers to safety, and properly position and secure the bus until assistance arrives.

EMERGENCY EXITS

Emergency exits are clearly identified by the words “EMERGENCY EXIT.” Operating instructions are printed near each exit. Some units are equipped with an audible alarm which sounds if an emergency exit is unlatched or open. If a buzzer sounds when turning on the ignition switch, check emergency exits to see that they are closed. All emergency exits meet Federal Motor Vehicle Safety Standard 217, “Bus Window Retention and Release.” These illustrations show various types of emergency exits.

WARNING *All emergency exits should be checked daily to ensure they are clearly labeled and operate properly. Exit windows, doors and hatches must not stick or bind, and must open smoothly and reliably without undue force. Report any damage or defects immediately and repair before transporting passengers.*

Transpec™ Safety Vent


The roof hatch serves as an important emergency exit. It is important that it is maintained properly and instruction labels are in place and clearly visible. All emergency exits should be inspected and operated daily to ensure that they are labeled and operate according to the instructions provided.

Maintenance Cautions


Transpec™ Safety Vents are designed to provide years of reliable service with a minimum amount of maintenance. All components are rustproof with lifetime finishes, and moving parts are Teflon™ coated to eliminate need for lubrication. Use of lubricants, paints, or other coatings—such as graffiti-detering spray—is not recommended.

Suggested maintenance includes periodic inspection of attaching fasteners for evidence of loosening due to tampering, and regular cleaning with mild soap and water. Although there are more powerful cleaning solutions available, some of them contain solvents and other chemicals that can attack the high strength materials used in the production of safety vents. It is the customer’s responsibility to ensure that cleaning solutions are compatible with the materials used on safety vents.


Graffiti-removing cleaners often contain acetone, ether, lacquer thinner or other solvents known to destroy the high strength properties of many engineering plastics, and use of these cleaners must be avoided. Graffiti-resisting coatings often leave a sticky residue that interferes with the operation of the ventilator mechanism. Use of these types of chemicals should be avoided.



Roof Hatch
Pop up (front or rear) or raise for additional ventilation




Rear Emergency Door




Rear Emergency Window



Split Sash Pushout Window



Side Emergency Door




Transit Sliding Pushout Window

EMERGENCY EQUIPMENT

Each state or province has unique laws regarding emergency equipment. Your unit may have some or all of the items listed below. Because of variations in option packages, the placement of this equipment inside the bus may vary from one unit to another, but it is important for you to recognize and know the locations of all the emergency equipment on your bus. It is important that you to read, and understand all literature, labels, and other written materials supplied by the equipment manufacturers. Be sure you familiarize yourself with all aspects of the emergency equipment before attempting to drive the bus.


Fire Extinguisher

The fire extinguisher is normally located to the left of the driver's seat, or on the right-hand side of the hood ledge near the stepwell when space is available. Your unit may be equipped with a 2.75, 4.5, 5, or 6 pound extinguisher, depending on the laws of your state or province. Inspect the pressure gauge every 30 days, or as required by individual state fire laws, to be certain the unit is fully charged. Inspect mounting fasteners periodically to be sure they are secure.



First Aid Kit

The first aid kit is mounted in the front of the bus body just above the right windshield. Size and contents of first aid kits vary due to state specifications. The contents of the kit should be inspected weekly or as required by local regulation to ensure that all contents comply with state specifications.



Body Fluid Cleanup Kit

The body fluid cleanup kit is designed to contain accidental spillage of biological matter, minimizing risk of exposure to potential health hazards. The contents of the kit should be inspected monthly, or as required by local regulation, to ensure that all contents comply with state specifications.

Fire Axe/Crowbar

The fire axe and crowbar are located on the electrical panel access cover to the left of the driver's seat as near to the front as possible. Every 30 days, inspect installation mounting fasteners to ensure that they are secure. Check fire axe and crowbar monthly to ensure that they are easily accessible and unobstructed.




Flare Kit

The flare kit is mounted on the left-hand side panel behind the driver's seat. Every 30 days or as required by local regulations, ensure that the contents of the flare kit are in place. Inspect mounting fasteners for flare kit box every 30 days to make sure they are tight.

Triangular Warning Devices


For states requiring the triangular warning devices be located in the driver's compartment, this container is mounted above the windshield at the upper center near the roof line. For other states, it is located on the left-hand rear floorboard, under the rear seat. Inspect contents of the kit every 30 days or as required by local code to ensure proper operation.



Recommended Warning Device Positioning

Some states allow a lockable "Emergency Equipment" compartment. This optional compartment is located above the windshield, toward the center of the bus. Supplies are organized and labeled in the compartment. The compartment locking mechanism is fitted with a warning buzzer, which will sound if the compartment is locked while the ignition switch is in the "on" position.

On rear engine units, the emergency equipment is located in the front of the bus. The compartment is located at the centerline of the bus at floor level, depending on the options selected at the time of manufacture.



TIRE / WHEEL EMERGENCIES

Spare Tire Location And Removal

If your unit is equipped with a frame mounted spare tire carrier, follow this procedure to remove and replace spare:

1. Remove the two securing nuts and rotate tire out of holes.
2. Open the access door, if equipped, through the access hole. Insert the lug wrench, placing the socket over the hex head on the shaft and turn clockwise; disengage the ratchet.
3. Slowly lower the tire by turning counter clockwise.



WARNING Hold the wrench securely while lowering the tire; the weight of the tire can cause the lug wrench handle to slip.

4. Remove the lifting platform from the tire.
5. To raise tire, reverse procedures, making certain to engage ratchet before cranking clockwise.

WARNING Never move under a vehicle supported only by hydraulic jacks. Always chock the wheels that are not being raised in both directions. Do not get under the tire/wheel while replacing a flat.

If your unit is equipped with a spare tire compartment, follow this procedure to remove and replace spare:

1. Unlatch the tire compartment door and secure in the open position with the chain and hook.
2. Pull out the rack.
3. Remove the wheel hold down clamp and lift off the wheel. Reverse the procedure above to replace the wheel.





Damaged Tires

WARNING An inflated tire and rim can be very dangerous when misused or worn out. Many accidents, some fatal, have resulted from improper handling and operation of bus rims and wheels. To help avoid personal injury and/or property damage, get expert tire service help if you can. If you must remove the wheel and change the tire without such help, take the following precautions:

- If the tire seems to contain air under pressure, stand to the side and check whether the wheel assembly appears normal by comparing it to another wheel assembly on the vehicle.
- Let the air out of the tire by taking out the valve core. If you have a way to put air back into a tire, note that it is good safety practice to let the air out of both tires of a dual assembly before taking off the damaged tire and rim assembly from the vehicle. After letting out the air, take off the tire and rim assembly and put on the spare wheel and tire assembly.
- If you are not fully expert on the procedures to follow, and/or are not equipped with the proper tools and equipment, do not attempt to raise the vehicle or remove or install the tire and wheel assembly. Obtain expert tire service help.
- Do not inflate a tire that has been run flat or is seriously low on air without first having the tire taken off the wheel and the tire and tube checked for damage.
- Note that work on bus wheels requires proper tools, safety equipment, and special training. You can be badly injured and/or damage can result from using the wrong service methods. Only trained people using the proper equipment should service bus tires and wheels.
- When putting air into a tire on the vehicle, stand to the side and use a clip on chuck and hose extension. Never add to your tires unless an accurate pressure gauge is also used. In choosing the right tire pressure, be careful not to go past the maximum pressure capacity shown on the tire.

WARNING Tire inflation pressure must not exceed the specifications of the tire and/or wheel rim manufacturer for the specific load, speed, and application. The inflation pressure embossed on the tire sidewall does not take the wheel or rim capacities into consideration. Tires should not be inflated above the pressure listed on the label without consulting your tire/wheel distributor.

Wheel And Rim Safety

Wheels and wheel components must be properly maintained to avoid adverse effects on the life of the tire and/or wheel. An inflated tire is potentially very destructive. Careless handling and inexperience cause accidents. Safety literature can be obtained from your wheel and rim distributor, a wheel and rim manufacturer, NHTSA, or OSHA. If you have any questions, consult the distributor or manufacturer directly. The load carrying requirements of each vehicle should also be determined before selecting the proper tire/wheel combination. Always remember that the weakest weight carrying component of the vehicle (i.e., the tires, wheels, axles, bearings, etc.) determines the load carrying capacity for the vehicle.

WARNING *Improper handling of wheels and rims has caused many injuries and deaths. Failure to follow directions is the leading cause of such accidents. Obtain procedures from wheel and rim manufacturer before working with a wheel or rim.*

The tire and wheel must always be properly matched. For example, do not mount a 20-inch tire on a 22-1/2-inch wheel. Failure to strictly adhere to these important instructions may result in an explosive separation and could cause serious bodily injury or death. It is very important to determine the size of each component before beginning any assembly operations.

When replacing tires, use the same size, load range, and construction type as originally installed on the vehicle. When replacing wheels, use original equipment manufacturer's wheels or equivalent available from your dealer with equivalent capacity, width, offset, and mounting configuration as those originally installed on your vehicle. Use of improper replacement wheels and tires may adversely affect ride, handling, load carrying capacity, bearing life, the clearance to body and chassis components, vehicle ground clearance, vehicle width, and brake cooling. Do not mix rim, lock ring, and wheel components from different manufacturers.



Jacking Instructions

WARNING Proper jacking procedures and basic safety measures must be observed to ensure safety of personnel while working under the bus. Always check the serviceability of any lifting equipment prior to use. Ensure that the lifting device is of sufficient strength to handle the bus, and that the surface provides the necessary firmness to support the weight of the bus concentrated on the footprint of the jack. Never move under a bus supported only by a hydraulic jack.


1. Park the bus on flat, level concrete or a comparable surface, capable of supporting the jacking device.
2. Apply the parking brakes.
3. Place chocks at the front and rear of the tires opposite the wheel, or wheels, to be lifted first.
4. Use jacks and jack stands, or blocks of sufficient capacity, to support the vehicle. Following the jack manufacturer's recommended procedure, place the jack securely under the axle at a spring or suspension beam nearest the tire/wheel to be repaired.
5. Jack the bus only to the height necessary to service.

WARNING Ensure any locking device on the jack is in place and operating properly. Support the vehicle under the main frame rails with jack stands or blocks before working under or around the bus.


6. After servicing is complete, lift the bus just enough to remove the jack stands or blocks.
7. Carefully lower the bus.

WARNING Do not work under a bus supported by jacks. Use only appropriate lifts and/or jack stands supporting frame rails when working under bus.

Rear Jack Point



Front Jack Point




Changing a Flat Tire

The lug nuts are tightened to a torque value of 450 - 500 Ft lb (610 – 678 Nm). Without the proper power tools, it is very difficult to remove the lug nuts. The lug nuts must be “broken loose” before lifting the wheel off the ground.

WARNING Never work around or under a bus supported only with a bottle jack.


1. Remove the lug nuts.
2. Position the spare as near to the hub as possible.
3. You will probably need to raise the hub slightly to position the wheel on the studs (lugs).
4. Hand-tighten all lug nuts.
5. Using the lug wrench, tighten all the lugs about a quarter turn.
6. Remove the blocks or jack stand.
7. Lower the bus enough to lock the wheel in place.
8. Tighten the lug nuts to 50 ft lbs (68 Nm) in the sequence shown.
9. Check the wheel for proper positioning on pilots and proper seating against the flange.
10. Tighten the nuts to 450–500 ft lbs (610 – 678 Nm) in the sequence shown.
11. Lower the jack and remove it from under the axle. Stow the damaged wheel and tire assembly, and the tools.





Schrader Valve

The bus is equipped with a Schrader valve which is located at the end of the wet tank. It allows the air brake reservoir to be charged with a common type air hose normally used by service stations and garages. Charging the system in this manner is only a means of providing air pressure for the air brake system with an inoperable air compressor or without cranking the engine and should only be used for moving the bus while servicing or in case of emergency.




Releasing Spring Brake Manually

When air pressure fails in the rear service brake chamber, the power spring applies the rear service brakes. Unless pressure can be re-established, the service brakes must be released, as follows, to move the bus.

WARNING Do not release the spring brake until the bus is secured by wheel chocks or tow vehicle. Failure to do so may result in bodily injury or property damage.

1. Remove the release stud tool and nut from the carrying pocket on the brake chamber assembly.
2. Remove the access plug from the end of the spring chamber.
3. Insert the release stud through the opening in the chamber and into the spring pressure plate.
4. Turn the release stud one quarter turn to engage the stud tangs with the slot in the pressure plate.
5. Keep the stud engaged and install the nut on the release stud.
6. Tighten the nut until the spring is fully caged and the brakes are released.
7. Do not loosen or remove the release stud and nut unless the brake chamber is completely assembled and is securely clamped.
8. When air pressure is restored, remove the release stud and install in carrying pocket.




Towing Or Pushing

CAUTION Never tow or push a vehicle equipped with an Allison automatic transmission unless the drive shaft has been removed, or the rear wheels have been raised off the ground. Do not tow by the front axle or any frame cross-member. Damage to the wiring and/or the air lines can result. Optional tow hooks are located at the front and/or rear of the vehicle under the bumper. Tow hooks are designed to tow or pull with both hooks simultaneously. Do not pull or tow with an individual hook. Bumpers provided on Blue Bird buses are designed to protect the vehicle and occupants from front and rear collisions. They are not designed for towing or jacking up the vehicle. Blue Bird does NOT recommend towing or jacking the vehicle by the bumpers.

WARNING Exercise extreme caution when the drive shaft is removed on a unit equipped with hydraulic brakes. The parking brake becomes inoperative when the drive shaft is disconnected. Do not leave the bus unattended until taking appropriate measures to prevent vehicle movement. Do not work under the bus when supported by bumper jacks. Use only appropriate jack stands supporting frame rails when under the bus.

WARNING Do not lift the bus with the rear tow hooks. These tow hooks should be used for flat ground maneuvering only.



ROUTINE OPERATION

Although the controls of a modern bus may appear similar to those of a regular passenger car or truck, the size and weight of the bus and its payload require many differences in design, components, and operating procedures. This section describes special considerations in operation of the engine, transmission, brakes, and other systems.

Remember: The bus is eight feet wide without outside mirrors and is 25 to 40 feet long. Therefore, it is two feet wider and two to three times as long as the average automobile. Acceleration will be slower than that of an automobile. The inexperienced operator may find that steering, brakes, and other systems feel different from what is familiar. In addition, the driver/operator must ensure that the loading area around the bus is clear of pedestrians before stopping, and that all unloaded passengers are a safe distance away from the bus before moving. For these reasons it very important, from a safety standpoint, to become familiar with bus operation through experience before attempting passenger transit.

WARNING *No one should attempt to operate this bus without: (1) thorough knowledge of all instruments and controls, (2) supervision, or actual driving experience in this or a similar vehicle under supervision, and (3) the appropriate license or permit to operate. Do not drive the bus until the space in front, on the sides, and in the rear is unobstructed. Most accidents occur because the operator did not ensure a clear path before driving.*

Inspection guidelines from individual state inspection manuals (such as Commercial Driver's License pre-trip inspection procedures) take precedence over those found in this manual. Guidelines found herein are in addition to those in your state's inspection requirements.

PRE-ROUTE INSPECTION

To keep your bus in the best operating condition, any malfunction or defect should be corrected before the next trip. Report needed services to responsible maintenance personnel.

Engine/Transmission:

- Check fuel level.
- Drain air tanks.
- Drain fuel/water separator.
- Check engine oil level.
- Check automatic transmission fluid level.
- Inspect engine air intake system, especially the air cleaner service indicator. See Air Intake System Inspection in the General Maintenance section of this manual.
- Inspect the engine coolant level at the sight glass.
- Remove any foreign material and dirt from the outside of the radiator core.

Body, outside the bus:

- Clean the windshield, mirrors, front windows, headlights, taillights, directional lights, and brake lights.
- Is the tailpipe clear?
- Does the rear emergency door open and close? Check warning buzzer operation.
- Check the wheelchair lift operation, if so equipped.
- Check tire pressure and the treads. Are the lug nuts in place?
- Drain the air brake tank.
- Is the area under the bus all clear?
- How is the general outside appearance? Is it clean? Is there a clear view of identifying features (license plate, school name, bus number, etc.)?
- Are the mirrors clean and adjusted?

Body, inside the bus:

- Are the seats and floor clean? Are the steps and aisle clear?
- Verify that all emergency exits open and close properly, and do not stick.
- Check the emergency equipment and the first aid kit.
- Is the fire extinguisher in place?
- Are the windshield and windows around the driver's area clean?
- Are the mirrors clean and adjusted?
- Are emergency doors/windows unlocked and operating freely?
- Do buzzers activate when exits are not fully latched?
- If so equipped, does the wheelchair chime sound?

**Starting the engine:**

- Be sure parking brakes are on.
- Put the transmission in Neutral.
- With the key in the “ON” position, check the fuel gauge. Check the brake warning buzzer or light, and the neutral safety switch.
- Start the engine. Look and listen for trouble signs; check the gauges.
- Does the wheelchair lift interlock function properly, if so equipped?

With the engine running, check (from driver’s seat):

- Mirrors, interior and stepwell lights, service door seal.
- Does the steering feel OK? Is there any unusual noise?
- Check the horn, defroster and heater blower, and windshield wiper operation.
- Does the brake pedal have the right height and feel? Is the gauge reading OK?
- If so equipped, does the wheelchair interlock function properly?

Outside checks required before driving away:

- Check turn signals in front and rear. Are they clean and flashing?
- Are flasher warning lights in front and rear clean and flashing?
- Is stop arm clean and working?
- Check high and low beam headlights.
- Are brake lights and taillights clean and working?
- Is hazard flasher working?

Final check while moving the bus:

- Is seat belt fastened?
- Do brakes stop and hold?
- Does steering feel OK? Are there any unusual noises? Is bus under control and tracking straight?
- Brake to a stop. Are all gauges OK?

Remember: Safety on the road depends on you. Observe weather and road conditions and drive accordingly. Be physically and mentally alert. When backing up near pedestrians or in congested areas, use someone outside to monitor or direct your movements. Look around before driving away from where you are parked and observe all traffic rules and regulations.

Weekly Inspection

- Perform all the Daily Inspection procedures.
- Drain air tanks.
- Check tires. Look for weather checks, worn areas and tread. Check the air pressure.
- Inspect seat cushion attachments for tightness.
- Inspect seat belts and buckles.
- Inspect outside lights for proper operation.

ENGINE OPERATION

Engine Exhaust Caution (Carbon Monoxide)

WARNING *Never idle the engine in a confined area. Never sit in a parked or stopped vehicle with the engine running. Exhaust gases, particularly carbon monoxide, can build up. These gases are harmful and potentially lethal. Carbon monoxide is colorless and odorless, but can be present with all other exhaust fumes. Do not drive with exhaust fumes present.*

If you suspect exhaust fumes are entering the bus, have the system inspected to determine the source, and make the appropriate corrections immediately.

The best protection from carbon monoxide entry into the bus is a properly maintained engine exhaust system, body, and body ventilation system. It is recommended that the exhaust system and body be inspected by a competent mechanic:

- Each time the vehicle is raised for an oil change.
- Whenever a change is noticed in the sound of the exhaust system.
- Whenever the exhaust system under the body or the rear of the vehicle is damaged.
- Whenever there is an inspection of piping and joints. Replace clamps that are leaking.

Exhaust system clamps are not reusable. Seal with exhaust sealant and install new clamp. Do not run the engine in a confined area (such as garages) longer than necessary to move the vehicle in or out of the area. When your bus is stopped in an open area with engine running for more than a short period, and if it is equipped with combination heating and external ventilation, then adjust the heating or ventilation system to force outside air into bus with the blower set at medium or high speed.

Keep the air inlet grille clear of snow or other obstructions at all times to assure proper operation of the ventilation system. Sitting in a parked vehicle with engine running for an extended period, in either a confined or open environment, is dangerous.

Diesel Fuel

All American units should take advantage of the high energy content and generally lower cost of No. 2 diesel fuel. Experience has shown that diesel engines will operate satisfactorily on No. 1 fuel. The engine in this vehicle must be operated only with ultra low sulfur diesel fuel (meeting EPA specifications for highway diesel fuel, including a 15 ppm sulfur cap).

WARNING *Use caution when filling the fuel tank(s) with a high delivery nozzle to prevent spillage. Fuel spray can cause serious injury; vent slowly. Do not fill to more than 95% capacity.*

CAUTION *In 2007 diesel engines, use only diesel fuel labeled Ultra Low Sulfur, per the engine manufacturer's specifications. In Caterpillar, use oils meeting API CJ-4 or Caterpillar ECF-3 compliant. See Caterpillar Operation and Maintenance Manual SEBU8083-08 for details. In Cummins, use oils meeting API CJ-4/SL and Cummins Engine Standard CES-20081. See Cummins Owners Manual ISB 6.7L CM2150 for details.*



Diesel Engine Starting Procedure

See the appropriate engine manufacturers operating manual for proper starting procedures. Starting procedures vary from different engine manufacturers and also varies with temperature.

1. Apply the parking brake.
2. Place the transmission shift lever in the neutral position.
3. Insert the ignition key and turn it to the ON position. All the instrument panel lights will come on momentarily. Depending upon conditions, the Wait To Start light may remain on. If so, wait until it goes off before trying to start the engine. This gives the engine grid heaters enough time to warm the combustion chambers for efficient starting.
4. After the engine starts, turn on the high idle switch (1,000-1,200 rpm) until the engine is fully warmed up.

CAUTION Do not engage the starter longer than 30 seconds without allowing the engine 120 seconds rest.

If the engine fails to start after a reasonable time, determine the cause of the failure. Pumping the accelerator will not assist in starting the engine. Refer to the engine manufacturer's recommended procedures.

CAUTION Do not race the engine during the "Warmup" period.

Starting With Boost Cables

WARNING Batteries can emit corrosive and potentially explosive fumes. Prevent sparks near the batteries. Do not allow battery cable ends to contact each other or the engine. Do not smoke when observing the battery electrolyte levels. Electrolytes are corrosive and can cause personal injury if they contact skin or eyes. Always wear protective glasses when working with batteries.

The Blue Bird All American bus has a 12-volt starting system. Use only 12 volts for boost starting. The use of a higher voltage will damage the electrical system.

Always connect the boost cables in parallel with the bus battery cables, negative (-) to negative (-) and positive (+) to positive (+). Do not reverse the battery cables. The alternator can be damaged.

Attach the ground cable last and remove it first.

1. Fasten the positive (+) clamp of the boost cable to the positive (+) post of the battery.
2. Fasten the negative (-) clamp of the boost cable to the negative (-) post of the battery.
3. Start the engine.
4. After the engine starts, disconnect the negative (-) boost cable from the battery.
5. Disconnect the positive (+) boost cable from the battery.

Using The Engine As A Brake

While going down a steep or long grade, it is a good practice to use the engine to retard vehicle speed. Reduce speed before the grade and shift into a lower gear (with either automatic or manual transmissions), being careful to select a gear which will slow the vehicle without over speeding the engine. Under such conditions, use the brakes sparingly, to prevent overheating. Overheating will cause the brakes to “fade”; that is, be less effective.

WARNING *Do not take transmission out of gear when the bus is moving. You may not be able to get the transmission back in gear, and the drastic slowing of engine speed could reduce air pressure supply to the air brake system, and result in a reduction of brake capacity.*

Engine Warning System

Your All American bus may have an optional alarm system to signal low oil pressure and high engine temperature. If the engine temperature exceeds the manufacturer’s recommendations, or if the oil pressure drops below the manufacturer’s recommendations, a buzzer sounds and an indicator light glows.

CAUTION *If the alarm system sounds, shut the engine off immediately. Operation of the engine after the alarm sounds could cause serious engine damage.*



Exhaust System

New federally mandated emission standards affect all buses equipped with 2007 or newer diesel engines. The exhaust systems of both Caterpillar and Cummins engines in Blue Bird buses are *aftertreatment* systems which incorporate *Diesel Particulate Filters* (DPF) instead of ordinary mufflers. These sophisticated exhaust systems reduce emissions by trapping exhaust-borne particulates (soot) in a filter built into the DPF.


Over time, soot accumulates in the DPF, and must be removed by a process referred to as *regeneration*. Regeneration is conceptually similar to the cleaning mode of a self-cleaning oven in that heat is required to remove the soot.

The rate at which soot accumulates is dependent upon multiple conditions including the quality of the diesel fuel, type of engine oil, and ambient temperature, engine load, and other factors. Regeneration occurs in three ways:

- Some regeneration occurs “naturally” whenever operating conditions (speed, engine load, etc.) result in exhaust system temperatures high enough to oxidize accumulated soot. This unassisted regeneration process can generically be referred to as “passive” regeneration.
- Regeneration can be caused by raising the temperature of the exhaust system. Both Caterpillar and Cummins engines are equipped with systems designed to increase exhaust temperature when the ECM senses that regeneration is needed, and when certain requirements, including a minimum travel speed, are met. This automatic “heat assisted” mode can be generically referred to as “active” regeneration.
- Regeneration can be manually activated by means of a switch. This procedure is generically referred to as “stationary” regeneration, and should only be performed by or under the direction of a qualified service technician, and in a controlled environment to avoid the potential for human injury or fire hazards.

The need for regeneration is communicated to the driver by a set of visual and audible signals in the instrument panel. An additional alert, the High Exhaust System Temperature (HEST) indicator, notifies the driver whenever exhaust system temperature is high due to recent regeneration.

Eventually, the normal ash accumulation which results from the regeneration process must be removed from the DPF, using equipment designed for the purpose at qualified engine service facilities. Refer to the engine manufacturer’s documentation for these service intervals. The engine operator’s manual provided with your bus contains additional information about exhaust system regeneration, and should be read and understood by the driver.



The exhaust systems of 2007 and newer engines incorporate engine-specific Diesel Particulate Filters, which operate at higher temperatures during their Regeneration cycles. The front exhaust pipes are insulated, and heat shields are installed at locations along the exhaust tubing. (Caterpillar shown.)

DPF Regeneration In Blue Bird Buses

As with most new mechanical processes, the introduction of more sophisticated exhaust systems in 2007 emission standards-compliant engines has generated some degree of initial confusion. Engine manufacturers have designed their own methods to accomplish the regeneration (cleaning) of the DPF, and therefore describe the process in somewhat differing terms.

Whether your Blue Bird bus is equipped with a Caterpillar or Cummins engine, neither system is complicated. Nor should the regeneration process be regarded with alarm. Both Drivers and service technicians should be at least conceptually familiar with the regeneration process.

As soot builds up in the DPF filter, the driver is notified in several stages by visual and audible alerts. The alert system is designed to provide reasonable and comfortable fore-warning and adequate opportunity for the needed regeneration. As the need for regeneration becomes more severe, the alerts become increasingly imperative; and the penalty for postponing the needed regeneration also increases.

When the earliest alerts occur, there is typically ample time to complete a route and then have a Stationary Regeneration procedure performed at a proper facility. If early alerts are ignored, and the condition is allowed to worsen, the engine will eventually de-rate automatically, and performance will reduce noticeably. If the condition is allowed to become severe, a Stationary Regeneration may not be possible, and the DPF may require removal and treatment using specialized equipment. Therefore, to minimize disruption of your bus operation, the regeneration-related alerts should be heeded and responded to at their early stages as a matter of routine.

Aftertreatment Terms

The following summarizes some of the terms associated with the exhaust systems of Blue Bird buses equipped with 2007 emission standards compliant engines. Both the driver and technician should become familiar with the following terms:

Aftertreatment. The process of highly filtering engine exhaust in order to reduce emissions, and of purging the exhaust system of accumulated exhaust residue.

DPF (Diesel Particulate Filter). A component in the exhaust system which takes the place of a traditional muffler. A DPF contains a special dissimilar metals filter which traps particulate accumulation (soot), which is then converted to carbon dioxide by the aftertreatment process. The Cummins DPF also contains a catalytic converter.

Regeneration. The process of cleaning accumulated soot from the filtering components inside the DPF. Regeneration occurs at high exhaust system temperatures to turn the soot into carbon dioxide gas. Regeneration can be thought of as conceptually similar to the clean cycle of a self-cleaning oven.

ARD (Aftertreatment Regeneration Device). A component of the Caterpillar Regeneration System, located on the right side of the engine, at the outlet of the turbo-charger. The ARD is controlled by the engine's ECM and is activated when regenera-

WARNING *Postponing regeneration beyond the early indications may result in the engine being automatically de-rated, and reduction of power while driving.*

WARNING *The aftertreatment regeneration process can cause extremely high exhaust gas temperatures hot enough to ignite or melt common materials, and to burn people.*

Carefully read, understand, and abide by all instructions, warnings, and cautions in the engine manufacturer's operator's manual (and other related engine manufacturer's literature) regarding safe operation when the HEST indicator is on.

Carefully read, understand, and abide by all instructions, warnings, and cautions in the engine manufacturer's operator's manual (and other engine manufacturer's literature) regarding safety conditions when performing Stationary regeneration.



tion needs to occur and the necessary conditions are met. When not in regeneration mode, the ARD is simply a chamber through which the exhaust flows. During regeneration, a charge of fuel and air is ignited in the ARD, and the resulting combustion creates additional heat to facilitate regeneration.

HEST Indicator (High Exhaust System Temperature). An instrument panel indicator which appears when the exhaust temperature is unusually high due to recent regeneration. This is a normal behavior of the aftertreatment system, intended to notify the driver and technician that the exhaust system temperature is high and that caution should be observed around the exhaust system.

DPF Indicator. An instrument panel indicator which displays when particulate accumulation has reached a preset level in the DPF, and regeneration is needed. The bus should either be operated with a more demanding duty cycle until the indicator goes off, or it should be scheduled for a Stationary Regeneration at a service facility.

Levels of Notification

Regeneration—the process which clears soot accumulation in the DPF—occurs automatically as the bus is operated, as long as certain operating conditions (such as minimum speed thresholds) are met. When bus operating conditions do not provide adequate opportunity for the regeneration system to keep the DPF clear, soot begins to accumulate. A system of driver alerts keeps the driver informed of when the exhaust system is in need of regeneration, and of high exhaust temperature associated with regeneration. Several levels of regeneration alerts occur in sequence, each indicating a more imperative warning.

High Exhaust Temperature Notification

The High Exhaust System Temperature (HEST) indicator appears to alert the driver when exhaust temperature is unusually high and that prudent judgement should be applied regarding the proximity of people or combustibles to the exhaust system. For example, the bus should not be parked on a surface of grass or weeds. The conditions under which the HEST indicator appears differ between Caterpillar- and Cummins-equipped buses:

With Caterpillar engine, the HEST indicator appears whenever the exhaust temperature is high (842°F or above), and the bus is either stopped or moving at a slow speed (approximately 5 MPH).

With Cummins engine, the HEST indicator appears whenever the exhaust temperature is high (752°F or above), regardless of moving speed.

The driver should be familiar with and abide by all instructions, warnings, and cautions in the engine manufacturer's operator's manual regarding safe operation when the HEST indicator is on.

- The HEST alert appears in the instrument panel.
- The audible alarm sounds one beep.

HEST Notification



The HEST alert appears in the instrument panel's warning bank.



The audible alert sounds one beep.

Level 1 Regeneration Notification: DPF Indicator Appears

In low-demand operating conditions, it is possible that the regeneration system does not have sufficient opportunity to prevent particulate build-up in the DPF. The ECM senses that accumulation is occurring and that regeneration is needed. The driver is notified as follows:

- The DPF Regeneration alert activates.
- The audible alert sounds one beep.

The above indicates that regeneration of the DPF is needed at the earliest convenience. The regeneration can be accomplished in either of two ways: If practical, the bus could simply be operated for a while at a speed above the automatic regeneration threshold; or the bus could be taken to a suitable location to have a Stationary Regeneration procedure performed.

If the bus is operated at a minimum highway driving speed (20 mph Caterpillar; 40 mph Cummins), the automatic regeneration system will activate. If minimum speed is maintained long enough (usually 20-30 minutes), the automatic regeneration mode can likely reduce the soot sufficiently to cause the DPF Icon to go off.



Therefore, the first appearance of the DPF icon should be perceived by the driver as a normal notification of action that needs to be taken, but not as an emergency situation. Typically, even if the bus route does not afford immediate opportunity for higher-speed operation, there is sufficient time to finish the bus route and return to the bus maintenance shop before the higher level of notification occurs. Exactly how much “warning time” the first appearance of the DPF indicator represents is dependant upon specific operating conditions. However, current data from Cummins suggest that, at this level of notification, the DPF needs to undergo regeneration within the next two to six hours of bus operation. If regeneration does not begin, a more imperative notification will activate.

Level 2 Notification: DPF Indicator Blinks

If the bus continues to be operated without taking the measures indicated by a Level 1 Notification (described above), particulate accumulation continues, and a more imperative notification occurs:

- The DPF Regeneration alert begins to flash.
- The audible alarm sounds continuously.
- The engine may be automatically de-rated.

The above indications should be interpreted as a more imperative alert that the exhaust system is in need of regeneration soon. As soon as practical, the bus should be operated at or above the minimum speed needed to allow automatic regeneration to activate, or a Stationary Regeneration must be performed. Again, situation-specific variables apply. Current data from Cummins suggest that at this level of notification, the DPF needs to be regenerated within the next one to two hours of bus operation. Otherwise, the third level of notification will occur.





Level 3 Notification: Check Engine Indicator Appears

If the bus continues to be operated without taking the measures indicated by a Level 2 Notification, particulate accumulation worsens. These indicators are activated:

- The DPF Regeneration alert continues to flash.
- The audible alert sounds continuously.
- The engine is automatically de-rated.
- The Check Engine alert appears.

The above indicates that a Manual Regeneration must be performed as soon as possible. Because the engine is automatically de-rated it may not be possible to drive at sufficient speed to cause active regeneration to occur.

With Cummins engine, depending upon the severity of the accumulation, the regeneration switch may not be allowed to initiate a regeneration without use of Cummins’s PC-based diagnostic software, Insite.

Level 4 Notification: Stop Engine Indicator Appears

If the bus continues to be operated without taking the measures indicated by a Level 3 Notification, particulate accumulation reaches a critical level. Engine power is automatically further de-rated by the ECM. The indicators differ slightly between Caterpillar- and Cummins-equipped buses:

Cummins:

- The DPF Regeneration alert deactivates.
- The audible alert sounds continuously.
- The engine is further de-rated.
- The Check Engine alert deactivates.
- The red Stop Engine alert appears.

Caterpillar:

- The DPF Regeneration alert continues to flash.
- The audible alert sounds continuously.
- The engine is further de-rated.
- The Check Engine alert remains on.
- The red Stop Engine alert appears.

The above indicates that accumulation has progressed to critical levels and the bus should be stopped with the engine off as soon as it is safe to do so. The bus should remain shut down until the aftertreatment system has been serviced.

With Cummins engine, the regeneration switch will not be allowed to initiate a regeneration without use of Cummins’s PC-based diagnostic software, Insite.

With Caterpillar engine, depending upon the severity of the accumulation, the regeneration switch may not be allowed to initiate a regeneration without the use of Caterpillar’s PC-based diagnostic software, Electronic Technician.

With either Caterpillar or Cummins engine, removal and cleaning of the DPF using specialized equipment may be required.


Level 3

Regen Needed

FLASH

Regen Needed

The DPF Regeneration alert flashes in the Message Display.




The audible alert sounds continuously.

ENGINE WARN

The Check Engine alert appears in the warning bank..

Level 4, Cummins



The audible alert sounds continuously.

STOP ENGINE

The Stop Engine alert appears in the warning bank.


Level 4, Caterpillar

Regen Needed

FLASH

Regen Needed

The DPF Regeneration alert flashes in the Message Display.



The audible alert sounds continuously.

ENGINE WARN

The Check Engine alert appears in the warning bank..

STOP ENGINE

The Stop Engine alert appears in the warning bank.

Stationary Regeneration Precautions

During active regeneration, the exhaust system can reach extremely high temperatures. Automatic active regeneration, which occurs while driving the bus, is programmed to occur only when the bus is moving at a minimum speed, and it stops when the vehicle slows or stops.

With Caterpillar engine, if the exhaust is still unusually hot from recent regeneration when the bus slows or stops, the HEST indicator appears to remind the driver of the high temperature condition.

With Cummins engine, the HEST indicator appears whenever the high temperature condition exists.

When performing a Stationary Regeneration, the entire process occurs for an extended period while the bus is stopped. It is therefore critical that prudent human safety and fire hazard precautions are followed. Those precautions include:

- Read, understand, and abide by all the precautions pertaining to regeneration procedures in the engine manufacturer's Operator's Manual.
- If at all possible, the Stationary Regeneration procedure should be conducted at a service facility by trained technicians.
- The Driver's first priority is the safety of the passengers. If a Stationary Regeneration must unavoidably be done by the Driver under a qualified technician's direction, alternate transportation should be arranged first, or passengers should be removed under proper supervision to a location away from the bus.
- Select an appropriate location to park the vehicle.
 - Choose a surface that will not burn or melt under high temperature, such as clean concrete or gravel, *not grass or asphalt*.
 - Ensure that nothing that can burn, melt, or explode (gasoline, wood, paper, plastics, fabric, compressed gas containers, hydraulic lines) is near the exhaust outlet. Abide by all instructions, warnings, and cautions in the engine manufacturer's operator's manual regarding safe operation when performing a Stationary Regeneration.
- Park the bus securely.
 - Set the parking brake. Put the transmission in Neutral. Chock the wheels.



- Secure the exhaust area.
 - If bystanders might enter the area, set up barriers to keep people safely away from the exhaust outlet.
 - If the procedure is performed indoors at a service facility, attach an exhaust discharge pipe rated for at least 1500°F.
 - Keep a fire extinguisher nearby.
- Check exhaust system surfaces to confirm that no tools, rags, grease, debris or any other objects are on or near the exhaust system.
- Start the engine.
- Operate the Regeneration Switch to begin the regeneration process.
- Monitor the process. If any unsafe condition occurs, shut off the engine immediately. During the regeneration process, the engine may change speed, and the turbocharger may whistle. When the process is complete, the engine will return to normal idle speed. Exhaust gas and exhaust surface temperatures will remain elevated until they have had time to cool to normal levels.

COMPRESSED NATURAL GAS

WARNING *Due to the dangerous potential of high pressure cylinders, it is important that anyone involved in their use be completely familiar with the Department of Transportation "Code of Federal Regulations Title 49" and the various Compressed Gas Association pamphlets that are available covering the care and use of high pressure cylinders. Regulations do not permit filling Natural Gas Vehicle (NGV) cylinders with an overcharge.*

The compressed natural gas (CNG) fuel system consists of DOT-certified CNG storage tanks (which replace the fuel tank), a structure to hold and protect the storage tanks, metallic fuel lines to deliver the fuel, high and low pressure regulators to reduce the pressure entering the throttle body, a fuel shutoff solenoid, and the throttle body which delivers the CNG/air mixture to the engine. The regulator includes an integral heater to preheat the CNG for anti-icing control.

A pressure relief system is part of the fuel system. This system is designed to vent the tank contents when pressure and temperature become excessive.

A fill connection is located near the entrance of the bus. If so equipped, the engine powering this bus is engineered specifically for use with CNG. Operation and maintenance procedures are similar to those used on gasoline or diesel engine vehicles. Differences identified are obvious.

Owner / Operator Responsibilities

The owner/operator should be aware of the code requirements and be familiar with applicable codes which apply to the area of operation. The owner/operator should be aware that fuel cylinders for CNG (Compressed Natural Gas) must be inspected every three years in accordance with NGV-2 specifications. The owner/operator should be aware that cylinder expiration date is fifteen years after the date of the cylinder manufacture. Compressed gas cylinders must be replaced at that time.

Testing and recertification of the compressed gas cylinders is not covered by Blue Bird warranty. Replacement of compressed gas cylinders, at the end of their service life, is not covered by Blue Bird warranty.

National Fire Protection

Association #52 States: Cylinders shall be manufactured, inspected, marked, tested, retested, equipped and used in accordance with U.S. Department of Transportation (DOT) or Canadian Transport Commission (CTC) regulations, exemptions or special permits specifically for CNG service and shall have a rated service pressure of not less than 2400 psig at 70° F (16.5 MPa at 21.1° C).

Pressure vessels shall be manufactured, inspected, marked and tested in accordance with the rules for construction of unfired pressure vessels, Section VIII (Division 1), ASME Boiler and Pressure Vessel Code.

When a vehicle is involved in an accident or fire causing damage to the CNG container, the CNG container shall be replaced or removed, inspected and tested in accordance with the document under which it was originally manufactured before being returned to service.



When a vehicle is involved in an accident or fire causing damage to any part of the CNG fuel system, the system shall be retested before being returned to service.

Damaged supply lines must be replaced, not repaired.

The owner or user, or both, shall maintain all containers, container appurtenances, piping systems, venting systems and other components in a safe condition.

As a precaution to keep pressure relief devices in reliable operating condition, care shall be taken in the handling or storing of compressed natural gas containers to avoid damage. Care shall also be exercised to avoid plugging by paint or other dirt accumulation of pressure relief device channels or other parts that could interfere with the functioning of the device. Only qualified personnel shall be allowed to service pressure relief devices. Only assemblies or original manufacturer's parts shall be used in the repair of pressure relief devices unless the interchange of parts has been proved by suitable tests.

CODE OF FEDERAL REGULATIONS #49 states: In addition to the requirements of this paragraph, cylinders marked DOT-3HT must be qualified in accordance with CGA pamphlet C-8 and must comply with the following:

Cylinders built prior to implementation of FMVSS 304 must be subjected, at least once in three years, to a test by hydrostatic pressure in a water jacket, for the determination of the expansion of the cylinder. A cylinder must be condemned if the elastic expansion exceeds the marked rejection elastic expansion.

Cylinder service life must not exceed fifteen years.

Each cylinder must be inspected and hydrostatically tested every three years in accordance with 49 CFR 173.34(e) as prescribed for DOT-8HT cylinders, except that the rejection elastic expansion criteria does not apply, permanent volumetric expansion must not exceed 5 percent of total volumetric expansion at test pressure and retest dates must be imbedded in the epoxy coatings in a permanent manner other than stamping. Retest dates may be steel stamped on the shoulder of the top head in accordance with 178.BB-15(c). Re-heat treatment or repair of cylinders is not authorized.

Fuel System Description

The fuel system begins with DOT-certified tanks designed to hold compressed natural gas (CNG) up to 3,600 psi at standard day temperature (70° F, or 21° C). The tanks are high strength steel wrapped with fiberglass for additional strength.

The fuel flows from the tank to the engine through manually controlled shutoff valves. These include an integral pressure relief valve consisting of a combination rupture disk (for pressure) and fuse plug (for temperature) to vent the contents of the tank should high pressure and high temperature occur, such as in a fire. The rated temperature for relief is 212° F.

From the valve, fuel flows into a common fuel line through high pressure stainless steel compression fittings. The tanks are joined to the common line through high pressure stainless steel Tees and crosses. Any open tank is connected to any other open tank, so for fueling, the fuel flows through the common line to all tanks. The tank shutoff valves isolate the tanks; the Tees on the valves still have the high line pressure.

Do not uncouple fittings until all tanks are closed and pressure has been purged from the line. The lines are high pressure rated 3/8 stainless steel seamless tubing which carries the fuel to the high pressure regulator.

In refilling, the fuel enters the fill valve on the entrance side of the bus and then flows through a check valve into the common tubing before reaching the tanks.

From the high pressure regulator, the fuel flows to the shutoff solenoid. The ignition switch, engine operation, and the fire suppression system activate the shutoff solenoid. The loss of any of these will shut off fuel supply to the low pressure regulator (LPR).

The fuel gauge is proportional to the pressure when corrected to 70° F. Fuel level is only accurate for the tanks that are open.

Safety Cautions And Warnings

Both gasoline and CNG are volatile, flammable fuels, yet they are safe to work around when necessary precautions are taken. As on a gasoline fueled system, carelessness with CNG can lead to a fire or explosion when a leak occurs. CNG will not pool and spread like gasoline. It has a narrower range of flammability than gasoline, as well as a higher ignition temperature. Despite these relative safety advantages, fire potential does exist. CNG is lighter than air, so it can collect in the higher regions of a room and possibly go undetected, creating fire potential.

Since the fuel system is a very high pressure system employing a flammable gas, all safety issues normally considered in these situations should be applied. Some of the more obvious precautions are listed below. This list is not necessarily intended to be complete, and responsibility for assuring full safety is that of the person(s) doing the work or operating the system.

WARNING *Handle natural gas with care. Compressed natural gas is a volatile fuel stored under high pressure. If fuel storage or delivery components are installed, serviced, or operated improperly, fire, explosion, and/or serious injury could result. Do NOT smoke while working on or around natural gas equipment. Avoid flames, sparks, and operation of electrical devices in or around a vehicle with a possible natural gas leak. Properly tighten all connections and thoroughly check for leaks after servicing fuel system. Natural gas fumes may cause sickness or death. Work in a well ventilated area.*

WARNING *Protect against high pressure CNG. Compressed natural gas is stored and routed to the engine at a pressure up to 3,600 psi. Do NOT attempt to remove or disassemble any fuel system component while it is pressurized. Explosive separation of components and escaping natural gas can cause serious injury. Avoid the hazard by relieving pressure before disconnecting any CNG fitting or line. Properly tighten all connections and thoroughly check for leaks before applying pressure. Never attempt to over pressurize the system.*



WARNING Protect against extremely cold escaping CNG. Compressed natural gas is stored at an extremely high pressure. If compressed natural gas escapes from a leak, it will expand into an extremely cold (-260° F) gas. Severe frostbite may occur from contact with escaping natural gas or its associated components. Avoid the hazard by relieving the pressure before disconnecting any CNG fitting or line. Properly tighten all connections and thoroughly check for leaks before applying pressure.

WARNING Storage tanks must be tested according to specified procedures at required dates. Failure to do so relieves the manufacturer of all responsibility and is a violation of federal law. See the manufacturer's label.

WARNING After an accident, all tanks, lines, and fittings should be thoroughly checked by qualified personnel before the vehicle is used again.

All valves are closed when turned fully clockwise (viewed from the top of the valve handle), and open when turned counterclockwise (viewed from the top of the valve handle).

WARNING Always provide good ventilation, including near the roof and/or the ceiling. Avoid working in noisy environments, because the sound of leaking gas may go undetected.

WARNING Never attempt to find a leak with your hands. A large leak can freeze burn the skin. Never place your hands, or any other part of your body, on a leak.

Always have the properly rated fire extinguishers at hand. Be that certain automatic fire suppression equipment is in place and in operating condition.

WARNING Avoid heat near pressure relief valves. The manufacturer's rating is 212° F for the relief valve. If it vents, the area will be filled with natural gas.

WARNING Rust or corrosion on tanks, lines, fittings, and valves can be a serious problem. Any part with serious corrosion should be replaced. Fiberglass coating on tanks should be in excellent condition. Any cracks or serious scrapes may require tank replacement. Contact the manufacturer.

WARNING Tanks cannot be filled to more than 3,000 psi or 3,600 psi temperature-corrected. Use only authorized refueling stations with adequate pressure controls and venting capacity. Venting contents of tanks should follow any federal and state guidelines, including EPA.

WARNING *Use only fuel connections designed for use with that on the bus. Do not attempt to force damaged fittings. Keep sources of heat and ignition away from fuel system and refueling apparatus.*

For more information, see drawing #1589001 in the owner's information package supplied with the vehicle.

Compressed Natural Gas Fuel

The performance and reliability of a natural gas vehicle is dependent upon the quality of fuel used. BTU content of natural gas can vary depending on locale. Excessive moisture can cause loss of power, and regulator freezing. Other contaminants, specifically lubricants and oil, can cause serious damage which is not covered by the engine manufacturer's warranty. In addition, poor quality fuel can affect emission certification.

CAUTION *It is the owner's/operator's responsibility to ensure that clean, quality fuel is used to prevent damage to the fuel system components and power plant. Damage caused by poor quality fuel is not covered by Blue Bird warranty.*

Fuel control systems used on engines fueled by compressed natural gas contain electronic sensors and other delicate components that are not tolerant of contaminants. Vehicle performance is dependent upon clean fuel and a regular schedule of vehicle maintenance.

Compressed natural gas is expected to be delivered from the compressor station and storage cascade free of contaminants including oil, water, and particulates. Conditions exist in some CNG fill stations that cause inferior fuel to load into the vehicle's fuel storage system.

Compressed Natural Gas Filters

Particulate and coalesce type filters are installed in Blue Bird CNG fuel systems. The primary filter is of stainless steel construction and is located at the fill point. This filter can be checked for contamination by closing the main shutoff valve on the frame and then relieving pressure which is trapped between the check valve in the fill nozzle and the main system check valve. The owner/operator should establish a service interval based on quality of gas from the compressor station. It is recommended that the filter sump be checked after the initial fill and every fifth fill thereafter, or on a schedule based on need.

The secondary filter has a black anodized housing and is adjacent to the fuel shutoff solenoid close to the engine. The secondary filter can be checked after relieving system pressure. This is best accomplished by closing the main shutoff on the frame and running the engine until the fuel supply is depleted and pressure is zero. Contamination of the secondary filter should not occur if a proper maintenance schedule has been followed at the fill point primary filter. Contamination of the secondary filter indicates that the CNG storage cylinders on the vehicle are contaminated. The owner/operator should insist that fuel from a compressor station be clean and dry.



Replacement filter elements are available through the Blue Bird Service Department.

WARNING *Compressed natural gas is highly flammable, and pressurized gas can cause serious personal injury or death.*

Refueling

WARNING *Refueling must be conducted in well-ventilated areas to prevent accumulation of dangerous gas levels.*

The National Fire Protection Association has recommended guidelines for CNG refueling systems. State and local regulation regarding NGV refueling may preclude economic feasibility of indoor refueling (such as in New York City). However, the significance of this issue may diminish if increased experience with fuel leads to less stringent regulations.

CNG refueling transfers natural gas under pressure and may be set up as either slow fill or fast fill. Slow fill generally uses overnight refueling and requires less costly refueling station equipment than fast fill. However, fast fill refueling time is only slightly longer than gasoline refueling time. LNG refueling transfers a cold (260° F) liquid under pressure (around 15 psi) and generally takes slightly longer than conventional refueling because a greater volume of liquid is transferred to compensate for its lower energy content.

The refueling station has a supply connection hose and a coupling that must be properly attached to the fuel system fill valve. The supply side is regulated for maximum pressure and uses a proper purge valve when decoupling from the filler. The regulators and relief valves of the fill station must be checked for proper values and operation.

Fuel enters the bus coupling from the filler connection, travels through a one-way check valve into the fuel lines, and then into any open tanks. Any tank that is open is in communication with any other open tank through the common fuel lines.

WARNING *Do not refill with the engine running or any source of ignition or heat nearby. The refueling station must be in a safe working condition with approved operable relief and vent valves.*

A ground stud is provided for attachment of the grounding cable at the compressor station. Check that the tank shutoff valves are open. Any tank with an open valve will be filled; any tank with a closed valve will not. If the bus has been operating with some tanks closed, it is preferable to fill the empty tanks first and then fill the remainder. Fill to the desired pressure. Maximum is 3,600 psi at 70°F. (Most fill stations have a dome valve to make the temperature correction automatically.) When fueling is complete, open the fill connector purge valve. Use only fuel filling couplings designed for use with the CNG. Do not force damaged couplings together.

CAUTION *A check valve is included in the system behind the fill connector to prevent backflow of fuel when purging and disconnecting the fuel nozzle.*

The tanks are full at 3,000 psi, or 3,600 psi at 70° F. The pressure will vary with temperature, decreasing with lower temperature and increasing with higher temperatures. Filling apparatus compensates for the temperature effect.

WARNING *Never fill to more than permissible pressure. Contact the manufacturer if an accidental overfill occurs.*

Specific Gravity

The specific gravity of natural gas relative to air (air = 1.00) is 0.56 to 0.62, depending on gas composition. This means that natural gas is lighter than air. In the event of a natural gas leak, the gas will rise and dissipate given open conditions. There is no possibility of CNG accumulating in pools on the ground beneath a spill.

Odorants have been added that allow natural gas to be detected before reaching dangerous concentrations.

In the case of LNG releases, the cold vapor is initially heavier than the surrounding warmer air, so it stays low near the ground (a visible vapor cloud is often formed from the condensation of water in the cold air gas mixture). As the vapor cloud warms, it will increase in volume, rapidly rise and dissipate in an open environment.

Fuel Toxicity And Safety

Natural gas is a nontoxic gas. However, it is flammable under proper conditions. Also, it can cause suffocation if it displaces enough oxygen. LNG has the added safety concern of being a cold (260° F) liquid under pressure. Contact with LNG or associated cold components may cause severe frostbite. Furthermore, many common materials change their strength characteristics when exposed to LNG temperatures, thus presenting additional hazards.

WARNING *LNG tanks have the potential for explosions under circumstances such as those described for LPG explosions.*

Although natural gas has odorants to aid in detection of leaks, these odorants are removed during liquefaction; thus LNG vapors cannot be detected by smell. LNG odorants have been developed but are not commonly used due to the relatively restricted use of LNG at this time.

Flammability

Auto-ignition temperature for natural gas at atmospheric pressure is 1,004° F compared to an auto-ignition temperature range of 442° to 880° F for gasoline and approximately 500° F for diesel fuel. The risk of fire in the presence of an ignition source exists when the ratio of air to fuel is within flammability limits (i.e., fuel can not ignite if it is mixed with too much or too little oxygen). The flammability limits for natural gas are 5.3 to 15 % volume of gas in air. For comparison, the flammability limits of unleaded gasoline are 1 to 7.6 % volume of gasoline in air. As a practical matter, there is no oxygen present in CNG cylinders or LNG tanks, therefore ignition within the



cylinder or tank is not possible. In the event of a fuel leak, there will be a small area in which the air/fuel ratio is within the flammability limits. In a closed garage, or within the passenger compartment, ignition conditions are more likely to be met. Odorants used in CNG allow its detection before the lower flammability limit is reached.

Antiknock Properties

Natural gas has a research octane rating of about 130, making it relatively resistant to engine knock. The antiknock property is a result of the high ignition temperature, resistance to auto-ignition, and the relatively low flame speed of natural gas. Antiknock properties allow the use of engine compression ratios in the range of 15:1 (compared to 8:1 to 10:1 for gasoline). The low flame speed of natural gas results in a longer duration of combustion. To compensate for the lower flame speed, ignition timing is advanced. As with other fuels, knock may occur with advanced ignition timing, prolonged combustion (i.e., too lean a mixture), and excessively high compression ratios.

Energy Conversions

100-125 cubic feet NG	=	1.0 gallon gasoline
114,000 Btu	=	1.0 gallon gasoline
136 cubic feet NG	=	1.0 gallon diesel
83,700 Btu	=	1.0 gallon LNG
1 cubic foot NG	=	1,000 Btu

Vehicle Performance And Emissions

NGV performance, fuel economy, and emissions can be significantly altered with vehicle tuning (i.e., ignition timing, air/fuel ratio). Appropriate tuning adjustments can optimize performance, fuel economy, and emissions. Alternatively, a compromise tuning may be effected. Tuning optimization for power generally increases emissions. Substantial improvements in performance and emissions can be obtained using natural gas conversion kits specially designed for a given vehicle make and model. Further improvements can be achieved with factory-built, dedicated NGVs.

Starting Procedure

Make sure that the main shutoff valve and at least one tank valve are open. The fuel gauge shows empty if no fuel is available to the mixer. Check the tank and main fuel shutoff valves if no fuel is indicated on the fuel gauge. (Note that fuel gauge takes time to register after turning the key.)

Starting procedures are the same as for starting a gasoline engine vehicle. With the vehicle in neutral, turn the key until the engine catches. Do not press the accelerator. If the engine has trouble starting, depress the accelerator slightly and release when the engine catches. Pumping the accelerator does not help start the engine. Engine operation and characteristics should be similar to those of a gasoline engine.

Cold Start

For cold starts, in low ambient temperatures, natural gas has an advantage over liquid fuels because it is already in the vapor phase. With correct conversion kit installation and vehicle maintenance, cold start ability is better with natural gas than with gasoline.

Operation And Maintenance Of CNG Vehicle Components

CNG vehicles require Department of Transportation (DOT)-certified cylinders for the storage of pressurized (maximum 3,600 psi) natural gas. Refueling port and lines with pressure safety valves must also be installed. High pressure fuel lines from the storage cylinder lead to a pressure regulator/reducer, which reduces gas pressure in one or two steps. In a fuel-injected converted vehicle, a mixer/carburetor must be added for the injection of natural gas. In carbureted fuel systems, a specialized mixer/carburetor for natural gas may be installed. LNG vehicles require insulated, pressurized (10 to 35 psi) fuel tanks. LNG is vaporized in the fuel line and warmed in the heat exchanger, generally located under the hood. The pressure regulator reduces pressure before the vapors are transported to the mixer/carburetor.

CAUTION *Do not use CNG pressure lines or vent lines to clamp, hang, connect, or attach any items, including harnesses, hoses, power steering hose, refrigerant hoses, or any other item.*



TRANSMISSIONS

Allison Automatic Transmission

Important: Allison supplies far more detailed information about your particular transmission than space allows in this manual. Although we try to cover the most important points here, it is imperative that you read and understand the Allison Transmission Operator’s Manual for more details about operation, care, and maintenance. If you did not receive this manual with your bus, please contact the transmission supplier. Both Blue Bird Body Company and Allison Transmissions continually strive to improve the quality and performance of their respective products. For this reason, information and instructions in the Allison Transmission Operator’s Manual supplied with the bus will take precedence over the general information in this publication.

Allison Model 3000 Bus Series Transmission


The Allison electronic transmission provides five forward speeds and one reverse. Fourth gear is a 1-to-1 ratio while the fifth gear is an overdrive with a 0.75-to-1 ratio. The push-button shift selector is located on the right area of the dash. The transmission and selector must be in neutral to start the engine.

The service brake must be applied before the transmission will shift from neutral to drive or reverse. If an attempt is made to shift the transmission into drive or reverse without applying the service brake it will remain in neutral, an audible alarm will sound, and the Range Inhibit light on the instrument panel will come on. If this occurs, apply the service brake and then select the desired gear.

Transmission and shift selector will return to “N” when engine is stopped and power switched off. If it does not return to “N” or if it starts in any other gear, the unit has malfunctioned. Seek service immediately.

The push-button shift selector has “R”, “N”, “D”, down arrow, up arrow, a “MODE” button, and a digital display. When a range button is pressed, a tone sounds, the “SELECT” indicator displays the chosen operation (if the Electronic Control Unit [ECU] determines the shift is acceptable), and the transmission shifts to the starting range as indicated on the monitor display. In “DRIVE”, selection of a specific gear can be accomplished by pressing the “UP” or “DOWN” arrow buttons. Conditions resulting in the “CHECK TRANSMISSION” light, located in the instrument cluster, will disable the pad and no tones will sound (see Check Transmission Light).

The “MODE” button, located on the push-button shift selector, activates an alternate shift schedule. By default, the start up is in primary or power mode. Pressing the “MODE” button causes the transmission to enter the economy mode. The display will indicate the economy mode is engaged. In economy mode, the transmission shifts to higher gear at lower engine rpm.





Allison Model 3000 Bus Series Transmission Gear Selection

WARNING *When leaving the vehicle while the engine is running, the operator must ensure the transmission is in "Neutral", the parking brake is engaged, and the wheels are chocked. The vehicle may move unexpectedly without these precautions.*

R—Reverse. The vehicle must be completely stopped before shifting from forward to reverse or from reverse to forward. The select indicator and the monitor will display "R" when the vehicle is in reverse.

N—Neutral. Use neutral to start the engine, to check vehicle accessories, and for extended periods of engine idle operation. Under normal operation, the transmission is directed by the ECU to neutral during the startup procedure. This occurs automatically with the push-button selector. If the vehicle starts in any range except neutral, seek service immediately.

WARNING *Do not allow your vehicle to coast in neutral. This practice can result in transmission damage. Engine retard and braking assistance is not available when the transmission is in neutral. It may not be possible to get the transmission back into gear while the bus is moving.*

D—Drive. When "D" is selected, the vehicle will start to move in first gear and the transmission will upshift automatically through each gear as the speed increases. As the vehicle slows down, the transmission will downshift automatically. The select indicator will display the highest gear available and the monitor will display the current operating gear.

2, 3, 4, 5 Gears. Occasionally, the road conditions, load, or traffic conditions will make it desirable to restrict the automatic shifting to a lower gear. Positions "5", "4", "3", and "2" provide progressively greater engine braking for going down grades (the lower the gear, the greater the braking effect). Push the "Up" or "Down" arrow to the desired gear. The select indicator will display your choice and the monitor will display the gear the bus is operating in.

1 Gear. Use position "1" gear when pulling through mud and deep snow, when maneuvering in tight spaces, or while driving up or down grades. Low gear provides the vehicle maximum power and maximum engine braking power.

The transmission incorporates a hold feature to prohibit upshifting beyond the gear selected during normal driving. For downhill operation, however, the transmission may upshift beyond the selected gear when the engine's governed speed is exceeded, and damage to the engine is possible.

Allison Model 2000 Bus Series Transmission

The Allison transmission provides four forward speeds and one reverse. The transmission is controlled with the selector lever located to the driver's right. The selector lever must be in the "N" position (neutral) to start the engine. If the engine starts in any other position, the neutral start switch is malfunctioning and should be repaired immediately. Use "D" (drive) for all normal driving conditions. The service brake must be applied before the transmission will shift from neutral to drive or reverse. If an

attempt is made to shift the transmission into drive or reverse without applying the service brake it will remain in neutral, an audible alarm will sound, and the Range Inhibit light on the instrument panel will come on. If this occurs, apply the service brake and then select the desired gear. The vehicle will begin to move in first gear, and as you press the accelerator, the transmission will upshift automatically. As the vehicle slows down, the transmission will automatically downshift to the correct gear. Use "3" and "2" when the road, load, or traffic conditions make it desirable to restrict the automatic shifting to a higher range. When the conditions improve, return the range selector to the normal driving position D. These positions also provide progressively greater engine braking power (the lower the gear range, the greater the braking effect). Use "1" when pulling through mud or snow or driving up steep grades. This position provides maximum engine braking power. Use "R" (reverse) for backing the bus. The bus should be completely stopped before shifting from a forward gear to reverse. Reverse gear provides the greatest traction.

Allison 2000 Bus Series Transmission Gear Selection

WARNING When leaving the vehicle while the engine is running, the operator must be sure the transmission is in Neutral, the parking brake is engaged, and the wheels are chocked. The vehicle may move unexpectedly without these precautions.

R—Reverse. Use reverse to back up the vehicle. The vehicle must stop completely, with the engine returning to idle speed, before shifting from forward to reverse or from reverse to forward. If your bus is equipped with a reverse warning signal, it will activate when shift selector is in reverse.


CAUTION Do not idle in "R" (reverse) for more than five minutes. Extended idle time in "R" (reverse) may cause transmission overheating and damage. Always select "N" (neutral) whenever time at idle exceeds five minutes.

N—Neutral. Use neutral to start the engine, to check vehicle accessories, and for extended periods of engine idle operation. If the vehicle starts in any other range, seek service immediately.

WARNING Do not allow your vehicle to coast in neutral. This practice can result in transmission damage. Engine retard and braking assistance is not available when the transmission is in neutral. It may not be possible to get the transmission back into gear while the bus is moving.

D—Drive. When "D" is selected, the vehicle will begin to move in first gear and the transmission will upshift automatically through each gear as speed increases. As the vehicle slows down, the transmission will downshift automatically.

CAUTION Do not idle in "D" (drive) for more than five minutes. Extended idle time in "D" (drive) may cause transmission overheating and damage. Always select "N" (neutral) whenever time at idle exceeds five minutes.





2, 3, 4 Gears. Occasionally, the road conditions, load, or traffic conditions will make it desirable to restrict shifting to a higher gear. Positions “4”, “3”, and “2” provide progressively greater engine power and braking for going down grades (the lower the gear, the greater the braking effect).

1 Gear. Use position “1” gear when pulling through mud and deep snow, when maneuvering in tight spaces, or while driving up or down grades. Low gear provides the vehicle with its maximum power and maximum engine braking power.

Park. If your bus is equipped with a “Park” selection, use it only after coming to a complete stop, and then apply the parking brake. Do not rely upon the transmission park pawl position alone to prevent the bus from rolling.

Range Inhibited Light

Under certain operating conditions, the Transmission Control Module (TCM) may determine that it is necessary to restrict gear selection to protect the transmission from damage and provide safer operating conditions. When this happens, the “RANGE INHIBITED” warning light will activate, and the transmission may not respond to the operator’s commands. Please see the Range Inhibited Light and Shift Inhibits section of the Allison Transmission operator’s manual for more information.

Check Transmission Light

The “CHECK TRANSMISSION” light is located in the instrument panel. The electronic control system is programmed to inform you if operating parameters have been exceeded and to automatically take action to protect the transmission. A diagnostic code will be registered when the “CHECK TRANSMISSION” light is on.

When the engine is started, the “CHECK TRANSMISSION” light turns on for a few seconds. This momentary indication shows that the lighting circuit is working properly.

If the light illuminates after startup, a problem has been detected. A diagnostic code will be recorded and shifts may be restricted. Depending on the problem’s severity, the operator may continue driving to reach service assistance. The TCM may restrict upshifts and downshifts. Please see your Allison Transmission operator’s manual for more details on how shifts may be inhibited.

CAUTION *If the transmission will not shift into “D” (drive), or “R” (reverse), it may be because of an adverse operating condition such as; engine RPM too high or service brakes not applied when attempting to shift from neutral. Check for the illumination of the “RANGE INHIBITED” light or “CHECK TRANS” light. See the appropriate section of the Allison transmission manual.*

Allison Automatic Transmission Driving Tips

Accelerator Control

The pressure of your foot on the accelerator pedal influences the automatic shifting. An electronic signal tells the ECU how far the driver has depressed the pedal. This provides the accurate shift spacing and control necessary for maximum performance.

Downshift or Reverse Inhibitor Feature with Allison 3000 PTS Transmission

Although there is no limitation on upshifting, there is a limit on downshifting and shifts from neutral into drive or reverse. If a downshift or neutral-to-range shift is selected when the engine speed or throttle position is too high, the ECU/TCM will not allow the shift until reaching a lower speed. If idle speed is too high, shifts to range are prohibited. A continuous "beep" tone sounds when reverse is selected during forward movement or if a neutral-to-range shift is selected at too high an engine speed.

Cold Weather Starts

Most Allison transmissions are programmed to restrict operation until operating temperature is reached. When the transmission fluid temperature is below -25° F (-32° C), the transmission will not shift into an operating range and the "Check Transmission" light will be illuminated. When the transmission fluid temperature is between -24° F and 20° F (-31° C to -7° C), the transmission will operate in 1st, 2nd, or Reverse only. If there is no other problem with the transmission, the "Check Transmission" light will not be illuminated. For transmission fluid temperatures above 20° F (-7° C), the transmission will shift and operate in a normal manner. Be sure to read and understand the cold weather operation instructions in the Allison Transmission™ Operator's Manual supplied with the bus.

Using the Engine to Slow the Vehicle

To use the engine as a braking force, shift the range selector to the next lower range. If the vehicle is exceeding the maximum speed for a lower gear, use the service brakes to slow the vehicle to an acceptable speed where the transmission may be downshifted safely. After reaching the lower speed, the ECU will automatically downshift the transmission. Engine braking provides good speed control for going down grades. When the vehicle is heavily loaded, or the grade is steep, it may be desirable to select a lower range before reaching the grade. If engine-governed speed is exceeded, the transmission will upshift automatically to the next range.

CAUTION *The transmission incorporates a hold feature to prohibit upshifting above the range selected during normal driving. For downhill operation, select a lower transmission range. However, if engine governed speed is exceeded, the transmission may upshift to the next higher range. Use the vehicle brakes to prevent exceeding engine governed speed in the held range.*



WARNING *If you only downshift or only use the service brakes when driving down a steep grade, you can lose control. To maintain control, combine downshifting, braking, and other retarding devices. Downshifting to a lower transmission range increases engine braking and helps maintain control. The transmission has a feature to prevent automatic up shifting above the lower range selected. However, during downhill operation, if the engine governed speed is exceeded in the lower range, the transmission may upshift to the next higher range. This will reduce braking and could cause a loss of control. Apply the vehicle brakes or other retarding device to prevent exceeding engine governed speed in the lower range selected.*

Electric Retarder (If Equipped)

- The electric retarder control switch is mounted on the vertical panel, left of the driver. It has five positions (one “off” and four retard positions). Each higher number increases the amount of retardation to slow the vehicle.
- Remember the retarder is a vehicle slowing device, not a stopping device. A full stop must be accomplished with the service brakes.
- Always release the accelerator completely before applying the retarder.
- Do not use the retarder when road surfaces are slippery.
- Consult the retarder manufacturer’s Owner’s or Operator’s Manual for additional information.

Transmission Indicators

Check Transmission Indicator

While driving, be alert to any abnormal shifting, unusual sounds or vibrations, smells, or frequent illumination of the "CHECK TRANSMISSION" light. If you experience any of these, get service immediately.

Transmission Oil Temperature Gauge

An optional gauge on the instrument panel indicates the transmission oil temperature. Extended operations at low vehicle speeds with the engine at full throttle can cause excessive oil temperatures. These temperatures may overheat the engine cooling system and lead to engine and/or transmission damage.

If excessive temperature is indicated by the engine coolant temperature gauge, stop the vehicle and check the cooling system. If the cooling system appears to be functioning properly, shift to neutral and accelerate the engine to 1,200–1,500 rpm. This will reduce the transmission temperature to operating level within two or three minutes. If high temperature persists, stop the engine and have the overheating condition investigated by service personnel.

If the transmission oil temperature gauge indicates excessive temperature, check the oil level in transmission (refer to the Oil Check Procedure in your Allison Transmission Operator's Manual). Stop the vehicle and shift to neutral. Accelerate the engine to 1,200–1,500 rpm. The temperature should return to normal within two or three minutes before the vehicle resumes operation. Normal temperature for both on and off-highway operation is 160° to 200° F. Oil temperature should never exceed 250° F. In units equipped with electronic transmissions, if the sump oil temperature reaches 250° F, the TCM will inhibit operation in the higher gears and turn on the "OIL TEMP" light, located on the shifter cover.

If high temperature in either engine or transmission persists, stop the engine and have the overheating conditions investigated by maintenance personnel.

CAUTION *The engine should never be operated for more than 30 seconds at full throttle with the transmission in gear and the vehicle not moving. Prolonged operation of this type will cause the transmission oil temperature to become excessively high and will result in damage to the transmission.*



BRAKING

Antilock Braking System (ABS)

In a vehicle equipped with an antilock braking system (ABS), motion sensors detect the speeds at which the wheels move. These sensors transmit this information to an Electronic Control Unit (ECU). If the wheels start to lock, the ECU signals the modulator assembly to regulate the brake pressure of each locking wheel.

An ABS indicator lamp on the dash (see "Indicator Light Panel" in Instrument Panel section) warns the driver of possible system faults and provides blink code information to diagnose the system. If this light is activated during normal vehicle operation, the driver may complete the trip, but the vehicle must be serviced as quickly as possible.

Hydraulic Brakes

WARNING Do not tap into the brake system or the power steering system to provide pressure for accessories. Tampering with either of these systems could result in loss of braking ability and/or steering ability.

CAUTION Hydraulic brake systems are power-assisted. Braking capacity is reduced without engine assist. Do not move bus with dead engine.

The electric power backup pump will operate whenever the engine is not operating and the key switch is in the ON position, or when the key is in the "OFF" position and the brake pedal is depressed. Test daily by feeling for the electric motor operation while applying the brakes with the engine not operating, or when the key switch is in the "ON" positions and the engine is not operating. Initially, the pedal will be hard to push, but will become softer as the electric motor starts.

WARNING Do not drive the bus when the electric backup pump does not operate properly.

Dual Brake System

The dual brake system allows the driver diminished brake capacity in case either the front or the rear brake circuit fails.

CAUTION When one section of the dual system fails, the following conditions will exist.

1. Bus stopping distance will increase. Drive the bus only with extreme caution. Service immediately!
2. The brake pedal will be softer to push.
3. The brake pedal will travel farther than normal.

Brake Warning System

The brake warning system includes a buzzer and a dash-mounted red light labeled "BRAKE SYSTEM". The light and buzzer will activate during the following conditions:

- Engine is running, brakes not applied, with a loss of electrical power to the electric backup pump motor.
- Engine is running, brakes not applied, with a loss of power assist from the power steering pump.
- Engine is running, brakes are applied, and either the front or rear section of the system has failed. The backup pump, buzzer, and light will remain on even after the brake pedal has been released.
- Engine is not running, brakes are not applied, but ignition key is "ON". This condition should happen every time the driver starts the bus. The bus should not be driven if the backup pump system is not working. The backup system should go off when the engine starts.
- Engine is not running, brakes are applied, and ignition is in ON position. This is a method for checking the backup pump.

With the engine not running and the ignition "OFF", a depressed brake pedal will cause the backup motor to run with no light and buzzer. The backup system should go off when the pedal is released. Without the assist of the power steering pump and without the assist of the backup pump, the master cylinder will allow the brakes to be applied. However, brake capacity will be very limited and the bus should not be driven under these conditions.

Parking Brake (Hydraulic Brakes)

The parking brake is designed to hold the loaded bus up to a 20 percent grade. The parking brake is not to be used as a normal service brake, but can be used to help stop in an emergency situation.

WARNING *The parking brake is designed to hold on a 20% grade, on a clean, dry, and smooth road surface. Parking on wet, icy, or snow-covered grades is not recommended. Chocking the wheel(s) is recommended when parking on any grade.*

When the parking brake is applied, and the ignition switch is "ON", a dash-mounted yellow light labeled "PARK" will warn the driver that the brake is applied. The bus should not be driven when the parking brake is applied. Doing so will prematurely wear the parking brake or damage other drive train components.

WARNING *Improper adjustment of the parking brake can significantly reduce the holding ability of the parking brake system.*



Hydraulic Brake/Throttle Interlock System (Optional)

The hydraulic brakes system of some All Americans include an optional Brake/Throttle Interlock feature which, when active, automatically applies the brakes and disables the throttle when the vehicle ignition is on and the lift door is open.


An on/off switch in the Driver's left switch panel enables the Driver to activate or deactivate the interlock system. When active, the interlock applies the service brakes. An audible alarm sounds in the event of an interlock malfunction.

When used with the existing vehicle parking brake, the brake interlock uses the vehicle's service brake system to provide additional brake holding action.

WARNING *The brake interlock is a safety device and is not intended to be used a parking brake. The Interlock system should never be used to stop the bus. Do not open the bus door(s) while the vehicle is in motion.*

The following are decals along with WARNINGS located forward of the switch panel below the driver's side window, on All Americans with hydraulic brakes.

Read Warnings and Operating Instructions prior to using.



690 Brake Lock

TO LOCK:

1. Set parking brake
2. Move lock switch to ON position

TO RELEASE:

1. Move lock switch to OFF position
2. Release parking brake

WARNING

Serious injury or death can occur if these instructions are not followed.



Vehicle equipped with Brake Lock System. Operator must read and understand operating instructions before using vehicle. Brakes will release if ignition is turned off when Brake Lock is remotely activated. Do not use Brake Lock in place of original equipment parking brake. Always set parking brake and use wheel chocks and outriggers with Brake Lock. Do not use Brake Lock for overnight or prolonged parking. Release Brake Lock before moving vehicle. Brake Lock and warning circuit are disabled if battery power is lost or disconnected.

WARNING

Serious injury or death can occur if these instructions are not followed. Opening vehicle service door causes brakes to be applied. Vehicle equipped with Door/Brake Interlock. Operator must read and understand operating instructions before using vehicle. Brakes will release if ignition is turned off when Door/Brake is remotely activated. Do not use Door/Brake for overnight or prolonged parking. Close vehicle service door before moving vehicle. Door/Brake and warning circuit are disabled if battery power is lost or disconnected.

Air Brakes

All Americans equipped with air brakes employ separate systems for the front and rear service brakes. A separate reservoir and air gauge is provided for each of these systems. A dual treadle valve is provided for operating the service brake system. In the event there is a failure in the air reserve for the front brakes, the rear service brakes can still be applied using the treadle valve, since the two service brake systems operate independently. If there is a failure in the air reserve for the rear service brake system, the front service brakes and the rear spring brakes can be applied through the treadle valve. This allows the operator to use a normal method of braking even though part of the system is malfunctioning. However, in the case of an air reserve failure, the low air pressure warning buzzer will activate, indicating trouble, and the respective air gauge on the dash will show which system has lost air pressure. The bus must not be operated under those conditions, but repaired before continuing operation.

The rear spring brakes can also be controlled by a dash-mounted valve located on the lower portion of the instrument panel. The spring brakes cannot be fully released until the air reserve pressure is above 60 psi. These brakes are in the released position when the control valve is pushed in, and in the applied position when the control valve is out. In the event there is a loss in air pressure, the valve will automatically move to the brake applied position and cannot be released until the air reserve pressure has been replenished.

Air Brake/Throttle Interlock System (Optional)

All Americans equipped with air brakes may include an optional Brake/Throttle Interlock feature which, when active, automatically applies the service brake and disables the throttle when the vehicle ignition is on and the lift door is open.

An Interlock Override switch in the Driver's left switch panel enables the Driver to temporarily override the interlock system. When used with the existing vehicle parking brake, the brake interlock uses the vehicle's service brake system to provide additional brake holding action.

WARNING *The brake interlock is a safety device and is not intended to be used as a parking brake. The Interlock system should never be used to stop the bus. Do not open the bus door(s) while the vehicle is in motion.*

Parking

Use the dash mounted valve to apply the rear spring brake when parking the bus. When the parking brake is applied, and the ignition switch is ON, a dash-mounted yellow light labeled PARK will warn the driver that the brake is applied.

CAUTION *Do not attempt to move bus before spring brakes are released.*

Draining Air Tanks

Condensation must be drained from the air tanks daily. To drain tanks properly, leave cocks open until all air escapes and draining stops.





HEATERS

Blue Bird heaters depend on engine generated heat to function. Heat from the engine is picked up by the engine coolant, which is pumped through the heater cores inside the bus, and then back into the engine. A typical heater inside the bus includes a heat exchanger coil, (core) and fans which move air across the coil. Air moving across the core picks up heat from the engine coolant and transfers it into the bus.

Satisfactory performance of the heaters is dependent upon:

- Adequate engine (coolant) temperature, which is controlled by the thermostat rating (which should never be higher than recommended by the engine manufacturer). Some All Americans feature optional shutters on the radiator that help to regulate engine coolant temperature.
- Coolant flow, which varies with engine speed. It can be increased, if necessary, with the use of an auxiliary water pump. The heaters are rated at six gallons per minute.
- Blower motors have multiple speeds and can be checked by operating the motors individually, while listening for variations in speed.

Heater Operation

Be sure the engine radiator is full and all coolant flow valves are open. See charts on valve location.

CAUTION Do not leave the engine running while opening or closing valves.



Warm the engine to operating temperature, running at up to 1,800 rpm if possible, and then turn on the heater fans and the auxiliary water pump if so equipped.

During extremely cold weather, operating the heater fans will cause the engine temperature to drop noticeably as heat from the engine is transferred into the bus. Also, the engine will generate more heat as it works under load. When the engine reaches operating temperature, the driver can control heater blower speeds for optimal defrosting and overall passenger comfort.

Control Panel Outlet Locations

The heater control panel is located on the dash to the right of the instruments. The indicated switches and levers control the motors and air outlets as shown.

The heater is located in the right front corner, forward of the entrance door. An auxiliary unit is located under the driver's seat. Electrical switches and mechanical diffusers control the volume and direction of airflow. The main heater has a three-speed control switch for



manual low or high speed operation, and an additional maximum output position for flash defrosting or extreme conditions. All the air from the main heater blower is directed to defrosting when the main outlet and foot warmer outlet are closed.

The Heater Master Switch turns off all heaters and radio to allow the driver to hear sounds outside the bus; for example, at a railroad crossing. When the switch is in the “on” position, neither the heater blowers nor the radio will operate.

Defrosting

Windshield fogging and frosting is caused by warm, humid air coming into contact with a colder windshield, which causes the moisture in the air to condense and freeze if the windshield is cold enough. The warmer the windshield, the less moisture will condense. During initial warmup, the defroster blowers should be operated at low speed to preheat the inside of the windshield glass. If the defrosters are not turned on until after condensation starts, it is more difficult to heat the glass and drive moisture away.

As passengers are loaded, the moisture content of the air inside the bus increases. This moisture content tends to be lowered by opening the heater fresh air inlet. Conditions will be especially difficult when large passenger loads stay on board for extended periods of time, such as on a charter or over-the-road activity trip. Traveling at highway road speeds causes heat to dissipate through the windshield glass, and each passenger’s breath continually adds to the air’s moisture content. To reduce fogging, open the forward driver’s window slightly to let the moist air escape.

Heater Defroster Location

The blower in the front main heater contributes to keeping the driver’s area glass clear of fog and frost. See OUTLET LOCATION diagram. For best results, fresh air should be flowing into the heater. To inspect the fresh air intake and make sure it is working properly, open the front access panel on the driver’s side of bus.

Driver / Passenger Comfort

When the windows are defrosted, the other openings can be set as necessary for comfort. The adjustable diffusers on the dash can be directed toward the driver and/or passengers as desired. The auxiliary unit under the driver’s seat has a two-speed electrical switch and it directs air upward for the driver’s left side and forward around the steering column area.

Standard Heater Cut Off Valves


Valves are provided in the heater piping to permit isolation of the heating circuit from the engine coolant circuit. This is useful in case a leak occurs within the system, or to restrict the flow of hot water through the bus during warm weather.

When Valves No. 1 and No. 2 in the diagrams below are closed, engine coolant is prevented from circulating through the heaters. (This does not restrict circulation of the engine cooling circuit, so it is safe to operate the engine with the valves closed.)

Engine: Caterpillar C7


VALVE NO.	LOCATION
1	AT THERMOSTAT HOUSING
2	AT TRANSMISSION OIL COOLER

All American Rear Engine



A3RE

All American Forward Engine



A3FE

- PRESSURE LINES
- - - RETURN LINES
- ① VALVES



CARE & MAINTENANCE

Although in most transportation operations, maintenance tasks will be performed by service technicians, familiarity with the basic technical data in this section will enhance the Driver's overall understanding of the vehicle, and may serve as a convenient reference for service technicians rendering roadside assistance. This section also contains general cleaning and care guidelines. For thorough service information and procedures, refer to the All American Service Manual.

Actual operating conditions must be considered and maintenance intervals adjusted accordingly. If at any time a system does not perform satisfactorily, corrective service should be performed at once. It is important that personnel attempting the repair or maintenance of this vehicle have access to, and a thorough knowledge of, the appropriate Blue Bird Service Manual.

ELECTRICAL

CAUTION *Repair and/or modification of the electrical system, including adding components, should be referred to a trained, experienced technician.*

The following guideline must be observed when working on the vehicle electrical system. Be particularly cautious when adding components that they do not exceed the ability of the electrical system as designed and manufactured.

1. Disconnect the battery before beginning any repair or modification to the electrical system.

WARNING *Always disconnect the battery negative NEG (-) terminal first to avoid sparks/arcing.*

2. Use only the proper gauge wiring with high temperature insulation, compliant with SAE J-1128 (150° C).
3. Be certain any added component is fitted with an adequate fuse, and that it does not exceed the capability of the electrical system as designed and manufactured.
4. Any "push on" type connectors must be insulated.
5. When installing or repairing wiring, always observe the following precautions:
 - Install clamps and ties to prevent chafing and contact with sharp edges.
 - Support wiring with insulated clamps at least every 30 inches (76 cm).
 - When the wiring must flex (i.e., when connected to moving parts like the engine), be certain to provide adequate slack loops.
 - Be certain to provide adequate length to prevent tension on the wires or connectors.
 - Be certain wiring is secured at least 4 inches (10 cm) from high heat sources (i.e., engine, exhaust system, transmission etc.).
 - Always use an appropriate rubber grommet when the wires must pass through a hole.
 - Protect all "hot" primary and ignition wires with an appropriate loom.
 - Never route a wire in contact with a fuel line.
 - Do not route wires in contact with plastic components.
6. Always be certain that all ground connections are replaced when wiring is performed on engine components.
 - The alternator ground strap must be a minimum 6 gauge wire.
 - The engine must have a ground strap that connects to the transmission housing. Use a bolt that connects the engine and transmission to ground to the frame. Use a "star" lock washer to make this connection. Allow adequate slack for motion between the engine/transmission and the frame.
7. Do not splice into existing wires when adding components. Run new wiring full length to an appropriate source connection and provide proper fuses.
8. When accessories are added, check installation guides very carefully. You may need to install a control relay for proper operation.



- Use a blank circuit breaker in the electrical panel if possible. If the accessory must be on during cranking, connect directly to the "hot bar". Always install the appropriate fuse in the circuit.
9. Always install insulating rubber boots on 6 gauge "hot" connections whether to the alternator, ammeter shunt, or another junction.

WARNING *To avoid sparks and arcing, always connect the negative NEG (-) battery terminal last.*

Wiring Circuit Color Code Major Circuits

FUNCTION	COLOR
LEFT REAR DIRECTIONAL LIGHT	YELLOW
RIGHT REAR DIRECTIONAL LIGHT	DK.GREEN
STOP LIGHTS	RED
BACKUP LIGHTS	BLUE
TAILLIGHTS	BROWN
GROUND	WHITE
IGNITION FEED, PRIMARY FEED	BLACK

Refer to the master wiring diagram for wire colors for other circuits.

Interior Lights

<i>Lamp Description</i>	<i>Trade Name</i>	<i>Trade No.</i>	<i>Color</i>	<i>Bulb No.</i>
Dome	Weldon™	8005	(Standard)	89
	Weldon™	8010	(Deluxe)	93
Stepwell	Arrow™	35		67
Emergency Door Light	Weldon™	8025		67
Switch Panel Pilots	Cole Hersee™	PL19		53
	Dial™	41204-1211		68
Switch Panel Illumination		1314962		53

Exterior Lights

Directional	KD™	772-9105		1156
	Weldon™	1010 Series Plain, w/Arrow™	Red, Amber 1156	
	Signal Stat™	1604		1156
Warning Light	Arrow™	B-776-A12		4433A
		B-776-RR		4433R
	Weldon™	1020-Series	Red and Amber	4636
Warning Light Halogen	Weldon™	H3 12V 55W		H3
Cluster and Marker	Weldon™	5050	Amber and Red	409
	Peterson™	122	Amber and Red	194
Side Directional	Truck Lite™	120034	non-replaceable	
	Arrow™	059-9900021CP		1073
Stop-Tail/Tag	Grote™	01-5085-88		1157
	Signal Stat™	2103		1157
Backup	KD™	854-5301		1156
	Weldon™	7-1010-1		1156
Stop	Weldon™	1010	Red	1156
	Arrow™	438		1157
	Signal Stat™	1605		1156
	KD™	772-9105		1156
Destination Sign				89
School Bus Sign				TS93




Doran Warning Light Monitor

Warning lights are such an essential safety feature, it is important to know when they are not working properly. This is the function of the Doran monitor. Its display is a schematic of the lights as they appear outside the bus. If current is flowing through a particular bus lamp circuit (i.e., the light is on), the monitor senses this and lights the corresponding monitor bulb. If the bus lamp burns out, current ceases and the corresponding monitor bulb goes out, indicating a fault. Once the defective lamp is replaced, and the warning lights are working normally again, this also should be shown by the monitor.

The Doran monitor is a reliable, long life device, but as with most electrical instruments, it can be overheated and damaged if an overload occurs in a bus light. Such overloads can exist if a bus light circuit becomes shorted, forcing current through a coil in the monitor, which exceeds the coil's rated capacity. Short circuits can occur if improper connections are made during installations, bus repairs, etc. If the monitor has an optional thermistor overload protection, the tail light circuits are overload protected (thermistors are located on the bottom of the component side of the printed circuit board).

If the Doran monitor is not working properly, check the troubleshooting chart on the next page to find a possible cause and solution.

The Doran Warning Light Monitor™ does not display any indicator LEDs:



- An overload situation has created an open circuit. Check the system fuses.
- An overload or physical damage has burned or broken a conductor on the printed circuit board:
 - Extra lights have been added to the circuit; i.e., trailer lights, etc.:
 - Remove the extra lights from the circuit
 - Replace the damaged printed circuit board
- Excessive vibration or abuse has resulted in a damaged monitor. Replace the printed circuit board

A particular LED on the Doran Warning Light Monitor™ does not display, but the bus running lights are operating properly:

- There is an open coil in the monitor
 - The coil is burned due to an overload. Replace the coil kit.
 - A solder joint has weakened (a cold solder joint). Flow new solder on the connection.
 - The reed switch has failed. The reed has broken or the contacts have failed. Replace the reed switch kit.
 - The printed circuit board is broken or burned. Replace the printed circuit board.
 - There is an open in the LED circuit. Replace the LED.

A monitor LED indicator is on but, the bus running light indicated is not operating, or the bus running light switch is in the off position and the monitor indicates the running lights are operating:

- Replace the coil and reed switch kit.

Neither the bus running lights nor the Doran Warning Light Monitor™ operate properly:

- The running light bulb may be burned out. Replace the light bulb.

2. The overload thermistor has protected the circuit from overload. Remove the overload condition.

- A short
- Incorrect light bulb/s
- Extra lights; i.e., trailer lights, etc.

CAUTION Do not attempt to check a light emitting diode (LED) with an ohmmeter. Some digital volt meters (DVM) have a diode checking position, which is acceptable to test LEDs. Any repair of the Doran Warning Light Monitor™ should be referred to a qualified technician.



Circuit Breakers


The electrical system is protected by circuit breakers located in a side mounted electrical box below the driver's window. If a current overload or "short" should occur in any body circuit, it will trip the circuit breaker. If a short occurs and the circuit breaker breaks, the circuit breaker will reset when the element cools; usually in about 15 seconds. A short may be indicated by blinking lights or fluctuating gauges. The shorted circuit should be corrected immediately. Refer to body or chassis master wiring diagrams. A complete wiring diagram is available from Blue Bird Body Company Technical Publications.

To access the electrical panel, open the access door located outside the bus below the driver's window. Use of appropriate amperage circuit breakers is required.

ACCESSORIES AND ADDED COMPONENTS

When adding accessories and aftermarket components, it is important to consider the results very carefully.

- Does the component over burden the electrical system?
- Does the accessory interfere with any of the driver's controls?
- Does the accessory interfere with the driver's field of vision?
- Heavy components and accessories must be mounted near, or below, the floor line to avoid raising the vertical center of gravity.
- Will passenger safety and comfort be adversely affected?



DOOR ADJUSTMENT & LUBRICATION

Maintenance procedures for entrance doors must be performed by qualified technicians at intervals of one month or 1,000 miles, whichever occurs first.

Continuing Maintenance Requirements

- Keep working parts of control tightened.
- Lubricate all working parts periodically, including hinges and overhead controls.
- Repair or replace worn seals.
- Maintain proper door opening and closing adjustment.

Outward Opening Door Adjustment

Outward Opening Doors are mounted in a prefabricated framework, which eliminates the effect of body construction variations on door and seal operation. Doors are suspended completely on sealed ball bearings located at the top corners of the framework, inside the body. The interlink connection between the doors is a single assembly with oppositely threaded, spherical bearing rod end connectors at each end, providing simple link length adjustment without disassembly. Loosen the lock nut, turn the tube, and retighten the nut when satisfactorily adjusted. The geometry of the mechanical link between the doors causes the rear door to close well ahead of the front door, so that the front nosing seal rubber always overlaps the rear. Oil impregnated bronze bearings in the lower corners of the framework serve as pivots (not supports). All controls and mechanisms and the complete lower step tread are sealed inside the bus and out of the weather when the door is closed.


Outward Opening (Air Powered) Adjustment

The pneumatic actuator is a cylinder connected to a lever on each door, located inside the header cover. An interconnecting link between the doors controls the operation sequence. A safety release valve is located over the door. Air switches inside the header cover operate Stepwell lights. A two way manually operated valve manages the driver's door control. Air pressure holds the door either open or closed, depending upon the position of that valve. The operation speed is adjustable by use of flow control valves located on the actuator.




Jackknife Door Adjustment

1. Loosen the roller bracket at the top of the rear door.
2. Adjust the length of rod (between the door control and the door) and the location of the rod end bracket on the door for proper open and closed position.
 - 2.1 Lengthen the rod if the door opens too far and does not close against the top seal.
 - 2.2 Shorten the rod if the door closes too hard and does not open far enough.
 - 2.3 Move the rod end bracket forward if the door does not close against the seal and does not open far enough.
 - 2.4 Move the rod end bracket rearward if the door opens and closes too far.
3. Attach the roller bracket to the rear door and adjust.
 - If the rear door hangs in the track when starting to close the door, move the bracket to the rear.
 - If the rear door does not open to the front enough, move the roller forward.
4. Perform the following adjustments and maintenance for ease of operation. The top of door should be approximately $\frac{3}{8}$ inch below the door header.
 - 4.1 Move the door upwards so that the rubber door sweeps do not drag on the stepwell treads. Adjust door height by loosening the bolts and nuts that attach the front door panel to the front hinge. Holes in the hinge are slotted. This permits vertical adjustment of the door.
 - 4.2 Ensure that the top edge of the door nosing rubber does not drag on the doorstop header rubber. Remove the first three upper screws in the inner and outer nosing rubber retainer strips and force the nosing rubber downwards. Replace the screws after the rubber nosing has been adjusted.
 - 4.3 The rear upper corner of the rear door panel should not drag on the rubber door stop on the header. To provide the required clearance, move the door roller bracket towards



Roller Bracket



Rod End Bracket

the rear of the bus. This will effectively move the door panel away from the doorstop rubber.

- 4.4 Clean the stepwell rubber treads and lower the door rubber sweeps regularly. Cleaning these surfaces will reduce friction as the door is operated.
5. Ensure that the door control rod end bracket is mounted squarely on the door. If it is not, the yoke end pivot pin will bind. Adjust it by loosening screws and tightening after the bracket has been squared up.
6. Inspect the pivot nut on the rod end bracket for burrs or other surface irregularities. Grind or file the pivot nut so that its upper and lower surface is smooth.
7. Lubricate the door hinge pin with a spray type lubricant (LPS No. 1, or equivalent). Lubricant should penetrate behind each hinge lug. Door hinges will operate quietly if properly lubricated.

Power Jackknife Door Adjustment

The following adjustments and lubrications should be performed on the power jackknife door to ensure its proper operation.

1. Lubricate the center hinge with LPS No. 1, or equivalent, lubricant.
2. Adjust the actuator yoke so when the cylinder rod is fully extended, the door is not forced beyond its normal stopping point at the front stepwell band. Adjust the actuator mounting bracket when required. Improper adjustment of the cylinder yoke can cause premature failure of door components.
3. Adjust the switch striker plate on the actuator to prevent binding in the closed position.
4. Ensure that the roller bracket is installed squarely on the rear door panel.
5. Ensure that the center hinge barrel is not binding against the outer skin of the rear door panel.
6. Adjust opening and closing speed of the door with the valves located on cylinder. Air pressure should be at normal operating range (100 to 125 psi) during this adjustment.
7. Torque the upper pivot bracket retaining screw at the lever assembly to 20 Ft. lbs. (27 N•m).

Sliding Bolt Vandal Lock

Lubricate the sliding bolt mechanism of the Sliding Bolt Vandal Lock every six months or 6,000 miles (whichever occurs first). Use LPS-1 spray lubricant, or equivalent.




Security Lock Lubrication (Outward Opening Door)

If the Outward Opening Door Security Lock becomes difficult to operate, remove the access plate on the inner door panel and lubricate with No. 2 lithium grease. (Access plate shown removed in illustration.)

Lubricate security locks every six months or 6,000 miles, whichever occurs first. Using LPS-1 or Apply™ lubricant (or equivalent), spray into the bushing and shaft in the center at the base of the lock handle. Also spray lubricant into key lock mechanism. Rotate the lock handle to ensure smooth operation.

Manual Security Lock (interior)



Access Doors

Periodic maintenance is necessary to prolong the life of access door latches, locks, and hinges. Each week, clean and inspect the door hinges and latch mechanisms. Clean with a nonabrasive degreaser or cleanser as required. Every three months, lubricate with either a graphite-type lubricant or a spray-type lubricant such as LPS. Following is a list of access doors for which these maintenance procedures are recommended:

- Battery Compartment Door
- Luggage Compartment Door
- Tire Compartment Door
- Fuel Fill Door
- Radiator Fill Door
- Side Electrical Panel Door
- Left and Right Hand Front Access Doors

Glove compartment and emergency equipment doors should be inspected on a daily basis. Open and close to ensure proper operation. If necessary, follow the same lubrication procedure as outlined above.

SEATING CARE

Seat Belt Inspection And Maintenance

Inspect seat belts and their attachments, at least weekly. Check seat belt buckles and adjustability to ensure proper operation. If necessary, lubricate the buckle with a graphite lubricant. When a buckle is found to be inoperable, replace it immediately. If there are any defects in the webbing (i.e., torn or frayed), the seat belt must be replaced immediately to ensure passenger safety. Hand wash webbing with warm water and mild soap. Rinse thoroughly and dry in the shade. Do not bleach or re-dye, because such processing may severely weaken the assembly.

WARNING Do not bleach or dye the webbing. Such processing may severely weaken the assembly.

Seat Inspection And Maintenance

Blue Bird seats are built to meet Federal Motor Vehicle Safety Standards. In order to provide a greater margin of safety during passenger transportation, follow these guidelines:

- Inspect and, if necessary, tighten seat leg and wall side mounting bolts every 90 days.
- Inspect and, if necessary, tighten cushion attachments weekly.
- Inspect upholstery for cuts and tears every 90 days. If upholstery is torn, remove it by taking out the staples at the bottom front of seat back or bottom of cushion and pulling the cover away. For installation of new cover, reverse this procedure.
- School bus seats are equipped with a special foam back pad. If the pad becomes damaged, it should be replaced with an approved part. Aftermarket suppliers should be checked for compliance with Federal standards.

DRIVER'S SEAT LUBRICATION

Moving parts of the driver's seat require lubrication for ease of operation, as well as longevity of the seat and prevention of excessive wear.

Currently available is white lithium-based grease in an aerosol can. It gives excellent coverage when carefully directed into moving part joints. The very light coating of lubrication provided by aerosol-carried solvent-type solution works very well for penetrating into a joint and cleaning away dirt, but it should only be depended on for lubrication if it is applied frequently. A common 10W30 or 10W40 motor oil will provide good lubrication.

Remember that all moving part joints, tilt pivots, slide forward/back adjustment, and vertical motion pivots (four in all) require lubrication. This should be done every six months or 6,000 miles, whichever occurs first. The use of lithium-based grease in aerosol form is recommended.



SEAT CARE AND CLEANING

It is imperative that the interior of the bus be kept clean; seats are an important part of this maintenance. Regular cleaning and care will prolong the life of the seats and improve the general appearance of the bus.

Everyday dirt and soil. Most everyday soil and dirt may be removed with a soap and water solution. If the stain is persistent, a stiff bristle brush may be used. Fabric covered seats should be rinsed with clean water after the stain is removed.

Paint, tar, and asphalt. Remove the stain immediately using a damp cloth and kerosene. Rub gently, using small strokes. Rinse thoroughly. This type of stain may become permanent if not cleaned immediately.

Nail polish and lacquer based stains. Soak up as much as possible with dry cloth immediately. Any remaining stain may be removed with a non-flammable cleaning fluid such as "Tuff Stuff™" or "Armor All™" cleanser. Rinse thoroughly with clean water.

Gum, grease, and shoe polish. Remove as much as possible immediately. If left for any length of time, shoe polish will stain permanently. Clean any remaining stain with "Tuff Stuff™" or "Armor All™" cleanser.

Ink. Remove stain immediately using a damp cloth and alcohol.

SEAT CUSHION REMOVAL AND INSTALLATION—DOT SEATS

WARNING If seat cushions are removed for maintenance, they must be re-installed using the following instructions. Failure to comply with these instructions could result in injury from unattached seat cushions in the event of an accident.

Removal

1. Loosen the two front swivel-type clamps at the front underside of the cushion with a screwdriver. Caution: Do not remove clamps.
2. Rotate the swivel clamps 180° to clear the front retaining channel frame.
3. Lift the forward edge of the cushion 2 to 3 inches (5 to 8 cm) and pull forward.

Installation

1. Place the rear edge of the cushion down on the base portion of the seat frame. Lifting the forward edge 2 to 3 inches (5 to 8 cm), slide the cushion to the rear to engage the positive type clamp into the rear retaining channel.
2. Lower the forward edge to the frame, making sure the swivel clamps are inside the frame and the positive type clamps are secure on the rear retaining channel.
3. Rotate the swivel clamp to engage the forward retaining channel frame.
4. Tighten with a screwdriver until clamps do not rotate.

SEAT CUSHION REMOVAL AND INSTALLATION—DOT SEAT BELT SEATS

Removal

1. Loosen the two front swivel-type clamps at the front underside of the cushion with a screwdriver. Caution: Do not remove clamps.
2. Rotate the swivel clamp located at the rear underside of seat cushion.
3. While lifting the rear edge of the cushion, pull the cushion to the rear and remove.

Installation

1. Place the forward edge of the cushion two inches (5 cm) to the rear of the front retaining channel. Slide the cushion forward, engaging the positive clamps onto the forward retaining channel.
2. Lower the rear edge to the frame and rotate the swivel clamps so they engage the square tube cross member.
3. Tighten screws in front and rear clamps with a screwdriver until clamps do not rotate.

TRACK MOUNTED PASSENGER SEATS


If your bus is equipped with track mounted passenger seats and you relocate the seats or remove them to accommodate wheelchairs, you must follow rules of spacing and placement to comply with Federal Motor Vehicle Safety Standard 222 "School Bus Passenger Seating and Crash Protection" and Federal Motor Vehicle Safety Standard 217 "Bus Window Retention and Release". A decal printed with these rules (as shown below) is installed on the interior body panel above the windshield.

WARNING *The federal rules governing passenger seating, spacing, and placement are explicit. When the seats are moved, the entity moving or rearranging the seating assumes responsibility for compliance with FMVSS 222 "School Bus Passenger Seating and Crash Protection" and FMVSS 217, "Bus Window Retention and Release".*


All passenger seats must have a seat or barrier in front of it to provide compartmentalization required by Federal Motor Vehicle Safety Standards. As you reconfigure your bus, you may need additional barriers, which are available from Blue Bird Body Company Part Sales.



FEDERAL STANDARD REQUIREMENTS FOR TRACK SEAT PLACEMENT
ALL PASSENGER SEATS MUST HAVE A SEAT OR BARRIER
THE SAME WIDTH AS THE SEAT IN FRONT OF IT



SEAT SPACING MEASURED AT AISLE



REAR SEAT PLACEMENT - DRIVER'S SIDE. (REAR SEAT ON ENTRANCE DOOR SIDE MAY TOUCH BODY.)



SIDE EMERGENCY DOOR CLEAR AISLE




EMERGENCY EXIT RELEASE CLEARANCE

SIGNS & SIGNALS

Stop Arms

Stop arms are required on Blue Bird All American school buses by, and in accordance with, Federal Motor Vehicle Safety Standard 131. Stop arm assemblies are purchased as a kit to meet state requirements. The stop arm is located on the left-hand side of the body under the driver's window. A manual switch on the switch panel most commonly operates stop arms.

For pneumatically operated stop arms, the manual switch activates an electric solenoid valve controlling the flow of air. Optionally, the solenoid valve may be activated by the warning lamp system. This system is operated by the air system on the chassis. No special preventive maintenance procedures are required with these systems; however, the air pressure may occasionally require adjustment to ensure proper opening and closing of the stop arm. The air regulator is accessible through the outside electrical panel door under the driver's window. To regulate the air pressure, remove the wire retaining clip below the regulator knob and pull the red lock ring. Turn the knob counterclockwise to decrease the pressure, and then slowly increase the pressure (turn knob clockwise) until the stop arm hinge is extended to approximately 90°. Lock the knob into position by pushing in the red lock ring and installing the wire retaining clip.



Electrically operated stop arms may be activated by a manual switch or, optionally, by the warning lamp system.

The "STOP" sign must extend, and if equipped with lights, the lights must be operating any time the red lights of the warning light system are flashing. For state-designed warning light/stop arm systems which allow the stop arm to withdraw while warning lights are operating, an audible alarm sounds to alert the driver of the condition.

Monthly Maintenance

- Oil the dual action breakaway hinge at its pivot points with a high performance, penetrating lubricant. Tri-Flow™ (duPont™) with Teflon™ is recommended.
- Check that the breakaway portion of hinge is freely movable.
- Check that fasteners are secure.

Quarterly Maintenance

- Perform the "Monthly" procedures, above.
- Remove front and rear covers of base and check that fasteners are secure.



Destination Signs

Hinged Sign Front

Mounted on the outside of the front roof cap, with internal control for changing the display. Periodically lubricate hinges and lever assembly with lightweight lubricating oil.

Hinged Sign Rear

Mounted on the outside of the rear roof cap, manually changed from outside. Periodically lubricate hinges with lightweight lubricating oil.

One Station Lighted Curtain

Replace bulbs as needed. Because of vibration, the curtain can loosen. To tighten the curtain, loosen the bolts, pull the curtain taught and then tighten the bolts.

Roller Destination Sign with Lighted Curtain

Replace bulbs as needed. Curtain may occasionally require same adjustment as One Station Sign. Periodically lubricate the roller gears with light grease, such as White Lube™. Lubricate the hinges on the access door with lightweight lubricating oil. To change the display, turn the crank located on the front, upper, inner panel above the windshield.

Two Station Sign

Front lighted with lettering on both sides. Lubricate the interior door hinge on the front, upper, inner panel with lightweight lubricating oil.

Lighted "School Bus" Sign

Back lighted yellow Plexiglas™ sign. Replace bulbs as needed. Lubricate the interior door hinge on the front, upper, inner panel with lightweight lubricating oil.

ENGINE & RUNNING GEAR

Air Intake System Inspection

Intake air must be filtered to prevent dirt and debris from entering the engine and causing premature wear. Air intake piping should be checked daily, as should charge-air piping and engine air cleaner service indicator, if equipped. Repair any leaks in the system before operating the bus. Never operate the engine without an air cleaner.

Intake Air Restriction Indicator (Cat C7 and John Deere 8.1L).

Some engines are equipped with a gauge which displays the difference in air pressure before and after the air cleaner. As the air cleaner element becomes dirty, the pressure differential rises. The air cleaner element must be replaced when the difference is 25 inches on the Cat C7, and 15 inches on the John Deere 8.1L. If your engine is equipped with a different type of service indicator, follow the manufacturer's recommendations to service the indicator.

CAUTION *Leaks in the intake system will prevent the Air Restriction Indicator from reading accurately. Always check the attendant piping for leaks, especially between the indicator and the engine intake.*

Maximum intake restriction (clean air filter element): 10.0 inches water (254 mm)

Maximum intake restriction (dirty air filter element): 25.0 inches water (635 mm)

Cat C7. Replace the engine air cleaner every 12 months, or when the air cleaner service indicator shows restriction of 25 inches of water. Do not rely completely on the restriction indicator. A leak in the system will prevent the restriction indicator from operating properly. Always look at the piping to ensure there are no leaks.

John Deere 8.1L. Inspect the air intake system every 12 months or 25,000 miles; whichever comes first. Replace the air cleaner if it is damaged or torn, or when the restriction indicator shows restriction of 15 inches of water. Do not rely completely on the air restriction indicator. A leak in the air intake piping could cause a false indication. Always visually inspect the system to ensure there are no leaks.


If the vehicle is operated in extremely dusty conditions, more frequent air cleaner maintenance may be necessary.

Air Intake Piping

Inspect the intake piping daily for wear points and damage to piping, loose clamps, or punctures that can cause damage the engine. Replace damaged pipes, and tighten loose clamps; replace if necessary, to prevent the air system from leaking. Check for corrosion under the clamps and hoses of the intake system piping. Corrosion can allow corrosive products and dirt to enter the intake system. Disassemble and clean as required.

ChargeAir Piping

Inspect the chargeair piping and hoses daily for holes, cracks, or loose connections. Tighten the hose clamps as necessary.





Charge-Air Cooler (CAC) Maintenance

Check this system every 3 months or 7,500 miles. Inspect the charge-air cooler (CAC) for dirt and debris blocking the fins. Check for cracks, holes, or other damage. If damage is found, refer to the manufacturer's dealer.

Engine Cooling System

In today's modern engine designs, accurate maintenance of the cooling system is critically important to engine life. Simply maintaining coolant level and performing occasional coolant changes does not adequately ensure that the cooling system is healthy. The chemical balance of engine coolant must always be correct. This requires diligent adherence to the engine manufacturer's coolant specifications, maintenance schedules, and procedures. Accurate coolant system maintenance records should be kept.

The engine coolant level in the reservoir should be checked daily as a part of routine pre-trip inspection. But whenever the coolant level is low, it must be replenished with only pre-mixed coolant of the same type and brand installed. Never top off coolant with plain water.

Careful pre-trip inspection and a program of routine maintenance checks of the condition of the cooling system by service technicians should ensure against enroute emergencies such as worn hoses or loose clamps resulting in coolant loss. In the case of such an emergency, however, if anything other than original premixed coolant is added in order to allow the bus to proceed to a service facility, the coolant system must be completely drained, flushed, and properly refilled with approved coolant before being returned to routine service. Any enroute event requiring topping off of the coolant should be reported to service personnel responsible for maintenance of the bus.

WARNING *Exercise extreme care when removing the cap from the engine coolant reservoir. Always allow time for the engine to cool before removing the cap. The pressurized coolant may be very hot and can spray out, causing serious burn injuries.*

Coolant Types

Engine coolant is generically divided between two types; "standard" and "long-life" (or "extended-life"). Extended-life coolants generally allow longer intervals between coolant changes (sometimes requiring additives to be added near the midpoint of their service life, and/or for special testing to be performed at certain intervals). Engine manufacturers, however, differ somewhat in regards to specifications for coolants which they recognize as "long-life" when used in their respective engines.

Blue Bird buses built as of August, 2006 come from the Blue Bird factory with one of three types of coolant. The standard coolant is John Deere Cool-Gard 50/50 pre-mix, which is green in color. This coolant is considered extended life when installed in John Deere engines. It is to be considered standard-life coolant when installed in Caterpillar or Cummins engines.

Caterpillar equipped buses purchased with a long-life coolant option have been filled with Shell Rotella ELC 60/40 premix, which is red in color.

Cummins equipped buses purchased with a long-life coolant option have been filled with Fleetguard ES Optimax 60/40 premix, which is red in color.

Blue Bird installs decals on or near the deairation tank filler which state the type of coolant installed at the factory. The decal states the approved premixed coolant and coolant manufacturer's part number for one gallon quantities. The decal also lists the manufacturer's part number for the concentrate which is approved for mixing with the premix for stronger glycol concentration.

CAUTION *When replenishing or replacing coolant, only use coolant of the same type already installed. Never mix coolants of different color, type, or brand. Plain water is corrosive at engine operating temperatures. Never add plain water to the system. When using concentrated coolant to raise the glycol concentration for extreme temperature environments, Blue Bird recommends only mixing the concentrate with pre-mixed coolant of the same type; not mixing with water.*

Coolant Testing and Replacement

Each engine manufacturer has its own specific requirements for coolant testing and maintenance. Therefore, refer to the engine Operator's Manual for your bus and follow the engine manufacturer's maintenance specifications.

Blue Bird recommends that Caterpillar cooling systems with red extended life Shell Rotella ELC coolant should be tested according to the Caterpillar Operation and Maintenance Manual.

Blue Bird recommends that Cummins cooling systems with red extended life Fleetguard ES Optimax coolant should be tested by sending samples to a Fleetguard lab for a monitor C test as specified in the Cummins Operator's Manual.

The John Deere Cool-Gard coolant may be tested by sending a sample to John Deere for a Cool Scan test, or may be manually tested by qualified service technicians using a John Deere Three Way test strip, which is included in John Deere 3-Way Heavy Duty Coolant Test Kit TY6175.

Follow the engine manufacturer's procedure for draining, flushing, and refill.

Blue Bird buses equipped with Caterpillar or Cummins engines may also be equipped with an optional coolant filter. The coolant filter element installed at the Blue Bird factory is compatible with all three of the above-described coolants:

BLUE BIRD NUMBER **0064641**
VENDOR (Wix) PART NUMBER **24070**



Shutters

The optional radiator shutters assist in maintaining a constant engine temperature by limiting the air flow through the radiator. The shutter blades are powered by air pressure from the brake system on the vehicle. The shutters are controlled automatically by an Alarmstat which is located in the upper radiator hose and an electric solenoid in the air line controlling the shutters. The shutters require no lubrication but must be cleaned as required or at least every two years or 24,000 miles, whichever occurs first. See the shutters installation diagrams provided with vendor maintenance information for plumbing, wiring, and parts requirements.

Transmission

Transmission Breather

The transmission has a self-contained breather at the top left rear of the transmission main housing. The breather provides a passage for normal expansion and contraction of air and fluid within the transmission. Be careful to avoid plugging this breather with paint, undercoating, or any other material. A small amount of oil mist comes out of the breather during normal operation. If an excessive amount of oil is found in this area, the cause should be investigated.

CAUTION *When cleaning the transmission, do not spray steam, water, or cleaning solution directly at the breather. This may contaminate the transmission fluid.*

Transmission Fluid Level

Transmission fluid cools, lubricates, and transmits hydraulic power. Always maintain proper fluid level. If fluid level is too low, the torque converter and clutches do not receive an adequate supply of fluid and the transmission will overheat. If the level is too high, the fluid aerates, causing the transmission to shift erratically and overheat. Fluid may be expelled through the breather or dipstick tube when the fluid level is too high. Please see your Allison Transmission Operator's Manual for information on how to check fluid levels at both cold and hot engine temperatures. Allison recommends a transmission fluid that meets DEXRON®-III specifications.

Transmission Fluid And Filter Changes

Please see your Allison Transmission Operator's Manual for procedures to change transmission fluid and filters, and the intervals at which these should be done.



Rear Axle

All drive axles have a vent on the top of the axle housing that allows the axle to breathe as the axle temperature changes. The vent must remain open to prevent seal failures. It is normal for the vent to ooze a small amount of lubricant.

Hydraulic Brakes


The brakes self-adjust for lining wear. Brake fluid in the reservoir, located behind the driver's seat, must be maintained to the correct level. As the brake linings wear, fluid level in the reservoir will go down, displacing the lining loss.

CAUTION Use only DOT brake fluid in this reservoir.

WARNING Put only brake fluid in the brake fluid reservoir and only power steering fluid in the power steering system. Mixing fluids or failure to use the proper fluid, could result in loss of braking or steering.

Parking Brake Adjustment

On All Americans with hydraulic brakes, the parking brake is adjusted by turning the knob on the parking brake lever. The knob is held in place with a set screw, and can be adjusted when the parking brake is released. When the parking brake is properly adjusted, 90–100 pounds of force—as measured 2" from the end of the lever—is required to set the brake.



WINDSHIELD WIPERS

Washer Solution Reservoir

Periodically check the windshield washer solution reservoir, located behind the driver's side front access panel of the All American Rear Engine. It is located behind the front access panel on the entrance door side of the Front Engine model. Be sure there is an adequate supply of fluid at all times. The solution used is a 50/50 mixture of methanol and water.

Wiper Assembly Replacement

To replace wiper assembly (Figure 1), loosen lock nut, remove screw, and pull wiper assembly loose from wiper arm. Replace the wiper assembly and use original screw and lock nut. Tighten lock nut securely, but do not tighten enough to compress the saddle. Blade must be free to move on the axis (machine screw) and within the saddle. Threading the lock nut until flush with the machine screw end will give a secure and serviceable installation.

Wiper Refill Replacement

To remove wiper refills, follow the procedure outlined below.

1. Lift end clip with screwdriver as shown in Figure 2. This releases locking indentations (A in Figure 3) and allows end clip retainers (B in Figure 3) to be removed through blade claw.
2. Repeat procedure on the opposite end of the wiper.
3. New end clips (Figure 3) are provided with replacement Anco™ refills. To install, remove one clip and slide the refill through all claws until the end clip locks in position.
4. Install the second end clip, and snap-lock devices A and B into place to secure refill.




Figure 1




Figure 2




Figure 3



CLEANING

Exterior Cleaning

The best way to preserve your vehicle's finish is to keep it clean by washing frequently. Wash the vehicle in lukewarm or cold water. Do not use hot water or wash in the direct rays of the sun. Do not use strong soap or chemical detergents. All cleaning agents should be promptly flushed from the surface and not allowed to dry on the finish. Polishing with nonabrasive wax is recommended to remove accumulated residue and eliminate any "weathered" appearance.

CAUTION *Pressure washing may cause damage to finish. Pre-test pressure washer on a similar surface before applying pressure and chemicals to your vehicle. Pressure washers that recirculate should filter the water to remove abrasive grit.*

Calcium chloride and other salts, ice melting agents, road oil and tar, tree sap, bird droppings, chemicals from industrial chimneys, and other foreign matter may damage vehicle finishes if allowed to remain on painted surfaces. Prompt washing may not completely remove all of these deposits. Additional cleaners may be needed. When using chemical cleaners developed for this purpose, be certain they are safe for use on painted surfaces.

Any stone chips, fractures, or deep scratches in the finish should be repaired promptly. Exposed metal will corrode quickly and may develop into a major repair expense.

Floor Cleaning

Regular cleaning and care will prolong the life of floor covering and improve the general appearance. Floor coverings should be swept daily and mopped weekly with a mild detergent and water. Do not use floor sweeping compounds. Be sure to remove dirt, pencils, paper, and any other debris that may cause the emergency door to seal improperly. Do not use harsh detergents or excessive amounts of water. Do not use a water hose to wash out the bus. Deterioration and damage to the wood floor could occur.


CAUTION *Petroleum products, such as oil and grease, quickly deteriorate the floor covering. These types of products should be removed from the surface as soon as possible. Continuous care must be exercised in the stepwell area, where foreign objects can create a safety hazard. The accumulation of dirt and foreign material in the stepwell area creates a hazard for passengers and could prevent the doors from operating properly. Ensure that screws for floor trims and aisle trims are seated tightly.*

HEATER CARE

The front heater can be accessed from the curbside access panel outside the bus at the front, and from the inside, on the dash near the stepwell. To access the heater core and filter inside the bus, remove the interior heater access panel shown.

Filter

The main heater core is protected by an air filter, which prevents dirt and dust from collecting on the heat exchange surfaces and thereby lowering heater efficiency. Care should be taken to keep the filter clean. A dirty filter restricts airflow and reduces heater output. To clean or replace the filter, remove the filter access panel. The operating conditions of your bus will determine how frequently the filter should be serviced.



Annual Maintenance

Hoses

Check all water hoses for kinks that can prevent water flow or chafing that can cause failure. Look and feel for hardening of rubber or cracks that result from aging. Hoses should be replaced when cracks first appear. Hoses under the bus and in the engine area will deteriorate faster than those inside the bus. Exposed hoses should be checked more frequently.

Cores

The heater will be most efficient when the core is clean. The core should be cleaned carefully with compressed dry air or vacuum and a soft bristle brush. Damaged fins should be straightened with a fin comb to prevent airflow restrictions. The forward heater core can be accessed through the right front inside access panel. Under seat heaters are accessed by removing the passenger seat cushions that are over them.

Motors, Switches, Blowers, and Fans

Maintenance free motors are used and do not require lubrication or cleaning over their operating life. However, excessive vibration caused by damaged blower wheels or fans can cause motor damage. Inspect wheels and fans for obstruction or damage by running each fan individually, listening and feeling for irregularities. Replace damaged wheels or fans to prevent damage to parts, fasteners, and motors.

Switches are also maintenance free; however, loose wiring connections to switches or motors can cause excessive resistance and overheating damage. Wires



to switches can be checked or repaired by removing the switch mounting panel next to the driver's seat.

Panels and Housings

Fasteners should be checked and tightened as necessary. A loose screw may allow a panel to vibrate, resulting in excessive noise, more loose screws, and/or metal fatigue.


Cleaning Auxiliary Fans

Auxiliary fan motor bearings are lifetime-lubricated, and do not require maintenance. Clean the blade and guard occasionally, with a soft bristle brush and a vacuum cleaner or compressed air, to help maintain efficiency. As with any other fan, if the blade is damaged or unbalanced, vibration damage can occur to the motor or surrounding components. If this is the case, the blade should be replaced immediately.

WARNING Do not operate a fan without the fan guard properly installed.

Procedure:

1. Remove the front half of the fan guard by gently separating the plastic tabs with a screwdriver or other hard instrument. Be careful not to damage the tabs, as these connect the front half of the fan guard to the rear half.
2. To remove the fan blade, use a 3/32-inch Allen wrench in the setscrew located directly behind the fan. This should loosen the fan blade for removal.
3. The rear half of the fan guard can also be removed if necessary. After pulling away the fan, remove the two nuts and washers on either side of the center point and lift off the rear piece.



MAINTENANCE SCHEDULE

Maintenance Task Schedule, A3FE

Ensure that the Safety Information, warnings and instructions are read and understood before operation or maintenance procedures are performed. Use whichever interval listed (time, mileage, engine hours) occurs first. Engines operated in severe operating conditions may require more frequent maintenance. See engine manufacturer's specifications for more information.

First Month Then Every 3 Months or 3000 Miles

Cooling System

Inspect & Tighten Hose Clamps

Tighten radiator hose clamps to 90 in lb. Tighten heater hose clamps to 45 in lb.

First 100 Miles Then Every 10,000 Miles

Tires & Wheels

Inspect & Tighten Lug Nuts

Torque to 450-500_ft lb with calibrated torque wrench. Do not over-tighten. Do not lubricate nuts or studs. Operating conditions may require more frequent checks.

First 1000 Miles Then Every 3 Months or 6000 Miles

Frame

Inspect & Tighten Body Tie Downs Body Tie Down Clamps

Inspect for missing, damaged rubber pads. Tighten clamps to 37-41 ft lb.

Inspect & Tighten Body Tie Downs Rear Isolator Mounts

Inspect rubber discs for cracking or damage. Inspect spring & fastener for damage. Tighten bracket to 70-80 ft lb. Tighten Isolator to 54-58 ft lb.

First 1000 Miles Then Every 6 Months or 6000 Miles

Axle & Suspension, Front

Lubricate Parabolic Spring Suspension Spring Pins

NLGI #2 Grease.

Axle & Suspension, Rear

Inspect Comfort Air Suspension Ride Height

Shock length, eye-to-eye: 22.68" +- .25"

First 1000 Miles Then Every 6 Months or 10,000 Miles

Axle & Suspension, Rear

Inspect & Tighten Comfort Air Suspension U-Bolts

Tighten 7/8" U-Bolts to 400-450 ft lb. Tighten 3/4" U-Bolts to 260-320 ft lb.


First 1000 Miles Then Every 12 Months or 12,000 Miles
Heaters & Defrosters

Inspect Front Heater Hoses & Clamps

Inspect for evidence of leaks or deterioration. replace with proper parts.

Axle & Suspension, Front

 Inspect & Tighten Parasteer Suspension
Axle-To-Suspension Fasteners

Torque to 260–320 ft lb.

First 5000 Miles Then Every 12 Months or 24,000 Miles
Transmission

Replace Transmission Sump Filter

First 5000 Miles Then Every 24 Months or 24,000 Miles
Transmission

Replace Transmission Main Fluid Filter

First 11,000 Miles Then Every 3 Months or 5000 Miles or 250 Engine Hours
Engine

Inspect All Belts

Inspect condition and tension of belt.

First 11,000 Miles Then Every 6 Months or 250 Engine Hours
Brakes

Replace Air Brakes Air Compressor Filter

First 11,000 Miles Then Every 6 Months or 6000 Miles
Cooling System

Inspect Charge Air Cooler

Inspect for clogging debris.

As Specified by Engine Manufacturer
Cooling System

Replace Coolant

See your Engine Operator's Manual. Use only premixed coolant(s) approved by the engine manufacturer. Never mix different types or brands of coolant.

Engine

Replace Oil & Filter

See Engine operators manual for oil and filter specifications and maintenance interval.

Adjust Valves

See Engine manufacturer's Service Manual for interval.

As Specified by Transmission Manufacturer
Transmission

Adjust Transmission Shift Cable	See Transmission Chapter.
---------------------------------	---------------------------

Every Day
Doors

Test Wheelchair Lift	Follow the manufacturers recommendations.
----------------------	---

Emergency Equipment

Inspect Fire Extinguisher Charge	Ensure that Extinguisher Charge is not expired.
----------------------------------	---

Inspect Fire Extinguisher Mounting Bracket	Ensure that Extinguisher bracket is secure and operates correctly.
--	--

Inspect First Aid Kit Contents	Ensure that kit supplies are fully replenished, clean, and not expired.
--------------------------------	---

Inspect First Aid Kit Mounting Bracket	Ensure that mounting bracket is secure and operates correctly.
--	--

Emergency Exits

Inspect All Emergency Exits	Test all emergency exits for proper operation, including warning buzzer.
-----------------------------	--

Warning Devices & Signs

Test Stop Arms & Crossing Arms	
--------------------------------	--

Windows

Inspect All Mirrors	Clean, adjust mirrors.
---------------------	------------------------

Inspect All Windows	Clean Windshield, door glass, driver's window, rear vision windows, rear door windows.
---------------------	--

Brakes

Inspect Air Brakes Air Lines & Fittings	Inspect for leaks or physical damage.
---	---------------------------------------

Drain Air Brakes Air Tanks	Drain daily in cold weather; weekly in warm weather.
----------------------------	--

Inspect Air Brakes Brake Chambers	See Air Brakes Chapter for inspection criteria.
-----------------------------------	---

Inspect Air Brakes Brake Shoes	Wear depends upon application environment. See Meritor Cam Brakes Appendix in Air Brakes Chapter for guidelines.
--------------------------------	--



Cooling System

Inspect Coolant Level	Top off with premixed coolant of same type as installed. Never mix coolants of different colors, types, or brands. See engine Operator's Manual for details.
-----------------------	--

Inspect Entire Cooling System	Visually inspect for any signs of leakage.
-------------------------------	--

Electrical

Inspect All Lights	Check all running, stop, marker, hazard, and warning lights for proper operation.
--------------------	---

Engine

Inspect Oil Level	See Engine operators manual for oil specifications.
-------------------	---

Fuel System

Inspect Fuel Cap	
------------------	--

Inspect Water Separator Petcock Drain	Check for water contamination.
---------------------------------------	--------------------------------

Intake System

Inspect Intake Tract Duct & Elbow	Visually inspect for proper fit and sealing, cuts, abarsions, signs of dirt contamination.
-----------------------------------	--

Inspect Intake Tract Restriction Indicator	Replace filter element if indicator is red.
--	---

Steering

Inspect Power Steering Fluid Level	Replinish to full mark. Dextron III.
------------------------------------	--------------------------------------

Tires & Wheels

Inspect All Tires & Wheels	Check air pressure. Visually inspect tires, tread wear, lug nuts, including spare.
----------------------------	--

Transmission

Inspect Transmission Fluid Level	Check production order for proper type of fluid to be added.
----------------------------------	--

Every Week**Seats**

Inspect & Tighten Passenger Seats Cushion
Screws

Inspect for loose cushions clips.

Inspect Passenger Seats Seat Belts

Lubricate buckles, clean webbing as required. Replace any damaged webbing straps.

Inspect Passenger Seats Upholstery

Inspect for cuts, tears, wear and soiled areas.

Brakes

Inspect Hydraulic Brakes Pads

Replace if worn to within 1/8" lining remaining.


Every Month or 3000 Miles
Doors

Clean & Lubricate All Doors Rubber Seals	Lubricate with Silicon Spray or protectant.
Lubricate All Doors Vandal Locks	Spray Apply lubricant into key locks. Use LPS #1 for sliding bolt locks.
Adjust Jack Knife Door Air Pressure	See Body Construction / Doors / Jack Knife Door
Adjust Jack Knife Door Control Rod	Adjust for proper open/closed position.
Adjust Jack Knife Door Control Rod Bracket	Adjust to prevent pivot pin binding.
Lubricate Jack Knife Door Hinge Pins	LPS 1
Adjust Jack Knife Door Roller Bracket	Adjust for proper open/closed position.
Adjust Jack Knife Door Switch	See Body Construction / Doors / Jack Knife Door
Adjust Outward Opening Door Control Rod	
Adjust Outward Opening Door Control Rod Bracket	Adjust for full and secure closure without binding.
Adjust & Lubricate Outward Opening Door Linkage	Adjust linkage for firm closure, and to ensure rear panel closes first.
Lubricate Outward Opening Door Pivots	Lubricate pivot pins with LPS 1.
Adjust Outward Opening Door Roller Bracket	Adjust for full and secure closure without binding.
Lubricate Power Jack Knife Door Air Pressure & Switch	LPS #1
Lubricate Power Jack Knife Door Hinge	LPS #1
Lubricate Wheelchair Lift Lube Points	See model-specific literature provided with lift.

Emergency Exits

Lubricate All Emergency Exits Hinges	LPS #1
Lubricate Rear Emergency Door Hinges	Lubricate at hinge grease fittings.
Lubricate Rear Emergency Door Hold-Open	Apply ASTM D4950 GC-LB Grade 2
Lubricate Roof Hatch Hatch Seal and Latch	Silicone lubricant to prevent sticking of rubber seal. Spray silicon lubricant into latch mechanism.

Floor

Inspect Floor Drains	Check drain hole in each body section under window for debris obstruction.
----------------------	--

Seats

Lubricate Driver's Seat	Lubricate per manufacturers recommendation.
Inspect & Tighten Passenger Seats Mountings	Use standard torque for bolt size , tread type and grade.

Warning Devices & Signs

Lubricate Stop Arm, Electric 4-Point Pivot	Lubricate four hinge pivot points with Try-Flow lubricant
Inspect & Tighten Stop Arm, Electric Fasteners	Check interior and exterior fasteners for loosening.

Windows

Lubricate Passenger Windows Latches & Slides	Use silicone lubricant.
--	-------------------------

Electrical

Inspect Battery Electrolyte Level	Replenish with distilled water.
-----------------------------------	---------------------------------

Every Month or 6000 Miles
Warning Devices & Signs

Adjust Stop Arm, Air Air Pressure	Adjust for full deployment and retraction
-----------------------------------	---

Every Month or 10,000 Miles
Axle & Suspension, Rear

Inspect Rear Axle Lubricant Level	If low, refill to bottom of filler opening. Use same lubricant type as already installed.
-----------------------------------	---

Every Month or 300,000 Miles
Brakes

Inspect Hydraulic Brakes Fluid	DOT-3 brake fluid.
--------------------------------	--------------------

**Every 3 Months or 3000 Miles****Cooling System**

Inspect Radiator Fins	Clean debris from fins.
Inspect Water Pump Belt	Inspect condition and tension of belt.

Every 3 Months or 5000 Miles
Brakes

Lubricate Air Brakes S-Cam	See Meritor Cam Brakes Appendix in Air Brakes Chapter for guidelines.
----------------------------	---

Lubricate Hydraulic Brakes Calipers	Lube per meritor specs.
-------------------------------------	-------------------------

Driveline

Lubricate Driveshafts Slip Joint	NLGI Grade #1 or #2 multipurpose grease.
----------------------------------	--

Lubricate Driveshafts U-Joint Bolts	NLGI Grade #1 or #2 multipurpose grease.
-------------------------------------	--

Inspect & Tighten Driveshafts U-Joint Bolts	Tighten to 45–50 ft lb.
---	-------------------------

Electrical

Inspect Alternator Connections	Inspect for loose wires, damaged terminals, damaged insulators.
--------------------------------	---

Inspect Battery Ground Strap	Check for solid connection, tight fasteners and absence of corrosion.
------------------------------	---

Fuel System

Inspect Fuel Lines	Inspect for leaks or signs of abrasion.
--------------------	---

Lubricate Fuel Stop Solenoid	
------------------------------	--

Inspect Fuel Tank Vent	Inspect for obstruction.
------------------------	--------------------------

Intake System

Inspect Air Cleaner Filter Element	Inspect for proper seating, secure lid. Replace if soiled, wet, or damaged.
------------------------------------	---

Inspect Intake Tract All Fasteners	Inspect for signs of contaminate infiltration, loose clamps, wear spots, holes in piping
------------------------------------	--

Inspect Intake Tract Charged Air Tubing	Inspect for signs of contaminate infiltration, loose clamps, wear spots, holes in piping
---	--

Inspect & Tighten Intake Tract Hose Clamps	Tighten to 10 in lb.
--	----------------------

Inspect & Tighten Intake Tract Spring Loaded Clamps	Tighten to near full spring compression.
---	--

Inspect Intake Tract Support Bracket	Visual inspection. Repair damaged parts immediately.
--------------------------------------	--



Inspect & Tighten Intake Tract T-Bolt Clamps	Tighten to 50 in lb.
--	----------------------

Inspect & Tighten Intake Tract Worm Gear Clamps	Tighten to 38–42 in lb.
---	-------------------------

Steering

Lubricate Axle Steering Linkage Drag Link	NLGI #2 EP multipurpose grease rated GC-LB or equivalent.
---	---

Lubricate Axle Steering Linkage King Pins	NLGI #2 EP multipurpose grease rated GC-LB or equivalent.
---	---

Lubricate Axle Steering Linkage Tie Rod Ends	NLGI #2 EP multipurpose grease rated GC-LB or equivalent.
--	---

Lubricate Intermediate Steering Shaft Slip Joint	Lubricate splines with multipurpose grease.
--	---

Every 3 Months or 24,000 Miles

Brakes

Inspect Air Brakes Air Dryer	See Bendix appendix for specific model in Air Brakes Chapter.
------------------------------	---

Inspect Hydraulic Brakes Booster & Master Cylinder	Inspect for signs of leakage or physical damage.
--	--

Every 6 Months or 6000 Miles
Warning Devices & Signs

Lubricate Destination Sign Hinges

Lubricate Destination Sign Roller Gears

Lightweight grease such as White Lube.

Axle & Suspension, Rear

Inspect & Tighten Comfort Air Suspension Shock Absorbers

Inspect for signs of leakage, wear, or damage. Tighten upper shock mounts to 50–70 ft lb. Tighten lower shock mounts to 150–180 ft lb.

Inspect Comfort Air Suspension Whole Assmebly

Visually inspect for damage.

Brakes

Replace Air Brakes Air Compressor Filter

Clean Air Brakes Check Valves

Clean & Lubricate Air Brakes Treadle Valve

See Bendix Treadle Valve Appendix in Air Brakes Chapter.

Clean Air Compressor Governor

Inspect Hydraulic Brakes Calipers

Inspect for signs of leakage or physical damage.

Adjust Hydraulic Brakes Park Brake Lever

Adjust engagement pressure at the lever to achieve 120 -125lbs. at break over center.

Electrical

Inspect Battery Battery Posts

Clean and apply anti corrosion agent.

Exhaust System

Inspect Exhaust Pipe Joints

Inspect for loose clamps, leaks, damage.

Fuel System

Replace Fuel Filter Filter Element

Clean Fuel Filter Inlet Screen

Clean. Replace if damaged.

Steering

Lubricate Steering Gear Pitman Arm Pivot

NLGI #2 EP multipurpose grease rated GC-LB or equivalent. Use hand-operated grease gun.



Every 6 Months or 10,000 Miles

Axle & Suspension, Rear

Inspect & Tighten Comfort Air Suspension Air Spring Anchor Bolts	Tighten to 20–30 ft lb.
Inspect & Tighten Comfort Air Suspension Air Spring Fasteners	Torque to 30–35 ft lb.
Inspect & Tighten Comfort Air Suspension Leveling Valve Mount Bolt	Tighten to 60–85 in lb.
Inspect & Tighten Comfort Air Suspension Lever Linkage Locknut	Tighten to 100–150 in lb.
Inspect & Tighten Comfort Air Suspension Lower Shock Mount	Tighten to 260–320 ft lb.
Inspect & Tighten Comfort Air Suspension Quick Align Bolts	Tighten to 525–575 ft lb.

Brakes

Lubricate Air Brakes Cam Shaft Housing	NLGI #2 EP multipurpose grease rated GC-LB or equivalent. Use hand-operated grease gun.
Lubricate Air Brakes Haldex Slack Adjusters	See Haldex lubricant specs in Air Brakes chapter.
Lubricate Air Brakes Meritor Slack Adjusters	See Meritor lubricant specs in Air Brakes chapter.

Steering

Lubricate Steering Column	Vision manual says to lubricate steering column. Where? With what? Check model applicability
---------------------------	--

Every 12 Months

Intake System

Test Intake Tract Restriction Indicator	Test indicator with vacuum gauge and pump.
---	--

Every 12 Months or 12,000 Miles
Heaters & Defrosters

Tighten Front Heater Fasteners	All fasteners holding such heaters in place in unit. For details on fasteners check installation prints.
Clean Front Heater Filter & Core	Clean dust from cores. Replace filter elements.
Bleed Heater System	Bleed air from heater circulation system. This procedure is done to keep system operating correctly.
Clean Underseat Heaters Filter Elements	Clean dust from cores.

Axle & Suspension, Front

Inspect Parabolic Spring Suspension Entire Assembly	Visually inspect for damage or misalignment.
Inspect & Tighten Parabolic Spring Suspension Hangar Bracket Bolts	Tighten to 75–85 ft lb.
Inspect Parabolic Spring Suspension Shock Absorbers	Visually inspect for leakage or damage.
Inspect & Tighten Parasteer Suspension Air Spring Fasteners	Torque to 20–30 ft lb.
Inspect & Tighten Parasteer Suspension Front Pivot Bolts	Torque to 450–480 ft lb.
Inspect & Tighten Parasteer Suspension Ride Height	Shock Length, eye-to-eye: 18.5" +/- .25"
Inspect & Tighten Parasteer Suspension Shock Absorbers	Inspect for leakage or damage. Torque upper and lower mount bolts to 50–70 ft lb.
Inspect & Tighten Parasteer Suspension Transverse Rod Bolts	Torque to 138–159 ft lb.

Axle & Suspension, Rear

Inspect Comfort Air Suspension Ride Height	Shock length, eye-to-eye: 24.68" +/- .25"
Inspect Comfort Air Suspension Ride Height	Shock length, eye-to-eye: 21.75" +/- .25"



Inspect & Tighten Comfort Air Suspension Shock Absorbers	Inspect for leakage or damage. Torque upper mount bolts to 50–70 ft lb. Torque lower mount bolts to 160–180 ft lb.
--	--

Inspect & Tighten Comfort Air Suspension Torque Arm Bolts	Torque to 150–205 ft lb.
---	--------------------------

Inspect & Tighten Comfort Air Suspension U-Bolts	Torque 7/8" bolts to 400–450 ft lb. Torque 3/4" bolts to 260–320 ft lb.
--	---

Cooling System

Test Entire Cooling System	Pressure Test Cooling system.
----------------------------	-------------------------------

Engine

Test Engine Starting Aid Block Heater	
---------------------------------------	--

Steering

Inspect Hydraulic Pump Body & Seals	Inspect for leaks.
-------------------------------------	--------------------

Inspect Steering Gear Body & Seals	Inspect for leaks.
------------------------------------	--------------------

Every 12 Months or 24,000 Miles

Brakes

Clean Air Brakes Pop Off Valves	
---------------------------------	--

Steering

Replace Hydraulic Reservoir Filter Element	Replace element and fluid. Replace more frequently in severe operating conditions. Dextron III.
--	---

Transmission

Replace Transmission Fluid	Use Dextron III fluid.
----------------------------	------------------------

Inspect Transmission Shift Cable	
----------------------------------	--

Inspect Transmission Vent	Clear vent hose of debris or obstruction.
---------------------------	---

Every 12 Months or 50,000 Miles

Axle & Suspension, Rear

Replace Rear Axle Petroleum Based Lubricant	Hypoid Gear Oil. Viscosity depends upon operating climate. See Viscosity/Temperature chart.
---	---

Every 12 Months or 100,000 Miles

Axle & Suspension, Rear

Replace Rear Axle Synthetic Lubricant	Viscosity depends upon operating climate. See Viscosity/Temperature chart.
---------------------------------------	--

Every 18 Months or 20,000 Miles**Cooling System**

Lubricate Shutters Pivots	Use Never Seize spray lubricant.
---------------------------	----------------------------------

Every 24 Months or 24,000 Miles**Brakes**

Clean Air Brakes Parking Brake Valve	See Bendix Appendixes in Air Brakes Chapter.
--------------------------------------	--

Clean Air Brakes Quick Release Valves	See Bendix Appendixes in Air Brakes Chapter.
---------------------------------------	--

Clean Air Brakes Relay Valves	See Bendix Appendixes in Air Brakes Chapter.
-------------------------------	--

Clean Air Brakes Spring Brake Valve	See Bendix Appendixes in Air Brakes Chapter.
-------------------------------------	--



Maintenance Task Schedule, A3RE

Ensure that the Safety information, warnings and instructions are read and understood before operation or maintenance procedures are performed. Use whichever interval listed (time, mileage, engine hours) occurs first. Engines operated in severe operating conditions may require more frequent maintenance. See engine manufacturer's specifications for more information.

First Month Then Every 3 Months or 3000 Miles

Cooling System

Inspect & Tighten Hose Clamps	Tighten radiator hose clamps to 90 in lb. Tighten heater hose clamps to 45 in lb.
-------------------------------	---

First 100 Miles Then Every 10,000 Miles

Tires & Wheels

Inspect & Tighten Lug Nuts	Torque to 450-500 ft lb with calibrated torque wrench. Do not over-tighten. Do not lubricate nuts or studs. Operating conditions may require more frequent checks.
----------------------------	--

First 1000 Miles Then Every 3 Months or 6000 Miles

Frame

Inspect & Tighten Body Tie Downs Body Tie Down Clamps	Inspect for missing, damaged rubber pads. Tighten clamps to 37-41 ft lb.
Inspect & Tighten Body Tie Downs Rear Isolator Mounts	Inspect rubber discs for cracking or damage. Inspect spring & fastener for damage. Tighten bracket to 70-80 ft lb. Tighten Isolator to 54-58 ft lb.

First 1000 Miles Then Every 6 Months or 6000 Miles

Axle & Suspension, Front

Lubricate Parabolic Spring Suspension Spring Pins	NLGI #2 Grease.
---	-----------------

Axle & Suspension, Rear

Inspect Comfort Air Suspension Ride Height	Shock length, eye-to-eye: 22.68" +- .25"
--	--

First 1000 Miles Then Every 6 Months or 10,000 Miles

Axle & Suspension, Rear

Inspect & Tighten Comfort Air Suspension U-Bolts	Tighten 7/8" U-Bolts to 400-450 ft lb. Tighten 3/4" U-Bolts to 260-320 ft lb.
--	---

First 1000 Miles Then Every 12 Months or 12,000 Miles
Heaters & Defrosters

Inspect Front Heater Hoses & Clamps

Inspect for evidence of leaks or deterioration. replace with proper parts.

Axle & Suspension, Front

 Inspect & Tighten Parasteer Suspension
Axle-To-Suspension Fasteners

Torque to 260–320 ft lb.

First 5000 Miles Then Every 12 Months or 24,000 Miles
Transmission

Replace Transmission Sump Filter

First 5000 Miles Then Every 24 Months or 24,000 Miles
Transmission

Replace Transmission Main Fluid Filter

First 11,000 Miles Then Every 3 Months or 5000 Miles or 250 Engine Hours
Engine

Inspect All Belts

Inspect condition and tension of belt.

First 11,000 Miles Then Every 6 Months or 250 Engine Hours
Brakes

Replace Air Brakes Air Compressor Filter

First 11,000 Miles Then Every 6 Months or 6000 Miles
Cooling System

Inspect Charge Air Cooler

Inspect for clogging debris.

As Specified by Engine Manufacturer
Cooling System

Replace Coolant

See your Engine Ooperator's Manual. Use only premixed coolant(s) approved by the engine manufacturer. Never mix different types or brands of coolant.

Engine

Replace Oil & Filter

See Engine operators manual for oil and filter specifications and maintenance interval.

Adjust Valves

See Engine manufacturer's Service Manual for interval.



As Specified by Transmission Manufacturer

Transmission

Adjust Transmission Shift Cable	See Transmission Chapter.
---------------------------------	---------------------------

Every Day

Doors

Test Wheelchair Lift	Follow the manufacturers recommendations.
----------------------	---

Emergency Equipment

Inspect Fire Extinguisher Charge	Ensure that Extinguisher Charge is not expired.
----------------------------------	---

Inspect Fire Extinguisher Mounting Bracket	Ensure that Extinguisher bracket is secure and operates correctly.
--	--

Inspect First Aid Kit Contents	Ensure that kit supplies are fully replenished, clean, and not expired.
--------------------------------	---

Inspect First Aid Kit Mounting Bracket	Ensure that mounting bracket is secure and operates correctly.
--	--

Emergency Exits

Inspect All Emergency Exits	Test all emergency exits for proper operation, including warning buzzer.
-----------------------------	--

Warning Devices & Signs

Test Stop Arms & Crossing Arms	
--------------------------------	--

Windows

Inspect All Mirrors	Clean, adjust mirrors.
---------------------	------------------------

Inspect All Windows	Clean Windshield, door glass, driver's window, rear vision windows, rear door windows.
---------------------	--

Brakes

Inspect Air Brakes Air Lines & Fittings	Inspect for leaks or physical damage.
---	---------------------------------------

Drain Air Brakes Air Tanks	Drain daily in cold weather; weekly in warm weather.
----------------------------	--

Inspect Air Brakes Brake Chambers	See Air Brakes Chapter for inspection criteria.
-----------------------------------	---

Inspect Air Brakes Brake Shoes	Wear depends upon application environment. See Meritor Cam Brakes Appendix in Air Brakes Chapter for guidelines.
--------------------------------	--

Cooling System

Inspect Coolant Level

 Top off with premixed coolant of same type as installed.
 Never mix coolants of different colors, types, or brands.
 See engine Operator's Manual for details.

Inspect Entire Cooling System

Visually inspect for any signs of leakage.

Electrical

Inspect All Lights

Check all running, stop, marker, hazard, and warning lights for proper operation.

Engine

Inspect Oil Level

See Engine operators manual for oil specifications.

Fuel System

Inspect Fuel Cap

Inspect Water Separator Petcock Drain

Check for water contamination.

Intake System

Inspect Intake Tract Duct & Elbow

Visually inspect for proper fit and sealing, cuts, abarsions, signs of dirt contamination.

Inspect Intake Tract Restriction Indicator

Replace filter element if indicator is red.

Steering

Inspect Power Steering Fluid Level

Replenish to full mark. Dextron III.

Tires & Wheels

Inspect All Tires & Wheels

Check air pressure. Visually inspect tires, tread wear, lug nuts, including spare.

Transmission

Inspect Transmission Fluid Level

Check production order for proper type of fluid to be added.

Every Week
Seats

 Inspect & Tighten Passenger Seats Cusion
 Screws

Inspect for loose cushions clips.

Inspect Passenger Seats Seat Belts

Lubricate buckles, clean webbing as required. Replace any damaged webbing straps.

Inspect Passenger Seats Upholstery

Inspect for cuts, tears, wear and soiled areas.

Brakes

Inspect Hydraulic Brakes Pads

Replace if worn to within 1/8" lining remaining.


Every Month or 3000 Miles
Doors

Clean & Lubricate All Doors Rubber Seals	Lubricate with Silicon Spray or protectant.
Lubricate All Doors Vandal Locks	Spray Apply lubricant into key locks. Use LPS #1 for sliding bolt locks.
Adjust Jack Knife Door Air Pressure	See Body Construction / Doors / Jack Knife Door
Adjust Jack Knife Door Control Rod	Adjust for proper open/closed position.
Adjust Jack Knife Door Control Rod Bracket	Adjust to prevent pivot pin binding.
Lubricate Jack Knife Door Hinge Pins	LPS 1
Adjust Jack Knife Door Roller Bracket	Adjust for proper open/closed position.
Adjust Jack Knife Door Switch	See Body Construction / Doors / Jack Knife Door
Adjust Outward Opening Door Control Rod	
Adjust Outward Opening Door Control Rod Bracket	Adjust for full and secure closure without binding.
Adjust & Lubricate Outward Opening Door Linkage	Adjust linkage for firm closure, and to ensure rear panel closes first.
Lubricate Outward Opening Door Pivots	Lubricate pivot pins with LPS 1.
Adjust Outward Opening Door Roller Bracket	Adjust for full and secure closure without binding.
Lubricate Power Jack Knife Door Air Pressure & Switch	LPS #1
Lubricate Power Jack Knife Door Hinge	LPS #1
Lubricate Wheelchair Lift Lube Points	See model-specific literature provided with lift.

Emergency Exits

Lubricate All Emergency Exits Hinges	LPS #1
Lubricate Rear Emergency Door Hold-Open	Apply ASTM D4950 GC-LB Grade 2
Lubricate Roof Hatch Hatch Seal and Latch	Silicone lubricant to prevent sticking of rubber seal. Spray silicon lubricant into latch mechanism.

Floor

Inspect Floor Drains	Check drain hole in each body section under window for debris obstruction.
----------------------	--

Seats

Lubricate Driver's Seat	Lubricate per manufacturers recommendation.
Inspect & Tighten Passenger Seats Mountings	Use standard torque for bolt size , tread type and grade.

Warning Devices & Signs

Lubricate Stop Arm, Electric 4-Point Pivot	Lubricate four hinge pivot points with Try-Flow lubricant
Inspect & Tighten Stop Arm, Electric Fasteners	Check interior and exterior fasteners for loosening.

Windows

Lubricate Passenger Windows Latches & Slides	Use silicone lubricant.
--	-------------------------

Electrical

Inspect Battery Electrolyte Level	Replenish with distilled water.
-----------------------------------	---------------------------------

Every Month or 6000 Miles
Warning Devices & Signs

Adjust Stop Arm, Air Air Pressure	Adjust for full deployment and retraction
-----------------------------------	---

Every Month or 10,000 Miles
Axle & Suspension, Rear

Inspect Rear Axle Lubricant Level	If low, refill to bottom of filler opening. Use same lubricant type as already installed.
-----------------------------------	---

Every Month or 300,000 Miles
Brakes

Inspect Hydraulic Brakes Fluid	DOT-3 brake fluid.
--------------------------------	--------------------

**Every 3 Months or 3000 Miles****Cooling System**

Inspect Radiator Fins	Clean debris from fins.
Inspect Water Pump Belt	Inspect condition and tension of belt.

Every 3 Months or 5000 Miles
Brakes

Lubricate Air Brakes S-Cam	See Meritor Cam Brakes Appendix in Air Brakes Chapter for guidelines.
----------------------------	---

Lubricate Hydraulic Brakes Calipers	Lube per meritor specs.
-------------------------------------	-------------------------

Driveline

Lubricate Driveshafts Slip Joint	NLGI Grade #1 or #2 multipurpose grease.
----------------------------------	--

Lubricate Driveshafts U-Joint Bolts	NLGI Grade #1 or #2 multipurpose grease.
-------------------------------------	--

Inspect & Tighten Driveshafts U-Joint Bolts	Tighten to 45–50 ft lb.
---	-------------------------

Electrical

Inspect Alternator Connections	Inspect for loose wires, damaged terminals, damaged insulators.
--------------------------------	---

Inspect Battery Ground Strap	Check for solid connection, tight fasteners and absence of corrosion.
------------------------------	---

Fuel System

Inspect Fuel Lines	Inspect for leaks or signs of abrasion.
--------------------	---

Lubricate Fuel Stop Solenoid	
------------------------------	--

Inspect Fuel Tank Vent	Inspect for obstruction.
------------------------	--------------------------

Intake System

Inspect Air Cleaner Filter Element	Inspect for proper seating, secure lid. Replace if soiled, wet, or damaged.
------------------------------------	---

Inspect Intake Tract All Fasteners	Inspect for signs of contaminate infiltration, loose clamps, wear spots, holes in piping
------------------------------------	--

Inspect Intake Tract Charged Air Tubing	Inspect for signs of contaminate infiltration, loose clamps, wear spots, holes in piping
---	--

Inspect & Tighten Intake Tract Hose Clamps	Tighten to 10 in lb.
--	----------------------

Inspect & Tighten Intake Tract Spring Loaded Clamps	Tighten to near full spring compression.
---	--

Inspect Intake Tract Support Bracket	Visual inspection. Repair damaged parts immediately.
--------------------------------------	--



Inspect & Tighten Intake Tract T-Bolt Clamps	Tighten to 50 in lb.
--	----------------------

Inspect & Tighten Intake Tract Worm Gear Clamps	Tighten to 38–42 in lb.
---	-------------------------

Steering

Lubricate Axle Steering Linkage Drag Link	NLGI #2 EP multipurpose grease rated GC-LB or equivalent.
---	---

Lubricate Axle Steering Linkage King Pins	NLGI #2 EP multipurpose grease rated GC-LB or equivalent.
---	---

Lubricate Axle Steering Linkage Tie Rod Ends	NLGI #2 EP multipurpose grease rated GC-LB or equivalent.
--	---

Lubricate Intermediate Steering Shaft Slip Joint	Lubricate splines with multipurpose grease.
--	---

Every 3 Months or 24,000 Miles

Brakes

Inspect Air Brakes Air Dryer	See Bendix appendix for specific model in Air Brakes Chapter.
------------------------------	---

Inspect Hydraulic Brakes Booster & Master Cylinder	Inspect for signs of leakage or physical damage.
--	--

Every 6 Months or 6000 Miles
Warning Devices & Signs

Lubricate Destination Sign Hinges

Lubricate Destination Sign Roller Gears

Lightweight grease such as White Lube.

Axle & Suspension, Rear

Inspect & Tighten Comfort Air Suspension Shock Absorbers

Inspect for signs of leakage, wear, or damage. Tighten upper shock mounts to 50–70 ft lb. Tighten lower shock mounts to 150–180 ft lb.

Inspect Comfort Air Suspension Whole Assmebly

Visually inspect for damage.

Brakes

Replace Air Brakes Air Compressor Filter

Clean Air Brakes Check Valves

Clean & Lubricate Air Brakes Treadle Valve

See Bendix Treadle Valve Appendix in Air Brakes Chapter.

Clean Air Compressor Governor

Inspect Hydraulic Brakes Calipers

Inspect for signs of leakage or physical damage.

Electrical

Inspect Battery Battery Posts

Clean and apply anti corrosion agent.

Exhaust System

Inspect Exhaust Pipe Joints

Inspect for loose clamps, leaks, damage.

Fuel System

Replace Fuel Filter Filter Element

Clean Fuel Filter Inlet Screen

Clean. Replace if damaged.

Steering

Lubricate Steering Gear Pitman Arm Pivot

NLGI #2 EP multipurpose grease rated GC-LB or equivalent. Use hand-operated grease gun.



Every 6 Months or 10,000 Miles

Axle & Suspension, Rear

Inspect & Tighten Comfort Air Suspension Air Spring Anchor Bolts	Tighten to 20–30 ft lb.
Inspect & Tighten Comfort Air Suspension Air Spring Fasteners	Torque to 30–35 ft lb.
Inspect & Tighten Comfort Air Suspension Leveling Valve Mount Bolt	Tighten to 60–85 in lb.
Inspect & Tighten Comfort Air Suspension Lever Linkage Locknut	Tighten to 100–150 in lb.
Inspect & Tighten Comfort Air Suspension Lower Shock Mount	Tighten to 260–320 ft lb.
Inspect & Tighten Comfort Air Suspension Quick Align Bolts	Tighten to 525–575 ft lb.

Brakes

Lubricate Air Brakes Cam Shaft Housing	NLGI #2 EP multipurpose grease rated GC-LB or equivalent. Use hand-operated grease gun.
Lubricate Air Brakes Haldex Slack Adjusters	See Haldex lubricant specs in Air Brakes chapter.
Lubricate Air Brakes Meritor Slack Adjusters	See Meritor lubricant specs in Air Brakes chapter.

Steering

Lubricate Steering Column	Vision manual says to lubricate steering column. Where? With what? Check model applicability
---------------------------	--

Every 12 Months

Intake System

Test Intake Tract Restriction Indicator	Test indicator with vacuum gauge and pump.
---	--

Every 12 Months or 12,000 Miles
Heaters & Defrosters

Tighten Front Heater Fasteners	All fasteners holding such heaters in place in unit. For details on fasteners check installation prints.
Clean Front Heater Filter & Core	Clean dust from cores. Replace filter elements.
Bleed Heater System	Bleed air from heater circulation system. This procedure is done to keep system operating correctly.
Clean Underseat Heaters Filter Elements	Clean dust from cores.

Axle & Suspension, Front

Inspect Parabolic Spring Suspension Entire Assembly	Visually inspect for damage or misalignment.
Inspect & Tighten Parabolic Spring Suspension Hangar Bracket Bolts	Tighten to 75–85 ft lb.
Inspect Parabolic Spring Suspension Shock Absorbers	Visually inspect for leakage or damage.
Inspect & Tighten Parasteer Suspension Air Spring Fasteners	Torque to 20–30 ft lb.
Inspect & Tighten Parasteer Suspension Front Pivot Bolts	Torque to 450–480 ft lb.
Inspect & Tighten Parasteer Suspension Ride Height	Shock Length, eye-to-eye: 18.5" +/- .25"
Inspect & Tighten Parasteer Suspension Shock Absorbers	Inspect for leakage or damage. Torque upper and lower mount bolts to 50–70 ft lb.
Inspect & Tighten Parasteer Suspension Transverse Rod Bolts	Torque to 138–159 ft lb.

Axle & Suspension, Rear

Inspect Comfort Air Suspension Ride Height	Shock length, eye-to-eye: 24.68" +/- .25"
Inspect Comfort Air Suspension Ride Height	Shock length, eye-to-eye: 21.75" +/- .25"



Inspect & Tighten Comfort Air Suspension Shock Absorbers	Inspect for leakage or damage. Torque upper mount bolts to 50–70 ft lb. Torque lower mount bolts to 160–180 ft lb.
--	--

Inspect & Tighten Comfort Air Suspension Torque Arm Bolts	Torque to 150–205 ft lb.
---	--------------------------

Inspect & Tighten Comfort Air Suspension U-Bolts	Torque 7/8" bolts to 400–450 ft lb. Torque 3/4" bolts to 260–320 ft lb.
--	---

Cooling System

Test Entire Cooling System	Pressure Test Cooling system.
----------------------------	-------------------------------

Engine

Test Engine Starting Aid Block Heater	
---------------------------------------	--

Steering

Inspect Hydraulic Pump Body & Seals	Inspect for leaks.
-------------------------------------	--------------------

Inspect Steering Gear Body & Seals	Inspect for leaks.
------------------------------------	--------------------

Every 12 Months or 24,000 Miles

Brakes

Clean Air Brakes Pop Off Valves	
---------------------------------	--

Steering

Replace Hydraulic Reservoir Filter Element	Replace element and fluid. Replace more frequently in severe operating conditions. Dextron III.
--	---

Transmission

Replace Transmission Fluid	Use Dextron III fluid.
----------------------------	------------------------

Inspect Transmission Shift Cable	
----------------------------------	--

Inspect Transmission Vent	Clear vent hose of debris or obstruction.
---------------------------	---

Every 12 Months or 50,000 Miles

Axle & Suspension, Rear

Replace Rear Axle Petroleum Based Lubricant	Hypoid Gear Oil. Viscosity depends upon operating climate. See Viscosity/Temperature chart.
---	---

Every 12 Months or 100,000 Miles

Axle & Suspension, Rear

Replace Rear Axle Synthetic Lubricant	Viscosity depends upon operating climate. See Viscosity/Temperature chart.
---------------------------------------	--

Every 18 Months or 20,000 Miles**Cooling System**

Lubricate Shutters Pivots	Use Never Seize spray lubricant.
---------------------------	----------------------------------

Every 24 Months or 24,000 Miles**Brakes**

Clean Air Brakes Parking Brake Valve	See Bendix Appendixes in Air Brakes Chapter.
--------------------------------------	--

Clean Air Brakes Quick Release Valves	See Bendix Appendixes in Air Brakes Chapter.
---------------------------------------	--



Clean Air Brakes Relay Valves	See Bendix Appendixes in Air Brakes Chapter.
-------------------------------	--

Clean Air Brakes Spring Brake Valve	See Bendix Appendixes in Air Brakes Chapter.
-------------------------------------	--



Maintenance Locations

1. Spring Pins
2. Rear Axle Lubricant
3. Axle Vent
4. King Pin
5. Tie Rod
6. Drag Rod
7. Steering Gear
8. Not Applicable
9. Brake Camshaft
10. Brake Slack Adjusters
11. Automatic Transmission
12. Universal Joints
13. Driveline
14. Intake Air Restriction Indicator



General Data

Dimensions

HEADROOM: 74 TO 77 INCHES

EXTERIOR HEIGHT: APPROXIMATELY 118 TO 121 INCHES

EXTERIOR HEIGHT W/AC: ADD 16 INCHES

EXTERIOR WIDTH: 96 INCHES

INTERIOR WIDTH: 90.75 INCHES

Fluid Capacities (In Quarts)

	Crankcase Oil		Engine Coolant	Auto Trans. Fluid
	w/Filter	w/o Filter		
Caterpillar C7	22.0	20.0	41.0	20.0
Cummins ISC	24.0	20.0	38.0	19.0
John Deere 6.826.0	24.0	24.0	30.0	20.0
John Deere 8.132.0	30.0	30.0	42.0	20.0

Engine Oil Pressure

CATERPILLAR C7: 48 PSI @ 210° F

CUMMINS ISC: 40–50 PSI @ 2,500 RPM, WARM

JOHN DEERE 6.8: 14–40 PSI, IDLE TO RATED

JOHN DEERE 8.1: 20–58 PSI, IDLE TO RATED



NOTES



NOTES



BLUE BIRD



T E C H N I C A L P U B L I C A T I O N S

Post Office Box 937 • Fort Valley, Georgia 31030, USA • www.blue-bird.com