





MOTOMANUAL

L6
GSM 900/1800/1900 MHz
USER MANUAL

Welcome

Introducing your new motorola L6 GSM wireless phone. Here's a quick anatomy lesson.



Note: The above illustration is for reference only. There may be slight differences between the appearances of handset and keys and contents of display used in this manual and those of your handset. Please refer to your handset for actuality.

* Push-to-Talk (PTT) is a network or subscription-dependent feature. For more details, see page 56.

Mobile Devices Business

(852)2506-3888 (Hong Kong)

www.motorola.com.hk (Hong Kong)

MOTOROLA and the Stylized M Logo are registered in the US Patent & Trademark Office. The Bluetooth trademarks are owned by their proprietor and used by Motorola, Inc. under license. Java and all other Java-based marks are trademarks or registered trademarks of Sun Microsystems, Inc. in the U.S. and other countries. All other product or service names are the property of their respective owners.

© Motorola, Inc. 2005.

Software Copyright Notice

The Motorola products described in this manual may include copyrighted Motorola and third-party software stored in semiconductor memories or other media. Laws in the United States and other countries preserve for Motorola and third-party software providers certain exclusive rights for copyrighted software, such as the exclusive rights to distribute or reproduce the copyrighted software. Accordingly, any copyrighted software contained in the Motorola products may not be modified, reverse-engineered, distributed, or reproduced in any manner to the extent allowed by law. Furthermore, the purchase of the Motorola products shall not be deemed to grant either directly or by implication, estoppel, or otherwise, any license under the copyrights, patents, or patent applications of Motorola or any third-party software provider, except for the normal, non-exclusive, royalty-free license to use that arises by operation of law in the sale of a product.

While Products specifications and features may be subject to change without notice, we are making every possible effort to ensure that user manuals are updated on a regular basis to reflect product functionality revisions. However, in the unlikely event that your manual version does not fully reflect the core functionality of your product, please let us know. You may also be able to access up-to-date versions of our manuals from our Motorola web site, at <http://www.motorola.com.hk>.

Certain mobile phone features are dependent on the capabilities and settings of your service provider's network. Additionally, certain features may not be activated by your service provider, and/or the provider's network settings may limit the feature's functionality. Always contact your service provider about feature availability and functionality. All features, functionality, and other product specifications, as well as the information contained in this user's guide are based upon the latest available information and are believed to be accurate at the time of printing. Motorola reserves the right to change or modify any information or specifications without notice or obligation.

Manual Number: 6887370Z26

Contents

Feature Locator	6	Customize	46
Safety Information	8	Ring Style	46
Recycling Information	16	Time & Date	47
Essentials	17	Wallpaper	47
About This Guide	17	Screen Saver	48
SIM Card	18	Display Appearance	48
Battery	19	Answer Options	49
Turn It On & Off	21	Calls	50
Make a Call	21	Turn Off a Call Alert.	50
Answer a Call	22	Recent Calls	50
Your Phone Number	22	Redial	51
Main Attractions	23	Return a Call	52
Take & Send a Photo.	23	Notepad	52
Record Video.	25	Hold or Mute a Call.	52
Create & Share Media	27	Call Waiting.	53
Cable Connections	28	Caller ID	53
Bluetooth® Wireless	29	Emergency Calls	54
Basics	34	International Calls	54
Display	34	1-Touch Dial.	54
Menus	38	Voicemail	55
Create SMS	40	Push-to-Talk (PTT)	56
Navigation Key	44	Other Features	62
Hands-free Speaker	44	Advanced Calling	62
Codes & Passwords	44	Phonebook	64
Lock & Unlock Phone	45	Messages	68
Lock & Unlock Keypad	45	Personalising	70
		Call Times & Costs	73

Hands-free	73
Data & Fax Calls	75
Network	76
Personal Organizer	76
Security	77
Fun & Games	78
MyMobileSoft.com	80
SAR Data	82
Index	84

Note: The functions available on this handset may vary in different regions and nations. Please contact your local customer service centres, agencies or retailers if you have any question about the handset functions. Motorola reserves all rights to revise and change this user's manual without obligation to notify any person of such revisions or changes.

Feature Locator

Main Menu



Phonebook



Recent Calls

- Received Calls
- Dialed Calls
- Notepad
- Call Times
- Call Cost *
- Data Times *
- Data Volumes *



Messages

- New Message
- Message Inbox
- Outbox
- Drafts
- MMS Templates
- Quick Notes
- Browser Msgs *
- Info Services *
- Voicemail *



Tools

- SIM Applications *
- Calculator
- Datebook
- Shortcuts
- Alarm Clock
- Dialling services
 - Fixed Dial
 - Quick Dial
 - Voice Dial



Games & Apps



WebAccess

- Browser
- Web Shortcuts
- Stored Pages
- History
- Go To URL
- Browser Setup
- Web Sessions



Multimedia

- Pictures
- Sounds
- Camera
- Videos
- Video Camera



Bluetooth Link

- Hands-free
- Device history
- Setup



Settings

- (see next page)

* Indicates network or subscription-dependent features

The above gives an example of typical structure of main menu. Please refer to your handset for the actual structure. You can reorder the main menu according to your needs.

Settings Menu



Personalise

- Home screen
- Main Menu
- Colour Style
- Greeting
- Wallpaper
- Screen Saver



Ring Styles

- Style
- Style Detail



Connectivity

- Bluetooth Link
- Sync



Call Divert *

- Voice Calls
- Fax Calls
- Data Calls
- Cancel All
- Divert Status



In-Call Setup

- In-Call Timer
- Call Cost Setup *
- My Caller ID
- Answer Options
- Call Waiting *



Initial Setup

- Time and Date
- 1-Touch Dial
- Display Timeout
- Backlight
- Scroll
- Language
- Contrast
- Brightness
- DTMF
- Master Reset
- Master Clear



Phone Status

- My Tel. Numbers
- Active Line *
- Battery Meter



Headset

- Auto Answer
- Voice Dial



Car Settings

- Auto Answer
- Auto Handsfree
- Power-off Delay
- Charger Time



Network

- New Network
- Network Setup
- Available Networks
- My Network List *
- Service Tone
- Network Jingle
- Network Jingle
- Call Drop Tone



Security

- Phone Lock
- Lock Keypad
- Lock Application
- Fixed Dial
- Call Barring *
- SIM PIN
- New Passwords
- Certificate Mgmt *



PTT Settings

- PTT Service



Java Settings

- Java App Loader
- Java System
- Delete All Apps
- App Vibration
- App Volume
- App Backlight

* Indicates network or subscription-dependent features

Safety and General Information

This section contains important information on the safe and efficient operation of your mobile device. Read this information before using your mobile device.¹

Exposure To Radio Frequency (RF) Energy

Your mobile device contains a transmitter and receiver. When it is ON, it receives and transmits RF energy. When you communicate with your mobile device, the system handling your call controls the power level at which your mobile device transmits.

Your Motorola mobile device is designed to comply with local regulatory requirements in your country concerning exposure of human beings to RF energy.

Operational Precautions

For optimal mobile device performance and to be sure that human exposure to RF energy does not exceed the guidelines set forth in the relevant standards, always follow these instructions and precautions.

External Antenna Care

If your mobile device has an external antenna, use only a Motorola-supplied or approved replacement antenna. Use of unauthorized antennas, modifications, or attachments could damage the mobile device and/or may result in your device not complying with local regulatory requirements in your country.

1. The information provided in this document supersedes the general safety information in user's guides published prior to September 1, 2005.

DO NOT hold the external antenna when the mobile device is IN USE. Holding the external antenna affects call quality and may cause the mobile device to operate at a higher power level than needed.

Product Operation

When placing or receiving a phone call, hold your mobile device just like you would a landline phone.

If you wear the mobile device on your body, always place the mobile device in a Motorola-supplied or approved clip, holder, holster, case, or body harness. If you do not use a body-worn accessory supplied or approved by Motorola, keep the mobile device and its antenna at least 2.5 centimeters (1 inch) from your body when transmitting.

When using any data feature of the mobile device, with or without an accessory cable, position the mobile device and its antenna at least 2.5 centimeters (1 inch) from your body.

Using accessories not supplied or approved by Motorola may cause your mobile device to exceed RF energy exposure guidelines. For a list of Motorola-supplied or approved accessories, visit our website at www.motorola.com.

RF Energy Interference/Compatibility

Nearly every electronic device is subject to RF energy interference from external sources if inadequately shielded, designed, or otherwise configured for RF energy compatibility. In some circumstances your mobile device may cause interference with other devices.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Follow Instructions to Avoid Interference Problems

Turn off your mobile device in any location where posted notices instruct you to do so. These locations include hospitals or health care facilities that may be using equipment that is sensitive to external RF energy.

In an aircraft, turn off your mobile device whenever instructed to do so by airline staff. If your mobile device offers an airplane mode or similar feature, consult airline staff about using it in flight.

Pacemakers

If you have a pacemaker, consult your physician before using this device.

Persons with pacemakers should observe the following precautions:

- ALWAYS keep the mobile device more than 20 centimeters (8 inches) from your pacemaker when the mobile device is turned ON.
- DO NOT carry the mobile device in the breast pocket.
- Use the ear opposite the pacemaker to minimize the potential for interference.
- Turn OFF the mobile device immediately if you have any reason to suspect that interference is taking place.

Hearing Aids

Some digital mobile devices may interfere with some hearing aids. In the event of such interference, you may want to consult your hearing aid manufacturer or physician to discuss alternatives.

Other Medical Devices

If you use any other personal medical device, consult your physician or the manufacturer of your device to determine if it is adequately shielded from RF energy.

Driving Precautions

Check the laws and regulations on the use of mobile devices in the area where you drive. Always obey them.

When using your mobile device while driving, please:

- Give full attention to driving and to the road. Using a mobile device may be distracting. Discontinue a call if you can't concentrate on driving.
- Use handsfree operation, if available.
- Pull off the road and park before making or answering a call if driving conditions so require.

Responsible driving practices can be found in the "Smart Practices While Driving" section at the end of this guide and/or at the Motorola website: www.motorola.com/callsmart.

Operational Warnings

Obey all posted signs when using mobile devices in public areas, such as health care facilities or blasting areas.

Automobile Air Bags

Do not place a mobile device in the air bag deployment area.

Potentially Explosive Atmospheres

Areas with potentially explosive atmospheres are often but not always posted, and can include fueling areas such as below decks on boats, fuel or chemical transfer or storage facilities, or areas where the air contains chemicals or particles, such as grain, dust, or metal powders.

When you are in such an area, turn off your mobile device, and do not remove, install, or charge batteries. In such areas, sparks can occur and cause an explosion or fire.

Damaged Products





If your mobile device or battery has been submerged in water, punctured, or subjected to a severe fall, do not use it until you take it to a Motorola Authorized Service Center. Do not attempt to dry it with an external heat source, such as a microwave oven.


Batteries and Chargers

If jewelry, keys, beaded chains, or other conductive materials touch exposed battery terminals, this could complete an electrical circuit (short circuit), become very hot, and could cause damage or injury. Be careful when handling a charged battery, particularly when placing it inside a pocket, purse, or other container with metal objects. **Use only Motorola Original™ batteries and chargers.**

Caution: To avoid risk of personal injury, do not dispose of your battery in a fire.

Your battery, charger, or mobile device may contain symbols, defined as follows:

Symbol	Definition
	Important safety information follows.
	Do not dispose of your battery or mobile device in a fire.
	Your battery or mobile device may require recycling in accordance with local laws. Contact your local regulatory authorities for more information.
	Do not throw your battery or mobile device in the trash.

Symbol	Definition
	Your mobile device contains an internal lithium ion battery.

Choking Hazards

Your mobile device or its accessories may include detachable parts, which may present a choking hazard to small children. Keep your mobile device and its accessories away from small children.

Glass Parts

Some parts of your mobile device may be made of glass. This glass could break if the product is dropped on a hard surface or receives a substantial impact. If glass breaks, do not touch or attempt to remove. Stop using your mobile device until the glass is replaced by a qualified service center.

Seizures/Blackouts

Some people may be susceptible to epileptic seizures or blackouts when exposed to flashing lights, such as when playing video games. These may occur even if a person has never had a previous seizure or blackout.

If you have experienced seizures or blackouts, or if you have a family history of such occurrences, please consult with your physician before playing video games or enabling a flashing-lights feature (if available) on your mobile device.

Discontinue use and consult a physician if any of the following symptoms occur: convulsion, eye or muscle twitching, loss of awareness, involuntary movements, or disorientation. It is always a good idea to hold the screen away from your eyes, leave the lights on in the room, take a 15-minute break every hour, and stop use if you are very tired.

Repetitive Motion


When you repetitively perform actions such as pressing keys or entering finger-written characters, you may experience occasional discomfort in your hands, arms, shoulders, neck, or other parts of your body. If you continue to have discomfort during or after such use, stop use and see a physician.

1. ITC05-360

European Union Directives Conformance Statement

Hereby, Motorola declares that this product is in compliance with

- The essential requirements and other relevant provisions of Directive 1999/5/EC
- All other relevant EU Directives



The above gives an example of a typical Product Approval Number.

You can view your product's Declaration of Conformity (DoC) to Directive 1999/5/EC (the R&TTE Directive) at www.motorola.com/rtte - to find your DoC, enter the product Approval Number from your product's label in the "Search" bar on the Web site

Caring for the Environment by Recycling



When you see this symbol on a Motorola product, do not dispose the product with household waste.

Recycling Mobile Phones and Accessories



Do not dispose of mobile phones or electrical accessories, such as chargers or headsets, with your household waste. In some countries or regions, collection systems are set up to handle electrical and electronic waste items. Contact your regional authorities for more details. If collection systems aren't available, return unwanted mobile phones or electrical accessories to any Motorola Approved Service Centre in your region.



Essentials

About This Guide

This guide shows how to locate a menu feature as follows:

Find it: Press  > **Recent Calls** > **Dialled Calls**

This example shows that, from the home screen, you press  to open the menu, highlight and select  **Recent Calls**, then highlight and select **Dialled Calls**.

Press  to scroll to and highlight a menu feature. Press the *center key*  to select the highlighted menu feature.

Symbols



This means a feature is network/subscription dependent and may not be available in all areas. Contact your service provider for more information.




This means a feature requires an optional accessory.

SIM Card


Your *Subscriber Identity Module* (SIM) card contains personal information like your phone number and phonebook entries.

Caution: Don't bend or scratch your SIM card. Keep it away from static electricity, water, and dirt.


1




2




3



4




5




Battery

Battery Installation


1




2



3



4



Battery Charging

New batteries are not fully charged. Plug the travel charger into your phone and an electrical outlet. Your phone display shows **Charge Complete** when finished.



Tip: Relax, you can't overcharge your phone battery. It will perform best after you fully charge and discharge it a few times.

You can charge your phone battery by connecting a cable from your phone's mini-USB port to a USB port on a computer. Both your phone and the computer must be turned on, and your computer must have the correct software drivers installed. Cables and software drivers are available in Motorola Original data kits, sold separately.



If your phone battery is completely drained, a PC USB charger will not charge it. Use the travel charger.

Battery Tips

Battery life depends on the network, signal strength, temperature, features, and accessories you use.

- Always use Motorola Original batteries and chargers. The warranty does not cover damage caused by non-Motorola batteries and/or chargers.
- New batteries or batteries stored for a long time may take more time to charge.
- When charging your battery, keep it near room temperature.
- When storing your battery, keep it uncharged in a cool, dark, dry place, such as a refrigerator.
- Never expose batteries to temperatures below -10°C (14°F) or above 45°C (113°F). Always take your phone with you when you leave your vehicle.
- It is normal for batteries to gradually wear down and require longer charging times. If you notice a change in



your battery life, it is probably time to purchase a new battery.





Contact your local recycling center for proper battery disposal.

Warning: Never dispose batteries in a fire because they may explode.


Before using your phone, read the battery safety information in the “Safety and General Information” section included in this guide.

Turn It On & Off


To turn on your phone, press and hold  for a few seconds or until the display turns on. If prompted, enter your 4-digit unlock code.




Caution: If you enter an incorrect PIN code 3 times in a row, your SIM card is disabled and your display shows **SIM Blocked**. Contact your service provider.


To turn off your phone, press and hold  for 2 seconds.

Make a Call

Enter a phone number and press  to make a call.


To “hang up,” press .


To maintain high audio quality during calls, please note the location of the phone's





microphone (as indicated by the arrow) and keep this area free of obstruction while in use.


Answer a Call



When your phone rings and/or vibrates, just press  to answer.

To “hang up,” press .

Your Phone Number

From the home screen, press   to see your number.

Tip: Want to see your phone number while you’re on a call? Press  > **My Tel. Numbers**.


You can edit the name and phone number stored on your SIM card. From the home screen, press  , select an entry, and press the **View** > **Edit** key. If you don’t know your phone number, contact your service provider.




Main Attractions

You can do much more with your phone than make and receive calls!


Take & Send a Photo


Press the  > **Multimedia** > **Camera** to see the camera viewfinder:




Note: The number of pictures remaining is only an estimate.

- 1 Point the camera lens at the photo subject.

You can press  to open the **Pictures Menu**. See the table after this procedure.


- 2** Press the center key  or **Capture** key to take a photo.
- To delete the photo and return to the active viewfinder, press the **Discard** key.
 - To store or send the photo, press the **Store** key.

When the viewfinder is active, press  to open the **Pictures Menu**:

Options	
Go to Pictures	See stored pictures and photos.
Auto-Timed capture	Set a timer for the camera to take a photo.
Pictures Setup	Open the setup menu to adjust photo settings.
View free space	See how much memory remains.

Record Video

Press **[Menu]** > **Multimedia** > **Video Camera** to see the video viewfinder.



Note: The number of video clips remaining is only an estimate.

Note: You can zoom only before you start recording.

If you want to send your video in an MMS message, the video length must be set to MMS. To set length, press **[Menu]** > **Videos setup** > **Video length**.

Point the camera lens at the video subject, then:

- 1 Press the center key **[Center]** or **Capture** key to start the video.
- 2 Press the **Stop** key to stop the video.
- 3 Press **Store** to store the video.

Storing options for the video include: **Store Only** to store the video or **Send in Message** to send the video in a Multimedia Message.

or

Press the **Discard** key to delete the video and return to the active viewfinder.

Press  to open the **Videos Menu** when the viewfinder is active. The menu can include the following options:

Options	
Go To Videos	Watch videos stored on your phone.
Videos setup	Open the setup menu to adjust video settings. Note: Set Video length to MMS if you want to send your video in an MMS message. Set Video length to Maximum to record longer clips you can store on your phone.
View free space	See how much memory remains. Note: Your phone stores any content that you add, like ring tones or games, in <i>user memory</i> . Your service provider may store some content in user memory before you receive the phone.

Create & Share Media

Your phone has a multimedia album in its **Games & Apps**:







Find it: Press  > **Games & Apps** > **Multimedia Album**

Press **Play All Photos** to show a slide show of all the pictures stored on your phone with randomly played music and frames.


Create Multimedia Album



To create a multimedia album:



Note: Only photos in JPG format and up to 640 X 480 resolution are supported.

- 1 Highlight **Create Album** by pressing  or the center select key .
- 2 Press  left or right to navigate to the slide you want to add a picture. Press  to select a slide.
- 3 Press , then choose the picture that you would like to add into the slide, then press .

For Frame options, highlight **No Frame**. To add a frame, press  right to see frame options.

For Animation options, highlight **No Animation**. To add animation, press  right to see animation options.

To enter text, highlight , and press . Enter text and press **OK**.

To preview the slide, highlight . Press  to begin the preview.

4 To create the next slide, press left soft key twice to return to slide menu.

To assign music, highlight **No Music**, press \odot right to select music track.

To set animation speed, highlight **Fast Speed**, press \odot right to select speed.

To save the album press .

To delete the current slide or album press .


Note: You can create a maximum of 20 slides per album. Only music tracks in .mp3 and .midi format can be used.

Cable Connections

Note: Motorola Original USB data cable and supporting software may be sold together with the phone or separately. Check your computer or hand-held device to determine the type of cable you need. To **transfer data** between your phone and computer, you must install the software included with the Motorola Original data kit. See the data kit user's guide for more information. To make **data and fax calls** through a connected computer, see page 75.



Your phone has a mini-USB port so you can connect it to a computer to transfer data.



Bluetooth[®] Wireless

Your phone supports Bluetooth wireless *pairing* (also called *linking* or *bonding*). You can pair your phone with a Bluetooth headset or car kit, or pair your phone with a computer to exchange and synchronize files.

Note: The use of wireless devices and their accessories may be prohibited or restricted in certain areas. Always obey the laws and regulations on the use of these products.

Turn Bluetooth Power On or Off

Find it: Press  > **Bluetooth Link** > **Setup** > **Power** > **On**

If Bluetooth **Power** is **On**, your phone can automatically pair with the handsfree device you have used before. Just turn on the device or move it near the phone.

Note: To extend battery life, use the above procedure and set Bluetooth **Power** to **Off** when not in use. Your phone will not pair with devices until you set Bluetooth **Power** back to **On** and pair your phone with the devices again.

Pair with a Headset or Hands-free Device


Before you try to pair your phone with a device, make sure your phone's Bluetooth power is **on** and the device is **on** and **ready** in *pairing* or *bonding* mode (see the user's guide for the device). You can pair your phone with only one device at a time.

Find it: Press  > **Bluetooth Link** > **Hands-free**
> **[Look for devices]**



Your phone lists the devices it finds within range.

- 1 Highlight a device in the list and press the **Select** key.
- 2 If necessary, enter the device passkey (such as 0000) and press the **Ok** key.

When your phone is paired, the Bluetooth indicator  shows in the home screen.






Tip: For information about your headset or handsfree device, refer to the instructions that came with it.

Copy Objects to Another Device










You can use Bluetooth pairing to copy a media object, phonebook entry or datebook event from your phone to a computer or other device.











Note: Preloaded multimedia objects cannot be copied.

- 1 Highlight the object on your phone that you want to copy to the other device.
- 2 To copy media objects, press  > **Mark** (or press **0** to mark objects) and then press  > **Copy marked files**. To copy Datebook events, choose the date by pressing , then press  > **Send**. To copy Phonebook entries, select the entry, then press  > **Share Phonebook Entry**.
- 3 Select a recognized device name, or **[Look for devices]** to search for the device where you want to copy the object.

Advanced Bluetooth Features

Features		
Make Phone Visible to Other Device	Allow a Bluetooth device to discover your phone:  > Bluetooth Link > Setup > Find Me	
Pair with Recognized Device	Pair your phone with a recognized handsfree device:  > Bluetooth Link > Hands-free > [Look for devices]	
Drop Pairing With Device	Highlight the device name and press the Drop key.	
Switch to Device During Call	Switch to a headset or car kit during a call:  > Use Bluetooth	
Move Multimedia Object to Device	Move a multimedia object to another device: Note: Preloaded multimedia objects cannot be moved. Highlight the object, press  > Move , select the device name. Caution: Moving an object deletes the original object from your phone.	

Features	
Copy Media Objects, Datebook Events, and Phonebook Entries	<p>Highlight the object you want to copy to another location.</p> <p> > Mark (or press 0 to mark objects) and then press  > Copy marked files. To copy Datebook events, choose the date by pressing , then press  > Send. To copy Phonebook entries, select the entry, then press  > Share Phonebook Entry.</p>
Print Media Objects, Datebook Events, and Phonebook Entries	<p>Highlight the object you want to print to a printer.</p> <p>To print media objects, press  > Mark (or press 0 to mark objects) and then press  > Print Marked Files.</p> <p>To print Datebook events and Phonebook entries, press  > Print.</p>
Select Print Templates	<p>You can select desired print templates in the Print Options screen. After you have selected Print Marked Files or Print, select Template > Change > View (press navigation key up or down to view different templates) > Select > [Print]</p> <p>Note: For Border Free picture printing, select Copy marked files instead of Print Marked Files. Preloaded pictures cannot be printed.</p>

Features

Edit Device Properties

Edit the properties of a recognized device:

Highlight the device name, press the **Edit** key.



Set Bluetooth Options


Highlight the device name, press  > **Bluetooth Link** > **Setup**




Basics



See page 1 for a basic phone diagram.

Display



The *home screen* shows when you turn on the phone. To dial a number from the home screen, press number keys and .




The menu feature icons, their names, and functions indicated by soft key labels shown in the above illustration give an example of typical home screen. You can change menu feature icons and functions on soft key labels according to your needs.

Press the 5-way navigation key () left, right, up, or down to select one of the menu feature icons. If you select a menu icon by mistake, press  to return to the home screen.


Note: Your home screen may look different from the display shown above. For example, your service provider may hide the menu feature icons to allow a better view of the wallpaper image. You can still select the menu icons when they are hidden from view.

The *Menu Indicator*  shows that you can press  to open the menu. *Soft Key Labels* show the current soft key functions. For soft key locations, see page 1.



Your home screen might show news from your service provider at the bottom. To change this news view, press  > **Settings** > **Personalise** > **Home screen** > **Headlines** > **Off**.





Status indicators may be shown at the top of the home screen:



* Indicates network or subscription- dependent feature


1 Signal Strength Indicator – Vertical bars show the strength of the network connection. You can't make or receive calls when  or  shows.

2 GPRS Indicator – Shows when your phone is using a *General Packet Radio Service* (GPRS) network connection. Indicators can include:


-  = GPRS PDP context active
-  = GPRS packet data available







3 Bluetooth Indicator – Shows when a Bluetooth[®] connection is active (.

4 Roam Indicator – Shows when your phone is seeking or using a network outside your home network. Indicators can include:

-  = 2G home
-  = 2G roam
-  = 2.5G home
-  = 2.5G roam



5 PTT* /Active Line Indicator

PTT Indicator – Shows when you can make and receive PTT calls (). Other indicators can include:

-  = secure packet data transfer
-  = unsecure packet data transfer
-  = secure application connection
-  = unsecure application connection
-  = secure *Circuit Switch Data* (CSD) call
-  = unsecure CSD call


* Indicates network or subscription-dependent feature




Active Line Indicator – Shows  to indicate an active call, or  to indicate when call diverting is on. Indicators for dual-line-enabled SIM cards can include:

 = line 1 active


 = line 1 active, call divert on

 = line 2 active

 = line 2 active, call divert on

Note: The icon of Active Line Indicator will be changed to  when you make PTT calls.

6 Message Indicator – Shows when you receive a new message.

 = text message




7 Ring Style Indicator – Shows the ring style setting.


 = loud ring

 = vibrate & ring

 = soft ring


 = vibrate then ring


 = vibrate

 = silent

8 Battery Level Indicator – Vertical bars show the battery charge level. Recharge the battery when your phone shows **Low Battery**.










Menus

From the home screen, press  to enter the main menu.




* Please refer to your handset for actual display of menu feature icons.

The following menu icons may be available, depending on your service provider and service subscription options.

Menu Features	
 Phonebook	 WebAccess
 Recent Calls	 Multimedia
 Messages	 Bluetooth Link
 Tools	 Settings
 Games & Apps	


Some features require you to select an option from a list:



- Scroll up or down to highlight the option you want.
- In a numbered list, press a number key to highlight an option.
- In an alphabetized list, press a key repeatedly to cycle through its letters and highlight the closest matching list option.
- When an option has a list of possible settings, scroll left or right to select the setting.
- When an option has a list of possible numeric values, press a number key to set the value.

Create SMS

To create a new message, enter text.



Press **[#]** in a text entry view to select an entry mode:

Entry Modes	
[] or 1	Your Primary text entry mode can be set to any iTAP™ [] or tap 1 mode.
[] or 2	Your Secondary text entry mode can be set to any iTAP [] or tap 2 mode, or set to None if you don't want a secondary entry mode.
1 2	Numeric mode enters numbers only.
@	Symbol mode enters symbols only.

To set your primary and secondary text entry modes, press **[] > Entry Setup** in a text entry view and select **Primary Setup** or **Secondary Setup**.


Tip: WANT TO BE LOUD IN YOUR MESSAGE? Press **[0]** in a text entry view to change text case to all capital letters (**AB**), next letter capital (**Ab**), or no capitals (**ab**).

iTAP™ Mode

Press **[#]** in a text entry view to switch to iTAP mode. If you don't see **ab** or **Ab**, press **[] > Entry Setup** to set iTAP mode as your primary or secondary text entry mode.

iTAP mode lets you enter words using one key press per letter. The iTAP software combines your key presses into common words, and predicts each word as you enter it.

For example, if you press **[7] [7] [6] [4]**, your display shows:




- If you want a different word (such as **Progress**), continue pressing keypad keys to enter the remaining letters.
- To enter numbers quickly, press and hold a number key to temporarily switch to numeric mode. Press the number keys to enter the numbers you want. Enter a space to change back to iTAP mode.
- Press **[1]** to enter punctuation or other characters.

Tap Mode


Press **[#]** in a text entry view to switch to tap mode. If you don't see **Ab 1** or **Ab 2**, press **[≡] > Entry Setup** to set tap mode as your primary or secondary text entry mode.

To enter text in tap mode, press a keypad key repeatedly to cycle through the letters and number on the key. Repeat this step to enter each letter.

For example, if you press **[3]** one time, your display shows:



When you enter three or more characters in a row, your phone may guess the rest of the word. For example, if you enter **prog** your display might show:



- The first character of every sentence is capitalized. If necessary, press **↵** down to change the character to lowercase before the cursor moves to the next position.
- Press **↵** to move the flashing cursor to enter or edit message text.
- If you don't want to save your text or text edits, press **⏏** > **Abort Message** to exit without saving.



Numeric Mode

Press **#** in a text entry view until you see **12**. Press the number keys to enter the numbers you want.

Symbol Mode

Press **#** in a text entry view until you see **@**. Press a keypad key to show its symbols at the bottom of the display. Highlight the symbol you want, then press the **Select** key.

Navigation Key

Press the *navigation key*  up, down, left, or right to scroll and highlight items in the display. When you highlight something, press the *center key*  to select it. The center key usually performs the same function as the right soft key.



Hands-free Speaker

You can use your phone's handsfree speaker to make calls without holding the phone to your ear.


During a call, press the **Speaker** key to turn the handsfree speaker on. Your display shows **Spkrphone On** until you turn it off or end the call.

Note: The handsfree speaker won't work when your phone is connected to a handsfree car kit or headset.

Codes & Passwords

Your phone's 4-digit **unlock code** is originally set to **1234**. The 6-digit **security code** is originally set to **000000**. If your service provider didn't change these codes, you should change them:


Find it: Press  > **Settings** > **Security** > **New Passwords**

If you forget your unlock code: At the **Enter Unlock Code** prompt, try entering 1234 or the last four digits of your phone number. If that doesn't work, press  and enter your 6-digit security code instead.

If you forget other codes: If you forget your security code, SIM PIN code, PIN2 code, or call barring password, contact your service provider.

Lock & Unlock Phone



You can lock your phone to keep others from using it. To lock or unlock your phone, you need the 4-digit unlock code.

To **manually lock** your phone: Press  > **Settings** > **Security** > **Phone Lock** > **Lock Now**.

To **automatically lock** your phone whenever you turn it off: Press  > **Settings** > **Security** > **Phone Lock** > **Automatic Lock** > **On**.

Note: You can make emergency calls on a locked phone (see page 54). A locked phone still rings or vibrates for incoming calls or messages, **but you need to unlock it to answer**.

Lock & Unlock Keypad

You can lock your keypad to prevent accidental key presses. Press   to lock or unlock the keypad.


Customize

Ring Style

Each ring style profile uses a different set of sounds or vibrations for incoming calls and other events. Here are the profiles you can choose:

 **Loud**

 **Vibrate**


 **Vibe then Ring**

 **Soft**

 **Vibe & Ring**

 **Silent**

The ring style profile's indicator shows at the top of your home screen. To choose your profile:

Find it: Press  > **Settings** > **Ring Styles** > **Style:** *style name*

Change Alerts in a Ring Style

You can change the alerts for incoming calls and other events. Your changes are saved in the current ring style profile.


Find it: Press  > **Settings** > **Ring Styles** > **Style Detail**

Note: *Style* represents the current ring style. You can't set an alert for the **Silent** ring style setting.


- 1 Highlight **Calls** (or **Line 1** or **Line 2** for dual-line phones), then press the **Change** key to change it.
- 2 Highlight the alert you want, then press the **Select** key.
- 3 Press the **Back** key to save the alert setting.


Time & Date

Your phone needs the time and date for the datebook.

To synchronize the time and date with the network*: Press  > **Settings** > **Initial Setup** > **Time and Date** > **Autoupdate** > **On**



To set the time and date: Press  > **Settings** > **Initial Setup** > **Time and Date** > *time or date*.

Note: If your home screen shows news information from your service provider, you must turn off the news view to see a clock. Press  > **Settings** > **Personalise** > **Home screen** > **Headlines** > **Off**.



* Indicates network or subscription-dependent feature

Wallpaper

Set a photo, picture, or animation as a wallpaper (background) image in your home screen.

Find it: Press  > **Settings** > **Personalise** > **Wallpaper**

Options	
Picture	Select an image for your wallpaper, or None for no wallpaper.
Layout	Select Centre to center the image in the display, Tile to repeat the image across the display, or Fit-to-screen to stretch the image across the display.

Screen Saver

Set a photo, picture, or animation as a screen saver. The screen saver shows when no activity is detected for a specified time.


Tip: This feature helps save your screen, but not your battery. To extend battery life, turn off the screen saver.

Find it: Press  > **Settings** > **Personalise** > **Screen Saver**


Options	
Picture	Select an image for your screen saver, or None for no screen saver.
Delay	Select the length of inactivity before the screen saver shows.

Display Appearance

To choose a phone **colour style** that sets the look and feel of your phone's display: Press  > **Settings** > **Personalise** > **Colour Style**.

To set your display **contrast**: Press  > **Settings** > **Initial Setup** > **Contrast**.

To save battery life, your **backlight** turns off when you're not using your phone. The backlight turns back on when you press a key. To set how long your phone waits before the backlight turns off:

Press  > **Settings** > **Initial Setup** > **Backlight**.

To save battery life, the **display** can turn off when you're not using your phone. The display turns back on when you press

a key. To set how long your phone waits before the display turns off:

Press  > **Settings** > **Initial Setup** > **Display Timeout**.

Answer Options


You can use additional, alternative methods to answer an incoming call. To activate or deactivate an answer option:

Find it: Press  > **Settings** > **In-Call Setup** > **Answer Options** > **Multi-key** > **On** or **Off**

Calls


To make and answer calls, see page 21.

Turn Off a Call Alert



You can press left or right of  to turn off a call alert before answering the call.

Recent Calls

Your phone keeps lists of incoming and outgoing calls, even for calls that didn't connect. The most recent calls are listed first. The oldest calls are deleted as new calls are added.



Shortcut: Press  from the home screen to see the dialled calls list.


Find it: Press  > **Recent Calls**

- 1 Highlight **Received Calls** or **Dialled Calls**, then press the **Select** key.
- 2 Highlight a call. A ✓ next to a call means the call connected.
 - To call the number, press .
 - To see call details (like time and date), press the **View** key.
 - To see the **Last Calls Menu**, press . This menu can include:

Options	
Store	Create a phonebook entry with the number in the No. field. Store does not appear if the number is already stored.
Delete	Delete the entry.
Delete All	Delete all entries in the list.
Hide ID/Show ID	Hide or show your caller ID for the next call.
Send Message	Open a new text message with the number in the To field.
Add Digits	Add digits after the number.
Attach Number	Attach a number from the phonebook or recent calls lists.

Redial


- 1 Press  from the home screen to see the dialled calls list.
- 2 Highlight the entry you want to call, then press .

If you hear a **busy signal** and you see **Call Failed**, you can press  or the **Retry** key to redial the number. When the call goes through, your phone rings or vibrates one time, shows **Redial Successful**, and connects the call.



Return a Call



Your phone keeps a record of your unanswered calls, and shows **X Missed Call(s)**, where **X** is the number of missed calls.

- 1 Press the **View** key to see the received calls list.
- 2 Highlight the call you want to return, then press .


Notepad


The last set of digits entered on the keypad are stored in *notepad* memory. This can be the last phone number you called, or a number that you “jot down” during a call for later use. To see the number stored in the notepad:

Find it: Press  > **Recent Calls** > **Notepad**

- To call the number, press .
- To create a phonebook entry with the number in the **No.** field, press the **Store** key.
- To open the **Dialling Menu** to attach a number or insert a special character, press .

Hold or Mute a Call

Press  > **Hold** to put all active calls on hold.


Press the **Mute** key (if available) or  > **Mute** to put all active calls on mute.

Call Waiting

When you're on a call, you'll hear an alert if you receive a second call.



Press  to answer the new call.

- To switch between calls, press the **Switch** key.
- To connect the two calls, press the **Link** key.
- To end the call on hold, press  > **End Call on Hold**.

To turn the call waiting feature on or off:

Find it: Press  > **Settings** > **In-Call Setup** > **Call Waiting**

Caller ID

Calling line identification (caller ID) shows the phone number for an incoming call in your display.



Your phone shows the caller's name and picture when they're stored in your phonebook, or **Anonymous Call** when caller ID information isn't available.

You can set your phone to play a different ringer ID for an entry stored in your phonebook (see page 65).


To show or hide **your phone number** from the next person you call, enter the phone number and press

 > **Hide ID/Show ID**.


Emergency Calls

Your service provider programs one or more emergency phone numbers, such as 999 or 112, that you can call under any circumstances, even when your phone is locked or the SIM card is not inserted.

Note: Emergency numbers vary by country. Your phone's preprogrammed emergency number(s) may not work in all locations, and sometimes an emergency call cannot be placed due to network, environmental, or interference issues.

- 1 Press the keypad keys to dial the emergency number.
- 2 Press  to call the emergency number.

International Calls

If your phone service includes international dialling, press and hold  to insert your local international access code (indicated by +). Then, press the keypad keys to dial the country code and phone number.





1-Touch Dial

To call phonebook entries 1 through 9, press and hold the single-digit speed dial number for one second.

You can set 1-touch dial to call the entries in your phone's memory phonebook, your SIM card's phonebook, or your Fixed Dial list:


Find it: Press  > **Settings** > **Initial Setup** > **1-Touch Dial**
> **Phone, SIM, or Fixed Dial**

To add a new phonebook entry, see page 64. To edit the **Speed No.** for a phonebook entry, press  > **Phonebook**, highlight the entry, and press  > **Edit**.

Voicemail

Your network stores the voicemail messages you receive. To listen to your messages, call your voicemail number.

Note: Your service provider may include additional information about using this feature.

When you **receive** a voicemail message, your phone shows the voicemail message indicator  and **New Message**. Press the **Read** key to read the message.

To **check** voicemail messages:

Find it: Press  > **Messages** > **Voicemail**

Your phone may prompt you to store your voicemail phone number. If you don't know your voicemail number, contact your service provider.

Note: You can't store a **p** (pause), **w** (wait), or **n** (number) character in this number. If you want to store a voicemail number with these characters, create a phonebook entry for it. Then, you can use the entry to call your voicemail.



Push-to-Talk (PTT)*

Push-to-Talk (PTT) lets you talk walkie-talkie style with other PTT subscribers. You can talk to one person or a group.


PTT and the other related features indicated are network and subscription dependent features, and are only available in PTT supported network areas. PTT connectivity requires PTT-compatible phones.



Note: To lock your PTT Key or turn PTT on or off, see page 60.

* Indicates network or subscription-dependent feature


Make a PTT Call

When  shows at the top of your home screen, you can make and receive PTT calls. To make a PTT call:

- 1 Enter a PTT subscriber's phone number in your home screen, or select a contact or group from a list and press the PTT Key:
 - **PTT Contacts** (press the PTT Key to open the list)
Note: If you change your **Open to** setting, your PTT Key does not open the contacts list (see page 60).
 - **PTT Quick Group** (press the PTT Key > **PTT Menu** > **PTT Quick Group**) This lets you select more than one contact for the call.
 - **PTT Groups** (press the PTT Key > **PTT Menu** > **PTT Groups**)

- 2 After the PTT call has been connected, hold the PTT Key and speak after you hear the tone. Release the PTT Key to let others speak.


To speak during a PTT call, hold your PTT Key and speak after the tone. Only one person can speak at a time.

To end the call, press . If nobody speaks for 20 seconds, the call ends.

To send a PTT alert instead of a standard PTT call, highlight a PTT contact in **PTT Contacts** and press the **Alert** key. The contact's phone rings or vibrates, and the contact can speak first. If the contact does not respond, the call ends. You can send alerts to groups after getting no response from a contact.

Answer a PTT Call

When you receive a PTT call, you hear a tone or alert followed by conversation from the caller.

- **To speak** when the caller stops speaking, hold your PTT Key and speak after the tone. Only one person can speak at a time.
- **To end the call**, press 

If you change your **My Answer Mode** setting, your phone does not automatically answer as described (see page 60).

When you receive a PTT alert, press the PTT Key and speak after the tone. You can also press the **Ignore** key to cancel the call.


Your phone shows **Missed Call** if you miss a PTT alert. It does not show **Missed Call** when you miss a standard PTT call unless you set **My Answer Mode** to **Manual** (see page 60).


PTT Contacts and Groups


You can store **PTT Contacts** to make one-to-one calls, or you can store **PTT Groups** to make group calls.



To store a contact, press PTT Key >  > **Add New Contact**.







Enter the contact's **Name** and phone number (**No.**), then press the **Done** key. Your network stores the contact and your phone returns to the **PTT Contacts** list with the new contact shown.



To create a group of contacts that you can call at the same time, press PTT Key >  > **Go To Groups** > **[Add New Group]**. Enter the group's **Name** and select the **Members**, then press the **Done** key. Your network stores the group and your phone returns to the **PTT Groups** list with the new group shown.


To see PTT contacts, press the PTT Key. Scroll to a contact and press  to **View**, **Edit**, or **Delete** it.




To see PTT groups, press the PTT Key >  > **Go To Groups**. Scroll to a group and press  to **View** or **Delete** it. You cannot edit a group, but you can delete it and create a new one with the members you want.


Icons in the PTT contact and group lists indicate if someone is online (, ) or offline (, ). They also tell you if a contact is blocked  (highlight the contact and press  > **Edit** > **Block Mode** > **On or Off**).

To set an **online alert**  to tell you when a contact comes online, highlight the contact and press  > **Enable Online Alert**. You can turn online alert tones on or off in your **PTT Setup** menu (see page 60).

To refresh the contact or group list from your network, press  > **Refresh List**.

To see only your frequently used contacts or groups, press  > **Frequently Used**.

PTT Settings

To **turn PTT on or off** from your home screen, press  > **Settings** > **PTT Settings** > **PTT Service** > **On/Off**.

Note: When PTT service has been activated, the Smart Key on the left of the handset can only be used for PTT functions.

You can change your PTT menu and call preferences.

Find it: Press PTT Key > **PTT Menu** > **PTT Setup** > **Personalise**

Options	
Open to	From the home screen, the PTT Key can open the PTT menu (PTT Menu), or your contacts list sorted by name (Contacts), or most recent call (Last Contact Called).
Sort by	Sort your contacts and groups by Name , online Status , or call Frequency .
My Answer Mode	Set the mode for incoming PTT calls to Manual (press the PTT Key to answer), Auto-Accept (standard mode that accepts all calls), or Do Not Disturb (accepts no calls).
Tone Volume	Set the volume for the tone you hear when it is your turn to speak.
PTT Speaker	Turn the speakerphone On or Off for PTT calls.

Options

Set Online Alert Tone














You can set an online alert to tell you when a contact or group comes online (highlight the entry in your **PTT Contacts** or **PTT Groups** and press










 > **Enable Online Alert**).

This setting tells your phone whether to play these alert tones (**On**) or not (**Off**).





Other Features

Advanced Calling

Features	
Conference Call	<p>During a call:</p> <p>Dial next number, press , press the Link key.</p> 
Transfer a Call	<p>During a call:</p> <p> > Transfer, dial transfer number, press </p> 
Attach a Phone Number	<p>Dial an area code or prefix for a phonebook number, then:</p> <p> > Attach Number</p> 
Speed Dial	<p>Speed dial a phonebook entry:</p> <p>Enter the speed dial number, press , then press .</p> <p>To add a phonebook entry, see page 64.</p> <p>Tip: If you forget Aunt Mildred's speed dial number, press  > Phonebook, highlight her entry, and press the View key.</p> 
Call Diverting	<p>Set up or cancel call diverting:</p> <p> > Settings > Call Divert</p> 

Features	
Call Barring	<p>Restrict outgoing or incoming calls:</p> <p> > Settings > Security > Call Barring</p> 
Change Phone Line	<p>If you have a dual-line-enabled SIM card, you can change your line to make and receive calls from your other phone number.</p> <p> > Settings > Phone Status > Active Line</p> <p>The active line indicator shows the active phone line (see page 36).</p> 
Fixed Dial	<p>When you turn on fixed dialling, you can call only numbers stored in the fixed dial list.</p> <p>Turn fixed dialling on or off:</p> <p> > Settings > Security > Fixed Dial</p> <p>Use the fixed dial list:</p> <p> > Tools > Dialling services > Fixed Dial</p> 
DTMF Tones	<p>Activate DTMF tones:</p> <p> > Settings > Initial Setup > DTMF</p> <p>To send DTMF tones during a call, just press number keys or highlight a number in the phonebook or recent calls lists and press  > Send Tones.</p>

Phonebook






Features	
Add New Entry	<p> > Phonebook >  > New > Phone Number</p> <p>Shortcut: Enter a phone number in the home screen, then press the Store key to create an entry for that number.</p> <p>Tip: One phone isn't enough for some people. When creating a phonebook entry, select MORE to store another number for the same Name.</p>
Dial Number	<p>Call a number stored in the phonebook:</p> <p> > Phonebook, highlight the phonebook entry, press </p> <p>Shortcut: In the phonebook, press keypad keys to enter the first letters of an entry name, then press the Search key to jump to the entry.</p>
Record a Voice Name	<p>When creating a phonebook entry, highlight Voice Name and press the Record key. Press Record and say the entry's name (within 2 seconds). When prompted, press Record again and repeat the name.</p> <p>Note: The Voice Name option isn't available in entries stored on the SIM card.</p>


















Features	
Voice Dial Number	<p>Voice dial a number stored in the phonebook:</p> <p>☰ > Tools > Dialling services > Voice Dial</p>
Set Ringer ID for Entry	<p>Assign a ring alert (ringer ID) to an entry:</p> <p>☰ > Phonebook > <i>entry</i> > ☰ > Edit > Ringer ID > <i>ringer name</i></p> <p>Note: The Ringer ID option isn't available in entries stored on the SIM card.</p> <p>Activate ringer IDs:</p> <p>☰ > Settings > Ring Styles > <i>style Detail</i> > Ringer IDs</p>
Set Picture ID for Entry	<p>Assign a photo or picture to show when you receive a call from an entry:</p> <p>☰ > Phonebook > <i>entry</i> > ☰ > Edit > Picture</p> <p>Note: The Picture option isn't available in entries stored on the SIM card.</p>
Set Category for Entry	<p>☰ > Phonebook > <i>entry</i> > ☰ > Edit > Category > <i>category name</i></p> <p>Note: The Category option isn't available in entries stored on the SIM card.</p>

Features	
Set Category View	<p>☐ > Phonebook ></p> <p>☐ > Categories > <i>category view</i></p> <p>You can show All entries, entries in a predefined category (Business, Personal, General, VIPs), or entries in a category you create.</p>
Set Primary Number or Address	<p>Set the primary number for an entry with multiple numbers:</p> <p>☐ > Phonebook, highlight the entry, press</p> <p>☐ > Set Primary > <i>number</i> or <i>address</i></p> <p>Note: The Set Primary option isn't available in entries stored on the SIM card.</p> <p>Tip: In Primary number view mode, you can still peek at other numbers stored for the same name. Highlight the name and press ◂ or ▸ left or right to see the other numbers.</p>
Create Group Mailing List	<p>You can put several phonebook entries in a group mailing list, then send a multimedia message to the list. To create a list:</p> <p>☐ > Phonebook > ☐ > New > Mailing List</p> <p>You can select the list name as an address for multimedia messages.</p> <p>Note: A Mailing List cannot include entries stored on the SIM card.</p>

Features	
Sort Phonebook List	<p>Set the order in which entries are listed:</p> <p>☰ > Phonebook > ☰ > Setup > Sort by > <i>sort order</i></p> <p>You can sort the phonebook list by Name, Speed No., Voice Name or Email. When sorting by name, you can see All numbers or just the Primary number for each name.</p>
Copy Phonebook Entry	<p>Copy an entry from the phone to the SIM card, or from the SIM card to the phone:</p> <p>☰ > Phonebook, highlight the entry, press ☰ > Copy > Entries > To</p>
Send Phonebook Entry in a Text Message	<p>Send a phonebook entry in a text message:</p> <p>☰ > Insert > Contact Info > Phonebook (highlight phonebook entries), press Add > Done</p>
Send Phonebook Entry Over Bluetooth® Connection	<p>Send a phonebook entry to another phone, computer, or device:</p> <p>☰ > Phonebook, highlight the entry, press ☰ > Share Phonebook Entry > [Look for devices]</p>

Messages

Features	
Send Text Message	<p>[] > Messages > New Message > New Short Msg > enter text > Send To > press center key  to select recipient > Send</p> 
Send Multimedia Message	<p>[] > Messages > New Message > New Multimedia Msg</p> 
Send Voice Message	<p>[] > Messages > New Message > New Voice Msg</p> <p>To record the voice message, press the Record key, speak, then press the Stop key. Your phone inserts the voice recording into a message.</p> 
Use a Multimedia Template	<p>Open a multimedia message with preloaded animations:</p> <p>[] > Messages > New Message > MMS Templates</p> 

Features		
Read Messages	<p> > Messages > Message Inbox</p> <p>Icons next to each message indicate if it is read  or unread . Icons can also indicate if the message is locked , urgent  or has an attachment .</p> <p>To see message options like Lock or Delete, highlight a message and press .</p>	
Store Message Objects	<p>Go to a multimedia message press:</p> <p> > Store</p>	
Store Text Messages on Your SIM Card	<p>To store incoming text messages on your SIM card, press:</p> <p> > Messages >  > Inbox Setup > Text Msg Setup > Store To > SIM</p>	
Browser Messages	<p>Read messages received by your micro-browser:</p> <p> > Messages > Browser Msgs</p>	
Info Services*	<p>Read subscription-based information services messages:</p> <p> > Messages > Info Services</p>	


* Indicates network or subscription-dependent feature

Features	
Change Message Service Center Number	<p>You can change the message service center number.</p> <p>☰ > Messages > ☰ > Inbox Setup > Text Msg Setup > Service Centre No.</p>







Personalising


Features	
Language	<p>Set menu language:</p> <p>☰ > Settings > Initial Setup > Language</p>
Scroll	<p>Set the highlight bar to stop or wrap around in menu lists:</p> <p>☰ > Settings > Initial Setup > Scroll</p>
Activate Ringer IDs	<p>Activate ringer IDs assigned to phonebook entries and categories:</p> <p>☰ > Settings > Ring Styles > <i>style</i> Detail > Ringer IDs</p>
Ring Volume	<p>☰ > Settings > Ring Styles > <i>style</i> Detail > Ring Volume</p>
Keypad Volume	<p>☰ > Settings > Ring Styles > <i>style</i> Detail > Key Volume</p>

Features	
Reminders	<p>Set reminder alerts for messages that you receive:</p> <p>☰ > Settings > Ring Styles > <i>style</i> Detail > Reminders</p>
News View *	<p>If your service provider broadcasts news information that always appears in your home screen, you can turn the news view on or off:</p> <p>☰ > Settings > Personalise > Home screen > Headlines > On or Off</p> 
Menu View	<p>Show the main menu as graphic icons or as a text-based list:</p> <p>☰ > Settings > Personalise > Main Menu > View</p>
Main Menu	<p>Reorder your phone's main menu:</p> <p>☰ > Settings > Personalise > Main Menu > Reorder</p>




* Indicates network or subscription-dependent feature

Features	
Shortcuts	<p>Create a shortcut to a menu item:</p> <p>Highlight the menu item, then press and hold .</p> <p>Use a shortcut:</p> <p>Press , then press the shortcut number.</p>
Master Reset	<p>Reset the phone to the default settings:</p> <p> > Settings > Initial Setup > Master Reset</p> <p>This phone will be reset to default settings.</p>
Master Clear	<p>Erase all downloaded files and clear all settings and entries you made except SIM card information, unlock code, security code, and lifetime timer:</p> <p> > Settings > Initial Setup > Master Clear</p> <p>Caution: Master clear erases all information you have entered (including phonebook and datebook entries) and content you have downloaded (including photos and sounds) stored in your phone's memory. After you erase the information, you can't recover it.</p>

Call Times & Costs*

Network connection time is the elapsed time from the moment you connect to your service provider's network to the moment you end the call by pressing . This time includes busy signals and ringing.

The amount of network connection time you track on your resettable timer may not equal the amount of time for which you are billed by your service provider. For billing information, contact your service provider.












Features	
Call Times	Show call timers:  > Recent Calls > Call Times
In-Call Timer	Show time or cost information during a call:  > Settings > In-Call Setup > In-Call Timer
Call Cost *	Show call cost trackers:  > Recent Calls > Call Cost



* Indicates network or subscription-dependent feature






Hands-free

Note: The use of wireless devices and their accessories may be prohibited or restricted in certain areas. Always obey the laws and regulations on the use of these products.

Features	
Speakerphone	<p>Activate the speakerphone during a call:</p> <p>Press the Speaker key (if available, or  > Spkrphone On).</p>
Auto Answer (Car Kit or Headset)	<p>Automatically answer calls when connected to a car kit or headset:</p> <p> > Settings > Car Settings or Headset > Auto Answer</p> 
Voice Dial (Headset)	<p>Enable voice dial with headset send/end key:</p> <p> > Settings > Headset > Voice Dial</p> 
Auto Handsfree (Car Kit)	<p>Automatically route calls to a car kit when connected:</p> <p> > Settings > Car Settings > Auto Handsfree</p> 
Power-off Delay (Car Kit)	<p>Set the phone to stay on for a specified time after the ignition is switched off:</p> <p> > Settings > Car Settings > Power-off Delay</p> 
Charger Time (Car Kit)	<p>Charge the phone for a specified time after the ignition is switched off:</p> <p> > Settings > Car Settings > Charger Time</p> 


Data & Fax Calls*

To connect your phone with a USB cable, see page 28.

Features		
Send Data or Fax	Connect your phone to the device, then place the call through the device application.	
Receive Data or Fax	Connect your phone to the device, then answer the call through the device application.	
Using Sync	<p>You can call an Internet server and synchronize your phonebook and datebook entries with the server.*</p> <p>To set up an Internet sync partner, press  > Settings > Connectivity > Sync > [New Entry]. Enter the server details, including server URL (you can omit http://) and Data paths (the folder below the URL where your data is stored).</p> <p>To synchronize files with a partner you set up, select the partner from the list in  > Settings > Connectivity > Sync.</p>	








* Indicates network or subscription- dependent feature








Network

Features	
Network Settings	See network information and adjust network settings:  > Settings > Network





Personal Organizer

Features	
Set Alarm	 > Tools > Alarm Clock > [New Alarm]
Turn off Alarm	When an alarm happens: To turn off the alarm, press the Disable key or  . To set an 8 minute delay, press the Snooze key.
Add New Datebook Event	 > Tools > Datebook , highlight the day, press  , press  > New
See Datebook Event	See or edit event details:  > Tools > Datebook , highlight the day, press  , press the View key
Event Reminder	When an event reminder happens: To see reminder details, press the View key. To close the reminder, press the Exit key.

Features	
Send Datebook Event to Another Device	Send a datebook event to another phone, computer, or device:  > Tools > Datebook , highlight the day, press  , highlight the event, press  > Send
Calculator	 > Tools > Calculator
Currency Converter	 > Tools > Calculator >  > Exchange Rate Enter exchange rate, press the Ok key, enter amount, and press  > Convert Currency .

Security

Features	
SIM PIN	Lock or unlock the SIM card:  > Settings > Security > SIM PIN Caution: If you enter an incorrect PIN code 3 times in a row, your SIM card is disabled and your display shows SIM Blocked .
Lock Feature	 > Settings > Security > Lock Application

Features	
Manage Certificates *	<p>Enable or disable Internet access certificates stored on your phone:</p> <p>☰ > Settings > Security > Certificate Mgmt</p> <p>Certificates are used to verify the identity and security of Web sites when you download files or share information.</p>












* Indicates network or subscription- dependent feature

Fun & Games

For basic information on the camera, see page 23.

Features	
Manage Pictures	<p>Manage photos, pictures, and animations:</p> <p>☰ > Multimedia > Pictures</p>
Manage Video Clips	<p>To play video clips, press ☰ > Multimedia > Videos, select the video clip > Play</p> <p>Note: Only MP4 with AMR video clips are supported under video download.</p>
Manage Sounds	<p>Manage ring tones and music that you have downloaded or composed:</p> <p>☰ > Multimedia > Sounds</p>




Features	
Create Ring Tones	<p>Create ring tones that you can use with your phone:</p> <p> > Multimedia > Sounds > [New iMelody]</p>
Start Micro-browser	<p> > WebAccess > Browser</p> 
Download Objects from Web Page	<p>Download a picture, sound, or other object from a Web page:</p> <p> > WebAccess > Browser, go to the page that links to the file, highlight the link, and select it.</p> <p>Note: Normal airtime and/or carrier usage charges apply.</p> 
Web Sessions	<p>Select or create a Web session:</p> <p> > WebAccess > Web Sessions</p> 
Download Game or Application	<p>You can download a Java™ game or application the same way you download pictures or other objects:</p> <p> > WebAccess > Browser, go to the page that links to the file, highlight the link, and select it.</p> <p>Note: Normal airtime and/or carrier usage charges apply.</p> 

Features

Start Game or Application

Start a Java™ game or application:

 > **Games & Apps**, highlight the game or application, press the **Select** key



MyMobileSoft.com

Introduction

MyMobileSoft.com¹ provides download of both free and paid software for your Motorola handset. Depends on each model, you may download games, ring tones, screen savers, wall papers, e-books, financial and others software from MyMobileSoft.com.

1. All software and applications contained on MyMobileSoft.com are third party products and provided as is. Motorola or its subsidiaries make no representations or warranties, expressly or impliedly. By way of example but not of limitation, Motorola or its subsidiaries make no representations or warranties of merchantability or fitness for a particular purpose, or that the use of the software and applications will not infringe any intellectual property rights. Motorola or its subsidiaries shall not be liable for any damages of any kind arising out of or relating to the use or inability to use the software and applications and services thereof. Amendment and availability of these software and applications are subject to change without any prior notice.

For more information, please visit the internet website:

www.mymobilesoft.com

Access to MyMobileSoft.com²

Find the Feature

☰ > Tools

> Shortcuts > 9

> Go To

OR

☰ > 9

This link guides you to the service of MyMobileSoft.com, which provides software and applications for your newly bought Motorola Mobile Phone.

2. You need to subscribe WAP service from your local operators, please make sure that you set up your handset correctly with appropriate parameters provided by your local operators.

www.mymobilesoft.com

Unlimited surprises waiting for
you to download

Specific Absorption Rate Data

This model meets international guidelines for exposure to radio waves.

Your mobile device is a radio transmitter and receiver. It is designed not to exceed the limits for exposure to radio waves recommended by international guidelines. These guidelines were developed by the independent scientific organization ICNIRP and include safety margins designed to assure the protection of all persons, regardless of age and health.

The guidelines use a unit of measurement known as the Specific Absorption Rate, or SAR. The ICNIRP SAR limit for mobile devices used by the general public is 2 W/kg and the highest SAR value for this device when tested at the ear was 1.33 W/kg.¹ As mobile devices offer a range of functions, they can be used in other positions, such as on the body as described in this user guide.² In this case, the highest tested SAR value is 0.72 W/kg.¹

As SAR is measured utilizing the device's highest transmitting power, the actual SAR of this device while operating is typically below that indicated above. This is due to automatic changes to the power level of the device to ensure it only uses the minimum level required to reach the network. While there may be differences between the SAR levels of various phones and at various positions, they all meet the governmental requirements for safe exposure. Please note that improvements to this product model could cause differences in the SAR value for later products; in all cases, products are designed to be within the guidelines.

The World Health Organization has stated that present scientific information does not indicate the need for any special precautions for the use of mobile devices. They note that if you want to reduce your exposure

then you can do so by limiting the length of calls or using a “hands-free” device to keep the mobile phone away from the head and body.

Additional Information can be found on the websites of the World Health Organization (<http://www.who.int/emf>) or Motorola, Inc. (<http://www.motorola.com/rfhealth>).

- 1 The tests are carried out in accordance with international guidelines for testing. The limit incorporates a substantial margin for safety to give additional protection for the public and to account for any variations in measurements. Additional related information includes the Motorola testing protocol, assessment procedure, and measurement uncertainty range for this product.
- 2 Please see the Safety and General Information section about body worn operation.

Index

A

- accessories 17, 72
- accessory connector port 1
- active line indicator 37
- active line, changing 62
- alarm clock 75
- alert
 - set 46
 - turn off 50
- animation 77
- answer a call 22, 49
- attach a number 51, 61

B

- backlight 48
- battery 19
- battery indicator 37
- battery life, extending 20, 29, 48
- bluetooth
 - indicator 36
- Bluetooth connection 29, 31, 66, 76
- brightness 48
- browser messages 68
- browser. See micro-browser

C

- cables 28
- calculator 76
- call
 - answer 22, 49
 - end 21, 22
 - make 21, 63
- call barring 62
- call cost 72
- call divert indicator 37
- call diverting 61
- call timers 72
- call waiting 53
- caller ID 51, 53, 64
- camera 23
- car kit 72
- center key 1, 44
- certificate management 77
- clock 47
- codes 44, 45
- conference call 61
- copy files 30

D

- data call 74
- data indicator 36
- date, setting 47

datebook 75
dial a phone number 21, 62,
63
dialled calls 50
display 34, 48, 70
divert calls 61
download media objects
68, 78
DTMF tones 62

E

emergency number 54
end a call 21, 22
end key 1, 21, 22
Enter Unlock Code
message 45

F

fax call 74
fixed dial 62

G

games 78
GPRS indicator 36
group mailing list 65

H

handsfree speaker 44
headset 72
headset jack 1

hold a call 52
home screen 34, 70

I

in-call indicator 37
Incoming Call message 53
information services 68
international access code
54
iTAP text entry mode 41

J

Java applications 78

K

keypad 45, 69

L

language 69
linking. See Bluetooth
connection

lock

- application 76
- keypad 45
- phone 45
- SIM card 76

Low Battery message 37

M

make a call 21, 63

- master clear 71
- master reset 71
- menu 38, 69, 70
- menu icons 38, 70
- menu indicator 35
- menu key 1, 17
- message 67, 68
- message indicator 37
- message reminders 70
- micro-browser 68, 78
- Missed Calls message 52
- multimedia album 27
- multimedia message 67, 68
- music 77
- mute a call 52

N

- navigation key 1, 17, 44
- network settings 75
- news 35, 70
- notepad 52
- number. See phone number
- numeric entry mode 43

O

- object exchange 30
- 1-touch dial 54
- optional accessory 17
- optional feature 17

P

- pairing. See Bluetooth connection
- passwords. See codes
- personalise 69
- phone number 22, 62, 63
- phonebook 51, 54, 61, 63
- photo 23, 77
- picture 77
- picture album 27
- picture ID 53, 64
- PIN code 21, 76
- power key 1, 21
- PTT 56
 - calls, answering 57
 - calls, making 56
 - contacts and groups 57
 - icons 58
 - indicator 36
 - Quick Groups 56
 - settings 59
 - turning on or off 59
- Push-to-Talk. See PTT

R

- received calls 50
- recent calls 50
- redial 51
- reminders 70
- return a call 52
- ring style indicator 37

ring style, setting 46
ring tone 77, 78
ringer ID 53, 64, 69
ringer volume 69
roam indicator 36

S

screen saver 48
security code 44
send key 1, 21, 22
shortcuts 71
signal strength indicator 36
SIM 68
SIM Blocked message 21,
76
SIM card 18, 21, 76
soft keys 1, 35
speakerphone 72
speed dial 61
store your number 22
symbol entry mode 44
synchronizing 74

T

tap text entry mode 42
telephone number. See
phone number
text entry 40
text message 67, 68
time, setting 47
timers 72
transfer a call 61

turn on/off 21

U

unlock
application 76
keypad 45
phone 21, 45
SIM card 76
unlock code 44, 45
USB cables 28

V

video clip 77
videos 25
voice dial 64, 73
voice message 67
voice name, recording 63
voicemail 55
voicemail message indicator
55
volume 69

W

wallpaper 47
Web pages 78
Web sessions 78
wireless connection. See
Bluetooth connection

Y

your phone number 22

www.motorola.com.hk

MOTOROLA, the stylized M logo and all other trademarks indicated as such herein are trademarks of Motorola, Inc. ® Reg. U.S. Pat. & Tm. Off. All other product or services names are the property of their respective owners.

©2005 Motorola, Inc. All rights reserved.
Printed in PRC.

6887370Z26