


「



**GUARDALL LTD**

Systems Development Group  
PO Box 233, Chubb House  
Staines Road West  
Sunbury-on-Thames  
Middlesex TW16 7XY

**UNITED KINGDOM**



**WINDSOR 700  
SERVICE MANUAL**

**Version 8.4**

Manual No. 320534



# CONTENTS

<b>USING THIS MANUAL</b> .....	<b>4</b>
<b>USING THE KEYPAD</b> .....	<b>5</b>
<b>ABBREVIATIONS</b> .....	<b>7</b>
<b>MENU TREE : ENGINEERING</b> .....	<b>8</b>
<b>MENU TREE : CONFIGURATION</b> .....	<b>9</b>
<b>FUNCTIONS:</b>	
<b>CLOCK : SET</b> .....	<b>10</b>
<b>CONFIGURE : CONCENTRATOR</b> .....	<b>11</b>
<b>CONFIGURE : COPY CONFIGURATION</b> .....	<b>14</b>
<b>CONFIGURE : DORMITORY</b> .....	<b>16</b>
<b>CONFIGURE : EMERGENCY CONFIGURE</b> .....	<b>19</b>
<b>CONFIGURE : ENTRY/EXIT ROUTE</b> .....	<b>20</b>
<b>CONFIGURE : HOLIDAY</b> .....	<b>24</b>
<b>CONFIGURE : LOBBY ACCESS</b> .....	<b>26</b>
<b>CONFIGURE : OUTPUT DRIVERS</b> .....	<b>30</b>
<b>CONFIGURE : POINT INPUT</b> .....	<b>32</b>
<b>CONFIGURE : POINT OUTPUT</b> .....	<b>39</b>
<b>CONFIGURE : REMOTE COMMS (COMMUNICATIONS TYPE)</b> .....	<b>45</b>
<b>CONFIGURE : REMOTE COMMS (EVENT GROUPS)</b> .....	<b>48</b>
<b>CONFIGURE : REMOTE COMMS (SERIAL EQUIPMENT)</b> .....	<b>53</b>
<b>CONFIGURE : RESPONSES</b> .....	<b>56</b>
<b>CONFIGURE : SCHEDULE</b> .....	<b>57</b>
<b>CONFIGURE : START/END CONFIGURATION</b> .....	<b>60</b>
<b>CONFIGURE : UI</b> .....	<b>62</b>
<b>CONFIGURE : ZONE</b> .....	<b>67</b>
<b>DEFINE : ACPO MODE</b> .....	<b>74</b>
<b>DEFINE : ATM TIMES</b> .....	<b>75</b>
<b>DEFINE : AUTO. BATTERY TEST</b> .....	<b>76</b>
<b>DEFINE : AUTO. BELL MUTE</b> .....	<b>78</b>
<b>DEFINE : AUTO. DETECTOR TEST</b> .....	<b>79</b>
<b>DEFINE : AUTO. LOG-OFF</b> .....	<b>81</b>
<b>DEFINE : AUTOMATIC SHUNT</b> .....	<b>82</b>
<b>DEFINE : AUXILIARY POINT LOGGING</b> .....	<b>83</b>
<b>DEFINE : BANK/COMMERCIAL</b> .....	<b>84</b>
<b>DEFINE : BATTERY TEST ON SET</b> .....	<b>85</b>
<b>DEFINE : BELL TEST TIMEOUT</b> .....	<b>86</b>
<b>DEFINE : DURESS ALARM</b> .....	<b>87</b>
<b>DEFINE : GROUP SHUNT</b> .....	<b>88</b>
<b>DEFINE : HS SHUNT</b> .....	<b>91</b>
<b>DEFINE : INOVA MPC CARD IDs</b> .....	<b>94</b>

**FUNCTIONS (contd.):**

DEFINE : INVALID PIN RESPONSE .....	95
DEFINE : IP PORTS .....	96
DEFINE : LIMIT TIME ADJUST.....	97
DEFINE : LINE FAULT OVERRIDE .....	98
DEFINE : LOG-IN METHOD.....	99
DEFINE : MANAGED RESET .....	100
DEFINE : NEW PIN LOCKOUT.....	101
DEFINE : PIN COMMAND FACILITY .....	102
DEFINE : PIN EXPIRY .....	103
DEFINE : PREVENT AUTO SET ALARMS.....	104
DEFINE : RESET AUTHORITY .....	105
DEFINE : SCHEDULE ALARM .....	106
DEFINE : TAMPER RESET .....	107
DEFINE : UI LOCKOUT .....	108
DEFINE : VERIFY ALARM.....	109
DEFINE : WORK LATE TYPE.....	111
POINT INPUT : ISOLATE/DEISOLATE .....	112
RESET : NET RESTART .....	114
RESET : SERVICE.....	115
SERVICEMAN : COMMISSION REMOTE COMMS .....	116
SERVICEMAN : LOG-ON .....	119
SERVICEMAN : PANEL ACCESS.....	120
SERVICEMAN : REMOTE COMMS (ENCRYPTION).....	121
SERVICEMAN : REMOTE CONFIGURATION.....	122
SET : FORCE .....	123
SET : LINE FAULT OVERRIDE .....	124
STATUS : DIAGNOSTIC LOG.....	125
STATUS : ISOLATE LIST .....	126
STATUS : POINT INPUT (CALIBRATE).....	127
STATUS : PRINT CONFIGURATION .....	128
TEST : MONITOR .....	131
TEST : SOAK .....	133
TEST : UI .....	135

# USING THIS MANUAL

---

## TO LOCATE A SECTION

This manual is self-indexing. Each function is described in a section with a large-type title in the top corner in alphabetical order. A list of the functions is at the end of this section.

## THE FORMAT

Each section has an introduction describing important features. Note, however, that this is not an exhaustive description due to space limitations.

A flow-chart is given illustrating what appears on the keypad display and suggesting your response. If the display does not relate to this flow-chart it will probably be because of the system status or an invalid action. The displays that relate to this situation are at the end of each section under the title of 'NOTES'.

## PROGRAMMABLE NAMES/NUMBERS

The numbers and names of features such as zones, users, etc. are programmable and will depend on the installation. They are represented in this manual by the use of code letters. Capital letters represent numbers (i.e. a user number is UU representing a 2 digit number). Small letters represent names and indicate the maximum number of characters (i.e. a user name is uuuuuuuuuuu). A list of these abbreviations is at the end of this section.

## MENUS

Menus consist of a title followed by a numbered list. The composition of a menu will vary depending on the system configuration, system status and the user. The numbers of the items in a menu will vary. Hence in this manual the option numbers are not shown - only the menu title and the text of the option to select is illustrated. For example:

FUNCTION SELECT♦ .. . Set Options ..	<-- Select 'Set Options'
---	--------------------------

## VARIABLE TEXT

A text message on the keypad display may often have a number of alternatives. Where this is the case a line title is put in square brackets on the display symbol and the lines that will actually appear where appropriate are itemised below.

For example: There are 3 possible text messages in line 3 of the display below:

POINT STATUS .. [point status ] ..
---

[point status ]  
normal  
off-normal  
tamper

## DISPLAY

The keypad has a 4-line 16 character LCD display. When the keypad is not being used the display will present the appropriate prompt for the user to log-on (see **USER : LOG-ON** in the User Manual) or when the keypad is inside a set zone the display may be blank. The keys will then be unusable and if anyone tried to use the keys it would cause an alarm.

## KEYS

The keypad has 15 keys that are marked with symbols:

- 0-9      Numeric keys
- ▲ ▼      Keys used to scroll menus and lists
- ✓        'Yes' and 'Enter' key
- x        'No' key
- C        'Clear' key

## INDICATOR LIGHTS

The keypad has 8 lights to alert you to the following when they are lit. Note that, with the exception of the 'Power' light, the lights will be held off until you log-on.

POWER	Mains supply is healthy
BATTERY LOW	The battery back-up capacity is low
SHUNT ON	A detector has been shunted (manually or automatically)
INVESTIGATE	The system is in a condition where a full set is not possible
CALL ENGINEER	A serviceman is required to reset or rectify the system
LINE FAULT	The communication to and from the Central Monitoring Station is faulty
TAMPER	A detector, keypad or other component has been in tamper
ALARM	A detector or other component has been in alarm

## TONES

The keypad contains a sounder to emit tones. There are various tones which may emanate:

- a) A 'beep' when a key is pressed
- b) A continuous tone for entry/exit procedure
- c) An intermittent tone for prewarning
- d) A sequence of tones for schedule expiry

## TO SELECT FROM A MENU

The options in a menu take the form of a numbered list. To select an option it must be placed at the top line of the menu. Use the cursor keys ('▲' and '▼') to scroll the menu. The ability to scroll is shown by a blinking symbol ♦ to the right of the menu title. To emphasise which is the top line of the menu the number associated with the option is made to blink. When the required option in the top line the selection is completed by pressing the '✓' key.

---

For example: To select the 'Set Options' menu from the 'Function Select' menu

```
FUNCTION SELECT◆  
1 Reset or Mute  
2 Unset Options  
3 Set Options
```

Press '▼' twice and the display will scroll to show:

```
FUNCTION SELECT◆  
3 Set Options  
4 Test  
5 View Status
```

The 'Set Options' line is now the top line of the menu. Press '✓' and the 'Set Options' menu will be selected. An alternative to the use of the '▲' and '▼' keys is to press the number of the required menu item. This will put the item into the menu top line.

Note that the items shown in a menu are dependant on the status of the system and user. This means that the number of items in a menu is variable and the numbering of the items is variable.

If in this process a mistake is made then pressing the 'Clear' key ('C') will usually return you to the preceding menu.

### TO SELECT CHARACTERS

Text entry is required for descriptors (names). These may include letters or numbers. As the keypad has no letter keys available a special technique is used to enter descriptors.

For a new descriptor the display will show the following symbol:

```
◆
```

The flashing cursor ◆ shows the first character position. Press '✓' and a space will be selected as the first character and the cursor moves to the right. If a character other than a space is required then use the '▲' or '▼' keys to step through the character set until the one required appears.

The character set is as follows:

```
ABCDEFGHIJKLMNOPQRSTUVWXYZabcdefghijklmnopqrstuvwxyz_+ -=0123456789.
```

Press '✓' to select the character and the cursor moves to the right for the next selection. If a mistake is made in the selection then press 'C' to move the cursor back. The process is completed when 16 characters have been entered, or alternatively when all the required characters have been entered then pressing '0' on the keypad will store the descriptor and complete the descriptor entry.


In modifying an existing descriptor the process is similar. Each character will blink in turn to show that character may be changed.

# ABBREVIATIONS

---


CC	Concentrator address
cccccccccccccccccc	Concentrator descriptor
E	Entry/Exit route number
eeeeeeeeeeeeeeeeee	Entry/Exit route descriptor
G	Shunt group number
gggggggggggggggggg	Shunt Group descriptor
H	High Security Shunt group number
hhhhhhhhhhhhhhhhh	High Security Shunt group descriptor
III	Point Input number
iiiiiiiiiiiiiiiiiii	Point Input descriptor
K	Keypad number
kkkkkkkkkkkkkkkkk	Keypad descriptor
OOO	Point Output number
ooooooooooooooooooo	Point Output descriptor
R	Remote Site number
rrrrrrrrrrrrrrrrrr	Remote Site descriptor
SS	Schedule number
sssssssssssssssssss	Schedule descriptor
T	Timed function number
UU	User number
uuuuuuuuuuuuuuuuuu	User descriptor (usually the name)
ZZ	Zone number
zzzzzzzzzzzzzzzzzz	Zone descriptor
DD-mmm-YY	Date (day-in numerals, month-in letters, year-in numerals)
DD-MM	Date (day-month in numerals)
HH:MM	Time (hours:minutes in numerals)
HH:MM:SS	Time (hours:minutes:seconds in numerals)
N	Number displayed
X	Number to be entered
Conc	Concentrator
HS	High-Security
PreW	Pre-Warning
UI	User Interface (Keypad)

# MENU TREE : ENGINEERING





# MENU TREE : CONFIGURATION



# CLOCK : SET

---

This facility is used to set the date and time.

---

```
FUNCTION SELECT◆  
..  
. Time functions  
..
```

*<-- Select 'Time functions'*

```
TIME FUNCTIONS ◆  
..  
. Set clock  
..
```

*<-- Select 'Set clock'*

```
SET CLOCK  
Date  
dd-mm-yyyy
```

Specify date.  
*Enter 2 digits (day). Press '✓'*  
*Enter 2 digits (month). Press '✓'*  
*Enter 4 digits (year). Press '✓'*

```
SET CLOCK  
Time  
hh:mm
```

Specify time.  
*Enter 2 digits (hour). Press '✓'*  
*Enter 2 digits (minute). Press '✓'*

```
SET CLOCK  
[day          ]  
DD-MMM-YY HH:MM  
Press YES or NO
```

Display of date and time for confirmation.  
*Press '✓' to update the clock*  
*Press 'X' to abort*

Returns to 'TIMED FUNCTIONS' menu


```
[day          ]  
Monday  
Tuesday  
Wednesday  
Thursday  
Friday  
Saturday  
Sunday
```

# CONFIGURE : CONCENTRATOR


This facility is used to configure the concentrators which are connected to the Data Gathering Network (DGN).

<b>8 Way</b>	8 point inputs used on Concentrator which therefore uses 2 address 'slots'
<b>4 Way</b>	4 point inputs used on Concentrator which therefore uses 1 address 'slot'
<b>Monarch</b>	Guardall product - a wireless Concentrator
<b>Daughter board</b>	Increases configurable outputs from 1 to 3 on a 4-way Concentrator and from 1 to 8 on an 8-way Concentrator

For the configuration of the Concentrator wiring type (i.e. End-of-Line, etc) see **CONFIGURE : POINT INPUT**



## CONCENTRATOR (Add)



CONFIGURE : CONCENTRATOR (Add) continued overleaf

---

CONFIGURE : CONCENTRATOR (Add) continued

```
CONCENTRATOR C
[daughter board]
Change?YES or NO
```

**If 8 Way or 4 Way:**

Specify whether a daughter board is fitted.  
Press '✓' to change displayed status  
Press 'X' to retain displayed status

```
[daughter board ]
Extra O/P UNUSED
Extra O/P USED
```

Returns to 'CONCENTRATOR' menu

NOTES

'Add new ones' not in menu      The system already has a full complement of concentrators.

'invalid number'                The number selected is out-of-range.

'invalid address'                The address selected is already configured.

---

**CONCENTRATOR (Modify)**

```
CONCENTRATOR   ♦
..
. Modify
..
```

<-- Select 'Modify'

.....continue as for CONCENTRATOR (Add)

---

**CONCENTRATOR (Remove)**

```
CONCENTRATOR   ♦
..
. Remove
..
```

<-- Select 'Remove'

```
REMOVE CONC
Enter physical
address - xx
```

Specify concentrator address.  
Enter 2 digit number. Press '✓'

Returns to 'CONCENTRATOR' menu if successful

CONFIGURE : CONCENTRATOR continued overleaf

**CONCENTRATOR (View)**

```
CONCENTRATOR  ♦  
..  
. View  
..
```

*<-- Select 'View'*

```
CONCENTRATOR  
Enter physical  
address - xx
```

Specify concentrator address.  
Enter 2 digit number. Press '✓'

```
VIEW CONC CC  
[type          ]  
[daughter board]
```

Display of concentrator type.  
Display of output capability.  
Press '✓' to continue

```
[type          ]  
Type - 8 Way  
Type - 4 Way  
Type - Monarch
```

```
[daughter board ]  
Standard O/Ps  
Extra O/P fitted
```

Returns to 'CONCENTRATOR' menu

# CONFIGURE : COPY CONFIGURATION

The PROM Pack allows configurations to be transferred between the Windsor 700 and the Windsor 700 Configuration Editor PC software or between Windsor 700s.

Power should be removed before the PROM Pack is plugged into or removed from the Control Unit board.

Note that if a configuration is transferred from one Windsor 700 to another and remote communications is in use, all remote sites should be decommissioned on the new Windsor 700 before using the remote communications facility (See **SERVICEMAN : COMMISSION REMOTE COMMS.**).

## COPY CONFIG (From PROM PACK)

```
CONFIG MENU  ♦
.  ..
. Copy Config
.  ..
```

*<-- Select 'Copy Config'*

```
COPY CONFIG  ♦
.  ..
. From prom pack
.  ..
```

*<-- Select 'From prom pack'*

```
INSTALLATION
Pack: x
Vigil: x
YES to continue
```

**If the PROM Pack installation number is not the same as the Control Unit data:**

The installation data is displayed  
*Press '✓' to continue*  
*Press 'X' to abort*

```
COPY CONFIG
Pack Vn - x:x
Vigil Vn - x:x
YES to continue
```

**If the PROM Pack software version is not the same as the Control Unit:**

The software version numbers are displayed  
*Press '✓' to continue*  
*Press 'X' to abort*

```
COPY CONFIG
Keep old user
table
Press YES or NO
```

Specify whether the user data in the configuration on the Control Unit is to be retained or whether the user data in the PROM Pack is to be imposed.  
*Press '✓' to retain the users*  
*Press 'X' to impose PROM Pack user data*

Returns to 'CONFIG MENU'


## NOTES

```
COPY CONFIG
From pack FAILED
checksum error
```


The configuration data in the PROM Pack is corrupted and invalid. Transfer of this data is therefore prevented.

CONFIGURE : COPY CONFIGURATION continued overleaf

CONFIGURE : COPY CONFIGURATION continued



NOTES



# CONFIGURE : DORMITORY

This facility enables the configuration of the two dormitory areas. Dormitories are interrelated points intended to provide false alarm immunity from accidental activations. This works by allowing a limited amount of sensor activity in a set system without causing an alarm. This activity is allowed for, say, 8 seconds, and no alarm is given provided that the sensors return to normal within those 8 seconds and there is no further activity for, say, 20 minutes. To increase the security each dormitory is divided into 2 groups of detectors and once the 8 seconds (or another specified time) of tolerance has started in one of the groups, no activity is permitted in the other group without an alarm being generated.

- Set D1**            The first group of points sharing the dormitory function
- Set D2**            The second group of points sharing the dormitory function
- First delay**        The period, starting with the activation of a point in the dormitory, during which that point may remain off-normal without causing an alarm. Other points in the same set may also go off-normal but points in the other set must remain normal to avoid causing an alarm.
- Second delay**      The period, starting after the first delay, during which all points in the dormitory must remain normal to avoid causing an alarm.

```

CONFIG MENU  ♦
..
. Dormitory
..
    
```

*<-- Select 'Dormitory'*

## DORMITORY (Add)

```

DORMITORY  ♦
..
. Add
..
    
```

*<-- Select 'Add'*

```

DORMITORY
Enter dormitory
number:- x
    
```

Specify set number.  
Enter 1 digit number. Press '✓'

```

DORMITORY D
Number of points
in set D1:- xxx
    
```

Specify number of point inputs in set.  
Enter 3 digit number. Press '✓'

```

DORMITORY D
Enter point for
set D1:- xxx
    
```

Specify point input number.  
Enter 3 digit number. Press '✓'  
  
Repeat for number of points.

```

DORMITORY D
Number of points
in set D2:- xxx
    
```

Specify number of point inputs in set.  
Enter 3 digit number. Press '✓'

CONFIGURE : DORMITORY (Add) continued overleaf



---

CONFIGURE : DORMITORY (Add) continued

DORMITORY D  
Enter point for  
set D2:- xxx

Specify point input number.  
*Enter 3 digit number. Press '✓'*

Repeat for number of points.

DORMITORY D  
First Delay t1  
= xx seconds

Specify first delay time (0 to 60secs).  
*Enter 2 digit number (00 to 60). Press '✓'*

DORMITORY D  
Second Delay t2  
= xx minutes

Specify second delay time (0 to 60mins).  
*Enter 2 digit number (00 to 60). Press '✓'*

Returns to 'DORMITORY' menu

NOTES

'invalid number'

The number selected is out-of-range or the number is a value already selected.

'Used by D1-retry'

The point is already in set D1 and may not be in D2.

---

**DORMITORY (Remove)**

DORMITORY     ♦  
..  
. Remove  
..

<-- Select 'Remove'

DORMITORY  
Enter dormitory  
number:- xx

Specify set number.  
*Enter 2 digit number. Press '✓'*

Returns to 'CONFIG MENU' if successful

---

**DORMITORY (View)**

DORMITORY     ♦  
..  
. View  
..

<-- Select 'View'


DORMITORY  
Enter dormitory  
number:- xx

Specify set number.  
*Enter 2 digit number. Press '✓'*

CONFIGURE : DORMITORY (View) continued overleaf

---

CONFIGURE : DORMITORY (View) continued



# CONFIGURE : EMERGENCY CONFIGURE

---

This facility is not available with Version 8.4

---

```
CONFIG MENU  ♦  
. . .  
. Emerg Reconfig  
. . .
```

*<-- Select 'Emerg Reconfig'*

```
OPTION  
NOT AVAILABLE  
Press CLEAR
```


Warning that the emergency configuration  
facility is not available.  
*Press 'C' to continue*

Returns to 'CONFIG MENU'


# CONFIGURE : ENTRY/EXIT ROUTE

This facility is used to configure Entry/Exit routes. Where there are no external means of unsetting a system it is necessary to establish an Entry route to allow the user to traverse a defined route within the premises, without causing an alarm, in order to reach a keypad and unset the system. Similarly an Exit route may be necessary to allow the user to leave the premises after setting the system. The Entry and Exit routes may be the same, or different.

<b>Entry point</b>	A point which when tripped will start the entry procedure.
<b>Exit point</b>	A point which completes the exit procedure.
<b>Route point</b>	A point which may be activated legitimately during the entry/exit procedure.
<b>Buffer point</b>	A point which generates a prewarning if activated during the entry/exit procedure, by the user mistakenly deviating from the entry/exit route. This prewarning is canceled by returning the point to normal and logging-on at a keypad.
<b>Exit Delay Time</b>	Specifies the time within which the exit procedure must be completed.
<b>Entry Delay Time</b>	Specifies the time within which the entry procedure must be completed.
<b>Timed setting</b>	Specifies whether the system is to be set following expiry of the exit time. An exit point is not required in systems with timed setting.
<b>Verifiable</b>	Specifies whether Entry Timeout is to be a verifiable alarm (see VERIFY ALARM)



## ENTRY/EXIT ROUTE (Add)



CONFIGURE : ENTRY/EXIT ROUTE (Add) continued overleaf

CONFIGURE : ENTRY/EXIT ROUTE (Add) continued

```
ADD E/E ROUTE E
Enter Point
Number:- xxx
```

Specify point on E/E route.  
Enter 3 digit number. Press '✓'

```
ADD E/E ROUTE E
On Entry is PT ♦
[point menu  ]
[point menu  ]
```

Specify point input type for entry  
Use '▲' or '▼' to scroll required type  
to line 3. Press '✓'

```
[point menu  ]
. Not used
. Route pt
. Entry point
. Buffer pt
```

```
ADD E/E ROUTE E
On Exit is PT ♦
[point menu  ]
[point menu  ]
```

Specify point input type for exit  
Use '▲' or '▼' to scroll required type  
to line 3. Press '✓'

```
[point menu  ]
. Not used
. Route pt
. Exit point
. Buffer pt
```

```
ADD E/E ROUTE E♦
..
. Route complete
..
```

<-- Select 'Route complete'

```
ADD E/E ROUTE E
Exit delay time
xxxx - seconds
```

Specify exit time.  
Enter 4 digit number (0000 to 3000). Press '✓'

```
ADD E/E ROUTE E
Entry delay time
xxxx - seconds
```

Specify entry time.  
Enter 4 digit number (0000 to 3000). Press '✓'

```
ADD E/E ROUTE E
[timed set fct ]
route expiry
Change?YES or NO
```

Specify if timed setting is required.  
Press '✓' to change displayed status  
Press 'X' to retain displayed status

```
[timed set fct ]
Timed Set on
NOT Timed Set on
```

CONFIGURE : ENTRY/EXIT ROUTE (Add) continued overleaf

CONFIGURE : ENTRY/EXIT ROUTE (Add) continued

```

ADD E/E ROUTE E
Entry timeout
[verify status ]
Change?YES or NO
    
```

Specify if entry timeout in alarm verify is required.  
*Press '✓' to change displayed status*  
*Press 'X' to retain displayed status*

```

[status
verifiable
NOT verifiable
    
```

Returns to 'E/E ROUTE' menu

NOTES

- 'invalid number'            The number selected is out-of-range.
- 'invalid point'            The number selected is not configured or it is already assigned.

**ENTRY/EXIT ROUTE (Modify)**

```

E/E ROUTE     ♦
..
. Modify
..
    
```

<-- Select 'Modify'

.....continues as for ENTRY/EXIT ROUTE (Add)

**ENTRY/EXIT ROUTE (Remove)**

```

E/E ROUTE     ♦
..
. Remove
..
    
```

<-- Select 'Remove'

```

REMOVE E/E ROUTE
Enter route
number:- x
    
```

Specify E/E route number.  
*Enter 1 digit number. Press '✓'*

```

REMOVE E/E ROUTE
Remove route E?
eeeeeeeeeeeeeeeeee
Press YES or NO
    
```

Display of E/E Route descriptor for confirmation.  
*Press '✓' to remove*  
*Press 'X' to abort*  
Returns to 'E/E ROUTE' menu

**ENTRY/EXIT ROUTE (View)**

```

E/E ROUTE     ♦
..
. View
..
    
```

<-- Select 'View'

CONFIGURE : ENTRY/EXIT ROUTE (View) continued overleaf

CONFIGURE : ENTRY/EXIT ROUTE (View) continued

```
VIEW E/E ROUTE
Enter route
number:- x
```

Specify E/E route number.  
Enter 1 digit number. Press '✓'

```
E/E E - PT.III ♦
iiiiiiiiiiiiiiiiii
[point use      ]
[point use      ]
```

Display of point input(s) on route.  
Display of point function.  
Use '▲' or '▼' to scroll point details  
Press '✓' to continue

```
[point use      ]
Entry pt
Exit pt
Entry route pt
Exit route pt
Entry Not used
Exit Not used
```

```
VIEW E/E ROUTE E
Entry delay-xxxx
Exit delay-xxxx
seconds
```

Display of entry time period.  
Display of exit time period.  
Press '✓' to continue

```
VIEW E/E ROUTE E
[set fct        ]
route expiry
[verify status  ]
```

Display of set function on route expiry.  
Press '✓' to continue


```
[set fct        ]
Timed Set on
NOT Timed Set on
```

Returns to 'E/E ROUTE' menu


```
[verify status  ]
verifiable
NOT verifiable
```

# CONFIGURE : HOLIDAY

This facility enables the programming of specified days as 'holidays' which override the schedule for those days. The 'holidays' act as a schedule closed window and, as such, inhibit the zone(s) associated with the schedule from being unset.



## HOLIDAY (Add)



CONFIGURE : HOLIDAY (Add) continued overleaf



CONFIGURE : HOLIDAY (Add) continued

```
HOLIDAY APPLIES
to zone ZZ
zzzzzzzzzzzzzzzzzz
Press YES or NO
```

Specify zone(s) to which holiday is to apply.  
Press '✓' if displayed zone required  
Press 'X' if displayed zone not required

Returns to FUNCTION SELECT menu if successful

NOTES

'invalid date'

The date entered is out-of-range or is already allocated as a holiday.

HOLIDAY (Remove)

```
HOLIDAYS
..
. Remove
..
```

<-- Select 'Remove'

```
REMOVE HOLIDAY
start DD-mmm-YY
end DD-mmm-YY
Press YES or NO
```

Confirm removal of holiday  
Press '✓' to remove holiday  
Press 'X' to view next holiday  
Press 'C' to quit without removing any holiday  
Returns to FUNCTION SELECT menu if successful

HOLIDAY (View)

```
HOLIDAYS
..
. View
..
```

<-- Select 'View'

```
VIEW HOLIDAY
starts DD-mmm-YY
ends DD-mmm-YY
```

Specify holiday.  
Use '▲' or '▼' to scroll required holiday to lines 2 and 3. Press '✓'

```
HOLIDAY APPLIES
to zone ZZ
zzzzzzzzzzzzzzzzzz
```

Display of zone list  
Use '▲' or '▼' to scroll zone list  
Press '✓' to continue

Returns to menu

# CONFIGURE : LOBBY ACCESS

---

This facility is used to configure card access through a door. Typically this is for allowing access to the ATM lobby of a bank.

The length of data read from a card is configurable. This allows a family of cards, which share a common data prefix, to operate the access. The data prefix length may be between 1 and 19 digits. (The maximum of 19 digits will normally mean individual cards may be identified if required). The prefix may contain "wildcard" digits which match any digit. Each card prefix is configured to be associated with specific readers.

The card access is enabled for a configured period. The open period is applicable to all the readers in the system. It will be repeated for each day of the week and will be unaffected by holidays.

**Open time**        The start of the period during which a valid card read will be acted upon.


**Close time**      The end of the period during which a valid card read will be acted upon.

When a card is swiped the following sequence of checks occurs. If any check fails the operation is aborted:

- The card prefix is checked.
- The card expiry date is checked.
- The lobby access period is checked for open period.


If the above checks are passed then the associated point output is activated. This is usually used to activate a 'door strike' which will allow the lobby door to open. To configure this point output see **CONFIGURE : UI**.

---



---

## TIMES



CONFIGURE : LOBBY ACCESS continued overleaf

CONFIGURE : LOBBY ACCESS continued

LOBBY TIMES  
Close time hh:mm

Specify lobby open time end \*  
Enter 2 digit number for hour. Press '✓'  
Enter 2 digit number for minute. Press '✓'

Returns to LOBBY ACCESS menu if successful

- \* If open time and close time are the same the lobby access will be untimed (ie 24 hours a day). If the close time is earlier than the open time the access will close the day after the open time.

CARDS (Add)

LOBBY ACCESS ♦  
..  
. Cards  
..

<-- Select 'Cards'

LOBBY CARDS ♦  
..  
. Add  
..

<-- Select 'Add'

ADD LOBBY CARD  
Card number:- xx

Specify card number (This may apply to a family of cards sharing the same data prefix).  
Enter 2 digit number (01 to 20). Press '✓'

ADD LOBBY CARD  
Prefix length  
xx digits

Specify length of card prefix (1 to 19 digits).  
Enter 2 digit number (01 to 19). Press '✓'

ADD LOBBY CARD  
Digits 1-NN  
of card prefix

Specify digits.  
Select digit numbers (0 to 9) for prefix.  
Use '▲' or '▼' for a wildcard, this is displayed as '.'

ADD LOBBY CARD  
Digits 17-NN  
of card prefix


**If number of digits is 17 or more:**  
Specify digits.  
Select digit numbers (0 to 9) for prefix.  
Use '▲' or '▼' for a wildcard, this is displayed as '.'

ADD LOBBY CARD  
Cannot be used  
at UI N  
Change?YES or NO


Specify keypad(s) which are to recognize the card  
Press 'X' to retain displayed status  
Press '✓' to change displayed status  
Repeat for all UI numbers  
Returns to 'LOBBY CARDS' menu

CONFIGURE : LOBBY ACCESS continued overleaf


**CARDS (Modify)**



**CARDS (Remove)**



**CARDS (View)**



CONFIGURE : LOBBY ACCESS continued

VIEW LOBBY CARD  
Digits 1-NN  
of card prefix  
NNNNNNNNNNNNNNNNNNNN

Digits in prefix.  
Press '✓' to continue

LOBBY CARD NN  
Digits 17-NN  
of card prefix  
NNN

**If number of digits is 17 or more:**  
Digits in prefix.  
Press '✓' to continue

VIEW LOBBY CARD  
[UI status     ]  
at UI N

Keypad(s) which are to recognize the card  
Press '✓' to continue

[UI status     ]  
Can be used  
Cannot be used

Returns to 'LOBBY CARDS' menu

# CONFIGURE : OUTPUT DRIVERS

---

Configure sounders and strobes.

The **Mk1A hardware** has the following configurable drivers:

Prewarning driver	prewarning
Closed-circuit driver	prewarning, sounder or strobe
Open-circuit driver 1	prewarning, sounder or strobe
Open-circuit driver 2	prewarning, sounder or strobe

The **Windsor 700 hardware** has the following configurable drivers:

Warn. 1	prewarning, sounder or strobe
Warn. 2	prewarning, sounder or strobe

```

CONFIG MENU  ♦
..
. System
..
    
```

*<-- Select 'System'*

```

MODIFY SYSTEM  ♦
..
. Mod O/P drives
..
    
```

*<-- Select 'Mod O/P drives'*

```

MOD O/P DRIVERS
Prewarn sounder
[connect state ]
Change?YES or NO
    
```

**Applies to Mk1A hardware only:**

Specify if pre-warning used.  
 Press '✓' to change displayed status  
 Press 'X' to retain displayed status  
 This menu is present on the Windsor 700 but has no effect.

```

[connect state ]
connected
not connected
    
```

```

OPEN CIRCUIT 1  ♦
[menu           ]
[menu           ]
[menu           ]
    
```

Specify use for Open Circuit 1/Warn 1  
 Note: Top line of menu shows current status  
 Use '▲' or '▼' to scroll required use to line 2. Press '✓'

```

[menu           ]
. Not connected
. Prewarning
. Sounder
. Strobe
    
```

CONFIGURE : OUTPUT DRIVERS continued overleaf

---

CONFIGURE : OUTPUT DRIVERS continued

OPEN CIRCUIT 2 ♦  
[menu ]  
[menu ]  
[menu ]

Specify use for Open Circuit 2/Warn 2  
Note: Top line of menu shows current status  
Use '▲' or '▼' to scroll required use  
to line 2. Press '✓'

[menu ]  
. Not connected  
. Prewarning  
. Sounder  
. Strobe

CLOSED CIRCUIT ♦  
[menu ]  
[menu ]  
[menu ]

**Applies to Mk1A hardware only:**  
Specify use for Closed Circuit  
Note: Top line of menu shows current status  
Use '▲' or '▼' to scroll required use  
to line 2. Press '✓'  
This menu is present on the Windsor 700 but has  
no effect

[menu ]  
. Not connected  
. Prewarning  
. Sounder  
. Strobe

Returns to 'MODIFY SYSTEM' menu

# CONFIGURE : POINT INPUT

Configure point input.

<b>Point type</b>	The point response depends on the type (see Surveyors Guide).
<b>Shunable</b>	The point may be shunted (alarm response inhibited, tamper response monitored).
<b>Isolatable</b>	The point may be isolated (alarm and tamper responses inhibited).
<b>Exemptable</b>	The point may be exempted (if off-normal the zone containing it may still be set. Subsequently the point will become part of the alarm system from the time it goes normal)
<b>Displayable</b>	The point may be displayed.
<b>Verifiable</b>	The point is in a verified alarm function (see CONFIGURE - VERIFY ALARM)
<b>Wiring type</b>	Depends on the Concentrator to which the point connects.
<b>Thresholds</b>	The boundaries for determining the pulse width signal on the DGN corresponding with the point condition (see Hardware Guide).
<b>Auto-shunt</b>	When a point goes into alarm the Auto Shunt timer for that point is started. When the timer expires then that point is shunted if it is still in alarm (subject to the shunt limit in the zone). This facility is used in conjunction with Auto Rearm. Note that Auto-shunt is not a recommended practice in some countries.
<b>Delayed Alarm</b>	Alarms can be delayed to enhance false alarm immunity. The operating mode of the delayed alarm depends on the configured value of delay period t2. If delay t2 is zero: The point must be constantly off-normal for the period t1 in order to cause an alarm. If delay t2 is non-zero      The point going off-normal starts period t1. During period t1 alarms are not generated by this point remaining off-normal or by this point returning to normal and going off-normal again. At the end of period t1 the period t2 starts. If the point is still off-normal or goes off-normal during period t2 then an alarm is caused. At the end of t2 the sequence may re-start with t1 being triggered again.

```

CONFIG MENU  ◆
..
. Point I/P
..
    
```

<-- Select 'Point I/P'

## POINT INPUT (Add)

```

POINT I/P  ◆
..
. Add
..
    
```

<-- Select 'Add'

```

ADD PT I/P
Enter point
number - xxx
    
```

Specify point number.  
 Enter 3 digit number. Press '✓'

```

ADD PT I/P III
Enter descriptor
◆
0=complete
    
```

Specify point descriptor.  
 Select characters (see **USING THE KEYPAD**)

CONFIGURE : POINT INPUT (Add) continued overleaf



CONFIGURE : POINT INPUT (Add) continued

```
ADD PT I/P III
Select type
[point type  ]
YES to accept
```

Specify point type.  
Use '▲' or '▼' to scroll required point type  
to line 3. Press '✓'

```
[point type  ]
Night Alarm - 1
Night Alarm - 2
Night Alarm - 3
24 Hour
PA
PA (day)
PA (silent)
PA (day,silent)
Battery Monitor
Signalling
Control point
24 Hour Warning
24 Hour Alarm
```

```
ADD PT I/P III
Ctl Pt action
[function  ]
YES to accept
```

**If Control Point:**  
Specify function of Control Point.  
Use '▲' or '▼' to scroll required function  
to line 3. Press '✓'

```
[function  ]
Clear Alarms
Partial Set
Partial Unset
```

```
ADD PT I/P III
[shunt state  ]
Change?YES or NO
```

**If not a PA point:**  
Specify if point is to be shunable.  
Press '✓' to change displayed status  
Press 'X' to retain displayed status

```
[shunt state  ]
shunable
not shunable
```

```
ADD PT I/P III
[isolate state  ]
Change?YES or NO
```

Specify if point is to be isolatable.  
Press '✓' to change displayed status  
Press 'X' to retain displayed status

```
[isolate state  ]
isolatable
not isolatable
```

```
ADD PT I/P III
[exempt state  ]
Change?YES or NO
```

Specify if point is to be exemptable.  
Press '✓' to change displayed status  
Press 'X' to retain displayed status

```
[exempt state  ]
exemptable
not exemptable
```

CONFIGURE : POINT INPUT (Add) continued overleaf

CONFIGURE : POINT INPUT (Add) continued

```

ADD PT I/P III
[display state ]
Change?YES or NO
    
```

Specify if point is to be displayable.  
 Press '✓' to change displayed status  
 Press 'X' to retain displayed status

```

[display state ]
displayable
not displayable
    
```

```

ADD PT I/P III
[verify state ]
Change?YES or NO
    
```

**For NA and 24HR points only:**  
 Specify if point is to be verifiable.  
 Press '✓' to change displayed status  
 Press 'X' to retain displayed status

```

[verify state ]
verifiable
not verifiable
    
```

```

ADD PT III as ♦
[attribute menu]
[attribute menu]
[attribute menu]
    
```

Specify attribute of point input.  
 Use '▲' or '▼' to scroll required attribute  
 to line 2. Press '✓'

```

[attribute menu ]
. normal point
. buffer point
. double buffer
. safe shunt sla{ve}
. safe shunt mas{ter}
. Break Glass Pt
    
```

```

ADD PT III
Enter number of
control points x
    
```

**If double buffer or safe shunt slave:**  
 Specify number of control (linked) points.  
 Enter 1 digit number. Press '✓'

```

ADD PT III
Enter control
point number xxx
    
```

Specify control point number(s).  
 Enter 3 digit number. Press '✓'

Repeat for the all control points

```

ADD PT I/P III
[status      ]
Detector test
Change?YES or NO
    
```

Specify if point is to be in detector test.  
 (This implies the point input is testable  
 via a point output i.e vibration detector)  
 Press '✓' to change specified status  
 Press 'X' to retain specified status

```

[status      ]
in
not in
    
```


```

ADD PT III
Det Test driving
point o/p :-xxx
    
```

**If point in detector test:**  
 Specify point output providing stimulus.  
 Enter 3 digit number. Press '✓'


CONFIGURE : POINT INPUT (Add) continued overleaf

CONFIGURE : POINT INPUT (Add) continued



CONFIGURE : POINT INPUT continued overleaf


CONFIGURE : POINT INPUT continued



NOTES

'Add point' not in menu	The max. number of points already configured.
'invalid number'	Number is out-of-range, or the number has already been allocated.
'not avail retry'	The number is allocated to a double buffer point or a safe shunt slave.

**POINT INPUT (Modify)**



.....continue as for POINT INPUT (Add)

CONFIGURE : POINT INPUT continued overleaf

**POINT INPUT (Remove)**

```
POINT I/P      ◆
..
. Remove
..
```

<-- Select 'Remove'

```
REMOVE PT I/P
Enter point
number - xxx
```

Specify point input number.  
Enter 3 digit number. Press '✓'

Returns to CONFIG MENU if successful

**POINT INPUT (View)**

```
POINT I/P      ◆
..
. View
..
```

<-- Select 'View'

```
VIEW PT I/P
Enter point
number - xxx
```

Specify point input number.  
Enter 3 digit number. Press '✓'

```
VIEW PT I/P III
iiiiiiiiiiiiiiii
[point type  ]
address cc-pp
```

Display of point descriptor.  
Display of point type.  
Display of point address.  
Press '✓' to continue

[point type ]  
see POINT INPUT (Add)

```
VIEW PT I/P III
Control point
[function  ]
```

**For Control Point:**  
Display of Control Point function  
Press '✓' to continue

[function ]  
see POINT INPUT (Add)

```
VIEW PT I/P III
[shunt state ]
[isolate state ]
[display state ]
```

Display of shuntable state.  
Display of isolatable state.  
Display of displayable state.  
Press '✓' to continue

[shunt state ]	[isolate state ]	[display state ]
is shuntable	is isolatable	is displayable
NOT shuntable	NOT isolatable	NOT displayable

CONFIGURE : POINT INPUT (View) continued

VIEW PT I/P III [exempt state ] [verify state ] [attribute ]	Display of exemptable state. Display of point attribute. Display of verifiable condition. <i>Press '✓' to continue</i>
[exempt state ] exemptable NOT exemptable	[verify state ]                      [attribute ] verifiable                              see <b>POINT INPUT (Add)</b> NOT verifiable

VIEW PT I/P III Controlled by III iiiiiiiiiiiiii	<b>For double buffer and Safe Shunt Slave:</b> Display of controlling point inputs <i>Use '▲' or '▼' to scroll</i> <i>Press '✓' to continue</i>
--	--

VIEW PT I/P III Wiring type [wiring type ]	Display of concentrator type. <i>Press '✓' to continue</i>
--	---

[wiring type ]  
see **POINT INPUT (Add)**

VIEW PT I/P III Threshold 1 nn% Threshold 2 nn% Threshold 3 nn%	Display of thresholds. <i>Press '✓' to continue</i>
--	--

VIEW PT I/P III Auto shunt delay in seconds: nnn	Display of Automatic Shunt delay. <i>Press '✓' to continue</i>
--	---

VIEW PT I/P III Alarm delay [delay type ]	Display of alarm delay type. <i>Press '✓' to continue</i>
---	--

[delay type ]  
see **POINT INPUT (Add)**

VIEW PT I/P III Delay t1: xxx in [t1 units]	<b>If alarm delay:</b> Display of alarm delay period t1. <i>Press '✓' to continue</i>
---	---

[t1 units ]  
seconds  
minutes

VIEW PT I/P III Delay t2: xxx in [t2 units]	Display of alarm delay period t2. <i>Press '✓' to continue</i>
---	---

[t2 units ]  
seconds  
minutes

Returns to 'CONFIG PT I/P' menu


# CONFIGURE : POINT OUTPUT

Point Outputs are the output connections on a concentrator (and daughter board if fitted) by which external devices (i.e. indicators) are driven by the system.


Point Outputs are assigned an address which incorporates the concentrator address and the address of the point on that concentrator. The first two Point Output addresses on a concentrator are used to provide Walk Test indications and therefore the first configurable point address is 03.

Point Outputs may be programmed to react to the state of Point Inputs, zones, and/or the system.

<b>Monitor</b>	The point output follows the normal, off-normal state of the event
<b>Latched</b>	The point output latches into an off-normal state following the trigger of the event
<b>Momentary</b>	The point output goes momentarily off-normal following the trigger of the event
<b>Point Input Driven</b>	Up to 8 point inputs may control the point output. Multiple inputs are ORed to provide the point input control signal, and this is ANDed with the zone state and system state if these are selected.
<b>Zone state gated</b>	Up to 4 states of the zone may control the point output. Multiple zone conditions are ORed to provide the zone condition control signal, and this is ANDed with the point input control signal, if any.
<b>System state gated</b>	The system condition, if any, is ANDed with the zone and point input conditions



## POINT OUTPUT (Add)



CONFIGURE : POINT OUTPUT (Add) continued overleaf

CONFIGURE : POINT OUTPUT (Add) continued

```

ADD PT O/P 000
Enter descriptor
♦
0=complete
    
```

Specify descriptor.  
Select characters (see **USING THE KEYPAD**)

```

ADD PT O/P 000
The point state
is normally [st]
Change?YES or NO
    
```

Specify normal state of point output.  
Press '✓' to change specified state  
Press 'X' to retain state

```

[st]
ON
OFF
    
```

```

ADD PT O/P 000
[point menu  ]
[point menu  ]
[point menu  ]
    
```

Specify type of point output.  
Use '▲' or '▼' to scroll required type  
to line 2. Press '✓'

```

[point menu  ]
. Momentary
. Monitor
. Latched
    
```

**If momentary:**

```

ADD PT O/P 000
Pulse delay
h:mm:ss->x:xx:xx
    
```

Specify delay before active.  
Enter 1 digit number (hours). Press '✓'  
Enter 2 digit number (minutes). Press '✓'  
Enter 2 digit number (seconds). Press '✓'

```

ADD PT O/P 000
Pulse duration
h:mm:ss-0:00:00
    
```

Specify active duration.  
Enter 1 digit number (hours). Press '✓'  
Enter 2 digit number (minutes). Press '✓'  
Enter 2 digit number (seconds). Press '✓'

```

ADD PT O/P 000
[link line 1  ]
[link line 2  ]
Change?YES or NO
    
```

Specify if point output is controlled  
by point input status.  
Press '✓' to change the specified mode  
Press 'X' to retain the specified mode

```

[link line 1  ]
Point is
Point IS NOT
    
```


```

[link line 2  ]
POINT I/P DRIVEN
POINT I/P DRIVEN
    
```

CONFIGURE : POINT OUTPUT (Add) continued overleaf



CONFIGURE : POINT OUTPUT (Add) continued



CONFIGURE : POINT OUTPUT (Add) continued overleaf

CONFIGURE : POINT OUTPUT (Add) continued

```

ADD PT O/P 000
[zone stat] ZZ
zzzzzzzzzzzzzzzzzzzz
Change?YES or NO
    
```

Specify zone(s) whose condition affects the point output  
 Press '✓' to change the displayed status  
 Press 'X' to retain the displayed status

```

[zone stat]
in zone
NOT in zone
    
```

```

ADD PT O/P 000
[system link  ]
gated
Change?YES or NO
    
```

Specify whether system state affects the point output.  
 Press '✓' to change the displayed status  
 Press 'X' to change the displayed status

```

[system link  ]
system state
not system state
    
```

```

ADD PT O/P 000
[system state  ]
[link          ]
Change?YES or NO
    
```

**If system state linked:**  
 Specify the system state(s) to control the point output function.  
 Press '✓' to change the displayed status  
 Press 'X' to retain the displayed status

```

[system state  ]
line fault
mains fail
Detr test fail
    
```

```

[link          ]
linked
NOT linked
    
```

Returns to 'POINT O/P' menu

**POINT OUTPUT (Modify)**

```

POINT O/P      ♦
..
. Modify
..
    
```

<-- Select 'Modify'

```

MOD PT O/P
Enter point
number - xxx
    
```

Specify point output number.  
 Enter 3 digit number. Press '✓'

.....continue as for POINT OUTPUT (Add)

CONFIGURE : POINT OUTPUT continued overleaf

**POINT OUTPUT (Remove)**

```
POINT O/P      ◆
..
. Remove
..
```

<-- Select 'Remove'

```
REMOVE PT OP 000
oooooooooooooooo
Press YES or NO
```

Specify point output(s) to be removed.  
Press '✓' to remove point  
Press 'X' to retain point

**POINT OUTPUT (View)**

```
POINT O/P      ◆
..
. View
..
```

<-- Select 'View'

```
VIEW PT O/P
Enter point
number - xxx
```

Specify point output number.  
Enter 3 digit number. Press '✓'

```
VIEW PT O/P 000
oooooooooooooooo
Address cc-pp
[normal state ]
```

Display of descriptor.  
Display of address.  
Display of normal state.  
Press '✓' to continue

```
[normal state ]
Normally OFF
Normally ON
```

```
VIEW PT O/P 000
[type          ]
```

Display of point output type.  
Press '✓' to continue

```
[type          ]
Monitor type
Momentary type
Latched type
```

```
VIEW PT O/P 000
Pulse delay
h:mm:ss
n:nn:nn
```

**For momentary point:**  
Display of delay before active.  
Press '✓' to continue

CONFIGURE : POINT OUTPUT (View) continued

VIEW PT O/P 000  
Pulse duration  
h:mm:ss  
n:nn:nn

Display of time active.  
Press '✓' to continue

VIEW PT O/P 000  
Point controlled

**If point input controlled:**  
Display of point input controlled status.  
Press '✓' to continue

VIEW PT O/P 000  
Linked to Point  
Input III ♦  
iiiiiiiiiiiiiiiiiii

Display of controlling points  
Use '▲' or '▼' to scroll points list  
Press '✓' to continue

VIEW PT O/P 000  
Zone state  
controlled

**If zone state controlled:**  
Display of zone state control status  
Press '✓' to continue

VIEW PT O/P 000  
Linked to zone  
state  
[function link ]

Display of zone states linked.  
Use '▲' or '▼' to scroll zone states  
Press '✓' to continue

[function link ]  
see POINT OUTPUT (Add)

VIEW PT O/P 000  
Depends on state  
of zone ZZ ♦  
zzzzzzzzzzzzzzzzzz

Display of zones.  
Use '▲' or '▼' to scroll zone list  
Press '✓' to continue

VIEW PT O/P 000  
System state  
controlled

**If system state controlled:**  
Display of system state link status  
Press '✓' to continue

VIEW PT O/P 000  
Linked to system  
state ♦  
[system state ]

Display of system states linked.  
Use '▲' or '▼' to scroll system states  
Press '✓' to continue

[system state ]  
see POINT OUTPUT (Add)

Returns to 'POINT O/P' menu

# CONFIGURE : REMOTE COMMS (COMMUNICATIONS TYPE)


Alarms may be reported to the central station by three means: (i) a parallel communicator such as a Redcare STU or digidialer; (ii) a ChubbCOM emulating an Ademco dialler; (iii) a serial communicator such as ChubbCOM, a modem, or a PAD.

**Primary / Secondary**      The definition depends on the mode:


**Parallel Port Communicators** : Applies to the Control Unit. Thus one communicator is designated the primary communicator and transmits the event messages unless a fault arises. Then the events are transmitted by the secondary communicator.

**Serial Port Communicators** : Applies to the Remote Site. Thus one remote site is designated the primary site and one is designated the secondary site. (Note that this may simply refer to different hardware in the same place or be geographically separate.)

**ADEMCO Emulation**      The ChubbCOM communicator may be used as a dialler performing the same functions as an ADEMCO dialler.



## COMMUNICATIONS TYPE (Add)



CONFIGURE : COMMUNICATIONS TYPE (Add) continued overleaf

CONFIGURE : COMMUNICATIONS TYPE (Add) continued

<pre>[comm type ]◆ [report type ] [report type ] [report type ]</pre>	<pre>Specify type of reporting. Use '▲' or '▼' to scroll required type to line 2. Press '✓'</pre>
<pre>[comm type ] PRIMARY SECONDARY</pre>	<pre>[report type ] Parallel Ademco Emul. Serial</pre>
<pre>PARALLEL Communicator: ◆ [Comm type ] [Comm type ]</pre>	<p><b>For Parallel:</b> Specify type of communicator. Use '▲' or '▼' to scroll required communicator to line 3. Press '✓'</p>
<pre>[Comm type ] not used General o/p Internet I Interdial II ADEMCO Plug on Telecom CARE Internet II</pre>	

NOTES

No 'Add' in 'COMMS TYPE' menu                      Primary & Secondary communications are already configured

<pre>ADEMCO EMUL./ SERIAL reporting NOT available Press CLEAR</pre>	<pre>The ADEMCO EMULATION mode and SERIAL mode are not configurable at the keypad in the software version installed.</pre>
---	--

**COMMUNICATIONS TYPE (Modify)**

<pre>COMMS. TYPE ◆ .. . Modify ..</pre>	<pre>&lt;-- Select 'Modify'</pre>
---	-----------------------------------

.....continue as for COMMUNICATIONS TYPE (Add)

CONFIGURE : COMMUNICATIONS TYPE continued overleaf

**COMMUNICATIONS TYPE (Remove)**

```
COMMS. TYPE  ♦
..
. Remove
..
```

*<-- Select 'Remove'*

```
REMOVE
COMMS TYPE
1 Primary
2 Secondary
```

Select Primary or secondary.  
Use '▲' or '▼' to scroll required type  
to line 3. Press '✓'

```
[comm type  ]
Remove all
[type  ] events
Press YES or NO
```

Request for confirmation to remove  
Press '✓' if removal required  
Press 'X' if removal not required

```
[comm type  ]
PRIMARY
SECONDARY
```

```
[type  ]
Primary
Secondary
```

**COMMUNICATIONS TYPE (View)**

```
COMMS. TYPE  ♦
..
. View
..
```

*<-- Select 'View'*

```
VIEW
COMMS TYPE
1 Primary
2 Secondary
```

Select Primary or secondary.  
Use '▲' or '▼' to scroll required type  
to line 3. Press '✓'

```
PRIMARY
PARALLEL EVENTS
communicator -
[comm type  ]
```

**For Primary:**  
Display of Communicator type.  
Use '▲' or '▼' to scroll. Press '✓'

```
SECONDARY
PARALLEL EVENTS
communicator -
[comm type  ]
```

**For Secondary:**  
Display of Communicator type.  
Use '▲' or '▼' to scroll. Press '✓'

Returns to menu

# CONFIGURE : REMOTE COMMS (EVENT GROUPS)


Configure remote comms. event groups.

Events are the zone, point, system messages which are sent to a Remote Site. Events are collected together to form an 'Event Group'. The group is assigned a number which has a significance based on the type of communications:


- Parallel** The Event Group number represents the parallel port pin which will be activated.
- ADEMCO emulation** The Event Group number represents the channel number.
- Serial** The Event Group number represents the channel number.

**Priority Events** For ADEMCO emulation and Serial the priority of Event Reporting over Management functions must be selectable. If 'High Priority Events' are selected then any management function in progress when event information requires transmission is suspended and the events information will be sent.

Note that if both the primary and secondary communicators are serial then the event group will go on either depending on the status of the receiver.



## EVENT GROUPS (Add)



CONFIGURE : EVENT GROUPS (Add) continued overleaf



CONFIGURE : EVENT GROUPS (Add) continued

ADD PRIMARY  
Event Group  
Enter No: xxxx

**For Serial Event Reporting:**

Select group number.  
Enter 4 digit number. Press '✓'

[group type ]  
No. 1 [priority]  
Priority Events  
Change?YES or NO

**For Serial Event Reporting/ADEMCO Emulation:**

Select priority.  
Press '✓' to change displayed status  
Press 'X' to retain displayed status

[group type ]  
PRIMARY  
SECONDARY

[priority]  
Low  
High

PRIMARY MESSAGE♦  
[type menu ]  
[type menu ]  
[type menu ]

Select message type.

Use '▲' or '▼' to scroll required type  
to line 2. Press '✓'

[type menu ]  
. Group Complete  
. System message  
. Zone messages  
. Point messages  
. Door messages

SYSTEM MESSAGES  
[system message]  
[status ]  
Change?YES or NO

**If system messages required:**

Select system messages.  
Press '✓' to change displayed status  
Press 'X' to retain displayed status

[system message ]  
ALL Alarm/Tamper  
Any Alarm  
Any Tamper  
Night Alarm only  
24hr Point only  
PA Alarms only  
Battery Low  
Comms Fail  
Comms Test  
Tamper on Bell  
Tamper on Panel  
DG Network Fail  
UI Network Fail  
Mains Fail  
Autoset Demand  
System SET  
System UNSET  
Clock Changed  
Service log  
Max shunts  
Max isolates  
Processor Reset  
System Error

[status ]  
USED  
UNUSED

CONFIGURE : EVENT GROUPS (Add) continued overleaf

CONFIGURE : EVENT GROUPS (Add) continued

Late Work Active  
 Work Early Activ{e}  
 Any Zone SET  
 Service access  
 Any schd expiry  
 Tamper set zone  
 Duress PIN  
 Incident  
 Any INOVA InvAcc  
 Any INOVA DurAcc  
 Any INOVA HeldOp  
 Any INOVA ForcOp  
 Any INOVA LnFaul  
 Any INOVA Tamper  
 INOVA Comms Fail  
 ISB failure  
 Battery failure  
 Pri. Comms Fail  
 Sec. Comms Fail  
 Test Message  
 Verified Alarm  
 Bat test failed

ZONE MESSAGES [zone message ] [status ] Change?YES or NO
---

**If zone messages are required:**

Select zone messages.  
*Press '✓' to change displayed status and move to next zone.*  
*Press 'X' to retain displayed status and move to next zone.*  
*Press '▲' and '▼' to move through the message types while leaving the zone unaltered. Entering a zone number and pressing '✓' goes to that zone number without changing the current displayed status.*

[zone message ]  
 Zone ZZ Alarm  
 Zone ZZ Tamper  
 Zone ZZ SET  
 Zone ZZ UNSET  
 Zone ZZ expiry  
 Zone ZZ PA alarm  
 Zone ZZ 24 hour  
 Zone ZZ night  
 Zone ZZ battery  
 Zone ZZ max isol{ates}  
 Zone ZZ max shun{ts}  
 Zone ZZ em. unse{t}  
 Zone ZZ Entry Du{ress}  
 Zone ZZ has shun{t}  
 Zone ZZ has isol{ate}  
 ATM Zone ZZ byps{s}  
 ZZ Autoset Fail

[status ]  
 Zone ZZ USED  
 Zone ZZ UNUSED

Keypad U Locked                    UI U USED  
     UI U UNUSED  
 Zone ZZ Verify A{larm}

CONFIGURE : EVENT GROUPS (Add) continued overleaf

CONFIGURE : EVENT GROUPS (Add) continued

```
POINT MESSAGES
Report point xxx
Point xxx [stat]
Change?YES or NO

[stat _____]
USED
UNUSED
```

**If Point messages are required:**  
 Select point messages.  
 Press '✓' to change displayed status  
 Press 'X' retain displayed status  
 Entering a point number and pressing '✓' goes to that point without changing the current status.  
 Press '▲' and '▼' to move 8 points at a time.

```
DOOR MESSAGES
[door function ]
Door x [status ]
Change?YES or NO

[door function _____]
Door xx InvAcc
Door xx DurAcc
Door xx HeldOp
Door xx ForcOp
Door xx LnFaul
Door xx Tamper
```

**If Door Messages are required:**  
 Select door function messages.  
 Press '✓' to change displayed status  
 Press 'X' to retain displayed status

```
[status _____]
USED
UNUSED
```

**EVENT GROUPS (Modify)**

```
EVENT GROUPS ♦
..
. Modify
..
```

<-- Select 'Modify'

.....continue as for EVENT GROUPS (Add)

**EVENT GROUPS (Remove)**

```
EVENT GROUPS ♦
..
. Remove
..
```

<-- Select 'Remove'

```
ADD GROUP ♦
1 Primary
2 Secondary
```

Select primary or secondary.  
 Use '▲' or '▼' to scroll required type to line 2. Press '✓'

```
REMOVE [type _____]
Event Group
Enter No: xx
```

**For Parallel/ADEMCO emulation:**  
 Select group number.  
 Enter 2 digit number. Press '✓'

CONFIGURE : EVENT GROUPS (Remove) continued overleaf

CONFIGURE : EVENT GROUPS (Remove) continued

```
REMOVE [type  ]
Event Group
Enter No: xxxx
```

**For Serial Event Reporting:**  
Select group number.  
Enter 4 digit number. Press '✓'

```
REMOVE [type  ]
Event Group nnnn
Press YES or NO
```

Display of group number for confirmation  
Press '✓' to remove  
Press 'X' to retain  
  
Returns to menu if successful

**EVENT GROUPS (View)**

```
EVENT GROUPS  ♦
..
. View
..
```

<-- Select 'View'

```
VIEW GROUP  ♦
1 Primary
2 Secondary
```

Select primary or secondary.  
Use '▲' or '▼' to scroll required type  
to line 2. Press '✓'

```
VIEW [type  ]
Event Group
Enter No: xx
```

**For Parallel/ADEMCO emulation:**  
Select group number.  
Enter 2 digit number. Press '✓'

```
VIEW [type  ]
Event Group
Enter No: xxxx
```

**For Serial Event Reporting:**  
Select group number.  
Enter 4 digit number. Press '✓'

```
VIEW [type  ]
Group No: nnnn
[priority  ]
Events
```

Display of priority.  
Press '✓' to continue

```
[priority  ]
Low priority
High priority
```

```
VIEW [type  ]
Group nnnn -
[message  ]
[message  ]
```

Display of group events.  
Press '✓' to continue

```
[message  ]
```


As in **CONFIGURE : EVENT GROUPS (Add)**  
and including 'Hist log events'

# CONFIGURE : REMOTE COMMS (SERIAL EQUIPMENT)


Configure type of serial equipment and mode of operation.

**Monitor Line facility** The health of the telephone line connection is periodically checked.

**Session Time-out** The maximum time for which an idle connection is retained since the last communication.



## SERIAL EQUIPMENT (Modify)



CONFIGURE : SERIAL EQUIPMENT (Modify) continued overleaf

CONFIGURE : SERIAL EQUIPMENT (Modify) continued

SERIAL PORT x  
Protocol: ♦  
[prot menu line]  
[prot menu line]

**If protocol is variable:**  
Select data protocol  
Use '▲' or '▼' to scroll required protocol  
to line 3. Press '✓'

[prot menu line ]  
. PS/006  
. PS/018  
. PS/024

SERIAL PORT x  
Data rate: ♦  
[rate menu line]  
[rate menu line]

Select data rate  
Use '▲' or '▼' to scroll required baud rate  
to line 3. Press '✓'

[rate menu line ]  
. 1200  
. 2400  
. 4800  
. 9600  
. 19200  
. 38400

SERIAL PORT x  
Monitor Line is  
[status ]  
Change?YES or NO

**If not INOVA:**  
Specify Monitor Line facility.  
Press '✓' to change displayed status  
Press 'X' to retain displayed status

[status ]  
ENABLED  
DISABLED

SERIAL PORT x  
Session Timeout  
xx:xx hh:mm

Specify Session time-out period.  
Select 2 digit hour. Press '✓'  
Select 2 digit minute. Press '✓'  
If zero, the session does not time out.

SERIAL PORT x  
Port address  
000.000.000.000

**For IP network applications:**  
Specify the Port IP address.  
Enter 4 3-digit numbers. Press '✓'

SERIAL PORT x  
Router address  
000.000.000.000

Specify the Router IP address.  
Enter 4 3-digit numbers. Press '✓'

SERIAL PORT x  
Subnet mask  
000.000.000.000

Specify the subnet mask.  
Enter 4 3-digit numbers. Press '✓'

Returns to menu if successful

CONFIGURE : SERIAL EQUIPMENT (View) overleaf

**SERIAL EQUIPMENT (View)**

```
SERIAL
EQUIPMENT  ♦
..
. View
```

*<-- Select 'View'*

```
VIEW
EQUIPMENT
Port number: x
```

Select serial port.  
Select number. Press '✓'

```
SERIAL PORT N
[comm. type  ]
[protocol    ]
[baud rate   ]
```

Display of communicator type  
Display of serial port baud rate  
Display of line monitor facility  
Press '✓' to continue

```
[comm. type  ]
not used
ChubbCOM
PAD
V.25bis
Hayes
Hayes HDX
WindsorModem
WModem HDX
INOVA
Direct
```

[protocol    ]	[baud rate   ]
not used	0 bps
PS/006	1200 bps
PS/018	2400 bps
PS/024	4800 bps
	9600 bps
	19200 bps
	38400 bps

```
SERIAL PORT N
[mon. facility ]
Session Timeout
H:MM hh:mm
```


Display of session time-out  
Press '✓' to continue

```
[mon. facility ]
Monitor Line
No Monitor Line
```

Returns to menu

# CONFIGURE : RESPONSES

Configure sounders/strobes delays and duration. Some point types such as NA2 and PA1 only activate the local sounder if a line fault is detected when the alarm occurs, or if a communication failure is detected within the **latent period** following the alarm. Configure the period over which mains fail should be detected before a Mains Fail alarm is generated.





# CONFIGURE : SCHEDULE

Schedules control when zones may be unset and when they must be set. Each zone may be controlled by one or more schedules. If a zone is not controlled by any schedules it may be set and unset at any time. Otherwise the zone may only become unset while at least one of its controlling schedules are in an **open window**. While at least one of its controlling schedules are **open** (but none are in an open window) the zone may remain set or unset, it may become set, but once it is set the zone cannot become unset. While all of a zone's controlling schedules are **closed**, the zone must become or remain set, it may not become or remain unset.

Normally the open window of a schedule starts at the **earliest normal opening** and ends at the **latest normal opening**, the schedule is then open until the **latest normal closing**, it is then closed until the following earliest normal opening.

The early open feature may be used to bring the start of the open window forward (see User Manual). The start of the open window cannot be brought forward any further than the **earliest early opening**. Similarly late working delays the when the schedule becomes shut. This can not be delayed any further than the **latest late working**.

If all five times above are set to zero, the schedule is closed all day.

## SCHEDULE (Add)

```
CONFIG MENU  ♦
..
. Schedule
..
```

*<-- Select 'Schedule'*

```
SCHEDULE S  ♦
ssssssssssss
Press YES to
select
```

Specify schedule number.  
Use '▲' or '▼' to scroll number. Press '✓'

```
SCHEDULE S
Controls zone ZZ
zzzzzzzzzzzzzzzz
Press YES or NO
```

Specify zone(s) to be controlled by the schedule.  
Press '✓' to select zone  
Press 'X' to reject zone  
Repeat for all zones

```
SCHEDULE S
[day          ]
Earliest early
opening:- xx:xx
```

**Repeat for each day:**  
Specify Earliest early opening.  
Enter 2 digit number (hour). Press '✓'  
Enter 2 digit number (min.). Press '✓'  
If not required the time must be set to the same as normal opening.

```
[day          ]
Monday
Tuesday
Wednesday
Thursday
Friday
Saturday
Sunday
```

CONFIGURE : SCHEDULE (Add) continued overleaf

CONFIGURE : SCHEDULE (Add) continued

SCHEDULE S  
[day            ]  
Earliest normal  
opening:- xx:xx

Specify Earliest normal opening.  
Enter 2 digit number (hour). Press '✓'  
Enter 2 digit number (min.). Press '✓'

SCHEDULE S  
[day            ]  
Latest normal  
opening:- xx:xx

Specify Latest normal opening.  
Enter 2 digit number (hour). Press '✓'  
Enter 2 digit number (min.). Press '✓'

SCHEDULE S  
[day            ]  
Latest normal  
closing:- xx:xx

Specify Latest normal closing.  
Enter 2 digit number (hour). Press '✓'  
Enter 2 digit number (min.). Press '✓'

SCHEDULE S  
[day            ]  
Latest late  
working:- xx:xx

Specify Latest late working.  
Enter 2 digit number (hour). Press '✓'  
Enter 2 digit number (min.). Press '✓'  
If not required the time must be set to  
the same as normal closing.

The above repeats for each day to be specified.

SCHEDULE S  
Enter descriptor  
♦

Specify schedule descriptor.  
Select characters (see **USING THE KEYPAD**)

Returns to 'Log-On'

NOTES

SCHEDULE ERROR  
Overlapping  
time settings

A mistake in data entry. For example  
Latest Normal Opening is before Earliest  
Normal Opening.

CONFIGURE : SCHEDULE continued overleaf

**SCHEDULE (Modify)**

```
CONFIG MENU  ◆
..
. Schedule
..
```

*<-- Select 'Schedule'*

```
SCHEDULE S
ssssssssssssssss
Press YES to
select
```

Specify schedule.  
Use '▲' or '▼' to scroll required schedule  
to line 2. Press '✓'

```
SCHEDULE  ◆
..
. Modify
..
```

*<-- Select 'Modify'*

.....continue as for SCHEDULE (Add)

**SCHEDULE (Remove)**

```
CONFIG MENU  ◆
..
. Schedule
..
```

*<-- Select 'Schedule'*

```
SCHEDULE S
ssssssssssssssss
Press YES to
select
```

Specify schedule.  
Use '▲' or '▼' to scroll required schedule  
to line 2. Press '✓'

```
SCHEDULE  ◆
..
. Remove
..
```

*<-- Select 'Remove'*

Returns to 'Log-On' if successful

# CONFIGURE : START/END CONFIGURATION

The behaviour of the Windsor 700 is largely controlled by its configuration. The configuration will usually be created using the Windsor 700 Configuration Editor PC software. The configuration is then transferred to the Windsor 700 either using a PROM Pack (See **CONFIGURE : COPY CONFIGURATION**) or a GuardStation (See **CONFIGURE : REMOTE CONFIGURATION**). The configuration may be altered (or in an emergency created) at the keypad. Before altering the configuration, the Windsor 700 must be put into configuration mode using the following procedure. Note that while the Windsor 700 is in configuration mode, it is unable to monitor alarms and all other keypads are disabled.

## CONFIGURATION (Start)

```
FUNCTION SELECT◆  
. . .  
. Configuration  
. . .
```

*<-- Select 'Configuration'*

```
Command Disables  
*** Panel      ***  
Press NO = Quit  
YES = Continue
```

Note that the system is no longer able to monitor alarms if the function is continued.  
*Press '✓' to continue*  
*Press 'X' to abort*  
If successful the 'CONFIG MENU' is presented. Continue according to requirement then perform 'End' as described overleaf.

## NOTES

```
CONFIG FAIL  
System set or  
partially set
```

Set zones will prevent the configuration examination/modification. The zones must be unset to continue.  
Press 'C'

```
Configuration  
disable  
Other users  
logged on
```


Other users are logged-on. or a remote user is logged-on. This prevents configuration examination.  
Press 'C'

```
Configuration  
disable  
Comms in use  
Press CLEAR
```

The comms link is in use. This prevents configuration examination.  
Press 'C'

CONFIGURE : START/END CONFIGURATION continued overleaf

**CONFIGURATION (End)**



NOTES

- |  |  |
|--|--|
| <pre>CONFIGURATION ERROR [error line 1 ] [error line 2 ]</pre>       | <p>There are a large number of error messages associated with this display.<br/> The error must be corrected.<br/> Press 'C' to return to menu</p>   |
| <pre>CONFIGURATION IS TOO LARGE Press CLEAR to return</pre>          | <p>The configuration is too large for the storage device which is fitted on the Control Unit PCB.<br/> The device will require substitution or the configuration must be reduced.<br/> Press 'C' to return to menu</p> |
| <pre>Limited maximum no. of users xx INFORM MASTER Press CLEAR</pre> | <p>The configuration data has filled the storage device to the extent that the space remaining to hold user data is restricted and the number of users will hence be limited as displayed.</p>                         |

# CONFIGURE : UI

This facility enables the programming of devices which connect to the User Interface Network (UIN).

**Disabled in a set zone** The display will be blank. Pressing a key will un-blank the display and the user may log-in.

**Disabled in an unset zone** The display will be blank but in this instance attempted use by pressing a key will have no effect. This facility is primarily intended for ATM bypass.

A card reader can be attached to one or more keypads. This can be used to grant access to an ATM lobby when a valid card is swiped (see **CONFIGURE : LOBBY ACCESS** for how to set up valid cards) or alternatively to provide access card log-on (see the User Manual for how to setup valid user cards). When configuring a keypad you must specify whether a lobby card reader is attached. If so, you must specify which point output is linked to the lobby door strike and for how long the door must be opened when a card is swiped. The point output must be configured to react to some point, zone, or system condition. Usually it will be configured as a monitor point linked to a signalling point input. this point input is then wired to a request to exit button.

```
CONFIG MENU  ◆
..
. UI Port
..
```

<-- Select 'UI Port'

## UI (Add)

```
UI PORT  ◆
..
. Add
..
```

<-- Select 'Add'

```
UI PORT
Enter address-x
```

Specify address of UI.  
Enter 1 digit number. Press '✓'

```
UI PORT K
Enter descriptor
◆
```

Specify descriptor of UI.  
Select characters (see **USING THE KEYPAD**)

```
UI PORT K
Select type
[UI type menu ]
```

Specify type of UI.  
Use '▲' or '▼' to scroll required UI type  
to line 3. Press '✓'

```
[UI type menu ]
. normal
```

CONFIGURE : UI (Add) continued overleaf

CONFIGURE : UI (Add) continued

UI PORT K  
[zone state] ZZ  
zzzzzzzzzzzzzzzzzzzz  
Change?YES or NO

Specify zone(s) to be controlled by UI.  
Press '✓' to change displayed status  
Press 'X' to retain displayed status

Repeats for all zones

[zone state ]  
Controls zone  
NOT for zone

UI PORT K  
[set line 1 ]  
in set zone  
Change?YES or NO

If the UI is disabled when all its zones are set,  
the display will be blanked. In this state,  
pressing a key unblanks the display and the user  
may log-in.

Press '✓' to change displayed status  
Press 'X' to retain displayed status

[set line 1 ]  
UI Disabled when  
UI Enabled when

UI PORT K  
[unset line 1 ]  
in unset zone  
Change?YES or NO

If the UI is disabled when all its zones are  
unset the display will be blanked. In this state,  
pressing a key will have no effect.

Press '✓' to change displayed status  
Press 'X' to retain displayed status

[unset line 1 ]  
UI Enabled when  
UI Disabled when

UI PORT K  
[line 2 ]  
Change?YES or NO

Specify whether UI has set/unset menu.  
Press '✓' to change displayed status  
Press 'X' to retain displayed status

[line 2 ]  
No Set/Uns Menu  
Set/Unset Menu

UI PORT K  
[key message ]  
Change?YES or NO

Specify whether UI has keyswitch.  
Press '✓' to change displayed status  
Press 'X' to retain displayed status

[key message ]  
UI with key  
no keyswitch

UI PORT K  
Card Login  
[line 3 ]  
Change?YES or NO

Specify whether UI has card reader for log-on.  
Press '✓' to change displayed status  
Press 'X' to retain displayed status

[line 3 ]  
Disabled  
Enabled

CONFIGURE : UI (Add) continued overleaf

CONFIGURE : UI (Add) continued

```

UI PORT K
Lobby access
[access status ]
Change?YES or NO
[access status ]
Disabled
Enabled
    
```

Specify whether UI has lobby access.  
 Press '✓' to change displayed status  
 Press 'X' to retain displayed status  
 If you select this then card reader log-on is disabled.

```

UI PORT K
Door strike on
point xxx
    
```

**If lobby access enabled:**  
 Specify point output controlling lobby door.  
 Enter 3 digit number. Press '✓'

```

UI PORT K
Door open for
xx seconds
    
```

Specify duration of point output (0 to 99s)  
 Enter 2 digit number (01 to 99). Press '✓'

Returns to 'UI NETWORK DEF' menu

NOTES

'invalid number'                      The number selected is out-of-range or the number has already been allocated.

**UI (Modify)**

```

UI PORT                      ♦
..
. Modify
..
    
```

<-- Select 'Modify'

.....continue as for UI (Add)

**UI (Remove)**

```

UI PORT                      ♦
..
. Remove
..
    
```

<-- Select 'Remove'

```

UI PORT
Enter address-x
    
```

Specify UI Address.  
 Enter 1 digit number. Press '✓'

CONFIGURE : UI (Remove) continued overleaf



CONFIGURE : UI (Remove) continued

```
REMOVE UI K
kkkkkkkkkkkkkkkkkk
Press YES or NO
```

Display of UI descriptor for confirmation.  
*Press '✓' to remove*  
*Press 'X' to abort*

Returns to 'CONFIG MENU' if successful

**UI (View)**

```
UI PORT ◆
..
. View
..
```

<-- *Select 'View'*

```
UI PORT
Enter address-x
```

Specify UI Address.  
*Enter 1 digit number. Press '✓'*

```
VIEW UI PORT K
kkkkkkkkkkkkkkkkkk
[key status ]
[set/unset menu]
```

Display of UI descriptor.  
 Display of keyswitch status.  
*Press '✓' to continue*

```
[key status ]
keyswitch fitted
No keyswitch
```

```
[set, unset menu ]
No Set/Uns menu
Set/Unset menu
```

```
VIEW UI PORT K
[set status ]
controllable
zones are set
```

Display of activity in set zones.  
*Press '✓' to continue*

```
[set status ]
Enabled when
Disabled when
```

```
VIEW UI PORT K
[unset status ]
controllable
zones are unset
```

Display of activity in unset zones.  
*Press '✓' to continue*

```
[unset status ]
Enabled when
Disabled when
```

```
VIEW UI PORT
Controllable
zone ZZ ◆
zzzzzzzzzzzzzzzzzz
```

Display of zones controlled by UI.  
*Use '▲' or '▼' to scroll zone list*  
*Press '✓' to continue*

CONFIGURE : UI (View) continued overleaf

---

CONFIGURE : UI (View) continued

VIEW UI PORT K  
Card login  
[card status ]

Display of swipe card login facility.  
*Press '✓' to continue*

[card status ]  
Enabled  
Disabled

VIEW UI PORT  
[access line 1 ]  
[access line 2 ]  
[access line 3 ]

Display of zones controlled by UI.  
*Press '✓' to continue*

[access line 1 ]  
Lobby access  
No Lobby access

Returns to menu  
[access line 2 ]      [access line 3 ]  
Door point 000      Open NN secs

## CONFIGURE : ZONE

This facility enables the creation or modification of a zone, the removal of a zone from the configuration or provides information on the zone(s) already configured.

<b>Normal</b>	The default zone type.
<b>Secure</b>	A zone which is always set and cannot be unset.
<b>Special secure</b>	This zone type is obsolete and should not be used.
<b>ATM Bypass</b>	A zone with one or more ATMs which may be accessed using the ATM Bypass feature.

**Max number of isolated points** This number must be less, by at least one, than the number of isolatable points in the zone.

**Max number of shunted points** This number must be less, by at least one, than the number of shunable points in the zone.

**Linked for set** Zones which will be set when this one is set. If setting of any of these zones would cause an alarm, then none of the zones are set, including this one.

```
CONFIG MENU  ♦
..
. Zone
..
```

*<-- Select 'Zone'*

### ZONE (Add)

```
ZONE  ♦
..
. Add
..
```

*<-- Select 'Add zone'*

```
ADD ZONE
Enter number:-xx
```

Specify zone number.  
Enter 2 digit number. Press '✓'

```
ADD ZONE ZZ
Enter descriptor
♦
0=complete
```

Specify zone descriptor.  
Select characters (see **USING THE KEYPAD**)


```
ADD ZONE ZZ
Define type  ♦
[zone type menu]
[zone type menu]
```

Specify zone type.  
Use '▲' or '▼' to scroll required type to line 3. Press '✓'

```
[zone type menu ]
. Normal
. Special secure
. ATM Bypass
```

CONFIGURE : ZONE (Add) continued overleaf

CONFIGURE : ZONE (Add) continued



CONFIGURE : ZONE (Add) continued overleaf

CONFIGURE : ZONE (Add) continued

ADD ZONE ZZ  
[line 2 ]  
Set/Unset Menu  
Change?YES or NO

Specify if zone will be displayed in the Set/  
Unset menu.  
*Press 'X' to retain displayed status.*  
*Press '✓' to change displayed status.*

[line 2 ]  
Show zone on  
Hide zone on

ADD ZONE ZZ  
[line 2 ]  
controller  
Change?YES or NO

**If a Normal zone:**  
Specify if zone is an ATM control zone.  
*Press 'X' to retain displayed status.*  
*Press '✓' to change displayed status.*

[line 2 ]  
NOT ATM  
ATM

ADD ZONE ZZ  
[line 2 ]  
Change?YES or NO

Specify if zone is to be a secure zone.  
*Press 'X' to retain displayed status.*  
*Press '✓' to change displayed status.*

[line 2 ]  
NOT secure zone  
secure zone

ADD ZONE ZZ  
[line 2 ]  
PIN Response  
Change?YES or NO

**If Keypad Alarm configured:**  
Specify if zone is to be Invalid PIN unset.  
*Press 'X' to retain displayed status.*  
*Press '✓' to change displayed status.*

[line 2 ]  
No Invalid  
Invalid

ADD ZONE ZZ  
[line 2 ]  
Change?YES or NO

Specify if zone has any "linked for set" zones.  
*Press 'X' to retain displayed status.*  
*Press '✓' to change displayed status.*

[line 2 ]  
No linked zones  
Linked zones

ADD ZONE ZZ  
Link to Zone ZZ  
zzzzzzzzzzzzzzzzzzzz  
Press YES or NO

**If linked zones specified above:**  
Specify which zones are to be linked to this  
zone for set.  
*Press 'X' to retain displayed status.*  
*Press '✓' to change displayed status.*

CONFIGURE : ZONE (Add) continued overleaf

CONFIGURE : ZONE (Add) continued

```
ADD ZONE ZZ
[line 2      ]
cmd restricted
Change?YES or NO
```

Specify whether selected commands are to have no access to this zone.  
*Press 'X' to retain displayed status.*  
*Press '✓' to change displayed status.*

```
[line 2      ]
Zone is NOT
Zone is
```

```
ADD ZONE ZZ
[line 2      ]
dual PIN access
Change?YES or NO
```

Specify whether zone is to be unset using dual PIN entry.  
*Press 'X' to retain displayed status.*  
*Press '✓' to change displayed status.*

```
[line 2      ]
Zone is NOT
Zone is
```

```
ADD ZONE ZZ
Rearm delay in
seconds: xxx
```

Specify rearm delay time.  
*Enter 3 digit number (000 to 255). Press '✓'*  
*(000 for rearm disabled)*

```
ADD ZONE ZZ
AutoUnshunt
[unshunt status]
Change?YES or NO
```

**If Autorearm configured:**  
Specify if autounshunt required  
*Press 'X' to retain displayed status*  
*Press '✓' to change displayed status*

```
[unshunt status ]
Enabled
Disabled
```

Returns to 'ZONE' menu

NOTES

- |                        |  |
|------------------------|--|
| 'Add zone' not in menu | Maximum number of zones already configured.  |
| 'invalid number'       | The number is out-of-range, or the number has already been assigned. For isolated and shunt limits see <b>INTRODUCTION</b> . |

**ZONE (Modify)**

```
ZONE      ◆
..
. Modify
..
```

<-- Select 'Modify'


.....continue as for ZONE (Add)

NOTES

- |                           |                                    |
|---------------------------|------------------------------------|
| 'Change zone' not in menu | No zones are currently configured. |
|---------------------------|------------------------------------|

CONFIGURE : ZONE continued overleaf

**ZONE (Remove)**



<-- Select 'Remove'


Specify zone number.  
Enter 2 digit number. Press '✓'

Returns to 'ZONE' menu if successful

**NOTES**

- 'Remove zone' not in menu      No zones already configured.
- 'invalid number'              The number is out-of-range, or the number has not been assigned.

**ZONE (View)**



<-- Select 'View'

Specify zone number  
or scroll to required zone. Press '✓'

Display of zone descriptor.  
Display of zone type.  
Display of Entry/Exit Route.  
Press '✓' to continue

[zone type  
see **ZONE (Add)**

Display of number of shuntable points.  
Display of number of isolatable points.  
Press '✓' to continue

Display of point inputs in zone.  
Use '▲' or '▼' to scroll

CONFIGURE : ZONE (View) continued overleaf

CONFIGURE : ZONE (View) continued

VIEW ZONE ZZ  
[line 2 ]  
Auto Set/Unset

Display whether this scheduled zone can be manually set or unset outside the schedule.  
*Press '✓' to continue*

[line 2 ]  
Manual and  
NOT Manual and

VIEW ZONE ZZ  
[Unset fct ]  
[Set fct ]  
on Sched expiry

Display of Unset function.  
Display of Set function.  
*Press '✓' to continue*

[Unset fct ]  
Auto Unset  
NOT Auto Unset

[Set fct ]  
Automatic Set  
NOT Set

VIEW ZONE ZZ  
[line 2 ]  
[line 3 ]

Display of whether zone may only be unset once within an open window.  
*Press '✓' to continue*

[line 2 ]  
NOT Restricted  
Restricted Unset

[line 3 ]  
Unset  
in open window

VIEW ZONE ZZ  
[line 2 ]  
Set/Unset Menu

Display of whether zone will be displayed in the Set/Unset menu.  
*Press '✓' to continue*

[line 2 ]  
Show Zone on  
Hide Zone on

VIEW ZONE ZZ  
[line 2 ]  
controller

**Only displayed for a Normal zone.**  
Display of whether zone is an ATM control zone.  
*Press '✓' to continue*

[line 2 ]  
NOT ATM  
ATM

VIEW ZONE ZZ  
[line 2 ]

Display whether zone is a secure zone.  
*Press '✓' to continue*

[line 2 ]  
NOT secure zone  
secure zone

CONFIGURE : ZONE (View) continued overleaf



CONFIGURE : ZONE (View) continued

VIEW ZONE ZZ  
Linked zone ZZ  
zzzzzzzzzzzzzzzzzzzz

**Only displayed if slave zones are defined:**  
Display zones linked to this zone for set.  
Use '▲' or '▼' to scroll  
Press '✓' to continue

VIEW ZONE ZZ  
[line 2            ]  
cmd restricted

Display whether selected commands are to have no access to this zone.  
Press '✓' to continue

[line 2            ]  
Zone is NOT  
Zone is

VIEW ZONE ZZ  
[line 2            ]  
dual PIN access

Display whether zone is to be unset by dual PIN access.  
Press '✓' to continue

[line 2            ]  
Zone is NOT  
Zone is

VIEW ZONE ZZ  
Rearm delay in  
seconds: xxx

Display of rearm delay.  
Press '✓' to continue

VIEW ZONE ZZ  
AutoUnshunt  
[unshunt status]

**If Autorearm configured:**  
Display whether autounshunt defined  
Press '✓' to continue

[unshunt status ]  
Enabled  
Disabled

Returns to 'ZONE' menu

# DEFINE : ACPO MODE

---

This facility is used to clear a remote communications activation if the user logs-on and unsets those zones in alarm. The Central Station will, for ACPO requirements, ignore alarms if they are cleared within x minutes.

---

```

CONFIG MENU  ◆
..
. System
..
    
```

<-- Select 'System'

```

SYSTEM      ◆
..
. Misc Sys Param
..
    
```

<-- Select 'Misc Sys Param'

```

MISC SYS PARA 1◆
..
. More Params
..
    
```

<-- Select 'More Params'

```

MISC SYS PARA 2◆
..
. ACPO Tx reset
..
    
```

<-- Select 'ACPO Mode'

```

ACPO TX RESET
[ACPO status ]
compliant
Change YES or NO
    
```

Specify requirement for ACPO Mode.  
 Press '✓' to change the displayed status  
 Press 'X' to retain the displayed status

Returns to 'MISC SYS PARAMS' menu

```


[ACPO status ]
Panel is ACPO
Panel not ACPO
    
```

# DEFINE : ATM TIMES

The ATM bypass facility allows a zone to be temporarily unset to allow the replenishment of an ATM. Each zone which protects such an ATM must be configured as an ATM bypass zone, see **CONFIGURE : ZONES**. The ATM bypass is controlled either from a dedicated keypad which is only in the ATM zone, or from a non-dedicated keypad that has access to one or more ATM zones when any ATM control zone is set.

At a dedicated ATM keypad the user will enter a PIN. If the PIN **entry wait period** is non-zero, the PIN has to be re-entered after waiting for the specified time. After replenishing the ATM, the PIN is entered and "Bypass Remove" selected. If the bypass is not removed within the **access period**, the bypass will automatically be removed (if the user is still present an alarm will be cause). If the user runs out of time the bypass can be renewed up to **access period repeat** times by re-entering the PIN and selecting "Extend Bypass".

At a non-dedicated keypad with ATM Bypass capability, only the **access period** and **access period repeat** fields are used.



## NOTES

'invalid number'


The selected number is out-of-range.

# DEFINE : AUTO. BATTERY TEST


This option allows the configuration of an automatic battery test which is to occur at configurable times. The test is then performed automatically at these times regardless of the set/unset status of the system. If the test fails it will not be possible to set the system. A configurable remote comms event will be reported. Any zones which are unset, unsetting or setting will be put into prewarning.

The test times can be configured in one of two ways:

- Daily**                The test will run at the configured time on the specified day.
- Periodically**      The test will run on the specified day at times separated by the configured period with the first test at the specified period after 00:00 (midnight). For example, if the configured period is 07:00 the test will run at 07.00, 14.00, and 21.00.



## AUTO. BATTERY TEST (Daily)



DEFINE : AUTO. BATTERY TEST continued overleaf

DEFINE : AUTO. BATTERY TEST continued

TIMED FUNCT. T  
[day ] at  
hh:mm

**If change requested from 'no test':**  
Specify days and times for test  
Press '**▲**' to display hours and minutes.  
Enter 2 digit number (hour). Press '**✓**'  
Enter 2 digit number (min). Press '**✓**'

TIMED FUNCT. T  
[day ] at  
hh:mm ♦  
Change?YES or NO

**If displayed time for the day**  
Press '**✓**' to change from no test  
Press '**X**' to retain no test

TIMED FUNCT. T  
[day ] at  
hh:mm

**If change requested from displayed time:**  
Specify days and times for test  
Press '**▲**' if no test required. Press '**✓**'  
Enter 2 digit number (hour). Press '**✓**'  
Enter 2 digit number (min). Press '**✓**'

Returns to 'DEF TIME PARAMS' menu

## AUTO. BATTERY TEST (Periodically)

TIMED FUNCT. T ♦  
..  
. Periodically  
..

<-- Select 'Periodically'

TIMED FUNCT. T  
[day ] every  
h:mm  
Change?YES or NO

Specify days and period interval for test  
Press '**✓**' to change the displayed period  
Press '**X**' to retain the displayed period  
Repeat for all days

[day ]  
Monday  
...  
Sunday

TIMED FUNCT. T  
[day ] every  
hh:mm

**If change requested:**  
Specify days and times for test  
Enter 2 digit number (hour). Press '**✓**'  
Enter 2 digit number (min). Press '**✓**'

Returns to 'DEF TIME PARAMS' menu

# DEFINE : AUTO. BELL MUTE

---

This facility enables a user to mute the system bells when logging-on.

---

```
CONFIG MENU  ♦
..
. System
..
```

*<-- Select 'System'*

```
SYSTEM  ♦
..
. Misc Sys Param
..
```

*<-- Select 'Misc Sys Param'*

```
MISC SYS PARA 1 ♦
..
. Auto Bell Mute
..
```

*<-- Select 'Auto Bell Mute'*

```
MISC SYS PARAM
Auto Bell Mute
[status      ]
Change?YES or NO
```

Specify requirement for Auto Bell Mute.  
*Press '✓' to change the displayed status*  
*Press 'X' to retain the displayed status*

Returns to 'MISC SYS PARAMS' menu

```
[status      ]
Enabled
Disabld
```


# DEFINE : AUTO. DETECTOR TEST

Those detectors which have a self test capability can be automatically tested. This option specifies time(s) for the test and the zone(s) within which it is to be performed.


The test times can be configured in one of two ways:

**Daily** The test will run at the configured time on the specified day.

**Periodically** The test will run on the specified day at times separated by the configured period with the first test at the specified period after 00:00 (midnight). For example, if the configured period is 07:00 the test will run at 07.00, 14.00, and 21.00.



## AUTO. DETECTOR TEST (Daily)



DEFINE : AUTO. DETECTOR TEST (Add) continued overleaf

DEFINE : AUTO. DETECTOR TEST (Add) continued

TIMED FUNCT. T  
[day ] at  
hh:mm

**If change requested from 'no test':**  
Specify days and times for test  
Press '**▲**' to display hours and minutes.  
Enter 2 digit number (hour). Press '**✓**'  
Enter 2 digit number (min). Press '**✓**'

TIMED FUNCT. T  
[day ] at  
hh:mm ♦  
Change?YES or NO

**If displayed time for the day**  
Press '**✓**' to change from no test  
Press '**X**' to retain no test

TIMED FUNCT. T  
[day ] at  
hh:mm

**If change requested from displayed time:**  
Specify days and times for test  
Press '**▲**' if no test required. Press '**✓**'  
Enter 2 digit number (hour). Press '**✓**'  
Enter 2 digit number (min). Press '**✓**'

TIMED FUNCT. T  
[stat] zone ZZ  
[status ]  
Change?YES or NO

Specify zones where the test will run.  
Press '**X**' to retain displayed status  
Press '**✓**' to change displayed status

[stat ]  
in  
NOT in

Returns to 'DEF TIME PARAMS' menu

**AUTO. DETECTOR TEST (Periodically)**

TIMED FUNCT. T ♦  
..  
. Periodically  
..

<-- Select 'Periodically'

TIMED FUNCT. T  
[day ] every  
h:mm  
Change?YES or NO

Specify days and period interval for test  
Press '**✓**' to change the displayed period  
Press '**X**' to retain the displayed period  
Repeat for all days

[day ]  
Monday  
...  
Sunday

TIMED FUNCT. T  
[day ] every  
hh:mm

**If change requested:**  
Specify days and times for test  
Enter 2 digit number (hour). Press '**✓**'  
Enter 2 digit number (min). Press '**✓**'

TIMED FUNCT. T  
[stat] zone ZZ  
[status ]  
Change?YES or NO

Specify zones where the test will run.  
Press '**X**' to retain displayed status  
Press '**✓**' to change displayed status


[stat ]  
in  
NOT in

Returns to 'DEF TIME PARAMS' menu



## DEFINE : AUTO. LOG-OFF

Define the time after which, if no keys have been used on a keypad, the user is automatically logged-off and any incomplete operation aborted.




# DEFINE : AUTOMATIC SHUNT

---


This facility will present the user with the 'Clear Alarms' command following log-on if the users area is in an alarm condition. Three attempts at 'Clear Alarms' may then be made, whereupon, if point(s) are still off-normal shunts will be automatically applied. The shunts are conditional, viz. the points are configured as shunable; the shunt total is within limit; the user has zone access for the applicable zones.

---



# DEFINE : AUXILIARY POINT LOGGING

Defines the logging of Auxiliary Point activation to be when the system is set, when unset or for when both set and unset. Logging can be further controlled on a per-point basis (see **POINT INPUT : ADD**). Log entries are limited to once a minute.



# DEFINE : BANK/COMMERCIAL

---

There are differences in alarm clearing in the bank and commercial sectors. This option allows the system to be tailored for use in these two sectors. If the system is configured as a **commercial system**, performing the Clear Alarms function also unsets the affected zones. If the system is configured as a **bank system**, any prewarning conditions will automatically be cleared when the master logs-on, and all clears and mutes apply to the zones to which the user has access irrespective of the keypad access.

---

```

CONFIG MENU  ◆
..
. System
..
    
```

*<-- Select 'System'*

```

SYSTEM      ◆
..
. Misc Sys Param
..
    
```

*<-- Select 'Misc Sys Param'*

```

MISC SYS PARA 1◆
..
. Bank/ Commerce
..
    
```

*<-- Select 'Bank/ Commerce'*

```

MISC SYS PARAM
[premises type ]
installation
Change YES or NO
    
```

Specify type of installation.  
*Press '✓' to change the displayed status*  
*Press 'X' to retain the displayed status*

Returns to 'MISC SYS PARAMS' menu

```

[premises type ]
Commercial
Bank
    
```


# DEFINE : BATTERY TEST ON SET

This facility enables a battery test to be performed on each occasion that the system is set.

When 'battery test on set' is configured a test will be performed whenever a user performs a set at a keypad. This includes full and partial set, extended and temporary set, but excludes the resecuring of ATM bypass zones. The test will also be performed if a remote set is performed. If the test fails then the user setting or remote setting is prohibited. The test will be performed when an automatic set on schedule expiry occurs. In this case a failed test will not prevent the setting.

The process of battery testing causes a delay of approx. 25 seconds. Battery failure is declared when the measured battery voltage is below 11.7V.

A remote comms event can be configured to signal battery fail on set.




# DEFINE : BELL TEST TIMEOUT

---


Configure time-out for Bell Test. This determines when the Bell Test will terminate if the user fails to manually terminate the test.

---




# DEFINE : DURESS ALARM

Duress is the means by which a user can raise an alarm through the keypad when he logs-on. Therefore, if he is forced to provide entry for unauthorized personnel, he can raise an alarm without causing suspicion. The duress type may be configured as shown below. In addition, the user may be required to confirm the duress alarm by pressing '✓' to the configured duress confirmation prompt. The meaning of each duress type is described elsewhere and is not given here for security reasons.




# DEFINE : GROUP SHUNT

A Group Shunt allows a group of points to be shunted or unshunted in a single operation. If any of the points in the list fail to shunt/unshunt, then none of the points in the list will be shunted/unshunted. Such failures can be caused if the user has no access to the zone in which a point lies, or if the operation would cause an alarm.




## GROUP SHUNT (Add)



DEFINE : GROUP SHUNT (Add) continued overleaf




DEFINE : GROUP SHUNT (Add) continued




NOTES

- 'invalid number'                      Number selected is out-of-range.
- 'invalid point'                      The point number selected is not configured or the number has already been selected.

**GROUP SHUNT (Remove)**



**GROUP SHUNT (Modify)**



DEFINE : GROUP SHUNT continued overleaf

**GROUP SHUNT (View)**

```
GROUP SHUNT  ♦
..
. View
..
```

*<-- Select 'View'*


```
VIEW PT LIST G
ggggggggggggggggggggg
Pt III in list  ♦
iiiiiiiiiiiiiiiiiii
```

Display of points in Group Shunt .  
Use '▲' or '▼' to scroll point list.  
Press 'C' to continue


Returns to 'GROUP SHUNT' menu

# DEFINE : HS SHUNT

A High Security Shunt allows a group of points to be shunted with the cooperation of two users. The first user must enable the shunt for a number of days. The second user can then turn the shunt on and off until either the first user disables the shunt or the time specified by the first user expires.




## HS SHUNT (Add)



DEFINE : HS SHUNT (Add) continued overleaf


DEFINE : HS SHUNT (Add) continued




NOTES

- |                  |  |
|------------------|--|
| 'invalid number' | Number selected is out-of-range.   |
| 'invalid point'  | The point number selected is not configured or the number has already been selected. |

**HS SHUNT (Remove)**



**HS SHUNT (Modify)**



DEFINE : HS SHUNT continued overleaf

**HS SHUNT (View)**

```
HS SHUNT  ◆  
..  
. View  
..
```

*<-- Select 'View'*

```
VIEW PT LIST H  
hhhhhhhhhhhhhhhh  
Pt III in list  
iiiiiiiiiiiiiiii
```

Display of points in HS Shunt.  
*Use '▲' or '▼' to scroll point list.  
Press 'C' to continue*


Returns to 'HS SHUNT' menu

## DEFINE : INOVA MPC CARD IDS

---


The INOVA MPC card IDs enable the Windsor 700 to communicate with an INOVA PrintServer. The INOVA PrintServer is supplied with two Master Programming Cards (MPCs), each of which has an embossed 4 digit number. These two numbers are configured on the Windsor 700 using this option.

---



# DEFINE : INVALID PIN RESPONSE

The Invalid PIN Response allows the users to unset a specified zone(s) regardless of schedule restrictions by entering four consecutive invalid PINs. You should further specify which zones can be unset using this method (see **ZONES : ADD**).




## DEFINE : IP PORTS

---

When the Windsor 700 is to be connected to an IP network the 'well-known ports' require specification. Ports are used in the TCP to name the ends of logical connections which carry long term conversations. The 'well-known port' is used by the server process as the contact port. The two numbers required, for the ACU (Windsor 700) and the host (ie Guardstation) are configurable using this option.

---





## DEFINE : LIMIT TIME ADJUST

This facility allows the limit on the use of the 'Time Adjust' command to be changed from the default which is 1 adjustment every 28 days to a limit of 2 adjustments in 24 hours.

```
CONFIG MENU  ◆
..
. System
..
```

<-- Select 'System'

```
SYSTEM  ◆
..
. Misc Sys Param
..
```

<-- Select 'Misc Sys Param'

```
MISC SYS PARA 1 ◆
..
. More Params
..
```

<-- Select 'More Params'

```
MISC SYS PARA 2 ◆
..
. Limit Time Adj
..
```

<-- Select 'Limit Time Adj'

```
LIMIT TIME ADJ
to twice in 24H
[status      ]
Change?YES or NO
```

Specify restriction on Time Adjust command  
Press 'X' to retain displayed status  
Press '✓' to change displayed status

```
[status      ]
Disabled
Enabled
```

Returns to the 'MISC SYS PARA 2' menu.

# DEFINE : LINE FAULT OVERRIDE

---

This facility configures whether the Line Fault status of the communicator will affect the setting of the system. The effect of Line Fault is stored by this method in the configuration data and will therefore not be lost on power interruption. An alternative method of line fault override which does not affect the configuration is available - see SET:LINE FAULT OVERRIDE.

---

```
CONFIG MENU  ♦
..
. System
..
```

*<-- Select 'System'*

```
SYSTEM  ♦
..
. Misc Sys Param
..
```

*<-- Select 'Misc Sys Param'*

```
MISC SYS PARA 1♦
..
. Line Fault O/R
..
```

*<-- Select 'Line Fault O/R'*

```
MISC SYS PARAM
Line Fault
[status      ]
Change?YES or NO
```

Specify line fault action.  
*Press 'X' to retain displayed status*  
*Press '✓' to change displayed status*


```
[status      ]
Ignored on Set
Prevents Set
```

Returns to the 'MISC SYS PARA 1' menu.

## DEFINE : LOG-IN METHOD

This facility is used to determine the log-in method to be used on the system. When a method is specified as 'required' this means that the method is essential for a user to log-in. For example if the system has 'PIN required' then users must use a PIN, or if the system has 'PIN required' and 'Card required' then users must use a Card and also a PIN in order to log-in.


When a card is specified as required but the keypad is not configured to have a card reader then the PIN will be used to log-in at that keypad.



# DEFINE : MANAGED RESET

This facility is used in a system where full user reset is disabled. By configuring Managed Reset the user may reset alarms following confirmation from the Central Station.

When the user logs on following an alarm the alarm log is presented followed by the 'Managed Reset' display. This presents the user with a contact number for the Central Station and a code number. The user should contact the Central Station and quote the code number. In response the user will be given a 5-digit PIN code and should log-on with this PIN. This will reset the system.



## DEFINE : NEW PIN LOCKOUT

Once a PIN has been changed, it may not be changed again for a period of time known as the **new PIN lockout period**. This facility is provided to prevent PIN changing being used as a means to discover other PINs.

```
CONFIG MENU  ♦
..
. System
..
```

*<-- Select 'System'*

```
SYSTEM  ♦
..
. Def Time Param
..
```

*<-- Select 'Def Time Param'*

```
DEF TIME PARAMS ♦
..
. New PIN lockou
..
```

*<-- Select 'New PIN lockou'*

```
DEF TIME PARAMS
New PIN change
lockout- xx days
```

Specify the period during which a PIN may not be changed.

*Enter 2 digit number (days). Press '✓'*


Returns to 'DEF TIME PARAMS' menu

# DEFINE : PIN COMMAND FACILITY

---


The PIN Command facility allows the user to quickly set or unset a specified zone by entering the PIN, followed by the Clear key. They are then prompted for the number of the zone to set/unset.

---



## DEFINE : PIN EXPIRY

To reduce the likelihood of PINs being discovered, each PIN must be changed every so often. This period is known as the PIN expiry time. After a PIN has expired, the user is allowed to log-on one final time. If the warning message is ignored and the PIN not changed, the PIN is deleted and the user is not allowed to log-on again. If this happens the master can allocate a new PIN using the enable user facility.




# DEFINE : PREVENT AUTO SET ALARMS

---

The Prevent Auto Set Alarms facility controls whether an automatic set is performed if this would cause an alarm. This is required in order to satisfy the requirements of BS4737.

---





## DEFINE : RESET AUTHORITY

In a commercial system connected to a central station, it is usual to require a service visit after an alarm. By disabling full user reset it is possible to prevent the user setting the system until a serviceman has performed a reset.

```
CONFIG MENU  ◆
..
. System
..
```

<-- Select 'System'

```
SYSTEM      ◆
..
. Misc Sys Param
..
```

<-- Select 'Misc Sys Param'

```
MISC SYS PARA 1◆
..
. Rst Authority
..
```

<-- Select 'Rst Authority'

```
MISC SYS PARAM
Full user reset
[reset status ]
Change?YES or NO
```

Specify user reset capability.  
Press '✓' to change specified capability  
Press 'X' to retain specified capability

Returns to 'MISC SYS PARA 1' menu


```
[reset status ]
Enabled
Disabld
```

# DEFINE : SCHEDULE ALARM

---


The schedules not only define when a zone may be opened, but also when it must be set. If a zone is not set by the time the schedule closes, an alarm will be generated if this feature is enabled.

---



## DEFINE : TAMPER RESET

This facility configures whether users are restricted in that they are not able to reset a system after a tamper. The reset which is restricted is either a manual or an automatic reset function. If the 'Tamper reset' is disabled then the restriction applies.




# DEFINE : UI LOCKOUT

---

Define the number of consecutive failed PIN entries that are allowed before the keypad is rendered unusable and the period of time that the keypad will remain unusable.

---



# DEFINE : VERIFY ALARM

Define the verified alarm function. This function will cause a special Verified Alarm event to be reported only when two verifiable alarm states occur within a configured time of each other. This is designed to reduce false alarms. Verified alarms are restricted to Night Alarm points, 24 hour points, Bell tamper and Entry Route Timeout. The configured time between states for a verified event (known as the Verified Alarm Duration) is from 1 to 255 minutes. A duration of zero is used to configure a duration until the system or zone is next unset.

When using verified alarms the individual alarm events of the involved points may be suppressed. This applies to the following events:

24H	24Hr Alarm (in any zone)
24H1 - 24H8	24Hr Alarm in Zone Z
NA	Night Alarm (in any zone)
NA1 - NA8	Night Alarm in Zone Z
P001 - P250	Alarm on point I


The following events are used to report the verified alarm:

VAS	Verified Alarm (system)
VAL1 - VAL8	Verified Alarm in Zone Z

The VAS event is caused by two verifiable sensors in any part of the system going into alarm within the Verified Alarm Duration of each other. The VALn event is caused by two verifiable sensors which are both in zone n going into alarm within the Verified Alarm Duration of each other. The Bell tamper is considered to be in all zones.

The Clear Alarms command will clear any existing or potential verified alarms. (Note however that if more than one verifiable points remains off-normal when performing Clear Alarms then a verified alarm will be generated because the points are re-asserted). Unsetting the system will clear any existing or potential verified alarms.

Note: The Verified Alarm Duration is accurate to the minute. Therefore, for example, a duration of 1 minute will mean a verified alarm may be generated if the interval between verified alarms is 1 min 59 seconds.



DEFINE : VERIFY ALARM continued overleaf

DEFINE : VERIFY ALARM continued

MISC SYS PARA 3 ♦  
..  
. Verify Alarm  
..

<-- Select 'Verify Alarm'

VERIFY ALARM  
Duration  
xxx minutes

Specify duration.  
Enter 3 digit number. Press '✓'  
(Duration is in the range 001 to 255, or  
000 = Duration is until zone/system is unset)

VERIFY ALARM  
suppress origin  
[status ]  
Change?YES or NO

Specify whether the originating alarm events are  
to be communicated.  
Press '✓' to change the displayed status  
Press 'X' to retain the displayed status

[status ]  
Disabld  
Enabled

VERIFY ALARM  
verify bell  
tamper [status ]  
Change?YES or NO

Specify whether bell tamper is to be  
a verifiable alarm.  
Press '✓' to change the displayed status  
Press 'X' to retain the displayed status


[status ]  
Disabld  
Enabled

Returns to 'MISC SYS PARA 3' menu

## DEFINE : WORK LATE TYPE

Define if Late Working is to be fixed increment or a variable increment. For the fixed increment the extension time is defined.


Note: This defines whether the Early Opening type is fixed or variable as well.



# POINT INPUT : ISOLATE/DEISOLATE

Isolating a detector causes off-normal and tamper states to be ignored. This is useful when you require a system to set despite point(s) being in tamper or at fault. The point must be configured as isolatable for this procedure and there is a configured limit to the number of isolated or soaked points in a zone.

## ISOLATE




### NOTES

- |                             |   |
|-----------------------------|---|
| 'Isolate point' not in menu | There are no isolatable points.                                       |
| 'invalid number'            | The number selected is out-of-range.                                  |
| 'invalid point'             | The point number selected can not be isolated.                        |
| 'Pt is isolated'            | The point selected is already isolated.                               |
| 'Cannot modify pt'          | The point is configured to be not isolatable.                         |
| 'limit exceeded'            | The zone already has the maximum permitted number of isolated points. |
| 'Pt is in soak'             | A point which is already in soak test cannot be isolated.             |


POINT INPUT : ISOLATE/DEISOLATE continued overleaf





NOTES

'Deisolate pt' not in menu      There are no points isolated.



# RESET : NET RESTART

---

This facility restarts the Data Gathering and User Interface Networks.

---

```
RESET AND MUTE ♦  
..  
. Net restart  
..
```

*<-- Select 'Net restart'*

Returns to the 'FUNCTION SELECT' menu.

This facility performs the following

1. Remove all shunts and isolates.
2. Clear all latched point inputs and outputs.
3. Restart the Data Gathering network and the User Interface network.

On completion the system is left unset.

---

```
RESET AND MUTE ♦
..
. Service Reset
..
```

<-- *Select 'Service Reset'*

Returns to the 'FUNCTION SELECT' menu.

## NOTES

---

```
RESET FAILED
SYSTEM STILL
IN ALARM
Press CLEAR
```

Check the system status to see what is still in alarm.

# SERVICEMAN : COMMISSION REMOTE COMMS

Windsor 700 is able to talk to the GuardStation remote controller. This allows a central user to monitor and manage many systems. Windsor 700 can also be configured to report alarms to the GuardStation. Having configured the system and set up GuardStation, the remote link must be commissioned. This allows the GuardStation to pass essential information to the Windsor 700 which will be required for future conversations.


Having commissioned remote communications, the information passed to the Windsor 700 is stored in the same memory as the configuration. The act of decommissioning deletes this information. There are several reasons for wanting to do this:

- (i) the GuardStation is being taken out of service and the Windsor 700 must no longer communicate with it;
- (ii) the network address or telephone number of the GuardStation has changed so the remote communications must be recommissioned;
- (iii) the GuardStation has been replaced by another without copying the database from the old to the new;
- (iv) the configuration has been copied from another Windsor 700, in this case all sites must be decommissioned before any is recommissioned — failure to do this will result in the Windsor 700s having the same identity; and
- (v) remote communications was configured with encryption disabled but encryption is now required - the encryption keys form part of the information passed during commissioning.

Note that decommissioning does not communicate with the GuardStation, therefore a similar procedure (called "deinitialising" must be carried out there.


Note also that encryption for a given site may be enabled or disabled using the Remote Comms option Encryption.

## COMMISSION REMOTE COMMS




SERVICEMAN : COMMISSION REMOTE COMMS continued overleaf


SERVICEMAN : COMMISSION REMOTE COMMS continued



NOTES



**DECOMMISSION REMOTE COMMS**



SERVICEMAN : COMMISSION REMOTE COMMS continued overleaf

---

SERVICEMAN : COMMISSION REMOTE COMMS continued

NOTES

Remote communications not commissioned Press CLEAR
---

There are no Remote Sites commissioned

*Press 'C' to return to menu*

# SERVICEMAN : LOG-ON

To log-on as a serviceman your access must first be established by a user log-on. This will be a customer's representative with an authority level of Master, Manager or User 1.

During initial commissioning, or when a system fault has occurred, there are no user PINs defined. To allow access a default user PIN (1111) is enabled. Use the default user PIN to log-on, select the 'Enable Service' option as shown below and then use the default service PIN (974072) to gain access in the service role.

NOTE: The service PIN changes with the date. The default service Pin is based on the default date. Therefore setting the date to the current date will disable the default service PIN. After a configuration has been downloaded from the PROM Pack the default service PIN will change in accordance with the configuration details.

The service PIN of the day is normally supplied by the Central Station.



This follows USER log-on:

```
FUNCTION SELECT ♦
. . .
. PIN/User menu
. . .
```

*<-- Select 'PIN Codes'*

```
PIN/ USER MENU ♦
. . .
. Enable service
. . .
```

*<-- Select 'Enable service'*


```
ENTER SERVICE
AUTHORISING CODE
:-
```

*Select your PIN number then press '✓'  
(For security each digit will appear as an  
asterisk)*

# SERVICEMAN : PANEL ACCESS

---

If the user who is logged-on does not press any key for a configured time (see **CONFIGURE : AUTO. LOG-OFF**), that user is logged-off. The serviceman may gain extra time by selecting panel access, this increases the log-off period by a configured multiple. If even more time is needed, the panel cover can be removed. Provided the serviceman is logged-on when the cover is removed, no tamper will occur. Once the cover is removed the serviceman will not be automatically logged-off until it is replaced.





# SERVICEMAN : REMOTE COMMS (ENCRYPTION)

This facility configures the system whether to encrypt the data communication with a Remote Site. The encryption keys are supplied at the time of commissioning but whether the encryption is used or not depends on the configuration.



```
FUNCTION SELECT ♦
..
. PIN/User menu
..
```

*<-- Select 'PIN/User menu'*

```
PIN/ USER MENU ♦
..
. Comms encrypt
..
```

*<-- Select 'Comms encrypt'*

```
REMOTE SITE
rrrrrrrrrrrrrrrrrr
Encrypt [status]
Change?YES or NO
```

Select whether encryption is applicable.  
Use '▲' or '▼' to scroll required Remote Site to line 2.  
Press '✓' to change displayed encryption status  
Press 'X' to retain displayed encryption status  
Press 'C' to return to PIN/USER menu.

```
[status
disabled
enabled
```

# SERVICEMAN : REMOTE CONFIGURATION

---

A GuardStation may be used to modify the Windsor 700 configuration. The existing configuration indicates which GuardStations (if any) may do this. Remote configuration may be permitted, not permitted, or permitted with local permission. If this last option is used, the serviceman must grant permission using the procedure described here. Once the procedure is complete the serviceman is logged-off. The GuardStation then has 30 minutes in which to commence the download. Permission is rescinded following the download or after a service reset. The GuardStation will be unable to perform a download if any local user is logged-on or if any zone is set.


Note that the GuardStation may upload the configuration without local permission.

**Configuration download** Act of sending a new configuration to the Windsor 700.

**Configuration upload** Act of reading the configuration from the Windsor 700, possibly for modification and future download.

□

---



This facility allows setting when points are off-normal or a system defect is present by presenting the off-normal points to be shunted; the shunt limits still apply.



```
SET FAILED
..
. Force set
..
```

Follows failure of conventional set operation:

*<-- Select 'Force set'*

```
FORCE SET SHUNT
Press YES or NO
III iiiiiiiiiiiiii
off-normal
```

**If points off-normal:**  
*Press '✓' to shunt point*

```
FORCE SET ALLOW
Press YES or NO
[defect      ]
```

**If system defect:**  
*Press '✓' to override*

```
[defect      ]
Battery Low
```

The set operation is re-tried automatically

## NOTES

```
CALL SECURITY
Shunt limit
exceeded
```


The point is configured as non-shunable or the total shunt limit is exceeded.

# SET : LINE FAULT OVERRIDE

This facility configures the Line Fault Override status of the system. When Line Fault Override is in operation then a user may set the system irrespective of the Line Fault status of the communicator.

The Line Fault Override status established by the method below is not retained in the non-volatile configuration memory and will therefore be lost if the Control Unit is de-powered. Also the existing Line Fault Override will be cleared if a configuration is entered. If it is required to place the Line Fault Override status in the non-volatile configuration memory see DEFINE : LINE FAULT OVERRIDE.


## LINE FAULT OVERRIDE (Enable)



### NOTES

'LF override' not in menu      Line Fault Override is already configured

## LINE FAULT OVERRIDE (Disable)



### NOTES


'Clear LF O/R' not in menu      Line Fault Override is not configured

## STATUS : DIAGNOSTIC LOG

---

Display the Diagnostic Log. This is intended for diagnostic purposes by Guardall. No explanation of this log is given in this manual.


---



# STATUS : ISOLATE LIST

Display list of isolated points (see **POINT INPUT : ISOLATE/DEISOLATE** in this document, and **POINT INPUT : SHUNT/UNSHUNT** in the User Manual).

□



## NOTES

'Shunt/Isolates' not in menu No isolatable points


# STATUS : POINT INPUT (CALIBRATE)

This facility displays the current state of a point input and allows the point to be calibrated.


The point input circuitry in a concentrator and the connected detector form a resistor network. The state of the point input depends upon the voltage across this network. The point status facility displays the deviation of the present voltage from normal. Typical deviations for each of the three basic concentrators are:-

No End-of-Line:           Normal = 0%, Alarm = -32%, Tamper(device) = +22%  
 End-of-Line:               Normal = 0%, Alarm = -19%, Tamper(device) = -38%  
 High-Security:            Normal = 0%, Alarm = -22%, Tamper(device) = -44%

If the status display is showing a small deviation when the point input is normal, it is possible to recalibrate the point. This may be required if contacts are dirty, the circuit wiring has a small resistance, or to accommodate end-of-line resistor tolerances. Calibration is particularly important for the High-Security Concentrator where the state thresholds are close together. Calibration is not allowed if the present voltage deviates from the nominal normal voltage by more than 6% (the point status is not-normal or marginal), this prevents faulty equipment being calibrated to appear normal.



## NOTES




# STATUS : PRINT CONFIGURATION

---

This facility prints the configuration data of the Windsor 700 system.


The printout is in a compact format employing abbreviations to describe various functions. The abbreviations are in most cases self-explanatory. The meaning of some of the abbreviations is given opposite.

---




---

## PRINT CONFIGURATION (Start)



---

## PRINT CONFIGURATION (Stop)





---

## PRINT CONFIGURATION ABBREVIATIONS

### FORM A - POINT INPUTS

#### FLAGS

S Shutable  
I Isolatable  
E Exemptable  
L Log Signal Point Activations  
V Verifiable  
A Auto-shutable

#### ATTRIBUTE

BUF Buffer point  
DBF Double Buffer point  
SSM Safe Shunt Master  
SSS Safe Shunt Slave  
BGP Break Glass Point/Call Point

#### LOGICAL FUNCTION

ANDO Outputs anded  
ANDI Inputs anded  
ORO Outputs ored  
ORI Inputs ored

### FORM B - ZONES

#### TYPE

NORM Normal zone  
ATM ATM zone

#### FLAGS

ST Zone is set  
TA Timer Alarm on schedule expiry  
AS Auto. set on schedule expiry  
EU Emergency Unset applicable  
AU Auto. unset on schedule open window  
MS Monitor shunt facility  
RU Restricted unset during schedule open window  
MC Manual operation plus automatic set/unset  
AT ATM Control zone  
SU Shown on set/unset menu  
2U Dual PIN access  
SE Secure zone  
RC Restricted Command access

### FORM E - ENTRY/EXIT ROUTES

#### ATTRIBUTES

ENT Entry point  
EXT Exit point  
IN Entry route point  
OUT Exit route point  
IBF Entry route buffer point  
OBF Exit route buffer point

### FORM F - KEYPADS

#### TYPE

UIC Normal  
MIM Mimic  
PNT Printer

---

PRINT CONFIGURATION ABBREVIATIONS (continued)

FLAGS

KSW    Keyswitch  
ENS    Enabled when controllable zones set  
DSU    Disabled if controllable zone(s) unset  
ATM  
HNG    Removable  
DAT  
EKY  
CHK  
LOB    Card reader attached for ATM lobby access  
CRD    Card reader attached for login  
SUN    Display set/unset menu

FORM G - CONCENTRATORS

TYPE

CDN    Canadian  
EOL    End-of-line  
HSC    High-security  
MON    Monarch  
NEOL   No end-of-line

FORM H - POINT OUTPUTS

CONTROL FLAGS

MOM    Momentary  
LTH    Latched  
NOF    Mornally off  
TRG    Triggered  
PNT    Point gated  
?      AND Point inputs anded  
?      CNT    Linked point input to be counted  
?  
?  
?  
?  
ATM    ATM zone bypassed  
WTS    Walk test  
DTS    Detector test  
PTS    PA test  
SET    Set zones  
UNS    Unset zones  
EXT    Exiting zones  
ENT    Entering zones  
CMP    Compromised zones  
PWD    Prewarning  
SND    Sounders  
STB    Strobes  
ALM    Alarms  
PAA    PA alarms  
TAM    Tamperers  
ARM    Armed zones  
SDC    Schedule closing  
LNF    Line Fault  
MNF    Mains Fail  
ADF    Auto Detector test fail  
ZIS    Zone is settable

# TEST : MONITOR

The monitor test when started records henceforth any changes of state that the detector makes. The changes may then be reviewed by using the view facility in the test.

Monitor test does not affect the operation of the detector in the alarm system.



```
FUNCTION SELECT◆  
..  
. Test  
..
```

*<-- Select 'Test'*

```
TEST MENU ◆  
..  
. Other tests  
..
```

*<-- Select 'Other tests'*

## MONITOR (Start)

```
POINT MON. TEST◆  
..  
. Start test  
..
```

*<-- Select 'Start test'*

The detector states will now be recorded.  
The test may be run for as long as required.  
Returns to POINT MON. TEST full menu

## MONITOR (View)

```
POINT MON. TEST◆  
..  
. View test  
..
```

*<-- Select 'View test'*

```
POINT MON. TEST  
Select point for  
view:- xxx
```

Specify detector point number.  
Enter 3 digit number. Press '✓'

```
VIEW POINT III  
iiiiiiiiiiiiiiiiii  
[point status ]  
[test log     ]
```

Display of detector status  
Use '▲' or '▼' to scroll list  
Press 'C' to return to menu

[point status ]	[test log     ]
point normal	no changes
point off-normal	was normal
point in tamper	was off-normal
	was in tamper
	all states used

TEST : MONITOR continued overleaf

---

TEST : MONITOR continued

NOTES

'invalid number'	The number selected is out-of-range.
'invalid point'	The number selected is not configured or the point may not be placed in monitor.

---

**MONITOR (Stop)**

POINT MON. TEST◆ .. . Stop test ..
---

<-- *Select 'Stop test'*

Returns to POINT MON. TEST menu


The soak test facility is used to assess the performance of detectors following repair or installation.

A detector under soak test does not participate in the alarm system so off-normal and tamper conditions do not generate alarms. However, in order to provide diagnostic information every change of state is entered in the historic log. The log entries are:


```
Point going normal :      status = 0
Point going off-normal :  status = 1
Point going into tamper : status = 3
```

There is a configured limit to the number of isolated or soaked points in a zone.

The soak test may be started at any time in an unset zone. A detector cannot be removed from soak if so doing would cause an alarm.



## SOAK (Start)



## NOTES

- |                  |   |
|------------------|---|
| 'invalid number' | The number is out-of-range.   |
| 'invalid point'  | The point number is not configured or the point may not be placed in soak test. |
| 'Pt is in soak'  | The selected point is already in soak test.                                     |
| 'limit exceeded' | The zone isolate limit is exceeded.   |

TEST : SOAK continued overleaf

```
SOAK TEST
..
. Remove point
..
```

*<-- Select 'Remove point'*

```
REMOVE PT. III
iiiiiiiiiiiiiiiiii
Press YES or NO
```

Display of point(s) in soak.  
*Press '✓' to remove soak*  
*Press 'X' to retain soak*  
*Press 'C' to return to menu*  
Returns to SOAK TEST menu automatically if all  
soak points are removed.

NOTES

```
REMOVE SOAK


** NO POINTS **
AVAILABLE
```

There are no points in soak test.


This facility allows the UI to be tested while the system is operational.

While in this mode the viewing angle of the LCD may be adjusted for optimum display clarity. For this, the keypad must be removed from the case base. Note that this will not cause a tamper - this is inhibited while the keypad is in self-test. After detaching the keypad from its base locate the potentiometer VR1.

Use a small screwdriver to adjust VR1. The extremes of the display are a blank display and a display comprising black rectangles (the background). The optimum position of VR1 will give a display in which the displayed characters are clearly visible and the rectangles of the background have virtually disappeared. When carrying out the adjustment hold the keypad in a position as near as possible to its normal operating position to ensure that the ambient lighting conditions and viewing angle are realistic.



*<-- Press '2' '5' '8' '0' simultaneously*




*Check display*

*For 5 secs:*

*Display of pixel pattern 1*

*For 2 secs:*


*Buzzer sounds & all LEDs light*



*Check display*


*For 5 secs:*

*Display of pixel pattern 2*



*Test keypad*

*Key-press should change 0 to 1 corresponding to the order 123456789▲0X▼C✓T (T = tamper). Pressing '0' should also light all LEDs and buzzer sounds for 2 secs.*



*<-- Press '2' '5' '8' '0' simultaneously  
Returns to operational mode*

---

NOTES