

PB Series

Service Manual

LAST Rev. NO : 2

LAST Rev. Date : 2009. 06. 10

Table of Contents

1. Proper Operation / Introduction	3
1.1. Preface.....	3
1.2. Precaution.....	3
2. Classification	4
2.1. Overall View.....	4
2.2. Display Pad (Key Pad).....	4
2.2.1. PB(Basic).....	4
2.2.2. PB(Full Option).....	4
오류! 책갈피가 정의되어 있지 않습니다.	
3. Getting Started	5
3.1. Sealing Method.....	5
4. Calibration Mode	6
4.1. General Calibration	6
4.1.1. C4 Setting	7
4.1.1.1. C4-1 Setting.....	7
4.1.2. SPAN Calibration Setting (C-3)	8
4.1.3. Gravity Constant Value Setting (C-9)	8
4.1.4. Calibration factor Setting (C-10).....	8
4.1.6. Percent Calibration (C-7).....	9
4.1.7. Battery Calibration (C-8)	10
5. Servicing & Parts Replacement	10
5.1. Trouble Shooting.....	10
5.2. Error Message.....	11
6. Options Installing.....	11
6.1. Serial Interface(RS-232C).....	11
7. Update.....	12
7.1. ROM Download Method	12
8. Exploded Views & Parts List	15
8.1. Exploded View	15
8.2. Loadcell Ass'y.....	17
8.3. Main PCB Ass'y (Top)	18
8.4. Main PCB Ass'y (Bottom).....	18
8.5. Display Ass'y.....	18
오류! 책갈피가 정의되어 있지 않습니다.	
8.6. Scale Ass'y.....	18
오류! 책갈피가 정의되어 있지 않습니다.	
9.Revision	20

1. Proper Operation / Introduction

1.1. Preface

Thank you for purchasing of our CAS scale.

This scale has been designed with CAS reliability, under rigid quality control and with outstanding performance.

WE hope that your departments enjoy with high quality of CAS product.

This manual will help you with proper operations and care of the PB(Portable Bench).

Please keep it handy for the future references.


1.2. Precaution

- Make sure that you plug your scale into the proper power outlet.
- Place the scale on a flat and stable surface.
- Plug into a power outlet 30 minutes before operations.
- Keep the scale away from strong EMI noises may cause incorrect weight readings.
- This scale must be installed in a dry and liquid free environment.
- Do not subject the scale to sudden temperature changes.
- Do not subject the platter to sudden shocks.
- If the scale is not properly level, please adjust the 4 legs at the bottom of the scale (turn legs clockwise or counterclockwise) so as to center the bubble of the leveling gauge inside the indicated circle.

Service Manual – PB Series REV NO : 2

2. Classification

2.1. Overall View



2.2. Display Pad (Key Pad)

2.2.1. PB(Basic)





Service Manual – PB Series REV NO : 2

Key	Function
ZERO (-O-) [Set]	To set zero point To do [SET] key in the SETUP mode.
TARE	To input or cancel the tare (the weight of container).
HOLD	To make the weight of item stable. This weight is average value.
POWER	To turn on or off.

3. Getting Started

3.1. Sealing Method

1	2	3	4	5	6	7	8																																								
DATE	PART NO.	REV	SYM	REVISIONS	8	7	8																																								
				CONTENTS																																											
				DRAWN	CHECKED	APPROVED																																									
 																																															
																																															
<table border="1" style="width: 100%; border-collapse: collapse;"> <tr> <td style="width: 25%;">TOLERANCES 10:1000 OTHERWISE SPECIFIED</td> <td style="width: 25%;">NAME OR TITLE PB SEALING METHOD</td> <td style="width: 50%;">CAS CORPORATION 119 GANAP-RI GWANGJUN-MYON YANGGU-SI GYEONGGI-DO, REP OF KOREA</td> </tr> <tr> <td>ANGULAR ± ORD.</td> <td colspan="2">MATERIAL</td> </tr> <tr> <td>DECIMAL ± ORD.</td> <td colspan="2">END FINISH</td> </tr> <tr> <td>OTTV/SET</td> <td colspan="2">FIRST USED IN ASSEMBLY</td> </tr> <tr> <td>CONTRACT OR CUSTOMER NO. 1</td> <td colspan="2">FIRST MADE FOR WORLD WIDE</td> </tr> <tr> <td>DRAWN</td> <td>CHECKED</td> <td>APPROVED</td> </tr> <tr> <td colspan="2" style="text-align: center;"><i>070626</i></td> <td>1:3</td> </tr> <tr> <td colspan="2" style="text-align: center;">2009년 4월 23일 제작자 김우호 300819</td> <td>0</td> </tr> <tr> <td colspan="8" style="text-align: center;">DO NOT SCALE DRAWING DIMENSIONS ARE IN MILLIMETER</td> </tr> <tr> <td colspan="8" style="text-align: center;">SCALE PART NO. REV.</td> </tr> </table>								TOLERANCES 10:1000 OTHERWISE SPECIFIED	NAME OR TITLE PB SEALING METHOD	CAS CORPORATION 119 GANAP-RI GWANGJUN-MYON YANGGU-SI GYEONGGI-DO, REP OF KOREA	ANGULAR ± ORD.	MATERIAL		DECIMAL ± ORD.	END FINISH		OTTV/SET	FIRST USED IN ASSEMBLY		CONTRACT OR CUSTOMER NO. 1	FIRST MADE FOR WORLD WIDE		DRAWN	CHECKED	APPROVED	<i>070626</i>		1:3	2009년 4월 23일 제작자 김우호 300819		0	DO NOT SCALE DRAWING DIMENSIONS ARE IN MILLIMETER								SCALE PART NO. REV.							
TOLERANCES 10:1000 OTHERWISE SPECIFIED	NAME OR TITLE PB SEALING METHOD	CAS CORPORATION 119 GANAP-RI GWANGJUN-MYON YANGGU-SI GYEONGGI-DO, REP OF KOREA																																													
ANGULAR ± ORD.	MATERIAL																																														
DECIMAL ± ORD.	END FINISH																																														
OTTV/SET	FIRST USED IN ASSEMBLY																																														
CONTRACT OR CUSTOMER NO. 1	FIRST MADE FOR WORLD WIDE																																														
DRAWN	CHECKED	APPROVED																																													
<i>070626</i>		1:3																																													
2009년 4월 23일 제작자 김우호 300819		0																																													
DO NOT SCALE DRAWING DIMENSIONS ARE IN MILLIMETER																																															
SCALE PART NO. REV.																																															
1	2	3	4	5	6	7	8																																								
POLD	POLD	POLD	POLD	POLD	POLD	POLD	POLD																																								

4. Calibration Mode

4.1. General Calibration

Pressing and holding calibration switch press [POWER] key to go to calibration mode.

User can move to other mode by using [ZERO] key in the calibration mode.

User also moves to other sub-modes for each mode by using [TARE] key.

Please simply follow below procedure to move to other mode.

- (1) Calibration Mode: Pressing and holding “Calibration Switch” press [POWER] key.
- (2) It displays “CAL-0” after “CAL”, and it blinks the version of scale three times.
- (3) Selecting menu: press [TARE].
- (4) ENTER(Setting) : [TARE] key

MODE	Function
CAL 1	Display normalized AD
CAL 2	Display Keypad infomation-
CAL 3	Weight Setting Mode “UnLoad” → [TARE] → “MIDD” → [TARE] after loading for 1/3 weight → “FULL” → [TARE] after loading for Full weight → “MIDD” → [TARE] after loading for 1/3 weight → “END”
CAL 4	Option Setting (Refer to Table 1)
CAL 5	Display filtered Raw AD
CAL 7	% Calibration
CAL 8	Battery calibration
CAL 9	Gravity constant
CAL 10	Set calibration factor “Unit” → [TARE] → select 0, 1 (0:kg, 1: lb) → [TARE] “CAPA” → [TARE] → select capacity → [TARE] “MCAPA” → [TARE] → select mid-capacity → [TARE] “W-dP” → [TARE] → Select Decimal Point → [TARE] “1 d” → [TARE] → Select division → [TARE] “Dual” → [TARE] → Enable dual interval (0:disable, 1:enable) → [TARE] “tare” → [TARE] → Enable custom tare (0:disable, 1:enable) → [TARE]
CAL 11	Set nation(00 : OIML , 01 : NTEP , 02: KOREA)

Service Manual – PB Series REV NO : 2

4.1.1. C4 Setting

4.1.1.1. C4-1 Setting

BIT 6~7	Initial Zero range	3	5%
		2	10%
		1	3%
		0	2%
BIT5	Last digit enable	0	Disable
		1	Enable
BIT4	Key zero percent	0	±3% key zero percent
		1	±2% key zero percent
BIT 2~3	Successive tare	3	(+), (-) All Direction successive Tare
		2	(+) Direction successive Tare
		1	(-) Direction successive Tare
		0	One Time tare
BIT0~1	Zero mark type	0	Gross zero indication
		1	Net zero indication
		2	Both(gross and net) zero indication

4.1.1.2. C4-3 Setting

BIT7	Dot Type	0	"." dot
		1	"," comma
BIT6	Use Preset tare (PB can't use)	0	Don't use
		1	Use
BIT5	Use Back light	0	Don't use
		1	Use
BIT4	Use Head message (PB can't use)	0	Don't use
		1	Use
BIT3	Use gram	0	Don't use
		1	Use
BIT2	Use oz	0	Don't use
		1	Use
BIT1	Use lb	0	Don't use
		1	Use
BIT0	Use Kg	0	Don't use
		1	Use

4.1.2. SPAN Calibration Setting (C-3)

- (1) Pressing and holding “Calibration Switch” press [POWER] key.

After “CAL” message blinks three times and shows the version of scale, it displays “CAL 1” message.

- (2) Press [ZERO] to display “CAL-3”.
- (3) Press [TARE] key and then it displays “zero ” message.
- (4) Press [TARE] key and then it displays “midup” message
- (5) Load middle weight (ex:1/3 full capacity) on the platform
- (6) Press [TARE] key and then it displays “span ” message
- (7) Load full weight on the platform
- (8) Press [TARE] key and then it displays “middn” message
- (9) Load middle weight (ex:1/3 full capacity) on the platform
- (10) Press [TARE] key and then it display “CAL 3” message

4.1.3. Gravity Constant Value Setting (C-9)

Current gravitational Acceleration value is set to 9.7994 m/s².

- (11) Pressing and holding “Calibration Switch” press [POWER] key.

After “CAL” message blinks three times and shows the version of scale, it displays “CAL-1” message.

- (12) Press [ZERO] to display “C-9”.
- (13) Press [TARE] key, and then “ G-1“ message and “9.7994” will be shown. The first digit,”9” will blink.
- (14) Input a gravitational acceleration value by using [ZERO] key.
- (15) Press [TARE] key, and then “G-2“ message blinks.”9.7994“ will be shown. The first digit,”9” will blink.
- (16) Input a gravitational acceleration value by using [ZERO] key.
- (17) Press [TARE] key to save the gravitational acceleration value, and “C-9 ” message will be shown.

4.1.4. Calibration factor Setting (C-10)

- (1) Pressing and holding “Calibration Switch” press [POWER] key.

- (2) After “CAL” message blinks three times and shows the version of scale, it displays “CAL-1” message.

- (3) Press [ZERO] to display “C-10”.

- (4) Press [TARE] key, and then “UNIT ” message and “0” will be shown. The first digit,”0” will blink. It means calibration unit is “kg” (0 : kg, 1 : lb)

- (5) Input a calibration unit by using [ZERO] key.

- (6) Press [TARE] key, and then “CAPA” message blinks.”0015“ will be shown. The first digit,”0” will blink. It means a full-capability is “15 (calibration unit, kg or lb)”

- (7) Input a capability by using [ZERO] key.

- (8) Press [TARE] key, and then "MCAPA" message blinks."0005" will be shown. The first digit,"0" will blink. It means a mid-capability is "05 (calibration unit, kg or lb)"
- (9) Input a capability by using [ZERO] key.
- (10)Press [TARE] key, and then "W-dP " message blinks."3" will be shown. The first digit,"3" will blink. It means a weight decimal point is "3 (will display 0.000)"
- (11)Input a weight decimal point by using [ZERO] key.
- (12) Press [TARE] key, and then "1d " message blinks."0.005" will be shown. The third digit,"0" will blink. It means a division is "0.005 (calibration unit, kg or lb)"
- (13) Input a division by using [ZERO] key.
- (14) Press [TARE] key, and then "dual " message blinks."1" will be shown. The third digit,"1" will blink. It means a dual interval is disable. (0 : disable, 1 : enable)"
- (15) Input a dual interval enable by using [ZERO] key.
- (16) Press [TARE] key to save the calibration factor, and " C- 10 " message will be shown.

- CAL METHOD (SPAN ,%)
- PROGRESSED TEST FACTS IN CAL MODE
- SETTING IS RELATED TO KEY VALUE
- SETTING FACTS IN THE OTHER CAL MODES (Gravity setting)
- SETTING FACTS IN SET MODE: INCLUDE A FUNCTION

4.1.5. Displaying Real A/D Value (C-5)

Display Raw AD

4.1.6. Percent Calibration (C-7)

- (1) Pressing and holding "Calibration Switch" press [POWER] key.
After "CAL" message blinks three times and shows the version of scale, it displays "CAL 1" message.
- (2) Press [ZERO] to display "CAL-7".
- (3) Press [TARE] key and then it displays "per 0 " message. Select the percent value using the [numeric] key. You can choose 10~90 percent. (Last digit of percent must be 0.)
- (4) Press [TARE] key and then it displays "zero" message
- (5) Press [TARE] key and then it displays "pspan " message
- (6) Load choice percentage weight of full weight on the platform
- (7) Press [TARE] key and then it displays "CAL 7" message

4.1.7. Battery Calibration (C-8)

(1) Pressing and holding “Calibration Switch” press [POWER] key.

After “CAL” message blinks three times and shows the version of scale, it displays “CAL 1” message.

(2) Press [ZERO] to display “CAL-8”.

(3) Press [TARE] key and then it displays voltage of battery.

(4) Change the jumper-pin of main PCB, ‘BAT’ to ‘+5V’.

(5) Press [ZERO] key two times and then Press [-] key two times.

And then it display ‘500’

(6) Change the jumper-pin of main PCB, ‘+5V’ to ‘BAT’.

(7) You can see the calibrated voltage of battery.

5. Servicing & Parts Replacement

5.1. Trouble Shooting


SYMPTOM	PROBABLE CAUSE	REMEDY
ERROR 0 (unstable error)	1)The Scale is not put on the flat part. 2)A Vibration or wind is exist around The Scale.	- Check a foot. (Footh are must all touched in flat part.) - Check a PCB's field ground. (Field ground is must connected to platform.)
ERROR 1(initial zero)	1)The Scale is not operate Calibration 2)Cable is not connected between Loadcell and PCB.	-Operate Calibration. -Check a L/C and PCB. (L/C and PCB are must connected.)
Batt → Error 0	1)ONEMODULE(A/D Converter) is damaged. 2)The Scale is not operate Battery Calibration	-Check a battery voltage(C-8) and then operate a battery calibration. -Check the A/D value. (C-1) If place a weight, A/D value have to changed.
NOT OPERATION(POWER OFF)	1)Power ON/OFF Key is damaged. 2) Battery discharge or not connected. 3)Fuse is down.(Open) 4)Power cable is down.	-Check a output voltage, holding a Tact S/W. -Check a battery connection and Battery voltage. -Check a fuse connection

5.2. Error Message


오류 종류(ERR ?)	원인(REASONS)	(SOLUTION)
"Err 0"	The "Err 0" occurs when scale is not stable.	Remove unstable facts.
"Err 1"	The "Err 1" occurs when a current zero point has shifted from the last span calibration.	Please call your CAS dealer.
"Err 2"	The "Err 2" is not a real error. Only it prompts return CAL switch to the normal position.	Please call your CAS dealer.
"Err 3"	The "Err 3" is an overload error.	Please remove the weight.
"Err 9"	The "Err 9" is no weight error. When scale is in counting mode, you must load the weight. If you have no weight on your scale, you can see this error message.	Please load the weight on your tray.
"Err 11"	The "Err 11" means a writing error of the internal nonvolatile memory. To recognize this error, be sure to check the voltage on the circuit and do calibration procedures.	If it still has "Err 11", replace the digital module.
"Err 12"	The "Err 12" warns that the scale has lost the parameters for weighing regulations or has lost the factors for a digital span calculation.	Enter each condition codes again. Please try a span calibration again if still not fixed.
"Err 14"	The "Err 14" means calibration range is not correct.	Please call your CAS dealer.

6. Options Installing

6.1. Serial Interface(RS-232C)




6.2. Serial Interface(RS-232C)



7. Update


7.1. ROM Download Method

(1) Connect a RS-232C Cable, between the scale and PC and then excute a O/M Downloader program.




Service Manual – PB Series REV NO : 2

(2) Check a ‘Communication port’ and click the ‘Init. Erase Command’. And then Click the ‘Start Download’, Communication port will be “Ready” status.




(3) Push a ‘Open ROM File’ button and then open the ROM File.



Service Manual – PB Series REV NO : 2


(4) If click the ‘Start Download’ holding a power ON/OFF key, You will see ROM Downloading display and then ROM download will be finished.



8. Exploded Views & Parts List

8.1. Exploded View


8.1.1. Display Ass'y



No.	NUMBER	REV.	PART NAME	SPEC	MATERIAL	Q'TY	VENDOR
1	2200-A00-0003	0	KEY BOARD PAD	167*79*0.2t	PC 0.2t	1	
2	2010-A00-0034	0	DISPLAY FILTER	135.5*46.5*1t	투명 PC 1t	1	
3	9020-A00-0078	0	CAPA STICKER	46.7x16.6x0.1t		1	
4	2000-A00-0311	0	DISPLAY UPPER	188*90*26.5	ABS 780 (KUMHO)	1	
5	2000-A00-0312	0	DISPLAY LOWER	188*90	ABS 780(KUMHO)	1	
6	1590-A00-0043	0	BATTERY SPRING A	ø1*20*21	SWC	2	
7	1590-A00-0044	0	BATTERY SPRING B	ø1*20*21	SWC	2	
8	1030-A00-0203	0	SEALING PLATE	35.2*26*1t	SPC	1	
9	1265-A00-0001	0	BOLT-SEALING	M3*5 (활동) BI	활동	2	
10	9900-A00-0001	0	봉인날	수출용	pb	1	
11	2000-A00-0313	0	BATTERY COVER	111.3*63.8*14.5	ABS 780(KUMHO)	1	
12	1261-A00-0004	0	BATTERY COVER BOLT	M4*0.7*8.5(SUS)TP	SUS	1	
13	1561-MSU-0300	0	E-RING	Φ3*Φ7*0.6	SUS	1	
14	1512-MSU-0410	0	SCREW TAPPING (PH)-2	M4*10	SUS	9	
15	1070-A00-0005	0	MAGNET	ø6*5(N30)	MAGNET	4	자구마그넷
16	7840-W00-0303	C	CONNECTOR WIRE	3P*220*303(CORE)		1	
17		0	MAIN PCB ASS'Y			1	


Service Manual – PB Series REV NO : 2

8.1.2. Scale Ass'y



No.	Number	Rev	Description	SPEC	MATERIAL	Q'TY	REMARK
1	2008-A00-0004	0	UPPER PAD	400*328*0.5t	PVC 0.5T	1	
2	2008-A00-0005	0	PVC SHEET	83x53x0.5t	PVC SHEET 0.5t	3	
3	1100-A00-0089	0	UPPER PLATFORM	443*355*45	AA 380-F DIE	1	
4	1502-A00-0306	0	SCREW MACHINE(PH)	M3*6	SCM	5	
5	2000-A00-0314	0	WIRE COVER	156*115*26.5	ABS 780(KUMHO)	1	
6	1100-A00-0090	0	LOWER BODY	610*355*49.5	AA380F-DIE	1	
7	7642-S00-0003		CABLE CLAMP	DA-3N	ABS	1	
8	2022-A00-0004	1	WATER LEVEL GAGE	φ14.9*8(S-2000)	ABS	1	
9	1561-MSU-0300	0	E-RING	Φ3*Φ7*0.6	SUS	2	
10	1100-A00-0091	0	BRACKET HANDLE	295*248*49.5	AA 380-F DIE	1	
11	1261-A00-0004	0	BATTERY COVER BOLT	M4*0.7*8.5(SUS)TP	SUS	2	
12	1502-A00-0405	0	SCREW MACHINE(PH)	M4*5	SCM	4	
13	1521-A00-0610	0	BOLT HEXAGON(WA)	M6*12(8.8T)	SCM	4	
14	2610-A00-0015	0	FOOT	M10*1.5*@70	RUBBER(NBR)	4	
15	1521-A00-0825	0	BOLT HEXAGON(WA)	M8*25(8.8T)	SCM	8	
16	1535-MSU-0830	0	BOLT-WRENCH(ST)	M8*30-SUS	SUS	4	
17	1540-MSU-0800	0	NUT	M8*1.25	SUS	4	
18			LOADCELL	BCS	AL-2024	1	

8.2. Loadcell Ass'y




Specifications


Capacity	50, 100, 250 Kgf
Rated Output	$2.0 \pm 0.2 \text{mV/V}$
Zero balance	$0 \pm 0.1 \text{mV/V}$
Accuracy class	
Combined error	0.03%
Repeatability	0.01%
Creep for 30min.	0.03%
Temperature effect on Zero value	0.028%/10°C
Span value	0.015%/10°C
Excitation voltage Recommended	10V DC
Maximum	15V DC
Resistance Input	$1100 \pm 100 \Omega$
Output	$1000 \pm 10 \Omega$
Insulation	>2000MΩ
Compensated temperature range	-10°C~40°C
Operating temperature range	-20°C~70°C

Service Manual – PB Series REV NO : 2

8.3. Main PCB Ass'y (Top)



8.4. Main PCB Ass'y (Bottom)



Service Manual – PB Series REV NO : 2

8.4.1. Main PCB(Part List)

1.1 MAIN PCB ASS'Y						
No	Part Name	Specification	Part Number	Q'ty	Remark	구분
1	PCB-MAIN	6100-PPB-0000-0(PB,LCD)	6100PPB00000	1		신규
2	ONE MODULE	ONE MODULE	6PA0A0000000	1	U10	
3	IC(REGULATOR)	XC6204C502MR(5.0V)	6220IS0C5020	1	U4	
4	IC(REGULATOR)	XC6204C332MR(3.3V)	6220IS0C3320	1	U8	
5	IC(LCD DRIVER)	HOLTEX HT1621B	6224I0016210	1	U1	
6	IC(DC DC CONVERTER)	XC6368A553MR	6242IS063680	1	U7	신규
7	TRANSISTOR CHIP	KTA1504 SY	6281I0015040	1	Q3	
8	TRANSISTOR CHIP	KTA1666	6281I0016660	2	Q1,4	
9	TRANSISTOR CHIP	2N2222A5	6281I0022220	2	Q2,5	
10	IC(REGULATOR)	KA7809A(D-PACK)	6220IS078090	1	U3	
11	MOSFET(N-CH) CHIP	XP161A1265PR	6273I0012650	1	Q6	신규
12	DIODE POWER	1N5819(SMD)	6291IS058190	2	D1,10	
13	DIODE-POWER	1N5406	6291IP054060	1	D6	
14	DIODE-CHIP	KDS184	6294ICP01840	1	D8	
15	DIODE-CHIP	MA2Q735	6293ISK07350	1	D2	신규
16	RESISTOR-CHIP 1/10W	WR06X0000JT(0Ω)	6527ID00000A	1	D5	Only Basic
17	RESISTOR-CHIP 1/10W	RR1220P-000D(0Ω)	6527ID000000	4	R5,7,40,41	Only Basic
18	RESISTOR-CHIP 1/10W	RR1220P-100D(10Ω)	6527ID001000	1	R1	
19	RESISTOR-CHIP 1/10W	RR1220P-101D(100Ω)	6527ID010000	6	R6,8,9,18,19,20	
20	RESISTOR-CHIP 1/10W	RR1220P-102D(1KΩ)	6527ID300100	3	R3,10,32	
21	RESISTOR-CHIP 1/10W	RR1220P-103D(10KΩ)	6527ID301000	6	R4,13,15,21,36,37	
22	RESISTOR-CHIP 1/10W	RR1220P-103D(30KΩ)	6527ID303000	1	R12	
23	RESISTOR-CHIP 1/10W	RR1220P-104D(100KΩ)	6527ID310000	7	R11,14,16,17,23,29,39	
24	RESISTOR-CHIP 1/10W	RR1220P-123D(12KΩ)	6527ID301200	1	R38	
25	INDUCTANCE	HB-1M2012-102JT(TP2,LP2,DBB)	6670T0001020	6	L1,2,3,4,5,6	
26	INDUCTANCE	CR-54(22uH)	6670T0200220	1	L7	신규
27	EMI BEAD FILTER	BFD-3565 R2	6800F003565A	1	L9	
28	CONDENSER-CHIP	CL21B 102KBNC	6712CHP01020	3	C8,9,10	
29	CONDENSER-CHIP	100uF/16V(SMD)	6706C1601000	3	C2,14,27	
30	CONDENSER	330uF/25V(SMD)	6706C2503300	1	C17	신규
31	CONDENSER	220uF/25V(SMD)	6706C2502200	1	C15	신규
32	CONDENSER	470uF/25V(SMD)	6706C2504700	1	C24	신규
33	CONDENSER-CHIP	47uF/16V(Tantal)	6702CAP0106D	1	C12	신규
34	CONDENSER-CHIP	CL21F 104KBNC	6712CHP01040	7	C1,11,13,16,25,26,28	
35	CONNECTOR(WAFER)	LWL0640-03 (LSW250-03)	7802CLL00030	1	CN3	
36	CONNECTOR(WAFER)	LWL0640-02 (LSW250-02)	7802CLL00020	1	CN4(PB)	
37	CONNECTOR(WAFER)	02-5267	7805CCN67020	1	CN5(DRY)	
38	FUSE	1.6A/250V φ5 UL,S,VDE,BSI(✉)fast blow type	7620S0516000	1	FUSE1	
39	FUSE HOLDER	GF-205B(EXP-300L)	7630S0002050	1	FUSE1	
40	PIEZO BUZZER	APR,ADR(CHINA)	700220000000	1	BZ1	
41	JUMP WIRE	φ0.6*10m/m	7844W0001000	1		
42	JUMPER	2PIN	7821CJM00020	3	JP1,+5V,BAT	
43	LCD	2402TF-P,B1(DB-II,DBB,NT)YEEBC	7212D000010B	1	LCD1	신규
44	DIODE-TVS	SD05	6294ICP00050	2	D11,12	
45	TACT S/W	11902(DJTA-1102)	7600STA19020	1	S5	
46	TACT S/W	KPT-1105B(DJTA-1102C)	7600STA1105B	4	S1,2,3,4	
47	Modular Jack	RJ-11(6P), Straight	7810C000006A	1	CN2	
48	LED BACKLIGHT	PB-LCD(one module) □ 가평,백식	7224D0000031	1	BK1	신규

Service Manual – PB Series REV NO : 2

8.4.1. PCB-Option (Part List)

1.3 RS-232C PART(OPTION)						
No	Part Name	Specification	Part Number	Q'ty	Remark	구분
1	CONDENSER-CHIP	CL21F 104KBNC	6712CHP01040	5	C3,4,5,6,7	OPTION
2	IC(INTERFACE)	SP3232ECY(3.3V)	6232IS032320	1	U2	OPTION
1.4 CHARGE PART(OPTION)						
No	Part Name	Specification	Part Number	Q'ty	Remark	구분
1	RESISTOR 2W	CFR 0.33Ω(±5%)	6512CJ000033	1	R22	OPTION
2	CONDENSER-CHIP	CL21F 104KBNC	6712CHP01040	1	C18	OPTION
3	RESISTOR-CHIP 1/10W	RR1220P-103D(10KΩ)	6527ID301000	1	R24	OPTION
4	RESISTOR-CHIP 1/10W	RR1220P-202D(2KΩ)	6527ID300200	1	R25	OPTION
5	RESISTOR-CHIP 1/10W	RR1220P-470D(47Ω)	6527ID300047	1	R26	OPTION
6	IC(DC DC CONVERTER)	MC34063AD	6242I003406A	1	U6	OPTION
7	CONDENSER-CHIP	CL21F 471KBNC	6712CHP04710	1	C22	OPTION
8	INDUCTANCE	220uH(NT SERIES)	6670T0102200	1	L8	OPTION
9	CONDENSER-CHIP	470uF/25V(SMD)	6706C2504700	1	C23	신규OPTION
10	DIODE POWER	1N5819(SMD)	6291IS058190	3	D4,5,7	OPTION
11	RESISTOR-CHIP 1/10W	RR1220P-333D(33 KΩ)	6527ID303300	1	R27	OPTION
12	RESISTOR-CHIP 1/10W	RR1220P-102D(1KΩ)	6527ID300100	1	R30	OPTION
13	RESISTOR-CHIP 1/10W	RR1220P-103D(10KΩ)	6527ID301000	1	R33	OPTION
14	RESISTOR-CHIP 1/10W	RR1220P-104D(100KΩ)	6527ID310000	2	R31,34	OPTION
15	RESISTOR-CHIP 1/10W	RR1220P-222D(2.2KΩ)	6527ID300220	2	R28,35	OPTION
17	IC(LINEAR)	LM393D(SOP)	6241IS003930	1	U9	OPTION
18	LED LAMP	ø5-(R,G) BL-BEG 204	7232DRG00050	1	D9	OPTION
1.6 DISPLAY ASS'Y(전자)						
No	Part Number	Part Name	Specification	Q'ty	Remark	구분
1	CONNECTOR WIRE	3P*220*303(CORE)	7840W000303C	1		신규
2	BATTERY WIRE	2P*70/190mm(PB)	7840W0072190	1		신규
3	BATTERY HOLDER WIRE	0.18*12C*200M/M(GRN,PB)	7870WGN02900	1		신규
4	CONNECTOR WIRE	2P*120/170mm(SW-LR BATTERY)	7840W000218A	1		OPTION
5	BATTERY	6V1.3AH_20HR(SW-LR)	7520-P00-0136	1		OPTION
6	CUSHION-VFD	30*20*2T	2631A0000010	2		
1.7 C/T BOX ASS'Y (전자)						
No	Part Number	Part Name	Specification	Q'ty	Remark	구분
1	DRY BATTERY	Manganese(C Type)	7520P0000400	4		
2	RS-232C WIRE	D9P*6P PHONE JACK-2M	7840W0009060	1		신규OPTION
3	SMPS ADAPTOR	100-240V / 12V 1.25A	7562-P12-02CE	1		OPTION

9.Revision

NO	CAUSE	DATE	APPROVAL
2	PCB Artwork, Part List, Calibration Setting , Options Installing Revision	2009.06.10	Kim kwanghyun