

Match-Balance Series

4300SC Balancer Service Manual




TABLE OF CONTENTS

<u>Page</u>	<u>Section</u>	<u>Subject</u>
4	1.0	Introduction
	2.0	Specifications
5	3.0	Systems explanations
	3.1	Microcontroller PCB function
	3.2	Encoder function
6	3.3	Brake system
	3.4	Shaft and bearings
	3.5	Transducers
7	3.6	Touch panel
	4.0	Spin cycle explanation
8	5.0	Self diagnostics (F-code explanations)
	5.1	F0 Recalculate and display weight amount from last spin
	5.2	F1 Calibrate balancer for span factor and encoder offset
	5.3	F2 Round off mode
	5.4	F3 Non-round off mode
9	5.5	F4 Ounces mode
	5.6	F5 Grams mode
	5.7	F7 Convert wheel diameter to millimeters
	5.8	F8 Weight placement angle size selection mode
	5.10	F12 Calibrate distance gauge
	xxx	F15/16 Programable threshold for gram mode
	5.11	F20 Display shaft imbalance
	5.12	F21 Shaft imbalance diagnostics
	5.13	F30 Test the display
	5.14	F31 Test the keyboard
	5.15	F40 Display power supply voltage
10	5.16	F42 Display left amplifier gain and offset
	5.17	F43 Display right amplifier gain and offset
11	5.18	F50 Display encoder position
	5.19	F51 Display total encoder count
	5.20	F53 Display shaft speed
	5.21	F54 Calibrate encoder
	5.22	F60 Display program revision level
	6.0	F90 Match Balance
	6.2	Other self diagnostic codes
	6.3	Direction error
	6.4	Cal error
12	7.0	Systematic troubleshooting
	7.1	Check AC power
13	7.2	Check DC power
	7.3	Check computer and touch panel functions
	7.4	Spin cycle test
14	7.5	Weight position test
15	7.6	Weight amount test
	8.0	Symptom Troubleshooting
	8.1	Weight chasing
16	8.3	Dynamic Weight Chasing

TABLE OF CONTENTS

<u>Page</u>	<u>Section</u>	<u>Subject</u>
17	8.3	Measure runout of bell housing
18	8.4	Transducer output diagnostics
	8.5	Tire vibration after balance
19	9.0	Tools required for 4300 service
20	10.0	Disassembly and assembly of the 4300
	10.1	Weight tray removal
	10.2	Encoder removal
	10.3	Transducer removal
21	10.4	Removing the shaft and bearings
	10.5	Motor - Drive Assembly
22	10.6	Suspension system repair
23	10.7	Wheel Guard Assembly

INTRODUCTION

1.0 Introduction The 4300 was introduced to fill a world wide market need. Many shops having space restrictions will find the 4300 Balancer space efficient, extremely accurate and portable.

The 4300 Balancer features:

- Microcontroller Technology
- Ease of Operation
- Self Calibration
- Nine Balancing Modes
- Operation in Grams or Ounces
- Large wheel capacity
- 117/230 VAC power operation
- Built in diagnostics
- Low cost maintenance
- Ease of repair
- Multiple balancing applications with many optional mounting adapters available.

The 4300 Balancer is designed to handle today's and tomorrow's wheel balancing needs.

2.0 SPECIFICATIONS:

Types of Balance: Static, Dynamic, and Match Balancing

Accuracy: 0.1 oz. (2.8g)

Rim Width: 3"-19" (76-483mm)

Rim Diameter: 8"-24" (203-610mm)

Tire Diameter: 40" (1112mm)

Tire Weight: 154 lbs. (70kg)

Shipping Weight 305 lbs. (134kg)

Shipping Volume 38.8 cu.ft. (1.1 cu.M.)

This Manual Explains the following features:

Key Pad

Microcontroller PCB


Encoder System

Shaft and Bearings

Brake

Troubleshooting Procedures

Tools Required



3.0

4300 SYSTEM(S) EXPLANATIONS

MICROCONTROLLER PRINTED CIRCUIT BOARD




Figure 1

3.1 Microcontroller PCB Functions

- Receives Analog Data from Crystal pickups, determining weight amount calculations.
- Receives Digital data from Encoder System for determining weight position and shaft rotation speed. Processes Analog and Digital Data through summing circuits.
- Stores input data in Ram and challenges calibration factors stored in EEPROM.
- Receives keyboard input and accesses ROM for program routine.
- Provides output through the LED readout, color position LEDs and piezo speaker.
- Provides diagnostic codes and readings stored in ROM.
- Allows manual calibration of the gain and offset adjustments for the pickup amplifier.
- Regulates voltage and provides fused protection for all digital circuits.
- Controls the motor rotation and braking functions.

3.2 Encoder

- Phase 1 and 2 are responsible for locating the position of the imbalance.
- Home reference is used to sense shaft movement and provide this input to the Microcontroller.
- Stabilizer arm is used to ensure the encoder does not rotate.
- Uses 100 windows which is multiplied 4 times by the computer to give a reading of 400 (0 to 399) or a resolution of .9 degrees.




Figure 2

3.3 Brake system: Used to stop the tire's rotation during any part of it's spin cycle. The Brake system is an electric-magnetic induction system using the motor a bridge rectifier and some control electronics. When a stop command or a brake command is entered by the computer, a DC voltage is generated by the bridge rectifier. This DC current is then limited by a braking resistor, routed through a relay and applied to the motor. An AC motor when fed with DC current will tend to "Buck" any rotation. This bucking will stop the rotation of the shaft. Shaft rotation is sensed by the encoder circuit, as the shaft stops the computer disconnects the DC brake. This DC brake is also used for the "Sticky-at-Top" feature.




Figure 4

3.4 Shaft and Bearings: Are designed to operate in a noise free environment. The shaft is balanced to within 0.03 ounces at the time of manufacturing. The bearings are Ball bearings which are shielded not sealed. Sealed bearings induce noise in the system and would not allow the bearings to operate smoothly. A grease coating is applied to the bearings, shaft and bearing housing to help eliminate noises which could interfere with the operation of the balancer. Locktite should not be used to hold the bearings in place. The shaft and bearings are available only as an

assembly.

3.5 Transducers: Are used to provide imbalance information to the Microcontroller. The input information is a voltage which varies in amplitude depending on the amount of force being applied. The Microcontroller will begin calculating weight amount readings once the proper transducer input is provided.

The transducers sense the amount of force being applied while spinning. This information of a repetitive static imbalance coupled with the shaft speed information being provided by the encoder will provide the necessary information needed by the computer to calculate the weight imbalance as well as the imbalance position.




Figure 5




Figure 6

3.6 Touch panel: Used for the entry of all commands to the microcontroller. It consists of a metal plate for the mounting of the printed circuit board and a vinyl overlay with an eleven conductor ribbon cable. Twisting or crimping the ribbon cable will damage the conductors. Striking the touch panel with anything other than a finger may damage it. Clean the touch panel with a dampened cloth of mild ammonia or use a lanolin based hand cleaner without grit. Don't use harsh chemicals to clean the touch panel.





Figure 7

4.0 Spin cycle explanation



4300 Self diagnostic "F" Codes

5.0 The 4300 incorporates self diagnostics to assist the user and technician in troubleshooting, calibration and repair. Refer to the following for explanations of each available code.

5.1 F0 - RE-CALCULATE AND DISPLAY WEIGHT AMOUNT FROM LAST SPIN.

Data from the last spin in current memory is used with any new parameters or set-ups to display new weight amounts. Current memory is maintained until the next spin cycle or until the unit is turned off.

5.2 F1 - BALANCER CALIBRATION

(BASIC-END-USER CALIBRATION)

Press "F1 and ENTER"

A: If EEPROM has not been initialized (this is the first time the board has been calibrated), then the balancer will first ask for calibration of the distance gauge as follows:

- 1 "CAL DIS" will be displayed.
- 2 Press "ENTER".
- 3 Initialization calibration distance value (140) will be displayed.
- 4 Measure to left face of the bell flange with the distance gauge.
- 5 Enter this number via the keyboard.
- 6 Perform steps B.1 through B.7.





Figure 8

B: If EEPROM had already been initialized, then the balancer will go directly to this procedure to set calibration factor for span and encoder (end user calibration):

- 1 "CAL SLU" and "ROT 360" will be displayed alternately.
 - 2 Install calibration slug onto left face of bell adapter. Rotate the bell at least one full revolution
 - 3 Press "ENTER", Place the calibration slug at the 6 o'clock or bottom dead center (BDC) position. Press "ENTER". "SPN SPN" will be displayed as the shaft spins.
 - 4 Unit will display "CAL —" during readings, brake, and then display "SLU OFF".
 - 5 Remove calibration slug.
 - 6 Press enter. "SPN SPN" is displayed during spin cycle.
 - 7 Unit will brake, then display "CAL G".
- Unit is now calibrated.



Cal Slug at "BDC" Figure 9

5.3 F2 - ROUND-OFF MODE (WEIGHT AMOUNT DISPLAY)

Weight amounts are rounded off to the nearest 0.25 ounce (5 gram) increment. Imbalances of 0.30 ounces or less (8.5 grams or less) will round to zero. This is the turn-on (or default) mode.

5.4 F3 - NON-ROUND-OFF MODE (WEIGHT AMOUNT DISPLAY)

Weight amounts are displayed in 0.05 ounce (1 gram) increments. This setting is in volatile memory, and reverts to "F2" when the unit is turned on.

5.5 F4 - OUNCES MODE

Sets weight amount display to ounces. This setting is in non-volatile memory. When the balancer is turned off and on, this mode of operation will be maintained.

5.6 F5 - GRAMS MODE

Sets weight amount display to grams. This setting is in non-volatile memory. When the balancer is turned off and on, this mode of operation will be maintained.

5.7 F7 - CONVERT WHEEL DIAMETER TO MILLIMETERS MODE

Allows direct entry of metric wheel diameters (i.e. 390 mm) when balancing this type of wheel. Selecting F7 toggles between "CON ON" (dia in mm) and "CON OFF" (dia in inches).

Press any key to exit this set-up.

This setting is in volatile memory. When the balancer is turned off and back on, the setting reverts to "CON OFF" (dia in inches).

5.8 F8 - WEIGHT PLACEMENT ANGLE SIZE SELECTION MODE

The entry of this code causes the green light to be displayed for either one encoder count or two. Selecting "F8" toggles between the following modes:

1. When the "FIN ON" message is displayed, the balancer will then be in the fine angle resolution mode (narrow window). The resolution for the wheel weight position display is set at 0.90 degrees (one encoder count).

2. When the "FIN OFF" message is displayed, the balancer will then be in the wide angle resolution mode (wide window). The resolution for the wheel weight position display is set at 1.80 degrees (two encoder counts).

This display mode entry will be recorded in non-volatile memory. When the balancer is turned off and on, this mode of operation will be maintained. The recommended mode is the FIN OFF for the majority of users.


5.10 F12 - CALIBRATE DISTANCE GAUGE

"CAL DIS" will be displayed.

Press "ENTER" and the old factor will be displayed. Place the distance gauge against the left face of the Shaft Adapter (bell). Read the distance gauge, and enter the new reading into the computer through the keyboard. The computer will automatically exit this routine when the last digit has been entered.

This data entry will be recorded in non-volatile memory.

Even though the balancer is turned off and on, this information will be maintained.



5.11 F20 - DISPLAY SHAFT IMBALANCE

The entry of this code causes the computer to display the shaft imbalance value which was recorded in non-volatile memory during the last shaft imbalance diagnostic procedure (F21). For this information to be meaningful, the following parameters must be entered: (DIST=62, WIDTH=5.5, DIA=13.0)

This information will remain the same until the F21 diagnostic procedure is run again.

5.13 F30 - TEST THE DISPLAY

The entry of this code causes the computer to turn on all 7 segments of each display block for 2 seconds.

Allows you to verify that all 7 segments of each LED is functioning. (All 7 segment displays show 8's).

All characters will begin to scroll across the display in sequence.

This test also verifies the computer understands input commands and has the ability to provide correct output.

Press "CANCEL" to exit this routine.

5.14 F31 - TEST THE KEYBOARD

The entry of this code causes the computer to display each key as it is pressed.

With "CANCEL" being the last entry to be made, you can now press each key and verify the proper response is present on the display.

Press "CANCEL" to exit this routine.

5.16 F42 - DISPLAY LEFT AMPLIFIER GAIN AND OFFSET

This display is used to check and calibrate the left channel amplifier gain and off set.


Note: These values are only meaningful when using the standard calibration slug.

Locate the left gain and offset adjustment potentiometers through the access plugs or on the microcontroller PCB. See figure below for POT location pictorial. The POT locations are labeled on the back side of the printed circuit board. Adjust using a potentiometer adjustment screwdriver.

Calibrate gain and offset as follows;

Observing readings.

The left display should show a gain reading centered on 1.58 +/- 0.02 (volts)




Adjust left gain potentiometer until the proper readings are obtained .

The right display should show the value of the amplifier offset voltage centered on 2.50+/- 0.01 (volts) Adjust left offset potentiometer until the proper readings are obtained .

NOTE - The gain adjustment will have some effect on the offset voltage. Make sure both displays are within specification.

Press "CANCEL" to exit this routine.




5.17 F43- DISPLAY RIGHT AMPLIFIER GAIN AND OFFSET

This display is used to check and calibrate the right channel amplifier gain and offset

Note: These values are only meaningful when using the standard calibration slug.

Locate the right gain and offset adjustment potentiometers through the access plugs or on the microcontroller PCB. See figure below for POT location pictorial. The POT locations are labeled on the back side of the printed circuit board. Adjust using a potentiometer adjustment screwdriver.



Calibrate gain and offset as follows;

Press enter to spin. Observing readings.

The right display should show a gain reading centered on 1.64 +/- 0.02 (volts)

Adjust right gain potentiometer until the proper readings are obtained . See figure 1, page 5 for pot location.

The right display should show the value of the amplifier offset voltage centered on 2.50+/- 0.01 (volts)

Adjust right offset potentiometer until the proper readings are obtained .

NOTE - The gain adjustment will have some effect on the offset voltage. Make sure both displays are within specification.

Press "CANCEL" to exit this routine.

5.18 F40 - DISPLAY POWER SUPPLY VOLTAGE

Enter F40 and press enter, the display will read BRD VLT, meaning board voltage. The regulator voltage delivered by the power source to the pcb (in volts) will be shown on the display.

The reading should be approximately 6.5 to 15.0 volts. Refer to the troubleshooting section of this manual for more details. This test is valid for whatever the AC line input voltage options.

Press "CANCEL" to exit this routine.

5.19 F50 - DISPLAY ENCODER POSITION

Numbers between "0" and "399" will be displayed on the right display, indicating the current encoder pulse.

Dashes will be displayed on the left display, indicating phase "1" (first dash), phase "2" (second dash), and home reference (third dash) of the encoder.

Press "CANCEL" to exit this routine.

5.20 F51 - DISPLAY TOTAL ENCODER COUNTS IN ONE REVOLUTION

Display should read "399" when the wheel is turning.

Press "CANCEL" to exit this routine.

5.21 F53 - DISPLAY SHAFT SPEED IN RPM

Spin the shaft and the RPM will be displayed, a reading of 140 +/- 10% is normal. Press "CANCEL" to exit this routine.

5.22 F54 - CALIBRATE ENCODER

Calibrates the encoder's zero count..

Rotate the bell adapter one complete revolution and then press "ENTER".

"ENC OFF" will be displayed.

Press "ENTER" the encoder position will be displayed.

Install the calibration slug, and rotate the shaft so the slug is directly at the 6 o'clock position.

Press "ENTER" to cause the computer to record the present position as the correct encoder zero position stored in non-volatile memory and exit the routine, or press "CANCEL" to exit this routine without changing the encoder calibration. F50 should be checked after the running the F54 calibration to verify correct position.

5.23 F60 - DISPLAY PROGRAM REVISION LEVEL

Left hand display will show "43", and right hand display will show revision level (i.e. "2.24").

Press "CANCEL" to exit this routine.

6.0 OTHER SELF DIAGNOSTIC CODES

6.4 CAL ER: Will flash should a error occur during the calibration procedure or should the system detect a problem when accessing the EEPROM for its calibration factors.

6.2 SHT UNB: Will flash after a calibration attempt whenever the shaft is unacceptably unbalanced. First review the calibration procedure to assure that the correct steps are being followed. It is common for this message to appear because of a calibration sequence has not been adhered to.

6.3 RPG/LPG LO: This is a message that appears whenever the pcb amplifier gains are set too low or whenever there is some type of malfunction with one of the pickups. **RPG** stands for "Right Pickup Gain"; **LPG** stands for "Left Pickup Gain".

4300 systematic troubleshooting

Basic troubleshooting of the 4300: is simplified using a systematic check of the various systems. This manual will assume the following;

1. The necessary hand tools are available (See tool list page 19)
2. A basic understanding of systems functions.
3. The use of this manual in its entirety.

Identify the symptom


No display
 No keyboard entry
 No spin cycle
 No position indication
 No weight amount display
 Requires multiple spins to balance wheel
 Vibration on vehicle after balance
 No brake functions

7.0 Systematic troubleshooting: is a recommended procedure for repairing the balancer. Follow these steps when repairing the 4300.

7.1 Check AC power:


AC power is used to power the transformer/power supply which converts 120/220 volts AC to DC power

6.5 volts - 15 volts depending on the output of the adapter. DO NOT assume the power outlet is good. Verify the AC output from the wall outlet by volt meter, substitution of a known good AC powered device, or the use of a polarity tester.




7.2 Check DC power: (Refer to the schematic Figure 20 of this manual).


7.3 Check computer functions: the Microcontroller self tests itself every time power is cycled. If the CPU has found a problem in any of its address, data, or control circuits it will cease processing functions and the sonic beeper will begin to sound. A stuck key on the touch panel would also cause this symptom. An easy way to test the microcontroller is to run test F-30.



Testing the touch panel (Refer to figure 21)



7.4 Spin cycle test:



7.5 Weight position test: Before beginning the following tests; mount a calibration slug on the back side of the shaft adapter. Turn the balancer on and spin the shaft using the "location 7" balancing mode.







Figure 10

7.6 Weight amount test: Before beginning the following tests; mount a calibration slug on the balancer adapter plate. Turn the balancer on. Insure the balancer is in the Location 1 balancing mode except where indicated by flow chart. Any repairs or mechanical calibrations will require complete "End User" calibration (F-1) before returning the 4300 to operation.



8.0 Symptom troubleshooting

Symptom troubleshooting assumes all systematic troubleshooting techniques have been used and that the various systems in the balancer are in working order.

8.1 Additional weight needed to balance tire. (Weight Chasing)

Static weight chase.

Using a balanced wheel assembly, enter the tire's parameters.

Place the cal slug on the balancer and using location 7, spin the balancer.

If the balancer reads other than 5.50 ounces, check the following;

1. Shaft imbalance (F-20)
2. Bell housing runout. (see 8.2 and 8.3)
3. Transducer gain and offset (F-42, F-43)

Dynamic weight chase

Remove the calibration slug.


Using "location 1" add a 3 ounce test weight to the inside plane of the wheel.

Spin the balancer. If the balancer reads other than 3 ounces check the following;

1. Bell housing runout.
2. Transducer gain and offset.
3. Mounting adapters
4. Transducer linearity. (the ability of the transducer to produce consistent output)
5. Distance gauge calibration or physical damage to the distance gauge.

If a reading of 3 ounces is obtained , move the weight to the outside plane. If the weight reads other than 3 ounces check the following;

1. Bell housing runout.
2. Transducer gain and offset.
3. Mounting adapters
4. Transducer linearity. (the ability of the transducer to produce consistent output)
5. Distance gauge calibration or physical damage to gauge.



Runout should be measured when the balancer requires more than one weight per tire side to balance the wheel.

8.3 Measuring Bell face runout

8.4 Transducer Output: Using Location mode 7 and F-42 for the left transducer and right transducer, check the transducer linear output in the following manner;

Use a balanced wheel

1) Spin the balancer until the green LED position indicator is lit. Output should be 0.00 to 0.10 with a balanced wheel.

2) Add a one ounce weight to the inside plane. Refer to the chart and then to the reading.

3) Continue to add weight using only 1 weight in the same wheel position. Readings should be very close ± 0.10 to those values shown on the chart.

4) Remove the right and left transducer connections from the main PCB. Connect the right transducer plug to the left transducer connector on the Main PCB.


Perform the steps 1 to 3.

Again the readings should compare to the chart. Numeric values may vary but linear output should remain constant.


If the transducer will not give a linear output replace it. Torque the new transducer in place and re-test.

5) Be sure to calibrate (F-1) the balancer when you have completed this procedure.

Use the blank chart to record your actual readings for the left and right transducers.



Determine transducer linear output



8.5 Tire vibration after the balance: Generally speaking this condition will occur in a wheel throughout all speed ranges if the balancer is not working properly.

If the condition only exists during given speed range look for:

Tire runout (radial and axial),

Bent rims

Wheels which are not hub centric. (Rims that are not centered by the center hole) and require the use of an optional mounting method.

Damaged bearing races or bent axles.

If the balancer has passed all systematic troubleshooting procedures and it appears to be functioning correctly, check the following:

1. Follow the procedures given for the F-20 and F-21 (shaft imbalance test)

2. Check cones for play when mounted to the shaft.

Cone tolerance is .003 inches of up and down movement on the shaft.

3. Check the encoder's Phase 1 and Phase 2 signal to ensure they are at 90 degrees to each other. (See figure 2 and troubleshooting guide for weight position)

4. Check the torque of the suspension system bolts.

If these suggestions do not solve your problem.

Remember

FMC is striving to be **OUR CUSTOMERS MOST VALUED EQUIPMENT SUPPLIER.**

If you require additional assistance;

Phone our technical assistance desk at:

1-800 FMC-TEAM inside the continental United States or

1 - (501) 327-4433 for all overseas customers.

Our FAX number is (501)-450-1585

Please direct all technical questions to the attention of technical assistance.

9.0 Tools required to service the 4300

Tools Required to service the 4300

Wrenches

5/16" or 8mm wrench or nut driver
1/2" or 13mm Wrench
9/16" or 14mm wrench
5/8" wrench
3/4" or 17mm wrench

Allen Wrenches

1/8" Allen wrench
5/32" Allen wrench
3/16" Allen wrench
5/16" or 8mm Allen wrench
12mm Allen wrench

Other Tools

Inch pound torque wrench
Foot pound torque wrench
6 inch in 1/16" increments or 50mm ruler
#2 Phillips or cross tip screwdriver
Digital volt / ohm meter
Potentiometer adjustment screwdriver


Supplies

Loctite #222 and #609
Silicone based grease (NAPA Balkamp #765-1351)
Putty for fine wheel balancing.

***A tire/wheel balanced to within 0.10 oz (1gr.) on the inside and outside or 0.20 oz. statically is required for the troubleshooting procedures.*

10.0

Disassembly of the 4300

10.1 Remove the weight tray and Microcontroller PCB

Remove the top cover of the 4300 by removing the Touchpanel first. Be careful when pulling the panel back and watch for the wires which are attached to the PCB. (*)

Disconnect the wires by gently raising the connector clip and pulling back on the wire's socket. **DO NOT PULL ON THE WIRES OR ATTEMPT PULLING UP ON THE CONNECTOR.**

Squeeze the touchpanel's connector side clips and gently pull back to disconnect the flat ribbon cable.



Refer to the drawing and remove the upper cover in the numbered order.

Assembly is the reverse order.

10.2 Removing the Encoder

Refer to the drawing and remove the encoder in the numbered order. Assembly is the reverse of disassembly. Care should be taken to insure the encoder's slotted shaft is correctly inserted in the shaft opening. The encoder should not wobble when the shaft is turned.

Once installation of the encoder is complete and power is restored to the balancer, you will need to refer to the Encoder calibration section of this manual to complete the installation procedure. Follow the numbered sequence in the drawing for removal of the transducers. The transducers have two small balls held in

10.3 Transducer removal

position by the torque of the set screw. Grease is applied to these balls during assembly to help hold them in place.

When placing the transducer back in the machine be sure the cables are disconnected to avoid damage to the transducer and apply more grease. Torque the transducer to **30 inch lbs., loosen 1/2 turn then torque again to 30 inch pounds.** Once power has been restored to the machine refer to the F42 and F43 calibration procedure in this manual to set amplifier gain and offset. F1 calibration must be performed after making any transducer adjustments. Remember if you were to adjust the bearing support or the shaft housing this would effect transducer torque and you would need to adjust as necessary.

10.4 Removing the Shaft and Bearings

Refer to the numbered sequence below for removal of the shaft and bearings from the 4300. **!!During the**

removal of the shaft care should be taken to not damage the bearings through heavy impact.

The shaft and bearings are available only as an assembly. Inspect for burrs or rust in the bearing tube before returning the shaft to service. Coat the bearings and the bearing seat with silicone grease to protect the bearings from rust and eliminate noise.

After complete assembly of all shaft components, refer to the shaft calibration portion of this manual.




Figure 16

Use the F-1 calibration procedure to complete the installation of the shaft and bearing assembly.

10.5 Motor Drive

Service of the 4300 Balancer Motor-Drive assembly is quite crucial. Proper belt tension should always be maintained. Normal operation as well as rough shipping prior to installation may require this tension be adjusted. Inspection of the shaft bearing tube where mounted to the motor/shaft bracket should reveal no slippage. If found to have slipped, use this procedure to adjust:

The specifications for drive belt adjustment are as follows:

1. The belt should be set with tension that allow a 3/8" deflection of the belt halfway between the pulleys with 10 to 12 pounds of force. Belt tension should be neither too loose or too tight.




Figure 17

2. If a start-up torque is unusually high, a loose belt may allow the motor to jump several teeth. Because excessive tension also creates problems, there must be a medium acceptable range. It has been determined that the easiest way to field adjust is to mount a heavy wheel/tire assembly that would allow belt slippage if belt were loose. Gradually increase motor tension until belt no longer skips teeth.

3. Tighten mounting bolts to the following specs:

Motor bracket mounting bolts, (4) 3/8-16x1 is 20 foot pounds.

Motor mount nuts, (4) 10-24, is 32 inch pounds.

NOTE: Inspection of the shaft bearing tube where mounted to the motor/shaft bracket should reveal no downward slippage. Rough shipping or handling could cause the motor and bracket assembly to slip downward. Any downward movement of the motor will tighten the belt tension. If found to have slipped, use the above procedure to adjust.

10.6 Suspension system: The bearing tube, shaft and bearings are designed to work in a low noise and free floating environment.

Limited service is required for this system.

After removal of the shaft/bearing assembly, remove the four bearing tube suspension bolts. (see figure 19) Remove the tube.


Assembly of the suspension is the reverse of disassembly. Deviation of the assembly procedure will add to your assembly time.


Center the tube front and rear as shown in figure 18

Torque the top rear suspension nut to 60 inch pounds. When the proper torque has been obtained, check the bearing tube for proper centering. Adjust as necessary.

Torque the front suspension bolts to **35 foot pounds** alternating from top to bottom one quarter turn at a time.


Once assembly of the balancer has been completed perform all calibration steps to the unit. Please refer to the calibration section of this manual.





10.6 Wheel Guard Assembly Installation or removal of the hood guard for service or initial setup requires only a small hammer to tap in a roll pin. For installation simply insert the guard support pivot pin into the balancer support tube. Make sure the pivot pin is all the way into tube, place the roll pin into the drilled hole of the pivot. Tap into place.


NOTE: The balancer *must* be secured to the floor prior to installation of the hood guard.




Reference drawings, charts and figures

<u>page</u>	<u>Section</u>	<u>Drawing, chart, or figure.</u>
5	3.0	Figure 1 Microcontroller PCB
5	3.2	Figure 2 Encoder
6	3.4	Figure 4 Shaft and bearings layout
6	3.5	Figure 5 Transducer location
6	3.5	Figure 6 Transducer location and wiring connections
7	3.6	Figure 7 Touch panel layout
8	5.2	Figure 8 Distance gauge calibration location
8	5.2	Figure 9 Calibration slug at Bottom Dead Center
14	7.5	Figure 10 Wiring diagram
16	8.3	Figure 12 Measure bell housing runout
20	10.1	Figure 13 Disassembly of the weight tray
20	10.2	Figure 14 Disassembly of the encoder
20	10.3	Figure 15 Disassembly of the transducers
21	10.4	Figure 16 Disassembly of the shaft and bearings
21	10.5	Figure 17 Disassembly of the motor drive assembly
22	10.6	Figure 18 Bearing Tube centering
23	10.6	Figure 19 Disassembly of the bearing tube.
23	10.7	Figure 20 Hood guard
27		Figure 21 Touch Panel layout

4300 Wiring Diagrams



4300 Wiring Diagram -230 Volt Model



WIRING DIAGRAM
220-240 V, 1PH
4300-1 4300-2

4300 Touch panel layout






Figure 21

Hood Wiring Diagram



4300 Encoder Wiring Harness



Match-Balance
Series

Automotive Service Equipment Division
Exchange Avenue
Conway Arkansas 72032 USA