



MOTO™ WX280/ WX288

## Your mobile.....



Prolonged exposure to music at full volume on the music player may damage the listener's hearing. Set your phone volume safely. Use only the recommended headphones.

WX280 / WX288

<sup>(1)</sup> Depending on your network operator.

### 1.1 Keys

- Navigation key  
 Confirm an option (press the middle of the key)  
 Access "Varied wallpaper" (long keypress)
- Pick up  
 Send a call  
 Access call memory (Redial) (short keypress)
- Switch on/Switch off the telephone (long keypress)  
 End call  
 Return to the main screen
- Left softkey
- Right softkey
- Access your voicemail (long keypress)
- In edit mode  
 - Short keypress: access the language list  
 - Long keypress: enter zero
- In Edit mode:  
 - Short keypress: change input methods  
 - Long keypress: access the Symbols table
- From main screen  
 - Short keypress: #  
 - Long keypress: activate/deactivate the vibrator  
 In edit mode:  
 - Short keypress: (space)  
 - Long keypress: add a word
- #

2

### 1.2 Main screen icons

- Battery charge level.
- Vibration alert:** your phone vibrates, but neither rings nor beeps except for the alarms.
- Bluetooth status (Blue - Activated).
- Headset connected.
- Call forwarding activated: your calls are forwarded.
- Alarm clock programmed.
- Voicemail message arrived.
- FM radio is on.
- Unanswered calls.
- WAP alerts <sup>(1)</sup>.
- Roaming.
- Line switching <sup>(1)</sup>: indicates the selected line.
- GPRS active connection status (Blue - Activated).  
 Shown only in no ciphering mode while calling, sending/receiving SMS.
- Level of network reception.
- Reception of a message in progress.
- Sending a message.
- Silence mode: your phone neither rings, beeps nor vibrates except for the alarms.
- Message unread.
- Message list is full: your terminal cannot accept any new messages. You must access the message list and delete at least one message on your SIM card.
- Preferred tariff areas <sup>(1)</sup>.
- Antenna off mode.


<sup>(1)</sup> Depending on your network operator.

3


## 2 Getting started .....

### 2.1 Set-up

#### Removing and installing the back cover



#### Installing and removing the battery



#### Inserting and removing the SIM Card



Place the SIM card with the chip facing downwards and slide it into its housing. Make sure that it is correctly inserted. To remove the card, press it and slide it out.

### 2.2 Power on your phone

Hold down the key until the phone powers on.

### 2.3 Power off your phone

Hold down the key from the main screen.

4

## 3 Calls .....

### 3.1 Making a call

Dial the desired number then press the key to place the call. If you make a mistake, you can delete the incorrect digits by pressing the right softkey.

To hang up the call, press the key.

#### Making an emergency call

If your phone is covered by the network, dial emergency number and press the key to make an emergency call. This works even without a SIM card and without typing the PIN code or unlocking the keypad.

### 3.2 Calling your voicemail <sup>(1)</sup>

To access your voicemail, hold down the key.

### 3.3 Receiving a call

When you receive an incoming call, press the key to talk and then hang up using the key.

### 3.4 Available functions during the call

During a call, you can use your directory, your diary, short messages, etc. without losing your correspondent by pressing the key.

<sup>(1)</sup> Contact your network operator to check service availability.

5

## 4 Call register .....

### 4.1 Call memory

You can access your call memory by pressing the key from the main screen.

### 4.2 Billing

You can access different items with this option: Amount, Duration, GPRS counter, Beep duration.

### 4.3 Call settings

You can access a number of items with this option: Call waiting, Call forwarding, Call barring, Caller ID, Line switching, Auto redial.

## 5 Directory.....

### 5.1 Consulting your directory

To access the **directory** from the main screen, press the key and select the icon from the menu.

### 5.2 Creating a file

Select the directory in which you wish to create a file, press the "Options" softkey, select "Create file" then .

6

## 6 Messages .....

### 6.1 Create message

From the main menu select "Messages" to create text/multimedia message. You can type a message but you can also modify a predefined message in **Templates** or customise your message by adding pictures, photos, sounds, titles, etc (only available while editing a MMS). While writing a message, select "Options" to access all the messaging options. You can save your messages that you send often to **Drafts** or **Templates**.

## 7 My settings.....

From the main screen, select the icon menu and select the function of your choice in order to customise your telephone: Color, Theme, Display, Clock, Keys, More settings...

## 8 Tools.....

### 8.1 Bluetooth <sup>(1)</sup>

Access this feature by selecting "Tools" from the main menu, then "Bluetooth".

### 8.2 Organizer

Once you enter this menu from "Tools", there is a monthly-view calendar for you to keep track of important meetings, appointments, etc. Days with events entered will be marked in color.

8

<sup>(1)</sup> WX288 only.

## 9 WAP .....

Access Wap options: Homepage, Bookmarks, Recent pages, Offline pages, Go to URL and Profiles.

## 10 File manager .....

You will have an access to all audio and visual files stored in phone in File manager.

### 10.1 My audios

Choose an audio for an incoming call, a message alert, power on/off ringtone or an alarm and scheduler.

### 10.2 My images

You can select an image or a photo as wallpaper or the ON/OFF screen.

### 10.3 My creations

This feature stores all the photos captured by your mobile phone.

### 10.4 Unknown files

Store files of unsupported format.

### 10.5 Formats and compatibility

- Sounds: midi, amr, ...
- Images: jpg, gif

9

## 11 Games .....

Your phone may include some games.

### 11.1 Game settings

It allows you to manage settings, in which you may set background music, sound effect and vibration alert.

## 12 FM radio <sup>(1)</sup>, <sup>(2)</sup> .....

Your phone is equipped with an FM radio <sup>(1)</sup> with RDS functionality. You can use the application as a traditional FM radio with automatic tuning and saved channels or with parallel visual information related to the radio program on the display, if you tune to stations that offer Visual Radio service. You can listen to it while running other applications.

## 13 Camera .....

Your mobile phone is fitted with a camera for taking photos that you can use in different ways:

- store them in your "File manager".
- send them in a multimedia message (MMS) to a mobile phone or an email address.
- customise your main screen.
- select them as incoming call image to a contact in your directory.

<sup>(1)</sup> The quality of the radio depends on the coverage of the radio station in that particular area.

<sup>(2)</sup> A compatible headset model API701AE7X3 needs to be attached to the device for proper functionality.

10

## 14 Profiles .....

With this menu, you may personalise ringtones for different events and environments.

## 15 Latin input mode .....

To write messages, there are two writing methods:

- Normal: this mode allows you to type a text by choosing a letter or a sequence of characters associated with a key. Press the key several times until the desired letter is highlighted. When you release the key the highlight character is inserted into the text.
- Predictive with the Zi mode: this mode speeds up the writing of your text. Write the word by pressing a key between and and . Press the key once and the word will be modified each time you press a key. As you go on, the word will keep changing. Example: For "Tomorrow", press on the following keys: => Tomorrow
- + key in edit mode  
 Short keypress: access the language list  
 Long keypress: enter zero

11

## Legal and Safety .....

### Battery Use & Safety

**Important: Handle and store batteries properly to avoid injury or damage.** Most battery issues arise from improper handling of batteries, and particularly from the continued use of damaged batteries.

- DON'Ts**
- **Don't disassemble, crush, puncture, shred or otherwise attempt to change the form of your battery.**
- **Don't let the phone or battery come in contact with water.** Water can get into the phone's circuits, leading to corrosion. If the phone and/or battery get wet, have them checked by your carrier or contact Motorola, even if they appear to be working properly.
- **Don't allow the battery to touch metal objects.** If metal objects, such as jewellery, stay in prolonged contact with the battery contact points, the battery could become very hot.
- **Don't place your battery near a heat source.** Excessive heat can damage the phone or the battery. High temperatures can cause the battery to swell, leak or malfunction. Therefore:
- Do not dry a wet or damp battery with an appliance or heat source, such as a hair dryer or microwave oven.
- Avoid leaving your phone in your car in high temperatures.
- DOs**
- **Do avoid dropping the battery or phone.** Dropping these items, especially on a hard surface, can potentially cause damage.
- **Do contact your service provider or Motorola if your phone or battery has been damaged by being dropped or by high temperatures.**

**Important: Use Motorola Original products for quality assurance and safeguards.** To aid consumers in identifying authentic Motorola batteries from non-original or counterfeit batteries (that may not have adequate safety protection), Motorola provides holograms on its batteries. Consumers should confirm that any battery they purchase has a "Motorola Original" hologram.

12

**Note:** Some mobile phones may contain a non Motorola-branded battery without a hologram when purchased. Those batteries are designed for use with your phone. If a replacement is needed, and a Motorola-branded battery is not available, only the type and model that came with your phone are recommended for use.

**Important:** Refer to Motorola's warranty for details of coverage and exclusions.

**Warning:** Use of an improper battery or charger may present a risk of fire, explosion, leakage or other hazard.

**Proper and safe battery disposal and recycling:** Proper battery disposal is not only important for safety, it also benefits the environment. Consumers may recycle their used batteries in many retail or service provider locations. Additional information on proper disposal and recycling may be found on the Web:  
 • [www.motorola.com/recycling](http://www.motorola.com/recycling)  
 • [www.rbr.org/call2recycle/](http://www.rbr.org/call2recycle/) (in English only)

**Disposal:** Promptly dispose of used batteries in accordance with local regulations. Contact your local recycling centre or national recycling organisations for more information on how to dispose of batteries.

**Warning:** Never dispose of batteries in a fire because they may explode.

### Battery Charging

- **Notes for charging your phone's battery:**
- When charging your battery, keep it near room temperature. Never expose batteries to temperatures below 0°C (32°F) or above 45°C (113°F) when charging.
- New batteries are not fully charged.
- New batteries or batteries stored for a long time may take more time to charge.
- Motorola batteries and charging systems have circuitry that protects the battery from damage from overcharging.
- If your battery is fully discharged, the phone may not display a charging indicator during the first 5-15 minutes whilst charging.

English - CBJ3140ALAAB

14

