



MOTOROKR™ U9

User's Guide

HELLOMOTO


Feel It, See It, Hear It! Your MOTOROKR™ U9 phone is made to be held, and made to be seen!



- Transfer your favorite **music** quickly and easily with Microsoft® Windows® Media Player 11, then control music playback with touch sensor keys in the external display (page 48).
- Personalize your phone with floating **animated screensavers** in the external display (page 32).
- Snap pictures automatically with your 2-megapixel multi-shot **camera** (page 55).
- Capture key moments in high-definition **video**, then upload to your blog (page 58).
- Access any **Web** site just like you do on your computer, with your phone's full HTML browser (page 54).
- Read and answer **text messages** in the external display (page 63).


For more information: To read feature instructions on your phone, press  >  **Tools > Help.**

To learn more about your phone, go to www.motorola.ca/U9support. To learn more about accessories, go to www.motorola.ca.


Introducing your new MOTOROKR™ U9 GSM wireless phone.



Tip: Press the *center key*  to open the main menu and select menu options. Press the *clear/back key*  to delete letters or numbers or to go back one menu.




Home Screen




1 Press & hold  until the display lights up, to turn on your phone.

2 Press  to open the Main Menu.

Main Menu



3 Press  up/down/left/right to scroll to a menu feature.

4 Press  to select it.

Note: This is the standard home screen and main menu layout. **Your phone's home screen and main menu may be different.** To change your home screen shortcuts and main menu appearance, see page 38.

Motorola, Inc.
Consumer Advocacy Office
1307 East Algonquin Road
Schaumburg, IL 60196
www.hellomoto.com

Note: Do not ship your phone to the above address. If you need to return your phone for repairs, replacement, or warranty service, please contact the Motorola Customer Support Center at:

1-800-331-6456 (United States)

1-888-390-6456 (TTY/TDD United States for hearing impaired)

1-800-461-4575 (Canada)

Certain mobile phone features are dependent on the capabilities and settings of your service provider's network. Additionally, certain features may not be activated by your service provider, and/or the provider's network settings may limit the feature's functionality. Always contact your service provider about feature availability and functionality. All features, functionality, and other product specifications, as well as the information contained in this user's guide are based upon the latest available information and are believed to be accurate at the time of printing. Motorola reserves the right to change or modify any information or specifications without notice or obligation.

MOTOROLA and the Stylized M Logo are registered in the US Patent & Trademark Office. The Bluetooth trademarks are owned by their proprietor and used by Motorola, Inc. under license. Java and all other Java-based marks are trademarks or registered trademarks of Sun Microsystems, Inc. in the U.S. and other countries.

Microsoft and Windows are registered trademarks of Microsoft Corporation; and Windows XP and Windows Media are trademarks of Microsoft Corporation. Macintosh is a registered trademark of Apple Computer, Inc. All other product or service names are the property of their respective owners.

© 2009 Motorola, Inc., All rights reserved.

Caution: Changes or modifications made in the radio phone, not expressly approved by Motorola, will void the user's authority to operate the equipment.

Software Copyright Notice

The Motorola products described in this manual may include copyrighted Motorola and third-party software stored in semiconductor memories or other media. Laws in the United States and other countries preserve for Motorola and third-party software providers certain exclusive rights for copyrighted software, such as the exclusive rights to distribute or reproduce the copyrighted software. Accordingly, any copyrighted software contained in the Motorola products may not be modified, reverse-engineered, distributed, or reproduced in any manner to the extent allowed by law. Furthermore, the purchase of the Motorola products shall not be deemed to grant either directly or by implication, estoppel, or otherwise, any license under the copyrights, patents, or patent applications of Motorola or any third-party software provider, except for the normal, non-exclusive, royalty-free license to use that arises by operation of law in the sale of a product.

Manual Number: 68000201170-B







contents


menu map	8	talking phone	30
Use and Care	10	handsfree speaker	30
getting started	11	codes & passwords	30
about this guide	11	lock & unlock external keys	31
insert your SIM card	12	lock & unlock phone	31
insert a memory card	13		
battery	14	personalize	32
turn phone on & off	18	animated screensavers in	
make a call	19	external display	32
answer a call	19	profiles	33
end a call	19	time & date	35
store a phone number	19	themes	36
call a stored phone number	20	rearrange home screen shortcuts ...	38
your phone number	20	wallpaper	39
		main menu appearance	39
basics	21	rearrange main menu	39
display	21	display appearance	39
volume	23	clock style	40
side select key/ camera key	24	answer options	40
external display	24		
text entry	25	calls	41
voice commands	28	turn off a call alert	41
		call history	41



redial	41	personal organizer	86
return a call	42	security	88
caller ID	42	fun & games	89
emergency calls	42	service & repairs	90
voicemail	43	SAR Data	91
entertainment	44	EU Conformance	93
music player	44	OSS Information	94
browser	54		
camera	55		
videos	58		
messages	63		
text messaging	63		
connections	68		
file manager	68		
cable connections	69		
Bluetooth® wireless	71		
phone software updates	75		
other features	76		
advanced calling	76		
phonebook	79		
personalize	83		
call times & costs	84		
handsfree	85		
network	86		

menu map

main menu



-  **Zone Vidéotron**
-  **Media**
 - Media Finder
 - Camera
 - Video Camera
 - Voice Recorder
-  **Games & Apps**
-  **Call History**
-  **Internet**
-  **Messages**
 - Messages
 - Create Message
 - Inbox
 - My Folders
 - Templates
 - Drafts
 - Outbox
 - Sent Messages
 - Call Voicemail

-  **Tools**
 - Calendar
 - Download Manager
 - File Manager
 - Memory Card *
 - Music and Sounds
 - Pictures
 - Videos
 - Voice Note
 - Application Downloads
 - Unrecognizable Files
 - My Documents
 - Alarm Clock
 - World Clock
 - Calculator
 - Dialing Services
 - Task List
 - Notes
 - Help

-  **Phonebook**
-  **Settings**
 - (see next page)

This is the standard main menu layout. **Your phone's menu may be different.**

To change your home screen shortcuts and your main menu appearance, see page 38.

Tip: Press  to exit the current menu, or press  to exit all menus.

* optional features

settings menu

- **Profiles**
- **Themes**
- **Home Screen**
 - NavKey Shortcuts
 - Change Wallpaper
 - External Clock Style
- **Connections**
 - Bluetooth®
 - USB Setting
 - Media Synchronization
 - Memory Card
 - Modem
 - USB Printing
 - Voice Networks *
 - Data Connections
- **Call Settings**
 - Speed Dial
 - Call Forward
 - In-Call Setup
 - Hearing Aid
 - In-Call Timer
 - Answer Options
 - In-Call Message Alert
 - Roam Alert
 - Call Waiting
 - Auto-Redial
 - Call Drop Tone
 - Dialing Setup
 - My Caller ID
 - DTMF
 - Hyphenation
 - Search Mode
 - Dialing Prefix
 - Call Barring *
 - Fixed Dialing
 - My SIM Number
 - Active Line *
- **Phone Settings**
 - Display Settings
 - Display Timeout
 - Screensaver
 - Brightness
 - Airplane Mode
 - Battery Meter
 - Time & Date
 - Language
 - **(continued next column)**
- **Phone Settings (continued)**
 - Talking Phone
 - Text Entry
 - Reset
 - Reset All Settings
 - Delete All Data
 - Delete Memory Cards
 - View Memory
 - Properties
 - Legal Notices
 - Java™ System
 - OTA Updates
 - Headset Settings
 - Auto-Answer
 - Voice Dial
 - TTY Settings
- **Internet**
- **Security**
 - Phone Lock
 - External Key Lock
 - Application Lock
 - SIM Lock
 - Change Passwords
 - Certificates
- **Network**
 - Current Network
 - Scan Avail. Networks
 - Find New Network
 - My Network List
 - Search Setup
 - Service Tone
- **Bluetooth**

* optional features

Use and Care

To care for your Motorola phone, please keep it away from:



liquids of any kind

Don't expose your phone to water, rain, extreme humidity, sweat, or other moisture. If it does get wet, don't try to accelerate drying with the use of an oven or dryer, as this may damage the phone.



dust and dirt

Don't expose your phone to dust, dirt, sand, food, or other inappropriate materials.



extreme heat or cold

Avoid temperatures below 0°C/32°F or above 45°C/113°F.



cleaning solutions

To clean your phone, use only a dry soft cloth. Don't use alcohol or other cleaning solutions.



microwaves

Don't try to dry your phone in a microwave oven.



the ground



Don't drop your phone.

getting started





CAUTION: Before using the phone for the first time, read the *Important Safety and Legal Information* guide included in the box.



about this guide

This guide shows how to locate a menu feature as follows:

Find it:  >  **Media** > **Camera**

This means that, from the home screen:

- 1 Press the *center key*  to open the menu.
- 2 Press the *navigation key*  to scroll to  **Media**, and press  to select it.

- 3 Press  to scroll to **Camera**, and press  to select it.

This guide uses the following symbols:

symbols



This means a feature is network, SIM card, or subscription dependent and may not be available in all areas. Contact your service provider for more information.




This means a feature requires an optional accessory.

insert your SIM card


Your *Subscriber Identity Module* (SIM) card stores your phone number and other information.

Caution: Don't bend or scratch your SIM card. Keep it away from static electricity, water, and dirt.


1



2



3



insert a memory card


You can store music, photos, and other multimedia files on an optional, removable microSD memory card.

Caution: Don't bend or scratch your memory card. Keep it away from static electricity, water, and dirt. Turn off your phone before you install or remove the memory card.


Note: Your phone can use a memory card with up to 4 GB capacity (greater than 1 GB storage guaranteed only for Motorola-approved microSD cards).

To insert the memory card:

1



2



To remove the memory card: Lift up the flexible retainer tab, and slide the memory card out of the slot.

battery

battery use & safety

IMPORTANT: HANDLE AND STORE BATTERIES PROPERLY TO AVOID INJURY OR DAMAGE.

Most battery issues arise from improper handling of batteries, and particularly from the continued use of damaged batteries.

DON'Ts

- **Don't disassemble, crush, puncture, shred, or otherwise attempt to change the form of your battery.**
- **Don't let the phone or battery come in contact with water.** Water can get into the phone's circuits, leading to corrosion. If the phone and/or battery get wet, have them checked by your carrier or contact Motorola, even if they appear to be working properly.

- **Don't allow the battery to touch metal objects.** If metal objects, such as jewelry, stay in prolonged contact with the battery contact points, the battery could become very hot.
- **Don't place your battery near a heat source.** Excessive heat can damage the phone or the battery. High temperatures can cause the battery to swell, leak, or malfunction. Therefore:
 - Do **not** dry a wet or damp battery with an appliance or heat source, such as a hair dryer or microwave oven.
 - Avoid leaving your phone in your car in high temperatures.

DOs

- **Do avoid dropping the battery or phone.** Dropping these items, especially on a hard surface, can potentially cause damage.
- **Do contact your service provider or Motorola if your phone or battery has been damaged from dropping or high temperatures.**

IMPORTANT: USE MOTOROLA ORIGINAL PRODUCTS FOR QUALITY ASSURANCE AND SAFEGUARDS.

To aid consumers in identifying authentic Motorola batteries from non-original or counterfeit batteries (that may not have adequate safety protection), Motorola provides holograms on its batteries. Consumers should confirm that any battery they purchase has a “Motorola Original” hologram.

Motorola recommends you always use Motorola-branded batteries and chargers.

Motorola mobile devices are designed to work with Motorola batteries. If you see a message on your display such as **Invalid Battery** or **Unable to Charge**, take the following steps:

- Remove the battery and inspect it to confirm that it has a “Motorola Original” hologram;
- If there is no hologram, the battery is not a Motorola battery;
- If there is a hologram, replace the battery and retry charging it;
- If the message remains, contact a Motorola Authorized Service Center.

Important: Motorola’s warranty does not cover damage to the phone caused by non-Motorola batteries and/or chargers.

Warning: Use of a non-Motorola battery or charger may present a risk of fire, explosion, leakage, or other hazard.

PROPER AND SAFE BATTERY DISPOSAL AND RECYCLING

Proper battery disposal is not only important for safety, it benefits the environment. Consumers may recycle their used batteries in many retail or service provider locations. Additional information on proper disposal and recycling may be found on the Web:

- www.motorola.com/recycling
- www.rbric.org/call2recycle/
(in English only)


Disposal: Promptly dispose of used batteries in accordance with local regulations. Contact your local recycling center or national recycling organizations for more information on how to dispose of batteries.




Warning: Never dispose of batteries in a fire because they may explode.

insert the battery

1




2



charge the battery

New batteries are not fully charged. Open the protective cover on



your phone's micro USB port, and insert the battery charger connector into your phone. Make sure the Motorola symbol on the battery charger connector is facing **up**, as shown in the illustration. Plug the other end of the battery charger into an electrical outlet.

The battery charge indicator light on your phone shows when the battery is charging. The display shows **Charge Complete** when finished.

Notes for charging your phone's battery:

- When charging your battery, keep it near room temperature. Never expose batteries to temperatures below 0°C (32°F) or above 45°C (113°F) when charging.
- New batteries are not fully charged.
- New batteries or batteries stored for a long time may take more time to charge.
- Motorola batteries and charging systems have circuitry that protects the battery from damage from overcharging.






Note: You can charge your battery by connecting a cable from your phone's micro USB port to a USB port on a computer. Both your phone and the computer must be turned on, and your computer must have the correct software drivers installed. The Motorola Original USB










cable and supporting software are sold separately.

Caution: If your computer has a USB hub with multiple USB devices attached, connecting your phone to the USB hub could potentially overload the phone's battery. To avoid any possibility of overcharging, you should connect your phone to a dedicated USB port on the computer.


extend battery life


- To turn off **Bluetooth®** power when you're not using it, press 
>  **Settings** > **Connections** > **Bluetooth**, press **Options** > **Setup Bluetooth** > **Bluetooth Power** > **Off**.
- To make your **display** turn off sooner, press  >  **Settings** > **Phone Settings** > **Display Settings** > **Display Timeout** > **5 Seconds**.
- To turn off the **screensaver** in the internal display, press 

>  **Settings** > **Phone Settings**
> **Display Settings** > **Screensaver** > **Off**.


- To turn off the **animated screensaver** in the external display, press  >  **Settings** > **Themes** press **Options** > **Edit**, press  right to select the **images** tab , press  down to scroll to **External Screensaver**, press  to select it, scroll to **None**, press  to select it.

turn phone on & off

Press and hold the **power/end key**  for a few seconds, or until the display turns on or off.




make a call


Open the flip, then enter a phone number and press the **send key** .

Tip: To **voice dial** a call, see page 28.

answer a call

When your phone rings and/or vibrates, open the phone flip or press  to answer.

end a call

To hang up, close the phone flip or press .

store a phone number

You can store a phone number in your phonebook.

Note: You can store a new contact in **phone memory**, or store the contact both in phone memory and on your **SIM card**. When you choose to store a contact to both locations, only the contact's name and phone number are stored on the SIM card.

To store a phone number:

- 1 Enter a phone number in the home screen.
- 2 Press **Save**.
- 3 Enter a name for the phone number, and enter other information as desired.
- 4 If you want to save the number on your SIM card in addition to storing it in phone memory, select **Save to SIM Card**.
- 5 Press **Save** to store the contact.


To edit or store additional information about the contact, see page 79.


call a stored phone number

To call a number stored in your phonebook:

Find it:  >  Phonebook

- 1 Scroll to the contact.

Shortcut: In the contact list, press keypad keys to enter the first letters of the contact you want. Press  to go to the contact.

- 2 Press  to call the contact.

Note: If you've got contacts stored on your SIM card, but the contacts aren't visible when you open the phonebook, you need to copy the contacts into phone memory.

Press **Options > Import Contacts > SIM Card**, press **Options > Select All**, press **Import**.

your phone number

To see your phone number:

Find it:  >  Settings > Call Settings > My SIM Number


To see your phone number while you're on a call, press **Options > My Tel. Numbers**.

To store or edit your name and phone number on your SIM card, select the field you want to edit. If you don't know your phone number, contact your service provider.


basics


display

The *home screen* appears when you turn on the phone.




Note: Your home screen may look different, depending on your service provider.

To dial a number from the home screen, press number keys and .

Press the *center key*  or the **Main Menu** soft key to open the main menu.



Press **Shortcuts** in the home screen to access some frequently-used phone features.

Press the *navigation key*  up, down, left, or right in the home screen to open basic features. To show, hide, or change feature icons in the home screen, see page 38.


Status indicators appear at the top of the home screen:





1 Signal Strength Indicator – Show the strength of the wireless network connection.


2 EDGE/GPRS Indicator – Shows when your phone is using a high-speed *Enhanced Data for GSM Evolution* (EDGE) network connection , or *General Packet Radio Service* (GPRS) network connection .

3 Bluetooth Indicator – Shows Bluetooth status:

 (solid blue) = Bluetooth powered on

 (solid green) = Bluetooth connected


 (flashing blue) = Bluetooth discoverable mode


4 Messaging Presence Indicator – 


Shows your instant messaging (IM) status:

 (green) = online  = offline


 = busy  = discrete


 (gray) = invisible to IM


5 IM Indicator – Shows when you receive a new IM message. 


6 Message Indicator – Shows when you receive a new text or voice message. Indicators can include: 




 = text message

 = voicemail message

 = text and
voice message

 = line 1
call forward on

 = line 2
call forward on


- 7 Location Indicator** – Shows  when your phone is providing location information to the network, or  when location information is turned off. 


- 10 Battery Level Indicator** – Vertical bars show the battery charge level. Recharge the battery when your phone shows **Low Battery**.

- 8 Profile Indicator** – Shows the alert profile setting:



 = ring only



 = ring
and vibrate

 = vibrate
only

 = vibrate
then ring


 = silent

- 9 Active Line Indicator** – Shows  to indicate an active call, or  to indicate when call forwarding is on. Indicators for dual-line-enabled SIM cards can include:


 = line 1 active  = line 2 active

volume


Press the *volume keys* to:




- turn off an incoming call alert
- change earpiece or speakerphone volume during a call
- change playback volume for a song or video
- set your phone's alert profile in the home screen (press the volume keys)

to scroll to a profile, then press  or the side select key to select it)

side select key/ camera key

The *side select key* gives you another way to do things. For example, when you scroll to a menu item, you can press the side select key to select it (instead of pressing .



Shortcut: From the home screen, press the side select key to activate the camera.

external display

When your phone flip is closed, the external display shows the time and indicates phone status, incoming calls, and other events.

set phone ring style in the external display

From the external display, press the external volume keys on the side of your phone to scroll to a profile, then press the side select key to select it.

use touch keys in the external display

When playing music on your phone, you can close the phone flip and use touch keys to control song playback in the external display (see page 48).


Note: Only the music player uses touch key controls in the external display.

text entry

Some features let you enter text.

Press **#** to select a text entry mode.

Character Counter



Change text entry options.

Flashing cursor indicates insertion point.

text entry modes

Ab "word" mode (see page 26)

Ab "abc" mode (see page 26)

text entry modes


123 numeric mode (see page 27)

☺ symbol mode (see page 28)

To **change** your global text entry settings or languages:


Find it:  >  Settings > Phone Settings > Text Entry


Change text case: In a text entry screen, press **0** to change text case to all capital letters (**!**), next letter capitalized (**!**), or next letter lowercase (no symbol).




Set word learning: Your phone can learn the words you enter, to improve text prediction and completion. In a text entry screen, press **Options** > **Text Entry** > **Set Text Prediction** > **Learn My Words**. Your phone shows  when word learning is active.

Set text completion: Set your phone to complete words based on the characters you enter. In a text entry screen, press **Options**



> **Text Entry** > **Set Text Prediction** > **Offer Completions**.

Your phone shows  when text completion is active.





Enter punctuation: In a text entry screen, press  to enter punctuation or other characters.


Edit or delete text: In a text entry screen, press  to move the cursor to the right of text you want to edit. Press the *clear/back key*  to delete the character left of the cursor. Hold  to delete word by word.



word mode


To switch to “word” predictive text entry mode, press  in a text entry screen until you see  in the display.


Word mode lets you enter words using one keypress per letter. The phone predicts each word as you enter it.


For example, if you press    , your display might show:


Press  to enter **Prog** & a space.

You can turn text completion on () or off () .





Press  up/down to see other words.

Press  to select a word.

Press  to delete character to left of cursor.


abc mode

To switch to “abc” text entry mode, press  in a text entry screen until you see  in the display.

To enter text, press a keypad key repeatedly to cycle through the letters and number on the key. Repeat this step to enter each letter.

For example, if you press **7** one time, your display might show:

Character displays at insertion point.



After two seconds, the character is accepted and the cursor moves to the next position.

When text completion is activated, your phone tries to guess the rest of the word:

- Press **⬇** to select the suggested word.
- Press **⬆** right to enter the suggested word and a space.
- If you want a different word, press keypad keys to enter the remaining letters.

numeric mode

Press **#** in a text entry screen until you see **123**. Press the number keys to enter the numbers you want.

Tip: Just need one number? To enter a number quickly, press and hold a number key until the number appears.

symbol mode

Press **#** in a text entry screen until you see **#**. The display shows the symbol associated with each keypad key. Press **↕** up/down repeatedly to see different symbols. To insert a symbol, press its key, or scroll to it and press **⬇**.

voice commands

You can use voice commands to tell your phone what to do.

Note: Not all languages support voice commands.

voice dial a call

You can dial a contact list entry by speaking its name, or dial any phone number by speaking its digits.

- 1 Press the external *voice command key* on the side of your phone. The phone loads the voice recognition software,

then prompts you to say a command or name.

- 2 Wait for the beep, then say the name of an entry as it appears in your contact list. Your phone confirms the name and makes the call.

or

Say “Dial Number.” Your phone prompts you to speak the digits in the phone number. Speak the digits. Your phone confirms the number and makes the call.

Tips:

- You can say a contact’s name and number type together. For example, say “John Smith mobile” to call the mobile number stored for John Smith.
- For voice command help, press the voice command key on the side of your phone, then press **Help**.

voice activate phone functions

You can use voice commands to open applications and perform many basic phone functions.

- 1 Press the external voice command key on the side of your phone. The phone prompts you to say a command.
- 2 Wait for the beep, then say a command from the list.

voice commands
" <i>contact name</i> "
"Dial Number"
"Send Message To <i>contact name</i> "
"Check Calendar"
"Check New Message"
"Check New Email"
"Add New Contact"
"Talking Phone"
"Check Battery"
"Check Signal"

voice commands
"Check Time"
"Check Date"
"Open Setup"
"Open Recent Calls"
"Open Theme"
"Open Camera"
"Open Web Access"
"Set Normal"
"Set Vibrate"
"Set Silent"
"Set Ring"
"Set Airplane"
"Set Airplane Off"

Tip: Press and release the voice command key on the side of your phone to see the list of voice commands.

talking phone

You can set your phone to recite caller ID information for incoming messages, read the names of menu features or contact list entries, read messages you receive, and provide audio feedback for phone functions.

Find it:  >  **Settings** > **Phone Settings**
> **Talking Phone**

Shortcut: Press and hold the external voice command key on the side of your phone. When the phone prompts you to say a command, say “Talking Phone.”

handsfree speaker

During a call, press **Options** > **Speaker On** to turn the handsfree speaker on. Your display shows the speakerphone indicator until you turn it off (press **Options** > **Speaker Off**) or end the call.

Note: The use of wireless phones while driving may cause distraction. Discontinue a


call if you can't concentrate on driving. Additionally, the use of wireless devices and their accessories may be prohibited or restricted in certain areas. Always obey the laws and regulations on the use of these products.

codes & passwords

Your phone's four-digit **unlock code** is originally set to **1234**. The six-digit **security code** is originally set to **000000**. If your service provider did not change these codes, you should change them:

Find it:  >  **Settings** > **Security**
> **Change Passwords**

You can also change your **SIM PIN** codes or call barring password.

If you forget your unlock code: At the **Please verify the Unlock Code** prompt, try entering **1234** or the last four digits of your phone number. If that doesn't work, press  to enter your six-digit security code instead.

If you forget other codes: If you forget your security code, SIM PIN code, PIN2 code, or call barring password, contact your service provider.

lock & unlock external keys

You can lock the external phone keys when the phone flip is closed, to prevent accidental keypresses when playing music, or when carrying the phone in a purse or pocket.

To **automatically lock** the external keys when the phone is idle and the phone flip is closed:

Find it:  >  Settings > Security > External Key Lock > Timer

You can set the time delay for locking the external keys (**2 seconds**, **4 seconds**, or **8 seconds**). The keys lock when you close the phone flip, and unlock when you open the phone flip.

To **turn off** the automatic lock feature:

Find it:  >  Settings > Security > External Key Lock > Timer > Off

To **unlock** the external keys when the flip is closed: Press and hold the side select key.

lock & unlock phone

You can lock your phone to keep others from using it. To lock or unlock your phone, you need the four-digit unlock code.

To **manually lock** your phone:

Find it:  >  Settings > Security > Phone Lock > Lock Now

To **automatically lock** your phone whenever you turn it off:






Find it:  >  Settings > Security > Phone Lock > Lock at Power On > On


personalize

animated screensavers in external display

Personalize your phone with floating animated screensavers in the external display:

Find it:  >  **Settings** > **Themes** press **Options** > **Edit**

- 1 Press  right to select the **images** tab .
- 2 Press  down to scroll to **External Screensaver**, then press .
- 3 Press  up/down to scroll to an animated screensaver.

Tip: Press  to preview the highlighted screensaver before you select it.

- 4 Press **Select** to select the highlighted screensaver.
- 5 Press **Save** to save your setting.

The **External Screensaver** appears in the external display when you close the phone flip.

Note: Changing the animated screensaver does **not** change the background image behind the clock in the external display.


shortcuts to themes

You can create a shortcut in the home screen that takes you directly to themes. To create a home screen shortcut, see page 38.

profiles

You can quickly change your phone's alert style or profile to match your activity or environment. Each profile uses a different set of ringtones or vibrations for incoming calls and other events. The alert profile indicator shows at the top of the home screen).

 Ring Only

 Ring and Vibrate

 Vibrate Only

 Vibrate then Ring

 Silent

To change your profile: From the home screen, press the external volume keys on the side of your phone. Alternatively, from the home screen press **Shortcuts** > **Change Alert Style** or **Change Profile**.

The **Silent** profile silences your phone until you set another profile.

Shortcut: From the home screen, press and hold **[#]** to quickly set the profile to







Vibrate Only.



change alert style settings

You can change the ringtones that a standard alert style uses to notify you of incoming calls and other events. You can also change the alert style's ring volume, keypad tone volume, and media playback volume settings. For dual-line-enabled SIM cards, you can set different ringtones to identify incoming calls on line 1 or line 2.

Note: You can't set a ringtone for the **Silent** alert style, or change some settings for some alert styles.

Find it:  >  **Settings** > **Profiles** > **Alert Style** > *alert style*

- 1 Press  or  to select the **alerts** tab , **volume** tab , **messages** tab , or **settings** tab .

- 2 Press  up/down to scroll to the alert or volume setting you want to change, then press .
- 3 Select the setting value you want.
- 4 Press **Back** to exit and save your changes.

To **reset** the default settings for an alert style:

Find it:  >  **Settings** > **Profiles** > **Alert Style**
> *alert style*, press **Options** > **Reset**

create a new profile

To create a **new** profile with the ringtones and volume settings you specify:

Find it:  >  **Settings** > **Profiles** > **Alert Style**
> *alert style*

- 1 Change alert style settings as described in the previous section.
- 2 Press **Options** > **Save as Profile**.
- 3 Enter a name for the profile, then press **Save** to save it.

To create **additional** profiles:

Find it:  >  **Settings** > **Profiles**, press **Options** > **Create Profile**

Note: Profile alert settings also can be set by the theme. When you apply a new theme, you can choose to apply the theme's alert settings to the current profile. Selecting this option **changes** the current profile to use the theme alert settings.

edit or delete profiles

To **edit** a profile:

Find it:  >  **Settings** > **Profiles**, scroll to the profile, press **Options** > **Edit**

Note: You can't edit the **Silent** profile, or change some settings for some profiles.

To **delete** a user-defined profile:

Find it:  >  **Settings** > **Profiles**, scroll to the profile, press **Options** > **Delete**

restore alert style settings

To delete all user-defined profiles and restore your phone's original alert style settings:

Find it:  >  Settings > Profiles, press Options > Restore Sound Settings

time & date

Your phone can automatically update the time and date. It uses the time and date for the **Calendar**.



To **synchronize** time and date with the network:




Find it:  >  Settings > Phone Settings > Time & Date > Auto-Update Time > On

To **manually** set the time and date:

Find it:  >  Settings > Phone Settings > Time & Date > Auto-Update Time > Off, then > Time and Date

To adjust time and date, press  left/right to scroll to a setting, then press  up/down to change it. Press **Set** to save your settings.



To show a **12-hour or 24-hour** digital clock in the home screen:

Find it:  >  Settings > Phone Settings > Time & Date > Time Format > 12 Hour Clock or 24 Hour Clock

To set the **date format** in the home screen:

Find it:  >  Settings > Phone Settings > Time & Date > Date Format

To set your **time zone**:

Find it:  >  Settings > Phone Settings > Time & Date > Time Zone, then select a city in your time zone

Shortcut: Press keypad keys to enter the first letters of the city you want.

themes

Use a phone *theme* to personalize the look and sound of your phone. Most themes include a wallpaper image, screensaver image, and ringtones.



To **apply** a theme:

Find it:  >  **Settings** > **Themes** > *theme*

To **download** a theme, see page 54.

To **delete** a theme:



Find it:  >  **Settings** > **Themes**, scroll to the theme, then press **Options** > **Manage** > **Delete**

Note: You can delete only downloaded themes or custom themes you create.

preview ringtones

To preview the ringtones on your phone, and choose the ringtone a theme uses to notify you of incoming calls:







Find it:  >  **Settings** > **Themes**, press **Options** > **Edit** > **Ringtone** > **Ringtones** > **Sounds & Ringtones** > **Preloaded Ringtones**

- 1 Press  up/down to scroll and listen to each ringtone in turn.
- 2 Press  to select the highlighted ringtone.
- 3 Press **Save** to save your selection.

apply a photo as wallpaper

Use one of your photos as a background *wallpaper* image in the home screen:

Find it:  >  **Settings** > **Themes**, press **Options** > **Edit**

- 1 Press  right to select the **images** tab .
- 2 Press  down to scroll to **Wallpaper**, then press  to select it.
- 3 Press  down to scroll to **Preloaded Wallpaper**, then press  to select it.





- 4 Scroll to the photo you want to use, then press **Select**.

Note: If the photo is stored on an installed memory card, select **Back to Graphics > Back to Pictures > Back to My Files > Memory Card > Pictures** to search for photos on the memory card.

- 5 Press **Save** to save your selection.






Photos that you copy to your phone from another device may not scale correctly when applied as wallpaper images. To **resize a wallpaper photo** so it displays at the correct size:

Find it:  >  **Settings > Themes**, press **Options > Edit**

- 1 Press  right to select the **images** tab .
- 2 Press  down to scroll to **Wallpaper Layout**, then press  to select it.
- 3 Scroll to **Fit-to-Screen**, then press **Select**.
- 4 Press **Save** to save the setting.

modify a theme

Find it:  >  **Settings > Themes**, scroll to the theme, press **Options > Edit**

- 1 Press  left/right to select the **sounds** tab  or **images** tab .
- 2 Press  up/down to scroll to the setting you want to change, then press .
- 3 Scroll to the image or sound file you want, then select it.
- 4 Press **Save** to save your theme changes.

The **Wallpaper** appears as a background image in your home screen.

The **Screensaver** appears in the display after a specified period of inactivity.

Skins set the look and feel of your phone's display.

To **reset** the standard settings for a modified theme:

Find it:  >  Settings > Themes > *theme*, press Options > Manage > Reset

To **restore** the default theme on your phone:

Find it:  >  Settings > Themes, press Options > Manage > Restore to Default

create a new theme

Find it:  >  Settings > Themes, press Options > Create Theme or Create a Copy

rearrange home screen shortcuts

From the home screen, you can press the navigation key left, right, up, or down as shortcuts to your favorite features. You can change the shortcuts to suit your needs.




To **change** navigation key shortcut icons in the home screen:

Find it:  >  Settings > Home Screen > NavKey Shortcuts > Left, Right, Up, or Down

Select a direction, then choose the feature you want to open when you press the navigation key in that direction.

To **show or hide** navigation key shortcut icons in the home screen:

Find it:  >  Settings > Home Screen > NavKey Shortcuts > Icon Display > Show or Hide

Note: You can press  to select the features in the home screen even when the icons are hidden.

wallpaper

Change the background wallpaper image in the home screen:

Find it:  >  Settings > Home Screen > Change Wallpaper > Graphics > Preloaded Wallpaper, scroll to an image, press **Select**

The new wallpaper is applied to the current theme.

main menu appearance

You can personalize the main menu to appear as a grid of graphic icons, a text-based list, or a set of spinning menu icons that you can scroll through:

Find it: From the main menu, press **Options** > View By > Grid or List or Spinner

rearrange main menu

You can change the order of the main menu features.

From the main menu, press **Options** > Reorder, scroll to the feature you want to move, press **Grab**, scroll to the destination location, press **Insert**.

display appearance

To set the **brightness** of your internal display:

Find it:  >  Settings > Phone Settings > Display Settings > Brightness

To save battery life, the **display** can turn off when you're not using your phone. To set the display timeout delay interval:

Find it:  >  Settings > Phone Settings > Display Settings > Display Timeout

To turn the internal display **screensaver** on or off:

Find it:  >  **Settings** > **Phone Settings**
> **Display Settings** > **Screensaver** > **On** or **Off**

Tip: To extend battery life, turn off the screensaver.

clock style

Change the clock style in the external display:


Find it:  >  **Settings** > **Home Screen**
> **External Clock Style** > **Digital** or **Analog**

answer options

You can use different ways to answer an incoming call. To turn on or turn off an answer option:

Find it:  >  **Settings** > **Call Settings**
> **In-Call Setup** > **Answer Options**

options	
Any Key Answer	Answer by pressing any key.
Open to Answer	Answer by opening the phone flip.

Note: You can always press  to answer a call.

calls

turn off a call alert


Press the external volume keys on the side of your phone to turn off the ringer before answering a call.


call history




Your phone keeps lists of incoming and outgoing calls, even for calls that didn't connect. The most recent calls are listed first. The oldest calls are deleted as new calls are added.



Find it:  >  Call History

Shortcut: Press  in the home screen to go to the **Dialed Calls** list.


- 1 Press  left/right to select a call list: **All Calls**, **Dialed Calls**, **Answered Calls**, **Missed Calls**, or **Frequent Calls**.


- 2 Press  up/down to scroll to a phone number.


Icons indicate if the call was incoming , outgoing , or missed . A check mark next to the icon indicates a connected call.

- To call the number, press .
- To check if a missed call left you a voicemail message, see page 43.
- To see call details (like time and date), press .
- Press **Options** to perform other operations on the number (send a message, save to contacts), or to set recent call options.

redial

- 1 Press  from the home screen to see the **Dialed Calls** list.



- 2 Scroll to the number you want to call, then press .

If you hear a **busy signal** and see **Call Failed**, press  or **Retry** to redial the number. When the call goes through, your phone shows **Connected** and connects the call.



return a call

Your phone keeps a record of your unanswered calls, and shows **X Missed Calls**, where **X** is the number of missed calls.

When you see the **X Missed Calls** message, press  to see the **Missed Calls** list. Scroll to the call you want to return, then press .

caller ID

Calling line identification (caller ID) shows the phone number for an incoming call in your phone's display.



Your phone shows the caller's name and picture when they're stored in your contact



list, or **Incoming Call** when caller ID information isn't available.

Note: Picture IDs aren't available for contacts stored on the SIM card.

Tip: Want to know who's calling without even looking at your phone? To give one of your contacts a special ringtone, see page 80.

To show or hide your phone number for the next outgoing call, enter the number you want to call, then press **Options** > **Show ID** or **Hide ID**.

To show or hide **your phone number** for all calls:


Find it:  >  **Settings** > **Call Settings** > **Dialing Setup** > **My Caller ID** > **All Calls** > **Show ID** or **Hide ID**

emergency calls


Your service provider programs one or more emergency phone numbers, such as 911 or

112, that you can call at any time, even when your phone is locked or the SIM card is not inserted.


Note: Check with your service provider, as emergency numbers vary by country. Your phone may not work in all locations, and sometimes an emergency call cannot be placed due to network, environmental, or interference issues. Do not solely rely on your wireless phone for essential communications such as medical emergencies.

To make an emergency call: Turn your phone on, exit any open application such as games, dial the emergency number, then press the *send key*  to call the emergency number.

voicemail


Your network stores the voicemail messages you receive. To listen to your messages, call your voicemail number. 

Note: Your service provider may include additional information about using this feature.

When you **receive** a voicemail message, your phone display shows **New Voicemail** and the new message indicator .

To **check** voicemail messages:

Find it:  >  Messages > Messages > Call Voicemail

Shortcut: Your service provider may store your voicemail phone number in speed dial location #1. If so, you can press and hold  in the home screen to listen to your voicemail message(s).

entertainment

music player

Copying and syncing music between your phone and computer has never been easier, with Microsoft® Windows® Media Player 11.

To listen to music on your phone, you need to:

- 1 Load music on your computer.
- 2 Transfer music from the computer to your phone.
- 3 Use the music player to play and manage music files on your phone.

Note: The unauthorized copying of copyrighted materials is contrary to the provisions of the Copyright Laws of the United States and other countries. This device is intended solely for copying non-copyrighted materials, materials in

which you own the copyright, or materials which you are authorized or legally permitted to copy. If you are uncertain about your right to copy any material, please contact your legal advisor.

1. load music on your computer

You can **load song files from a music CD** onto your computer:

- 1 Insert the music CD in your computer's CD drive.
- 2 Launch Windows Media Player 11.
- 3 Copy the music CD to the media player library (also called *ripping* the CD).

If your computer is connected to the Internet, the media player may retrieve CD information such as song titles, album name, artist name, and album artwork. This

information will display in your phone's music player.

set the default song format and bit rate on your computer

Microsoft® Windows® Media Player 11 lets you adjust format and bit rate settings to optimize sound quality or increase the number of song files you can store on your phone.

Windows Media Audio format offers the optimal balance between file size and sound quality. Song files in this format tend to require more storage space than files that use Windows Media Audio Pro format.

Windows Media Audio Pro format is designed for use in portable devices with limited storage capacity. The format provides improved sound quality at lower bit rates.

MP3 format is the most popular format for distributing music on the Web. This format offers high sound quality at a reasonable file size.

To set the default file format and bit rate:

- 1 Insert the music CD in your computer's CD drive.
- 2 Launch Windows Media Player 11.
- 3 Select the Rip tab in Windows Media Player 11.
- 4 Click the Rip tab down arrow, then choose Format > Windows Media Audio, Windows Media Audio Pro, or mp3.

- 5 Click the Rip tab down arrow again, then choose Bit Rate > *bit rate*.

Tip: To maximize the number of songs you can store on your phone, set the bit rate to 128 Kbps or lower. Use the lowest bit rate that provides an acceptable sound quality.

convert iTunes AAC files to MP3 files on your computer

Use the iTunes desktop application to convert standard iTunes AAC files to MP3 files that are compatible with Windows Media Player 11.

Note: The iTunes desktop application can only convert AAC files ripped from a music CD. It can't convert music files purchased from the iTunes store.

- 1 Open the iTunes desktop application on your computer.
- 2 Select Edit > Preferences, then click the Advanced tab and click Importing.

- 3 Open the Import Using pop-up menu, then select the MP3 Encoder option. Click OK to save your settings.

- 4 Select one or more songs in your iTunes music library, then choose Advanced > Convert Selection to MP3.

The converted MP3 file copies appear in your computer's music library alongside the original AAC files.

2. transfer music to your phone



Use Windows Media Player 11 to transfer music from the computer to your phone. (If necessary, you can download Windows Media Player 11 at www.microsoft.com/windowsmedia).

Note: Windows Media Player 11 requires Windows XP™ or later to run. If you are using an earlier version of Windows OS, see page 51 to manually transfer music to your phone.

Note: Windows Media Player 11 can copy and sync music files only to the memory card in your phone. To copy files to phone memory, see page 51 to manually transfer music to your phone.

Note: Windows Media Player 11 can only be used to copy music files to your phone. You can't use Windows Media Player 11 to copy pictures or videos to the phone.

on your phone

Insert a memory card in your phone (see page 13), then press  >  **Settings**
> **Connections** > **USB Setting** > **Media Synchronization**

Attach the Motorola Original USB cable to the micro USB port on your phone and to an available USB port on your computer. The Motorola Original USB cable and supporting software are sold separately.



Note: Some phone functions are temporarily unavailable when a USB connection is active.

on your computer

Run Windows Media Player 11. Your phone appears in the upper right corner of the Windows Media Player 11 screen, and the music files stored on the phone's memory card are listed on the left side of the screen.

- 1 Select the Sync tab in Windows Media Player 11.
- 2 Drag and drop songs or playlists onto the Sync List on the right side of the Windows Media Player 11 screen.
- 3 Click Start Sync to copy the songs onto the phone's memory card.
- 4 When you finish, disconnect your phone from the computer.

3. play music

To play music on your phone:

Find it:  >  **Media** > **Media Finder**
> **Music Library** > *category* > *song name*


Select a song or playlist from the following categories: **Recently Played**, **Shuffle Songs** (play all songs in random order), **All Songs**, **Playlists**, **Artists**, **Albums**, **Genres**, or **Composers**.

Note: If you receive a call during a song, the song pauses until the call is over.


flip closed



When a song or playlist starts to play, close the phone flip and use the touch keys to control song playback in the external display.

Tip: For best results, use the flat part of your finger to activate the touch key controls.




flip open

Use the navigation key  to control song playback when the phone flip is open.

Press  up to pause/play, press down to stop. Press  left/right to skip to previous/next song.


Timer Shows % Played



Select & adjust music player options.

Return to previous screen.

When a song is playing, press **Options** to select music player options:



options	
Hide	Hide the music player while music plays. To see the music player again, go to the home screen, then press  up.
Manage	Show song Properties , such as file name, type, and size.
Remove	Delete the song file.
Send to	Send the song in a message or email, or send it to another device over a Bluetooth® connection.
Apply to	Add the song to a playlist or make it a ringtone.

use Bluetooth® stereo headphones




Connect your phone with optional Bluetooth stereo headphones to listen to music stored on your phone.

To connect your phone to a set of Bluetooth stereo headphones for the first time, make sure the headphones are **on** and **ready** in *pairing* or *bonding* mode (see the device user's guide).

Find it:  >  **Settings** > **Connections**
> **Bluetooth**, press **Options** > **Search For Device**
> **Headset**

Your phone lists the Bluetooth audio devices it finds within range.

- 1 Scroll to the stereo headphones in the list.
- 2 Press  to connect with the stereo headphones.

options

Use Bluetooth/Use Handset To send the audio to a Bluetooth® headset, turn on Bluetooth power, then select **Use Bluetooth** to connect to a recognized Bluetooth headset or search for a new headset.

When a Bluetooth audio connection is active, select **Use Handset** to drop the Bluetooth connection and switch the audio back to the phone.

Note: This option appears only when Bluetooth power is turned on.

Setup Customize settings.

During a song, the music player shows the song title, artist, album, and artwork, if available.

lock external phone keys

You can lock the external phone keys and touch keys when the phone flip is closed, to prevent accidental keypresses while playing a song or playlist.

To **manually lock** the external keys: Close the phone flip, then press and hold the side select key. The keys remain locked until you open the phone flip.

To **automatically lock** the external keys, see page 31.

manually transfer music to your phone or memory card

Without using Windows Media Player 11, you can manually copy or sync music files from the computer to phone memory, or to an optional microSD memory card in the phone. (To insert a memory card, see page 13).

supported audio formats

Before you copy audio files to your phone, make sure the files are in a format the phone recognizes: AMR-NB, AMR-WB, AAC (MPEG4 AAC-LC), AAC+; Enhanced AAC+, MP3, Real Audio 8 LBR (Cook), Real Audio 8 Sipro (ACELP®.net), and Real Audio 10.

on your phone

Press  >  Settings > Connections > USB Setting > Memory Card

Attach the Motorola Original USB cable to the micro USB port on your phone and to an available USB port on your computer. The Motorola Original USB cable and supporting software are sold separately.



on your computer

Your phone and memory card appear as removable disks on your computer.

- 1 Find where your phone and memory card appear as Removable Disk icons.


On a Windows PC, this is the My Computer window. On a Macintosh® computer, it's on the desktop.

- 2 Double-click the Removable Disk icon for your phone or memory card.
- 3 To copy the desired files onto the phone or memory card, drag and drop them onto the appropriate removable disk icon.
- 4 When you finish, remove the phone safely from your computer:
 - **If you are using a PC**, click the Safely Remove Hardware icon in the system tray at the bottom of your computer screen, then select Safely Remove USB Mass Storage Device.
 - **If you are using a Mac**, select and drag the Removable Disk icon to the Trash.

customize the music player

Find it:  >  Media > Media Finder
> Music Library, press Options > Setup

You can select the following options:



options	
Shuffle	Play songs in a random order.
Equalizer	Set the equalizer level for improved sound definition.
Auto- Repeat	Replay the song or playlist when the last file finishes playing.
Spatial Audio	Set separation level for a stereo headset or headphones.
Bass Boost	Set the bass level.
Internet Connection	Set your Internet connection preferences. 

When you scroll to a song in a list and press **Options**, you may see additional options for the song and list, such as **Delete**, **Send to**, and **Apply to**.

create a playlist

create a playlist on your computer

Use Windows Media Player 11 to create a playlist of music files stored on the computer.





On your phone, press  >  **Settings**
> **Connections** > **USB Setting** > **Memory Card**.

Connect your phone to the computer through a USB cable connection, then drag and drop the playlist onto the phone or memory card.



create a playlist on your phone

Find it:  >  **Media** > **Media Finder**
> **Music Library** > **Playlists**, press **Options**
> **Create New Playlist**


1 Enter a name for the playlist.

- 2** Select a storage location for the playlist (**Memory Card** or **Phone Memory**), then press **Save**.
- 3** Scroll to the playlist you created, and press  to select it.
- 4** Scroll to **Add Songs**, and press  to select it.
- 5** Scroll to **All Songs**, **Artists**, **Albums**, **Genres**, or **Composers**, and press  to select it.
- 6** Scroll to the songs you want to add, and press  to select them.
- 7** Press **Add** to add the selected songs to the playlist.
- 8** Repeat the procedure to add more songs, or press **Back** to return to the **Playlists** menu.

play a playlist

Find it:  >  **Media** > **Media Finder**
> **Music Library** > **Playlists**, scroll to the playlist,
press **Options** > **Play**

close the music player

From the music player screen or home screen, press  to close the music player.



browser

Use your phone's full HTML browser to surf to your favorite Web sites, upload videos to a video blog, and download files and applications to your phone. Log on to your Internet-based email account to check your email on the go.





To **launch** the browser:

Find it:  >  Internet > Browser

Press  up/down/left/right to scroll through Web pages. Scroll to a link and press  to select it. Press **Back** at any time to return to the previous screen.

Some Web pages may contain a text entry window for exchanging information with a Web site. Scroll to the window, select it, and

enter text as usual (for more information about text entry, see page 25).

To **go to a Web page**, press  >  Setting > Internet > Go to URL, enter the Web address, then press **Go**.

To **bookmark** the current Web page, press **Options** > Active Page > Add Bookmark.

To go to a **bookmarked Web page**, press **Options** > My Bookmarks > *bookmark*.

To **change the homepage** that appears when you launch the browser, go to the Web page you want to use, then press **Options** > Active Page > Use as Homepage.

To **upload** a video to a video blog site, see page 59.

To **download** a media file, theme, or Java™ game or application to your phone, go to the Web page that links to the file, scroll to the link, and select it.

To **exit** the browser, press **Options** > Exit.

check your email account

Check your personal Web-based **email** account (such as Hotmail, Gmail, or Yahoo).



Note: You must have browser service activated on your phone to use this feature.

Find it:  >  **Setting** > **Internet** > **Go to URL**

Enter the URL for your Web-based email account, then press **Go**.

browser settings

To use your phone's browser, the browser must be configured with the appropriate settings for Internet access, and you must have data service activated for your account with your cellular service provider (additional fees may apply for this service).

If necessary, you can get the required Internet browsing settings for your phone by

contacting your service provider directly, or by visiting the following Web site:



<https://hellomoto.wdsglobal.com/site/phonefirst>

Note: Not all service provider settings may be available yet through this Web site.

camera


The 2-megapixel digital camera on your phone can take photos at up to 1200 x 1600 pixels resolution. Just aim and shoot to take a photo, then press **Send** to share it with your friends.

take a photo

Find it:  >  **Media** > **Camera**

Shortcut: From the home screen, press the side select key to activate the camera.

The phone's internal display acts as the camera *viewfinder*.



Use the viewfinder to compose your scene, then press to take the photo.

- To store the photo, press .

- To send the photo in a message, press **Send** (see page 63).
- To discard the photo, press .
- To select other photo options, press **Options**. You can choose to **Save Only**, **Discard**, **Send to** (message, email, or Bluetooth connection), **Apply to** (wallpaper, screensaver, new or existing contact), **Edit**, or **Print via** (Bluetooth connection, USB connection, or memory card).




Tip: To send your photo in an MMS text message, the picture resolution must be set to **X-Small**, **Small**, or **Medium**. To set resolution, press > > **Media** > **Camera**, press **Options** > **Camera Settings** > **Picture Settings** > **Resolution**.




view a photo

To view a stored photo that you've taken:

Find it:  >  Media > Media Finder > Pictures > Captured Pictures > *photo*

camera settings

When the camera viewfinder is active, you can use the navigation key  to adjust the following camera settings. Press  up or down to scroll to a setting, then press  left or right to change it:

settings	
Zoom	Press  right to zoom in, press left to zoom out.
Styles	Press  left/right to select Color , Black & White , Antique , Negative , Reddish , Greenish , or Bluish .
Scene	Press  left/right to select Automatic , Night , or Manual .

When the camera viewfinder is active, press **Options** to select the following camera options:

options	
Capture	Take a photo.
Go To My Media	See, edit, and delete stored pictures and photos.
Video Mode	Switch to the video camera.
Auto-Timer	Set a timer for the camera to take a photo.
Multi-Shot	Set the camera to take multiple photos in sequence.


videos





record a video



Find it:  >  Media > Video Camera

The phone's internal display acts as the video camera *viewfinder*.

options	
Camera Settings	Customize camera settings:
	<ul style="list-style-type: none">• Review Time• Default Name• Storage Location• Picture Settings<ul style="list-style-type: none">• Resolution• Shutter Tone• Quality• Video Settings<ul style="list-style-type: none">• Resolution• Capture Tone• Quality• Video Length



- 1 To begin video recording, press .
- 2 Press **Stop** to stop video recording.
 - To store the video, press .
 - To send the video in a message, press **Send**. 
 - To discard the video, press .
 - To select other video options, press **Options**. You can choose to **Save Only**, **Discard**, **Send to** (message, email, or Bluetooth connection), or **Preview** the video.




Tip: To send your video in an MMS text message, the video length must be set to **MMS Short** or **MMS Long**. To set length, press  >  **Media** > **Video Camera**, press **Options** > **Camera Settings** > **Video Settings** > **Video Length**.


When the video camera viewfinder is active, press **Options** to set video recording options:

options	
Capture	Begin video recording.
Go To My Media	See, edit, and delete stored videos.
Picture Mode	Switch to the photo camera.
Audio On/Off	Turn audio recording on/off.
Camera Settings	Customize camera settings (see page 58).

upload video to a blog

Upload a video you've recorded to your video blog site:

- 1 Press  >  **Internet** to launch your phone's browser.
- 2 Go to a video blogging service Web site.
- 3 Log in to your account.
- 4 Scroll to **Upload Videos** and press .


5 Follow the browser prompts to scroll to the video you want to upload, then press .

6 Scroll to **Upload** and press .


Your phone uploads the video to the blog.

play a video

Find it:  >  **Media** > **Media Finder** > **Videos**
> *video*

Press  left/right
to skip to
previous/next video.

Press  to
pause/play video.




Select & adjust video
camera options.

Timer Shows
% Played

When a video is playing, press **Options** to
select video options.

Note: Your phone's options may vary. Most options apply only to user-recorded videos, and are not available for pre-installed videos.

options	
Slideshow	Show the video in full screen. (Press  to return to actual size.)
Manage	Show video Properties , such as file name, type, and size.
Delete	Delete the video.
Zoom	Show the video at actual size, or scale the video to fit the viewing area.
Send To	Send the video in a message or email, or send it to another device over a Bluetooth® connection.

options	
Use Bluetooth/ Use Handset	To send the audio soundtrack to a Bluetooth® headset, turn on Bluetooth power, then select Use Bluetooth to connect to a recognized Bluetooth headset or search for a new headset. When a Bluetooth audio connection is active, select Use Handset to drop the Bluetooth connection and switch the audio back to the phone. Note: This option appears only when Bluetooth power is turned on.
Setup	Adjust video settings.

supported video formats

Before you copy video files to your phone, make sure the files are in a format the phone recognizes: H.263 + AMR-NB, AAC, Real Audio MPEG4 + AMR-NB, AAC, and Real Audio.

messages

text messaging

read & reply to a message in the external display

When the phone flip is closed and you receive a message, your phone plays an alert, and the external display shows **New Message from X**, where **X** is the sender's number or name.



To read and reply to the message in the external display:

- 1 Press the volume keys on the side of your phone to scroll to **View**, then press the side select key to read the message.
- 2 When you finish reading the message, press the side select key to close it.

- 3 To answer the message, press the volume keys to scroll to **Quick Reply**, then press the side select key.
- 4 Press the volume keys to scroll to a pre-written *quick note* message, then press the side select key to select it.

Tip: Your phone stores a variety of pre-written quick notes, and you can create and store additional quick notes. For more information, see page 65.

- 5 Press the volume keys on the side of your phone to scroll to **Send**, then press the side select key to send your reply.

send a message

A message can contain text and pictures, sounds, or other media objects. You can add multiple pages to a message and put text and media objects on



each page. You can send a message to other compatible phones or to email addresses.

Find it:  >  Messages > Messages

> **Create Message**



- 1 Press keypad keys to enter text on the page (for more information about text entry, see page 25).

To insert a **picture, sound, or other media object** on the page, press **Options** > **Insert**. Select the file type and the file. (**Note:** File size restrictions may apply to pictures and videos sent in a message.)

To insert **another page**, press **Options** > **Insert** > **Page**. You can enter more text and objects on the new page.

- 2 When you finish the message, press **Options** > **Sending Options** to set message options (such as **Subject** and **Priority**).
- 3 When you finish setting message options, press **Done**.

- 4 Press **Send To** to select message recipients. You can:


- Select one or more entries from your contact list (press  to scroll to an entry, and press  to select it).
- Enter a new number or email address (press **Options** > **Enter Number** or **Enter Email**).

- 5 Press **Send** to send the message.

Your phone might tell you that this is a multimedia message, if it contains multiple pages or media objects. Some phones or networks don't support multimedia messages. Press **Yes** to send the message.

To save or cancel the message, press **Options** > **Save to Drafts** or **Cancel Message**.

receive a message

When you receive a message, your phone plays an alert, and the internal display shows **New Message** with the new message indicator .



To **read** the message, press **View**. If the message contains media objects:

- Pictures and animations show as you read the message.
- Sound files play as you read the message. Press the external volume keys on the side of your phone to change the sound volume.
- Attached files are added to the end of the message. To open an attachment, select the file indicator or file name.

To **answer** the message, press **Options > Reply**.

more message & email features

features

confirm a message was sent



To confirm that your message was sent:

 >  **Messages** > **Messages** > **Outbox**
> *message*

Your phone lists the message recipient(s) and shows message status. **Sent** indicates the message was sent successfully, **Failed** indicates the message was not sent.

send a prewritten quick note



 >  **Messages** > **Messages**
> **Templates** > **Text Templates** > *quick note*,
press **Options** > **Send**

To create a new quick note:

 >  **Messages** > **Messages** > **Templates**
> **Text Templates**, press **Options** > **Create Template**

features

use a multimedia template









Open a multimedia template with pre-installed media:

 >  Messages > Messages > Templates > Multimedia Templates

read old messages



 >  Messages > Messages > Inbox

Icons next to each message show if it is **read** , **unread** , **urgent** , or has an **attachment** . Press **Options** to perform various operations on a message.

read new messages or email



When your display shows **New Message**, press **Read**.

store message objects



Go to a multimedia message page, then press **Options** > **Store**.

features

create folder



Create a personal folder to store your messages.

 >  Messages > Messages > My Folders, press **Options** > **Create Folder**

browser messages



Read messages received by your browser:

When your display shows **New Message**, press **View**.

To activate browser messages and adjust browser message settings:

 >  Messages > Messages, press **Options** > **Settings** > **Browser Messages**

features

info services



Read subscription-based information services messages:

When your display shows **New Message**, press **View**.

To activate information services and adjust info services settings:

 >  **Messages** > **Messages**, press **Options**
> **Settings** > **Info Services**

connections

file manager

Manage music and sound files, photos, videos, and other files stored on your phone, and on an optional removable microSD memory card.

Find it:  >  Tools > File Manager

Select a folder or **Memory Card** to see its contents.

To **play** a sound file or voice note, or **view** a photo or video, just scroll to the file and select it.

To **edit** a file: Scroll to the file and press **Options** > **Manage** to copy, move, or rename it. Other options let you delete, send, or apply the file. You can't perform some operations on some copyrighted or pre-installed files.


To **copy files** between your phone and a computer, you can use a cable connection

(see following section) or a Bluetooth® connection (see page 72).

format memory card

To **format** the memory card or see memory card **properties** (such as name and available memory):

Find it:  >  Tools > File Manager

- 1 Press  to scroll to the memory card.
- 2 Press **Options** > **Memory Card** > **Format** or **Properties**.


move or copy files between the phone and memory card


Caution: When you **move** a file to a new location, the file is **deleted** from its original location.

Find it:  >  Tools > File Manager

- 1 Scroll to the file you want to move or copy.
- 2 Press **Options > Manage > Move or Copy**.
Note: The **Move** and **Copy** options do not appear if the file is copyright-protected.
- 3 Scroll to the destination location, then press **Place**.

USB cable connections



 To transfer data between your phone and a computer, insert the micro USB connector plug from a USB cable into your phone's micro USB port. Connect the other end of the cable to the computer.







Note: The Motorola Original USB cable and supporting software are sold separately. Check your computer to determine the type of cable you need.







Note: Some phone functions are temporarily unavailable when a USB connection is active.

To use Windows Media Player 11 to **sync music files** from a computer to a memory card installed in your phone: Press  >  **Settings > Connections > USB Setting > Media Synchronization**, then connect your phone to the computer. For more information, see page 46.

To manually **transfer music, pictures, and videos** between your computer and phone (phone memory or installed memory card): Press  >  **Settings > Connections > USB Setting > Memory Card**, then connect your phone to the computer. For more information about manually transferring music files, see page 51.

To use your phone as a **modem**: Press  >  **Settings** > **Connections** > **USB Setting** > **Modem**, then connect your phone to the computer.

To **transfer contact lists and calendar entries** between your computer and phone: Press  >  **Settings** > **Connections** > **USB Setting** > **Modem**, then connect your phone to the computer. Run the optional Motorola Phone Tools accessory application on the computer. You can also use the Motorola Phone Tools application to transfer and sync music files from the computer to your phone. See the Motorola Phone Tools user's guide for more information.

To make **data calls** through a computer: Press  >  **Settings** > **Connections** > **USB Setting** > **Modem**, then connect your phone to the computer. Use the computer application to place or answer the call.

To **print** an image over a USB PictBridge connection: Press  >  **Settings** > **Connections** > **USB Setting** > **USB Printing**, then connect your phone to a

PictBridge-compatible printer. Select the image(s) you want to print, then press **Options** > **Print via** > **USB**.

end a USB connection

Caution: Do not disconnect your phone from the computer while files are being transferred.

On a PC running Windows XP™ or later:

When file transfer is complete, remove the USB cable from your phone and computer.

On a PC running an earlier version of Windows OS:

Click the Safely Remove Hardware icon in the system tray at the bottom of your computer screen, then select Safely Remove USB Mass Storage Device. Remove the USB cable from your phone and computer.

On a Macintosh® computer: Select and drag the Removable Disk icon to the Trash. Remove the USB cable from your phone and computer.

Bluetooth® wireless

Your phone supports Bluetooth wireless connections. You can connect your phone with an optional Bluetooth headset or Bluetooth car kit to make handsfree calls, or with a set of Bluetooth stereo headphones to listen to music stored on your phone. Connect your phone with a device that supports Bluetooth connections to exchange files, connect with a printer that supports Bluetooth connections to print images, or use your phone as a Bluetooth wireless modem to connect to the Internet.





For maximum Bluetooth security, you should always connect Bluetooth devices in a safe, private environment.

turn Bluetooth power on or off

Your phone automatically turns Bluetooth power on when you use a Bluetooth feature.

To turn Bluetooth power on or off at any time:

Find it:  >  **Settings** > **Connections**
> **Bluetooth**, press **Options** > **Setup Bluetooth**
> **Bluetooth Power** > **On**

Note: To extend battery life and maximize Bluetooth security, use this procedure to set Bluetooth power to **Off** when not in use. Your phone will not connect to another device until you use a Bluetooth feature again, or set Bluetooth power back to **On**.

use a Bluetooth headset or handsfree car kit

Before you try to connect your phone to a handsfree device for the first time, make sure the device is **on** and **ready** in *pairing* or *bonding* mode (see the device user's guide).


You can connect your phone with only one device at a time.

Find it:  >  **Settings** > **Connections**

> **Bluetooth**, press **Options** > **Search For Device**

> **Headset**

Your phone lists the Bluetooth audio devices it finds within range.

- 1 Scroll to a device in the list.
- 2 Press  to connect with the highlighted device.

copy files to another device

You can copy a media file, contact, calendar event, or bookmark to another phone or computer that supports Bluetooth connections.

Note: You can't copy some copyrighted objects.

Before you try to copy a file to another device, make sure the receiving device is **on** and **ready** in discoverable mode. Also, make sure the device is not busy with another Bluetooth connection.

- 1 On your phone, scroll to the object that you want to copy to the other device.
- 2 Press **Options**, then select:
 - **Send To** > **Bluetooth** for an image or sound file.
 - **Share** > *contact* > **Bluetooth** for a contact.
 - **Share Via** > **Bluetooth** for a calendar event or bookmark.

- 3 Select a recognized device name.

or

Select [**Search For Devices**] to search for new devices, then select the device where you want to copy the object.




- 4 Press **Options** > **Send**.
- 5 If necessary, enter a mutually agreed upon passkey (such as **0000**) on your phone and the device, then press **OK** to connect to the device.

Your phone shows **Sending** while the file is transferred. When file transfer is complete, the phone shows **Send Successful**, and prompts you to press **OK** to continue.

receive files from another device

Before you try to receive a file from another device, make sure your phone's Bluetooth power is **on** (see page 71).

Place your phone within range (approximately 10 meters/30 feet) of the other Bluetooth device, and send the file from the device.

If your phone and the sending device were not previously paired, place your phone in discoverable mode so the sending device can locate it. Press  >  **Settings** > **Connections** > **Bluetooth**, press **Options** > **Discoverable On 3 Minutes**. The Bluetooth indicator  in the home screen flashes when your phone is in discoverable mode.

Your phone shows **Incoming Transfer** while the file is transferred. When file transfer is complete, the phone shows **Successful**, and tells you where the file was stored.

send a photo to a printer

You can send a photo to a printer that supports Bluetooth connections.

Note: You can print A4, US Letter, and 4x6 size pages. To print another size, copy the image to a linked computer and print it from there.

- 1 On your phone, take a new photo or scroll to a stored image that you want to print, then press **Options** > **Print via** > **Bluetooth**.

Note: If you see **Service Not Supported** when you try to print, select **Send To** > **Bluetooth** instead. (The **Send To** option does not print the image name or date stamp.)






- 2 Select a recognized printer name, or press **Options** > **Search For Printers** to search for another printer where you want to send the image.
- 3 If available, modify print options.

more Bluetooth features


Note: A device is *recognized* after you connect to it once (see page 71).

features

pair with recognized device

Press  >  **Settings** > **Connections** > **Bluetooth**, press  left to select the **My Devices** tab, press  up/down to scroll to the device name, press  to connect.

drop connection with device

Scroll to the connected device name and press  to disconnect.

remove device from device list

Scroll to the device name and press **Options** > **Manage** > **Remove Device**.

Note: You can't remove a device from the list while your phone is connected to the device.

features

switch audio to Bluetooth headset or Bluetooth car kit during call



Press **Options** > **Use Bluetooth**.

To switch audio back to the phone, press **Options** > **Use Handset**.



edit properties of recognized device



Scroll to the device name, press **Options** > **Manage** > **Edit Device**.

set Bluetooth options



Press  >  **Settings** > **Connections** > **Bluetooth**, press **Options** > **Manage** > **Setup Bluetooth**.

phone software updates

Sometimes, we think of ways to make your phone's software faster or more efficient after you've purchased your phone. You can find out if your phone can be updated at:

www.hellomoto.com/update

Your service provider can send updated phone software over-the-air to your phone. When your phone receives a software update, you can install it immediately, or defer installation until later. To install a deferred software update:

 >  **Settings** > **Phone Settings** > **OTA Updates** > **Update Software**

other features



advanced calling

To use voice commands for calling, see page 28.

features

speed dial

Your phone can store nine phone numbers that you can call with a single keypress. To **store** a speed dial phone number:


 >  **Phonebook**, press **Options** > **Setup** > **Speed Dial List** > *speed dial location*

To **call** a speed dial number, press and hold the single-digit speed dial number for one second.

features

international calls



If your phone service includes international dialing, press and hold  to insert your local international access code (indicated by +). Then, press number keys to dial the country code and phone number.

hold a call

Press **Options** > **Hold** to put all active calls on hold.

mute a call

Press **Options** > **Mute** to put all active calls on mute.

features


hearing aid

Use your phone with a hearing aid that operates in telecoil mode:

 >  Settings > Call Settings > In-Call Setup
> Hearing Aid > Telecoil On

call waiting



When you're on a call, you'll hear an alert if you receive a second call. Press  to answer the new call.

- To switch between calls, press **Switch**.
- To connect the two calls, press **Link**.
- To end the call on hold, press **Options > End Call On Hold**.

To turn call waiting on or off:

 >  Settings > Call Settings > In-Call Setup
> Call Waiting > On or Off

features

make another call during a call




During a call:

Options > New Call, press **Options > Browse Contacts**

conference call




During a call:

Dial next number, press , press **Options > Link Calls**

transfer a call



During a call:

Options > Transfer Call, dial transfer number, press 

call forwarding



Set up or cancel call forwarding:

 >  Settings > Call Settings > Call Forward

call barring



Restrict outgoing or incoming calls:

 >  Settings > Call Settings > Call Barring

features

TTY calls



Set up your phone for use with an optional TTY device:

 >  **Settings** > **Phone Settings** > **TTY Settings**

change phone line



If you have a dual-line-enabled SIM card, you can change your line to make and receive calls from your other phone number:

 >  **Settings** > **Call Settings** > **In-Call Setup**
> **Active Line**

The active line indicator shows the active phone line (see illustration on page 23).

features

fixed dial



When you turn on fixed dialing, you can call only numbers stored in the fixed dial list.

Note: You must enter your SIM PIN2 code to turn fixed dialing on or off. If you forget your PIN2 code, contact your service provider.

Turn fixed dialing on or off:

 >  **Settings** > **Call Settings** > **Fixed Dialing**
> **On** or **Off**

Use the fixed dial list:

 >  **Tools** > **Dialing Services** > **Fixed Dial**

service dial



Dial service phone numbers stored by your service provider:

 >  **Tools** > **Dialing Services** > **Service Dial**

features

DTMF tones

Activate DTMF tones:

ⓘ > ⚙ Settings > Call Settings > Dialing Setup
> DTMF

To send DTMF tones during a call, just press the number keys.

phonebook

features

call a contact

ⓘ > 📞 Phonebook, scroll to the contact, press 📞 to call

Note: If a contact has multiple phone numbers or email addresses, press ⓘ left/right to select the number or email address you want.

features

add new contact

ⓘ > 📞 Phonebook, press Options
> Create Contact

Press ⓘ left/right to select the **details** tab **F**, **address** tab **📍**, **ID** tab **👤**, or **notes** tab **📝**. Press ⓘ up/down to scroll to information you want to change, then press ⓘ to select it.

send message to contact

ⓘ > 📞 Phonebook, scroll to the contact, press Options > Send Message

add additional phone number or email address to contact

ⓘ > 📞 Phonebook, scroll to the contact, press Options > Edit, press ⓘ left/right to select the **details** tab **F**, press ⓘ up/down to scroll to an empty **Number** or **Email** field, press ⓘ to select it

features

set picture ID for contact

Assign a photo or picture to show in the display when you receive a call from a contact:

•◂ > 📞 Phonebook, scroll to the contact, press **Options** > **Edit**, press ◂◃ left/right to select the **ID** tab ⓘ, press ◂◃ up/down to scroll to **Picture ID**, press ◂◃ to select it

set ring ID for contact

Assign a distinctive call alert (*ring ID*) for a contact:

•◂ > 📞 Phonebook, scroll to the contact, press **Options** > **Edit**, press ◂◃ left/right to select the **ID** tab ⓘ, press ◂◃ up/down to scroll to **Ring ID**, press ◂◃ to select it

features

assign contact to category

•◂ > 📞 Phonebook, scroll to the contact, press **Options** > **Edit**, press ◂◃ left/right to select the **details** tab ⓘ, press ◂◃ up/down to scroll to **Category**, press ◂◃ to select it

set category view

•◂ > 📞 Phonebook, press **Options** > **Filter By**

You can show contacts in a predefined category (**Email**, **Family**, **Friends**, **Work**), or contacts in a category that you create (select **Create Category**).

create group mailing list



Assign contacts to a group message list or email list:

•◂ > 📞 Phonebook, press **Options** > **Create List** > **Message** or **Email**

features

show contact photos

Show contacts with picture ID photos, or as a text list:



 >  Phonebook, press Options > Setup
> Default View > Thumbnail or List

set contact list sort order

 >  Phonebook, press Options
> Default Sort Order > First Name or Last Name

create & use private contacts


Identify one or more contacts as private contacts. You must enter your six-digit security code to access the private contacts on your contact list.

 >  Phonebook, press Options > Setup
> Private Contacts



features

import contacts to phone memory

Import all contacts to phone memory, from the SIM card or from another location:

 >  Phonebook, press Options
> Import Contacts > SIM Card or File Manager

manage SIM card contacts


 >  Phonebook, press Options > Setup
> SIM Card Manager

Delete contacts stored on your SIM card, or import contact to the SIM card from phone memory, or from another location.

features

send contact(s) to another device

Send one or more contacts to another phone, computer, or device:


•• >  **Phonebook**, scroll to the contact, press **Options** > **Share**, press •• to select the current contact, press •• up/down to scroll to **Bluetooth**, **Messaging**, or **Email** transfer method, press **Select** to select it

To send multiple contacts, press **Options** > **Share** > **Multiple Contacts** (instead of the current contact).

features

delete contact(s)

Delete one or more contacts from your contact list:

•• >  **Phonebook**, scroll to the contact, press **Options** > **Delete**, press •• to select the current contact, press **Yes** to confirm deletion

To delete multiple contacts, press **Options** > **Delete** > **Multiple Contacts** (instead of the current contact).

personalize

features


language

Set menu language:

 >  Settings > Phone Settings > Language

reminders

Set the reminder alert for event notifications:

 >  Settings > Profiles, press  left/right to select the **settings** tab ,
> Calendar Alarm

reset settings

Reset default settings for all options **except** the unlock code, security code, and lifetime timer:

 >  Settings > Phone Settings > Reset
> Reset All Settings

features

delete data

Caution: This option **erases all information you have entered** (including contacts and calendar entries) **and content you have downloaded** (including photos and sounds) stored in your phone's memory. After you erase the information, you can't recover it.

This option does **not** delete SIM card information:

 >  Settings > Phone Settings > Reset
> Delete All Data


features

delete memory card information

Caution: This option **erases all information you have entered** (including contacts and calendar entries) **and content you have downloaded** (including photos and sounds) stored on your memory card and/or SIM card. After you erase the information, you can't recover it.

 >  Settings > Phone Settings > Reset > Delete Memory Cards

call times & costs



Network connection time is the elapsed time from the moment you connect to your service provider's network to the moment you end the call by pressing . This time includes busy signals and ringing.

The amount of network connection time you track on your resettable timer may not equal the amount of time for which you are billed by your service provider. For billing information, contact your service provider.

features

call times

See call timers:

 >  Call History, press Options > Call Times



in-call timer



Show call time information during a call:

 >  Settings > Call Settings > In-Call Setup > In-Call Timer



call cost

See call cost trackers and credit information:

 >  Call History, press Options > Call Costs





features

call cost setup





Set a credit limit:

 >  Call History, press **Options** > **Call Costs**
> **Call Cost Setup**

data times



See data call timers:

 >  Call History, press **Options** > **Data Times**

data volumes



See data volume meters:

 >  Call History, press
Options > **Data Volumes**

handsfree

Note: The use of wireless phones while driving may cause distraction. Discontinue a call if you can't concentrate on driving. Additionally, the use of wireless devices and their accessories may be prohibited or restricted in certain areas. Always obey the laws and regulations on the use of these products.

features

auto answer (headset)



Automatically answer calls when connected to a car kit or headset:

 >  **Settings** > **Phone Settings**
> **Headset Settings** > **Auto-Answer**

voice dial (headset)



Enable voice dial with headset send/end key:

 >  **Settings** > **Phone Settings**
> **Headset Settings** > **Voice Dial**

network

features

network settings



See network information and adjust network settings:

 >  **Settings** > **Network**

personal organizer

features


set alarm

 >  **Tools** > **Alarm Clock**

Shortcut: From the home screen, press **Shortcut** > **Set Alarm**.

turn off alarm


When the display shows an alarm:

To turn off the alarm, press **Dismiss** or .




To set an eight-minute delay, press **Snooze**.

features

set calendar default view



 >  **Tools** > **Calendar**, press **Options**
> **Calendar Setup** > **Default View**

add new calendar event

 >  **Tools** > **Calendar**, scroll to the day and/or start time, press , enter event details

You can set a music or sound file, voice note, or video as a calendar event reminder. When creating a calendar event, select **Alarm Style** > *alarm type*, scroll to the file (or create a new file), press **Insert**.

see calendar event

 >  **Tools** > **Calendar** > *event*

To edit event details, press **Options** > **Edit**.

features

calendar event reminder

When the display shows and sounds an event reminder:

To see reminder details, select **Open Event**.

To close the reminder, press **Dismiss**.



send calendar event to another device

Send a calendar event to another phone, computer, or device:

 >  **Tools** > **Calendar** > *event*, press **Options** > **Share via** > **Bluetooth** or **Message**

manage downloaded files

Manage files and applications that you've downloaded onto your phone from the browser or over a Bluetooth® connection:

 >  **Tools** > **Download Manager**

features

world clock

Show time and date information for multiple cities around the world:

 >  **Tools** > **World Clock**

task list

Create a checklist of tasks you need to perform, and set your phone to notify you when task deadlines arrive:

 >  **Tools** > **Task List**




notes

Write and store notes on your phone:

 >  **Tools** > **Notes**

features

record voice note

 >  **Media** > **Voice Recorder**, press  to start recording, press **Stop** to stop recording

To save the voice note, press **Save**.

To perform various operations on the voice note, press **Options**.

Note: Recording of phone calls is subject to varying State and Federal laws regarding privacy and recording of phone conversations. Always obey the laws and regulations on the use of this feature.

play voice note

Play back a voice note you've recorded:



 >  **Tools** > **File Manager** > **Voice Note**
> *voice note*

calculator

 >  **Tools** > **Calculator**

features

currency converter

 >  **Tools** > **Calculator**, press **Options**
> **Set Exchange Rate**, enter exchange rate, press **Set**, enter amount, press **Options** > **Convert Currency**


security

features

SIM PIN

Caution: If you enter an incorrect PIN code three times before the correct code, your SIM card is disabled, and your display shows **SIM Blocked**.

Lock or unlock the SIM card:

 >  **Settings** > **Security** > **SIM Lock**

lock application



 >  **Settings** > **Security** > **Application Lock**

features

manage certificates



Enable or disable Internet access certificates stored on your phone:

 >  **Settings** > **Security** > **Certificates**

Certificates are used to verify the identity and security of Web sites when you download files or share information.

features

airplane mode

Turn off your phone's calling features in locations where wireless phone use is prohibited. This lets you use the music player and other non-network features while you are on an airplane, without interfering with airplane communications.

 >  **Settings** > **Phone Settings**
> **Airplane Mode** > **On**

To reactivate your phone's calling features, turn off airplane mode.

fun & games

features

start a game or application



Start a Java™ game or application:

 >  **Games & Apps** > *game* or *application*

service & repairs

If you have questions or need assistance, we're here to help.

Go to www.motorola.com/support, where you can select from a number of customer care options. You can also contact the Motorola Customer Support Center at 1-800-331-6456 (United States), 1-888-390-6456 (TTY/TDD United States for hearing impaired), or 1-800-461-4575 (Canada).

Specific Absorption Rate Data

This model wireless phone meets the government's requirements for exposure to radio waves.

Your wireless phone is a radio transmitter and receiver. It is designed and manufactured not to exceed limits for exposure to radio frequency (RF) energy set by the Federal Communications Commission (FCC) of the U.S.

Government and by the Canadian regulatory authorities. These limits are part of comprehensive guidelines and establish permitted levels of RF energy for the general population. The guidelines are based on standards that were developed by independent scientific organizations through periodic and thorough evaluation of scientific studies. The standards include a substantial safety margin designed to assure the safety of all persons, regardless of age or health.

The exposure standard for wireless mobile phones employs a unit of measurement known as the Specific Absorption Rate, or SAR. The SAR limit set by the FCC and by the Canadian regulatory authorities is 1.6 W/kg.¹ Tests for SAR are conducted using standard operating positions accepted by the FCC and by Industry Canada with the phone transmitting at its highest certified power level in all tested frequency bands. Although the SAR is determined at the highest certified power level, the actual

SAR level of the phone while operating can be well below the maximum value. This is because the phone is designed to operate at multiple power levels so as to use only the power required to reach the network. In general, the closer you are to a wireless base station, the lower the power output.

Before a phone model is available for sale to the public in the U.S. and Canada, it must be tested and certified to the FCC and Industry Canada that it does not exceed the limit established by each government for safe exposure. The tests are performed in positions and locations (e.g., at the ear and worn on the body) reported to the FCC and available for review by Industry Canada. The highest SAR value for this model phone when tested for use at the ear is 1.36 W/kg, and when worn on the body, as described in this user guide, is 0.56 W/kg. The SAR value for this product in its data transmission mode (body-worn use) is 1.36 W/kg. (Body-worn measurements differ among phone models, depending upon available accessories and regulatory requirements).²

While there may be differences between the SAR levels of various phones and at various positions, they all meet the governmental requirements for safe exposure. Please note that improvements to this product model could cause differences in the SAR value for later products; in all cases, products are designed to be within the guidelines.

Additional information on Specific Absorption Rates (SAR) can be found on the Cellular Telecommunications & Internet Association (CTIA) Web site:

<http://www.phonefacts.net>

or the Canadian Wireless Telecommunications Association (CWTA) Web site:

<http://www.cwta.ca>


1. In the United States and Canada, the SAR limit for mobile phones used by the public is 1.6 watts/kg (W/kg) averaged over one gram of tissue. The standard incorporates a substantial margin of safety to give additional protection for the public and to account for any variations in measurements.
2. The SAR information includes the Motorola testing protocol, assessment procedure, and measurement uncertainty range for this product.

European Union Directives Conformance Statement



Hereby, Motorola declares that this product is in compliance with:

- The essential requirements and other relevant provisions of Directive 1999/5/EC
- All other relevant EU Directives



The above gives an example of a typical Product Approval Number.

You can view your product's Declaration of Conformity (DoC) to Directive 1999/5/EC (to R&TTE Directive) at www.motorola.com/rtte. To find your DoC, enter the Product Approval Number from your product's label in the "Search" bar on the Web site.

OPEN SOURCE SOFTWARE INFORMATION

For instructions on how to obtain a copy of any source code being made publicly available by Motorola related to software used in this Motorola mobile device, you may send your request in writing to the address below. Please make sure that the request includes the model number and the software version number.

MOTOROLA, INC.
OSS Management
600 North US Hwy 45
Libertyville, IL 60048
USA

The Motorola website opensource.motorola.com also contains information regarding Motorola's use of open source.

Motorola has created the opensource.motorola.com to serve as a portal for interaction with the software community-at-large.

To view additional information regarding licenses, acknowledgments and required copyright notices for open source packages used in this Motorola mobile device, please select **Main Menu > Settings > Phone Settings > Legal Notices**. In addition, this Motorola device may include self-contained applications that present supplemental notices for open source packages used in those applications.

index

A

- abc mode 26
- accessories 11, 50, 71, 85
- active line indicator 23
- active line, change 78
- airplane mode 29, 89
- alarm clock 86
- alert
 - set 24, 33, 36
 - turn off 23, 41
- alert profile 33
- alert style profiles 23
- animated graphics 32
- answer a call 19, 40
- audio file formats 51
- audio player 44

B

- battery 17
- battery charge indicator
 - light 17
- battery indicator 23

- battery life, extend 14, 39, 40, 71
- blog 59
- Bluetooth indicator 22
- Bluetooth indicator light 3
- Bluetooth wireless 50, 71
- bonding. See Bluetooth wireless
- brightness 39
- browser 54, 55, 66, 87
- browser messages 66

C

- cables, using 69
- calculator 88
- calendar 86, 87
- call

- answer 19, 40
 - end 19
 - make 19, 20
- call alert 80
- call barring 30, 77
- call forward indicator 23

- call forwarding 77
- call history 41
- call timers 84, 85
- call waiting 77
- caller ID 42, 80
- camera 3, 55, 58
- car kit 85
- center key 11
- certificate management 89
- charge indicator light 3
- clear/back key 2, 26
- clock 35, 39, 40
- codes 30, 31
- conference call 77
- costs, track 84, 85
- customer support 90

D

- data call 85
- date 35, 39
- delete data 83
- delete text 26

dial a phone number 19,
20, 78

dialed calls 41

display 4, 21, 39

download files 54

download manager 87

download media objects
66

drafts folder 64

DTMF tones 79

E

earpiece volume 23

EDGE indicator 22

email 66

email address 19, 79

emergency number 42

end a call 19

end key 19

Enter Unlock Code
message 30

external display 3, 24, 32

F

feature icons 38

file manager 68

filter contacts 80

fixed dial 78

flip 19, 24, 40

forward calls 77

G

GPRS indicator 22

group mailing list 80

H

handsfree speaker 3, 30

headset 85

hearing aid 77

hold a call 76

home screen 4, 21, 38

I

IM indicators 22

in-call indicator 23

Incoming Call message 42

information services 67

international access code
76

K

keypad 40

keypad volume, adjust 33,
34

L

language 83

lanyard hook 2

line 1 and line 2 33

linking. See Bluetooth
wireless

location indicator 23

lock

application 88

external keys 31, 51

phone 31

SIM card 88

Low Battery message 23

M

main menu, personalize 39

make a call 19, 20

media playback 33, 34

media volume, adjust 33,
34

memory card 13, 68

menu 4, 21, 39

menu icons 21, 39

- menu key 11
- menu, personalize 39
- message
 - read 65, 66
 - send 63
- message indicator 22, 63, 65
- message reminders 83
- micro USB port 2, 3, 17, 69
- microphone 2
- Missed Calls message 42
- multimedia message 63, 66
- music player 44
- mute a call 76

N

- navigation key 11
- network settings 86
- notes 87
- numeric entry mode 27

O

- open to answer 40
- optional accessory 11
- optional feature 11

P

- pairing. See Bluetooth wireless
- passwords. See codes
- personalize 83
- phone number
 - store 19, 79
 - your number 20, 78
- phonebook
 - add entry 19, 79
 - dial entry 20
 - filter 80
 - picture ID 42
 - search 20
 - send contact 82
 - view 80

- photo 55
- picture ID 42, 80
- PIN code 18, 30, 88
- PIN2 code 30, 78
- power key 18
- predictive text entry 26
- printing 70, 74
- profile indicator 23
- profiles 23, 33

Q

- quick note 63, 65

R

- received calls 41
- redial 41
- reminders 83
- repairs 90
- reset settings 83
- resolution 58
- return a call 42
- ring ID 80
- ring style 24
- ringer volume, adjust 33, 34
- ringtone 33, 36, 49

S

- screensaver 36, 40
- security code 30
- send key 19
- service dial 78
- side select key/camera key 2, 3, 24
- signal strength indicator 22
- silent mode 24

- silent profile 33
- SIM Blocked message 88
- SIM card 12, 18, 30, 78, 88
- SIM card, delete
 - information 84
- skin 36
- smart key 24
- soft keys 2, 21
- software update 75
- speakerphone 85
- speed dial 76
- spinner 39
- stereo headphones 50
- store phone numbers 19,
 - 79
- store your phone number
 - 20
- support 90
- symbol entry mode 28

T

- talking phone 30
- task list 87
- technical support 90
- text edit 26
- text entry 25

- text entry mode 26
- text message 63
- text messaging 63
- text templates 63, 65
- theme 36
- time 35
- timers 84, 85
- touch keys 24, 48
- transfer a call 77
- TTY device 78
- turn on/off 18

U

- unlock
 - application 88
 - external keys 31, 51
 - phone 18, 30, 31
 - SIM card 88
- unlock code 30, 31
- USB cables 69

V

- vibrate mode 24
- vibrate profile 33
- video 58
- video blog 59

- video file formats 62
- voice command key 2, 3,
 - 28
- voice commands 28
- voice dial 28, 85
- voice note 88
- voicemail 43
- voicemail message
 - indicator 43
- volume 23, 33, 34
- volume keys 2, 3, 23

W

- wallpaper 36, 39
- Web pages 54, 55
- word text entry mode 26
- world clock 87

Y

- your phone number 20

U.S. patent Re. 34,976

www.motorola.com

