

GENERAC®

Portable Products

SVP5000

Portable Generator Owner's Manual



DANGER! This generator is designed for outdoor use only. **Never** use this generator inside any building or enclosure including the generator compartment of a recreational vehicle (RV). **Carbon monoxide poisoning, fire and/or an explosion may result.** No user performed modifications, including venting of exhaust and/or cooling ventilation, will eliminate the danger. Always have at least two feet of clearance on all sides of the generator even while operating the unit outdoors.



DANGER! You must isolate the generator from the electric utility by opening the electrical system's main circuit breaker or main switch if this unit is used for backup power. **Failure to isolate the generator from the power utility may result in injury or death to electric utility workers and damage to the generator** due to a backfeed of electrical energy.

The Emission Control System for this generator is warranted for standards set by the Environmental Protection Agency. For warranty information refer to the engine owner's manual.



Model No. 9719-3 (5,000 Watt AC Generator) Manual No. B4468 Revision 3 (7/11/2000)

Visit our Generac website: www.generac-portables.com



This is the safety alert symbol. It is used to alert you to potential personal injury hazards. Obey all safety messages that follow this symbol to avoid possible injury or death.



EQUIPMENT DESCRIPTION

This generator is an engine-driven, revolving field, alternating current (AC) generator. It was designed to supply electrical power for operating compatible electrical lighting, appliances, tools and motor loads. This manual contains information for a generator that operates 120 and/or 240 Volt, single phase, 60 Hz devices that require up to 5,000 watts (5.0 kW) of power that pull up to 41.7 Amps at 120 Volts or 20.8 Amps at 240 Volts.

CAUTION! Do Not exceed the generator's wattage/ampere capacity. Add up the rated watts of all devices you are connecting to generator receptacles at one time. This total should not be greater than 5,000 watts. In most cases rated watts of the electrical device can be found on the device nameplate. If the device nameplate gives only volts and amps, multiply volts times amps to obtain watts (volts X amps = watts).

The SVP5000 generator has the following features:

- 120/240 Volt AC, 20 Amp locking receptacle.
- 120 Volt AC, 30 Amp locking receptacle.
- 120 Volt, 20 Amp duplex receptacle.
- Low Oil Shutdown: Automatically shuts down the engine if oil drops below safe operation level.
- Five gallon overhead fuel tank.
- The generator's revolving field is driven at about 3600 rpm by a Briggs & Stratton 10HP engine.

DANGER! Do Not tamper with engine governed speed. High operating speeds are dangerous and increase risk of personal injury or damage to equipment. The generator supplies correct rated frequency and voltage only when running at proper governed speed. Incorrect frequency and/or voltage can damage some connected electrical loads. Operating at excessively low speeds imposes a heavy load at such reduced speeds, when adequate engine power is not available, and may shorten engine life.

SAFETY RULES

This generator set was designed and manufactured for specific applications. **Do Not** attempt to modify the unit or use it for any application it was not designed for. If you have any questions about your generator's application, ask your dealer or consult the factory.

The manufacturer could not possibly anticipate every circumstance that might involve a hazard. For that reason warnings in the Manual and warnings on tags or decals affixed to the unit are not all-inclusive. If you intend to handle, operate or service the unit by a procedure or method not specifically recommended by the manufacturer, first make sure that such a procedure or method will not render this equipment unsafe or pose a threat to you and others.

Read this manual carefully and become familiar with your generator set. Know its applications, its limitations and any hazards involved.



WARNING:



The engine exhaust from this product contains chemicals known to the State of California to cause cancer, birth defects, or other reproductive harm.

- The generator produces a very powerful voltage that can cause extremely dangerous electrical shock. Avoid contact with bare wires, terminals, etc. **Never** permit an unqualified person to operate or service the generator.
- **Never** handle any kind of electrical cord or device while standing in water, while barefoot or while hands or feet are wet. Dangerous electrical shock may result.
- The National Electric Code requires the frame and external electrically conductive parts of the generator be properly connected to an approved earth ground. Local electrical codes may also require proper grounding of the generator. Consult with a local electrician for grounding requirements in your area.
- Use a ground fault circuit interrupter in any damp or highly conductive area (such as metal decking or steel work).




- **Do Not** use worn, bare, frayed or otherwise damaged electrical cord sets with the generator. Using a defective cord set may result in electrical shock or damage to equipment and/or property.
- Operate unit only on level surfaces and where it will not be exposed to excessive moisture, dirt, dust or corrosive vapors.
- Gasoline is highly **FLAMMABLE** and its vapors are **EXPLOSIVE**. **Do Not** permit smoking, open flames, sparks or heat in the vicinity while handling gasoline. Avoid spilling gasoline on a hot engine. Comply with all laws regulating storage and handling of gasoline.
- **Do Not** overfill the fuel tank. Always allow room for fuel expansion. If tank is overfilled, fuel can overflow onto a hot engine and cause **FIRE** or **EXPLOSION**.
- **Never** store a generator with fuel in the tank where gasoline vapors might reach an open flame, spark or pilot light (as on a furnace, water heater, clothes dryer). **FIRE** or an **EXPLOSION** may result.
- Generator exhaust gases contain **DEADLY** carbon monoxide gas. This dangerous gas, if breathed in sufficient concentrations, can cause unconsciousness or even death. Operate this equipment only in the open air where adequate ventilation is available.
- The unit requires an adequate flow of cooling air for its continued proper operation. **Never** operate the unit inside any room or enclosure where the free flow of cooling air into and out of the unit might be obstructed. Allow at least 2 feet of clearance on all sides of generator or you could damage the unit. Read "Cold Weather Operation" on page 7.
- **Never** start or stop the engine-generator with electrical loads connected to receptacles with the connected devices turned **ON**. Start the engine and let it stabilize before connecting any electrical loads. Disconnect all electrical loads before shutting down the generator.
- **Do Not** insert any object through cooling slots of the engine-generator. You could damage the unit or injure yourself.

- **Never operate the generator:**

in rain; in any enclosed compartment; when connected electrical devices overheat; if electrical output is lost; if engine or generator sparks; if flame or smoke is observed while unit is running; if unit vibrates excessively.

GROUNDING THE GENERATOR

The National Electrical Code requires that the frame and external electrically conductive parts of this generator be properly connected to an approved earth ground. Local electrical codes may also require proper grounding of the unit. For that purpose, a **GROUNDING WING NUT** is provided on the generator end (Figure 1).



Generally, connecting a No. 12 AWG (American Wire Gauge) stranded copper wire to the grounding wing nut and to an earth-driven copper or brass grounding rod (electrode) provides adequate protection against electrical shock. Be careful to keep the grounding wire attached after connecting the stranded copper wire. However, local codes may vary widely. Consult with a local electrician for grounding requirements in your area.


Properly grounding the generator helps prevent electrical shock if a ground fault condition exists in the generator or in connected electrical devices. Proper grounding also helps dissipate static electricity, which often builds up in ungrounded devices.



KNOW YOUR GENERATOR

Read this owner's manual and safety rules before operating your generator.

Compare the illustrations with your generator, to familiarize yourself with the locations of various controls and adjustments. Save this manual for future reference.



120 Volt AC, 20 Amp Duplex Receptacle — May be used to supply electrical power for the operation of 120 Volt AC, 20 Amp, single phase, 60 Hz electrical lighting, appliance, tool and motor loads.

120 Volt AC, 30 Amp Receptacle — May be used to supply electrical power for the operation of 120 Volt AC, 30 Amp, single phase, 60 Hz electrical lighting, appliance, tool and motor loads.

120/240 Volt AC, 20 Amp Receptacle — May be used to supply electrical power for the operation of 120 and/or 240 Volt AC, 20 Amp, single phase, 60 Hz electrical lighting, appliance, tool and motor loads.


Circuit Breakers (AC) — Each receptacle is provided with a circuit breaker to protect the generator against electrical overload. Breakers are "push to reset" type.

Fuel Shut Off — Controls fuel supply to engine.

Fuel Tank — Capacity of 5 U.S. gallons (19 liters).

Grounding Wing Nut — Provides a tie-point for connecting the generator frame to earth ground.

Oil Fill — Fill engine with oil here. See page 5 for oil requirements.



BEFORE STARTING THE ENGINE

Add Oil



WARNING! Any attempt to crank or start the engine before it has been properly filled with the recommended oil may result in an engine failure.

To fill your engine with oil:

- Place generator on a level surface.
- Clean area around oil fill and remove oil fill cap.
- Select the oil's viscosity grade and fill engine with oil following the instructions given in the engine owner's manual. **Do Not overfill!**
- Install oil fill cap.

NOTE: The generator's revolving field rides on a pre-lubricated and sealed ball bearing that requires no additional lubrication for the life of the bearing.

Add Gasoline




DANGER! Explosion Hazard! **Never** fill fuel tank indoors. **Never** fill fuel tank when engine is running or hot. **Do Not** light a cigarette or smoke when filling the fuel tank.



WARNING! **Do Not** overfill the fuel tank. Always allow room for fuel expansion.

- Use regular **UNLEADED** gasoline with the Generator engine. **Do Not** use premium gasoline. **Do Not** mix oil with gasoline.
- Clean area around fuel fill cap, remove cap.
- Add unleaded regular gasoline, slowly to fuel tank. Be careful not to overfill. Allow about 1/2" of tank space for fuel expansion (Figure 2).

Figure 2 — Fill Tank with Fuel



- Install fuel cap and wipe up any spilled gasoline.

IMPORTANT: It is important to prevent gum deposits from forming in essential fuel system parts such as the carburetor, fuel filter, fuel hose or tank during storage. Also, experience indicates that alcohol-blended fuels (called gasohol, ethanol or methanol) can attract moisture which leads to separation and formation of acids during storage. Acidic gas can damage the fuel system of an engine while in storage.

To avoid engine problems, the fuel system should be emptied before storage of 30 days or longer. See "Storage" on page 10. **Never** use engine or carburetor cleaner products in the fuel tank or permanent damage may occur.



OPERATING THE GENERATOR



CAUTION! Never start or stop, the engine with electrical loads connected to the unit and with the connected devices turned ON.

Starting the Engine




DANGER! Breathing Hazard! Never run engine indoors or in enclosed poorly ventilated areas. Engine exhaust contains carbon monoxide, an odorless and deadly gas.



WARNING! Burn Hazard! Temperature of muffler and nearby areas may exceed 150°F (65°C). Avoid these areas.


- Unplug **all** electrical loads from generator receptacles before starting the engine.
- Make sure the unit is in a level position.
- Open the fuel shut-off valve (Figure 3).

Figure 3 — Fuel Shut-Off Valve




- Move the choke lever to the “Choke” position (Figure 4).

Figure 4 — Choke Lever



- Set the engine control switch to the “On” position (Figure 5).

Figure 5 — Engine Control Switch



- Grasp starter grip and pull slowly until you feel some resistance. Then pull cord out with rapid full arm stroke. Let rope return slowly. **Do Not** let rope “snap back” against starter.
- When engine starts, move choke lever to “Run” position.

NOTE: If engine fails to start after 3 pulls, move the choke lever to “Run” and pull starter rope again.

NOTE: If the engine still fails to start, check for proper oil level in crankcase. Unit is equipped with a low oil shutdown system. See engine owner's manual for information regarding the low oil shutdown system.

NOTE: If engine fires, but does not continue to run, move choke lever to “Run” and repeat starting instructions.

Connecting Electrical Loads

- Let engine stabilize and warm up for a few minutes after starting.
- Plug in and turn on the desired 120 and/or 240 Volt AC, single phase, 60 Hz electrical loads.
- **Do Not** connect 240 Volt loads to the 120 Volt duplex receptacles.
- **Do Not** connect 3-phase loads to the generator.
- **Do Not** connect 50 Hz loads to the generator.
- **DO NOT OVERLOAD THE GENERATOR.** Add up the rated watts (or amps) of all loads to be connected at one time. This total should not be greater than the rated wattage/amperage capacity of the generator. See “Don't Overload the Generator” on page 9.



Stopping the Engine

- Unplug **all** electrical loads from generator panel receptacles. **Never** start or stop engine with electrical devices plugged in and turned on.
- Let engine run at no-load for several minutes to stabilize the internal temperatures of engine and generator.
- Move engine control switch to the “Off” position.
- Close the fuel shut-off valve.

COLD WEATHER OPERATION

Under certain weather conditions (temperatures below 40°F [4°C] and a high dew point), your Generac generator may experience icing of the carburetor and/or the crankcase breather system.

In an emergency, use the original shipping box as a temporary shelter:


- Cut off all flaps.
- Cut out one of the long sides of the box to expose exhaust side of unit. Ensure a minimum of two feet clearance between open side of box and nearest object.
- Cut appropriate slots to access receptacles of unit. You may also need to cut a clearance slot for the handle.
- Start unit, then place box over it.

IMPORTANT: Remove shelter when temperature is above 40°F [4°C].

For a more permanent shelter, build a structure that will enclose three sides and the top of the generator:

- Make sure entire muffler-side of generator is exposed. A typical shelter is shown in Figure 6.

Figure 6 — Typical Cold Weather Temporary Shelter



- Ensure a minimum of two feet clearance between open side of box and nearest object.
- Face exposed end away from wind and elements.
- Enclosure should hold enough heat created by the generator to prevent icing problems.



CAUTION! **Never** run unit indoors; **Do Not** enclose generator any more than shown. Remove shelter when temperatures are above 40°F [4°C].




RECEPTACLES

120 Volt AC, 20 Amp Duplex Receptacles

Each of these receptacles is protected against overload by 20 Amp push-to-reset circuit breaker.

Figure 7 — 120 Volt, 20 Amp Duplex Receptacle




Use each receptacle to operate 120 Volt, 60 Hz, single phase loads requiring up to 2,400 (2.4kW) watts of power at 20 Amps of current (Figure 7).

120/240 Volt AC, 20 Amp Locking Receptacle

Use a NEMA L14-20P plug with this receptacle. Connect a 4-wire cord set rated for 250 Volt loads at 20 AC Amps (or greater) (Figure 8). You can use the same 4-wire cord if you plan only to run a 120 Volt load.

This receptacle powers 120/240 Volt AC, 60 Hz, single phase loads and is protected by a 20 Amp push-to-reset circuit breaker.


Figure 8 — 120/240 Volt, 20 Amp Locking Receptacle



120 Volt AC, 30 Amp Locking Receptacle

Use a NEMA L5-30P plug with this receptacle. Connect a 3-wire cord set rated for 125 Volt AC loads at 30 Amps to the plug (Figure 9).

Figure 9 — 120 Volt, 30 Amp Locking Receptacle



Use this receptacle to operate 120 Volt AC, 60 Hz, single phase loads requiring up to 3,600 watts (3.6 kW) of power at 30 Amps. The outlet is protected by a 30 Amp push-to-reset circuit breaker.



DON'T OVERLOAD THE GENERATOR

Overloading a generator in excess of its rated wattage capacity can result in damage to generator and to connected electrical devices. Observe the following, to prevent overloading the unit:

- Add up the total wattage of all electrical devices to be connected at one time. This total should NOT be greater than the generator's wattage capacity.
- The rated wattage of lights can be taken from light bulbs. The rated wattage of tools, appliances and motors can usually be found on a data plate or decal affixed to the device.
- If the appliance, tool or motor does not give wattage, multiply 120 Volts times ampere rating to determine watts (volts x amps = watts).
- Some electric motors, such as induction types, require about three times more watts of power for starting than for running. This surge of power lasts for only a few seconds when starting such motors. Be sure you allow for this high starting wattage when selecting electrical devices to connect to your generator. First figure the watts needed to start the largest motor. Add to that figure the running watts of all other connected loads.
- Devices in the wattage reference guide (Figure 10) are provided to help you to determine how many items the generator can operate at one time.

Figure 10 — Wattage Reference Guide

Recreational/Home Uses		Professional/Contractor Uses	
Tool/Appliance.....	Watts	Tool/Appliance.....	Watts
AM/FM clock radio	50	*1/3 hp airless sprayer	600
Light bulb	100	3/8" hammer drill.....	600
Fan	200	Variable speed Sawzall®.....	960
20" color TV	400	1/2" power drill	1000
*Deep freezer	500	Quartz-halogen work light.....	1000
Personal computer and 15" monitor	800	Belt sander	1200
*1/3 hp furnace fan blower.....	800	7 1/4" circular saw	1500
Microwave oven.....	800	7 1/4" worm drive saw	1600
*18 cu ft refrigerator	800	*1 1/2 hp air compressor	1800
Sump pump	1000	*10" power miter saw.....	1800
Electric skillet.....	1250	6" bench grinder	1800
*1/2 hp water well pump	1400	*6" table planer	1800
*12,000 Btu window air conditioner	1400	*10" table/radial arm saw.....	2000
Space heater	1800	Wire feed welder.....	2400
Electric water heater.....	4000	* allow 3 times listed watts for starting this device	



SPECIFICATIONS

Maximum Surge Watts		6,250 watts
Continuous Wattage Capacity		5,000 watts
Power Factor		1.0
Rated Maximum Continuous Load		
At 120 Volts		41.7 Amps
At 240 Volts		20.8 Amps
Phase		1 phase
Rated Frequency		60 Hertz
Fuel Tank Capacity		.5 U.S. gallons

GENERAL MAINTENANCE RECOMMENDATIONS

The owner/operator is responsible for making sure that all periodic maintenance tasks are completed on a timely basis; that all discrepancies are corrected; and that the unit is kept clean and properly stored. **Never operate a damaged or defective generator.**

Engine Maintenance

See engine manual for instructions.

Generator Maintenance

Generator maintenance consists of keeping the unit clean and dry. Operate and store the unit in a clean dry environment where it will not be exposed to excessive dust, dirt, moisture or any corrosive vapors. Cooling air slots in the generator must not become clogged with snow, leaves or any other foreign material.

NOTE: Do Not use a garden hose to clean generator. Water can enter engine fuel system and cause problems. In addition, if water enters generator through cooling air slots, some of the water will be retained in voids and cracks of the rotor and stator winding insulation. Water and dirt buildup on the generator internal windings will eventually decrease the insulation resistance of these windings.

To Clean the Generator

- Use a damp cloth to wipe exterior surfaces clean.
- Soft, bristle brush may be used to loosen caked on dirt or oil.
- A vacuum cleaner may be used to pick up loose dirt and debris.
- Low pressure air (not to exceed 25 psi) may be used to blow away dirt. Inspect cooling air slots and opening on generator. These openings must be kept clean and unobstructed.

STORAGE INSTRUCTIONS

The generator should be started at least once every seven days and allowed to run at least 30 minutes. If this cannot be done and you must store the unit for more than 30 days, use the following guidelines to prepare it for storage.

Generator Storage

- Clean the generator as outlined in "To Clean the Generator."
- Check that cooling air slots and openings on generator are open and unobstructed.



DANGER! Storage covers can be flammable. **Do Not** place a storage cover over a hot generator. Let the unit cool for a sufficient time before placing the cover on the unit.

Engine Storage

See engine owner's manual for instructions.


Other Storage Tips

- **Do Not** store gasoline from one season to another.
- Replace your gasoline can if it starts to rust. Rust and/or dirt in a gasoline can cause problems when you use contaminated fuel with this unit.
- Store in clean and dry area.





TROUBLESHOOTING

Problem	Cause	Solution
Engine is running, but no AC output is available.	1. Circuit breaker is open. 2. Poor connection or defective cord set. 3. Connected device is bad. 4. Fault in generator.	1. Reset circuit breaker. 2. Check and repair. 3. Connect another device that is in good condition. 4. Contact Generac service facility.
Engine runs good but bogs down when loads are connected.	1. Short circuit in a connected load. 2. Generator is overloaded. 3. Engine speed is too slow. 4. Shorted generator circuit.	1. Disconnect shorted electrical load. 2. See "Don't Overload the Generator" on page 9. 3. Contact Briggs & Stratton service facility. 4. Contact Generac service facility.
Engine will not start; or starts and runs rough.	1. On/Off switch set to Off (o). 2. Dirty air cleaner. 3. Out of gasoline. 4. Stale gasoline. 5. Spark plug wire not connected to spark plug. 6. Bad spark plug. 7. Water in gasoline. 8. Overchoking. 9. Low oil level. 10. Excessively rich fuel mixture. 11. Intake valve stuck open or closed. 12. Engine has lost compression.	1. Set switch to On (-). 2. Clean or replace air cleaner. 3. Fill fuel tank. 4. Drain gas tank and fill with fresh fuel. 5. Connect wire to spark plug. 6. Replace spark plug. 7. Drain gas tank; fill with fresh fuel. 8. Put choke lever to "Run" position. 9. Fill crankcase to proper level. 10. Contact Briggs & Stratton service facility. 11. Contact Briggs & Stratton service facility. 12. Contact Briggs & Stratton service facility.
Engine shuts down during operation.	1. Out of gasoline. 2. Low oil level. 3. Fault in engine.	1. Fill fuel tank. 2. Fill crankcase to proper level. 3. Contact Briggs & Stratton service facility.
Engine lacks power.	1. Load is too high. 2. Dirty air filter. 3. Engine needs to be serviced.	1. See "Don't Overload the Generator" on page 9. 2. Replace air filter. 3. Contact Briggs & Stratton service facility.
Engine "hunts" or falters.	1. Choke is opened too soon. 2. Carburetor is running too rich or too lean.	1. Move choke to halfway position until engine runs smoothly. 2. Contact Briggs & Stratton service facility.





ELECTRICAL SCHEMATIC







WIRING DIAGRAM





EXPLODED VIEW — GENERATOR





PARTS LIST — GENERATOR

Item	Part #	Qty	Description	Item	Part #	Qty	Description
1	NSP	1	ENGINE, B & S 10 H.P.	36	81919	1	COVER, Rear Panel
2	66825C	1	CARRIER, Rear Bearing	37	68868	1	OUTLET, 120 Volt 30Amp. Locking Rec.
3	91825	1	ASSY., Brush & Bridge Rectifier	38	68867	1	OUTLET, 120/240 Locking Rec.
4	66365-G	1	HOUSING, Engine Adapter	39	68759	1	OUTLET, 120 Volt 20Amp Duplex
5	22129	2	WASHER, M8 - 5/16 Lock	40	84242	2	GROMMET, R. B. C.
6	86307	4	HHMS, 5/16" x 3/4"	41	25244	2	NUT, 5/16 - 18 Hex
7	91844J	1	ASSEMBLY, Rotor	42	74908	4	TAPTITE, M5 0.8 x 10
8	65791	1	BEARING	43	22264	6	LOCK WASHER, #8
9	96796	1	WASHER, Special	44	51715	6	NUT, Hex M4 - 0.7
10	47480	1	HHCS, 5/16" - 24 x 7"	45	75207A	1	CIRCUIT BREAKER, 30 Amp
11	91859J	1	ASSEMBLY, Stator	46	75207	2	CIRCUIT BREAKER, 20 Amp
12	81917	1	PIN, M4 x 10 Roll	47	26850	2	WASHER, Shakeproof 1/4"
13	86308C	4	HHCS, M6 - 1.0 x 130	48	75475	6	PPHMS, M4 - 0.7 x 10
14	48031C	2	CLAMP, Hose 1/4"	49	82857	2	MOUNT, Rubber
15	88977	1	SWITCH, Low Oil Shutdown	50	82308	6	SCREW, Self Tapping
16	70642	2	MOUNT, Vibration 45 Deg.	51	86494	1	WING SCREW, M6 x 16
17	B4871	1	COVER, Bearing Carrier	53	A91020	1	CRADLE
18	52858	6	NUT, M8 Locking 1.25 Flange	54	67022	1	GROMMET, Rubber
19	76222	2	PPHMS, M8 1.25 x 40 mm	55	22471	2	NUT, No. 8-32
20	14353621	1	WIRE, Ground	56	22769	1	WASHER, Shakeproof #10
21	82881	3	LOCK WASHER, Internal	57	66849	2	SCREW, M5 - 0.8 x 15
22	86292	5	SCREW, #10 Self Drilling	58	91842A	1	WIRE, LOS
23	38150	6	FLAT WASHER, #8	59	22695	1	6-Pin Connector - Male
24	23365	6	LOCK WASHER, No. 8 serrated	60	22694	1	6-Pin Connector
25	B4465	1	DECAL, Control Panel	61	32713	1	SCREW, No. 10-32 x 5/8"
26	B78951A	1	SHIELD, Heat	62	91841	1	GASKET, LOS
27	56893	2	SCREW 10 - 24 x 1/2" Crimptite	63	83465	4	GROMMET, Mounting Tank
28	77374	1	TANK, Plastic 5 Gal.	64	B4986	1	DECAL, Ground
29	23365	1	WASHER, No. 8 Shakeproof	65	B2153	4	SCREW, Self Driller #12-14 x 7/8"
30	78831B	4	CAPSC, M6 x 60 mm Hx Hd	Accessories Not Illustrated			
31	90878	1	CAP, Fuel				
32	77395	4	NUT, M6 Flange Lock	37806	120 Volt, 30 Amp Plug		
33	78299	1	BUSHING, Plastic Tank	43483	120/240 Volt, 20 Amp Plug		
34	80270	1	VALVE, Plastic Tank				
35	81898	1	PANEL, Control				

LIMITED WARRANTY FOR PORTABLE GENERATORS

(EXCEPT GN ENGINE SERIES)

Generac Portable Products (hereafter referred to as the COMPANY) warrants to the original purchaser that its generator will be free from defects in materials or workmanship for a period of one year* from the date of original purchase. This warranty does not apply to units used for prime power in place of utility. This warranty does not include the gasoline engine when furnished or attached because such engine is covered solely by the warranty of the manufacturer of the engine. Starting batteries are not warranted by the COMPANY.

***NOTE:** Rental units, demonstrators, commercial applications, such as construction or income producing, are warranted for 90 days. Rental units, demonstrators, or commercial applications such as construction or utility which are resold are not covered under warranty by the COMPANY. Any warranty, whether expressed or implied, rests solely with the seller.

During said warranty period, the COMPANY will, at its option, repair or replace any part which, upon examination by the COMPANY is found to be defective under normal use and service. All transportation costs under warranty, including return to the factory if necessary, are to be borne by the purchaser and prepaid by the purchaser. This warranty does not include nominal maintenance and service and does not apply to a generator set, or parts, which have been subjected to improper or unauthorized installation, misuse, negligence, accident, overloading, overspeeding, improper maintenance, repair or storage so as, in the COMPANY's judgment, to adversely affect its performance and reliability.

THERE IS NO OTHER EXPRESS WARRANTY. THE COMPANY HEREBY DISCLAIMS ANY AND ALL IMPLIED WARRANTIES, INCLUDING BUT NOT LIMITED TO THOSE OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE TO THE EXTENT PERMITTED BY LAW. THE DURATION OF ANY IMPLIED WARRANTIES WHICH CANNOT BE DISCLAIMED IS LIMITED TO THE TIME PERIOD AS SPECIFIED IN THE EXPRESS WARRANTY. LIABILITY FOR INCIDENTAL, CONSEQUENTIAL, OR SPECIAL DAMAGES UNDER ANY AND ALL WARRANTIES IS EXCLUDED TO THE EXTENT PERMITTED BY LAW. THE COMPANY ALSO DISCLAIMS ANY RESPONSIBILITY FOR INCIDENTAL OR CONSEQUENTIAL DAMAGES SUCH AS THE LOSS OF TIME OR THE USE OF THE POWER EQUIPMENT, OR ANY COMMERCIAL LOSS DUE TO THE FAILURE OF THE EQUIPMENT; AND ANY IMPLIED WARRANTIES ARE LIMITED TO THE DURATION OF THIS WRITTEN WARRANTY.

Some states do not allow limitations on how long an implied warranty lasts, or the exclusions or limitations of incidental or consequential damages, so the above limitations or exclusions may not apply to you. This warranty gives you specific legal rights and you may also have other rights, which vary from state to state.

This warranty is effective for all products manufactured after June, 1998, and supersedes all prior warranties of the COMPANY.

For service, contact your nearest COMPANY authorized warranty service facility or call 1-877-544-0982. Warranty service can only be performed by a COMPANY authorized service facility. At the time of requesting warranty service, evidence of original purchase date must be presented.

GENERAC PORTABLE PRODUCTS
Jefferson, Wisconsin 53549