

**HONDA**  
**PORTABLE GENERATOR**

**EM400**

**OWNER'S MANUAL**

*Thank you for purchasing the HONDA generator*

////////////////////////////////////// **PREFACE** //

The HONDA EM 400 Portable Generator Model is a compact, light, low-noise AC-DC generator.

This manual contains important and helpful information for the proper operation and servicing of your HONDA EM 400 generator.

The manual should be read thoroughly to obtain the fullest satisfaction and the best performance from the generator. Careful handling, proper operation, and performance of the scheduled maintenance will keep the generator in the best operating condition, assuring long, trouble-free service.

If difficulties should develop, consult your nearest authorized HONDA Generator Dealer for prompt and expert assistance.

## SAFE OPERATION

### Observe the following for safe operation:

1. Do not use the generator inside a room, tunnel, well, or any other confined area.
2. Do not enclose or cover the generator with a box.  
The generator will overheat and the accumulation of carbon monoxide may be lethal.
3. Point the exhaust outlet in the direction of an open space with good ventilation.
4. Be very careful of people and domestic animals in the vicinity of the generator.
5. Keep all combustible materials such as gasoline, matches, celluloid, explosives, etc., away from exhaust.
6. Ensure that the generator is at least three feet away from walls, buildings, or adjoining equipment during operation.  
If it is necessary to install the generator in a confined area such as a basement, motor home or boat, proper mounting and ventilation of the unit are essential.

#### **WARNING :**

**Exhaust gases contain poisonous carbon monoxide. Do not operate the generator in an enclosed area.**

#### **WARNING :**

**Gasoline is flammable and explosive under certain conditions. Always stop the engine and do not smoke or allow open flames or sparks near the generator when refueling.**

7. Operate the generator on a level surface.
8. Do not move or tilt the generator while it is in use.
9. Do not refuel while the engine is running.
10. Do not fill the fuel tank over the level line.
11. Do not attempt to service the generator while the engine is running.
12. Do not operate the generator in rain or snow.
13. Do not operate the generator with wet hands.
14. Do not connect the generator to household wiring.
15. Operate the generator where cooling air is adequate and the ambient temperature is between 5°F (-15°C) and 104°F (40°C).



- BEFORE STARTING : CHECK FOR SPILLED FUEL OR FUEL LEAKS.  
DO NOT PLUG IN UNTIL ENGINE IS STARTED.
- BEFORE REFUELING : STOP ENGINE BEFORE FILLING FUEL TANK.  
DO NOT FILL OVER LEVEL LINE.
- OPERATE GENERATOR OUT - OF - DOORS IN WELL VENTILATED  
AREA AWAY FROM COMBUSTIBLE MATERIALS.

## CONTENTS

PREFACE.....	1
SAFETY IN OPERATION.....	2
MAIN FEATURES.....	5
SUITABLE APPLIANCES.....	6
MAIN COMPONENT LOCATION.....	7
STANDARD ACCESSORIES.....	9
PRE-OPERATING INSPECTION.....	10
STARTING THE GENERATOR.....	13
CONNECTING ELECTRICAL APPLIANCES.....	15
SHUTTING OFF THE GENERATOR.....	18
MAINTENANCE.....	19
Changing Engine Oil.....	20
Air Cleaner Service.....	21
Spark Plug Cleaning.....	22
Checking Breaker Points.....	23
Lubricating Recoil Starter.....	24
Fuse Replacement.....	25
Spark Arrestor Cleaning.....	26
TRANSPORTING.....	27
EXTENDED STORAGE.....	28
WIRING DIAGRAM.....	30
SPECIFICATIONS.....	31

## MAIN FEATURES

The EM 400 is a gasoline, air-cooled generator with a manual recoil starter, automatic choke and solid state voltage regulator.

The combination of the recoil starter and automatic choke facilitates engine starting regardless of ambient temperatures.

The solid state voltage regulator supplies alternating and direct current at a stabilized voltage.

Item	Alternating Current	Direct Current
Rated Engine Speed	3,840 rpm	3,900 rpm
Rated Cycles/sec.	64 Hz	
Rated Voltage	115 V	13 V
Rated Wattage-continuous	300 W	
Rated Amperage		8.3 A

- A maximum wattage of 400 W (3.5 amperes) may be drawn for 15 min. after the engine has started.

## //////////////////////SUITABLE APPLIANCES////////////////////////////////////

### **Alternating Current**

The EM 400 generator is designed to operate several types of alternating current electrical appliances.

- Lighting equipment, radios, and other small appliances.
- Television:  
Some television sets will show signs of vertical oscillation.
- Single-phase motorized appliances:  
Some electrical appliances, such as televisions, tape recorders, electric clocks and others with synchronous motors cannot be operated properly with the EM400. These appliances will operate at a slightly faster rate of speed due to the generator's slightly higher than

normal operating frequency. Most motors require more than the rated amperage for starting. If this current surge exceeds four amperes, the appliance cannot be operated by the EM400.

### **Direct Current**

The EM 400 generator DC should not be used for any purpose other than charging a 12 volt automotive battery.

#### **NOTE:**

- Alternating and direct current cannot be used simultaneously.
- If there is any question regarding appliance-generator compatibility consult your nearest authorized HONDA Generator Dealer.

////////////////////MAIN COMPONENT LOCATION////////////////////

**EM 400-Front View**



- ① Fuel filler cap
- ② Carrying handle
- ③ Air cleaner cover
- ④ Control lever

- ⑤ Starter grip
- ⑥ Oil filler cap
- ⑦ DC pilot light
- ⑧ DC output receptacle

- ⑨ DC-AC selector switch
- ⑩ AC output receptacle



## EM 400-Rear View



① Rear cover

② Exhaust outlet



③ Cover securing knob

## STANDARD ACCESSORIES

The following accessories are included with the generator and packed in the same shipping case.

- (1) DC charging leads
- (2) Spare fuses  
3.5 Amp. for AC  
10 Amp. for DC
- (3) Spark plug
- (4) Tool kit

The spare fuses, spark plug and tool kit are stored inside the rear cover as shown below.



## PRE-OPERATING INSPECTION

*Before starting the engine, observe the following procedure:*


**NOTE:** *Stabilize the generator on level ground.*

### Fuel

Fill the tank up to the "LEVEL" indicator in the fuel filler.

**Fuel tank capacity: 2.0 lit. (0.5 U.S. gal.)**

Total operating time with a full tank of fuel is approximately 4 hours.



- ① Level indicator
- ② Fuel filler

### WARNING :

- Always stop the engine before refueling.
- Never overfill the fuel tank.

### CAUTION :

- Do not use a gasoline-oil mixture as fuel in this engine.
- Exercise care to keep dirt, water or other foreign substances from contaminating the fuel.
- Use low-lead or regular gasoline with a Research Octane number of 91 or higher or Pump Octane number of 86 or higher.

### NOTE :

Pump Octane is the octane formula specified by the Cost of Living Council.

## Engine Oil


Remove the oil filler cap and fill the engine with oil to the upper level mark on the dipstick.

For a proper oil level reading, place the dipstick on the lip of the threaded hole, remove and check the level.

### NOTE:

- Do not screw in the dipstick, when checking the oil level.
- Check the oil level only when the generator is on level ground.

Oil capacity: 0.3lit. (0.3 U.S. qt.)



① Oil level gauge




## Type of Oil

Use high quality automotive engine oil. Select the proper viscosity oil for the operating temperature.

**10w-30** multigrade oil is recommended for all temperature use.

S. A. E. Grade	Outside temp.	
	°F	°C
30	60	15
20 20W	32	0
10W		




## AC-DC Selector Switch

Place the AC-DC selector switch in the left-hand AC position when operating AC appliances and in the right-hand DC position when charging an automobile battery.

### NOTE:

When the AC-DC selector switch is in the AC position the DC receptacle is blocked and when the switch is in the DC position the AC receptacle is blocked.



① AC-DC selector switch

## STARTING

If a load is connected to the generator before it is running, the generator engine will be difficult to start.

### CAUTION:


Always plug the appliance into the receptacle after the engine is running.

### Starting Procedure

1. Move the control lever to the "ON" position.
2. Pull the starter grip lightly until compression is felt. Then pull the grip swiftly.

### WARNING:

Do not let go after pulling the starter grip. Let it return gently.



① Control lever




① Control lever

② Starter grip

**NOTE :**

If the engine does not start after about ten attempts ;

1. Remove the cover to ensure the link connections are connected properly.
2. Remove the spark plug and return the control lever to the "OFF" position, then pull the grip several times.
3. Reinstall the spark plug and follow the starting procedure.



- ① Link connection  
② Spark plug cap

## //////////////////////////////////////CONNECTING ELECTRICAL APPLIANCES//////////////////////////////////////

The EM 400 provides both alternating and direct current but they cannot be used simultaneously. The AC-DC selector switch is of the interlock type to prevent simultaneous use.


### AC Operation

1. Ensure that the engine is running smoothly.
2. Ensure that the AC-DC selector switch is set in the AC position.
3. Insert the plug of the AC appliance into the AC output receptacle.

### CAUTION:

A three pronged plug should be used.

- ① AC-DC selector switch
- ② AC output plug
- ③ DC pilot light





## DC Operation


The DC circuitry is only designed to charge a **12 Volt automotive battery**. Before connecting the generator to the battery, make sure all electrical items on the automobile are "off".

1. Ensure that the engine runs smoothly.
2. Ensure that the AC-DC selector switch is in the DC position.
3. Insert the DC charging lead plug into the DC output receptacle.
4. Clamp the positive (+) charging lead to the positive (+) terminal of the battery and the negative (-) charging lead to the negative (-) terminal.

## CAUTION:

- Do not attempt to start the automobile engine with the generator still connected to the battery.


- ① AC-DC selector switch
- ② DC charging leads
- ③ DC pilot light



**NOTE:**

The DC pilot lamp will be "on" when the DC power is operating normally. If the lamp does not light, check the DC fuse and the pilot lamp bulb.


If the lamp still does not light, consult your nearest HONDA Generator Dealer.



① Charging leads

## SHUTTING OFF THE GENERATOR

1. Turn off the electrical appliance.
2. Move the control lever to the "OFF" position.



① Control lever

## MAINTENANCE

### Periodical Service Chart

Maintenance is the most important factor in keeping the equipment in best operating condition. Be sure to perform the servicing periodically in accordance with the maintenance schedule below.

Item \ Period	EVERY OPERATION	FIRST 20 HOURS	EVERY 100 HRS OR 6 MONTHS	EVERY 200 HRS OR 12 MONTHS	REF. PAGE
Engine Oil	I	R	R		11, 20
Fuel	I				10
Air Cleaner	Service more frequently if operated in dusty area.		C		21
Spark Plug			I		22
Contact Breaker Point				I	23
*Combustion Chamber				C	
*Valve Seat				I	
*Fuel Tank				C	
*Fuel Tube, Rubber Mount		Check every year and replace if necessary.			

I : Inspect and service as necessary    R : Replace    C : Clean

\* denotes to consult your HONDA Dealer.

If generator is used for long periods of time, oil change intervals may be increased to 100 hours.

## Changing Engine Oil

### Draining

Remove the oil filler cap and drain oil from the filler hole by tilting the whole generator.

### CAUTION:

Do not drain engine oil when the generator is running.

### Filling


Fill oil through the filler hole and check the level. (See page 11).

**Oil capacity: 0.3 lit. (0.3 U.S. qt.)**

**Recommended oil is described on page 12.**



① Filler hole




② Oil level gauge

## Air Cleaner Service

A dirty air cleaner will cause a loss in power output.

### Cleaning

1. Remove the air cleaner cover and the air cleaner element.
2. Wash the air cleaner element in standard solvent.
3. Soak the air cleaner element in oil. Squeeze out the excess and install the air cleaner case.



① Air cleaner element

The air cleaner must be serviced at more frequent intervals when operating the generator in extremely dusty areas.

### WARNING:

**Do not smoke or allow open flames or sparks near any cleaning solvent.**

### CAUTION:

**Do not run the generator without the air cleaner.**



## Spark Plug Cleaning And Adjustment

In order for the engine to develop full power, the spark plug must be free of carbon deposits and the plug gap properly set.

### Spark plug removal

Remove the rear cover and unscrew the plug with the plug wrench provided in the tool kit.

### Cleaning

Use a wire brush to remove carbon de-

posits. Do not damage the electrodes or scratch the insulator.


### Spark gap adjustment

Use a feeler gauge to measure the plug gap. If necessary adjust the gap by bending the grounded side electrode.


**Standard spark gap: 0.4 mm. (0.016 in.)**

### CAUTION:

**Use only a NGK CM-6 spark plug.**



① Spark plug wrench



## Checking Breaker Points


If the contact points become pitted or dirty, they should be cleaned with a point file.

### Ignition Timing

Incorrect ignition timing will cause a drop in power output and starting may be difficult.

### Adjustment procedure


1. Remove the front and rear covers, the



- ① Front cover
- ② Right end cover
- ③ Rear cover

right end cover and the contact breaker cover.


2. Proper ignition timing is determined by observing when the contact points begin to open. The points should start to open when the cooling fin with the red timing mark aligns with the red timing index mark on the generator case.



- ① Red mark
- ② Contact point cover screws



3. If the ignition timing requires adjustment, loosen the contact point cover screws and make the adjustment with the adjusting screw.
4. After completing the adjustment, replace the contact points cover, right end cover, and the front and rear covers.




- ③ Contact point cover screw
- ④ Adjusting screw
- ⑤ Contact points

## Lubricating the Recoil Starter

If there is a clatter in the recoil starter, the recoil starter pawls should be lubricated.

For lubrication, remove the front cover and apply two or three drops of oil to the recoil starter through the oil hole in the fan located behind the side cover.




- ① Oil hole

## Fuse Replacement



The fuseholder is located directly above the muffler, inside the rear cover. The DC fuseholder is on the left and the AC fuseholder is on the right. Always use the recommended fuse to prevent damage to the generator.

**Fuse size AC: 3.5A, DC: 10A**

Spare fuses should always be carried in the spare fuseholder under the rear cover.



- ① Spare fuses
- ② Spare spark plug



- ③ DC fuseholder
- ④ AC fuseholder

## Spark Arrestor Cleaning

The exhaust system spark arrestor must be cleaned of accumulated carbon periodically.


### WARNING:

**Ensure that the exhaust system is not hot when performing this operation.**

1. Remove the rear cover.
2. Remove the spark arrestor cover by loosening and removing the two spark arrestor cover bolts.
3. Remove accumulated carbon with a small brush.
4. Reinstall the spark arrestor cover and rear cover.

### NOTE:

**When installing the rear cover, ensure that the tabs on the bottom of the cover are inserted into the slots.**




- ① Muffler
- ② Spark arrestor cover
- ③ Spark arrestor cover bolts

## TRANSPORTING

Observe the following precautions when preparing the generator for transportation.

- Set the control lever to the "OFF" position.
- Ensure that the fuel tank cap is secured.
- Prevent the generator from being bumped or dropped.
- Maintain the generator in an upright position when transporting.




① Control lever

## EXTENDED STORAGE

### Extended Storage

When the generator is not to be used for a long period of time, observe the following:

- Set the control lever to the "OFF" position.
- Close the breaker points and valves by pulling the rope starter slowly until compression is felt and then pull an additional 1-2 in. (3-4 cm). In this position, both the intake and exhaust valves as well as the breaker points are closed, preventing the breaker points surfaces and the valve face seat from corroding.



● **Draining gasoline**


If the generator is not to be used for a period of time longer than a month, remove the drain screw on the carburetor and move the control lever to the "ON" position to drain the fuel from the tank and the carburetor.

**WARNING:**

**Do not smoke or allow open flames or sparks near generator when draining.**


**Storage area**

Store the generator in an area where it is dry, free from dust and well ventilated.



① **Drain screw**

# WIRING DIAGRAM



- G.....Green
- Bk.....Black
- Y.....Yellow
- R.....Red
- W.....White
- Br.....Brown
- Bl.....Blue
- LG.....Lightgreen

## ////////////////////// SPECIFICATIONS ////////////////////////

### Dimension & Weight

Length	14.0 in. (355 mm)
Width	10.4 in. (265 mm)
Height	12.2 in. (310 mm)
Dry weight	38.6 lbs. (17.5 kg)
Curb weight	41.9 lbs. (19.0 kg)

### Engine

Engine Type	4 cycle side valve, 1 cylinder
Displacement	55.4 cc (3.38 cu. in.)
Bore × Stroke	42 × 40 mm (1.65 × 1.57 in.)
Rated output	0.75 HP/3,840 rpm
Maximum output	1.2 HP/4,000 rpm
Cooling	Forced air cooled
Ignition	Magneto ignition
Spark plug	CM-6 (NGK)
Engine oil capacity	0.3 lit. (0.3 U.S. qt.)
Fuel	Gasoline
Fuel tank capacity	2.0 lit. (0.5 U.S. gal.)
Compression ratio	5.5 : 1



## **Current customer service contact information:**

### **United States, Puerto Rico, and U.S. Virgin Islands:**

Honda Power Equipment dealership personnel are trained professionals. They should be able to answer any question you may have. If you encounter a problem that your dealer does not solve to your satisfaction, please discuss it with the dealership's management. The Service Manager or General Manager can help. Almost all problems are solved in this way.

If you are dissatisfied with the decision made by the dealership's management, contact the Honda Power Equipment Customer Relations Office. You can write:

American Honda Motor Co., Inc.  
Power Equipment Division  
Customer Relations Office  
4900 Marconi Drive  
Alpharetta, GA 30005-8847

Or telephone: (770) 497-6400 M-F, 8:30 am - 5:00 pm EST

When you write or call, please provide the following information:

- Model and serial numbers
- Name of the dealer who sold the Honda power equipment to you
- Name and address of the dealer who services your equipment
- Date of purchase
- Your name, address, and telephone number
- A detailed description of the problem

MEMO



**HONDA**

HONDA MOTOR CO., LTD. TOKYO, JAPAN

3187003

英SM A 10007507  
PRINTED IN JAPAN