

# PARTS LIST

for

# **KitchenAid®**

VARIATIONS  
OF

**Model No.**

**KFC3100**

**FOOD CHOPPER**




FOR CUSTOMER SATISFACTION ALWAYS USE  
FACTORY SPECIFICATION PARTS



# MOTOR AND HOUSING PARTS

For Models: KFC3100WH, KFC3100BI, KFC3100BU, KFC3100ER, KFC3100OB



# MOTOR AND HOUSING PARTS

For Models: KFC3100WH, KFC3100BI, KFC3100BU, KFC3100ER, KFC3100OB

<b>Illus. No.</b>	<b>Part No.</b>	<b>DESCRIPTION</b>
1		Literature Parts
	LIT8204527	Owners Manual
	LIT8204526	Parts List
2		Upper Housing
	4176667	White
	4176677	Empire Red
	4176680	Cobalt Blue
	4176683	Onyx Black
	4176687	Biscuit
3		Overlay
	4176668	White
	4176678	Empire Red
	4176681	Cobalt Blue
	4176684	Onyx Black
	4176688	Biscuit
4		Base
	4176669	White
	4176679	Empire Red
	4176682	Cobalt Blue
	4176685	Onyx Black
	4176689	Biscuit
5		Power Cord
	4176670	White
	4176686	Black
6	4176671	Motor
7	4176672	Trim Band
8	4176464	Foot
9	4176400	Screw
10	4176673	Lid
11	4176674	Blade
12	4176675	Bowl
13	4176676	Handle, Bowl