



AristoPower 460

DC WELDING POWER SOURCES



INSTRUCTION MANUAL


This manual provides complete instructions for the following power sources starting with Serial Number MORJ30001, August 2002:

ESAB ITEM NO. 0558002668, AristoPower 460 - 230/460/575 vac, 3 ph., 60 Hz

Revision B

0558003748

03 / 2004



BE SURE THIS INFORMATION REACHES THE OPERATOR

These INSTRUCTIONS are for experienced operators. If you are not fully familiar with the principles of operation and safe practices for arc welding and cutting equipment, we urge you to read our booklet, "Precautions and Safe Practices for Arc Welding, Cutting, and Gouging," Form 52-529. Do NOT permit untrained persons to install, operate, or maintain this equipment. Do NOT attempt to install or operate this equipment until you have read and fully understand these instructions. If you do not fully understand these instructions, contact your supplier for further information. Be sure to read the Safety Precautions before installing or operating this equipment.

USER RESPONSIBILITY

This equipment will perform in conformity with the description thereof contained in this manual and accompanying labels and/or inserts when installed, operated, maintained and repaired in accordance with the instructions provided. This equipment must be checked periodically. Malfunctioning or poorly maintained equipment should not be used. Parts that are broken, missing, worn, distorted or contaminated should be replaced immediately. Should such repair or replacement become necessary, the manufacturer recommends that a telephone or written request for service advice be made to the Authorized Distributor from whom it was purchased.

This equipment or any of its parts should not be altered without the prior written approval of the manufacturer. The user of this equipment shall have the sole responsibility for any malfunction which results from improper use, faulty maintenance, damage, improper repair or alteration by anyone other than the manufacturer or a service facility designated by the manufacturer.

Copies of this manual can be obtained by any of the following;

Contacting your local ESAB supplier.

**Downloading a copy from the ESAB web site at
www.esabna.com**

Sending a written request to

**ESAB WELDING & CUTTING PRODUCTS
ATTN: LITERATURE DEPT.
411 S EBENEZER ROAD
FLORENCE SC 29501**

TABLE OF CONTENTS

SECTION	TITLE	PAGE
SECTION 1	SAFETY	4
SECTION 2	DESCRIPTION	10
SECTION 3	INSTALLATION	16
SECTION 4	OPERATION	20
SECTION 5	MAINTENANCE	21
SECTION 6	TROUBLESHOOTING	22
SECTION 7	REPLACEMENT PARTS	27



WARNING: These Safety Precautions are for your protection. They summarize precautionary information from the references listed in Additional Safety Information section. Before performing any installation or operating procedures, be sure to read and follow the safety precautions listed below as well as all other manuals, material safety data sheets, labels, etc. Failure to observe Safety Precautions can result in injury or death.



PROTECT YOURSELF AND OTHERS -- Some welding, cutting, and gouging processes are noisy and require ear protection. The arc, like the sun, emits ultraviolet (UV) and other radiation and can injure skin and eyes. Hot metal can cause burns. Training in the proper use of the processes and equipment is essential to prevent accidents. Therefore:

1. Always wear safety glasses with side shields in any work area, even if welding helmets, face shields, and goggles are also required.
2. Use a face shield fitted with the correct filter and cover plates to protect your eyes, face, neck, and ears from sparks and rays of the arc when operating or observing operations. Warn bystanders not to watch the arc and not to expose themselves to the rays of the electric-arc or hot metal.
3. Wear flameproof gauntlet type gloves, heavy long-sleeve shirt, cuffless trousers, high-topped shoes, and a welding helmet or cap for hair protection, to protect against arc rays and hot sparks or hot metal. A flameproof apron may also be desirable as protection against radiated heat and sparks.
4. Hot sparks or metal can lodge in rolled up sleeves, trouser cuffs, or pockets. Sleeves and collars should be kept buttoned, and open pockets eliminated from the front of clothing
5. Protect other personnel from arc rays and hot sparks with a suitable non-flammable partition or curtains.
6. Use goggles over safety glasses when chipping slag or grinding. Chipped slag may be hot and can fly far. Bystanders should also wear goggles over safety glasses.



FIRES AND EXPLOSIONS -- Heat from flames and arcs can start fires. Hot slag or sparks can also cause fires and explosions. Therefore:

1. Remove all combustible materials well away from the work area or cover the materials with a protective non-flammable covering. Combustible materials include wood, cloth, sawdust, liquid and gas fuels, solvents, paints and coatings, paper, etc.
2. Hot sparks or hot metal can fall through cracks or crevices in floors or wall openings and cause a hidden smoldering fire or fires on the floor below. Make certain that such openings are protected from hot sparks and metal."
3. Do not weld, cut or perform other hot work until the workpiece has been completely cleaned so that there are no substances on the workpiece which might produce flammable or toxic vapors. Do not do hot work on closed containers. They may explode.
4. Have fire extinguishing equipment handy for instant use, such as a garden hose, water pail, sand bucket, or portable fire extinguisher. Be sure you are trained in its use.

5. Do not use equipment beyond its ratings. For example, overloaded welding cable can overheat and create a fire hazard.
6. After completing operations, inspect the work area to make certain there are no hot sparks or hot metal which could cause a later fire. Use fire watchers when necessary.
7. For additional information, refer to NFPA Standard 51B, "Fire Prevention in Use of Cutting and Welding Processes", available from the National Fire Protection Association, Batterymarch Park, Quincy, MA 02269.



ELECTRICAL SHOCK -- Contact with live electrical parts and ground can cause severe injury or death. DO NOT use AC welding current in damp areas, if movement is confined, or if there is danger of falling.

1. Be sure the power source frame (chassis) is connected to the ground system of the input power.
2. Connect the workpiece to a good electrical ground.
3. Connect the work cable to the workpiece. A poor or missing connection can expose you or others to a fatal shock.
4. Use well-maintained equipment. Replace worn or damaged cables.
5. Keep everything dry, including clothing, work area, cables, torch/electrode holder, and power source.
6. Make sure that all parts of your body are insulated from work and from ground.
7. Do not stand directly on metal or the earth while working in tight quarters or a damp area; stand on dry boards or an insulating platform and wear rubber-soled shoes.
8. Put on dry, hole-free gloves before turning on the power.
9. Turn off the power before removing your gloves.
10. Refer to ANSI/ASC Standard Z49.1 (listed on next page) for specific grounding recommendations. Do not mistake the work lead for a ground cable.




ELECTRIC AND MAGNETIC FIELDS -- May be dangerous. Electric current flowing through any conductor causes localized Electric and Magnetic Fields (EMF). Welding and cutting current creates EMF around welding cables and welding machines. Therefore:

1. Welders having pacemakers should consult their physician before welding. EMF may interfere with some pacemakers.
2. Exposure to EMF may have other health effects which are unknown.
3. Welders should use the following procedures to minimize exposure to EMF:
 - A. Route the electrode and work cables together. Secure them with tape when possible.
 - B. Never coil the torch or work cable around your body.
 - C. Do not place your body between the torch and work cables. Route cables on the same side of your body.
 - D. Connect the work cable to the workpiece as close as possible to the area being welded.
 - E. Keep welding power source and cables as far away from your body as possible.



FUMES AND GASES -- Fumes and gases, can cause discomfort or harm, particularly in confined spaces. Do not breathe fumes and gases. Shielding gases can cause asphyxiation. Therefore:

1. Always provide adequate ventilation in the work area by natural or mechanical means. Do not weld, cut, or gouge on materials such as galvanized steel, stainless steel, copper, zinc, lead, beryllium, or cadmium unless positive mechanical ventilation is provided. Do not breathe fumes from these materials.
2. Do not operate near degreasing and spraying operations. The heat or arc rays can react with chlorinated hydrocarbon vapors to form phosgene, a highly toxic gas, and other irritant gases.
3. If you develop momentary eye, nose, or throat irritation while operating, this is an indication that ventilation is not adequate. Stop work and take necessary steps to improve ventilation in the work area. Do not continue to operate if physical discomfort persists.
4. Refer to ANSI/ASC Standard Z49.1 (see listing below) for specific ventilation recommendations.
5. **WARNING: This product, when used for welding or cutting, produces fumes or gases which contain chemicals known to the State of California to cause birth defects and, in some cases, cancer. (California Health & Safety Code §25249.5 et seq.)**



CYLINDER HANDLING -- Cylinders, if mishandled, can rupture and violently release gas. Sudden rupture of cylinder, valve, or relief device can injure or kill. Therefore:

1. Use the proper gas for the process and use the proper pressure reducing regulator designed to operate on the compressed gas cylinder. Do not use adaptors. Maintain hoses and fittings in good condition. Follow manufacturer's operating instructions for mounting regulator to a compressed gas cylinder.
2. Always secure cylinders in an upright position by chain or strap to suitable hand trucks, undercarriages, benches, walls, post, or racks. Never secure cylinders to work tables or fixtures where they may become part of an electrical circuit.
3. When not in use, keep cylinder valves closed. Have valve protection cap in place if regulator is not connected. Secure and move cylinders by using suitable hand trucks. Avoid rough handling of cylinders.
4. Locate cylinders away from heat, sparks, and flames. Never strike an arc on a cylinder.
5. For additional information, refer to CGA Standard P-1, "Precautions for Safe Handling of Compressed Gases in Cylinders", which is available from Compressed Gas Association, 1235 Jefferson Davis Highway, Arlington, VA 22202.



EQUIPMENT MAINTENANCE -- Faulty or improperly maintained equipment can cause injury or death. Therefore:

1. Always have qualified personnel perform the installation, troubleshooting, and maintenance work. Do not perform any electrical work unless you are qualified to perform such work.
2. Before performing any maintenance work inside a power source, disconnect the power source from the incoming electrical power.
3. Maintain cables, grounding wire, connections, power cord, and power supply in safe working order. Do not operate any equipment in faulty condition.
4. Do not abuse any equipment or accessories. Keep equipment away from heat sources such as furnaces, wet conditions such as water puddles, oil or grease, corrosive atmospheres and inclement weather.
5. Keep all safety devices and cabinet covers in position and in good repair.
6. Use equipment only for its intended purpose. Do not modify it in any manner.



ADDITIONAL SAFETY INFORMATION -- For more information on safe practices for electric arc welding and cutting equipment, ask your supplier for a copy of "Precautions and Safe Practices for Arc Welding, Cutting and Gouging", Form 52-529.

The following publications, which are available from the American Welding Society, 550 N.W. LeJuene Road, Miami, FL 33126, are recommended to you:

1. ANSI/ASC Z49.1 - "Safety in Welding and Cutting"
2. AWS C5.1 - "Recommended Practices for Plasma Arc Welding"
3. AWS C5.2 - "Recommended Practices for Plasma Arc Cutting"
4. AWS C5.3 - "Recommended Practices for Air Carbon Arc Gouging and Cutting"
5. AWS C5.5 - "Recommended Practices for Gas Tungsten Arc Welding"
6. AWS C5.6 - "Recommended Practices for Gas Metal Arc Welding"
7. AWS SP - "Safe Practices" - Reprint, Welding Handbook.
8. ANSI/AWS F4.1, "Recommended Safe Practices for Welding and Cutting of Containers That Have Held Hazardous Substances."



MEANING OF SYMBOLS - As used throughout this manual: Means Attention! Be Alert! Your safety is involved.



Means immediate hazards which, if not avoided, will result in immediate, serious personal injury or loss of life.



Means potential hazards which could result in personal injury or loss of life.



Means hazards which could result in minor personal injury.



ADVERTENCIA: Estas Precauciones de Seguridad son para su protección. Ellas hacen resumen de información proveniente de las referencias listadas en la sección "Información Adicional Sobre La Seguridad". Antes de hacer cualquier instalación o procedimiento de operación, asegúrese de leer y seguir las precauciones de seguridad listadas a continuación así como también todo manual, hoja de datos de seguridad del material, calcomanías, etc. El no observar las Precauciones de Seguridad puede resultar en daño a la persona o muerte.



PROTEJASE USTED Y A LOS DEMAS-- Algunos procesos de soldadura, corte y ranurado son ruidosos y requieren protección para los oídos. El arco, como el sol, emite rayos ultravioleta (UV) y otras radiaciones que pueden dañar la piel y los ojos. El metal caliente causa quemaduras. **EL entrenamiento en el uso propio de los equipos y sus procesos es esencial para prevenir accidentes. Por lo tanto:**

1. Utilice gafas de seguridad con protección a los lados siempre que esté en el área de trabajo, aún cuando esté usando careta de soldar, protector para su cara u otro tipo de protección.
2. Use una careta que tenga el filtro correcto y lente para proteger sus ojos, cara, cuello, y oídos de las chispas y rayos del arco cuando se esté operando y observando las operaciones. Alerta a todas las personas cercanas de no mirar el arco y no exponerse a los rayos del arco eléctrico o el metal fundido.
3. Use guantes de cuero a prueba de fuego, camisa pesada de mangas largas, pantalón de ruedo liso, zapato alto al tobillo, y careta de soldar con capucha para el pelo, para proteger el cuerpo de los rayos y chispas calientes provenientes del metal fundido. En ocasiones un delantal a prueba de fuego es necesario para protegerse del calor radiado y las chispas.
4. Chispas y partículas de metal caliente puede alojarse en las mangas enrolladas de la camisa, el ruedo del pantalón o los bolsillos. Mangas y cuellos deberán mantenerse abotonados, bolsillos al frente de la camisa deberán ser cerrados o eliminados.
5. Proteja a otras personas de los rayos del arco y chispas calientes con una cortina adecuada no-flamable como división.
6. Use careta protectora además de sus gafas de seguridad cuando esté removiendo escoria o puliendo. La escoria puede estar caliente y desprenderse con velocidad. Personas cercanas deberán usar gafas de seguridad y careta protectora.



FUEGO Y EXPLOSIONES -- El calor de las flamas y el arco pueden ocasionar fuegos. Escoria caliente y las chispas pueden causar fuegos y explosiones. **Por lo tanto:**

1. Remueva todo material combustible lejos del área de trabajo o cubra los materiales con una cobija a prueba de fuego. Materiales combustibles incluyen madera, ropa, líquidos y gases inflamables, solventes, pinturas, papel, etc.
2. Chispas y partículas de metal pueden introducirse en las grietas y agujeros de pisos y paredes causando fuegos escondidos en otros niveles o espacios. Asegúrese de que toda grieta y agujero esté cubierto para proteger lugares adyacentes contra fuegos.
3. No corte, suelde o haga cualquier otro trabajo relacionado hasta que la pieza de trabajo esté totalmente limpia y libre de substancias que puedan producir gases inflamables o vapores tóxicos. No trabaje dentro o fuera de contenedores o tanques cerrados. Estos pueden explotar si contienen vapores inflamables.
4. Tenga siempre a la mano equipo extintor de fuego para uso instantáneo, como por ejemplo una manguera con agua, cubeta con agua, cubeta con arena, o extintor portátil. Asegúrese que usted esta entrenado para su uso.
5. No use el equipo fuera de su rango de operación. Por ejemplo,

- el calor causado por cable sobrecarga en los cables de soldar pueden ocasionar un fuego.
6. Después de terminar la operación del equipo, inspeccione el área de trabajo para cerciorarse de que las chispas o metal caliente ocasionen un fuego más tarde. Tenga personal asignado para vigilar si es necesario.
7. Para información adicional, haga referencia a la publicación NFPA Standard 51B, "Fire Prevention in Use of Cutting and Welding Processes", disponible a través de la National Fire Protection Association, Batterymarch Park, Quincy, MA 02269.

CHOQUE ELECTRICO -- El contacto con las partes eléctricas energizadas y tierra puede causar daño severo o muerte. **NO use soldadura de corriente alterna (AC) en áreas húmedas, de movimiento confinado en lugares estrechos o si hay posibilidad de caer al suelo.**



1. Asegúrese de que el chasis de la fuente de poder esté conectado a tierra a través del sistema de electricidad primario.
2. Conecte la pieza de trabajo a un buen sistema de tierra física.
3. Conecte el cable de retorno a la pieza de trabajo. Cables y conductores expuestos o con malas conexiones pueden exponer al operador u otras personas a un choque eléctrico fatal.
4. Use el equipo solamente si está en buenas condiciones. Reemplace cables rotos, dañados o con conductores expuestos.
5. Mantenga todo seco, incluyendo su ropa, el área de trabajo, los cables, antorchas, pinza del electrodo, y la fuente de poder.
6. Asegúrese que todas las partes de su cuerpo están insuladas de ambos, la pieza de trabajo y tierra.
7. No se pare directamente sobre metal o tierra mientras trabaja en lugares estrechos o áreas húmedas; trabaje sobre un pedazo de madera seco o una plataforma insulada y use zapatos con suela de goma.
8. Use guantes secos y sin agujeros antes de energizar el equipo.
9. Apague el equipo antes de quitarse sus guantes.
10. Use como referencia la publicación ANSI/ASC Standard Z49.1 (listado en la próxima página) para recomendaciones específicas de como conectar el equipo a tierra. No confunda el cable de soldar a la pieza de trabajo con el cable a tierra.

CAMPOS ELECTRICOS Y MAGNETICOS -Son peligrosos.



La corriente eléctrica fluye a través de cualquier conductor causando a nivel local Campos Eléctricos y Magnéticos (EMF). Las corrientes en el área de corte y soldadura, crean EMF alrededor de los cables de soldar y las maquinas. Por lo tanto:

1. Soldadores u Operadores que use marca-pasos para el corazón deberán consultar a su médico antes de soldar. El Campo Electromagnético (EMF) puede interferir con algunos marca-pasos.
2. Exponerse a campos electromagnéticos (EMF) puede causar otros efectos de salud aún desconocidos.
3. Los soldadores deberán usar los siguientes procedimientos para minimizar exponerse al EMF:
 - A. Mantenga el electrodo y el cable a la pieza de trabajo juntos, hasta llegar a la pieza que usted quiere soldar. Asegúrelos uno junto al otro con cinta adhesiva cuando sea posible.
 - B. Nunca envuelva los cables de soldar alrededor de su cuerpo.
 - C. Nunca ubique su cuerpo entre la antorcha y el cable, a la pieza de trabajo. Mantenga los cables a un sólo lado de su cuerpo.
 - D. Conecte el cable de trabajo a la pieza de trabajo lo más cercano posible al área de la soldadura.
 - E. Mantenga la fuente de poder y los cables de soldar lo más lejos posible de su cuerpo.



HUMO Y GASES -- El humo y los gases, pueden causar malestar o daño, particularmente en espacios sin ventilación. No inhale el humo o gases. El gas de protección puede causar falta de oxígeno.

Por lo tanto:

1. Siempre provea ventilación adecuada en el área de trabajo por medio natural o mecánico. No solde, corte, o ranure materiales con hierro galvanizado, acero inoxidable, cobre, zinc, plomo, berilio, o cadmio a menos que provea ventilación mecánica positiva. No respire los gases producidos por estos materiales.
2. No opere cerca de lugares donde se aplique substancias químicas en aerosol. El calor de los rayos del arco pueden reaccionar con los vapores de hidrocarburo clorinado para formar un fosfógeno, o gas tóxico, y otros irritant es.
3. Si momentáneamente desarrolla irritación de ojos, nariz o garganta mientras está operando, es indicación de que la ventilación no es apropiada. Pare de trabajar y tome las medidas necesarias para mejorar la ventilación en el área de trabajo. No continúe operando si el malestar físico persiste.
4. Haga referencia a la publicación ANSI/ASC Standard Z49.1 (Vea la lista a continuación) para recomendaciones específicas en la ventilación.

5. **ADVERTENCIA-- Este producto cuando se utiliza para soldaduras o cortes, produce humos o gases, los cuales contienen químicos conocidos por el Estado de California de causar defectos en el nacimiento, o en algunos casos, Cancer. (California Health & Safety Code §25249.5 et seq.)**



MANEJO DE CILINDROS-- Los cilindros, si no son manejados correctamente, pueden romperse y liberar violentamente gases. Rotura repentina del cilindro, válvula, o válvula de escape puede causar daño o muerte. Por lo tanto:

1. Utilice el gas apropiado para el proceso y utilice un regulador diseñado para operar y reducir la presión del cilindro de gas. No utilice adaptadores. Mantenga las mangueras y las conexiones en buenas condiciones. Observe las instrucciones de operación del fabricante para montar el regulador en el cilindro de gas comprimido.
2. Asegure siempre los cilindros en posición vertical y amárrelos con una correa o cadena adecuada para asegurar el cilindro al carro, transportes, tablleros, paredes, postes, o armazón. Nunca asegure los cilindros a la mesa de trabajo o las piezas que son parte del circuito de soldadura. Este puede ser parte del circuito eléctrico.
3. Cuando el cilindro no está en uso, mantenga la válvula del cilindro cerrada. Ponga el capote de protección sobre la válvula si el regulador no está conectado. Asegure y mueva los cilindros utilizando un carro o transporte adecuado. Evite el manejo brusco de los



MANTENIMIENTO DEL EQUIPO -- Equipo defectuoso o mal mantenido puede causar daño o muerte. Por lo tanto:

1. Siempre tenga personal cualificado para efectuar la instalación, diagnóstico, y mantenimiento del equipo. No ejecute ningún trabajo eléctrico a menos que usted esté cualificado para hacer el trabajo.
2. Antes de dar mantenimiento en el interior de la fuente de poder, desconecte la fuente de poder del suministro de electricidad primaria.
3. Mantenga los cables, cable a tierra, conexiones, cable primario, y cualquier otra fuente de poder en buen estado operacional. No opere ningún equipo en malas condiciones.
4. No abuse del equipo y sus accesorios. Mantenga el equipo lejos de cosas que generen calor como hornos, también lugares húmedos como charcos de agua, aceite o grasa, atmósferas corrosivas y las inclemencias del tiempo.
5. Mantenga todos los artículos de seguridad y coverturas del equipo en su posición y en buenas condiciones.
6. Use el equipo sólo para el propósito que fue diseñado. No modifique el equipo en ninguna manera.



INFORMACION ADICIONAL DE SEGURIDAD -- Para más información sobre las prácticas de seguridad de los equipos de arco eléctrico para soldar y cortar, pregunte a su suplidor por una copia de "Precautions and Safe Practices for Arc Welding, Cutting and Gouging-Form 52-529."

Las siguientes publicaciones, disponibles através de la American Welding Society, 550 N.W. LeJuene Road, Miami, FL 33126, son recomendadas para usted:

1. ANSI/ASC Z49.1 - "Safety in Welding and Cutting"
2. AWS C5.1 - "Recommended Practices for Plasma Arc Welding"
3. AWS C5.2 - "Recommended Practices for Plasma Arc Cutting"
4. AWS C5.3 - "Recommended Practices for Air Carbon Arc Gouging and Cutting"
5. AWS C5.5 - "Recommended Practices for Gas Tungsten Arc Welding"
6. AWS C5.6 - "Recommended Practices for Gas Metal Arc Welding"
7. AWS SP - "Safe Practices" - Reprint, Welding Handbook.
8. ANSI/AWS F4.1, "Recommended Safe Practices for Welding and Cutting of Containers That Have Held Hazardous Substances."



SIGNIFICADO DE LOS SIMBOLOS -- Según usted avanza en la lectura de este folleto: Los Símbolos Significan ¡Atención! ¡Esté Alerta! Se trata de su seguridad.



PELIGRO

Significa riesgo inmediato que, de no ser evadido, puede resultar inmediatamente en serio daño personal o la muerte.



ADVERTENCIA

Significa el riesgo de un peligro potencial que puede resultar en serio daño personal o la muerte.



CUIDADO

Significa el posible riesgo que puede resultar en menores daños a la persona.

AVERTISSEMENT: Ces règles de sécurité ont pour objet d'assurer votre protection. Veuillez à lire et à observer les précautions énoncées ci-dessous avant de monter l'équipement ou de commencer à l'utiliser. Tout défaut d'observation de ces précautions risque d'entraîner des blessures graves ou mortelles.

1. PROTECTION INDIVIDUELLE-- Les brûlures de la peau et des yeux dues au rayonnement de l'arc électrique ou du métal incandescent, lors du soudage au plasma ou à l'électrode ou lors du gougeage à l'arc, peuvent s'avérer plus graves que celles résultant d'une exposition prolongée au soleil. Aussi convient-il d'observer les précautions suivantes:

a. Portez un écran facial adéquat muni des plaques protectrices et des verres filtrants appropriés afin de vous protéger les yeux, le visage, le cou et les oreilles des étincelles et du rayonnement de l'arc électrique lorsque vous effectuez des soudures ou des coupes ou lorsque vous en observez l'exécution.

AVERTISSEZ les personnes se trouvant à proximité de façon à ce qu'elles ne regardent pas l'arc et à ce qu'elles ne s'exposent pas à son rayonnement, ni à celui du métal incandescent.

b. Portez des gants ignifugés à crispins, une tunique épaisse à manches longues, des pantalons sans rebord, des chaussures à embout d'acier et un casque de soudage ou une calotte de protection, afin d'éviter d'exposer la peau au rayonnement de l'arc électrique ou du métal incandescent. Il est également souhaitable d'utiliser un tablier ininflammable de façon à se protéger des étincelles et du rayonnement thermique.

c. Les étincelles ou les projections de métal incandescent risquent de se loger dans des manches retroussées, des bords relevés de pantalons ou dans des poches. Aussi convient-il de garder boutonnés le col et les manches et de porter des vêtements sans poches à l'avant.

d. Protégez des étincelles et du rayonnement de l'arc électrique les autres personnes travaillant à proximité à l'aide d'un écran ininflammable adéquat.

e. Ne jamais omettre de porter des lunettes de sécurité lorsque vous vous trouvez dans un secteur où l'on effectue des opérations de soudage ou de coupage à l'arc. Utilisez des lunettes de sécurité à écrans ou verres latéraux pour piquer ou meuler le laitier. Les piquetures incandescentes de laitier peuvent être projetées à des distances considérables. Les personnes se trouvant à proximité doivent également porter des lunettes de protection.

f. Le gougeage à l'arc et le soudage à l'arc au plasma produisent un niveau de bruit extrêmement élevé (de 100 à 114 dB) et exigent par conséquent l'emploi de dispositifs appropriés de protection auditive.

2. PRÉVENTION DES INCENDES-- Les projections de laitier incandescent ou d'étincelles peuvent provoquer de graves incendies au contact de matériaux combustibles solides, liquides ou gazeux. Aussi faut-il observer les précautions suivantes:

a. Éloigner suffisamment tous les matériaux combustibles du secteur où l'on exécute des soudures ou des coupes à l'arc, à moins de les recouvrir complètement d'une bâche non-inflammable. Ce type de matériaux comprend notamment le bois, les vêtements, la sciure, l'essence, le kérosène, les peintures, les solvants, le gaz naturel, l'acétylène, le propane et autres substances combustibles semblables.

b. Les étincelles ou les projections de métal incandescent peuvent tomber dans des fissures du plancher ou dans des ouvertures des murs et y déclencher une ignition lente cachée. Veiller à protéger ces ouvertures des étincelles et des projections de métal.

c. N'exécutez pas de soudures, de coupes, d'opérations de gougeage ou autres travaux à chaud à la surface de barils, bidons, réservoirs ou autres contenants usagés, avant de les avoir nettoyés de toute trace de substance susceptible de produire des vapeurs inflammables ou toxiques.

d. En vue d'assurer la prévention des incendies, il convient de disposer d'un matériel d'extinction prêt à servir immédiatement, tel qu'un tuyau d'arrosage, un seau à eau, un seau de sable ou un extincteur portatif.

e. Une fois le travail à l'arc terminé, inspectez le secteur de façon à vous assurer qu'aucune étincelle ou projection de métal incandescent ne risque de provoquer ultérieurement un feu.

3. CHOC ÉLECTRIQUE-- Le gougeage à l'arc et à l'arc au plasma exige l'emploi de tensions à vide relativement importantes; or, celles-ci risquent de causer des dommages corporels graves et même mortels en cas d'utilisation inadéquate. La gravité du choc électrique reçu dépend du chemin suivi par le courant à travers le corps humain et de son intensité.

a. Ne laissez jamais de surfaces métalliques sous tension venir au contact direct de la peau ou de vêtements humides. Veillez à porter des gants bien secs.

b. Si vous devez effectuer un travail sur une surface métallique ou dans un secteur humide, veillez à assurer votre isolation corporelle en portant des gants secs et des chaussures à semelles de caoutchouc et en vous tenant sur une planche ou une plate-forme sèche.

c. Mettez toujours à la terre le poste de soudage/coupage en le reliant par un câble à une bonne prise de terre.

d. N'utilisez jamais de câbles usés ou endommagés. Ne surchargez jamais le câble. Utilisez toujours un équipement correctement entretenu.

e. Mettez l'équipement hors tension lorsqu'il n'est pas en service. une mise à la masse accidentelle peut en effet provoquer une surchauffe de l'équipement et un danger d'incendie. Ne pas enrouler ou passer le câble autour d'une partie quelconque du corps.

f. Vérifiez si le câble de masse est bien relié à la pièce en un point aussi proche que possible de la zone de travail. Le branchement des câbles de masse à l'ossature du bâtiment ou en un point éloigné de la zone de travail augmente en effet le risque de passage d'un courant de sortie par des chaînes de

AVERTISSEMENT: Ces règles de sécurité ont pour objet d'assurer votre protection. Veuillez à lire et à observer les précautions énoncées ci-dessous avant de monter l'équipement ou de commencer à l'utiliser. Tout défaut d'observation de ces précautions risque d'entraîner des blessures graves ou mortelles.

1. PROTECTION INDIVIDUELLE-- Les brûlures de la peau et des yeux dues au rayonnement de l'arc électrique ou du métal incandescent, lors du soudage au plasma ou à l'électrode ou lors du gougeage à l'arc, peuvent s'avérer plus graves que celles résultant d'une exposition prolongée au soleil. Aussi convient-il d'observer les précautions suivantes:

a. Portez un écran facial adéquat muni des plaques protectrices et des verres filtrants appropriés afin de vous protéger les yeux, le visage, le cou et les oreilles des étincelles et du rayonnement de l'arc électrique lorsque vous effectuez des soudures ou des coupes ou lorsque vous en observez l'exécution.

AVERTISSEZ les personnes se trouvant à proximité de façon à ce qu'elles ne regardent pas l'arc et à ce qu'elles ne s'exposent pas à son rayonnement, ni à celui du métal incandescent.

b. Portez des gants ignifugés à crispins, une tunique épaisse à manches longues, des pantalons sans rebord, des chaussures à embout d'acier et un casque de soudage ou une calotte de protection, afin d'éviter d'exposer la peau au rayonnement de l'arc électrique ou du métal incandescent. Il est également souhaitable d'utiliser un tablier ininflammable de façon à se protéger des étincelles et du rayonnement thermique.

c. Les étincelles ou les projections de métal incandescent risquent de se loger dans des manches retroussées, des bords relevés de pantalons ou dans des poches. Aussi convient-il de garder boutonnés le col et les manches et de porter des vêtements sans poches à l'avant.

d. Protégez des étincelles et du rayonnement de l'arc électrique les autres personnes travaillant à proximité à l'aide d'un écran ininflammable adéquat.

e. Ne jamais omettre de porter des lunettes de sécurité lorsque vous vous trouvez dans un secteur où l'on effectue des opérations de soudage ou de coupage à l'arc. Utilisez des lunettes de sécurité à écrans ou verres latéraux pour piquer ou meuler le laitier. Les piquetures incandescentes de laitier peuvent être projetées à des distances considérables. Les personnes se trouvant à proximité doivent également porter des lunettes de protection.

f. Le gougeage à l'arc et le soudage à l'arc au plasma produisent un niveau de bruit extrêmement élevé (de 100 à 114 dB) et exigent par conséquent l'emploi de dispositifs appropriés de protection auditive.

2 PRÉVENTION DES INCENDES-- Les projections de laitier incandescent ou d'étincelles peuvent provoquer de graves incendies au contact de matériaux combustibles solides, liquides ou gazeux. Aussi faut-il observer les précautions suivantes:

a. Éloigner suffisamment tous les matériaux combustibles du secteur où l'on exécute des soudures ou des coupes à l'arc, à moins de les recouvrir complètement d'une bâche non-inflammable. Ce type de matériaux comprend notamment le bois, les vêtements, la sciure, l'essence, le kérosène, les peintures, les solvants, le gaz naturel, l'acétylène, le propane et autres substances combustibles semblables.

b. Les étincelles ou les projections de métal incandescent peuvent tomber dans des fissures du plancher ou dans des ouvertures des murs et y déclencher une ignition lente cachée. Veiller à protéger ces ouvertures des étincelles et des projections de métal.

c. N'exécutez pas de soudures, de coupes, d'opérations de gougeage ou autres travaux à chaud à la surface de barils, bidons, réservoirs ou autres contenants usagés, avant de les avoir nettoyés de toute trace de substance susceptible de produire des vapeurs inflammables ou toxiques.

d. En vue d'assurer la prévention des incendies, il convient de disposer d'un matériel d'extinction prêt à servir immédiatement, tel qu'un tuyau d'arrosage, un seau à eau, un seau de sable ou un extincteur portatif.

e. Une fois le travail à l'arc terminé, inspectez le secteur de façon à vous assurer qu'aucune étincelle ou projection de métal incandescent ne risque de provoquer ultérieurement un feu.

3. CHOC ÉLECTRIQUE-- Le gougeage à l'arc et à l'arc au plasma exige l'emploi de tensions à vide relativement importantes; or, celles-ci risquent de causer des dommages corporels graves et même mortels en cas d'utilisation inadéquate. La gravité du choc électrique reçu dépend du chemin suivi par le courant à travers le corps humain et de son intensité.

a. Ne laissez jamais de surfaces métalliques sous tension venir au contact direct de la peau ou de vêtements humides. Veillez à porter des gants bien secs.

b. Si vous devez effectuer un travail sur une surface métallique ou dans un secteur humide, veillez à assurer votre isolation corporelle en portant des gants secs et des chaussures à semelles de caoutchouc et en vous tenant sur une planche ou une plate-forme sèche.

c. Mettez toujours à la terre le poste de soudage/coupage en le reliant par un câble à une bonne prise de terre.

d. N'utilisez jamais de câbles usés ou endommagés. Ne surchargez jamais le câble. Utilisez toujours un équipement correctement entretenu.

e. Mettez l'équipement hors tension lorsqu'il n'est pas en service. une mise à la masse accidentelle peut en effet provoquer une surchauffe de l'équipement et un danger d'incendie. Ne pas enrouler ou passer le câble autour d'une partie quelconque du corps.

f. Vérifiez si le câble de masse est bien relié à la pièce en un point aussi proche que possible de la zone de travail. Le branchement des câbles de masse à l'ossature du bâtiment ou en un point éloigné de la zone de travail augmente en effet le risque de passage d'un courant de sortie par des chaînes de

AristoPower 460 Power Source

- Easy-to-use advanced technology
- Customizable MA-6 man/machine communications. Upgradable using ESAT software (ESAB Software Administration Tools).
- 107 preprogrammed synergic welding programs for standard & pulsed Mig and Stick welding
- 10 memory locations for user-defined welding parameter storage
- Digital preset of voltage, amperage or wire speed on process selection.
- Robust, reliable, energy saving 450 amp/100% Duty Cycle power source
- SuperSwitch™ Technology design, provides superior inverter like performance in the welding arc while providing SCR like reliability.
- Energy and power efficient, the best in its class with a 92% efficiency figure. Saves energy and reduces power costs. Uses up to 50% less current than conventional SCR machines.
- True Multi-process, three phase power source designed for heavy duty Industrial DC welding applications.
- Use for High Performance Mig, Pulse Mig, Flux Cored wire, Stick electrode welding, and Air Carbon Arc Gouging
- Variable inductance for fine tuning of the arc characteristics when short arc welding.
- Adjustable arc force and hot start control for superior stick electrode performance.
- 100% Solid State, no mechanical contactor
- Sheet metal parts and hardware made of stainless steel. Top and side panel made of Kydex polymer for superior durability in harsh environments.
- Auto Fan feature standard in the unit for energy savings. Automatically turns the fan motor on and off.
- Convenient 115vac auxiliary power receptacle.
- Compatible with AristoDrive 4-30 and AristoDrive 4-48 wire feeders.
- NAS (Tweco) style Quick Disconnect gun-to-feeder connection is standard

3
YEAR
WARRANTY



Shown with AristoDrive 4 -30 wire feeder, GM-400 Mig welding torch, TR-29 truck kit, work cable, clamp and welding wire.

Specifications:

Rated DC Output @ 100% Duty Cycle
 50/60Hz, cv or cc 450 amps 38 vdc
 Rated DC Output @ 60% Duty Cycle
 50/60Hz, cv or cc 500 amps 39 vdc
 Welding Range 10A/12V to 500A/40V
 Open Circuit Voltage Max. 80vdc
 Primary Input Voltage and Current @ 100% DutyCycle
 230/460/575vac, 60Hz 3ph 66/33/26 amps
 Power Factor at Rated Output 89%
 Efficiency at Rated Output 92%
 Auxiliary Output Power 115vac 50/60Hz, 10 amps

Physical Dimensions:
 W x L x H 18.8"(483mm), 32.5" (819mm), 25"(622mm)
 Net Weight 322 lbs.(146 Kg)
 Shipping Weight 375 lbs. (170Kg)

Build a Custom AristoPower Welding System

AristoPower™ Power Source	AristoDrive 4™ Wire Feeder	Connection Cable	Gunmaster 400 NAS Connection	Options & Accessories
AristoPower-460 0558002668	AristoDrive 4-30 * 0558003276	6ft. (2m)	12 ft. x .035-.045 0558001656 15 ft. x .035-.045 0558001659 12 ft. x .052-1/16 0558001657 15 ft. x .052-1/16 0558001660	Complete Your Custom System by Ordering Components from the Options & Accessories List on the following page
	AristoDrive 4-48 * 0558003275	0456527880		
	AristoDrive 4-48 * 0558003275	0456527881		
	Boom System 0558003700	52ft. (16m) 0456527882		
	Balance Boom** 0558003442	82ft. (25m) 0456527883		
	Balance Boom 12ft. 0558003442	114ft. (35m) 0456527884		
	Balance Boom 16ft. 0558003365	0456527884		

* Includes MA-6 MMC

** See Boom Sales Sheets for complete information



MMA-6 MMC (Man/Machine Communications)

Easy to set weld parameters for MIG, MIG Pulse, Stick or Gouging. Choose synergic weld parameters from of 107 possibilities. Set the wire feed speed and weld!

Internal Memory stores up to 10 different weld parameter set-ups. Recall parameters with a simple push of a button. Programmable soft keys allow direct access to flexible functions, such as hot start, crater fill, 2/4 stroke trigger, wire inch, gas purge, etc.

Large display gives real time readout of voltage, current, and wire speed.

Preset inductance, gas pre & post flow, inch or metric units, auto weld schedule select, arc force, burnback and more. Update and change weld data using optional ESAT software for maximum flexibility.



Options & Accessories

AristoPower-460

TR-29 Truck 37924

This truck kit provides complete mobility of the power source. The kit consists of front casters, rear cylinder rack for two cylinders, gas cylinder bracket and chain, and pull handle.

Wire Feeder Swivel Mount Kit 36172

This kit allows the wire feeder to be placed on an insulated swivel post on top of the power source. The feeder can freely rotate, minimizing potential wire feed problems.

ESAT PC Software Package 0458847880

PC software for service, diagnostics, troubleshooting, and upgrading (PC is not included).

Aristo Control 5 Program Box 466801881

Use this option to access 5 different weld schedules saved to memory locations 1 through 5. Arc trim is remotely controlled from the box.

Aristo Control 5 Program, Bar 466515881

The option has the same function as the 5 Program Box yet is more compact and mobile.

Aristo Synergic Control Box 466801880

Provides remote control for synergic wire feed speed and voltage trim.

Aristo Synergic Control Bar 466515880

The option has the same function as the Synergic Box yet is more compact and mobile.

2.1. SAFETY

Before the AristoPower 460 power source is put into operation, the safety section at the front of this manual should be read completely. This will help avoid possible injury due to misuse or improper installation.

The definitions relating to the:



safety notations are described at the end of the Safety Section in the front of this manual — **read them and their specific text references carefully.**

2.2. DESCRIPTION

This manual has been prepared for use by an experienced operator. It provides information to familiarize the operator with the design, installation and operation of the AristoPower 460 power source. DO NOT attempt to install or operate this equipment until you have read and fully understand these instructions. The information presented here should be given careful consideration to ensure proper installation and optimum weld performance of this equipment.

Table 2-1. Rating Label for AristoPower 460

ESAB WELDING & CUTTING PRODUCTS					
		ARISTOPOWER/ MULTIPOWER 460			
		50A/ 14V - 500A/ 40V			
U-MAX		X	60%	100%	
80V		I_2	500A	450A	
		U_2	40A	38A	
INPUT		60 Hz	U_2	I_2	I_2
			230V	76A	66A
			400V	38A	33A
COOLING AF		IP 21	575V	31A	26A

954672-B 4/02

The AristoPower 460 power source is a constant current (CC) and constant voltage (CV), three-phase, secondary chopper dc design with solid state contactor and control circuitry. This is a multi-process power source designed to provide the volt-ampere characteristics desired for conventional MIG (GMAW) and flux core (FCAW) arc welding in the CV (constant voltage) mode, Mig Pulse (GMAW-P) arc or stick (SMAW) welding and air carbon arc cutting/gouging (CAC-A) in the CC (constant current) mode. Table 2-1 outlines the electrical and physical specifications.

Features

- Auto Fan - The AristoPower 460 fan will run when the power source is first powered up and will remain running for 30 seconds then shut down. The fan will start again when welding begins. The fan will remain running for 6.5 minutes after welding stops and then shut down automatically if welding has not continued.
- Stainless steel frame for environmental durability.
- Durable composite side and top panels will not corrode.
- 100% duty cycle at 450 amps output.
- Upgrade and reconfigure with ESAT (ESAB Software Administration Tool) software.

A. VOLT - AMPERE CHARACTERISTICS

The curves shown in Figure 2-1 represent the static volt-ampere characteristics for the power source. The slant of these curves is referred to as the "slope" and is generally defined as the voltage drop per 100 amperes of current use. These curves show the output voltage available at any given output current from the minimum to the maximum setting of the voltage/current control.

B. FRONT AND REAR PANEL DESCRIPTION

1. POWER ON/OFF SWITCH & LAMP

The main power switch is located on the right front panel of the power source. This switch energizes the main transformer, control circuitry and illuminates the Power "ON" lamp.




Figure 2-1 - MultiPower 460 Volt-Ampere Curves

2. FAULT/TEMPERATURE LAMP

The **FAULT/TEMP** lamp illuminates if an over temperature condition occurs within the **AristoPower 460** power source. This condition may be caused by excessive duty cycle or over-current conditions. When an over temperature condition occurs, the welding output is turned off and the unit must be allowed to cool. The machine will automatically reset when the temperature falls to a safe level.

3. CONTROL RECEPTACLE

There are two 12-pin receptacles on the front panel and two 12-pin receptacles on the rear panel. Any of the four receptacles accepts the control cable from the **AristoDrive** wire feeder and handles all the control signals needed for operation. The remaining receptacles are use for remote controls, service and trouble shooting accessories.

4. AUXILIARY 115 VAC RECEPTACLE

A 115 Vac receptacle is provided to supply power to accessories such as a water cooler, heated CO₂ regulator, or small hand tools. The receptacle is rated 115 Vac / 10 amps with a floating neutral.

5. 42VAC AND 115 VAC CIRCUIT BREAKER (CB1 & CB2)

These resettable 10 amp circuit breakers (CB1 & CB2) protect the 42 volt wire feeder/control and 115 volt auxiliary receptacle circuitry against over current.

6. COMPONENT CONNECTION RECEPTACLES

There are 2 receptacles on the front panel and 2 on the rear panel for connection of wire feeders, accessories and service monitoring equipment.

7. WELD CABLE CONNECTION LUGS

A positive and negative lug connector is provided on the front and a 600A positive "twist lock" connector is mounted on the rear panel.

2.3. OPTIONAL ACCESSORIES

A number of remote control units can be connected to the **Aristo** via the Remote Control Adaptor

A. REMOTE PROGRAM AND SYNERGIC CONTROLS

(SEE OPTIONS & ACCESSORIES PG. 11)

The remote control adaptor converts analog signals from the remote control to a digital signal, which is transmitted to the power source.




Figure 2-2. Standard Control Panel




Figure 2-3. Front View




Figure 2-4. Rear View

When the adapter is connected, the power source and wire feed unit is in remote control mode; the buttons on the MMC control (man/machine communications mounted in the wire feeder) are blocked and only adjustment of the voltage and wire feed speed trim is allowed. When a remote control unit is used, the function will be changed to the setting of current during MMA welding. Only one adapter may be connected to the welding system.

B. TR-29 TRUCK KIT (PN - 37924)

This truck kit provides complete mobility of the power source. The kit consists of front castors, rear cylinder rack and wheels, gas cylinder bracket, cylinder chain and pull handle.

C. SWIVEL MOUNT KIT (PN - 36172)

This kit allows the wire feeder to be placed on an insulated swivel post on top of the power source. The feeder can freely rotate, relieving potential wire feed problems caused by sharp bends in the gun cable while, at the same time, increasing the radius of the working area.

3.1. INSTALLATION

A. LOCATION

A proper installation site is necessary for the power source to provide dependable service. A proper installation site permits freedom of air movement through the unit while minimizing exposure to dust, dirt, moisture and corrosive vapors. A minimum of 18 inches (46 cm) is required between the side and rear panels of the power source and the nearest obstruction.

The selected site should also allow easy removal of the power source outer enclosure for maintenance. See Specifications (pg. 10) for overall dimensions of the unit.

CAUTION

Do not use filters on this unit as they would restrict the volume of intake air required for proper cooling. Output ratings on this unit are based on an unobstructed supply of cooling air drawn over its internal components. Warranty is void if any type of filtering device is used.

CAUTION

For lifting purposes and for keeping dust, moisture, and other foreign material from entering the power source, the lifting eyebolt must be fully tightened with a tool.

WARNING

ELECTRIC SHOCK CAN KILL! Before making electrical input connections to the power source, "Machinery Lockout Procedures" should be employed. If the connections are to be made from a line disconnect switch, place the switch in the off position and padlock it to prevent inadvertent tripping. If the connection is made from a fuse box, remove the corresponding fuses and padlock the box cover. If it is not possible to use padlocks, attach a red tag to the line disconnect switch (or fuse box) warning others that the circuit is being worked on.

B. RECEIVING, UNPACKING AND PLACEMENT

When requesting information concerning this equipment, it is essential that Item number, Serial number and Model number of the equipment be supplied.

1. Upon receipt, remove all packing material and carefully inspect for any damage that may have occurred during shipment. Any claims for loss or damage that may have occurred in transit must be filed by the purchaser with the carrier. A copy of the bill of lading and freight bill will be furnished by the carrier on request.
2. Remove the power source from the container. Remove all packing materials. Check the container for any loose parts.
3. Check air passages at front and rear of cabinet, making sure that packing material has not obstructed air flow through the power source.
4. Install the lifting bolt furnished with the power sources into the top of the unit.
5. After selecting an installation site, place the power source in the desired location. The unit may be lifted either by using the lifting bolt or by forklift truck. If a forklift is used for lifting the unit, be sure that the lift forks are long enough to extend completely under the base.

C. PRIMARY (INPUT) ELECTRICAL CONNECTION

This power source is a three-phase unit and must be connected to a three-phase power supply. It is recommended that the unit be operated on a dedicated circuit to prevent impairment of performance due to an overloaded circuit.

1. The primary power leads must be insulated copper conductors. Three power leads and one ground wire are required. Either rubber covered cable or conduit (flexible or solid) may be used. Table 3-1 provides recommended input conductors and line fuse sizes.
2. Remove the top cover. Identify primary power input connection block, chassis ground lug on the fan shroud frame, and primary input terminal board. Refer to Figures 3-1 thru 3-5.
3. When using the provided strain relief, refer to Figure 3-2 for proper cable strip lengths. It is important to follow the cable strip guide to ensure that if the primary input cable is ever pulled from the strain relief, the input conductors will be pulled from the Terminal Block before the ground lead is pulled from the ground lug. Once stripped, thread the input and ground conductors through the large strain-relief in the rear panel of the power source. Connect the ground wire to the terminal lug located on the fan shroud frame. Connect the primary power leads to terminals L1, L2 and L3 on the input power block. Secure the strain relief on the input cable.
4. Check all connections for proper tightness. Ensure all connections are correct and well-insulated.

Table 3-1. Recommended Sizes for Input Conductors and Line Fuses

Rated Input @ 100% Duty Cycle		Input & GND Conductor* CU/AWG	Fuse Size Amps
Volts	Amps		
220	68	No. 6	100
230	66	No. 6	100
400	37	No. 8	60
460	33	No. 8	60
575	26	No. 10	50

*Sized per National Code for 80 °C rated copper conductors @ 30 °C ambient. Not more than three conductors in raceway or cable. Local codes should be followed if they specify sizes other than those listed above.




Figure 3-1. Primary Power Leads L1,L2, L3 & Ground




Figure 3-2. Recommended Cable Strip Lengths

- Figures 3-3 thru 3-5 illustrate the input voltage terminal board and the input voltage link connections. The particular voltages from which this power source may be operated are stated on the rating plate. The voltage links were factory set for highest voltage stated on the rating plate (575VAC). If the power source is to be operated on another stated input voltage, the links must be reset for that particular input voltage. Always verify the input voltage and check the link arrangement regardless of factory setting. The voltage links are set up by reconfiguring the copper link bars to the silk-screened voltage designations for the desired voltage.




Figure 3-3. Input Terminal Board Configuration for 230/460/575 Model (factory supplied in the 575 configuration)




Figure 3-4. Input Terminal Board Configuration 230/460 Model (factory supplied in the 460 configuration)




Figure 3-5. Input Terminal Board Configuration 200/400 Model (factory supplied in the 400 configuration)

⚠ WARNING

Be sure that the branch circuit or main disconnect switch is off, or electrical input fuses are removed, before attempting any inspection or work inside the power source. Placing the power switch in the off position does not remove all power from inside the power source.

D. OUTPUT WELDING CONNECTIONS (SECONDARY)

The output connections are located on the front panel (Figure 2-3). The positive connection is located at the bottom left corner and the negative connection is located at the bottom right corner. An additional (+) twist lock connect is available on the rear panel. In most instances, the work cable is connected to the negative output terminal lug. Table 3-6 provides the recommended secondary cable output sizes.

1. CONNECTIONS FROM THE WIRE FEEDER

The wire feeder control cable connects to the 12 pin J1 receptacle on the lower front or the rear panel of the AristoPower 460. The secondary output cable connects (in most cases) between the positive output lug of the AristoPower 460 and the power connection block of the wire feeder. See the wire feeder installation instructions for other connections such as shield gas, water, remote controls, Mig guns and wire feeder operation.

2. CONNECTIONS FOR STICK AND TIG WELDING

The Tig torch and stick electrode holder connect directly to the appropriate AristoPower 460 output lugs on the lower front panel. The choice of the Positive or Negative terminal depends on the welding process and electrode type being used. In most cases the Tig torch will connect to the negative lug and work cable will connect to the positive lug. The stick electrode holder usually connects to the positive lug and the work cable to the negative lug.

Table 3-6. Output Cable Sizes (Secondary)

Welding Current	Total Length (Feet) of Cable in Weld Circuit*				
	50	100	150	200	250
100	6	4	3	2	1/0
150	4	3	1	1/0	2/0
200	3	1	1/0	2/0	3/0
250	2	1/0	2/0	3/0	4/0
300	1	2/0	3/0	4/0	4/0
400	2/0	3/0	4/0	4/0	2-2/0
500	3/0	3/0	4/0	2-2/0	2-3/0

* Total cable length includes work and electrode cables. Cable size is based on direct current, insulated copper conductors, 100-percent duty cycle and a voltage drop of 4 or less volts. The welding cable insulator must have a voltage rating that is high enough to withstand the open circuit voltage of the power source.

! WARNING

ELECTRIC SHOCK CAN KILL! Before making electrical input connections to the power source, "Machinery Lockout Procedures" should be employed. If the connections are to be made from a line disconnect switch, place the switch in the off position and padlock it to prevent inadvertent tripping. If the connection is made from a fuse box, remove the corresponding fuses and padlock the box cover. If it is not possible to use padlocks, attach a red tag to the line disconnect switch (or fuse box) warning others that the circuit is being worked on.

4.1. OPERATION

A. WIRE FEEDER COMPATIBILITY

The AristoPower 460 Pulse power source **MUST** be used with an AristoDrive wire feeder only. There are two models available. The AristoDrive 4-30 (30 mm drive rolls) and the AristoDrive 4-48HD (48 mm drive rolls).

B. MA-6 MAN/MACHINE COMMUNICATIONS

In the MIG process mode, the digital displays will read preset wire feed speed in inches per minute and preset arc volts when the PRESET button is pressed. Once welding begins, the displays will show average welding current and volts in the top and bottom display, respectively. The displays have a "HOLD" circuit that retains the welding conditions. After welding stops, the display will continue to show the last average welding current and voltage sampled for 10 seconds, then returns to "0".



Figure 4-1. Wire Feed Speed & Volts Display

C. TIG and STICK WELDING

In the TIG and STICK process mode, you must depress and "HOLD" the PRESET button while presetting the welding current in the top display. Releasing the preset button causes the display to return to zero. Once welding begins, the display will show average welding current and volts in the top and bottom display, respectively. After welding stops, the current display will again return to zero. There is no "HOLD" circuit for the display meters when using the TIG and STICK process modes.

! WARNING

The chassis must be connected to an approved electrical ground. Failure to do so may result in electrical shock, severe burns or death.

! WARNING

Check the voltage links for proper voltage on the Input Terminal board before applying primary power.

! WARNING

Before making any connections to the power source output terminals make sure that all primary input power to the machine is off.



Figure 4-2. Overall Front View

5.1. CLEANING

Periodically, remove the cover from the power source and blow accumulated dust and dirt from the air passages and interior components by using clean low pressure air. The frequency of cleaning required depends upon the environment in which the power source is used.

It is imperative that all air passages be kept as clean as possible in order to allow adequate air flow to provide proper cooling.

After cleaning with low pressure air, check for and tighten any loose hardware, including all electrical connections. Check for frayed and/or cracked insulation on all power cables and replace if necessary.

5.2 INSPECTION AND SERVICE

Keep the power source dry, free of oil and grease, and protected at all times from damage by hot metal and sparks.

5.2.1 FAN MOTOR

Keep the fan motor free of accumulated dust and lint.

5.2.2 TRANSFORMER

Other than periodically cleaning the dust and dirt from the transformer, no maintenance is required. Ensure that only clean, dry, low pressure air is used.

5.2.3 WIRE FEEDER CONTROL CIRCUITS

These circuits are protected by two 10 amp circuit breakers mounted in the front panel. If these open, the contactor and wire feeder will not operate.

5.2.4 OVER TEMPERATURE PROTECTION

If the power source reaches an abnormally high internal temperature, the thermal protection will deenergize the contactor circuit, shutting down the power source but leaving the cooling fan on. After the power source has cooled to a safe level, the thermal protection will automatically reset. While de-energized, the contactor and wire feeder cannot be operated.


6.0 TROUBLESHOOTING

If the power source is operating improperly, the following troubleshooting information may be used to locate the source of the trouble.

Check the problem against the symptoms in the following troubleshooting guide (Table 6-1.) The remedy for the problem may be quite simple. If the cause cannot be quickly located, open up the unit and perform a simple visual inspection of all the components and wiring. Check for proper terminal connections, loose or burned wiring or components, blown fuses, bulged or leaking capacitors, or any other sign of damage or discoloration.

Table 6-1 Troubleshooting Table

CONDITION		ACTION
Unit Inoperative	A. B. C. D. E.	No input power. Check main line (user's) switch fuses -- replace if needed. Poor or improper input (terminal board) connections. Defective on/off switch on rear panel -- replace. Thermal light on. Main transformer overheating. Also check for proper cooling, proper primary hookup, or shorted turn on secondary. Loss of primary phase. Find & replace defective fuse.
No Output -- Fan Running	A. B. C. D.	Poor or improper electrical input -- check input connections on TB. Poor connections at output terminals/work station -- check, tighten or replace. Main transformer overheating -- thermal switches tripped due to restricted cooling air. Temperature light on front panel will be lit. Let unit cool down. PC board defective or loose PC board connector(s) -- if loose, reinsert; if defective, replace.
Limited Output or Low Open-Circuit Voltage	A. B. C.	Input voltage jumper links on terminal board improperly set -- check for proper voltage. Poor output connections. Take apart, clean, and reassemble. Panel-Remote switch in Remote position and remote voltage pot disabled.
Erratic Weld Current	A. B. C. D.	Welding cable size too small -- use correct cables. Loose welding cable connection (will usually get hot) -- tighten all connections. Improper wire feeder setup. PC board defective -- replace.
High Output, No Voltage Control	A. B.	PC board defective or loose -- reset and/or replace board. Shorted I.G.B.T. - Replace I.G.B.T. and check driver PCB.
No 115 Volt ac Output	A.	Circuit breaker tripped. Check 115V CB2 -- Reset.
Line Fuse Blows When Power Source is First Turned On	A. B.	Shorted SCR in Main Bridge -- replace. Shorted capacitor in Capacitor Bank.
Wire Feeder is Inoperative	A. B.	Loose feeder control cable -- Check and tighten all connections. A Circuit Breaker tripped -- Check 42V CB1 -- Reset.



Schematic Diagram -AristoPower 460 - 230/460/575V
CONTINUED


0558003406-A

MAIN CONTROL BOARD


DETAIL "A"

PCB1											
F	H	C	L	G	S	W	X	Y	B		
1	SSR1-4 ORN	1	TS3-2 WHT	1	PCB1-C2 WHT	1	SH1-1 RED	1	PCB2-C1 BRN	1	PCB1-B21 BLK
2	SSR1-3 RED	2	FAULT(+)	2	PCB1-G1 WHT	2	SH1-2 BLK	2	OTB(-)	2	PCB1-X3 BLK
3	POWER(2) YEL	3	FAULT(-)	3	PCB3-P1-6 RED	3	SH1-3 WHT	3	PCB2-C2 ORN	3	PCB1-Y2 BLK
4	POWER(1) VIO	4	TS1-1 YEL	4	PCB5-P1-5 BLK	4	SH1-4 GRN	4		4	
5		5		5		5	OTB(+)	5		5	
6	6	6	6	6	6	6	6	6	6	6	6
7	7	7	7	7	7	7	7	7	7	7	7
8	8	8	8	8	8	8	8	8	8	8	8
9	9	9	9	9	9	9	9	9	9	9	9
10	10	10	10	10	10	10	10	10	10	10	10


PCB1 CAN (TYPICAL) (A)
(REAR VIEW OF 9 PIN CAN CONNECTOR)



FRONT PANEL REAR



RIGHT SIDE VIEW



DETAIL "C"


PCB3	
1	TB2-3 GRY
2	TB2-4 BLU
3	PCB1-G4 BLK
4	PCB1-G8 BLK
5	PCB1-G3 RED
6	

TB2	1	2	3	4	5	6	7	8	9	10	11	12	
T1-AX5 *	PCB1-H7 BRN	T1-AX6 *	PCB1-H6 WHT	T1-BX5 *	PCB3 P1-1 GRN	T1-BX6 *	PCB3 P1-3 BLU	T1-CX4 *	PCB1-H2 RED	T1-CX6 *	PCB1-H1 ORN	T1-CX5 *	PCB2-E1 YEL
T1-AX7 *	PCB2-E1 YEL	T1-AX8 *	PCB2-E2 YEL	T1-AX9 *	PCB4-E2 YEL	T1-AX10 *	CB1-1 VIO	T1-AX11 *	REC-3 WHT				

REFERENCE DRAWINGS:
SCHEMATIC: 0558003405
WIRE KIT: 0558003404
CABLE/HOSE KIT: 0558003696

DETAIL "B"

PCB2 & PCB4			
E	C	D	
1	TB2-8 YEL	1	PCB1-CAN6 WHT
2	TB2-9 YEL	2	PCB1-CAN5 RED
3	CB1-1 VIO	3	PCB1-CAN2 BLK
4	CB1-1 VIO	4	PCB1-CAN7 ORN
5		5	
6		6	



Wiring Diagram -AristoPower 460 - 230/460/575V

7.1 REPLACEMENT PARTS

Replacement Parts are illustrated on the following figures. When ordering replacement parts, order by part number and part name, as illustrated on the figure. Always provide the series or serial number of the unit on which the parts will be used. The serial number is stamped on the unit nameplate.

7.2 ORDERING

To assure proper operation, it is recommended that only genuine ESAB parts and products be used with this equipment. The use of non-ESAB parts may void your warranty.


Replacement parts may be ordered from your ESAB distributor or from:

**ESAB Welding & Cutting Products
Attn: Customer Service Dept.
P.O. Box 100545, 411 S. Ebenezer Road
Florence, SC 29501-0545**


Be sure to indicate any special shipping instructions when ordering replacement parts.

To order parts by phone, contact ESAB at 1-843-664-5540. Orders may also be faxed to 1-800-634-7548. Be sure to indicate any special shipping instructions when ordering replacement parts.


Refer to the Communication Guide located on the last page of this manual for a list of customer service phone numbers.




NO.	QTY. REQ.	ITEM NO.	DESCRIPTION	CIRCUIT SYMBOL
		0558002668	AristoPower Power 460cvcc	
1	2	678025	Terminal Assembly	
2	1	952219	Outlet 110V (Square)	
3	2	950122	Ckt Breaker 10A 32VDC/250VAC	CB1, 2
4	1	672786	Bolt Eye .75—10 X 2.00SL STL GR	
5	1	0486958884	Control PC	PCB1
6	1	456 680 880	Termination Resistor Plug (not Shown)	




NO.	QTY. REQ.	ITEM NO.	DESCRIPTION	CIRCUIT SYMBOL
		0558002668	AristoPower Power 460cvcc	
1	2	678025	Terminal Assembly	
2	1	91514	Label Warning Arc Welding & Cutting	
3	1	954008	Danger High Voltage	
4	1	9512240	Label Caution Lifting Eye	
5	1	0558002969	Panel Right Side	
6	1	950945	SW Pwr Disc 100A 600V	S1
7	2	678025	Terminal Assembly	




NO.	QTY. REQ.	ITEM NO.	DESCRIPTION	CIRCUIT SYMBOL
		0558002668	AristoPower Power 460cvcc	
1	1	1312733	Label for Install Use COP Wire	
2	1	950219	Relief Strain 2" (Non-enclosed)	
3	1	0558001371	Panel Top Kydex Env	
4	1	0558001370	Panel Left Side Kydex Env	



NO.	QTY. REQ.	ITEM NO.	DESCRIPTION	SYMBOL
		0558002668	AristoPower Power 460cvcc	
1	3	9511916	Diode Fwd 200V 250A	
2	3	9511915	Diode Rev 200V 250A	
3	1	954864	Label 3 Phase	
4	1	2062334	Fan Motor 1/3 HP 1625 RPM	
5	1	954699	Label Warning Fan Hazard	
6	1	36173	Blade Fan 14" 5(or)6 Fin	
7	1	33939	Inductor 7 Turn	L2



NO.	QTY. REQ.	ITEM NO.	DESCRIPTION	SYMBOL
		0558002668	AristoPower Power 460cvcc	
1	2	17280110	Res WW Fix'd ST 100W 5% 100.00	R3, R4
2	1	0558002712	Transformer 230/460/575V	T1
3	12	672065	Strap Terminal	
4	20	36110	Board Input Terminal 230/460/575V	



NO.	QTY. REQ.	ITEM NO.	DESCRIPTION	SYMBOL
		0558002668	AristoPower Power 460cvcc	
1	1	952938	SCR 480V 18A Panel MNT	SH1 TS6 Q1, 2, 3 C4
2	1	951997	Transducer Current	
3	1	951085	SW THML D/T 176 15A 120V Q/D	
4	3	0558003077	IGBT 600V/300A	
5	1	951940	Capacitor 1.0uf 600VDC 10%	

Revision History

The "A" revision updates the replacement parts section and editorial changes throughout this manual. Replacement Parts listings and diagrams have also been updated. See dneco# 023350.

The "B" revision changes the Control PC item number from 0486846884 to 0486958884 per CN #043009.

