


WESLO® CADENCE 391

Model No. WCTL39102

Serial No. _____




USER'S MANUAL

QUESTIONS?

As a manufacturer, we are committed to providing complete customer satisfaction. If you have questions, or if there are missing parts, please call:

1-888-936-4266

Mon.–Fri. 8h00 until 18h30 EST
(excluding holidays).



⚠ CAUTION

Read all precautions and instructions in this manual before using this equipment. Save this manual for future reference.



Visit our website at

www.weslo.com

TABLE OF CONTENTS

IMPORTANT PRECAUTIONS	2
BEFORE YOU BEGIN	4
ASSEMBLY	5
PROPER EXERCISE FORM	6
OPERATION AND ADJUSTMENT	7
TROUBLESHOOTING AND STORAGE	10
CONDITIONING GUIDELINES	12
PART LIST	13
EXPLODED DRAWING	14
ORDERING REPLACEMENT PARTS	15
LIMITED WARRANTY	Back Cover

IMPORTANT PRECAUTIONS

⚠ WARNING: To reduce the risk of burns, fire, electric shock or injury to persons, read the following important precautions and information before operating the treadmill.

1. It is the responsibility of the owner to ensure that all users of this treadmill are adequately informed of all warnings and precautions.
2. Use the treadmill only as described in this manual.
3. Place the treadmill on a level surface, with at least 2.4 m (8 ft.) of clearance behind it and 0.5 m (2 ft.) on each side. Do not place the treadmill on any surface that blocks air openings. To protect the floor or carpet from damage, place a mat under the treadmill.
4. Keep the treadmill indoors, away from moisture and dust. Do not put the treadmill in a garage or covered patio, or near water.
5. Do not operate the treadmill where aerosol products are used or where oxygen is being administered.
6. Keep children under the age of 12 and pets away from the treadmill at all times.
7. The treadmill should be used only by persons weighing 115 kg (250 lbs.) or less.
8. Never allow more than one person on the treadmill at a time.
9. When connecting the power cord (see page 7), plug the power cord into a surge suppressor (not included) and plug the surge suppressor into a grounded circuit capable of carrying 15 or more amps. No other appliance should be on the same circuit. Do not use an extension cord.
10. Use only a CUL-listed surge suppressor of 450 joules minimum surge dissipation with voltage rating of 400 volts or less, rated at 15 amps, with a 1 mm² (14-gauge) cord of 1.5 m (5 ft.) or less in length. Do not use an extension cord.
11. Failure to use a properly functioning surge suppressor could result in damage to the control system of the treadmill. If the control system is damaged, the walking belt may change speed or stop unexpectedly, which may result in a fall and serious injury.
12. Keep the power cord and the surge suppressor away from heated surfaces.

12. Never move the walking belt while the power is turned off. Do not operate the treadmill if the power cord or plug is damaged, or if the treadmill is not working properly. (See **BEFORE YOU BEGIN** on page 4 if the treadmill is not working properly.)
13. The roller guards must be 32mm (1/8 in.) from the rear roller. Remove the key and adjust the roller guards, if necessary.
14. Wear appropriate exercise attire when using the treadmill. Do not wear loose clothing that could become caught in the treadmill. Athletic support clothes are recommended for both men and women. *Always wear athletic shoes. Never use the treadmill with bare feet, wearing only stockings, or in sandals.*
15. Never start the treadmill while you are standing on the walking belt.
16. Always hold the handrails while exercising on the treadmill.
17. Adjust the speed in small increments.
18. To reduce the possibility of the treadmill overheating, do not operate the treadmill continuously for longer than 1 hour.
19. Never leave the treadmill unattended while it is running. Always remove the key when the treadmill is not in use.
20. The pulse sensor is not a medical device. Various factors, including the user's movement, may affect the accuracy of heart rate readings. The pulse sensor is intended only as an exercise aid in determining heart rate trends in general.
21. Inspect and tighten all parts of the treadmill every three months.
22. To change the incline level of the treadmill, refer to the instructions on page 9. Do not attempt to change the incline level in any other way.
23. Never drop or insert any object into any opening.
24. Always unplug the power cord before performing the maintenance and adjustment procedures described in this manual. Never remove the motor hood unless instructed to do so by an authorized service representative. Servicing other than the procedures in this manual should be performed by an authorized service representative only.
25. This treadmill is intended for in-home use only. Do not use this treadmill in any commercial, rental, or institutional setting.

⚠ WARNING: Before beginning this or any exercise program, consult your physician. This is especially important for persons over the age of 35 or persons with pre-existing health problems. Read all instructions before using. ICON assumes no responsibility for personal injury or property damage sustained by or through the use of this product.

SAVE THESE INSTRUCTIONS


BEFORE YOU BEGIN

Thank you for selecting the WESLO CADENCE® 391 treadmill. The natural motion and versatility of treadmills have made them the most popular way to get an effective cardiovascular workout. The CADENCE 391 treadmill blends advanced technology with innovative design to let you enjoy this effective exercise in the convenience and privacy of your home. Feel better, look better, and be healthier in just a few minutes a day.

For your benefit, read this manual carefully before using the treadmill. If you have additional questions,


please call our Customer Service Department toll-free at **1-888-936-4266**, Monday through Friday 8h00 until 18h30 eastern time (excluding holidays). To help us assist you, please note the product model number and serial number before calling. The model number is WCTL39102. The serial number can be found on a decal attached to the treadmill (see the front cover of this manual for the location).

Before reading further, please review the drawing below and familiarize yourself with the parts that are labeled.




ASSEMBLY


Set the treadmill in a cleared area and remove all packing materials. Do not dispose of the packing materials until assembly is completed. Refer to the drawings below to identify small parts used in assembly. **Assembly requires an adjustable wrench (not included).**



1. Raise the Upright (11) to the vertical position. Insert the 3/8" x 1" Bolt (18) and the 3/8" x 1 1/2" Washer (28) into the lower end of the Upright. Finger tighten the Bolt into the Frame (59).




2. Hold the upper end of the Right Handrail (10) under the Console (3). Insert a 3/8" x 1 3/4" Bolt (2) up into the Handrail, and finger tighten the Bolt into the plate under the Console.



Attach the Left Handrail (1) in the same manner.


3. Insert a 3/8" x 2 3/4" Bolt (49) into the lower end of the Right Handrail (10) and through the Frame (59). Reach under the Frame and tighten a 3/8" Flange Nut (48) onto the Bolt.



Attach the Left Handrail (not shown) in the same manner.


Tighten all Bolts used in steps 1 and 2.

4. Remove the paper backing from the Adhesive Clip (64). Press the Adhesive Clip onto the Right Endcap (63) in the indicated location. Press the Allen Wrench (65) into the Adhesive Clip.



5. **The Console (3) requires two "AA" batteries (not included). Alkaline batteries are recommended.**

Slide the Battery Cover (15) up as shown. Press two batteries into the battery compartment, with the negative (-) ends of the batteries touching the springs. Close the battery cover.




6. Make sure that all parts are tightened before you use the treadmill. **Note: To protect the floor or carpet from damage, place a mat beneath the treadmill.**

PROPER EXERCISE FORM

The instructions on pages 7 to 9 of this manual explain the operation and adjustment of the treadmill. For maximum treadmill performance, it is important to maintain proper form when walking on the treadmill. The drawing below demonstrates the proper form. Be sure to remember the following important guidelines:

- **Always hold the handrails when stepping on and off the treadmill, and when exercising on the treadmill.**
- **Always stand on the foot rails when turning on the power or starting the walking belt.** The walking belt may not start while you are standing on it.
- **While walking on the treadmill, rest your hands on the handrail, keep your back straight, and lean forward slightly.** Do not lean back or push forward against the walking belt with your feet. If you slow the walking belt with your feet, it may come to a stop. If this happens, stand on the foot rails until the walking begins to move again.
- **To change the incline level of the treadmill, refer to page 9. Do not attempt to change the incline level any other way.** The incline range of the treadmill is 11% to 14%. This range is ideal for maximum treadmill performance.



OPERATION AND ADJUSTMENT

THE PERFORMANT LUBE™ WALKING BELT

Your treadmill features a walking belt coated with PERFORMANT LUBE™, a high-performance lubricant. **IMPORTANT: Never apply silicone spray or other substances to the walking belt or the walking platform. Such substances will deteriorate the walking belt and cause excessive wear.**

HOW TO PLUG IN THE POWER CORD

⚠ DANGER: Improper connection of the equipment-grounding conductor can result in an increased risk of electric shock. Check with a qualified electrician or serviceman if you are in doubt as to whether the product is properly grounded. Do not modify the plug provided with the product—if it will not fit the outlet, have a proper outlet installed by a qualified electrician.


Your treadmill, like any other type of sophisticated electronic equipment, can be seriously damaged by sudden voltage changes in your home's power. Voltage surges, spikes, and noise interference can result from weather conditions or from other appliances being turned on or off. **To decrease the possibility of your treadmill being damaged, always use a surge suppressor with your treadmill (see drawing 1 at the right).**

Use only a single-outlet surge suppressor that is CUL 1449 listed as a transient voltage surge suppressor (TVSS). The surge suppressor must have a UL suppressed voltage rating of 400 volts or less and a minimum surge dissipation of 450 joules. The surge suppressor must be electrically rated for 120 volts AC and 15 amps. There must be a monitoring light on the surge suppressor to indicate whether it is functioning properly. Failure to use a properly functioning surge suppressor could result in damage to the control system of the treadmill. If the control system is damaged, the walking belt may change speed or stop unexpectedly, which may result in a fall and serious injury.

This product must be grounded. If it should malfunction or break down, grounding provides a path of least resistance for electric current to reduce the risk of electric shock. This product is equipped with a cord having an equipment-grounding conductor and a grounding

plug. **Plug the power cord into a surge suppressor, and plug the surge suppressor into an appropriate outlet that is properly installed and grounded in accordance with all local codes and ordinances. Important: The treadmill is not compatible with GFCI-equipped outlets.**


This product is for use on a nominal 120-volt circuit, and has a grounding plug that looks like the plug illustrated in drawing 1 below. A temporary adapter that looks like the adapter illustrated in drawing 2 may be used to connect the surge suppressor to a 2-pole receptacle as shown in drawing 2 if a properly grounded outlet is not available.



The temporary adapter should be used only until a properly grounded outlet (drawing 1) can be installed by a qualified electrician.

The green-colored rigid ear, lug, or the like extending from the adapter must be connected to a permanent ground such as a properly grounded outlet box cover. Whenever the adapter is used it must be held in place by a metal screw. **Some 2-pole receptacle outlet box covers are not grounded. Contact a qualified electrician to determine if the outlet box cover is grounded before using an adapter.**

DIAGRAM OF THE CONSOLE



Note: If there is a thin sheet of clear plastic on the console, remove it.

CAUTION: Before operating the console, read the following important precautions.


- Do not stand on the walking belt when turning on the power.
- Always wear the clip while operating the treadmill. When the key is removed from the console, the power will shut off.
- After the speed control is moved, there will be a pause before the walking belt begins to move.
- Adjust the speed in small increments until you are familiar with the treadmill.
- To reduce the risk of electric shock, keep the console dry. Avoid spilling liquid on the console and use only a sealed water bottle.

STEP BY STEP CONSOLE OPERATION

Make sure that the power cord is properly plugged in (see HOW TO PLUG IN THE POWER CORD on page 7). Next, step onto the foot rails of the treadmill. Find the clip attached to the key (see the drawing above). Slide the clip onto your waistband. Follow the steps on pages 8 and 9 to operate the console.


1 Insert the key fully into the power switch.

Note: The two displays will not appear when the key is first inserted.




2 Press the On/Reset button.

The two displays will appear. Note: If batteries were just installed, the displays will already appear.



3 Reset the speed control and start the walking belt.

Slide the speed control fully to the left, to the "RESET" position. Next, slide the control to the right until the walking belt begins to move at a slow speed.




Carefully step onto the walking belt and begin walking. Change the speed of the walking belt as desired by sliding the speed control. Note: To stop the walking belt, slide the speed control to the "RESET" position.

4 Monitor your progress with the two displays.

Time/Distance display—The left display shows the elapsed time and the distance that you have walked or run. Every few seconds, the display will change from one number to the other.




Cals/Fat Cals/Speed/Pulse display—The right display shows the approximate number of *calories* and *fat calories* you have burned (see FAT BURNING on page 12) and the speed of the walking belt. Every few seconds, the display will change from one number to the next. The left mode bar will appear when the number of calories is shown; the right mode bar will appear when the number of fat calories is shown. This display will also show your heart rate when the pulse sensor is used.



To reset the displays, press the On/Reset button.

5 Measure your pulse, if desired.

To use the pulse sensor, stand on the foot rails and place your thumb on the pulse sensor as shown. The pulse sensor is pressure-activated. Fully press



down the pulse sensor. **Do not press too hard, or the circulation in your thumb will be restricted, and your pulse will not be detected.** Next, slightly raise your thumb until the heart-shaped indicator in the Cals/Fat Cals/Speed/Pulse display flashes **steadily**. Hold your thumb at this level. After 5 to 10 seconds,

your pulse will be displayed. Hold your thumb on the sensor for another 15 seconds for the most accurate reading. If the displayed pulse appears to be too high or too low, or if your pulse is not displayed, lift your thumb off the sensor and allow the display to reset. Press down again on the sensor as described above. Make sure that your thumb is positioned as shown, and that you are applying the proper amount of pressure. Try the sensor several times until you become familiar with it. Always stand still while measuring your pulse.


6 When you are finished exercising, stop the walking belt and remove the key.

Step onto the foot rails, slide the speed control to the RESET position, and remove the key from the console. The displays will turn off a few minutes after the key is removed. **Note: Any time that the walking belt is stopped for a few minutes, the displays will automatically turn off to conserve the batteries.**

HOW TO CHANGE THE INCLINE OF THE TREADMILL

To vary the intensity of your exercise, the incline of the treadmill can be changed. There are three different incline levels. **Before changing the incline, remove the key and unplug the power cord.**

To change the incline, carefully lay the treadmill on its left side. Remove the incline pin from the right incline leg as shown in drawing 1. Adjust the incline leg to the desired height and fully re-insert the incline pin. Make sure the incline pin is in the "locked" position shown in drawing 2. Lay the treadmill on its right side. Repeat the procedure for the left incline leg.




CAUTION: Before using the treadmill, make sure that both incline pins are fully inserted at the same height. Do not use the treadmill with the incline pins removed.

TROUBLESHOOTING AND STORAGE

Most treadmill problems can be solved by following the simple steps below. Find the symptom that applies to your treadmill and follow the steps listed. If further assistance is needed, please call our Customer Service Department toll-free at 1-888-936-4266, Monday through Friday, 8h00 until 18h30 eastern time (excluding holidays).

1. SYMPTOM: THE POWER DOES NOT TURN ON

- Make sure that the power cord is plugged into a surge suppressor, and that the surge suppressor is plugged into a properly grounded outlet (see page 7). Use only a CUL-listed surge suppressor, rated at 15 amps, with a 1 mm² (14-gauge) cord of 1.5 m (5 ft.) or less in length.
- After the power cord has been plugged in, make sure that the key is fully inserted into the console (see step 1 on page 8).
- Check the circuit breaker located on the treadmill frame near the power cord. If the switch protrudes as shown, the circuit breaker has tripped. To reset the circuit breaker, wait for five minutes and then press the switch back in.




2. SYMPTOM: THE POWER TURNS OFF DURING USE

- Check the circuit breaker located on the treadmill frame near the power cord. If the circuit breaker has tripped, the switch will protrude (see the drawing above). To reset the circuit breaker, wait for five minutes and then press the switch back in.
- Make sure that the power cord is plugged in.
- Remove the key from the console. Reinsert the key fully into the console (see step 1 on page 8).

3. SYMPTOM: THE DISPLAYS OF THE CONSOLE DO NOT FUNCTION PROPERLY

- Check the batteries in the console (see assembly step 5 on page 6). Most problems are the result of drained batteries.
- If the speed display does not show a correct reading, remove the key and **UNPLUG THE POWER CORD**. Remove the four screws from the sides and front of the hood. Carefully remove the hood. Locate the Reed Switch (73) and the Magnet (75) on the left side of the Pulley (43). Turn the Pulley until the Magnet is aligned with the Reed Switch. **Make sure that the gap between the Magnet and the Reed Switch is about 3 mm (1/8 in.)**. If necessary, loosen the Screw (53) and move the Reed Switch slightly. Retighten the Screw. Re-attach the hood and run the treadmill for a few minutes to check for a correct speed reading.




4. SYMPTOM: THE WALKING BELT SLOWS OR STOPS WHEN WALKED ON


- Use only a single-outlet surge suppressor that meets all of the specifications described on page 7.
- Increase the incline of the treadmill (see HOW TO CHANGE THE INCLINE OF THE TREADMILL on page 9).
- Make sure that you are using proper form when walking on the treadmill (see PROPER EXERCISE FORM on page 6).
- If the walking belt still slows when walked on, please call our Customer Service Department.

5. SYMPTOM: THE WALKING BELT IS OFF-CENTER

a. If the walking belt has shifted to the left, first remove the key and **UNPLUG THE POWER CORD**. Using the allen wrench, turn the rear roller adjustment bolt clockwise 1/4 of a turn. Plug in the power cord, insert the key and run the treadmill for a few minutes. Repeat until the walking belt is centered.




b. If the walking belt has shifted to the right, first remove the key and **UNPLUG THE POWER CORD**. Using the allen wrench, turn the rear roller adjustment bolt counterclockwise 1/4 of a turn. Plug in the power cord, insert the key and run the treadmill for a few minutes. Repeat until the walking belt is centered.




STORAGE

Unplug the power cord when the treadmill is not in use.

Remove the bolt and nut from the lower end of each handrail.




Remove the bolt from the upper end of each handrail.



Remove the bolt and washer from the lower end of the upright. Lay the upright on the treadmill. **Keep all bolts and washers in a secure location.**

Remove the batteries from the console and cover the treadmill during extended periods of storage.



CONDITIONING GUIDELINES

⚠️ WARNING: Before beginning this or any exercise program, consult your physician. This is especially important for individuals over the age of 35 or individuals with pre-existing health problems.

The pulse sensor is not a medical device. Various factors, including your movement, may affect the accuracy of heart rate readings. The sensor is intended only as an exercise aid in determining heart rate trends in general.

The following guidelines will help you to plan your exercise program. For more detailed exercise information, obtain a reputable book or consult your physician.

EXERCISE INTENSITY

Whether your goal is to burn fat or to strengthen your cardiovascular system, the key to achieving the desired results is to exercise with the proper intensity. The proper intensity level can be found by using your heart rate as a guide. The chart below shows recommended heart rates for fat burning and aerobic exercise.

AEROBIC	165	155	145	140	130	125	115
MAX FAT BURN	145	138	130	125	118	110	103
FAT BURN	125	120	115	110	105	95	90
Age	20	30	40	50	60	70	80

To find the proper heart rate for you, first find your age near the bottom of the chart (ages are rounded off to the nearest ten years). Next, find the three numbers above your age. The three numbers define your “training zone.” The lower two numbers are recommended heart rates for fat burning; the higher number is the recommended heart rate for aerobic exercise.

Fat Burning

To burn fat effectively, you must exercise at a relatively low intensity level for a sustained period of time. During the first few minutes of exercise, your body uses easily accessible *carbohydrate calories* for energy. Only after the first few minutes does your body

begin to use stored *fat calories* for energy. If your goal is to burn fat, adjust the speed and incline of the treadmill until your heart rate is near the lowest number in your training zone.

For maximum fat burning, adjust the speed and incline of the treadmill until your heart rate is near the middle number in your training zone.

Aerobic Exercise

If your goal is to strengthen your cardiovascular system, your exercise must be “aerobic.” Aerobic exercise is activity that requires large amounts of oxygen for prolonged periods of time. This increases the demand on the heart to pump blood to the muscles, and on the lungs to oxygenate the blood. For aerobic exercise, adjust the speed and incline of the treadmill until your heart rate is near the highest number in your training zone.

WORKOUT GUIDELINES

Each workout should include the following three parts:

A Warm-up—Start each workout with 5 to 10 minutes of stretching and light exercise. A proper warm-up increases your body temperature, heart rate and circulation in preparation for exercise.

Training Zone Exercise—After warming up, increase the intensity of your exercise until your pulse is in your training zone for 20 to 60 minutes. (During the first few weeks of your exercise program, do not keep your pulse in your training zone for longer than 20 minutes.) Breathe regularly and deeply as you exercise—never hold your breath.

A Cool-down—Finish each workout with 5 to 10 minutes of stretching to cool down. This will increase the flexibility of your muscles and will help prevent post-exercise problems.

EXERCISE FREQUENCY

To maintain or improve your condition, complete three workouts each week, with at least one day of rest between workouts. After a few months, you may complete up to five workouts each week if desired.

The key to success is to make exercise a regular and enjoyable part of your everyday life.

PART LIST—Model No. WCTL39102

R1003A

Key No.	Qty.	Description	45 Key No.	1 Qty.	Walking Belt Description
1	1	Left Handrail			
2	2	3/8" x 1 3/4" Bolt	46	2	Foot Rail
3*	1	Console	47	1	Pulley/Flywheel
4	1	Upright Wire Harness	48	2	3/8" Flange Nut
5	2	Console Cage Nut	49	2	3/8" x 2 3/4" Bolt
6	5	Console Screw	50	1	Controller
7	1	Pot Wire	51	1	Controller Plate
8	1	Console Cable Loom	52	4	Plastic Stand-Off
9	1	Key/Clip	53	5	Electric Screw
10	1	Right Handrail	54	4	4" Cable Tie
11	1	Upright	55	2	8" Cable Tie
12	1	Motor Swivel Bolt	56	1	Tie Holder
13	1	Upright Cage Nut	57	1	Potentiometer
14	1	Motor Swivel Nut	58	1	Speed Control
15	1	Battery Cover	59	1	Frame
16	1	Motor	60	2	Rubber Pad
17*	1	Motor/Pulley/Flywheel	61	1	Tension Spring
18	2	3/8" x 1" Bolt	62	1	Roller Ground Wire
19	1	Motor Tension Washer	63	1	Right Endcap
20	1	Star Washer	64	1	Adhesive Clip
21	1	Motor Tension Nut	65	1	Allen Wrench
22	4	Wire Clip	66	1	Short Roller Adjustment Bolt
23	4	Hood Anchor	67	1	Left Endcap
24	6	Anchor Screw	68	1	Rear Roller
25	1	Upright Pivot Nut	69	6	Platform Screw
26	2	Upright Pivot Washer	70	4	Hood Screw
27	1	Upright Cable Loom	71	1	Hood
28	1	3/8" x 1 1/2" Washer	72	2	Roller Guard Screw
29	1	Reed Switch Clip	73	1	Reed Switch/Sensor Wire
30	1	Power Cord	74	1	Roller Tension Nut
31	1	Circuit Breaker	75	1	Magnet
32	1	Upright Pivot Bolt	76	1	Motor Belt
33	1	Grommet	77	9	#8 Flat Washer
34	2	Frame Endcap	78	1	Long Roller Adjustment Bolt
35	9	Screw	79	2	Roller Guard
36	2	Incline Pin	80	2	Handgrip
37	2	Incline Leg Cap	81	2	3/8" Cap Washer
38	2	Incline Leg	82	4	Belt Guide Screw
39	2	Belt Guide	#	1	8" Green Ground Wire
40	1	Front Roller Adjustment Bolt	#	1	8" White Wire, Male/Female
41	4	Adjustment Washer	#	1	User's Manual
42	1	Safety Cover			
43	1	Front Roller/Pulley			
44	1	Walking Platform			


* Includes all the parts in the box.

Indicates a non-illustrated part.

Specifications are subject to change without notice. See the back cover for information about ordering replacement parts.

EXPLODED DRAWING—Model No. WCTL39102

R1003A



ORDERING REPLACEMENT PARTS

To order replacement parts, call our Customer Service Department toll-free at **1-888-936-4266**, Monday through Friday 8h00 until 18h30 Eastern Time (excluding holidays). When ordering parts, please be prepared to give the following information:

- The **MODEL NUMBER** of the product (WCTL39102)
- The **NAME** of the product (WESLO CADENCE® 391 treadmill)
- The **SERIAL NUMBER** of the product (see the front cover of this manual)
- The **KEY NUMBER** and the **DESCRIPTION** of the part(s) (see page 13 of this manual).



ICON of Canada, Inc.
900 de l'Industrie
St-Jérôme, Québec
Canada, J7Y 4B8

LIMITED WARRANTY

ICON OF CANADA, INC., (ICON), warrants this product to be free from defects in workmanship and material, under normal use and service conditions, for a period of one (1) year from the date of purchase. This warranty extends only to the original purchaser. ICON's obligation under this warranty is limited to replacing or repairing, at ICON's option, the product through one of its authorized service centers. All repairs for which warranty claims are made must be pre-authorized by ICON. This warranty does not extend to any product or damage to a product caused by or attributable to freight damage, abuse, misuse, improper or abnormal usage or repairs not provided by an ICON authorized service center, to products used for commercial or rental purposes, or to products used as store display models. No other warranty beyond that specifically set forth above is authorized by ICON.

ICON is not responsible or liable for indirect, special or consequential damages arising out of or in connection with the use or performance of the product or damages with respect to any economic loss, loss of property, loss of revenues or profits, loss of enjoyment or use, costs of removal, installation or other consequential damages of whatsoever nature. Some provinces do not allow the exclusion or limitation of incidental or consequential damages. Accordingly, the above limitation may not apply to you. The warranty extended hereunder is in lieu of any and all other warranties and any implied warranties of merchantability or fitness for a particular purpose is limited in its scope and duration to the terms set forth herein. Some provinces do not allow limitations on how long an implied warranty lasts. Accordingly, the above limitation may not apply to you.

This warranty gives you specific legal rights. You may also have other rights which vary from province to province or so specified by the retailer of your equipment.

ICON OF CANADA, INC., 900 de l'Industrie, St. Jérôme, QC J7Y 4B8





WEIDER PRO-FORM WESLO

PRODUCT WARRANTY REGISTRATION

IMPORTANT: MAIL WITHIN 14 DAYS OF PURCHASE

NAME: _____ PHONE: _____

ADDRESS: _____

COUNTY: _____ POSTCODE: _____

MODEL NO. _____ SERIAL NO. _____ PURCHASE DATE: _____

RETAILER NAME: _____ RETAILER ADDRESS: _____

<p>1) Primary user(s) of product: <input type="checkbox"/> Male <input type="checkbox"/> Female <input type="checkbox"/> Family</p> <p>2) Age of primary user: <input type="checkbox"/> 0-24 <input type="checkbox"/> 35-44 <input type="checkbox"/> 55-64 <input type="checkbox"/> 25-34 <input type="checkbox"/> 45-54 <input type="checkbox"/> 65 and over</p> <p>3) Annual household income: <input type="checkbox"/> 0-9,999 <input type="checkbox"/> 15,000-19,999 <input type="checkbox"/> 10,000-14,999 <input type="checkbox"/> 20,000+</p> <p>4) How many times a week do you exercise? <input type="checkbox"/> Less than 3 times <input type="checkbox"/> 3 times or more</p> <p>5) Have you ever purchased an ICON product before? <input type="checkbox"/> Yes <input type="checkbox"/> No</p> <p>6) Where did you first see or hear about ICON products? <input type="checkbox"/> Magazine <input type="checkbox"/> Friend/relative <input type="checkbox"/> Newspaper Ad <input type="checkbox"/> Store <input type="checkbox"/> Other</p> <p>7) What was the primary reason for purchasing this ICON product? <input type="checkbox"/> Store Employee <input type="checkbox"/> Television Ads <input type="checkbox"/> Colour <input type="checkbox"/> Electronic Features <input type="checkbox"/> Magazine Ads <input type="checkbox"/> Price <input type="checkbox"/> Product Design <input type="checkbox"/> Product Innovation <input type="checkbox"/> Other Features</p>	<p>8) Did you consider purchasing fitness equipment from another manufacturer? <input type="checkbox"/> No <input type="checkbox"/> Yes What other manufacturer? _____</p> <p>9) Based on your impression of what you have purchased, would you buy another ICON product? <input type="checkbox"/> Yes <input type="checkbox"/> No <input type="checkbox"/> No Opinion If not, what other brand equipment would you purchase? _____</p> <p>10) What other type of exercise equipment do you own? <input type="checkbox"/> Bicycle <input type="checkbox"/> Exercise Cycle <input type="checkbox"/> Treadmill <input type="checkbox"/> Home Gym <input type="checkbox"/> Weight Bench <input type="checkbox"/> Stepper <input type="checkbox"/> Cardio Glide <input type="checkbox"/> Other</p> <p>11) Which type of magazines do you read regularly? <input type="checkbox"/> Sports <input type="checkbox"/> Fitness <input type="checkbox"/> Motoring <input type="checkbox"/> Business <input type="checkbox"/> Computer <input type="checkbox"/> General</p> <p>12) Do you wish to be sent further bulletins about ICON products? <input type="checkbox"/> Yes <input type="checkbox"/> No</p>
---	---

THANK YOU FOR YOUR TIME
© 2003 ICON of Canada, Inc.

WESLO is a registered trademark of ICON Health & Fitness, Inc.