

SERVICE MANUAL

BA-4 CHASSIS

<u>MODEL</u>	<u>COMMANDER</u>	<u>DEST.</u>	<u>CHASSIS NO.</u>
KV-21XE40B	RM-Y155	E	SCC-S06G-A



KV-21XE40B



RM-Y155

TRINITRON® COLOR TV
SONY®



SPECIFICATIONS

	KV-21XE40B
Power Requirements	120V-220V, 50-60 Hz
Number of Inputs/Outputs	
Video ¹⁾	2
Audio ²⁾	2
Speaker Output (W)	4W X 2
Power Consumption (W)	
In use (Max.)	105W
In standby	3W
Dimensions (W/H/D)	
(mm)	610 x 464.5 x 469.5 mm
(in.)	24 x 18 x 18 ^{1/2}
Mass	
(kg)	20.6 kg
(lbs)	45 lbs.

Television System

PAL-M, PAL-N, NTSC

Channel Coverage

VHF: 2-13 / UHF: 14-69 / CATV: 1-125

Picture Tube

Trinitron Tube

Visible Screen Size

20-inch picture measured diagonally

Actual Screen Size

21-inch picture measured diagonally

Antenna

75 ohm external terminal for VHF/UHF

Supplied Accessories

Remote commander (w/2 size AA (R6) batteries)

RM-Y155

Antenna Dipole

Antenna Connector

Converter

¹⁾ 1 Vp-p 75 ohms unbalanced, sync negative²⁾ 500 mVrms (100% modulation), Impedance: 47 kilohms***Design and specifications are subject to change***

TABLE OF CONTENTS

<u>Section</u>	<u>Title</u>	<u>Page</u>	<u>Section</u>	<u>Title</u>	<u>Page</u>
	Warnings and Caution	4			
	Self-Diagnostic Function	4			
	Safety Check Out Instructions	7			
1. GENERAL			6. DIAGRAMS		
1-1. Instruction Manual - English Edition			6-1. Block Diagrams.....		27
Connecting the TV.....		8	6-2. Circuit Boards Location.....		30
Using the Remote Control		8	6-3. Printed Wiring Boards and Schematic Diagrams		30
Setting Menu Language.....		9	• A Board.....		35
Setting up your Channels.....		9	• C Board.....		39
Watching the TV.....		9	6-4. Semiconductors.....		41
Additional Features.....		10			
Troubleshooting.....		11	7. EXPLODED VIEWS		
1-2. Instruction Manual - Spanish Edition			7-1. Chassis		42
Instalacion.....		12			
Uso del Control Remoto.....		12	8. ELECTRICAL PARTS LIST		
Ajuste de Idioma de los Menus.....		13	• A Board Parts List		43
Programacion de Canales.....		13	• C Board Parts List		49
Otras Funciones.....		14	• Accessories and Packing Material		50
Solucion de Problemas.....		15			
2. DISASSEMBLY					
2-1. Rear Cover Removal		16			
2-2. A Board Removal		16			
2-3. Service Position		16			
2-4. Picture Tube Removal		17			
..					
3. SET-UP ADJUSTMENTS					
3-1. Beam Landing.....		18			
3-2. Convergence.....		19			
3-3. Focus.....		20			
3-4. Screen (G2).....		20			
3-5. Method of Setting the Service Adjustment Mode.....		20			
3-6. White Balance Adjustments.....		20			
4. SAFETY RELATED ADJUSTMENTS.....		21			
5. CIRCUIT ADJUSTMENTS					
5-1. Electrical Adjustment by Remote Commander.....		23			
5-2. A Board Adjustments.....		25			

WARNINGS AND CAUTIONS

CAUTION!

SHORT CIRCUIT THE ANODE OF THE PICTURE TUBE AND THE ANODE CAP TO THE METAL CHASSIS, CRT SHIELD, OR CARBON PAINTED ON THE CRT, AFTER REMOVING THE ANODE.

WARNING!!

AN ISOLATION TRANSFORMER SHOULD BE USED DURING ANY SERVICE TO AVOID POSSIBLE SHOCK HAZARD, BECAUSE OF LIVE CHASSIS. THE CHASSIS OF THIS RECEIVER IS DIRECTLY CONNECTED TO THE AC POWER LINE.

SAFETY-RELATED COMPONENT WARNING!!

COMPONENTS IDENTIFIED BY SHADING AND MARK \triangle ON THE SCHEMATIC DIAGRAMS, EXPLODED VIEWS AND IN THE PARTS LIST ARE CRITICAL FOR SAFE OPERATION. REPLACE THESE COMPONENTS WITH SONY PARTS WHOSE PART NUMBERS APPEAR AS SHOWN IN THIS MANUAL OR IN SUPPLEMENTS PUBLISHED BY SONY. CIRCUIT ADJUSTMENTS THAT ARE CRITICAL FOR SAFE OPERATION ARE IDENTIFIED IN THIS MANUAL. FOLLOW THESE PROCEDURES WHENEVER CRITICAL COMPONENTS ARE REPLACED OR IMPROPER OPERATION IS SUSPECTED.

ATTENTION

APRES AVOIR DECONNECTE LE CAP DE L'ANODE, COURT-CIRCUITER L'ANODE DU TUBE CATHODIQUE ET CELUI DE L'ANODE DU CAP AU CHASSIS METALLIQUE DE L'APPAREIL, OU AU COUCHE DE CARBONE PEINTE SUR LE TUBE CATHODIQUE OU AU BLINDAGE DU TUBE CATHODIQUE.

ATTENTION!!

AFIN D'EVITER TOUT RESQUE D'ELECTROCUTION PROVENANT D'UN CHÂSSIS SOUS TENSION, UN TRANSFORMATEUR D'ISOLEMENT DOIT ETRE UTILISÉ LORS DE TOUT DÉPANNAGE. LE CHÂSSIS DE CE RÉCEPTEUR EST DIRECTEMENT RACCORDÉ À L'ALIMENTATION SECTEUR.

ATTENTION AUX COMPOSANTS RELATIFS A LA SECURITE!!

LES COMPOSANTS IDENTIFIES PAR UNE TRAME ET PAR UNE MARQUE \triangle SUR LES SCHEMAS DE PRINCIPE, LES VUES EXPLOSEES ET LES LISTES DE PIECES SONT D'UNE IMPORTANCE CRITIQUE POUR LA SECURITE DU FONCTIONNEMENT. NE LES REMPLACER QUE PAR DES COMPOSANTS SONY DONT LE NUMERO DE PIECE EST INDIQUE DANS LE PRESENT MANUEL OU DANS DES SUPPLEMENTS PUBLIES PAR SONY. LES REGLAGES DE CIRCUIT DONT L'IMPORTANCE EST CRITIQUE POUR LA SECURITE DU FONCTIONNEMENT SONT IDENTIFIES DANS LE PRESENT MANUEL. SUIVRE CES PROCEDURES LORS DE CHAQUE REMPLACEMENT DE COMPOSANTS CRITIQUES, OU LORSQU'UN MAUVAIS FONCTIONNEMENT SUSPECTE.

SELF-DIAGNOSTIC FUNCTION

The units in this manual contain a self-diagnostic function. If an error occurs, the STANDBY/TIMER lamp will automatically begin to flash. The number of times the lamp flashes translates to a probable source of the problem. A definition of the STANDBY/TIMER lamp flash indicators is listed in the instruction manual for the user's knowledge and reference. If an error symptom cannot be reproduced, the remote commander can be used to review the failure occurrence data stored in memory to reveal past problems and how often these problems occur.

DIAGNOSTIC TEST INDICATORS

When an error occurs, the STANDBY/TIMER lamp will flash a set number of times to indicate the possible cause of the problem. If there is more than one error, the lamp will identify the first of the problem areas.



Results for all of the following diagnostic items are displayed on screen. No error has occurred if the the screen displays a "0" .

Diagnostic Item Description	No. of times STANDBY/TIMER lamp flashes	Self-diagnostic display/ Diagnostic result	Probable Cause Location	Detected Symptoms
* Power does not turn on	Does not light		* Power cord is not plugged in. * Fuse is burned out (F601)	* Power does not come on. * No power is supplied to the TV. * AC power supply is faulty.
* +B overcurrent (OCP)	2 times	2:0 or 2:1	* H.OUT (Q502) is shorted. (A board) * IC1751 and Q1751 is shorted. (C board)	* Power does not come on. * Load on power line is shorted.
* Vertical deflection stopped	4 times	4:0 or 4:1	* +13V is not supplied. (A board) * IC 541 is faulty (A board)	* Has entered standby state after horizontal raster. * Vertical deflection pulse is stopped. * Power line is shorted or power supply is stopped.
* White balance failure (not balanced)	5 times	5:0 or 5:1	* Video OUT (Q392 to 394) is faulty. (A board) * IC301 is faulty. (A board) * G2 is improperly adjusted. (Note 2)	* No raster is generated. * CRT cathode current detection reference pulse output is small.

Note 1: If a +B overcurrent is detected, stoppage of the vertical deflection is detected simultaneously.
The symptom that is diagnosed first by the microcontroller is displayed on the screen.

Note 2: Refer to Screen (G2) Adjustment in Section 3-4 of this manual.

DISPLAY OF STANDBY/TIMER LIGHT FLASH COUNT



<u>Diagnostic Item</u>	<u>Flash Count*</u>
+B overcurrent	2 times
Vertical deflection stopped	4 times
White balance failure	5 times

* One flash count is not used for self-diagnostic.

STOPPING THE STANDBY/TIMER FLASH

Turn off the power switch on the TV main unit or unplug the power cord from the outlet to stop the STANDBY/TIMER lamp from flashing.

SELF-DIAGNOSTIC SCREEN DISPLAY

For errors with symptoms such as "power sometimes shuts off" or "screen sometimes goes out" that cannot be confirmed, it is possible to bring up past occurrences of failure for confirmation on the screen:

[To Bring Up Screen Test]

In standby mode, press buttons on the remote commander sequentially in rapid succession as shown below:

Screen display → channel [5] → Sound volume [−] → Power ON



Note that this differs from entering the service mode (sound volume [+]).

Self-Diagnostic screen display

SELF DIAGNOSTIC		
2:		0
3:	N/A	0
4:		0
5:		1
101:	N/A	0

-----Numeral "0" means that no fault has been detected.

-----Numeral "1" means a fault has been detected one time only.

HANDLING OF SELF-DIAGNOSTIC SCREEN DISPLAY

Since the diagnostic results displayed on the screen are not automatically cleared, always check the self-diagnostic screen during repairs. When you have completed the repairs, clear the result display to "0".

Unless the result display is cleared to "0", the self-diagnostic function will not be able to detect subsequent faults after completion of the repairs.

[Clearing the result display]


To clear the result display to "0", press buttons on the remote commander sequentially as shown below when the diagnostic screen is being displayed.

Channel [8] → ENTER

[Quitting Self-diagnostic screen]

To quit the entire self-diagnostic screen, turn off the power switch on the remote commander or the main unit.

6. SELF-DIAGNOSTIC CIRCUIT

**+B overcurrent (OCP)**

Occurs when an overcurrent on the +B(115V) line is detected by pin 18 of IC301. If the voltage to pin 18 of IC301 is less than 1V when V.SYNC is more than seven verticals in a period, the unit will automatically turn off.

Vertical deflection stopped

Occurs when an absence of the vertical deflection pulse is detected by pin 17 of IC001. Power supply will shut down when waveform interval exceeds 2 seconds.

White balance failure

If the RGB levels* do not balance within 2 seconds after the power is turned on, this error will be detected by IC301. TV will stay on, but there will be no picture.

*(Refers to the RGB levels of the AKB detection Ref pulse that detects IK.)

SAFETY CHECK-OUT

After correcting the original service problem, perform the following safety checks before releasing the set to the customer:

1. Check the area of your repair for unsoldered or poorly soldered connections. Check the entire board surface for solder splashes and bridges.
2. Check the interboard wiring to ensure that no wires are "pinched" or contact high-wattage resistors.
3. Check that all control knobs, shields, covers, ground straps, and mounting hardware have been replaced. Be absolutely certain that you have replaced all the insulators.
4. Look for unauthorized replacement parts, particularly transistors, that were installed during a previous repair. Point them out to the customer and recommend their replacement.
5. Look for parts which, though functioning, show obvious signs of deterioration. Point them out to the customer and recommend their replacement.
6. Check the line cords for cracks and abrasion. Recommend the replacement of any such line cord to the customer.
7. Check the B+ and HV to see if they are specified values. Make sure your instruments are accurate; be suspicious of your HV meter if sets always have low HV.
8. Check the antenna terminals, metal trim, "metallized" knobs, screws, and all other exposed metal parts for AC Leakage. Check leakage as described below.



LEAKAGE TEST

The AC leakage from any exposed metal part to earth ground and from all exposed metal parts to any exposed metal part having a return to chassis, must not exceed 0.5 mA (500 microampere). Leakage current can be measured by any one of three methods.

1. A commercial leakage tester, such as the Simpson 229 or RCA WT-540A. Follow the manufacturers' instructions to use these instructions.
2. A battery-operated AC milliammeter. The Data Precision 245 digital multimeter is suitable for this job.
3. Measuring the voltage drop across a resistor by means of a VOM or battery-operated AC voltmeter. The "limit" indication is 0.75 V, so analog meters must have an accurate low voltage scale. The Simpson's 250 and Sanwa SH-63Trd are examples of passive VOMs that are suitable. Nearly all battery operated digital multimeters that have a 2V AC range are suitable. (See Fig. A)

HOW TO FIND A GOOD EARTH GROUND

A cold-water pipe is guaranteed earth ground; the cover-plate retaining screw on most AC outlet boxes is also at earth ground. If the retaining screw is to be used as your earth-ground, verify that it is at ground by measuring the resistance between it and a cold-water pipe with an ohmmeter. The reading should be zero ohms. If a cold-water pipe is not accessible, connect a 60-100 watts trouble light (not a neon lamp) between the hot side of the receptacle and the retaining screw. Try both slots, if necessary, to locate the hot side of the line, the lamp should light at normal brilliance if the screw is at ground potential. (See Fig. B)



SECTION 1-1 GENERAL

The instructions mentioned in this section are partial abstracts from the Operating Instruction Manual. The page numbers shown reflect those of the Operating Instruction Manual.

Warnings and Cautions

To prevent fire or shock hazard, do not expose the TV to rain or moisture.



This symbol is intended to alert the user to the presence of uninsulated "dangerous voltage" within the product's enclosure that may be of sufficient magnitude to constitute a risk of electric shock to persons.

This symbol is intended to alert the user to the presence of important operating and maintenance (servicing) instructions in the literature accompanying the appliance.

CAUTION
When using TV games, computers, and similar products with your TV, keep the brightness and contrast functions at low settings. If a fixed (non-moving) pattern is left on the screen for long periods of time at a high brightness or contrast setting, the image can be permanently imprinted onto the screen. Continuously watching the same channel can cause the imprint of station logos onto the TV screen. These types of imprints are not covered by your warranty because they are the result of misuse.

You are cautioned that any changes or modifications not expressly approved in this manual could void your authority to operate this equipment.

Safety Precautions

- Operate the TV only on 120 V AC.
 - One blade of the power plug is wider than the other for safety purposes and will fit into the power outlet only one way. If you are unable to insert the plug fully into the outlet, contact your dealer.
- TO PREVENT ELECTRIC SHOCK, DO NOT USE THIS POLARIZED AC PLUG UNLESS THE BLADES CAN BE FULLY INSERTED TO PREVENT BLADE EXPOSURE.**


2

Step 1: Connecting the TV

The following steps guide you through your initial set up. Check the model number of your TV (located on the front of this manual) and select the appropriate diagram.


Connecting an Indoor, Outdoor or Cable Antenna

This connection offers the best picture quality. Connection is made directly from the cable or antenna to the TV.



Connecting to a Cable TV System Through a Cable Box

Some pay cable TV systems use scrambled or encoded signals that require a cable box* to view all channels.



Note
If you will be controlling all channel selection through your cable box, you should consider using the CHANNEL FIX feature discussed on page 11.

3


Connecting a VCR

See your VCR instructions to set up the VCR. After connecting the VCR to the TV, you will be able to do the following:

- Watch video tapes
- Record one TV program while viewing another

Notes


- If your cable system requires the use of a cable box, install it between the cable and the VCR.
- For a monaural VCR, connect the audio output of the VCR to the AUDIO L (MONO) on the TV.



Connecting a Camcorder

All models except KV-13M40

Use this connection to view a video tape from a camcorder.



Notes


- For a monaural camcorder, connect the audio output of the camcorder to AUDIO L (MONO) on the TV.
- If you are connecting your camcorder to a monaural TV (KV-13M50, 13M51, 20M40 only), plug the white audio connector into the AUDIO L-input on the TV.
- You can also connect a camcorder to inputs on the rear of the TV (all models).

4

Step 2: Using the Remote Control

Inserting Batteries

Insert two size AA (R6) batteries (supplied) by matching the + and - on the batteries to the + and - inside the battery compartment. With normal use, the batteries should last for approximately six months.




Notes

- Remove the batteries to avoid possible damage from battery leakage if you will not be using the remote control for an extended period of time.
- Handle the remote control with care. Avoid dropping it, getting it wet, or placing it in direct sunlight, near a heater, or where the humidity is high.

Remote Control Operation Buttons

In the instructions that follow, please refer to the buttons on your remote control. The remote control shown is model RM-Y155.



5

Warnings and Cautions • Connecting the TV • Connecting an Antenna • Connecting a Cable Box

Connecting a VCR • Connecting a Camcorder • Using the Remote Control • Inserting Batteries • Remote Control Operation Buttons

Step 3: Setting Menu Language

Changing the Menu Language

Except Canadian models

The menu illustrations are for KV-20S40. Your on-screen menu may not look like those used within this manual. When a feature is only available to a limited set of models, those models will be listed.

If you want to view the menus in Spanish, you can change the menu language.

1 Press MENU.

The main menu appears. Move the cursor \blacktriangle or \blacktriangledown to the SET UP menu, press SELECT.



2 Press \blacktriangle or \blacktriangledown to move the cursor to LANGUAGE and press SELECT.

ENGLISH will appear red.



3 Press \blacktriangle or \blacktriangledown to select ESPAÑOL and press SELECT.

ESPAÑOL will turn red and the menu will appear in Spanish.



4 Press MENU to return to the TV program.

6

Step 4: Setting up Your Channels

Setting Up the TV Automatically

KV-20M40, 20S40, 20S41 only


The Easy Set Up Guide allows you to set up the on-screen language and set all receivable channels. (The Easy Set Up Guide screen appears every time you turn on the TV until you perform AUTO PROGRAM).

1 Press POWER to turn on your TV.

The Easy Set Up Guide screen appears.

2 (Except Canadian Models) Press CH + to select English screens or CH - to select Spanish screens.

3 Press VOL + to continue or VOL - for a DEMO of functions and menus.



To perform this function again

Press the SET UP button on your TV.

Auto Programming Your Channels (AUTO PROGRAM)

The AUTO PROGRAM feature allows you to set all receivable channels in one step. After this function is completed, you may delete unwanted channels or add additional channels.

Notes


- If the TV is set to VIDEO, you cannot run AUTO PROGRAM. Press TV/VIDEO on the remote control until a channel number appears.
- It is usually best to preset channels during the day when more channels are broadcasting and receivable.

1 Press MENU.



2 Move the cursor \blacktriangle or \blacktriangledown to the SET UP menu and press SELECT.

The SET UP menu appears.



3 Move the cursor \blacktriangle or \blacktriangledown to CHANNEL SET UP and press SELECT.

4 Move the cursor \blacktriangle or \blacktriangledown to AUTO PROGRAM and press SELECT.

AUTO PROGRAM appears on the screen and the TV starts scanning and presetting channels.



Notes

- Pressing any button on the remote control while AUTO PROGRAM is scanning and presetting channels will cause AUTO PROGRAM to stop.
- When you run AUTO PROGRAM your CHANNEL FIX and ON/OFF TIMER settings will be erased.

7

Setting the Menu Language • Setting up Your Channels • Easy Set Up • Auto Programming

Skipping or Adding Channels (CHANNEL SKIP/ADD)

After you run AUTO PROGRAM, you can skip unnecessary channels or add new ones.

1 Press MENU and select the SET UP menu.

2 Move the cursor to CHANNEL SET UP and press SELECT.

3 Press \blacktriangle or \blacktriangledown to CHANNEL SKIP/ADD and press SELECT.



4 To skip or add a channel:

- (1) Press CH +/- or 0-9 to enter the desired channel.
- (2) Press SELECT to SKIP or ADD.



5 To skip or add other channels, repeat step 4.

6 Press MENU to return to the TV program.

Note

- If a channel you want to add was not received by AUTO PROGRAM, you must use the 0-9 buttons to manually add the channel.

Setting Cable TV On or Off (CABLE)

If you have connected the TV to a cable TV system, set CABLE to ON. If you will be using an antenna, set CABLE to OFF to receive VHF/UHF channels.

1 Press MENU.

2 Move the cursor to the SET UP menu and press SELECT.

3 Move the cursor to CHANNEL SET UP and press SELECT.



4 Move the cursor to CABLE and press SELECT.

5 Press \blacktriangle or \blacktriangledown to select ON or OFF.

6 Press SELECT.

7 Press MENU to return to the TV program.



After adjusting the CABLE setting, you will need to run AUTO PROGRAM. (See page 7).

Note

- If no picture appears, the TV may be set to a video input and CABLE can not be selected. Press TV/VIDEO until a channel number appears, then follow steps 1-6.

8

Watching the TV

Press POWER to turn the TV on.

Note

- If VIDEO is on the screen, press TV/VIDEO until a channel number appears.

Selecting a Channel Directly

Press 0-9 to select a channel.

The channel changes after 2 seconds, or you can press ENTER for immediate selection.



Scanning Channels

Press CH +/- until the channel appears.

Note

- Keeping the CH + or - button pressed, allows you to rapidly scan to the desired channel.



Jumping Quickly Between Two Channels

Press JUMP.

The TV alternates or jumps between the last two channels viewed.



Note

- You can only jump to channels you have selected with the 0-9 keys.

Muting the Sound

Press MUTING.

MUTING appears on the screen.

To restore the sound, press MUTING again, or press VOL +.



Displaying On-Screen Information

Use the DISPLAY key to check current time, channel and Multichannel TV Sound (MTS).

1 Press DISPLAY.

The channel number and local time (if set), are displayed. The TV displays the MTS mode if SAP or STEREO are selected and available (KV-20S40, 20S41 only).

The MTS mode display disappears after 4 seconds.

2 Press DISPLAY again.

CCI (default setting) appears on the screen for a few seconds. A printed version of the dialog and sound effects will appear, if available.

3 To turn off CAPTION VISION, press DISPLAY again until DISPLAY OFF appears.

It will take a few seconds for DISPLAY OFF to disappear.

Notes

- See page 12 for more information about CAPTION VISION.
- See page 14 for more information about MTS.

Watching Video Tapes

1 Press TV/VIDEO until the correct video input appears.



2 Press PLAY on your VCR to view the video tape.

3 Press TV/VIDEO to return to the TV program.

Listening with Headphones or an Earphone

Plug the headphones or earphone into the jack on the front of the TV. Using headphones will turn off the sound to the TV speakers.

Note

- If your TV is monaural, the monaural sound will be heard from both headphones.

9


Channel SKIP/ADD • CABLE • Watching the TV • Selecting • Scanning • JUMP • Muting • On-Screen Information • Watching Video Tapes • Headphones

Additional Features

Setting the SLEEP Timer

The SLEEP timer programs the TV to stay on for a length of time and then shut off automatically.

- Press SLEEP until the length of time you want the TV to stay on appears. SLEEP appears one minute before the TV shuts off.
- To cancel the sleep timer, press SLEEP again until SLEEP OFF appears, or turn off the TV.



Setting DAYLIGHT SAVING

All models except KV-13M40

You can program DAYLIGHT SAVING to automatically adjust the time.

- Press MENU and select the TIMER menu.
- Move the cursor to DAYLIGHT SAVING and press SELECT.
- Press \blacktriangle or \blacktriangledown to select YES or NO based on the following options:
Spring: Select YES, the current time moves one hour ahead.
Fall: Select NO, the current time moves back one hour.



Setting the clock (CURRENT TIME SET)

All models except KV-13M40

- Press MENU and select the TIMER menu.
- Move the cursor to CURRENT TIME SET and press SELECT.
- Set the current day.
Press SELECT and press \blacktriangle or \blacktriangledown until the day entry is highlighted, press SELECT.
- Set the current time.
Press SELECT until the time entry is highlighted.
Press \blacktriangle or \blacktriangledown until the current hour is displayed and press SELECT.
Press \blacktriangle or \blacktriangledown until the current minute is displayed and press SELECT.



Setting the ON/OFF TIMER

All models except KV-13M40

You can program your TV for scheduled viewing using the ON/OFF TIMER. The CURRENT TIME SET must be set in order for the ON/OFF TIMER to function.

- Press MENU and select the TIMER menu.
- Move the cursor to ON/OFF TIMER and press SELECT.



Additional Features (continued)

3 Enter the ON/OFF TIMER setting.

- Press SELECT until the day entry is highlighted.
Press \blacktriangle or \blacktriangledown to cycle through the day options.
Select an entry and press SELECT.
- Press SELECT until the time entry is highlighted.
Press \blacktriangle or \blacktriangledown to set the hour and press SELECT.
Press \blacktriangle or \blacktriangledown to set the minute and press SELECT.
- Press \blacktriangle or \blacktriangledown to set the duration, up to six hours, and press SELECT.
The TIMER indicator, on the front of the TV, will light up.



To erase your ON/OFF TIMER settings
Press RESET, while in the TIMER menu.


Note

- If you exit the ON/OFF TIMER menu while setting the TIMER, your settings will be saved.


Setting FAVORITE CHANNEL

This feature provides quick access to your favorite channels.

- Press MENU and select the SET UP menu.
- Move the cursor to FAVORITE CHANNEL and press SELECT.



- Press \blacktriangle or \blacktriangledown to select AUTO or MANUAL and press SELECT.
Selecting AUTO will display the last five channels chosen with the remote control's 0-9 buttons.
- Press \blacktriangle or \blacktriangledown to select 1, 2, 3, 4 or 5 and press SELECT.
- Press \blacktriangle or \blacktriangledown to highlight the desired channel and press SELECT.




To use FAVORITE CHANNEL

Press SELECT when in normal viewing mode. Your options will appear on the screen.

Setting CHANNEL FIX

This feature is useful when you want to control all channel selection through a cable box or video equipment.

- Press MENU and select the SET UP menu.
- Move the cursor \blacktriangle or \blacktriangledown to CHANNEL SET UP and press SELECT.



- Select CHANNEL FIX and set your TV to one of the following options:

- 2-6: When the cable box is connected to VHF/UHF input. Use your cable box remote to change channels.
- VIDEO 1: When you have connected video equipment (e.g. DSS receiver) and you want the TV fixed to it. You will be able to alternate between video sources.
- OFF: When you want to switch CHANNEL FIX off.



Notes

- For information on connecting a cable box, see page 3.
- ON/OFF TIMER settings will be erased when CHANNEL FIX is set.
- FAVORITE CHANNEL can not be accessed when CHANNEL FIX is set.


Blocking out a Channel (CHANNEL BLOCK)

This feature is useful in preventing child access to designated channels.

- Press MENU and select the SET UP menu.
- Move the cursor \blacktriangle or \blacktriangledown to CHANNEL BLOCK and press SELECT.



- Move the cursor to 1 or 2 and press SELECT.
- Press \blacktriangle or \blacktriangledown until you reach the channel you want to block and press SELECT.



When you try to tune to the blocked channel, BLOCKED will appear on the screen. CAPTION VISION will also be blocked.

To erase your CHANNEL BLOCK settings

Press RESET, while in the CHANNEL BLOCK menu.

Selecting CAPTION VISION

Some programs are broadcast with CAPTION VISION. These services are sometimes limited to specific broadcasting networks and may not be available in your area. (CCI is the default setting).

- Press MENU and select the SET UP menu.
- Move the cursor \blacktriangle or \blacktriangledown to CAPTION VISION and press SELECT.
- Press \blacktriangle or \blacktriangledown and set your TV to one of the following options:



Choose	To Display
CCI, 2, 3 or 4	A printed version of the dialog or sound effects of a program. (The default setting is CCI).
TEXT 1, 2, 3 or 4	Station/network related information that usually is not related to the program.
XDS (Extended Data Services)	A program's type, name, length and call letters.

- Press DISPLAY.
The caption will appear in a few seconds, if available.
- To turn off CAPTION VISION, press DISPLAY until DISPLAY OFF appears.

Notes

- Captions disappear for a few seconds when you press the MUTING button.
- Captions may appear with a white box or other errors, if you have poor reception on the channel.

Using the VIDEO Menu

Adjusting the VIDEO Settings

You can adjust the PICTURE, BRIGHTNESS, COLOR, HUE, and SHARPNESS of any TV image.

- Press MENU and select the VIDEO menu.



- Move the cursor \blacktriangle or \blacktriangledown to the feature you want to adjust and press SELECT.
See the ADJUSTABLE ITEMS chart below for a list of the adjustments you can make.



ADJUSTABLE ITEMS

Item	Press \blacktriangle to	Press \blacktriangledown to
PICTURE	Increase the contrast	Decrease the contrast
BRIGHTNESS	Brighten the picture	Darken the picture
COLOR	Increase color intensity	Decrease color intensity
HUE	Increase the green tones	Decrease the green tones
SHARPNESS	Sharpen the picture	Soften the picture

- Press MENU to return to the TV program.

Restoring the factory video settings
Press RESET, while in the VIDEO menu.


Audio Menu

Selecting Stereo or Bilingual Programs (MTS)

KV-20540, 20541 only

The Multichannel TV Sound (MTS) feature allows you to enjoy Stereo Sound (STEREO), Second Audio Programs (SAP), or Monaural Sound (MONO) when available.

- 1 Press MENU and select the AUDIO \blacktriangleright menu.
- 2 Move the cursor to MTS and press SELECT.



- 3 Press \blacktriangle or \blacktriangledown to select STEREO, SAP, or MONO and press SELECT.

Choose	To
STEREO	Listen to stereo sound.
SAP	Listen to bilingual and other programs.
MONO	Reduce noise during poor stereo broadcasts.

For Direct MTS Access

Press MTS repeatedly to cycle through the MTS options.

Note

- If your TV does not have sound, try changing your MTS setting.

Troubleshooting

If you are having a problem with your TV, try the suggestions below. If the problem persists, contact your nearest Sony dealer.

Problem	Suggestion
No picture, no sound	<ul style="list-style-type: none"> • Make sure the power cord is connected. • If a red light keeps flashing on the front of your TV, for more than a few minutes, call your local service center. • Check the TV/VIDEO setting: when watching TV, set to TV; when watching video tapes, set to VIDEO (page 9). • Make sure the batteries have been inserted correctly into the remote control. • Try another channel. It could be station trouble.
Poor or no picture, good sound	<ul style="list-style-type: none"> • Adjust PICTURE in the VIDEO menu (page 13). • Adjust BRIGHTNESS in the VIDEO menu (page 13). • Check the antenna and/or cable connections (page 3).
Good picture, no sound	<ul style="list-style-type: none"> • Press MUTING so that MUTING disappears from the screen (page 9). • Check your AUDIO settings. Your TV may be set to SAP (page 14).
No color	<ul style="list-style-type: none"> • Adjust COLOR in the VIDEO menu (page 13). • Make sure that a black and white program is not being broadcast.
Only snow appears on the screen	<ul style="list-style-type: none"> • Check the CABLE setting in the SET UP menu (page 8). • Check the antenna and/or cable connections (page 3). • Make sure the channel selected is currently broadcasting.
Dotted lines or stripes	<ul style="list-style-type: none"> • Adjust the antenna. • Move the TV away from other electronic equipment. Some electronic equipment can create electrical noise, which can interfere with TV reception.
Double images or ghosts	<ul style="list-style-type: none"> • Check your outdoor antenna or call your cable service.
Cannot receive higher number channels (UHF) when using an antenna	<ul style="list-style-type: none"> • Make sure CABLE is set to OFF in the SET UP menu (page 8). • Use AUTO PROGRAM to add channels that are not presently in the memory (page 7).
Cable stations don't seem to work	<ul style="list-style-type: none"> • Make sure CABLE is set to ON in the SET UP menu (page 8). • Use AUTO PROGRAM to add channels that are not presently in the memory (page 7).
Remote control does not operate	<ul style="list-style-type: none"> • Batteries could be weak. Replace them (page 5). • Move the TV 3-4 feet away from fluorescent lights.
The TV needs to be cleaned	<ul style="list-style-type: none"> • Clean the TV with a soft dry cloth. Never use strong solvents such as thinner or benzene, which might damage the finish of the cabinet.
The TV is fixed to one channel	<ul style="list-style-type: none"> • Try turning CHANNEL FIX off (page 11). • Use AUTO PROGRAM to add receivable channels that are not presently in the TV memory (page 7).

If, after reading these operating instructions, you have additional questions related to the use of your Sony television, please call our Direct Response Center at 1-800-222-SONY (7669).

SECTION 1-2 GENERAL

Las instrucciones contenidas en esta sección, son abstractos del manual de instrucciones y operación. La numeración de las páginas hacen referencia el número de página en el manual original.

Advertencias

Para evitar el riesgo de incendios o de descargas eléctricas, no exponga al televisor a la lluvia ni a la humedad.



Este símbolo sirve para indicar al usuario la presencia de altas tensiones sin aislar en el interior de este producto, las que pueden ser de una magnitud que presente riesgo de descargas eléctricas.

Este símbolo sirve para indicar al usuario que el manual que acompaña a este producto contiene instrucciones importantes referentes al funcionamiento y mantenimiento del producto.

PRECAUCIÓN
Al utilizar videojuegos, computadoras o productos similares con el televisor, mantenga las preferencias de brillo y contraste a un nivel bajo. Si una imagen fija permanece en la pantalla durante mucho tiempo con elevada intensidad de brillo o contraste, la imagen puede quedar grabada en la pantalla de forma permanente. Igualmente, ver continuamente el mismo programa de televisión podría dejar grabada en la pantalla el logotipo de la emisora. La garantía no cubre estas quemaduras de la pantalla, ya que se deben al mal uso del aparato.

Cualquier cambio o modificación que no se detalla expresamente en el presente manual podría anular su autorización para emplear este aparato.

Precauciones de seguridad

- Alimente el televisor exclusivamente con 120 V CA (con excepción KV-14MB40C, 21MB40C, 21ME40C, 21SB40C, 21SE40C).
- Alimente el televisor exclusivamente con 220 V CA (sólo KV-14MB40C, 21MB40C, 21ME40C, 21SB40C, 21SE40C).

- Por motivos de seguridad, un contacto de la clavija del cable eléctrico de este aparato es más ancho que el otro y la clavija entrará en el enchufe en solamente una posición. Si no puede introducirlo totalmente en el enchufe, consulte con su concesionario. **PARA EVITAR DESCARGAS ELÉCTRICAS, NO USE ESTA CLAVIJA POLARIZADA A MENOS QUE LOS CONTACTOS QUEDEN COMPLETAMENTE DENTRO DEL ENCHUFE.**
 - Si algún líquido u objeto cae dentro del televisor, desenchufe el aparato y llévelo a revisión por un técnico calificado antes de volver a utilizarlo.
 - Si no va a utilizar el televisor durante varios días, desconéctelo. Para desenchufar el cable eléctrico, sujételo por la clavija, nunca tire del cable mismo.
- Para mayores informes sobre medidas de seguridad, consulte el folleto "NORMAS IMPORTANTES SOBRE SEGURIDAD" que acompaña al televisor.

Protección del televisor

- Para evitar el sobrecalentamiento interno, no cubra las rejillas de ventilación.
- No instale el televisor en un lugar caliente o húmedo, ni donde esté expuesto a cantidades excesivas de polvo o a vibraciones mecánicas.

Nota sobre CAPTION VISION
Este aparato de televisión permite ver texto superpuesto a las imágenes, en cumplimiento con lo dispuesto en el inciso 15.119 de las normas de la Comisión Federal de Comunicaciones (FCC) de EUA.

Nota para el técnico que instala el sistema de cable
El inciso 820-40 de NEC contiene normas para la puesta a tierra y en particular, dispone que la tierra del cable debe conectarse al sistema de puesta a tierra del edificio, en el punto más cercano a la entrada del cable como sea factible.


El empleo de este televisor para fines que no sean el de ver en privado programas de televisión de UHF, de VHF o transmitidos por compañías de cable para uso del público en general, puede requerir la autorización de la emisora o compañía de cable, del propietario del programa o de ambos.

Paso 1: Instalación





Este instructivo le guiará durante la instalación de su televisor. Siga las indicaciones de los dibujos correspondientes a su televisor (el número de modelo aparece en la portada de este manual) y seleccione el diagrama apropiado.

Conexión a Antena Interior, Exterior o de Cable

Utilice esta conexión para lograr una óptima calidad de imagen. Se conecta el cable o la antena directamente al televisor.




Si no se puede conectar la antena o el cable directamente a la terminal de antena del televisor, utilice las instrucciones de la ilustración correspondiente.



Conexión a Sistema de Cable por Medio de Decodificador.

Algunos sistemas de televisión por cable de paga usan señales deformadas o codificadas que requieren un decodificador* para poder ver todos los canales.



Nota

- Si va a hacer la selección de todos los canales a través de su decodificador, debe usted considerar la posibilidad de usar la función FJAR CANAL, que se describe en la página 11.

Advertencias • Instalación • Conexión a Antena • Conexión a Decodificador


Conexión a Videogradora

Consulte las instrucciones para instalar la videogradora. Una vez conectada la videogradora al televisor, podrá:

- Ver videocintas
- Grabar un programa de televisión mientras ve otro

Notas


- Si su sistema de cable requiere de un decodificador, conéctelo entre el cable y la videogradora.
- Si utiliza una videogradora monoaural, conecte la salida de audio de la videogradora al conector AUDIO L (MONO) del televisor.



Conexión a Cámara de Video

Con excepción KV-14MB40, 14MB40C

Utilice esta conexión para ver la videocinta de una cámara de video.




Notas

- Si utiliza una cámara de video monoaural, conecte la salida de audio de la cámara al enchufe AUDIO L (MONO) del televisor.
- Si conecta su cámara de video a un televisor monoaural (sólo KV-14MB40, 14MB40C, 21MB40C, 21MB40M, 21MB40P, 21ME40, 21ME40C), enchufe la clavija blanca de audio de la cámara en la entrada de AUDIO L del televisor.
- También puede conectar su cámara de video a las entradas localizadas en la parte posterior del televisor (todos los modelos).

Paso 2: Uso del Control Remoto

Instalación de las Pilas

Inserte dos pilas AA (R6) (se incluyen). Asegúrese que los signos + y - de las pilas concuerdan con los signos + y - dentro del control remoto. Las pilas deben durar aproximadamente 6 meses con uso normal.




Notas

- Para evitar el daño que podría causar la fuga de electrolito de las pilas, síquelas del compartimiento si no piensa utilizar el control remoto durante largo tiempo.
- Mantenga el control remoto con cuidado. No lo deje caer ni permita que se moje. No lo coloque bajo la luz solar directa, cerca de un calentador o en lugares húmedos.

Operación de los Botones del Control Remoto

Las siguientes instrucciones se refieren a los botones de su control remoto. El dibujo corresponde al control remoto RM-Y155.



Si pierde su control remoto

Con excepción KV-14MB40, 14MB40C

Usted puede usar los botones en la parte delantera del televisor para controlar los menús y cambiar los canales.

Conexión a Videogradora • Conexión a Cámara de Video • Uso del Control Remoto • Instalación de las Pilas • Operación de los Botones del Control Remoto

Paso 3: Ajuste de Idioma de los Menús

Cambio de Idioma de los Menús


Las ilustraciones de los menús que se utilizan corresponden al modelo KV-21SE40. Es posible que sus menús en pantalla no aparezcan igual que aquellos utilizados en este manual. Al presentar funciones que se encuentren en otros modelos, el manual indicará los números de modelo correspondientes.

Si prefiere ver los menús en inglés, puede cambiar el idioma de los menús.


- 1 Oprima **MENU**. Aparece el menú principal. Coloque el cursor \blacktriangle o \blacktriangledown en el menú de **PREFERENCIAS** y oprima **SELECT**.



- 2 Oprima \blacktriangle o \blacktriangledown para colocar el cursor en **LÉNGUAJE** y oprima **SELECT**. La palabra **ESPAÑOL** se pondrá roja.



- 3 Oprima \blacktriangle o \blacktriangledown para colocar el cursor en **ENGLISH** y oprima **SELECT**. **ENGLISH** se pondrá roja y los menús aparecerán en inglés.



- 4 Para volver a la pantalla normal, oprima **MENU**.

Nota
• Con excepción de los modelos KV-14MB40, 14MB40C, usted puede controlar los menús usando los botones en la parte delantera del televisor siguiendo las instrucciones en la pantalla.

6

Paso 4: Programación de Canales

Programación Automática del Televisor

Con excepción KV-14MB40, 14MB40C

La función Guía de Programación Fácil le permitirá seleccionar el idioma de los menús y sintonizar automáticamente todos los canales que el televisor pueda recibir. (Mientras no lleve a cabo la AUTO PROGRAMACION, la pantalla que muestra la Guía de Programación Fácil aparecerá cada vez que se encienda el televisor).

- 1 Oprima **POWER** para encender el televisor. Aparecerá en pantalla la Guía de Programación Fácil.



- 2 Oprima **CH+** para que los menús aparezcan en inglés o **CH-** para que aparezcan en español.
- 3 Oprima **VOL+** para continuar o **VOL-** para una demostración de las funciones y menús.

Para repetir Auto Ajuste
Oprima **SET UP** en la parte delantera del televisor.

Programación Automática de los Canales (AUTO PROGRAMACION)

La función de **AUTO PROGRAMACION** le permite programar en un solo paso todos los canales que su televisor pueda recibir. Después, podrá omitir los canales que no desee incluir o añadir otros.

- Notas**
- Si el televisor está ajustado a una entrada de VIDEO, no podrá utilizar **AUTO PROGRAMACION**. Oprima **TV/VIDEO** del control remoto hasta que aparezca un número de canal.
 - Se recomienda programar los canales durante el día, cuando es mayor el número de canales que están transmitiendo.

- 1 Oprima **MENU**.



- 2 Coloque el cursor \blacktriangle o \blacktriangledown en el menú de **PREFERENCIAS** y oprima **SELECT** o **ENTER**. Aparece el menú de **PREFERENCIAS**.



- 3 Coloque el cursor \blacktriangle o \blacktriangledown en **AJUSTE DE CANAL** y oprima **SELECT**.

- 4 Coloque el cursor \blacktriangle o \blacktriangledown en **AUTO PROGRAMACION** y oprima **SELECT**.

En la pantalla aparece **AUTO PROGRAMACION** y el televisor empezará a buscar y programar los canales automáticamente.



Notas

- Si oprime cualquier botón del control remoto mientras **AUTO PROGRAMACION** esté activada, esta función cesará.
- Al llevar a cabo función **AUTO PROGRAMACION**, se borrarán sus selecciones de **FIJAR CANAL** y **ENCENDIDO/APAGADO**.

7

Ajuste de idioma de los Menús • Programación de Canales • Guía de Programación Fácil • Programación Automática de Canales

Para Omitir o Añadir Canales (OMITIR/AÑADIR)

Después de efectuar la **AUTO PROGRAMACION**, podrá omitir los canales no deseados o añadir otros.

- 1 Oprima **MENU** y seleccione el menú de **PREFERENCIAS**.
- 2 Coloque el cursor en **AJUSTE DE CANAL** y oprima **SELECT**.
- 3 Oprima \blacktriangle o \blacktriangledown en **OMITIR/AÑADIR CANAL** y oprima **SELECT**.



- 4 Para omitir o añadir un canal:

- (1) Oprima **CH +/-** o del 0 al 9 para seleccionar el canal que desea.
- (2) Oprima **SELECT** para seleccionar **OMITIR** o **AÑADIR**.



- 5 Para omitir o añadir otros canales, repita el paso 4.
- 6 Oprima **MENU** para volver al programa de televisión.

Nota
• Si quiere añadir un canal que no se captó con **AUTO PROGRAMACION**, tendrá que usar los botones de 0 a 9 para añadirlo.

Para Activar o Desactivar el Sistema de Cable (CABLE)

Si conecta su televisor a un sistema de cable, cambie la función **CABLE** a **SI**. Si utiliza una antena, cambie la función **CABLE** a **NO** para recibir canales de VHF/UHF.

- 1 Oprima **MENU**.
- 2 Coloque el cursor en el menú de **PREFERENCIAS** y oprima **SELECT**.
- 3 Coloque el cursor en **AJUSTE DE CANAL** y oprima **SELECT**.



- 4 Coloque el cursor en **CABLE** y oprima **SELECT**.
- 5 Oprima \blacktriangle o \blacktriangledown para seleccionar **SI** o **NO**.
- 6 Oprima **SELECT**.
- 7 Oprima **MENU** para volver al programa de televisión.



Después de ajustar la función de **CABLE** necesita efectuar la **AUTO PROGRAMACION**. (Consulte pág. 7).

Nota
• Si la imagen no aparece, es posible que el televisor está ajustado a una entrada de video y no se puede seleccionar **CABLE**. Oprima **TV/VIDEO** hasta que aparezca un número de canal y repita los pasos del 1 al 6.

8

Para ver Programas de Televisión

Oprima **POWER** para encender el televisor.

Nota
• Si la indicación **VIDEO** aparece en la pantalla, oprima **TV/VIDEO** para que aparezca un número de canal.

Selección Directa de Canales

Oprima los botones del 0 al 9 para seleccionar un canal.

El canal cambiará en 2 segundos, o puede oprimir **ENTER** después de haber seleccionado el canal para un cambio inmediato.



Exploración de Canales

Oprima **CH +/-** hasta que aparezca el canal que desea.

Nota
• Al mantener **CH +/-** oprimido, usted puede llegar rápidamente al canal deseado.



Cambio Rápido Entre dos Canales

Oprima **JUMP**

Oprima este botón para alternar entre dos canales.



Nota
• Podrá cambiar rápidamente sólo a un canal que haya seleccionado con los botones del 0 al 9.

Eliminación del Sonido

Oprima **MUTING**.

En la pantalla aparece la indicación **MUTING**.

Para restablecer el sonido, vuelva a oprimir **MUTING** u oprima **VOL +**.



Información en Pantalla

Utilice el botón **DISPLAY** para ver la hora actual, canal y función de sonido multicanal (MTS).

- 1 Oprima **DISPLAY**. Aparecerán el número de canal y la hora actual (si está ajustada). También aparecerá la modalidad de sonido multicanal (MTS) que está en uso si se ha seleccionado un segundo programa de audio (5AP) o sonido estéreo (ESTEREO) (sólo KV-21SB40C, 21SB40M, 21SB40P, 21SE40, 21SE40C). La indicación **MTS** desaparecerá a los 4 segundos.
- 2 Oprima **DISPLAY** una vez más. **CC1** (el ajuste de fábrica) aparecerá en la pantalla. Una versión escrita del diálogo aparecerá, si la emisora ofrece este servicio.
- 3 Para desactivar **CAPTION VISION**, vuelva a oprimir **DISPLAY** hasta que aparezca la indicación **DISPLAY OFF**. **DISPLAY OFF** desaparecerá a los tres segundos.

Notas
• Consulte la página 12 para mayores informes sobre **CAPTION VISION**.
• Consulte la página 14 para mayores informes sobre **MTS**.

Para ver Videocintas

- 1 Oprima **TV/VIDEO** hasta que aparezca la entrada de video que busca.
- 2 Para ver la cinta, oprima **PLAY** en su videograbadora.
- 3 Oprima **TV/VIDEO** para regresar a un programa de televisión.



Uso de Auriculares

Introduzca la clavija de los auriculares en el enchufe ubicado en la parte delantera del televisor. Al usar los auriculares, automáticamente se apagará el sonido de las bocinas del televisor.

Nota
• Si su televisor es monoaural, escuchará el sonido monoaural en ambos auriculares.

9

OMITIR/AÑADIR • CABLE • Para ver Programas • Selección de Canales • JUMP • Eliminación de Sonido • Información en Pantalla • Videocintas • Auriculares

Otras Funciones

Apagado Automático (SLEEP)

La función SLEEP permite que el televisor esté encendido por el período de tiempo que usted indique y después se apague automáticamente.

- 1 Oprima SLEEP hasta que aparezca el número de minutos que desee. Un minuto antes de que el televisor se apague, aparecerá en la pantalla el mensaje SLEEP.
- 2 Para cancelar el apagado automático, vuelva a oprimir SLEEP hasta que aparezca SLEEP OFF o apague el televisor.



Nota

- Si su televisor no recibe una señal en treinta minutos, se apagará automáticamente.

Para poner HORA DE VERANO

Puedes programar HORA DE VERANO para ajustar automáticamente el tiempo.

- 1 Oprima MENU y seleccione el menú de RELOJ.
- 2 Coloque el cursor en HORA DE VERANO y oprima SELECT.
- 3 Coloque \blacklozenge para seleccionar SI o NO basándose en las siguientes opciones:
Primavera: Seleccione SI para adelantar el reloj una hora.
Otoño: Seleccione NO para atrasar el reloj una hora.



Para poner el reloj a la hora (FIJAR HORA ACTUAL)

- 1 Oprima MENU y seleccione el menú de RELOJ.
- 2 Coloque el cursor en FIJAR HORA ACTUAL y oprima SELECT.



- 3 Indique el día.
Oprima SELECT hasta realizar el día.
Oprima \blacklozenge hasta que aparezca el día de hoy y oprima SELECT.
- 4 Indique la hora.
Oprima SELECT hasta realizar la hora.
Oprima \blacklozenge hasta que aparezca la hora actual y oprima SELECT.
Oprima \blacklozenge hasta que aparezca el minuto actual y oprima SELECT.



Para usar ENCENDIDO/APAGADO

Usted puede ajustar su televisor para ver programas específicos. Para usar ENCENDIDO/APAGADO, primero tiene que poner a la función FIJAR HORA ACTUAL.

- 1 Oprima MENU y seleccione el menú de RELOJ.
- 2 Coloque el cursor en ENCENDIDO/APAGADO y oprima SELECT.



10

Otras Funciones (continuación)

- 3 Indique el día, hora, duración y canal deseados.

- a Oprima SELECT hasta realizar el renglón correspondiente a los días.
Oprima \blacklozenge para cambiar la opción del día.
Cuando aparezca el día deseado, oprima SELECT.
- b Oprima SELECT hasta realizar la hora.
Oprima \blacklozenge para indicar la hora deseada y oprima SELECT.
Oprima \blacklozenge para indicar el minuto deseado y oprima SELECT.
- c Oprima \blacklozenge para indicar la duración deseada, hasta de seis horas, y oprima SELECT.
- d Oprima \blacklozenge para indicar el canal deseado y oprima SELECT. Se encenderá el indicador del reloj en la parte delantera del televisor.



Para borrar las indicaciones seleccionadas mediante ENCENDIDO/APAGADO Oprima RESET mientras se encuentra en el menú de ENCENDIDO/APAGADO.

Nota

- Si se sale del menú de ENCENDIDO/APAGADO al estar programando esta función, quedarán registradas las indicaciones seleccionadas.


Programación de CANAL FAVORITO

Esta función le dará rápido acceso a sus canales favoritos.

- 1 Oprima MENU y seleccione el menú de PREFERENCIAS.
- 2 Coloque el cursor en CANAL FAVORITO y oprima SELECT.



- 3 Oprima \blacklozenge para seleccionar AUTO o MANUAL y oprima SELECT.
Al seleccionar AUTO, se mostrarán en pantalla los últimos cinco canales escogidos con los botones de 0 a 9 del control remoto.
- 4 Oprima \blacklozenge para seleccionar 1, 2, 3, 4 o 5 y oprima SELECT.
- 5 Oprima \blacklozenge para seleccionar el canal que desee y oprima SELECT.



Para usar CANAL FAVORITO

Oprima SELECT cuando el menú no esté activado. Sus opciones aparecerán en la pantalla.


Programación de FIJAR CANAL

Esta función resulta útil cuando quiera hacer todos los cambios de canal a través de un decodificador de cable o un aparato de video.

- 1 Oprima MENU y seleccione el menú de PREFERENCIAS.
- 2 Coloque el cursor en AJUSTE DE CANAL y oprima SELECT.



- 3 Seleccione FIJAR CANAL y ajuste en el televisor a una de las siguientes opciones:
2-6: Cuando el decodificador se encuentre conectado a AUX y el cable o antena esté conectado a la entrada VHF/UHF. Utilice el control remoto de su decodificador para cambiar canales.



VIDEO 1: Cuando haya conectado un aparato de video (p.ej. receptor de DSS) y quiere que el televisor reciba la señal de ese aparato. Así podrá intercambiar entre las dos fuentes de video.
OFF: Cuando quiere apagar FIJAR CANAL.

Notas

- Para detalles sobre la conexión de un decodificador, consulte la página 3.
- Se borrarán las selecciones de ENCENDIDO/APAGADO al utilizar la función FIJAR CANAL.
- La función CANAL FAVORITO no puede ser accedida cuando la función de FIJAR CANAL ha sido seleccionada.

11

Para usar BLOQUEAR CANAL

Esta función sirve para impedir que los niños vean determinados canales.

- 1 Oprima MENU y seleccione el menú de PREFERENCIAS.
- 2 Coloque el cursor en BLOQUEAR CANAL y oprima SELECT.



- 3 Coloque el cursor para 1 o 2 y oprima SELECT.

- 4 Oprima \blacklozenge para mostrar el canal que desea bloquear y oprima SELECT.
Al escoger el canal que va a suprimir, la palabra BLOQUEADO aparecerá en la pantalla y se suprimirá CAPTION VISION.



Para cancelar las opciones seleccionadas bajo BLOQUEAR CANAL Oprima RESET mientras se encuentre en el menú de BLOQUEAR CANAL.

Para seleccionar una Opción de CAPTION VISION

Algunos programas son transmitidos con subtítulos conocidos como CAPTION VISION. Estos servicios son limitados a específicas emisoras y es posible que no estén disponibles en su área. (El ajuste de fábrica es CC1).

- 1 Oprima MENU y seleccione el menú de PREFERENCIAS.
- 2 Coloque el cursor en CAPTION VISION y oprima SELECT.
- 3 Oprima \blacklozenge y programe su televisor a una de las siguientes opciones:



Elija

Elija	Para mostrar
CCI, 2, 3 o 4	Un versión escrita del diálogo o los efectos de sonido de un programa. (El ajuste de fábrica es CCI).
TEXT 1, 2, 3 o 4	Información de emisora / estación que no está relacionado con el programa.
XDS (Servicio ampliado de datos)	Un tipo de programa, nombre, duración y siglas de canal.

- 4 Oprima DISPLAY.

Los subtítulos aparecerán, si la emisora ofrece este servicio.

- 5 Para desactivar CAPTION VISION, oprima DISPLAY hasta que aparezca DISPLAY OFF.

Notas

- La información escrita desaparecerá durante unos segundos si oprime el botón MUTING.
- La información escrita podrá aparecer con un cuadro blanco u otros errores si la recepción del canal es deficiente.

12

Uso del Menú de VIDEO

Ajustes de la imagen (VIDEO)

Puede cambiar el contraste, brillo, color, tinte y nitidez de la imagen.

- 1 Oprima MENU y seleccione el menú de VIDEO.



- 2 Oprima \blacklozenge para seleccionar la función que desea ajustar y oprima SELECT.



Consulte la tabla DESCRIPCIÓN DE FUNCIONES para una explicación de los ajustes que se pueden hacer.

DESCRIPCIÓN DE FUNCIONES

Función	Oprima \blacklozenge	Oprima \blacklozenge
CONTRASTE	Aumentar el contraste	Disminuir el contraste
BRILLO	Aumentar el brillo de la imagen	Disminuir el brillo de la imagen
COLOR	Aumentar el nivel de los colores	Disminuir el nivel de los colores
TINTE	Aumentar los tonos verdes	Disminuir los tonos verdes
NITIDEZ	Aumentar la nitidez de imagen	Suavizar la imagen

- 3 Oprima MENU para volver al programa de televisión.

Para reestablecer los niveles de video originales

Oprima RESET, cuando se encuentre en el menú de VIDEO.

13


Uso del Menú de AUDIO

Selección de Programas Estereofónicos o Bilingües (MTS)

Solo KV-21SB40C, 21SB40M, 21SB40P, 21SE40, 21SE40C

La función de Sonido Multicanal (MTS) permite disfrutar de sonido estereofónico (ESTEREO), un Segundo Programa de Audio (SAP) o de Sonido Monoaural, (MONO), cuando existe.

- 1 Oprima MENU y seleccione el menú AUDIO.
- 2 Oprima **▲** o **▼** en MTS y oprima SELECT.



- 3 Oprima **▲** o **▼** para seleccionar ESTEREO, SAP, o MONO y oprima SELECT.

Elija	Para
ESTEREO	Escuchar sonido estereofónico.
SAP	Escuchar programas bilingües y afines.
MONO	Reducir el ruido durante transmisiones estereofónicas deficientes.

Acceso directo a MTS

Oprima MTS en su control remoto para recorrer las opciones MTS.

Nota

- Si el televisor no tiene audio, puede ser la función SAP este seleccionada. Confirme la selección de AUDIO.

Solución de Problemas

En caso de un problema con su televisor, siga estas recomendaciones. Si el problema persiste, comuníquese con el concesionario Sony más cercano.

Problema	Sugerencia
Ausencia de imagen y sonido	<ul style="list-style-type: none"> • Asegúrese de que el cable eléctrico esté bien conectado. • Si la luz roja en la parte delantera del televisor centellea, llame al centro de servicio. • Compruebe si el ajuste TV/VIDEO es correcto: TV para ver la televisión y VIDEO para cintas de video (página 9). • Coloque las pilas del control remoto en la posición correcta. • Pruebe otro canal. Es posible que el problema se deba a la emisora.
Imagen defectuosa o ausencia de imagen, pero sonido adecuado	<ul style="list-style-type: none"> • Ajuste CONTRASTE en el menú VIDEO (pág. 13). • Ajuste BRILLO en el menú VIDEO (pág. 13). • Revise las conexiones de la antena o del cable (pág. 3).
Buena imagen, pero ausencia de sonido	<ul style="list-style-type: none"> • Oprima MUTING para que la palabra MUTING desaparezca de la pantalla (pág. 9). • Compruebe que el ajuste de AUDIO. Es posible que el función de SAP ha sido seleccionada. (pág. 14).
Ausencia de color	<ul style="list-style-type: none"> • Ajuste la opción COLOR del menú VIDEO (pág. 13). • Compruebe que no se trata de un programa en blanco y negro.
Si aparece sólo nieve en la pantalla	<ul style="list-style-type: none"> • Compruebe la función CABLE en el menú de PREFERENCIAS (pág. 8) • Revise las conexiones de la antena o del cable (pág. 3). • Compruebe si el canal está transmitiendo.
Lineas punteadas o rayas	<ul style="list-style-type: none"> • Ajuste la posición de la antena. • Mantenga el televisor alejado de otros aparatos electrónicos. Algunos aparatos electrónicos provocan ruidos eléctricos que pueden interferir con la recepción del televisor.
Imágenes dobles o "fantasmas"	<ul style="list-style-type: none"> • Compruebe su antena area o comuníquese con su proveedor del cable.
No se reciben los canales UHF utilizando una antena	<ul style="list-style-type: none"> • Compruebe si la función CABLE del menú de PREFERENCIAS está en NO (pág. 8) • Use AUTO PROGRAMACION para añadir los canales que no estén en la memoria del televisor (pág. 7).
No se reciben los canales de cable	<ul style="list-style-type: none"> • Compruebe si la opción CABLE del menú de PREFERENCIAS está en SI (pág. 8). • Use AUTO PROGRAMACION para añadir los canales que no estén en la memoria del televisor (pág. 7).
El control remoto no funciona	<ul style="list-style-type: none"> • Las pilas pueden estar descargadas; cámbielas (pág. 5).
El televisor necesita una limpieza	<ul style="list-style-type: none"> • Limpie el televisor con un paño suave y seco. No utilice solventes fuertes como adelgazador de pintura o bencina, que pueden dañar el acabado del mueble.
No se puede cambiar el canal	<ul style="list-style-type: none"> • Desactive la función FIJAR CANAL (página 11). • Utilice AUTO PROGRAMACION para añadir canales que no se encuentren en la memoria del televisor (página 7).

Correccion

Para el modelo KV-21XE40B, las opciones son equivalentes al model KV-21SE40A. Las diferencias en operación y especificación se indican en el texto siguiente:

En la pagina 2 de Advertencias, KV-21XE40B se puede alimentar con 120V-220V 50-60 Hz.

En la pagina 3, el modelo KV-21XE40B no tiene el boton de MAIN POWER. Usted puede encender el televisor oprimiendo TV POWER que se encuentra en el control remoto.


En la pagina 16, el modelo KV-21XE40B tiene las especificaciones siguientes:

Alimentacion:
Consumo de energia:


120-220V 50-50 Hz
En uso 105W
En espera 3W

SECTION 2 DISASSEMBLY


2-1. REAR COVER REMOVAL



2-2. A BOARD REMOVAL



2-3. SERVICE POSITION





2-4. PICTURE TUBE REMOVAL

WARNING Before removing anode cap:

H.V. remains in the CRT even after the power is disconnected.


To avoid electrical shock, discharge CRT before attempting to remove the anode cap : Short between anode and CRT coating earth ground strap.



• REMOVAL OF THE ANODE-CAP

NOTE: Short circuit the anode of the picture tube and the anode cap to the metal chassis, CRT shield or carbon painted on the CRT, after removing the anode.

• REMOVAL PROCEDURES




① Turn up one side of the rubber cap in the direction indicated by arrow ①.

② Use your thumb to pull the rubber cap firmly in the direction indicated by arrow ②.

③ When one side of the rubber cap separates from the anode button, the anode-cap can be removed by turning the rubber cap and pulling it in the direction of arrow ③.

• HOW TO HANDLE AN ANODE-CAP

- ① Do not use sharp objects which may cause damage to the surface of the anode-cap.
- ② Do not squeeze the rubber covering too hard to avoid damaging the anode-cap. A material fitting called a shatter-hook terminal is built into the rubber.
- ③ Do not force turn the foot of the rubber cover. This may cause the shatter-hook terminal to protrude and damage the rubber.



SECTION 3 SET-UP ADJUSTMENTS

The following adjustments should be made when a complete realignment is required or a new picture tube is installed. These adjustments should be performed with rated power supply voltage unless otherwise noted.

The controls and switch should be set as follows unless otherwise noted:

PICTURE control normal

BRIGHTNESS control normal

Perform the adjustments in order as follows:

1. Beam Landing
2. Convergence
3. Focus
4. Screen (G2) and White Balance

Note: Test Equipment Required

1. Color Bar Pattern Generator
2. Degausser
3. DC Power Supply
4. Digital Multimeter

3-1. BEAM LANDING

Preparation:

- Feed in the white pattern signal.
- Before starting, degauss the entire screen.

1. Input a raster signal with the pattern generator.
2. Loosen the deflection yoke mounting screw, and set the purity control to the center as shown in Fig.2.
3. Turn the raster signal of the pattern generator to green.
4. Move the deflection yoke backward, and adjust with the purity control so that green is in the center and red and blue are at the sides evenly. (Fig.3)
5. Move the deflection yoke forward, and adjust so that the entire screen becomes green. (Fig.1)
6. Switch over the raster signal to red and blue and confirm the condition.
7. When the position of the deflection yoke is determined, tighten it with the deflection yoke mounting screw.
8. When landing at the corner is not right, adjust by using the disk magnets. (Fig.4)




Fig. 2




Fig. 3




Fig. 1





Fig. 4

3-2. CONVERGENCE

Preparation:


- Before starting, perform FOCUS, V. LIN and V. SIZE adjustments.
- Set BRIGHTNESS control to minimum.
- Feed in dot pattern.

(1) Vertical Static Convergence




1. Adjust V. STAT magnet to converge red, green and blue dots in the center of the screen. (Vertical movement)

Tilt the V. STAT magnet and adjust static convergence to open or close the V. STAT magnet.





2. When the V. STAT magnet is moved in the direction of arrow (a) and (b), red, green, and blue dots move as shown below:



If the blue dot does not converge with red and green dots, perform the following steps:

- Move BMC magnet (a) to correct insufficient H. Static convergence.
- Rotate BMC magnet (b) to correct insufficient V. Static convergence.

In either case, repeat Beam Landing Adjustment.




(2) Dynamic Convergence Adjustment

Preparation:

- Before starting, perform Horizontal and Vertical Static Convergence Adjustment.

1. Slightly loosen deflection yoke screw.
2. Remove deflection yoke spacers.
3. Move the deflection yoke for best convergence as shown below. (Fig. 8)
4. Tighten the deflection yoke screw.
5. Install the deflection yoke spacers.



(3) Screen-corner Convergence





Fig. 9



Affix a permalloy assembly corresponding to the misconverged areas:



3-3. FOCUS

1. Adjust FOCUS control for best picture.




Fig. 10-A

3-4. SCREEN (G2)

1. Input a dots pattern.
2. Set the PICTURE and BRIGHT controls at minimum and COLOR control at normal.
3. Adjust SBRT, GCUT, BCUT in service mode with an oscilloscope as shown in Fig. 11 so that voltages on the red, green, and blue cathodes are: 170Vdc




Fig. 11

4. Observe the screen and adjust:


SCREEN (G2) VR
to obtain the faintly visible background of dot signal.

3-5. METHOD OF SETTING THE SERVICE ADJUSTMENT MODE

(1) SERVICE MODE PROCEDURE


1. Standby mode. (Power off)
2. **DISPLAY** → **5** → **VOL (+)** → **POWER** on the Remote Commander. (Press each button within a second.)

(2) SERVICE ADJUSTMENT MODE IN



3. The CRT displays the item being adjusted.
4. Press **1** or **4** on the Remote Commander to select the item.
5. Press **3** or **6** on the Remote Commander to change the data.
6. Press **MUTING** then **ENTER** to write into memory.

(3) SERVICE ADJUSTMENT MODE MEMORY



7. Turn set off and on to exit.

3-6. WHITE BALANCE ADJUSTMENTS

1. Input an entire white signal.
2. Set to Service adjustment Mode.
3. Set DCOL to "0"
4. Set the PICTURE and BRIGHT to minimum.
5. Adjust with SBRT if necessary.
6. Select GCUT and BCUT with **1** and **4**.
7. Adjust with **3** and **6** for the best white balance.
8. Set the PICTURE and BRIGHT to maximum.
9. Select GDRV and BDRV with **1** and **4**.
10. Adjust with **3** and **6** for the best white balance.
11. Reset DCOL to "1".
12. Write into the memory by pressing **MUTING** then **ENTER**.

SECTION 4 SAFETY RELATED ADJUSTMENTS

A BOARD

☒ R582 CONFIRMATION METHOD (HV HOLD-DOWN CONFIRMATION) AND READJUSTMENTS

The following adjustments should always be performed when replacing the following components which are marked with ☒ on the schematic diagram:

IC301, IC521, IC602, D572, D573, D574, DY,
C511, C574, C575, R578, R582, R583, R584,
R585, R586, R625, R626, R634, R635, T504 (FBT)

(1) Preparation before Confirmation


- 1) Turn the POWER switch ON. Input an entirely white signal and set the PICTURE and BRIGHT controls to maximum.
- 2) Confirm that the voltage between C574(+) and ground is more than: 99.8VDC
when the set is operating normally with 120.0-240.0 ± 2.0 VAC.

(2) Hold-down Operation Confirmation

- 1) Connect the current meter between Pin 11 of the FBT (T504) and the PCB land where Pin 11 would normally attach.
- 2) Input a dot signal and set PICTURE and BRIGHTNESS to minimum:
 $I_{ABL} = 95 + 100 / -95 \mu A$
- 3) Confirm the voltage of A board TP-600 is $116.8 \pm 0.3 VDC$
- 4) Connect the Digital Voltmeter and the DC power supply via diode 1SS119 to C574 (+). (See figure 1.0 on next page.)
- 5) Increase the DC power voltage gradually until the picture blanks out.
- 6) Read the digital voltmeter indication.
- 7) Turn DC power source off immediately.
STANDARD
Less than or equal to: 127.3 VDC
- 8) Input a white signal and set PICTURE and BRIGHTNESS to Max
- 9) Repeat steps from (4) to (7).
STANDARD
Less than or equal to: 127.3 VDC

(3) Hold-down Readjustment

If the current setting indicated in step 2-2 cannot be met, readjustment should be performed by altering the resistance value of R582, a component marked with ☒.



B+ VOLTAGE CONFIRMATION AND ADJUSTMENT

The following adjustments should always be performed when replacing the following components which are marked with ☒ on the schematic diagram:

IC001, IC602, R030, R626, R632,
R633, R635, R636, R637, R638, R639

- 1) Supply 130 ± 2.0 VAC to the set with a variable auto transformer.
- 2) Input a dot signal.
- 3) Set the PICTURE control and the BRIGHT control to minimum condition.
- 4) Set to service adjustment mode.
- 5) Select PADJ with [1] and [4].
- 6) Adjust with [6] to the 0 level.
- 7) Confirm the voltage of A BOARD TP-600 is less than 125V DC.
- 8) If step 7 is not satisfied, replace the components, repeat the above steps.
- 9) Supply 120.0 ± 2.0 VAC to the set with a variable auto transformer.
- 10) Adjust with [3] and [6] for: $116.8 \pm 0.3 V DC$
- 11) Write into the memory by pressing [MUTING] then [ENTER].

SECTION 5 CIRCUIT ADJUSTMENTS

5-1. ELECTRICAL ADJUSTMENT BY REMOTE COMMANDER

Use Remote Commander (RM-Y155) to perform circuit adjustments on this model.

NOTE : Test Equipment Required.

1. Pattern Generator
2. Frequency Counter
3. Digital Multimeter
4. Audio OSC

7. Press **8** then **ENTER** on the Remote Commander to initialize.




Carry out step 7 when adjusting IDs 0 to 4 and when replacing and adjusting IC003.

(1) Method of Setting the Service Adjustment Mode

SERVICE MODE PROCEDURE


1. Standby mode. (Power off)
2. **DISPLAY** → **5** → **VOL (+)** → **POWER** on the Remote Commander. (Press each button within a second.)

SERVICE ADJUSTMENT MODE IN



3. The CRT displays the item being adjusted.
4. Press **1** or **4** on the Remote Commander to select the item.
5. Press **3** or **6** on the Remote Commander to change the data.
6. Press **MUTING** then **ENTER** to write into memory.


SERVICE ADJUSTMENT MODE MEMORY



(2) Memory Write Confirmation Method

1. After adjustment, pull out the plug from the AC outlet, then replace the plug in the AC outlet again.
2. Turn the power switch ON and set to service mode.
3. Call the adjusted items again to confirm they were adjusted.

(3) Adjust Buttons and Indicator



RM-Y155

8. Turn set off and on to exit.

(4) Item of Adjustments

NO.	ITEM	FUNCTION	DATA RANGE	INITIAL DATA				AVERAGE DATA
				NTSC	PAL-M	PAL-N	VIDEO	
1	HSIZ	HORIZONTAL AMP. ADJ.	0-6.3	3.1	3.1	3.1		3.1
2	HPOS	HORIZONTAL POS. ADJ.	0-6.3	2.1	2.1	1.9		2.8
3	VBOW	VRT LINE BOWING ADJ.	0-1.5		6			8
4	VANG	VRT LINE BOW SLANT ADJ.	0-1.5		6			10
5	TRAP	HORIZ. TRAPEZOID ADJ.	0-1.5		1.5			1.5
6	PAMP	HORIZ. PIN DISTORTION ADJ.	0-6.3	3.1	3.1	3.1		3.1
7	CPIN	SAME AS PAMP-SCRN TP/BTM	0-6.3	3.1	3.1	3.1		3.1
8	VSIZ	VERTICAL AMP. ADJUST	0-6.3	4.3	4.3	4.7		4.4
9	VPOS	VERTICAL POSITION ADJ.	0-6.3	3.5	3.5	2.8		3.3
10	VLIN	VERTICAL LINEARITY ADJ.	0-1.5	7	7	7		5
11	SCOR	VERTICAL AMOUNT ADJ.	0-1.5	7	7	7		9
12	VZOM	16:9 CRT Z MODE ON/OFF	0,1		0			0
13	EHT	VRT HI-VOLT. CORRECTION	0-1.5		1.5			1.5
14	ASP	ASPECT RATIO CONTROL	0-6.3		4.7			4.7
15	SCRL	16:9 CRT Z MODE TRAN SCRL	0-6.3		3.1			3.1
16	HBLK	RGB OUT WIDTH CONTROL	0,1		1			1
17	LBLK	LEFT SCREEN HBLK CONTROL	0-1.5		1.5			1.5
18	RBLK	RGT SCREEN HBLK CONTROL	0-1.5		3			3
19	VUSN	V SAW WAVEFORM COMPRES	0,1		0			0
20	HDW	H. DRIVE PULSE WIDTH	0,1		0			0
21	EWDC	EW/DC ADJUST	0,1		0			0
22	LVLN	SCREEN BTM VRT LIN ADJUST	0-1.5		0			0
23	UVLN	SCREEN TOP VRT LIN ADJUST	0-1.5		0			0
24	RDRV	R OUTPUT DRIVE CONTROL	0-6.3		3.0			3.2
25	GDRV	G OUTPUT DRIVE CONTROL	0-6.3		2.4			2.8
26	BDRV	B OUTPUT DRIVE CONTROL	0-6.3		2.1			2.5
27	RCUT	R OUTPUT CUTOFF CONTROL	0-1.5		1.5			7
28	GCUT	G OUTPUT CUTOFF CONTROL	0-1.5		7			5
29	BCUT	B OUTPUT CUTOFF CONTROL	0-1.5		7			6
30	DCOL	DYNAMIC COLOR ON/OFF	0,1		0			1
31	SHUE	SUB HUE	0-3.1		1.5			1.5
32	SCOL	SUB COLOR	0-3.1	1.4	1.4	1.4		1.5
33	SBRT	SUB BRIGHTNESS	0-3.1		7			5
34	RON	R OUTPUT ON/OFF	0,1		1			1
35	GON	G OUTPUT ON/OFF	0,1		1			1
36	BON	B OUTPUT ON/OFF	0,1		1			1
37	AXPL	AXIS PAL	0,1		0			0
38	AXNT	AXIS NTSC	0,1		0			0
39	CBPF	CHROMA BPF ON/OFF	0,1		1			1
40	CTRP	Y TRAP FILTER ON/OFF	0,1		0,1:combfilter models			0
41	COFF	COLOR ON/OFF	0,1		0			0
42	KOFF	SET COLOR KILLER	0,1		0			0
43	SSHP	SUB SHARPNESS	0-1.5		1.0			1.0
44	SHPF	SHARPNESS CIRCUIT F0	0,1		1		1	1
45	PREL	PRE/OVR SHOOT SWITCHING	0,1		0			0
46	Y-DC	DC TRANS RATIO SWITCHING	0,1		1			1
47	GAMM	GAMMA CORRECTION AMNT	0-3		0			0
48	ABLM	ABL MODE SWITCHING	0,1		1			1
49	VTH	ABL C D VTH SWITCHING	0,1		1			1
50	YDEL	Y DELAY TIME CONTROL	0-1.5		7			7
51	NCOL	NO COLOR ID	0,1		1			1
52	FSC	FSC OUT ON/OFF	0,1		'1' for V series, '0' for S,M & trinorma			0
53	K-ID	KILLER ID CONTROL SW	0,1		0			0
54	HOSC	H VCO OSCILLATION FREQ	0-1.5		1.0			1.0
55	VSS	V SYNC SLICE LEVEL	0,1		0			0
56	HSS	H SYNC SLICE LEVEL	0,1		0			0
57	HMSK		0,1		1			1
58	VTMS	SELECT SIGNAL VTIM PIN	0-3		0			0
59	CDMD	V CNT DWN MODE SWITCHING	0-3		0		1	1
60	AFC	AFC LOOP GAIN SWITCHING	0-3		0		0	0
61	FIFR	FIELD FREQUENCY	0-3		'3' for NTSC models, '1' for trinorma			1
62	SBAL	SUB BALANCE	0-1.5		1.3			1.3
63	DISP	OSD POSITION	0-1.2.7		1.5			1.5
64	PADJ	POWER ADJUSTMENT	0-6.3		5.1			4.7

SERVICE ID0 25

Note: No. 1 through 64 show adjustment order.

(5) Feature ID Map

	KV-	DESTINATION	ID-0	ID-1	ID-2	ID-3	ID-4	ID-5
1	21XE40B	(E)	23	3	1	195	51	1

5-2. A BOARD ADJUSTMENTS

H. FREQUENCY ADJUSTMENT

1. Input a monoscope signal.
2. Set to Service adjustment Mode.
3. Connect a frequency counter to base of Q501 (TP-500 H. DRIVE).
4. Select the item of AFC, set to 3 level (free run).
5. Check H. Frequency for the 15650 ± 200 Hz.
6. Select the item of AFC again, adjust the level "0".
7. Write into the memory by pressing **MUTING** then **ENTER**.

V. FREQUENCY ADJUSTMENT


1. Select video 1 with no signal input.
2. Set the conditions with standard setting.
3. Connect the frequency counter across TP-508 or CN501 VDY (+) pin ⑥ connector and ground.
4. Check V. Frequency for the 50 ± 2 Hz.

SUB CONTRACT ADJUSTMENT (SCON)

1. Input a color-bar signal.
2. Select the red color.
3. Set to Service adjustment Mode.
4. Select the item DCOL to "0" level.
5. Set the conditions as follows.


PICTURE MAX
 COLOR MIN
 BRIGHT CENTER

R ON ON (1)
 G ON OFF (0)
 B ON OFF (0)



1: ON
 0: OFF

6. Connect an oscilloscope to CN1752 Pin ④ or (R OUT) of C Board and ground.
7. Select RDRV with **1** and **4**.
8. Adjust with **3** and **6** for: 1.70 ± 0.05 Vp-p.




9. Reset the item DCOL to "1" level.
10. Write the memory by pressing **MUTING** then **ENTER**.
11. Return the following back to normal after adjustment.

PICTURE MAX
 COLOR CENTER
 BRIGHT CENTER

R ON ON (1)
 G ON ON (1)
 B ON ON (1)

DISPLAY POSITION ADJUSTMENT (DISP)

1. Input a color-bar signal.
2. Set to Service adjustment Mode.
3. Select DISP with **1** and **4**.
4. Adjust with **3** and **6** for adjustment of characters to center.
5. Write the memory by pressing **MUTING** then **ENTER**.
6. Check if the text is displayed on the screen.




SUB BRIGHT ADJUSTMENT (SBRT)

1. Input a cross-hatch signal.
2. Set to Service adjustment Mode.
3. Set the PICTURE and BRIGHT to minimum.
4. Select SBRT with **1** and **4**.
5. Adjust with **3** and **6** to obtain a faintly visible cross-hatch.
6. Write into the memory by pressing **MUTING** then **ENTER**.

SUB HUE, SUB COLOR ADJUSTMENT (SHUE, SCOL)

1. Input a color-bar signal.
2. Set to Service adjustment Mode.

3. Select the item DCOL and set to "0" level.
4. Connect an oscilloscope to CN1752 Pin ⑥ (BLUE OUT) of C Board and ground.
5. Select SHUE and SCOL with **[1]** and **[4]**.
6. Adjust with **[3]** and **[6]** for the $V1 = V4 \pm 0.1V_{p-p}$ (SCOL) and $V2 = V3 \pm 0.1V_{p-p}$ (SHUE).




7. Reset the item DCOL to "1" level.
8. Write into the memory by pressing **[MUTING]** then **[ENTER]**.

V. SIZE ADJUSTMENT (VSIZ)

1. Input a cross-hatch signal.
2. Set to Service adjustment mode.
3. Select VSIZ with **[1]** and **[4]**.
4. Adjust with **[3]** and **[6]** for the best vertical size.


V. SIZE (VSIZ)



V. CENTER ADJUSTMENT (VPOS)

1. Input a cross-hatch signal.
2. Set to Service adjustment Mode.
3. Select VPOS with **[1]** and **[4]**.
4. Adjust with **[3]** and **[6]** for the best vertical center.
5. Write into the memory by pressing **[MUTING]** then **[ENTER]**.

V. CENTER (VPOS)




H. CENTER ADJUSTMENT (HPOS)

Note : Perform this adjustment after checking H. FREQUENCY.


1. Input a cross-hatch signal.
2. Set the Service adjustment Mode.
3. Select HPOS with **[1]** and **[4]**.
4. Adjust with **[3]** and **[6]** for the best horizontal center.
5. Write into the memory by pressing **[MUTING]** then **[ENTER]**.

H. CENTER (HPOS)



V. LINEARITY (VLIN) AND V CORRECTION


1. Input a cross-hatch signal.
2. V. Correction is automatically adjusted from the circuit and should satisfy the conditions below:




SERVICE ADJUSTMENT MODE MEMORY

1. Change DCOL to "1".
2. After completing all adjustments, press "0" then **[ENTER]**.

READ FROM MEMORY



6-2. Circuit Boards Location










6-3. Printed Wiring Boards and Schematic Diagrams

Note:




- All capacitors are in μF unless otherwise noted. pF : $\mu\mu\text{F}$ 50WV or less are not indicated except for electrolytic and tantalums.
- All electrolytics are 50V unless otherwise specified
- Indication of resistance, which does not have one for rating electrical power, is as follows:

Pitch: 5mm
Rating electrical power 1/4W


- All resistors are in ohms.
 $\text{K}\Omega=1000\Omega$, $\text{M}\Omega=1000\text{K}\Omega$
-  nonflammable resistor.
- Δ : internal component.
- : panel designation and adjustment for repair.
- All variable and adjustable resistors have characteristic curve B, unless otherwise noted.
- The components identified by  in this manual have been carefully factory-selected for each set in order to satisfy regulations regarding X-ray radiation. Should replacement be required, replace only with the value originally used.
- When replacing components identified by  make the necessary adjustments indicated. If results do not meet the specified value, change the component identified by  and repeat the adjustment until the specified value is achieved. (Refer to R582 on pages 21 and 22).
- When replacing parts in the table below be sure to perform the related adjustment.

Part replaced ()	Adjustment ()
IC301, IC521, IC602, D572, D573, D574, DY, C511, C574, C575, R578, R582, R583, R584, R585, R586, R625, R626, R634, R635, T504 (FBT)	HV HOLD-DOWN (R582)
IC001, IC602, R030, R626, R632, R633, R635, R636, R637, R638, R639	B+ VOLTAGE CONFIRMATION

- All voltages are in V.
- Voltage is DC with respect to ground unless otherwise noted.
- Readings are taken with a 10M Ω digital multimeter.
- Readings are taken with a color-bar signal input.
- Voltage variations may be noted due to normal production tolerance.
- Circled numbers are waveform references.


-  : B + Line
-  : B - Line
-  : signal path

Reference Information

RESISTOR	: RN	METAL FILM
	: RC	SOLID
	: FPRD	NON FLAMMABLE CARBON
	: FUSE	NON FLAMMABLE FUSIBLE
	: RW	NON FLAMMABLE WIREWOUND
	: RS	NON FLAMMABLE METAL OXIDE
	: RB	NON FLAMMABLE CEMENT
	: 	ADJUSTMENT RESISTOR
COIL	: LF-8L	MICRO INDUCTOR
CAPACITOR	: TA	TANTALUM
	: PS	STYROL
	: PP	POLYPROPYLENE
	: PT	MYLAR
	: MPS	METALIZED POLYESTER
	: MPP	METALIZED POLYPROPYLENE
	: ALB	BIPOLAR
	: ALT	HIGH TEMPERATURE
	: ALR	HIGH RIPPLE


Note: The symbol  display is on the component side.

The components identified by shading and mark Δ are critical for safety. Replace only with part number specified.


The symbol  indicates fast operating fuse. Replace only with fuse of same rating as marked.

A BOARD IC VOLTAGE LIST


IC001		IC002		7	2.0	10	6.0
pin	volt	pin	volt	8	5.0	11	6.0
1	0.4	1	GND	9	5.2	12	GND
2	4.9	2	5.0	10	GND	13	6.0
3	0.60	3	4.9	11	3.8	IC521	
4	3.0	4	12.0	12	2.5	pin	volt
5	0.0	5	5.0	13	3.6	1	12.5
6	0.3	6	GND	14	3.5	2	0.9
7	NC	7	N/A	15	5.9	3	1.0
8	NC	8	0	16	7.7	4	GND
9	NC	IC003		17	0.7	5	8.7
10	0.1	pin	volt	18	3.5	6	9.7
11	0.1	1	GND	19	2.9	7	1.3
12	5.0	2	GND	20	2.7	8	13.0
13	0	3	GND	21	2.2	IC541	
14	5.0	4	GND	22	1.9	pin	volt
15	NC	5	4.8	23	1.7	1	2.4
16	0.0	6	4.8	24	1.8	2	13.0
17	-0.3	7	GND	25	0.1	3	-11.3
18	5.0	8	5.0	26	4.0	4	-13
19	5.0	IC004		27	4.02	5	0.3
20	2.0	pin	volt	28	4.0	6	13.7
21	0	1	3.3	29	0	7	2.4
22	2.2	2	5.0	30	4.6	IC601	
23	0	3	0	31	4.6	pin	volt
24	2.4	IC200		32	4.6	1	1.7
25	2.4	pin	volt	33	9.0	2	0.1
26	GND	1	5.9	34	4.8	3	154.6
27	5.0	2	0.3	35	4.8	4	18.0
28	NC	3	6.1	36	0	5	GND
29	NC	4	0.3	37	4.0	IC 602	
30	5.0	5	6.1	38	4.7	pin	volt
31	5.1	6	9.0	39	4.7	1	2.5
32	NC	7	5.2	40	GND	2	GND
33	5.0	8	GND	41	5.2	3	9.5
34	2.6	IC201		42	7.4	TU101	
35	NC	pin	volt	43	5.2	pin	volt
36	4.8	1	6.0	44	9.0	1	9.0
37	4.8	2	0.3	45	5.3	2	30
38	4.8	3	6.1	46	0	3	5.1
39	4.8	4	0.3	47	2.5	4	4.9
40	NC	5	6.1	48	0	5	4.8
41	0	6	9.0	IC401		6	0
42	0.1	7	5.2	pin	volt	7	7.3
43	5.0	8	GND	1	0.8	8	1.6
44	0.1	IC301		2	NC	9	9.0
45	4.9	pin	volt	3	2.4	10	3.6
46	NC	1	3.50	4	12.6	11	0
48	NC	2	5.2	5	2.4	17	4.6
49	0	3	1.4	6	GND	18	4.4
50	0	4	5.2	7	0.8	19	5.0
51	0	5	5.0	8	6.0	20	0.4
52	0	6	4.5	9	GND	21	0
						22	0.3
						23	0
						24	0
						25	0
						26	4.5
						27	4.5



A BOARD : IC401 TDA7057Q




A BOARD : IC541 TDA8172



A BOARD : IC200, 201 NJM2521M

• A BOARD WAVEFORMS



A BOARD TRANSISTOR VOLTAGE LIST

	B	C	E
Q001	5.2	0.7	5.0
Q002	0.7	0.3	0
Q202	0.02	0.7	GND
Q203	1.8	GND	0.7
Q204	0	0.7	GND
Q205	4.6	GND	5.2
Q300	0.4	2.7	GND
Q301	3.7	2.3	3.8
Q302	3.7	GND	3.8
Q305	3.8	GND	4.4
Q390	4.6	9.0	3.9
Q391	4.5	9.0	3.8
Q392	1.8	GND	2.5
Q393	1.7	GND	2.4
Q394	1.9	GND	2.5
Q501	-0.7	47.0	GND
Q502	0	109	GND
Q571	112.5	6.5	113.1
Q601	0	0	GND
Q602	1.0	3.7	0.4
Q604	0.1	2.7	GND
Q605	9.7	9.8	9.0
Q608	31.7	32.4	31.5
Q650	5.7	9.0	5.1
Q670	0.7	0.3	0

All voltages are in V

A BOARD TRANSISTOR VOLTAGE LIST

	D	G	S
Q607	115.2	32.5	31.5


All voltages are in V

A BOARD

SEMICONDUCTOR LOCATION

DIODE		IC	
D001	G-10	IC001	I-10
D002	G-12	IC002	I-12
D003	I-8	IC003	J-11
D004	I-9	IC004	G-13
D038	I-11	IC200	G-3
D090	H-10	IC201	H-4
D201	H-3	IC301	H-9
D202	G-3	IC401	F-6
D203	J-13	IC521	F-4
D204	J-12	IC541	E-4
D205	G-3	IC601	B-9
D208	E-10	IC602	E-8
D209	J-12	TRANSISTOR	
D210	I-2	Q001	G-10
D302	G-8	Q002	H-9
D310	H-9	Q202	F-7
D311	H-9	Q203	F-10
D403	F-11	Q204	F-10
D502	D-4	Q205	I-6
D541	F-4	Q300	G-9
D552	D-3	Q301	H-8
D561	D-2	Q302	G-8
D562	D-1	Q305	H-10
D571	D-3	Q390	J-6
D572	F-3	Q391	G-7
D573	F-3	Q392	H-10
D574	F-4	Q393	G-9
D581	F-3	Q394	G-9
D601	C-10	Q501	D-6
D602	E-10	Q502	B-6
D603	E-11	Q571	E-3
D605	D-10	Q601	E-9
D609	A-9	Q602	G-10
D610	B-10	Q604	F-9
D611	D-7	Q605	D-8
D613	C-8	Q607	A-12
D614	C-8	Q608	A-12
D615	A-16	Q650	H-6
D616	B-7	Q670	E-10
D617	C-7		
D620	B-6		
D631	C-11		
D632	B-11		
D633	B-12		
D634	A-13		
D635	A-13		
D636	C-12		
D637	A-13		
D638	A-13		
D650	H-7		

• C BOARD WAVEFORMS



C BOARD IC VOLTAGE LIST

IC1751	
pin	volt
1	2.3
2	2.1
3	2.3
4	0
5	3.8
6	202.5
7	139.3
8	150.4
9	141.8

All voltages are in V


C BOARD TRANSISTOR VOLTAGE LIST

	B	C	E
Q1751	0.7	0.1	0


All voltages are in V

6-4. SEMICONDUCTORS

2SA1162-G
2SD601A-Q
2SB709A-QRS-TX




2SA1175-HFE
2SC2785-HFE




2SC3209LK
2SD1312-K
2SD774-34




2SK2845-LB102




2SC5426-01




MA111




D3SB60F




D10SC4M




D2S4MF




D1N20R
RD6.2ESB2
RD8.23SB2
MTZJ-5.1C
RD5.6ESB2
RD10ESB2
MTZJ-30D
RD3.3ESB2



U05G
D1NL40-TA2
ERA22-08TP3
LNK0120022G
1SS133T-77
ERC06-15S
MDV04-600
S2L60F
EZ0150AV1



D1NL20-TA
EGP20G
EL1Z
1SS83



SECTION 7 EXPLODED VIEWS

• Items with no part number and no description are not stocked because they are seldom required for routine service

• The component parts of an assembly are indicated by the reference numbers in the remarks column.

• Items marked " * " are not stocked since they are seldom required for routine service. Some delay should be anticipated when ordering these items.


Note:

The components identified with gray shading and a critical symbol (Δ) are critical for safety. Replace only with part number specified.

Note:

Les composants identifiés par un trame et une marque Δ sont critiques pour la sécurité. Ne les remplacer que par une pièce portant le numéro spécifié.

7-1. CHASSIS



REF.NO.	PART NO.	DESCRIPTION	REMARK	REF.NO.	PART NO.	DESCRIPTION	REMARK
1	4-046-161-01	EMBLEM (NO.8) SONY		17	* A-1298-700-A	A BOARD, COMPLETE	
2	X-4035-232-1	BEZNET, ASSY	3-5	18	Δ 1-453-283-11	TRANSFORMER ASSY, FLYBACK (NX-1744//X4E4)	
3	4-062-604-01	DOOR		19	Δ 8-598-431-10	TUNER BTF-WA411	
4	4-062-607-01	GUIDE, LED		20	1-766-374-11	PLUG, F PIN	
5	4-062-603-01	BUTTON, MULTI		21	Δ 1-769-796-71	CORD, POWER (WITH CONNECTOR)	
6	1-505-930-11	SPEAKER (9x5 cm)		22	1-452-032-00	MAGNET, DISC	
7	Δ 8-738-768-05	CRT 21NX		23	4-051-735-22	PIECE (A) 75 CONVERSION CORRECTION	
8	4-365-808-01	SCREW (5), TAPPING		24	3-704-372-31	HOLDER, HV	
9	Δ 8-451-440-21	DY Y21NXA-X					
10	4-053-005-01	SPACER, DY					
11	1-452-277-00	MAGNET, BMC					
12	* A-1331-867-A	C BOARD, MOUNTED					
13	* 4-375-394-01	SPRING, TENSION					
14	Δ 1-411-941-11	COIL, DEMAGNETIZATION					
16	4-062-602-01	REAR COVER					

Note: The components identified by shading and mark Δ are critical for safety. Replace only with part number specified.

Note: Les composants identifiés par un trame et une marque Δ sont critiques pour la sécurité. Ne les remplacer que par une pièce portant le numéro spécifié.

A

REF.NO.	PART NO.	DESCRIPTION	REMARK	REF.NO.	PART NO.	DESCRIPTION	REMARK
CN502 *	1-564-509-11	PLUG, CONNECTOR	6P	D633	8-719-948-45	DIODE ERA22-08	
CN601 *	1-580-843-11	PIN, CONNECTOR (POWER)		D634	8-719-991-33	DIODE 1SS133T-77	
CN602	1-508-786-00	PIN, CONNECTOR (5MM PITCH)	2P	D635	8-719-991-33	DIODE 1SS133T-77	
DIODE				D636	8-719-063-70	DIODE D1NL20U	
D001	8-719-921-44	DIODE MTZJ-5.1C		D637	8-719-109-93	DIODE RD6.2ESB2	
D002	1-810-039-21	LED UNIT		D638	8-719-510-48	DIODE D1N20R	
D003	8-719-991-33	DIODE 1SS133T-77		D650	8-719-109-89	DIODE RD5.6ESB2	
D004	8-719-991-33	DIODE 1SS133T-77		FUSE			
D038	8-719-109-89	DIODE RD5.6ESB2		F601 Δ	1-532-506-51	FUSE	6.3A/250V
D090	8-719-404-49	DIODE MA111		FERRITE BEAD			
D201	8-719-110-17	DIODE RD10ESB2		FB501	1-410-396-41	FERRITE	0.45UH
D202	8-719-110-17	DIODE RD10ESB2		FB600	1-410-397-21	FERRITE	1.1UH
D203	8-719-110-17	DIODE RD10ESB2		FB601	1-410-397-21	FERRITE	1.1UH
D204	8-719-110-17	DIODE RD10ESB2		FB602	1-410-397-21	FERRITE	1.1UH
D205	8-719-982-22	DIODE MTZJ-30D		FB603	1-412-911-11	FERRITE	
D208	8-719-110-17	DIODE RD10ESB2		FB604	1-410-397-21	FERRITE	1.1UH
D209	8-719-110-17	DIODE RD10ESB2		FB605	1-410-397-21	FERRITE	1.1UH
D210	8-719-110-17	DIODE RD10ESB2		FB606	1-410-397-21	FERRITE	1.1UH
D302	8-719-921-44	DIODE MTZJ-5.1C		IC			
D310	8-719-404-49	DIODE MA111		IC001	8-759-540-75	IC M37273M8-204SP	
D311	8-719-404-49	DIODE MA111		IC002	8-759-371-21	IC MM1319AFBE	
D403	8-719-991-33	DIODE 1SS133T-77		IC003	8-759-527-74	IC M24C02-MN6T	
D502	8-719-302-43	DIODE EL1Z		IC004	8-742-014-11	HYB IC SBX1981-51	
D541	8-719-908-03	DIODE GP08D		IC200	8-759-450-93	IC NJM2521M-TE1	
D552	8-719-302-43	DIODE EL1Z		IC201	8-759-450-93	IC NJM2521M-TE1	
D561	8-719-979-85	DIODE EGP20G		IC301	8-752-082-35	IC CXA2060AS	
D562	8-719-979-85	DIODE EGP20G		IC401	8-759-490-17	IC TDA7057AQ/N2	
D571 Δ	8-719-991-33	DIODE 1SS133T-77		IC521 Δ	8-759-100-96	IC UPC4558G2	
D572	8-719-991-33	DIODE 1SS133T-77		IC541	8-759-980-58	IC TDA8172	
D573	8-719-110-08	DIODE RD8.2ESB2		IC601 Δ	8-749-013-75	IC STR-F6654	
D574 Δ	8-719-302-43	DIODE EL1Z		IC602 Δ	8-759-198-31	IC UPC1093J-1-T	
D581 Δ	8-719-991-33	DIODE 1SS133T-77		JACK			
D601	8-719-063-70	DIODE D1NL20U		J201	1-580-443-11	JACK, PIN	3P
D602	8-719-991-33	DIODE 1SS133T-77		J202	1-691-110-11	JACK, PIN	3P
D603	8-719-991-33	DIODE 1SS133T-77		J400	1-568-267-21	JACK	
D605 Δ	8-719-510-51	DIODE D3SB60F		CHIP CONDUCTOR			
D609	8-719-311-31	DIODE RU-1P		JR001	1-216-295-91	SHORT	
D610	8-719-510-02	DIODE D1NS4		JR002	1-216-295-91	SHORT	
D611	8-719-110-17	DIODE RD10ESB2					
D613	8-719-063-70	DIODE D1NL20U					
D614	8-719-063-70	DIODE D1NL20U					
D615	8-719-312-10	DIODE RU4AM-T3					
D616	8-719-510-73	DIODE S3L20UF4					
D617	8-719-027-43	DIODE S2L20UF					
D620 Δ	8-719-057-52	DIODE EZ0150AV1					
D631	8-719-911-55	DIODE U05G					
D632	8-719-911-55	DIODE U05G					



Note: The components identified by shading and mark Δ are critical for safety. Replace only with part number specified.

Note: Les composants identifiés par un trame et une marque Δ sont critiques pour la sécurité. Ne les remplacer que par une pièce portant le numéro spécifié.

REF.NO.	PART NO.	DESCRIPTION	REMARK	REF.NO.	PART NO.	DESCRIPTION	REMARK
<u>COIL</u>				<u>RESISTOR</u>			
L001	1-410-470-11	INDUCTOR	10UH	Q650	8-729-111-55	TRANSISTOR	2SD1312-K
L002	1-412-032-11	INDUCTOR CHIP	100UH	Q670	8-729-140-96	TRANSISTOR	2SD774-34
L003	1-412-032-11	INDUCTOR CHIP	100UH				
L150	1-412-032-11	INDUCTOR CHIP	100UH				
L151	1-412-029-11	INDUCTOR CHIP	10UH				
L160	1-412-029-11	INDUCTOR CHIP	10UH	R001	1-249-429-11	CARBON	10K 5% 1/4W
L301	1-412-031-11	INDUCTOR CHIP	47UH	R002	1-249-429-11	CARBON	10K 5% 1/4W
L302	1-412-029-11	INDUCTOR CHIP	10UH	R003	1-216-033-00	RES, CHIP	220 5% 1/10W
L503	1-412-553-11	INDUCTOR	3.3MMH	R004	1-216-073-00	RES, CHIP	10K 5% 1/10W
L504	1-412-533-21	INDUCTOR	47UH	R005	1-247-815-91	CARBON	220 5% 1/4W
L591 Δ	1-412-531-31	INDUCTOR	33UH	R007	1-216-025-91	RES, CHIP	100 5% 1/10W
<u>PHOTO COUPLER</u>				R008	1-216-033-00	RES, CHIP	220 5% 1/10W
PH600	8-749-010-64	PHOTO COUPLER	PC123F2	R009	1-247-815-91	CARBON	220 5% 1/4W
<u>IC LINK</u>				R010	1-216-033-00	RES, CHIP	220 5% 1/10W
PS201	1-532-984-11	LINK, IC	2A/90V	R011	1-247-815-91	CARBON	220 5% 1/4W
<u>TRANSISTOR</u>				R013	1-247-863-91	CARBON	22K 5% 1/4W
Q001	8-729-216-22	TRANSISTOR	2SA1162-G	R016	1-249-413-11	CARBON	470 5% 1/4W
Q002	8-729-216-22	TRANSISTOR	2SA1162-G	R017	1-216-113-00	RES, CHIP	470K 5% 1/10W
Q202	8-729-422-27	TRANSISTOR	2SD601A-Q	R018	1-249-417-11	CARBON	1K 5% 1/4W
Q203	8-729-216-22	TRANSISTOR	2SA1162-G	R019	1-249-425-11	CARBON	4.7K 5% 1/4W
Q204	8-729-422-27	TRANSISTOR	2SD601A-Q	R020	1-249-427-11	CARBON	6.8K 5% 1/4W
Q205	8-729-216-22	TRANSISTOR	2SA1162-G	R021	1-249-415-11	CARBON	680 5% 1/4W
Q300 Δ	8-729-422-27	TRANSISTOR	2SD601A-Q	R022	1-249-416-11	CARBON	820 5% 1/4W
Q301	8-729-216-22	TRANSISTOR	2SA1162-G	R023	1-249-421-11	CARBON	2.2K 5% 1/4W
Q302	8-729-216-22	TRANSISTOR	2SA1162-G	R025	1-249-426-11	CARBON	5.6K 5% 1/4W
Q305	8-729-216-22	TRANSISTOR	2SA1162-G	R026	1-249-426-11	CARBON	5.6K 5% 1/4W
Q390	8-729-422-27	TRANSISTOR	2SD601A-Q	R027	1-249-426-11	CARBON	5.6K 5% 1/4W
Q391	8-729-422-27	TRANSISTOR	2SD601A-Q	R028	1-216-049-91	RES, CHIP	1K 5% 1/10W
Q392	8-729-216-22	TRANSISTOR	2SA1162-G	R030	1-249-429-11	CARBON	10K 5% 1/4W
Q393	8-729-216-22	TRANSISTOR	2SA1162-G	R031	1-216-045-00	RES, CHIP	680 5% 1/10W
Q394	8-729-216-22	TRANSISTOR	2SA1162-G	R032	1-216-033-00	RES, CHIP	220 5% 1/10W
Q501	8-729-140-50	TRANSISTOR	2SC3209LK	R033	1-247-815-91	CARBON	220 5% 1/4W
Q502 Δ	8-729-043-43	TRANSISTOR	2SC5426-01	R038	1-216-049-91	RES, CHIP	1K 5% 1/10W
Q571 Δ	8-729-200-17	TRANSISTOR	2SA1091-O	R040	1-249-413-11	CARBON	470 5% 1/4W
Q601	8-729-119-78	TRANSISTOR	2SC2785-HFE	R043	1-249-417-11	CARBON	1K 5% 1/4W
Q602	8-729-422-27	TRANSISTOR	2SD601A-Q	R044	1-216-033-00	RES, CHIP	220 5% 1/10W
Q604	8-729-111-55	TRANSISTOR	2SD1312-K	R045	1-216-065-91	RES, CHIP	4.7K 5% 1/10W
Q605	8-729-423-99	TRANSISTOR	2SD2137-OP	R046	1-216-033-00	RES, CHIP	220 5% 1/10W
Q607	8-729-044-30	TRANSISTOR	SK2845-LB102	R047	1-216-065-91	RES, CHIP	4.7K 5% 1/10W
Q608	8-729-119-78	TRANSISTOR	2SC2785-HFE	R048	1-216-025-91	RES, CHIP	100 5% 1/10W
				R049	1-216-089-91	RES, CHIP	47K 5% 1/10W
				R050	1-249-429-11	CARBON	10K 5% 1/4W
				R051	1-216-033-00	RES, CHIP	220 5% 1/10W
				R054	1-216-073-00	RES, CHIP	10K 5% 1/10W
				R056	1-249-425-11	CARBON	4.7K 5% 1/4W
				R057	1-216-065-91	RES, CHIP	4.7K 5% 1/10W
				R058	1-216-065-91	RES, CHIP	4.7K 5% 1/10W
				R065	1-216-033-00	RES, CHIP	220 5% 1/10W



Note: The components identified by shading and mark **△** are critical for safety. Replace only with part number specified.

Note: Les composants identifiés par un trame et une marque **△** sont critiques pour la sécurité. Ne les remplacer que par une pièce portant le numéro spécifié.

REF.NO.	PART NO.	DESCRIPTION	REMARK	REF.NO.	PART NO.	DESCRIPTION	REMARK
R066	1-216-033-00	RES, CHIP	220 5% 1/10W	R261	1-216-097-91	RES, CHIP	100K 5% 1/10W
R070	1-249-425-11	CARBON	4.7K 5% 1/4W	R262	1-216-025-91	RES, CHIP	100 5% 1/10W
R071	1-249-425-11	CARBON	4.7K 5% 1/4W	R268	1-216-065-91	RES, CHIP	4.7K 5% 1/10W
R072	1-247-815-91	CARBON	220 5% 1/4W	R269	1-216-065-91	RES, CHIP	4.7K 5% 1/10W
R073	1-249-425-11	CARBON	4.7K 5% 1/4W	R280	1-216-022-00	RES, CHIP	75 5% 1/10W
R074	1-216-073-00	RES, CHIP	10K 5% 1/10W	R284	1-216-295-91	SHORT	
R075	1-216-073-00	RES, CHIP	10K 5% 1/10W	R290	1-216-025-91	RES, CHIP	100 5% 1/10W
R076	1-216-121-91	RES, CHIP	1M 5% 1/10W	R300	1-216-295-91	SHORT	
R077	1-216-097-91	RES, CHIP	100K 5% 1/10W	R301	1-216-295-91	SHORT	
R081	1-249-413-11	CARBON	470 5% 1/4W	R302	1-216-295-91	SHORT	
R085	1-216-073-00	RES, CHIP	10K 5% 1/10W	R304	1-216-073-00	RES, CHIP	10K 5% 1/10W
R086	1-216-073-00	RES, CHIP	10K 5% 1/10W	R306	1-216-675-11	METAL CHIP	10K 0.50% 1/10W
R087	1-216-045-00	RES, CHIP	680 5% 1/10W	R307	1-216-075-00	RES, CHIP	12K 5% 1/10W
R088	1-216-045-00	RES, CHIP	680 5% 1/10W	R310	1-216-049-91	RES, CHIP	1K 5% 1/10W
R089	1-216-045-00	RES, CHIP	680 5% 1/10W	R312	1-216-033-00	RES, CHIP	220 5% 1/10W
R090	1-249-429-11	CARBON	10K 5% 1/4W	R313	1-247-815-91	CARBON	220 5% 1/4W
R091	1-249-429-11	CARBON	10K 5% 1/4W	R314	1-247-815-91	CARBON	220 5% 1/4W
R092	1-216-051-00	RES, CHIP	1.2K 5% 1/10W	R315	1-247-815-91	CARBON	220 5% 1/4W
R096	1-216-045-00	RES, CHIP	680 5% 1/10W	R316	1-216-025-91	RES, CHIP	100 5% 1/10W
R099	1-249-425-11	CARBON	4.7K 5% 1/4W	R318	1-216-073-00	RES, CHIP	10K 5% 1/10W
R101	1-216-073-00	RES, CHIP	10K 5% 1/10W	R319	1-216-073-00	RES, CHIP	10K 5% 1/10W
R150	1-216-025-91	RES, CHIP	100 5% 1/10W	R320	8-719-976-99	DIODE DTZ5.1B	
R151	1-216-025-91	RES, CHIP	100 5% 1/10W	R321	1-216-069-00	RES, CHIP	6.8K 5% 1/10W
R201	1-216-113-00	RES, CHIP	470K 5% 1/10W	R322	1-216-073-00	RES, CHIP	10K 5% 1/10W
R202	1-216-113-00	RES, CHIP	470K 5% 1/10W	R324	1-249-425-11	CARBON	4.7K 5% 1/4W
R204	1-216-022-00	RES, CHIP	75 5% 1/10W	R329	1-216-025-91	RES, CHIP	100 5% 1/10W
R205	1-247-895-91	CARBON	470K 5% 1/4W	R330	1-216-025-91	RES, CHIP	100 5% 1/10W
R206	1-247-895-91	CARBON	470K 5% 1/4W	R331	1-216-025-91	RES, CHIP	100 5% 1/10W
R230	1-216-073-00	RES, CHIP	10K 5% 1/10W	R347	1-216-045-00	RES, CHIP	680 5% 1/10W
R231	1-216-073-00	RES, CHIP	10K 5% 1/10W	R356	1-216-057-00	RES, CHIP	2.2K 5% 1/10W
R234	1-216-057-00	RES, CHIP	2.2K 5% 1/10W	R383	1-216-057-00	RES, CHIP	2.2K 5% 1/10W
R235	1-216-057-00	RES, CHIP	2.2K 5% 1/10W	R384	1-216-057-00	RES, CHIP	2.2K 5% 1/10W
R237	1-247-815-91	CARBON	220 5% 1/4W	R385	1-216-057-00	RES, CHIP	2.2K 5% 1/10W
R238	1-249-417-11	CARBON	1K 5% 1/4W	R390	1-216-025-91	RES, CHIP	100 5% 1/10W
R239	1-247-815-91	CARBON	220 5% 1/4W	R391	1-216-049-91	RES, CHIP	1K 5% 1/10W
R240	1-249-417-11	CARBON	1K 5% 1/4W	R392	1-216-025-91	RES, CHIP	100 5% 1/10W
R241	1-216-065-91	RES, CHIP	4.7K 5% 1/10W	R393	1-216-049-91	RES, CHIP	1K 5% 1/10W
R242	1-249-434-11	CARBON	27K 5% 1/4W	R394	1-216-025-91	RES, CHIP	100 5% 1/10W
R243	1-216-689-11	RES, CHIP	39K 5% 1/10W	R400	1-247-863-91	CARBON	22K 5% 1/4W
R251	1-216-041-00	RES, CHIP	470 5% 1/10W	R432	1-247-854-11	CARBON	9.1K 5% 1/4W
R252	1-216-041-00	RES, CHIP	470 5% 1/10W	R501	1-249-421-11	CARBON	2.2K 5% 1/4W
R253	1-215-899-11	METAL OXIDE	15K 5% 2W F	R502 △	1-215-923-00	METAL OXIDE	10K 5% 3W F
R254	1-216-025-91	RES, CHIP	100 5% 1/10W	R508 △	1-215-864-00	METAL OXIDE	150 5% 1W F
R255	1-216-025-91	RES, CHIP	100 5% 1/10W	R532	1-215-437-00	METAL	4.7K 1% 1/4W
R256	1-249-425-11	CARBON	4.7K 5% 1/4W	R533	1-215-461-00	METAL	47K 1% 1/4W
R257	1-216-073-00	RES, CHIP	10K 5% 1/10W	R534	1-215-453-00	METAL	22K 1% 1/4W
R258	1-249-429-11	CARBON	10K 5% 1/4W	R535	1-249-441-11	CARBON	100K 5% 1/4W
R259	1-216-073-00	RES, CHIP	10K 5% 1/10W	R541	1-216-065-91	RES, CHIP	4.7K 5% 1/10W
R260	1-216-097-91	RES, CHIP	100K 5% 1/10W	R542	1-249-429-11	CARBON	10K 5% 1/4W

Note: The components identified by shading and mark Δ are critical for safety. Replace only with part number specified.

Note: Les composants identifiés par un trame et une marque Δ sont critiques pour la sécurité. Ne les remplacer que par une pièce portant le numéro spécifié.



REF.NO.	PART NO.	DESCRIPTION	REMARK
<u>THERMISTOR</u>			
THP601	1-808-059-31	THERMISTOR, POSITIVE	
<u>TUNER</u>			
TU101	Δ 8-598-431-10	TUNER, FSS BTF-WA411	
<u>VARISTOR</u>			
VDR601	Δ 1-809-267-41	VARISTOR ERZV10D471	
VDR602	1-809-267-41	VARISTOR ERZV10D471	
<u>CRYSTAL</u>			
X300	1-579-972-11	VIBRATOR, CRYSTAL	
X301	1-567-505-11	OSCILLATOR, CRYSTAL	
X302	1-579-973-11	VIBRATOR, CRYSTAL	
C			
* A-1331-867-A C BOARD, MOUNTED			
	1-900-800-81	WIRE ASSY, G2 LEAD	
	4-382-854-11	SCREW (M3X10), P, SW (+)	
<u>CAPACITOR</u>			
C1751	1-107-652-11	ELECT 10MF 20% 250V	
C1752	1-115-350-51	CERAMIC 0.0047MF 2KV	
C1755	1-107-667-11	ELECT 2.2MF 20% 160V	
<u>CONNECTOR</u>			
CN1751	* 1-564-509-11	PLUG, CONNECTOR	6P
CN1752	1-564-510-11	PLUG, CONNECTOR	7P
CN1753	1-695-915-11	TAB (CONTACT)	
CN1754	1-695-915-11	TAB (CONTACT)	
CN1755	1-695-915-11	TAB (CONTACT)	
<u>DIODE</u>			
D1751	8-719-110-08	DIODE RD8.2ESB2	
D1754	8-719-901-83	DIODE 1SS83TD	
D1755	8-719-901-83	DIODE 1SS83TD	
D1756	8-719-901-83	DIODE 1SS83TD	
D1758	8-719-302-43	DIODE EL1Z	

REF.NO.	PART NO.	DESCRIPTION	REMARK
<u>IC</u>			
IC1751	8-759-491-92	IC TDA6107Q-N1	
<u>JACK</u>			
J1751	Δ 1-251-688-11	SOCKET, CRT	
<u>COIL</u>			
L1751	1-410-478-11	INDUCTOR 47UH	
<u>TRANSISTOR</u>			
Q1751	8-729-119-78	TRANSISTOR 2SC2785-HFE	
<u>RESISTOR</u>			
R1751	1-247-887-00	CARBON 220K 5% 1/4W	
R1752	1-247-863-91	CARBON 22K 5% 1/4W	
R1753	1-249-421-11	CARBON 2.2K 5% 1/4W	
R1754	1-249-441-11	CARBON 100K 5% 1/4W	
R1755	1-249-415-11	CARBON 680 5% 1/4W	
R1756	1-260-099-11	CARBON 1K 5% 1/2W	
R1757	1-260-099-11	CARBON 1K 5% 1/2W	
R1758	1-260-099-11	CARBON 1K 5% 1/2W	
R1759	1-260-087-11	CARBON 100 5% 1/2W	
R1760	1-260-123-11	CARBON 100K 5% 1/2W	
R1761	1-216-372-11	METAL OXIDE 1.8 5% 2W F	
R1763	1-247-807-31	CARBON 100 5% 1/4W	
R1764	1-247-807-31	CARBON 100 5% 1/4W	
R1765	1-247-807-31	CARBON 100 5% 1/4W	
R1770	1-260-132-11	CARBON 560K 5% 1/2W	

KV-21XE40B

Note: The components identified by shading and mark Δ are critical for safety. Replace only with part number specified.

Note: Les composants identifiés par un trame et une marque Δ sont critiques pour la sécurité. Ne les remplacer que par une pièce portant le numéro spécifié.

<u>REF.NO.</u>	<u>PART NO.</u>	<u>DESCRIPTION</u>	<u>REMARK</u>	<u>REF.NO.</u>	<u>PART NO.</u>	<u>DESCRIPTION</u>	<u>REMARK</u>
<u>ACCESSORIES AND PACKING MATERIALS</u>							
	1-501-730-41	ANTENNA, TELESCOPIC					
	1-417-182-11	CONVERTER (EAC-25)					
	Δ 1-769-796-71	CORD, POWER (WITH CONNECTOR)					
	3-861-824-41	MANUAL, INSTRUCTION					
	3-864-793-41	INSERT, BA4 BOLIVIAN MODEL					
	4-041-254-01	BAG, PROTECTION					
	4-041-254-11	BAG, PROTECTION					
*	4-061-391-01	CUSHION, LOWER ASSY					
*	4-061-392-01	CUSHION, UPPER ASSY					
*	4-061-395-01	CARTON, INDIVIDUAL					
<u>REMOTE COMMANDER</u>							
	1-475-635-11	REMOTE COMMANDER (RM-Y155)					
	1-475-758-11	REMOTE COMMANDER (RM-Y155)					
	9-939-830-01	BATTERY COVER, REMOTE					

9-965-848-01

Sony Corporation
Sony Technology Center
Product Quality Division
Service Promotion Department

English
98HJ74057-1
Printed in U.S.A.
© 1998.8