

Please keep this instruction sheet for future reference, as it contains important information.

Adult assembly is required.

Tools required for assembly: Phillips Screwdriver, Hammer and Scrap Block of Wood (not included). If you have any questions about this product, or are missing a part, please call us toll-free

at 1-800-432-5437, rather than return this product to the store.

We are available between 8 AM - 6 PM EST Monday through Friday.

Hearing-impaired consumers using TTY/TTD equipment, please call 1-800-382-7470.

Or write to: Fisher-Price® Consumer Relations, 636 Girard Avenue, East Aurora, N.Y. 14052.

Age: 2-5 years Weight limit: 55 lbs (25 kg).



www.fisher-price.com

Parts

! WARNING

To avoid serious injury:

- Adult supervision is required.
- Never use near cars and other motor vehicles, near streets, steps, sloped driveways, hills, roadways, alleys, swimming pool areas or other bodies of water.
- Always wear shoes or sneakers.
- Never allow more than one rider.


CAUTION

This product contains small parts in its unassembled state.


Adult assembly is required.

IMPORTANT!

- Please save all packaging material until assembly is complete to ensure that no parts are discarded.
- Please wipe each part with a clean, dry cloth before assembly.




Assembly




- Fit the seat onto the frame.
- Push firmly near the back end of the seat to "snap" it into place.
- Insert and "snap" the key into the frame.


Hint: You may need to tap the key with a hammer to secure it in place.



- Place one end of the straight axle into the cap nut.
 Tap the end of the straight axle with a hammer.
 Make sure the cap nut is securely attached to the straight axle.
- Slide a wheel hub, flat side down, onto the straight axle.
- Slide a rear wheel, *indented side down*, onto the straight axle.
- Slide a bushing, grooved side down, onto the straight axle.



- Turn the frame upside down.
- Insert the straight axle assembly through the holes in the rear of the frame.




- Turn the assembly upright.
- Slide a bushing, *smooth side first*, onto the end of the straight axle.
- Slide a wheel, *flat side first*, onto the end of the straight axle.
- Slide a wheel hub, *pointed end first*, onto the end of the straight axle.

Assembly




- Fit the cap nut on the end of the straight axle.
- Tap the cap nut with a hammer. Gently pull the rear wheel to be sure the cap nut is securely attached to the straight axle.


Hint: You may need the help of another adult to hold the other end of the straight axle in place.




- Fit the tabs on the wheel cap into the slots in the wheel hub. Push to "snap" the wheel cap in place.
- Repeat this procedure to attach the other wheel cap to the other wheel hub.



• Fit two pedal hubs onto the pedal axle tabs. Make sure the tabs fit into the slot in each pedal hub.




 Press the pedal hubs into the center of the front wheel until they are flush with the surface of the front wheel.




- Insert the remaining pedal hubs on top of and below the pedal axle and into the hole in the center of the front wheel.
- Press the pedal hubs until they are flush with the surface of the front wheel.


Assembly




- Place a scrap block of wood under the front wheel assembly.
- Fit a pedal on the pedal axle. Tap the pedal with a hammer until it is secure.
- Pull the pedal up to be sure it is secure. If you can remove it, you have not secured it properly. Tap it with the hammer again.
- Repeat this procedure to attach the other pedal to the other end of the pedal axle.



- Place the front wheel assembly between the fork arms.
 Make sure the pedal axle fits into the groove at the bottom of each fork arm.
- Place a fork cover over the pedal axle on one fork arm.
- Insert two #8 x 3/4" screws into the fork cover and tighten.
- Repeat this procedure to attach the other fork cover to the other fork arm.



• Insert the fork post up through the hole in the neck of the frame. Make sure the fork is positioned so that the fork covers face the rear wheels.





• Fit the handlebar front to the fork post.

Hint: The handlebar front is designed to assemble to the fork post one way.

- Fit the handlebar back to the fork post and handlebar front. Hold them together firmly.
- First, insert the remaining #8 x ³/₄" screws through the outer holes in the handlebar back and tighten.
- Then, insert the #8 x 2¹/₄" screw through the center hole in the handlebar back and tighten.

Label Decoration





Proper label application will help to keep the labels looking their best!

- Wash your hands before applying the labels.
- Make sure the areas where the labels will be applied are clean and dry. Wipe your vehicle with a clean, soft, dry cloth to remove any dust or oils.
- For best results, avoid applying a label more than once.
- Apply the labels as shown in the illustration above.
- After applying a label, rub the label firmly with a cloth to make sure the label is adhered to your vehicle.

Assembly is complete.

Care

- Periodically, check the plastic parts and if broken or cracked, dispose of them properly.
- Periodically, check all fasteners regularly to be sure they are tight. If the fasteners are not tight, tighten them as necessary.
- To clean, use a mild soap and water solution and a clean cloth. Rinse clean with water to remove soap residue.

IMPORTANT! It is a good practice to start training children very young regarding the importance of helmet use. When children are older and riding bicycles and faster vehicles, it is important that they use a helmet each and every time they ride. For this reason, even while riding a tricycle, it is a good idea to familiarize your child with helmet use, so that it becomes a habit for life. Choose a helmet that complies with requirements of the applicable certifying agency for bicycle helmets.

For other countries outside the United States:

Canada: call 1-800-567-7724, or write to: Mattel Canada Inc., 6155 Freemont Blvd., Mississauga, Ontario L5R 3W2.

Great Britain: telephone 01628 500302.

Australia: Mattel Australia Pty. Ltd., 658 Church Street, Locked Bag #870, Richmond, Victoria 3121 Australia. Consumer Advisory Service 1300 135 312.

New Zealand: 16-18 William Pickering Drive, Albany 1331, Auckland.

Asia: Mattel East Asia Ltd, Room 1106, South Tower, World Finance Centre, Harbour City, Tsimshatsui, HK, China.