

Service - Hotpoint Electric Cooking

Please carry out the checks detailed on the **Something Wrong** page. If there is a problem with your appliance then contact your Service Centre by using the table below to identify the appropriate phone number.

Please have the following information available when you call :

1. (a) Your name.
(b) Your address and postcode.
(c) Your telephone number.

2. The date and the name of the shop/retailer where the appliance was purchased.

Shop / Retailer : _____ Date : _____

3. The Model number and Serial number of your appliance (See Features page for Rating plate location).

Model Number : _____ Serial Number : _____

4. Clear and concise details of the fault.

5. Details of any Extended Warranty or Service Insurance Schemes.

Your In-Guarantee Service Telephone Number

The arrangements for In-Guarantee Service depend upon which Retail Outlet you purchased your product from.

| Shop / Retailer from where your appliance was purchased | Telephone Number for In-Guarantee Service |
|---|---|
| Just Rentals | 01443 441 111 |
| Hydro Electric / Scottish Hydro | 0800 300 000 |
| Any Other Shop / Retailer : UK | 0541 500 500 |
| - Republic of Ireland | 1850 302 200 |

If you have any other queries regarding Service or Parts, our Parts and Service division will be pleased to help. You should write to :

Hotpoint Service, Customer Service Department, Morley Way, Peterborough. PE2 9JB

For Parts and Accessories, please telephone our Parts Order Hotline on
0541 530 530 (UK) or 01 842 6836 (Republic of Ireland).

Note 1 : If under guarantee, our Engineers will need to see a copy of your purchase receipt when they call.

Note 2 : Our Engineers will use every effort to avoid damage to floor coverings and adjacent units when carrying out repair/service work, but in locations where the Engineer advises you that it will be impossible to move the appliance without risk of damage, he will only proceed with your approval that no liability will be accepted.

FULL INSTRUCTIONS FOR INSTALLING AND OPERATING YOUR HOTPOINT DOUBLE OVEN MODEL BD81

Hotpoint®

Retention of this Instruction Book

This Instruction Book must be kept handy for reference as it contains important details on the safe and proper use of the appliance.

If you sell or pass the appliance to someone else, or move house and leave it behind, make sure this Book is also provided so the new owner can become familiar with the appliance and safety warnings.

Before you operate your new Hotpoint Double Oven

Please read these instructions fully.

ENSURE THAT THE OVEN IS INSTALLED BY A QUALIFIED ELECTRICIAN FOLLOWING THE INSTRUCTIONS BELOW.

1. Your oven should **not** be located adjacent to a gas hob/heater or eye level grill as flames from the burners could cause damage to your oven.
2. For your own safety and to get the best results from your oven it is important to read through this Handbook **before** using your oven for the first time including the Always and Never on pages 8 and 9.

Electrical Requirements

- For your own safety, we recommend that your cooker is installed by a competent person – such as one who is registered with NICEIC (National Inspection Council for Electrical Installation Contracting). The cooker should be installed in accordance with the latest Edition of the IEE Regulations.

WARNINGS – INCORRECT INSTALLATION COULD AFFECT THE SAFETY OF THE OVEN.
– THIS APPLIANCE MUST BE EARTHED.
– BEFORE CONNECTING OR INSTALLING THE OVEN THE ELECTRICITY SUPPLY MUST BE SWITCHED OFF.

- **THE INSTALLER MUST** check that the voltage shown on the rating plate corresponds with the house electricity supply.
- The oven must be supplied via a suitable double pole isolating switch, having a contact separation of at least 3 mm in all poles placed in a readily accessible position adjacent to the unit.
- The maximum loading for your oven is 5.2kW.
- If the oven is to be wired into a connector unit this may be positioned behind the oven provided the following requirements are met:
 - i) The connector unit must not project from the wall more than 25 mm.
 - ii) The top of the connector must not be more than 350 mm above the base of the oven recess.
- After unpacking the oven stand it on the packing base in order to avoid damage.

Electrical Connections

- Remove the terminal cover at the rear base of the oven. Pass the cable through the cable clamp and connect to the appropriate terminals provided. Allow sufficient cable so that the oven can be set down on the floor whilst still connected up. Tighten the screws on the cable clamp and replace the terminal cover. Make mains connections.
This appliance conforms to EN55014 regarding suppression of Radio and Television reception interference.
Where a double oven is used a 20 amp double pole control switch should be used to feed the unit using a suitable rated cable. We recommend that a minimum of 4mm² PVC insulated twin and earth cable conforming to B.S. 6004.
- Where a hob is fitted adjacent to an oven then a 45 amp Double Pole control switch should be used to feed both units via separate suitably rated cables. We recommend that a minimum of 4mm² PVC insulated twin and earth cable conforming to B.S. 6004.

WARNING: CHILDREN SHOULD NOT BE ALLOWED TO PLAY WITH THE APPLIANCE OR TAMPER WITH THE CONTROLS.

Hotpoint Service Cover

Satisfaction Guaranteed or Your Money Back

Hotpoint gives you a unique 'Satisfaction Guaranteed' promise – valid for ninety days after you have purchased your Hotpoint product. If there is a technical problem with your Hotpoint appliance, just call Hotpoint Service (see back page). If necessary we will arrange for an engineer to call. If the technical problem is not resolved under this Guarantee, Hotpoint will replace your appliance or, if you prefer, give you your money back. Your statutory rights are not affected, and the Guarantee is additional and subject to the terms of Hotpoint's Five Year Parts Guarantee.

Hotpoint's Free Five Year Guarantee

- From the moment your appliance is delivered Hotpoint guarantees it for **FIVE YEARS**.
- In the Five Years all replacement parts are **FREE** provided that they are fitted by our own Service Engineer. During the first year our Engineer's time and labour is also free.
- Our guarantee covers loss of food in our refrigeration and freezer products up to £250 during the first year, subject to verification by one of our engineers.
- After the first year we will charge for our Engineer's time and labour. We do, however, operate a range of Service Plans (see opposite) which, for an annual payment, enables you to cover any repair costs which may be necessary.
- All our service repairs are guaranteed for twelve months in respect of our labour and any parts fitted.
- The appliance must be used in the United Kingdom, and must not be tampered with or taken apart by anyone other than our own Service Engineers.
- You may, however, buy parts which can be safely fitted without specialist knowledge or equipment. The correct fitting of such parts, provided they are genuine Hotpoint spares, will not affect your Guarantee. Parts are available from our Hotpoint Spares Centres (see back page).
- Our guarantee does not cover the cost of any repair, or loss of food in refrigeration products, due to power failure, accidents or misuse. Nor does it cover the cost of any visits to advise you on the use of your appliance. Please read thoroughly the instruction book supplied with this appliance.
- If at any time during the Guarantee period we are unable to repair your appliance, we will refund any repair costs paid to us in the previous twelve months. We will also offer you a new appliance at a reduced charge instead of a repair.
- Our Guarantee is in addition to and does not affect your legal rights.
- Should you need independent advice on your consumer rights, help is available from your Consumer Advice Centre, Law Centre, Trading Standards Department and Citizens Advice Bureau.
- All Hotpoint servicing is carried out by our own Service Organisation located throughout the United Kingdom and Eire. We will be happy to deal with any problems which you may have.

Hotpoint's Extended Warranties

Whether you have just one or a number of Hotpoint appliances in your kitchen, Hotpoint has a range of Service Plans to give you complete peace of mind. They enable you to extend your one year labour guarantee so that you can have repairs completed **FREE** during the membership period.

Service Cover

We offer a number of payment methods: cheque, credit card or you can spread the cost and pay by direct debit (full details can be obtained on Free phone 0800 716356). This covers you for all repairs during the period of cover, which can be from 1 to 4 years. Service Cover also includes loss of food, up to the value of £250, in refrigeration appliances. There is also an option of Service Cover with Maintenance at an additional cost. This includes an annual Electrical and Safety check and replacement of any parts as necessary.

Kitchen Cover

An annual payment covers you for all repairs for all your Hotpoint appliances which are less than ten years old. It also covers the cost of loss of food up to £250 in our refrigeration and freezer products. There is also the option of Kitchen Cover with Maintenance at an additional cost. Any additional Hotpoint appliances purchased after you have joined Hotpoint Kitchen Cover will automatically be included during the annual period of cover without further charge.

Appliance Registration

To ensure that you have the opportunity to benefit from any of the above Service Schemes and other offers you should complete and return immediately the Appliance Registration Form (Questionnaire supplied with this appliance). Full details and costs of our Service Schemes, together with an application form, will be sent to you at the end of the first year of the guarantee.

Annual Safety/Maintenance Checks

Hotpoint strongly recommends that all its appliances are regularly checked for electrical and mechanical safety, whether or not they are covered by a Service Plan. Worn door gaskets or hoses may cause a leak on an appliance, which could become dangerous if neglected.

Proof of Purchase

For future reference please attach your purchase receipt to this booklet and keep it in a safe place.

Spare and Accessories

Spare and accessories can be ordered from your local Hotpoint Spares Centre (see back page), using the order form enclosed.

NOTE: Our Engineers will use every effort to avoid damage to floor coverings and adjacent units when carrying out repairs/service work, but in locations where the Engineer advises you that it will be impossible to move appliances without risk of damage, he will only proceed with your approval that no liability is accepted.

PLEASE READ THIS BOOKLET CAREFULLY.

Contents

| | |
|--|-------|
| Before you operate your new Hotpoint Double Oven Electrical Requirements | 2 |
| Installation Instructions | 2 |
| For Your Safety - Always | 4-7 |
| Never | 8 |
| The main parts of your Double Oven | 9 |
| The cooking systems in your Double Oven | 10 |
| Before using your Oven for the first time | 11 |
| Temperature Conversion Scale | 12 |
| Controls | 12 |
| The Automatic Oven Timer | 13-14 |
| Grilling in the Top Oven | 15-18 |
| Cooking in the Top Oven - Conventional Cooking | 20-21 |
| Cooking Temperature Charts | 22 |
| Grilling in the Lower Oven | 23-24 |
| Grilling in the Lower Oven - Temperature Chart | 25 |
| Cooking in the Lower Oven - Fan Grilling | 26 |
| Lower Oven Temperature Charts - Fan Grilling | 26 |
| Cooking in the Lower Oven - Fan Cooking | 27 |
| Fan Only | 28-29 |
| Eco Cooking - Lower Oven | 30 |
| Care and Cleaning | 31-39 |
| If Something Goes Wrong | 40-43 |
| Hotpoint Service Cover | 44-45 |
| Hotpoint Service and Spares | 46 |
| Back Cover | 46 |

This appliance conforms to the following EEC Directives:

Low Voltage Equipment
73/23/EEC
93/68/EEC

Electromagnetic Compatibility

89/336/EEC
92/31/EEC
93/68/EEC



Installation Instructions

Ensure that the electricity supply is turned off before installing your appliance.

IMPORTANT **DO NOT LIFT OVEN BY THE DOOR HANDLES.**

This equipment is designed specifically for domestic purposes and Hotpoint Limited cannot accept responsibility if used for any other type of application.

All electrical installations must be carried out by a NICEIC registered installer.

WARNING: THIS APPLIANCE MUST BE EARTHED.

1. General

The appliance is designed for mounting at a safe level into an open housing which must be secured to the backing wall.

2. Oven Unit Housing Cabinets

- a. The oven unit housing cabinet dimensions must comply with Fig. 4. (See pages 6 and 7.)
- b. An air gap of 50 mm minimum must be provided at the rear of any top or bottom cupboards or shelves. (See Fig. 1 page 6.)
- c. Ventilation must be unobstructed, ie. from adjacent cabinetry. This can be done by either raising the base of the cabinets using the adjusting feet (or spacers) or alternatively by providing a slot in the cabinet plinth to the dimensions shown overleaf.
- d. The air gap at the rear allows the warmed air to pass out of the inner cabinet space, but where it is intended to fit

cupboards above the oven unit to ceiling height it is essential that the warmed air is exhausted through the front of the cabinet Fig. 1. (See page 6.)

- e. If an oven unit is installed adjacent to a tall cabinet, steam escaping from the oven when the door is opened could condense on, and perhaps stain, the adjacent surface. To prevent permanent staining, the adjacent surface should be made of a material that is heat resistant and easy to clean. Adjacent tall cabinets should not be deeper than the oven housing cabinet.

IMPORTANT

It is essential that the lower cupboard is constructed in the manner illustrated see pages 6 and 7 ie. having side, back and roof panels so joined as to provide no apertures which could permit access to the oven unit when installed.

3. Final Installation

- a. Using a spirit level, check that the housing cabinet is level from side to side and from front to back in its installed position.
- b. Correct any unevenness by placing wooden packing under the bottom of the cabinet. Make sure that the cabinet rests firmly on the cabinet floor without rocking
- c. Before the oven is fitted, the cabinet must be firmly secured to the backing wall for stability.

If something goes wrong ...

Oven does not cook evenly

Check:
(a) Temperature and shelf positions are as recommended in the Oven Temperature Charts.
(b) Oven utensils being used allow sufficient air flow around them.

Grilling is uneven

Ensure that Grill pan has been positioned as stated in the Grilling section of this book.

Oven lamp does not work

The oven lamp is not covered by the guarantee. The part is easily changed (see the section on oven lamp replacement) A new lamp may be obtained from our Spare Parts department by calling: 0541 530530

Condensation on the wall at the rear of the cooker.

Steam and / or condensation may appear from the vent at the rear of the appliance when using an oven particularly for foods with a high water content e.g. frozen chips, roast chicken etc. This is normal, and any excess should be wiped off.

Steam / Condensation in the oven after use.

Steam is a by - product of cooking any food with a high water content. To help minimise always:
a) Try to avoid leaving food in the oven to cool after being cooked.
b) Use a covered container, wherever possible.

If you have been through the above list and there is still a problem; You should identify your Service Agent using the list on the back page and contact your Local Service Office.

DISPOSAL OF YOUR PRODUCT

To minimise the risk of injury to children please dispose of your product carefully and safely. Remove all doors and lids (where fitted). Remove the mains cable (where fitted) by cutting off flush with the appliance and always ensure that no plug is left in a condition where it could be connected to the electricity supply. To help the environment, Local Authority instructions should be followed for the disposal of your product.

If something goes wrong ...

Slight odour or small amount of smoke when grill / oven used first time

This is normal and should cease after a short period.

Nothing Works

If you find that the timer display is blank, then it is likely that there is no electricity supply to your oven. Check:

- (i) That the main cooker wall is switched on
- (ii) Other appliances, to see if you have had a power cut
- (iii) The main circuit breaker for the property

Timer Display shows "0:00" with "Auto" Flashing

The power supply to your oven has possibly been interrupted, but has now come back on again. Reset the timer to the correct day and "Manual" operation using the instructions given in the timer section of the book.

Main oven and Top ovens do not work, but the grill works

Your timer may be set for an Auto Cooking programme. Check the timer to see whether "Auto" is lit or flashing. If it is then please follow the instructions given in the Timer section of this book to return the timer to Manual operation.

Top oven and grill do not work, but Main oven works.

Operating the cooker under the following conditions may cause a safety device to operate:

- (a) Grilling with the door closed - Always grill with the door fully open
 - (b) Grilling for an excessively long period at maximum setting - see Grilling guide.
- Switch off appliance and allow to cool for approx 30 mins. Switch the cooker back on and check that the Grill / Top oven is now operating.

Grill does not work.

Check that you have selected: 'Grill' function on the 'Top oven grill select' knob (B) and a grill setting on the 'Grill knob (A)' (see grilling page)

Grill keeps turning on and off

When the Grill control is operating at less than its maximum setting, the Grill will cycle on and off, this is normal and **not** a fault.

Draught from beneath control panel

A gentle flow of air will be blown from beneath the control panel when the appliance is used. If the appliance is still warm, this cooling fan may run on, or restart itself when all controls have been turned off.

The fan will stop once the appliance has been cooled. This is normal and **not** a fault.

Timer buzzer / bleeper operates continually

The bleeper will stop automatically after several minutes. To cancel, press the minute minder button to silence.

Oven temperatures too high or low

Check temperature and shelf positions are as recommended in the Oven Temperature Charts. It may be necessary to increase or decrease the recommended temperature slightly to suit your taste.

Installation Instructions

- d. Affix the correct number of self adhesive spacer pads to the outside of the side trims over the fixing holes to make up to the actual cabinet aperture (see Fig. 3 page 7).
- e. The oven unit should now be lifted (by 2 persons) into the cabinet and pushed fully home. (Care should be taken not to dislodge the spacer pads.)
- f. Finally the oven unit must be secured to the cabinet by means of the four pozi wash head screws, two through each side trim.

9. REMOVE ALL PACKING MATERIAL FROM THE GRILL AND OVEN INTERIOR.


List of Loose Items

- 4 x Pozi Wash Head No. 6 x 15mm screws.

Care and Cleaning

- Return the inner door panel to the closed position as shown in Fig. 4.

Fig. 4



WARNING: CARE MUST BE TAKEN WHEN CLOSING THE DOOR INNER PANEL AS THE DOOR WILL ATTEMPT TO SNATCH SHUT, WITHOUT THE WEIGHT OF THE HANDLE/ OUTER GLASS ASSEMBLY AVOID TRAPPING YOUR FINGERS.

- The inside of inner and outer door/glass can now be cleaned using only warm soapy water and cloth **taking care not to damage the glass screen.**

- Refit the handle/outer glass assembly by opening the oven door and hold taking care not to trap fingers, see Fig. 3. Hook the handle/outer glass assembly back into the rubber grommets at the bottom of inner door panel, see Fig. 3. Fit the handle/outer glass assembly back in position at the top ensuring the fixing tags on the handle/outer glass assembly. Fit inside the door inner panel while still holding door together refit the two screws and washers, see Fig. 2.

NEVER OPERATE THE OVENS WITHOUT THE OUTER GLASS PANELS CORRECTLY REFITTED.

Fig. 2





Fig. 1

Care and Cleaning




Fig. 8




Fig. 9




Fig. 10

WARNING: ALWAYS SWITCH OFF YOUR APPLIANCE AT THE MAINS SUPPLY AND ALLOW TO COOL BEFORE CLEANING.

TO CLEAN INSIDE OF OUTER AND INNER GLASS PANELS

1. Position top or main oven door as shown in Fig. 1. **NOTE:** The door can be wedged open using a towel between the door and the side trim thus leaving your hands free.

2. Grip inner door panel and handle/outer glass assembly. Remove two screws and fibre washers (put to one side) as shown in Fig. 2

3. Pull handle/outer glass assembly at the top outwards while still holding the inner door panel and unhook handle/outer glass assembly at the bottom by lifting handle/outer glass assembly upwards as shown in Fig. 3. Take care not to dislodge rubber grommets in bottom of door.




Fig. 1




Fig. 2




Fig. 3

Fig. 4





Fig. 3

For Your Safety, Always ...

Please read through before operating your appliance.

- ALWAYS** Have your appliance installed by a competent engineer or electrical contractor.
- ALWAYS** Ensure the appliance has been properly earthed.
- ALWAYS** Remove all transportation packing from inside the oven/grill before switching on for the first time.
- ALWAYS** Make sure you understand the controls prior to using them. (See pages 13 and 14)
- ALWAYS** Keep children away from the oven at all times when oven/grilling as surfaces will get extremely hot.
- ALWAYS** Remember that the oven and utensils will be very hot when in use.
- ALWAYS** Take care when opening the door. Let the steam and hot air escape before removing the food.
- ALWAYS** Use dry quality oven gloves for removing hot food utensils from the oven/grill.
- ALWAYS** Select the correct shelf position before turning the oven or grill on.
- ALWAYS** Turn off the electricity supply at the wall switch before cleaning.
- ALWAYS** Ensure poultry is thoroughly defrosted before cooking well.
- ALWAYS** Check all controls on the appliance are switched off before retiring to bed or after use.
- ALWAYS** Keep ventilation slots clear of obstructions.
- ALWAYS** Reset the oven timer to Manual after completing an Automatic Cooking Programme.
- ALWAYS** Take care on warm days when using the oven for delayed automatic cooking as certain foods can spoil.
- ALWAYS** Use a thick cloth to protect your fingers when replacing the oven lamp.
- ALWAYS** Refer servicing to a qualified appliance service engineer.
- ALWAYS** Follow the guide lines for successful defrosting when using the fan only mode.

Care and Cleaning

It should not normally be necessary to clean the Stay Clean panels with water. If the user feels it is desirable to do so, wash them down in warm, soapy water, followed by rinsing with clear water: **Do not use biological/enzyme washing powder, harsh abrasives or oven chemical cleaners of any kind.**

Replacement oven liners are available should you require them, from your nearest Hotpoint Service Centre (see back page).

Replacement of Oven Lamp

WARNING: ISOLATE OVEN FROM SUPPLY BEFORE REPLACING LAMP.


the rod shelves. Grip the light glass dome, unscrew anti-clockwise and lift out. Reach into the aperture with fingers, and unscrew the faulty lamp anti-clockwise (25W 300°C SES) (Part No. 620601) which can be obtained from your nearest Hotpoint Service Centre. Fit replacement lamp, and refit dome. When screwing and unscrewing the faulty lamp use a thick cloth to protect your fingers should the lamp break.

WARNING: ISOLATE OVEN FROM SUPPLY BEFORE REMOVING DOOR.

Oven Door Removal Main (Lower) Oven

The door is removable to facilitate occasional cleaning of heavy soiling from the oven floor and from the door itself.

Please note that the door is heavy and care should be taken not to pinch your fingers during the removal and replacement. To remove, open the door fully and, using a coin or screwdriver, turn the two discs clockwise to the position shown below (Fig. 8). Slightly close the door, unhook the lower hinge fingers, then pull the door away from the oven front frame. To replace, insert the lower fingers and the hooked ends of the doorstays, ensuring that the slots in the lower fingers engage with the front frame (Fig. 9). Fully open the door and turn the discs anti-clockwise to their normal working positions (Fig. 10). Close the door - the hinge will now lock into position.



Care and Cleaning

TURN OFF THE MAIN SWITCH BEFORE CLEANING.

Before switching on again, ensure that all controls are in the **OFF** position.

Cleaning the Exterior

The outside of both ovens can be cleaned, when cooled down, using a cloth which has been rinsed in warm soapy water. The oven can then be wiped down with a clean dry cloth. **Never** use an abrasive powder as this will damage the surface.

Lower Oven

Remove the rod shelves and meat pan.

Use a fine steel wool soap pad to remove stubborn stains from the rod shelves, meat pan and the floor of the oven. Refer to the instruction opposite and on page 28 for cleaning the 'Stay Clean' panels.

Do not use aerosol cleaners on this oven as they could adversely affect the fan motor unit, and cannot be wiped off the fan blade.

Decorative Trims

It is advisable to clean the decorative trims regularly to prevent any build up of soiling which may detract from the appearance of the Cooker. The recommended method of cleaning is to wipe over the trims with a soft cloth wrung out in hot water, or mild non-abrasive cleaner. (If in doubt try the cleaner on a small area of trim which is not noticeable in normal use), then after wiping with a cloth wrung out in clear water, dry with a soft clean cloth.

Do not use scouring pads or abrasive cleaners/powders which may scratch the surface. Under no circumstances should abrasive cleaning materials be used on the Timer Lens.

Top Oven

Use a fine steel wool soap pad to remove stubborn stains from the rod shelves, grill pan and floor and roof of the oven.

Stay Clean Oven Liners

Refer to the instructions below for cleaning the following Stay Clean panels: **Oven** – side and rear panels.

How Stay Clean Oven Liners Work

The surfaces of the Stay Clean oven liners are treated on the mottled face with a special vitreous enamel which absorbs cooking soils. At temperatures of 220°C (425°F) or above, the special surface enables these soils to be slowly destroyed. The higher the temperature, the more effective it is. In most cases normal cooking operations at this temperature will permit this cleaning operation to proceed during cooking. However if higher cooking temperatures are not used regularly, it may be necessary, in order to prevent heavy soiling, to run the oven without meat pan, at maximum setting for a couple of hours. This may be necessary once a month or every two or three months depending on the type and amount of oven cooking.

For Your Safety, Never ...

NEVER Leave children playing unsupervised where the oven is installed and in use.

NEVER Attempt to grill with the grill/oven oven door closed.

NEVER Allow children to sit or stand on any part of the appliance.

NEVER Store food stuffs in the same cabinet as the oven.

NEVER Store items above an oven that children may attempt to reach.

NEVER Operate the oven with the inner glass panel removed.

NEVER Remove the oven shelves when the oven is hot.

NEVER Use water to extinguish oil or fat fires.

NEVER Use the oven/grill as a space heater.

NEVER Cover oven interior and shelves with aluminium foil.

NEVER Heat up unopened food containers as pressure can build up causing the container to burst.

NEVER Attempt to clean the oven until the mains supply has been switched off and the oven is cool.

NEVER Defrost the meat and poultry by warming through in the oven.


NEVER Store any aerosols/flammable liquids etc. in adjacent cabinetry.

NEVER Store anything which might catch fire in or near the oven.

NEVER Operate the grill when the ovens are set to cook automatically.

The main parts of your Double Oven

WARNING: DO NOT TOUCH THE GLASS DOORS WHEN THE OVEN IS IN USE AS THESE AREAS CAN BECOME HOT.



Menus

Fruity Chicken Casserole

- 4 chicken joints
- 1 red pepper, de-seeded and sliced
- 2 sticks of celery, chopped
- 1 large onion, peeled and sliced
- 100g (4oz) mushrooms, sliced
- 400g (14oz) can sliced peaches
- 3 tablespoons cornflour
- 1 tablespoon soya sauce
- 3 tablespoons malt vinegar
- Salt and pepper

- 50g (2oz) pudding rice
- Knob of butter
- 25g (1oz) sugar
- 500ml (1pt) milk, warmed
- Grated nutmeg

Rice Pudding

1. Skin chicken joints and place in 2 litre (3 1/2 pint) casserole dish.
 2. Fry pepper, onion, celery and mushrooms in oil.
 3. Cover chicken with vegetables.
 4. Drain fruit, reserving juice, and add to casserole.
 5. Blend cornflour with soya sauce, vinegar and reserved juice, bring to the boil in a saucepan, add seasoning and pour into casserole dish.
1. Place the washed rice into a greased dish and dot with butter.
 2. Dissolve the sugar in the heated milk and pour over the rice.
 3. Sprinkle grated nutmeg over the top.
 4. Leave uncovered, place in oven.

Menus

Menu 5 continued

- 225g (8oz) slightly stale bread
- 250ml (1/2 pint) milk
- 2 eggs
- 1 tablespoon brandy, optional
- 175g (6oz) mixed dried fruit
- 40g (1 1/2oz) demerara sugar
- 50g (2oz) melted butter
- 1 teaspoon mixed spice
- Finely grated rind of 1 lemon
- Grated nutmeg
- Caster sugar

Spiced Bread Pudding

1. Grease shallow ovenproof dish. Line base with greased greaseproof paper.
2. Cut bread into very small pieces.
3. Bring milk to boil and pour over bread. Add pinch of salt, allow to stand for about 20 mins or until pulped.
4. Lightly beat eggs and stir into bread mixture with brandy, dried fruit, sugar, butter, mixed spice and lemon rind. Mix well together.
5. Turn mixture into prepared dish. Sprinkle with little nutmeg and caster sugar.
6. Place in oven.

Ratatouille

- 375g (12oz) aubergines
- Salt
- 225g (8oz) onions, peeled and sliced
- 1-2 cloves of garlic, crushed
- 2 tablespoons vegetable oil
- 375g (12oz) tomatoes, skinned and roughly chopped
- 375g (12oz) courgettes, sliced
- 375g (12oz) red peppers, de-seeded and sliced
- Bunch of fresh herbs
- Salt and pepper
- Chopped parsley

1. Slice aubergines and sprinkle with salt, leave for 30 mins, pat dry.
2. Cook onions gently with garlic, in oil until soft.
3. Add remaining ingredients, and heat thoroughly.
4. Place in casserole dish.
5. Cover tightly with foil and lid.
6. Place in oven.

Menu 6

Tomato Soup Fruity Chicken Casserole Rice Pudding

- 1 medium sized onion, peeled and chopped
- 15ml (1 tbsp) vegetable oil
- 675g (1 1/2lb) tomatoes, roughly chopped
- 500ml (1 pint) vegetable stock
- Salt and pepper
- 5ml (1 level tsp) caster sugar

Tomato Soup

1. Fry onion gently in oil until soft.
2. Add tomatoes, stock, seasoning and bring to boil.
3. Place in casserole dish cover with foil and lid and place in oven.
4. Before serving, sieve soup.
5. Reheat, adjust seasoning if necessary and stir in sugar.
6. For cream of tomato soup stir in 50 ml (2floz) cream and reheat soup very gently without boiling. Garnish with a swirl of cream.

Method
Cook on 'Eco' setting for 7 hrs.


The Cooking Systems in your Double Oven

Your new oven is equipped with five heating systems:

1. **Conventional Heating (Top Oven)** - with upper and lower heat. This system is particularly suitable for roasting and baking on one shelf only.
2. **Grilling (Top Oven)** - Has a full width, fully controllable grill. The grill also has an economy setting which enables you to use just the left section.
NOTE: The Top Oven Door should be fully open when grilling.
3. **Fan Cooking (Lower Oven)** - the fan oven operates by constantly blowing heated air from an element wrapped around the fan into the oven. This gives improved efficiency and, in general, allows you to cook at lower temperatures. It also means that there is less need to be particular about shelf positions and that you can bake at more than one level simultaneously (Batch Baking).
4. **Fan Grilling (Lower Oven)** - controlled by the oven thermostat - this is a combination of heat from the grill element and hot air circulated by the fan. Joints of meat and poultry will be browned as if they were cooked on a rotisserie or spit but more economically as the door is left closed.
5. **Thermostat Grilling (Lower Oven)** - can be used for conventional grilling with a full grill width. Use the lower oven thermostat control to set the required temperature.

NOTE: The Lower Oven Door should be open at the detent position when grilling.

It should be noted that at the end of a cooking period there may be a momentary puff of steam when the oven door is opened. This will disperse in a few seconds and is a perfectly normal characteristic of an oven with a good door seal.



Before Using the Oven for the First Time

Make sure the electricity supply is switched ON.

Please note that when the double oven is used for the first time a slight odour may be emitted due to the 'burning off' of any temporary finish on oven fittings and elements and the removal of moisture absorbed by the lagging. The odour will cease after a short period of use.

To remove the 'new smell', heat up the empty oven for 30 minutes keeping the door closed. Ensure

that the room is well ventilated (eg, open a window or door) and that persons who may be sensitive to the odour avoid any fumes. It is suggested that any pets be removed from the room until the new smell has ceased. Turn the selector switch to fan oven function, then turn oven thermostat to MAX. Also turn Top Oven/Grill selector to MAX. The oven temperature thermostat lights will come on as well as the interior light, oven fan, control panel illumination, and cooling fan.

Temperature Conversion Scale

The chart below gives details of comparisons of oven settings for gas conventional ovens and fan oven in degrees °F and °C

| GAS MARK | CONVENTIONAL OVEN | | FAN OVEN |
|----------|-------------------|-----|----------|
| | °F | °C | °C |
| 1/2 | 250 | 120 | 100 |
| 1 | 275 | 140 | 120 |
| 2 | 300 | 150 | 130 |
| 3 | 325 | 160 | 140 |
| 4 | 350 | 180 | 160 |
| 5 | 375 | 190 | 170 |
| 6 | 400 | 200 | 180 |
| 7 | 425 | 220 | 20 |
| 8 | 450 | 230 | 210 |
| 9 | 475 | 240 | 220 |

Menus

4 Large potatoes

Jacket Potatoes

1. Scrub the potatoes, prick well.
2. Wrap each potato in a piece of cooking foil.

Pear Pudding

- 50g (2oz) butter } Melted
50g (2oz) dark brown sugar } together
100g (4oz) margarine
100g (4oz) caster sugar
2 size 4 eggs
100g (4oz) self raising flour, sieved
1/4 teaspoon almond essence
3 pears, peeled, cored and cut into 4
1. Coat base of soufflé dish with melted butter and sugar.
 2. Cream together margarine and sugar until light and fluffy.
 3. Beat in each egg, fold in flour, and stir in almond essence.
 4. Place prepared pear slices in base of dish then cover with cake mixture.
 5. Cover dish tightly with foil.
 6. Place in oven.

Menu 5

Method

Cook on 'Eco,' setting for 7 hrs

Rich Onion Soup Honey Roast Ham Ratatouille Bread Pudding

Rich Onion Soup

- 450g (1lb) onions, peeled and thinly sliced
25g (1oz) butter
1 tablespoon vegetable oil
1 teaspoon salt
1½ teaspoon brown sugar
40g (1 1/2oz) plain flour
750ml (1 1/2 pint) brown stock
125ml (1/4 pint) stout or brown ale
1. Gently cook onions in butter and oil in large saucepan for 5 minutes.
 2. Add salt and sugar and cook for 2 minutes.
 3. Remove from heat and stir in flour, stock and beer.
 4. Bring to boil. Place in casserole dish.
 5. Cover tightly with foil and lid.
 6. Place in oven.

Honey Roast Ham

- 2kg (4 1/2lb) joint middle cut gammon
Sauce:
2 tablespoons honey
2 tablespoons sherry
1 tablespoons demerara sugar
1. Soak gammon in cold water overnight. Drain and dry.
 2. Coat with sauce, wrap in foil.
 3. Place in tin.
 4. Cook on 180°C for 30 minutes. Add rest of meal to oven and set to 'Eco' setting for 7 hrs.

Menus

Menu 3 continued

- 10 oz (275g) long grain rice
- 3 tablespoons (45ml) oil
- 1 1/4pt (625ml) water

Long Grain Rice

1. Wash the rice.
2. Fry the rice in oil until lightly browned.
3. boil the water , add salt and place with rice in casserole dish.
4. Cover dish tightly with foil and lid.
5. Place in oven.

Fruit Crumble

- 675g (1 1/2lb) Fruit, prepared
 - 75g (3oz) Caster sugar
 - 175g (6oz) Plain flour
 - 75g (3oz) Butter
 - 75g (3oz) demerara sugar
1. Place prepared fruit and sugar in dish.
 2. Rub butter into flour until it resembles fine breadcrumb.
 3. Stir in demerara sugar and mix well.
 4. Sprinkle over fruit.
 5. Place in oven.

Menu 4

- Salmon Pate
- Roast Lamb
- Jacket Potatoes
- Pear Pudding

Salmon Pate

- 450g (1lb) cooked, or canned salmon, pink or red
- 4 x 2.5 cm (1") thick slices of white bread from large loaf
- 250ml (1/2 pint) milk
- 25g (1oz) butter, softened
- 1 egg yolk
- 2 tablespoons chopped parsley
- Juice of 1/2 lemon
- Salt and Pepper

Method

Cook on 'Eco' setting for 7 hrs.


Roast Lamb

- 1.25 kg (2 1/2lb) Leg of Lamb
- 1 teaspoon rosemary
- 1 tablespoon parsley, chopped
- Salt and pepper
- Bay leaf

Mixed together

1. Wipe meat. Place in piece of foil.
2. Season well with mixture and wrap tightly in foil.
3. Place on rack in dish.
4. Cook in oven at 170°C for 30 minutes before setting to 'Eco'.

The Controls



IMPORTANT

Before using your oven, ALWAYS make sure that the timer has been set to **MANUAL operation**. Unless this is done, the oven cannot heat up. Before seeking assistance, make sure you have done this.

To select any feature simply press the selector knob centre to release the knob. Rotate the knob in either direction until the required function

appears in the window. Many of the functions will also require the Oven Thermostat to be set to the required temperature, or Grill to the required setting. After use, both knobs can be returned to the storage/safety position by again pressing in the centre of the knob.

Lower Oven Selector Switch Functions



Off. With the selector in this position the oven will be off with the exception of the Oven Clock display.



Oven Light. In this position the Oven Light will be on.



Fan Only. The Oven Temperature control must be set to the off position.



Fan Oven (Rear Element and Fan). Use the Oven Temperature control to set the required temperature.



Fan Grill (Inner and Outer Top Elements and Fan). Use the Oven Temperature control to set the required temperature.



Grill (Top Element). Use the Oven Temperature Control to set the required temperature.

The Controls

When Using the Top Oven

To use the Top Oven, you must turn the Top Oven/Grill Selector clockwise to the required temperature.

The Top Oven thermostat light will immediately come on and remain on until the oven reaches the required temperature.

It then cycles off and on during cooking as the thermostat maintains the oven temperature.

If the thermostat light does not come on when the top oven is turned on, check that the oven is set to Manual (see pages 15 to 17).

Always remember to keep the oven door closed.

After use always set the Top Oven/Grill Selector back to 'O' (OFF) position.

When Using the Grill (Top Oven)

Keep young children away from the appliance when the grill is in use as the surfaces get extremely hot.

Grilling should not be undertaken with the grill/Top Oven door closed.

Turn the Top Oven/Grill Selector clockwise past the thermostat settings to the half grill **or** full grill settings depending upon which you require.

To set the heat of the grill turn the grill control clockwise to any setting between 1 & 6.

After use always turn the Top Oven and grill controls anti-clockwise back to 'O' (OFF) position.

Platwarming

Turn the Top Oven/Grill Selector clockwise to the plate warming setting. Place the dishes to be warmed in the Top Oven (see page 20).

When Using the Lower Oven

Turn the Multifunction selector switch to the required function (fan oven, fan grill, grill).

Then set Oven Temp Control to the required temperature. The thermostat light will come on and remain on until the oven reaches the required temperature. The light will then cycle off and on as the thermostat maintains the oven temperature.

If the thermostat light does not come on, check that Timer is set to Manual. (See pages 15 & 17).

Eco Setting

The lower oven has an economy setting on fan oven position only.

To select turn multi-function selector to fan oven position then set the oven temp control to the Eco setting (see pages 29 – 37)

NOTE

Eco cooking can be cooked automatically (see pages 15 – 17)

Menus

Braised Topside au Poivre

450g (1lb) Topside of beef, cut into 4 slices
1 tablespoon black peppercorns, crushed
Salt
25g (1oz) butter
2 tablespoons vegetable oil
4 small courgettes, thickly sliced
4 tomatoes, sliced
125ml (1/4 pint) red wine

1. Sprinkle beef with peppercorns and salt.
2. Heat butter and oil in frying pan, cook half the courgettes and tomatoes, place in bottom of casserole dish.
3. Fry meat on both sides and place on top of vegetables, then cook remaining vegetables and place on top of meat in casserole dish.
4. Add red wine to pan and bring to the boil. Pour into casserole dish.
5. Cover dish with foil and fit lid tightly.
6. Place in oven.

Rhubarb and Raspberry Crunch Layer

100g (4oz) butter, melted
100g (4oz) rolled oats
100g (4oz) digestive or ginger biscuits coarsely crushed
50g (2oz) mixed chopped nuts
175g (6oz) demerara sugar, divided in half
Good pinch of cinnamon
450g (1lb) rhubarb, cut into 2.5cm (1") lengths
225g (8oz) frozen raspberries

1. Mix together butter, oats, crushed biscuits, nuts, half sugar and cinnamon.
2. In another bowl mix remaining sugar and fruits together.
3. Place half fruit in bottom of a 1.1 litre (2 pint) greased ovenproof dish. Sprinkle with half biscuit mixture.
4. Repeat layers.
5. Place in oven.

Menu 3

Chilli Con Carne

Rice

Fruit Crumble

675g (1 1/2lb) minced beef
15ml (1 tbs) vegetable oil
1 large onion, skinned and chopped
1/2 green pepper, seeded and chopped
2 x 425g (15oz) can tomatoes, chopped
Salt and Pepper
1 tablespoon chilli powder
1 teaspoon brown sugar
2 tablespoons tomato puree
425g (15oz) can red kidney beans, blended together

Chilli Con Carne

Method

Cook on 'Eco' setting for 7 hrs.

1. Fry minced beef in oil until lightly browned, add onion and pepper and fry for 5 mins, until soft.
2. Blend together chilli powder, brown sugar and tomato puree.
3. Stir in tomatoes, chilli paste and seasoning. Bring to boil.
4. Place in casserole dish.
5. Cover tightly with foil and lid.
6. Place in oven.

Menus

Menu 1 continued

Braised Red Cabbage

- 225g (8oz) onion, peeled and chopped
- 2 tablespoons vegetable oil
- 450g (1lb) red cabbage, finely shred
- 225g (8oz) cooking apple, peeled, cored and diced
- 225g (8oz) pear, peeled, cored and diced
- 3 tablespoons brown sugar
- 1/2 teaspoon nutmeg
- Salt and Pepper
- 3 tablespoon cider vinegar
- Juice of 1 orange

1. Place onion and oil in pan and cook for 3 minutes.
2. Add cabbage, apple and pear and cook for 3-4 minutes. Place in casserole dish.
3. Add remaining ingredients to pan and heat to boiling. Pour over vegetables.
4. Cover dish tightly with foil and lid.
5. Place in oven.

Summer Pudding

- 8-10 slices of bread, crusts removed
- 50g (2oz) butter melted
- 50g (2oz) demerara sugar
- 375g (12oz) prepared fruit, eg. strawberries, raspberries etc.
- 50g (2oz) caster sugar
- 2 tablespoons water

1. Grease a basin or souffle dish with butter and sprinkle with sugar.
2. Line with buttered and sugared bread, placing the buttered side towards the out side of the basin.
3. Pack firmly with fruit and add sugar and water.
4. Cover with buttered, sugared bread.
5. Cover dish with foil.
6. Place in oven.

Menu 2

Spring Vegetable Soup

Braised Topside au Poivre Rhubarb and Raspberry Crunch Layer

Spring Vegetable Soup

- 3 medium sized carrots, peeled and sliced
- 2 medium sized onions, peeled and diced
- 2 sticks celery, cut into 1" pieces
- 15g (1/2oz) butter
- 58g (2 1/4oz) can tomato puree
- 2 vegetable stock cubes
- Salt and Pepper
- 50g (2oz) sliced green beans
- 100g (4oz) shredded white cabbage
- 1 teaspoon cornflour, blended with a little cold water

Method


Cook on 'Eco' setting for 7 hrs.

1. Melt butter in pan, add carrots, onions and celery and fry gently for 3-4 minutes.
2. Stir in tomato puree, crumbled stock cubes, 1 litre (1 3/4 pints) water and seasoning.
3. Bring to the boil, transfer to large casserole dish.
4. Add remaining ingredients to dish, cover tightly with foil and lid.
5. Place in oven.

The Automatic Oven Timer

To Set Time of Day

- Step 1** Make sure all oven controls are turned off.
- Step 2** Check the electricity supply to the cooker is turned on.
- Step 3** When switched on the display will show 0.00 and Auto flashing intermittently.




12.00

- Step 4** Press and hold the "End Time" and "Cook Period" button together. Display shows 12.00.

At the same time press either the "+" or "-" buttons to set the correct time of day.

THE TIME OF DAY IS NOW SET.



To Set Timer To Switch OFF Automatically

This allows you to cook immediately for a chosen period before the oven switches Off Automatically


- Step 1** Ensure the time of day is set correctly.
- Step 2** Place food onto the correct shelf position in the oven.
- Step 3** Turn the oven control to the required temperature (Oven should now be operating).

Step 4

Press and release the cook period button the display will read 0.00 with the cookpot lit.

Within 2 seconds press and hold the "+" button until the required cooking period is set.

(Adjustment can be made by pressing the "-" button).



13.23

The timer display will revert to the time of day with the Auto symbol and Cookpot lit.



At the end of the cooking period the Auto symbol will Flash and an intermittent bleeping sound will be heard.
— This will continue for approximately 2 minutes unless the timer is reset within this period (See Step 6).

To Set Timer To Switch OFF Automatically (cont.)

Step 5
Turn off the oven control.

Step 6
Press the manual button to cancel the bleeping.
(If 2 minutes has not elapsed.)

Press manual button again to return oven to **Manual Operation**.



To Set Timer To Switch ON and OFF Automatically

This allows you to cook at a specified time for a chosen period before the oven switches Off Automatically.

Step 1 Ensure the time of day is set correctly.

Step 2 Place food onto the correct shelf position in the oven.

Step 3
Press and release the cook period button the display will read 0.00 with the cookpot lit.

Within 2 seconds press and hold the “+” button until the required cooking period is set.

(Adjustment can be made by pressing the “-” button).

The timer display will revert to the time of day with the Auto symbol and Cookpot lit.


Step 4
Press the release the End time button the display will read the earliest possible end time with the Cookpot and Auto symbol lit.

Within 2 seconds press and hold the “+” button to set to the time you require the food to be ready, with only the Auto symbol lit.
(Adjustment can be made by pressing the “-” button).

Step 5
Turn the oven control to the required temperature.
The oven will now switch on later in the day for the cooking period required and will cut off automatically at the end time setting.

At the end of the cooking period the Auto symbol will flash and an intermittent bleeping sound will be heard.

This will continue for approximately 2 minutes unless the timer is reset within the period. (See Step 7 on next page).



Menus

Menu 1

Leek and Potato Soup
Stuffed Peppers
Braised Red Cabbage
Summer Pudding

Leek and Potato Soup

450g (1lb) Leeks, trimmed, washed and cut into rings
450g (1lb) Potatoes, peeled, washed and thinly sliced
2 tablespoons vegetable oil
500ml (1 pint) hot vegetable stock
Salt and Pepper
250ml (1/2 pint) single cream
250ml (1/2 pint) milk

Method

Cook on a ‘Eco’ setting for 6 hrs.

1. Prepare leeks and potatoes.
2. Fry leeks in oil until soft. Add potato slices and cook for 3 minutes.
3. Add stock and seasoning, bring to boil.
4. Transfer to large casserole dish, cover with foil and fit lid tightly. Place in oven.
5. At end of cooking, puree until thick and smooth.
6. Stir in cream and milk and re-heat gently, do not boil.

Stuffed Peppers

4 Peppers, washed
1 tablespoon vegetable oil
1 small onion, peeled and diced
4 mushrooms, wiped and sliced
1 courgette, sliced
2 tomatoes, peeled and chopped
50g (2oz) long grain rice, cooked
Salt and Pepper

1. Cut tops of peppers, deseed and carefully remove stalks from tops.
2. Blanch in boiling water for 2 minutes, drain.
3. Heat oil in pan, cook onion until soft.
4. Add mushrooms, courgette and tomatoes, cook for 3-4 minutes.
5. Add rice and seasoning, cook for 2 minutes.
6. Place blanched peppers in casserole dish, divide vegetable mixture equally into the peppers. Put lids on peppers.
7. Cover dish tightly with foil and the lid.
8. Place in oven.

Using The 'Eco' Setting

Points to bear in mind when preparing food:--

1. Make sure all dishes will fit into the oven before preparing the food.
2. All dishes cooked by the 'Eco' setting should be cooked for a minimum of 6 hours. They will 'hold' at this setting for a further hour but marked deterioration in appearance will be noticed in some cases.
3. Joints of meat and poultry should be cooked at fan oven 170°C for 30 mins before turning to the Eco setting.
4. Meat over 2.7 Kg. (6 lbs.) and poultry over 2 Kg. (4 lbs. 8oz) are unsuitable for the Eco setting.
5. Always stand covered joints on a rack over the meat tin, to allow good air circulation.
6. Fork joints can only be cooked, if by testing with a meat thermometer and internal temperature of at least 88°C is reached.
7. This method is unsuitable for stuffed meat and poultry.
8. Always bring soups, casseroles and liquids to the boil before putting in the oven.
9. When casseroles are used, cover the food first with foil and then the lid to prevent loss of moisture.
10. Always thaw frozen food completely before cooking.
11. Root vegetables will cook better if cut into small even sized pieces.
12. Always adjust the seasoning and thickenings at the end of the cooking time.
13. Egg and fish dishes need only 1-5 hours cooking and should be included in day cooking sessions, where they can be observed from time to time.
14. Dried red kidney beans must be boiled for a minimum of ten minutes after soaking, before inclusion in any dish.

Storage and Re-heating of Food

1. If food is to be frozen or not served immediately, cool it in a clean container as quickly as possible.
2. Thaw frozen food completely in the refrigerator before re-heating.
3. Re-heat food thoroughly and quickly either on the hotplate or in the fan oven, 170°C and then serve immediately.
4. Only re-heat food once.

To Set Timer To Switch ON and OFF Automatically (cont.)


The oven will no longer operate until the timer has been reset to manual operation.

Step 6
Turn off the oven control.


Step 7

Press the manual button to cancel the bleeping sound. (If 2 minutes has not elapsed.)

Press manual button again to return oven to **Manual Operation.**



Other Notes On Timer Operation

1. When cooking Automatically the cook period can be checked at any time simply by pressing the cook period button.
2. When cooking Automatically the End time can be checked at any time by simply pressing the stop time button. (This also can be altered at any time by following step 4 above.
3. Having set a cooking period and End time an electronic device stores the information. The device within the timer will switch the oven on at the required start time.
4. If a mistake is made and is not readily rectified after the cook period to show **0.00** (as per Step 3 above) then press the Manual button (see Step 7 above) and start the sequence again.
5. After an Automatic sequence the bleeping sound could also be switched off by pressing any of the three buttons **Minute Cook**, **End Manual**, **Cook Period**, **End Time**.
 

However the cooker cannot be re-used until the timer has been set to manual operation, this is achieved by pressing the manual button (see Step 7 above).
6. If at any time the display shows three flashing zero's **0.00**. It is likely that the electricity supply to the oven has been interrupted. Reset the timer to the correct time of day. *Food in the oven may therefore not have been cooked, before serving check food is thoroughly cooked.*
7. To give yourself more time to set each function press and hold the required function button and at the same time press "+" or "-" button.

NOTE: Between the hours of 10.00p.m. and 6.00a.m. the intensity of the display reduces.


To Set The Minute Minder



Step 1
Ensure the time of day is set correctly.


Step 2
Press and release the Minute Minder Button. Within 5 seconds press and hold the “+” button until the required time is set, a bell symbol will be lit.

This can be adjusted by pressing the “-” button.



The timer will then revert back to the time of day.
At the end of the set time a beeping sound will be heard and the bell symbol will flash.

This can be cancelled by pressing the Minute Minder button.



NOTE: If necessary the Minute Minder can be cancelled before the tone sounds by pressing the Minute Minder button and then pressing the “-” button until 0.00 appears in the display window.

The ‘Eco’ Setting 90°C

This is used for slow cooking, keeping food warm and warming plates for short periods. Extra care must be taken when warming bone china as it may be damaged if too hot.

Some advantages of slow cooking

are:
The oven stays cleaner because there is less splashing.

Timing of food is not as critical, so there is less fear of overcooking.

Inexpensive cuts of meat are tenderised.

Fully loading the oven can be very economical.

Cooking times can be extended in some cases by up to 2hrs. for late-corners.

The kitchen stays cooler.

Bearing in mind these advantages, it makes sense to cook larger quantities of food than required and store them in a freezer to be used cold or for re-heating. It is important to follow the guidelines given for preparing food using the ‘Eco’ setting.

Defrosting Frozen Meat and Poultry

Joints of meat and whole birds should be defrosted slowly, preferably in a refrigerator (allowing 5-6 hours per lb), or at room temperature (allowing 2-3 hours per lb).

Frozen meat or poultry must be completely defrosted before placing in the oven.

The Main Oven has a Fan Only position. Set Multifunction Selector switch to Fan Only function - this can be used to assist defrosting by circulating the air around the food, time to defrost will depend on type and size of the food and the room temperature.

DO NOT turn the temperature control on.

DO NOT defrost meat and poultry by warming the food through.

Foods ideally suited for fan defrosting (without heat) are those which are normally served cold, e.g. cream/cream cakes, butter cream filled cakes, gateaux, cheese cakes, iced cakes, quiches, pastries, biscuits, bread, croissants, fruit and many delicate frozen foods.

If fish, meat and poultry are to be 'fan only' defrosted as selected on the Selector Switch (without heat), then where possible the items of food should be small and thin, eg. fish filets, peeled shrimp, cubed or ground meat, sliced meat, thin chops, steaks or liver.

The items should be placed so the maximum amount of surface area is exposed to the circulating air and turned regularly to ensure even defrosting.

Fan defrosting without heat is only suitable for meat and poultry joints up to a maximum weight of 4lb.

It is important to wash both roast and cooking utensils immediately after defrosting.

It is vitally important to strictly adhere to the basic principles of food handling and hygiene to prevent the possibility of bacterial growth.

Defrosting

Food can be defrosted in the main oven as though it was thawing at room temperature, with the advantage that it is much quicker. The selector switch should be set at Fan Only and the food for defrosting placed on a tray.

No heat is required for defrosting.

Automatic Cooking

Never operate the Grill when the ovens are set to cook automatically.

Hints on Automatic Cooking

1. Select foods which will take the same time to cook and require approximately the same temperature.

2. Set the oven timer so that the food has just finished or about to finish cooking on your return to the oven. This will ensure the food has not cooled down and does not require reheating before serving.

3. Food should be as cold as possible when it goes into the oven, ideally straight from the refrigerator. Frozen meat and poultry should be thawed thoroughly before it is put into the oven.

4. We advise that warm food should never be placed in the oven if there is to be a delay period. Stews prepared by frying the meat and vegetables should be cooked as soon as possible.

5. We advise dishes containing left over cooked poultry or meat, for example shepherd's pie, should not be cooked automatically if there is to be a delay period.

6. Stews and joints should be cooked by the long slow method, so that the delay period is kept to a minimum.

7. On warm days, to prevent harmful bacteria growth in certain foods (ie: poultry, joints, etc) the delayed start should be kept to a minimum.

8. Wine or beer may ferment and cream may curdle during the delay period, so it is best to add these ingredients just before serving.

9. Foods which discolour should be protected by coating in fat or tossing in water to which lemon juice has been added, prior to placing food in the oven.

10. Dishes containing liquid should not be filled too full to prevent boiling over.

11. Foods should be well sealed (but not airtight) in a container to prevent the loss of liquid during cooking. Aluminium foil gives a good seal.

12. Ensure food is cooked thoroughly before serving.

Grilling in the Top Oven

Keep young children away from the appliance when the grill is in use as the surfaces get extremely hot.

Grilling should NOT be undertaken with the Grill/Top Oven door closed. (See below)

Never: Line the grill pan with aluminium foil.

The grill control provides variable heat control of the grill element and will only operate once the oven control has been set to a grill position (fully clockwise).

The grill regulator is designed to provide variable heat control of either the twin grill elements on together or the single left-hand grill element only, depending on which mode you select:

To select twin grill, first turn the Top Oven/Grill Selector clockwise to Full Grill.

The heat can now be adjusted by setting the grill regulator.

To select single grill turn the Top Oven/Grill Selector clockwise to Half Grill. In both cases the oven light and control panel illumination will come on.

Food which requires browning only should be placed under the hot grill directly on the shelf in the first or second runner from the bottom of the oven, according to the depth of the dish.

Care should be taken when removing the grill pan during or directly after use.

After use, always return both controls anticlockwise to the **OFF** position.

NOTE: The grill pan must be cleaned after every use. Excess fat build up in the bottom of the pan could cause a fire hazard.


The heat can now be adjusted by setting the grill regulator.

Please note that the Grill will not operate unless the Top Oven/Grill Selector is in a grill position. After use, turn both controls ANTI-CLOCKWISE to their off positions.

Grill Procedure

Ensure oven timer is set to Manual. Pre-heat the grill at setting 6 for approximately 5 minutes.

When toasting/grilling, the rod shelf is placed in either the first or second runner position from base. The grill pan is placed on the shelf and pushed back as far as possible to correctly position it under the grill element. Leave the control at 6 for toast, and for sealing and fast cooking of foods. For thicker foods requiring longer cooking, turn the switch to a lower setting after the initial sealing on both sides at 6. The thicker the food, the lower the control should be set.



Cooking in the Lower Oven – Fan Cooking



Operation

Turn the Multifunction Selector switch to the required function. The control panel illumination and oven light will remain on.

Then set oven temp control to the required temperature. The oven thermostat light will immediately come on and remain on until the oven reaches the set temperature. This light will then automatically turn on and off during cooking and the oven will operate whilst the oven is switched on and door closed.

Note: If the thermostat light does not come on when the Oven Temp Control is turned, check that the Timer is in Manual Operation.

Since a fan oven heats up more quickly, and generally cooks food at a lower temperature than a conventional oven, pre-heating the oven is often unnecessary. However, foods such as bread, scones, Yorkshire pudding, do prefer to be placed in a pre-heated oven.

The charts on pages 21 and 22 are a guide only, giving approximate cooking temperatures and times. To suit personal taste and requirements, it may be necessary to increase or decrease temperatures by 10°C.

Oven Positions

Since the distribution of heat in fan ovens is very even, most foods will cook satisfactorily on any shelf position, but the shelves should be evenly spaced.

To ensure even circulation do not use meat pans larger than 390 x 300mm (15in x 12in) and baking trays no larger than 330 x 255 mm (13in x 10in), these should be positioned centrally on the oven shelf.

Food should not be placed directly on the floor of the oven.

Never use more than 3 shelves in the oven as air circulation will be seriously restricted.

To avoid unnecessary cleaning, rod shelves which are not in use should be removed from the oven.

Allow extra cooking time when batch baking eg. 6 x 150 mm (6 in) Victoria sandwich tins.

Temperature and Time

When all three shelves are used to cook large quantities of food for home freezing or parties, it may be necessary to increase the cooking times given in the charts on pages 21 and 22 by a few minutes.

NB. Recipes in cookery books give times and temperatures for cooking in conventional ovens. To adapt for fan oven refer to the temperature chart on page 12.

Oven Interior Light Lower (Main) Oven

To select oven light only, turn the multifunction selector switch to the oven light function. The oven light will come on.

Cooling Fan

A cooling fan is incorporated to protect the oven controls and oven housing from overheating. It will operate when any of the oven controls are switched **On** and may continue for a time after all controls are **Off**. A gentle flow of air will be projected from below the control panel.

If the controls become too hot, a cut-out comes into operation and the Top Oven/Grill will switch off (cut-out thermostat behind the controls) and only the oven clock will remain on. The cut out will reset automatically and oven switch on.

If this operates frequently there is a fault with your appliance. Contact your local service office.


Lower Oven Temperature Chart – Fan Grilling

Shelf positions are counted from the base upwards ie: lowest shelf position is 1.

| Type of Meat or Poultry | Weight Kg | Temp °C | Time (min/kg) | Plus Extra Time (mins) | Total Cooking Time (mins) | Tips |
|--|--|---|---|----------------------------------|--|---|
| PORK Pork Chop - thick | | 170 | 25 | - | Dependent on size | Season grill on shelf position 2. Turn over after 15 mins. |
| Game Steaks | | 160 | 30 | - | Dependent on size | Grill on shelf position 2. Turn after 15 mins. |
| Pork - any type of joint | 1.0 1.5 2.0 2.5 over 2.5 | 160-170 150-170 140-150 140-150 140 | 60-70 60-70 65-75 65-75 70-75 | 45 45 50 50 50 | 105-120 130-150 180-230 220-240 | Score fat with sharp knife and rub on salt. Pork should always be thoroughly cooked. So overcook rather than undercook. Grill on shelf position 1. |
| LAMB Lamb chop - thick | | 170 | 25 | - | Dependent on size | Season. Grill on shelf position 2. Turn over after 15 mins. |
| Lamb - any type of joint | 1.0 1.5 2.0 2.5 over 2.5 | 160-170 160-170 150-160 150-160 150 | 30-40 35-40 35-45 40-45 45-50 | 45 45 50 50 50 | 78-88 90-110 120-140 150-170 | Score fat. Season with pepper and rosemary, if you prefer the lamb pink. Choose the shorter time. Grill on shelf position 1. |
| BEEF Beef - joints which have an outside layer of fat eg. Rib, Rolled, Sirloin | 1.0 1.5 2.0 2.5 over 2.5 | 170-180 170-180 160-170 160-170 160 | 40-50 40-50 40-50 45-50 45-50 | 20 20 20 30 40 | 60-70 80-90 100-110 140-150 | Season. If joint preferred rare grill for the shorter time. If preferred well done grill for the longer time. Grill on shelf position 1. |
| CHICKEN | 1.0 1.5 2.0 2.5 over 2.5 less than 1kg each | 180 180 170 170 160-170 180 | 30 30 35 35 40 30 | 30 30 30 30 30 30 | 60 75 100 115 | Season and brush over with melted butter to give nicely browned skin. Grill on shelf position 1. |
| Chicken joints | | 180 | 30 | - | 60 | Shelf 1. |
| DUCK | 1.5 2.0 2.5 | 180 180 180 | 30 30 35 | 30 30 30 | 75 90 115-130 | Dry thoroughly and lightly salt. Grill on shelf position 1. |
| GOOSE | up to 4 4-5 | 170-190 160-170 | 40 45 | 40 40 | - | Can be stuffed. Grill on shelf position 1 |
| TURKEY | up to 5 6-8 | 170 150 | - | - | 150-165 165-175 | Season and brush over with melted butter to give nicely browned skin. Grill on shelf position 1 |
| GAME Grouse Partridge Pheasant | Any Any Any | 170-180 170-180 170-180 | 30-50 40-50 40-50 | - | - | Well hung meat will require less cooking time. grill on position 1. |
| Beefburgers | 450g(lb) | 170 | 25mins per 450g (lb) | - | - | Shelf 2. |
| Sausages | 450g (lb) | 170 | 25mins per 450g (lb) | - | - | Shelf 2. Prick sausages before cooking. |
| Bacon | 450g (lb) | 170 | 25mins per 450g (lb) | - | - | Shelf 2. Roll up Bacon before cooking. 4 pieces of steak, sausages, chops, Bacon, tomatoes & mushrooms. Cook sausages, chops, Bacon for 10 mins, add steak, cook for further 20 mins. Tomatoes & mushrooms should be placed on inner under roasting rack for total cooktime. |
| Mixed Grill | | 170 | | | 30 | |

Fixing the Grill Pan Handle

Fix the grill pan handle securely in position before use. The grill pan handle is detachable from the pan, to facilitate cleaning and storage. The handle fits onto the grill pan edge with the small recess, Fig. 5.



Tilt the handle over the recess and slide it towards the centre, Fig. 6. Ensure the handle is fully located Fig. 7. Insert the washer and fixing screw and tighten fully to ensure handle is secured.

Always fit the screw prior to use.

Cooking in the Top Oven – Conventional Cooking

The Top Oven can be used to cook small quantities of food or used in conjunction with the Main Oven to provide additional cooking space so often necessary when entertaining.

The oven is designed so that the grill element operates at a reduced heat output (element will not glow), combined with a heating element situated underneath the floor of the oven.

Do not place items directly onto the floor of the oven.

To ensure even cooking of the food it is important that cooking utensils are positioned correctly on the oven shelf directly beneath the element. (As a guide, the front of the utensil should be approximately 100 mm/4 in from the front of the shelf.)

There are two cooking positions, the shelf placed on runner 1 or 2 (from the base).

Food or utensils must never be placed directly on the floor of the oven.

There should always be at least 25mm (1 in) between the top of the food and the grill element.

Do not use utensils larger than 300mm x 230mm (12in x 9in). Larger utensils should be used in the Main oven.

Operation

To heat the oven, turn the Top Oven/Grill Selector clockwise, selecting the required temperature between 100°C (200°F) and 220°C (425°F) as recommended in the Top Oven Temperature Charts. The oven light and the control panel illumination will come on.

The Top Oven indicator light will immediately come on and remain on until the oven reaches the required temperature.

The indicator light will then automatically go off and on during cooking as the thermostat maintains the correct temperature. If the indicator light doesn't come on when the control knob is turned, check that the oven timer is set to Manual as described in 'Oven Timer Operation'.

Cooking Meat/Poultry in the Top Oven

The Top Oven is most useful for the longer slower cooking required for cheaper cuts of meat – casserole cooking, pot roasting, braising etc. Small joints of meat up to 1.5 kg (3 lb), or poultry, up to 3.6 kg (8 lb) in weight can be roasted in a small meat pan in the Top Oven, but should preferably be 'slow roasted' or covered with a lid of aluminium foil (one or two incisions in the top of the foil will allow the meat or poultry to brown).

Larger joints of meat, and poultry weighing more than 3.6 kg (8 lb), should be roasted in the Main Oven.

Do not use the Main Oven meat pan or the grill pan as a meat pan in the Top Oven as air circulation will be seriously restricted.

Top Oven as a Warming Compartment for Plates and Dishes

Place the plates and dishes on the shelf that has been positioned on runner 1 (from the base) and turn on the Top Oven/Grill Selector clockwise to the Platewarming position for 10-15 minutes. **DO NOT** use the grill control.

Cooking in the Lower Oven - Fan Grilling

As with the Circulaire fan oven cooking there is no need to pre-heat the oven – yet another economy feature. Also you can cook more than one thing at a time – even up to 4 small chickens.

Temperatures


These will be similar to those used for the more traditional form of roasting but the guide will give you an indication of which temperature to set the Thermostat. But remember that because of the way the oven is heated this is a more economical way of roasting.

General Recommendations

Most types of meat and poultry cooked by this method will have an all over brownness and crispness on the outside. The only exceptions are very lean joints, such as veal, which, because of its low fat content, is better cooked using conventional heating.

1. **Always** place the pan on the shelf position recommended. (See Chart).
2. There is no need to preheat the oven before cooking and all fan grilling should be carried out with the oven door closed, this saves energy. The cooking temperatures and times are calculated from a cold oven.
3. After rinsing and drying meat, place on the food support roasting rack over the meat pan supplied with the anti-splash trivet in position. It is important that the anti-splash trivet is used, as it will stop the splashing of fat and help keep the oven clean.
4. Position meat in oven as recommended in the roasting chart.
5. Fan grilling is ideally suited for cooking all types of poultry and larger joints of meat (e.g. stuffed, rolled joints and legs of pork and lamb). Results will be as if you had cooked the food on a rotisserie. If you use frozen meat or poultry it must be completely defrosted before it is cooked.

6. When cooking a joint always grill it with the fat side uppermost in order to crisp it. For bigger joints or where there is little bone, grill at the lower temperature given in the table and cook for a longer time per kg.
7. When cooking any type of poultry start grilling the underside uppermost and turn breast uppermost about a third to halfway through the cooking period. If cooking stuffed poultry allow slightly longer cooking time.



Pan trivet and food support rack.

Turn the Multifunction Selector Switch to Fan Grill and Thermostat to temperature required as shown in the chart on page 25. Turn the food over approximately halfway through cooking, taking care not to burn yourself.

The fan grilling operation can be selected/timed using the automatic oven timer. See pages 15 to 17. See Fan Grilling Roasting Chart on page 25.

Grilling in the Lower Oven Temperature Chart

| Food | Preheat for 5 mins | Shelf Position from Base of Oven | Approx. Cooking Time |
|--|--------------------|----------------------------------|--------------------------------------|
| Toasting of Bread Products | 230°C | 6 | 3-10 mins, depending on type of food |
| Small cuts of meat, sausages, bacon, etc | 150°C | 5 or 6 | 5-15 mins |
| Chops etc | 170°C | 5 | 25-30 mins |
| Fish whole Fillets | 170°C | 5 | 10-15 mins |
| Pre-cooked potato products | 200-230°C | 6 | 10 mins |
| Pizzas | 170°C | 5 | 12-15 mins |
| Browning of Food | 230°C | 5 | 10-15 mins depending on type of food |

The temperatures below relate to heat settings recommended on food packs

High = 230°C
 Medium High = 200°C
 Medium = 175°C

Medium Low = 150°C
 Low = 130°C
 Very Gentle = 100°C

Oven Temperature Charts – Baking

| Baking | Top Oven Cooking | | | | Fan Oven Cooking | | |
|-------------------------------|------------------|----------|--------------------------|-------------------------------|------------------|----------|-------------------|
| | Food | Pre-heat | Temperature °C | Time in mins. | Position in Oven | Pre-heat | Temperature °C |
| Scones | Yes | 210/220 | 10-15 | Runner 1 from bottom of oven. | Yes | 210/220 | 8-10 |
| Small Cakes | Yes | 180/190 | 20-25 | Runner 1 from bottom of oven. | | 170/180 | 15-20 |
| Victoria Sandwich | Yes | 170/180 | 20-30 | Runner 1 | | 160/170 | 20-25 |
| Sponge Sandwich (fatless) | Yes | 180/190 | 20-25 | Runner 1 from bottom of oven. | Yes | 170/190 | 15-20 |
| Swiss Roll | Yes | 200/210 | 10-15 | Runner 1 from bottom of oven. | Yes | 180/200 | 12-15 |
| Semi-rich Fruit cakes | Yes | 150/160 | 60-75 7 inch | Runner 1 | | 140/150 | 75-90 |
| Rich Fruit Cakes | Yes | 140/150 | Time Dependent on size | Runner 1 | | 130/140 | Depending on size |
| Shortcrust Pastry | Yes | 190/200 | Time Dependent on recipe | Runner 1 from bottom of oven. | | 190/200 | 45-50 |
| Puff Pastry | Yes | 200/210 | Time Dependent on recipe | Runner 1 from bottom of oven. | | 190/200 | Dependent on use |
| Yorkshire Pudding | Yes | 190/200 | 30-40 | Runner 2 from bottom of oven. | Yes | 180/190 | 40-45 |
| Individual Yorkshire Puddings | Yes | 200/210 | 20-30 | Runner 2 from bottom of oven. | Yes | 190/200 | 20-25 |
| Milk Pudding | Yes | 140/150 | 90-120 | Runner 1 | | 130/140 | 105-135 |
| Baked Custard | Yes | 150/160 | 40-50 | Runner 1 | | 140/150 | 40-50 |
| Bread | Yes | 200/210 | 30-45 | Runner 1 | Yes | 200/210 | 45-50 |
| Meringues | Yes | 100 | 150-180 | Runner 2 from bottom of oven. | No | 80-90 | 180-240 |

Note: If soft margarine is used for cake making, temperatures recommended by the manufacturers should be followed. Temperatures recommended in this chart refer to cakes made with block margarine only.

Oven Temperature Charts – Meat

| Top Oven Cooking | | | | | Fan Oven Cooking | | | |
|------------------------------|----------|----------------|--|-------------------------------|---------------------------------|----------|----------------|---|
| Meat | Pre-heat | Temperature °C | Time (approx.) | Position in Oven | Meat | Pre-heat | Temperature °C | Time (approx.) |
| Beef/ Lamb (slow roasting) | Yes | 170/180 | 35 mins per 450g (1lb) + 35 mins over. | Runner 1 from bottom of oven. | Beef | No | 160/180 | 20-25 mins per 450g (1lb) + 20 mins extra |
| Beef/ Lamb (foil covered) | Yes | 190/200 | 35-40 mins per 450g (1lb) | | Lamb | No | 160/180 | 20-30 mins per 450g (1lb) + 25 mins extra |
| Pork (slow roasting) | Yes | 170/180 | 40 mins per 450g (1lb) + 40 mins over | | Pork | No | 160/180 | 25-30 mins per 450g (1lb) + 25 mins extra |
| Pork (foil covered) | Yes | 190/200 | 40 mins per 450g (1lb) | | Veal | No | 160/170 | 25-30 mins per 450g (1lb) + 25 mins extra |
| Veal (slow roasting) | Yes | 170/180 | 40-45 mins per 450g (1lb) + 40 mins over | | Chicken/ Turkey up to 4kg (8lb) | No | 160/180 | 18-20 mins per 450g (1lb) + 20 mins extra |
| Veal (foil covered) | Yes | 190/200 | 40-45 mins per 450g (1lb) | | Turkey 4 to 5.5kg (8 to 12lb) | No | | 13-15 mins per 450g (1lb) at 150/160°C |
| Poultry/Game (slow roasting) | Yes | 170/180 | 25-30 mins per 450g (1lb) + 25 mins over | | over 5.5kg (12lb) | | | allow 12 mins per 450g at 150°C |
| Poultry/Game (foil covered) | Yes | 190/200 | 25-30 mins per 450g (1lb) | | Casserole Stews | No | 140-150 | 1½ - 2 Hrs |
| Casserole Cooking | Yes | 150 | 2-2½ hrs | | | | | |

If using aluminium foil, never: 1. Allow foil to touch sides of oven. 2. Cover oven interior with foil. 3. Cover shelves with foil.

The most accurate method of testing the readiness of joints of meat or whole poultry is to insert a meat thermometer into the thickest part of a joint, or the thickest part of poultry thighs, during the cooking period. The meat thermometer will indicate when the required internal temp has been reached.

Beef - Rare: 60°C **Lamb:** 80°C **Poultry:** 90°C
 Medium: 70°C **Pork:** 90°C
 Well Done: 75°C **Veal:** 75°C

Grilling in the Lower Oven



Keep young children away from the appliance when the grill is in use as the surfaces get extremely hot.

Grilling should NOT be undertaken with the Oven door closed.

Turn the Multifunction Selector Switch to Grill and the Oven temperature Control to the required temperature.

Grilling should be carried out with the oven door open (see fig. 6 below). It is advisable to pre-heat grill eg. for 5 mins. The grill pan with grid should be used at shelf position (see page 24) according to the various foods. Position the grill pan directly under the heating element. For toasting and sealing fast cooking foods leave the oven temperature control at 230°C. For thicker foods requiring longer

The oven door is designed to remain open at the position shown.

cooking times turn the Oven Temp. Control down to a lower temperature. The initial sealing of both sides at 230°C and the thicker the food, the lower the temperature on the Oven Temperature Control.

Food that only requires browning should be done on a lower shelf position. If excessive smoke is being emitted then turn the Oven Temp. Control to a lower setting and/or move the grill pan to a lower position.

After use, both controls should be returned to the **OFF** position.

NOTE: The grill pan must be cleaned after every use. Excess fat build up in the bottom of the pan could cause a fire hazard.

The grill will only operate when the oven temperature control and the Main Oven Selector have been set.

NOTE: Ensure that the oven timer is set at MANUAL




Fig. 6
Door Position for Grilling