

**SAMSUNG**

# ROOM AIR CONDITIONER


AW05B05A(AW0500, AW0500A)

AW05E05A(AW0510, AW1510A)

AW05F05A

# ***SERVICE*** Manual

## AIR CONDITIONER



## CONTENTS

1. Precautions
2. Product Specifications
3. Installation and Operating Instructions
4. Disassembly and Reassembly
5. Troubleshooting
6. Exploded Views and Parts List
7. Block Diagram
8. Wiring Diagram

# 1. Precautions

1. **Warning:** Prior to repair, disconnect the power cord from the circuit breaker.
2. **Use proper parts:** Use only exact replacement parts. (Also, we recommend replacing parts rather than repairing them.)
3. **Use the proper tools:** Use the proper tools and test equipment, and know how to use equipment may cause problems later—intermittent contact, for example.
4. **Power Cord:** Prior to repair, check the power cord and replace it if necessary.
5. **Avoid using an extension cord, and avoid tapping into a power cord.** This practice may result in malfunction or fire.
6. **After completing repairs and reassembly, check the insulation resistance.** Procedure: Prior to applying power, measure the resistance between the power cord and the ground terminal. The resistance must be greater than 30 megohms.
7. **Make sure that the grounds are adequate.**
8. **Make sure that the installation conditions are satisfactory.** Relocate the unit if necessary.
9. **Keep children away from the unit while it is being repaired.**
10. **Be sure to clean the unit and its surrounding area.**




Fig. 1-1 Avoid Dangerous Contact




Fig. 1-2 No Tapping and No Extension Cords




Fig. 1-3 No Kids Nearby!




Fig. 1-4 Clean the Unit

# MEMO

## 2. Product Specifications


### 2-1 Table

Item	Unit of Measure	AW05B05A (AW0500)	AW05E05A (AW0510)	AW05B05A (AW0500A)	AW05E05A (AW0510A)	AW05F05A	Remarks
Type	-	Window					
Dimensions:	Inches	17 13/16 x 12 3/8 x 13 9/16					
Width x Height x Depth	mm	452 x 314 x 345					
Packing Size:	Inches	19 11/32 x 14 7/8 x 17 11/32					
Width x Height x Depth	mm	491 x 378 x 440					
Voltage:	Volt	115					
Phase	-	Single					
Frequency	Hz	60					
Operating Current	A	5.6	4.8	5.6	4.8	4.8	
Power Consumption	W	625	515	625	515	560	
Refrigerant Type	FREON	R-22					
Refrigerant Charge	OZ(kg)	9.0(255)	12.0(340)	9.0(255)	12.0(340)	12.0(340)	
Cooling Capacity	BTU/h	5,000	5,100	5,000	5,100	-	
	Kcal/h	-	-	-	-	1,250	
E.E.R	(BTU/h,W)	8.0	9.7	8.0	9.7	9.7	
	(Kcal/hw)	-	-	-	-	2.22	
Humidity Removed	LT/h	1.5	1.5	1.5	1.5	1.5	
Air Circulation	C.F.M	134	125	134	125	125	
Net Weight	LBS	46	46	46	46	46	
Condenser	Row	1	2	1	2	2	
Condenser Fan	Type	Propeller Fan					
Evaporator	Row	1	2	1	2	2	
Evaporator Fan	Type	Squirrel Cage					
Fan Motor	Model	AFS015ZREA					
Compressor(Rotary)	Model	44A052HW1KA	44A052HS1KA	2R7S126A6F	2R7S126A6F	44A052HS1KA	
Overload Protect	-	MRA12040-12008					
Fan Motor Capacitor	μF/VAC	4 & 30/370	3.5 & 30/370	4 & 35/270	3.5 & 35/370	3.5 & 30/370	
Compressor Capacitor	μF/VAC	(DUAL TYPE)					
Plug Type	-	Parallel					
Fan Speed Control	-	Selector S/W					
Thermo Control	-	Thermostat					
Design Pressure	PSI	300/150					
High Side/Low Side							

# 2-2 Dimensions

---

Unit : mm



---

## 3. Installation and Operating Instructions

---

### 3-1 Installation

---

#### 3-1-1 Selecting Area for Installation


Select an area for installation that is suitable to the customer's needs.

1. Make sure that you install the unit in an area providing good ventilation. The air conditioner must not be blocked by any obstacles affecting the airflow near the air inlet and the air outlet.
2. Make sure that you install the unit in an area that allows good air handling. The installation area must be able to endure vibration from the unit.
3. Make sure that you install the unit away from heat or vapor.
4. Make sure that you install the unit in an area which is cool and has adequate space.
5. Make sure that you install the unit in an area away from TVs, audio units, cordless phones, fluorescent lighting fixtures and other electrical appliances (at least 1 meter clearance).
6. Make sure that you install the unit in an area which provides easy drainage for condensed water.
7. Make sure that you install the unit in area not exposed to the rain or direct sunlight. (Install a separate sunblind if exposed to direct sunlight).
8. Make sure that you install the unit in an area allowing good air movement. Do not install it in a space that would cause noise amplification of noise.
9. Fix the unit firmly if mounted in a high place.

**Caution:**

It is harmful to the air conditioner if it is used in the following environments : greasy areas (including areas near machines), salty areas such as coast areas, areas where sulfuric gas is present (such as hot spring areas), Contact your dealer for advice.

## 3-2 Controls and Components



### 3-2-1 Thermostat


- Control Operation :  
By turning control knob clockwise(toward higher numbers), the temperature will be cooler.  
By turning the control knob counterclockwise(toward lower numbers), the temperature will be warmer.
- Level 1 : Cool air will be supplied above 30~35°C  
Cool air will be ceased below 28~32.5°C
- Level 10 : Cool air will be supplied above 11~17°C  
Cool air will be ceased below 7~13°C

### 3-2-2 Selector

- Slowly turn the Fan Selector Switch in the following order :  
to LOW FAN, HIGH FAN, HIGH COOL, MED COOL, LOW COOL.
- OFF : All functions will be off.
- LOW FAN : The circulation of air is low.
- HIGH FAN : The circulation of air is maximum.
- LOW COOL : Circulation, cooling, and humidity removal are low(all simultaneously operated).
- MED COOL : Circulation, cooling, and humidity removal are medium(all simultaneously operated).
- HIGH COOL : Circulation, cooling, and humidity removal are maximum(all simultaneously operated).

## 4. Disassembly and Reassembly

### 4-1 Compressor Replacement Flow Chart





## 4-2 Checking the Oil

---

Put approximately 10cc oil into a transparent container and test it.

### 4-2-1 Oil quality

Condition of Refrigerant Cycle	Condition of Oil		Remarks
	Color	Odor	
Normal	Light Yellow	No Odor	Return with the system
Overheat	Brown Color	-	Oil Change
Motor Damage	Dark Brown	Pungent Oil	Oil Change

### 4-2-2 Changing and adding refrigerant oil

1. Change the compressor - DO NOT recharge the oil as the compressor itself is already charged.
2. Change the condenser .... add 50cc
3. Change the evaporator .... add 50cc
4. When the refrigerant is replaced .... add 30cc oil.
5. After vacuum is completed, the oil is filled through the high pressure side.
6. In the event of a refrigerant leak, generally it is not necessary to add oil (unless the oil has leaked significantly).





## 4-3 Refrigerant Oil Specifications

---




Model	Oil Specification	Oil Change
AW05B05A(AW0500)	SONTEX 200LT	260CC
AW05E05A(AW0510)	SONTEX 200LT	260CC
AW05B05A(AW0500A)	SUNISO 4GDID	260CC
AW05E05A(AW0510A)	SUNISO 4GDID	260CC
AW05F05A	SONTEX 200LT	2600CC
AW05F05A	SUNTEX 200LT	260CC

## 4-4 Disassembly and Reassembly Procedure

Stop operating of the air conditioner and remove the power cord before repairing the unit.

No.	Part name	Procedures	Remarks
①	Ass'y - Grille	<ol style="list-style-type: none"> <li>1. Remove the knobs and the grille screw located behind the guard air filter.</li> <li>2. Remove the grille from the cabinet by pushing in on the grille tabs on both cabinet sides, and then lift the grille off the top latches.</li> </ol>	
②	Ass'y - Frame	<ol style="list-style-type: none"> <li>1. Remove the 7 screws on each of the cabinet and lift the cabinet upward.</li> </ol>	
③	Ass'y - Evaporator	<ol style="list-style-type: none"> <li>1. Remove foam-seal on the top of the unit.</li> <li>2. Remove 4 screw on the both side of evaporator.</li> <li>3. Separate the evaporator from the unit.</li> </ol>	
④	Ass'y - Blower	<ol style="list-style-type: none"> <li>1. Loose the nut to disassemble the blower.</li> </ol>	

## Disassembly and Reassembly

No.	Part name	Procedures	Remarks
⑤	Ass'y - Condenser & Fan propeller	<ol style="list-style-type: none"> <li>1. Remove the 2 screws on the bottom between the base-pan and the condenser and 2 screws on left side of condenser.</li> <li>2. Separate the cond-casing from the base-pan.</li> <li>3. Loose the nut to disassemble the fan-propeller.</li> <li>4. Separate the fan-propeller from the motor and the cond-casing.</li> </ol>	
⑥	Ass'y - Control	<ol style="list-style-type: none"> <li>1. Remove the 2 screws at the bottom of between the base-pan and the control-box.</li> </ol>	
⑦	Ass'y - Motor	<ol style="list-style-type: none"> <li>1. Remove the 2 screws on the motor and mounor motor.</li> <li>2. Separate the motor from mounor motor.</li> </ol>	

---

## 5. Troubleshooting

---

Before troubleshooting the air conditioner,  
it is necessary to determine whether the electrical power or the electrical parts are faulty.  
Follow this procedure :

---

### 5-1 Method of Troubleshooting and Cautions on Troubleshooting

---

#### 5-1-1 Check the Voltage of the power source.

The input voltage shall be 115V/60Hz  
The air conditioner may not operate properly if the voltage is out of this range.


#### 5-1-2 Check weak and fragile parts.

#### 5-1-3 Check the connection of terminals.

#### 5-1-4 When a malfunction occurs:

Malfunction		Check point	Possible cause
①	The compressor does not operate.	1. check the thermostat position. 2. check the connection of the lead wire. 3. check the over load protector. 4. check the compressor.	1. Setting temp is lower than room temp. 2. Disconnection of the lead wire. 3. O.L.P is faulty 4. Compressor is faulty
②	The motor does not operate.	1. check the connection of the lead wire & switch. 2. check the motor	1. disconnection of the lead wire 2. switch is faulty. 3. motor is faulty
③	The cooling capacity is low.	1. check the refrigerant leakage. 2. check the evaporator condition ( freezing, blocked with dusts, etc. ) ※Difference of temp. exists between the suction side and the discharge side at least 12°C ※Standard condition Indoor : 27°C outdoor : 35°C	1. Caused by the pipe crack 2. shortage of refrigerant 3. clean the evaporator & air filter.
④	Noise	1. check vibration of the pipe 2. check the propeller fan and blower ( not loose or broken ). 3. check bearing noise of the motor 4. check the compressor noise against that of other compressors.	1. pipes are contact with the other parts. 2. the hex nut is loose 3. the parts are broken 4. motor is faulty 5. compressor is faulty

# 6. Exploded View and Parts List



Part List

No.	Code No.	Description	Specification	Q'TY					Remarks
				AW05B05A (AW0500)	AW05E05A (AW0510)	AW05B05A (AW0500A)	AW05E05A (AW0510A)	AW05F05A	
1	DB64 - 00124A	KNOB - THERMO	ABS, SC - 94445R, ASSY	1	1	1	1	1	
2	DB64 - 00124B	KNOB - SELECTOR	ABS, SC - 94445R, ASSY	1	1	1	1	1	
3	DB92 - 00034A	ASSY - GRILLE	ASSY, SC - 94445R	1	1	1	1	-	
	DB92 - 00032B	ASSY-GRILLE	ASSY, SC - 94445R	-	-	-	-	1	
3-1	DB64 - 00043A	GRILLE - FRONT	HIPS, SC - 94445R	1	1	-	-	1	
3-2	DB66 - 00023A	BLADE - V	PP, SC - 94445R	1	1	1	1	1	
4	DB66 - 00024A	LEVER - DAMPER	ABS, SC - 94445R	1	1	1	1	1	
5	DB63 - 00026A	GUARD - AIR FILTER	ABS, SC - 94445R	1	1	1	1	-	
	DB63 - 00026B	GUARD - AIR FILTER	ABS, SF(GREEN)	-	-	-	-	1	
6	DB63 - 00027A	TRAY - DRAIN	EPS	1	1	1	1	1	
7	DB96 - 00208A	ASSY - EVAP	D - FIN, OD 9.52 1R	1	-	1	-	-	
	DB75 - 00028A	ASSY - EVAP	T3, OD 2R	-	1	-	1	1	
8	DB70 - 00014A	PLATE - EVAP CASING	SGCC - M	1	1	1	1	1	
9	DB60 - 30004A	NUT - FLANGE	SM20C, NTR	1	1	1	1	1	
10	DB67 - 00013A	BLOWER	ABS	1	1	1	1	1	
11	DB61 - 00083A	CASE - EVAP	EPS	1	1	1	1	1	
12	DB73 - 00031A	RUBBER - PIPE	NR, BLK	1	1	1	1	1	
13	DB63 - 00031A	COVER - PIPE	PP	1	1	1	1	1	
14	DB67 - 00012A	PARTITION	SGCC - M	1	1	1	1	1	
15	DB61 - 00084A	MOUNT - MOTOR	SGCC - M	1	1	1	1	1	
16	DB31 - 00035A	MOTOR - FAN	AFS015ZREA	1	1	1	1	1	
17	DB61 - 00085A	CASE - COND	SGCC - M	1	1	1	1	1	
18	DB67 - 00014A	FAN - PROPELLER	ABS	1	1	1	1	1	
19	DB60 - 30020A	NUT - FLANGE	M6, FEFZY, LF	1	1	1	1	1	▲
20	DB96 - 00210A	ASSY - COND	SLIT, OD 7.0, 1R	1	-	1	-	-	▲
	DB96 - 00209A	ASSY - COND	T3, OD 2R x 15S	-	1	-	1	1	
21	DB90 - 00123B	ASSY - BASE	ASSY	1	1	1	1	1	
22	DB73 - 00016A	GROMMET - ISOLATOR	EPDM, BLK	3	3	-	3	3	
	DB73 - 00046A	GROMMET - ISOLATOR	EPDM, MEI COMP	-	-	3	3	-	
23	DB60 - 30028A	NUT - WASHER	HEX, 2C, M8, ZPC	3	3	3	3	3	
24	DB62 - 00249A	TUBE - DISCHARGE	C1220T-0, OD 7.93	1	-	-	-	-	▲
	DB62 - 00200B	TUBE - DISCHARGE	-	-	1	-	-	1	▲
	DB62 - 00365A	TUBE - DISCHARGE	C1220T-0	-	-	1	1	-	▲
25	DB62 - 00202A	TUBE - SUCTION	C1220T-0, OD 9.52	1	1	-	-	-	
	DB62 - 00366A	TUBE - SUCTION	C1220T-0, OD 9.52	-	-	1	1	-	
	DB62 - 00296A	TUBE - SUCTION	C1220T-0, OD 9.52	-	-	-	-	1	
26	DB96 - 00197B	ASSY - TUBE CAPILLAR	ID 1.2x1100	1	-	1	-	-	▲
	DB96 - 00200B	ASSY - TUBE CAPILLAR	ID 1.2x750	-	1	-	1	1	▲
27	DB63 - 20002A	GASKET	EPDM, T 0.8	1	1	-	-	1	
	DB63 - 00024A	GASKET	EPDM, T 0.8	-	-	1	1	-	
28	DB47 - 20002F	OLP	MRA12040 - 12008	1	1	-	-	1	
	DB35 - 00012A	OLP	MRA99087 - 9201	-	-	1	1	-	
29	DB63 - 10504A	COVER - TERMINAL	NORYL, BLK	1	1	-	-	-	
30	DB63 - 00090A	COVER - TERMINAL	EPDM, BLK	1	1	-	-	-	
	DB63 - 00023A	COVER - TERMINAL	NORYL, BLK, MEI COMP	-	-	1	1	-	
	DB63 - 10026A	COVER - TERMINAL	NORYL, BLK	-	-	-	-	1	
31	DB60 - 00001A	NUT - FLANGE	HEX, M5, SM20C	1	1	1	1	1	
32	DB63 - 00089A	COVER-PARTITION	ABS	1	1	1	1	1	
33	DB93 - 00259A	ASSY - CONTROL BOX	ASSY	1	-	-	-	-	▲
	DB93 - 00259B	ASSY - CONTROL BOX	ASSY	-	1	-	-	-	▲
	DB93 - 00259G	ASSY - CONTROL	AW0500A	-	-	1	-	-	▲
	DB93 - 00259H	ASSY - CONTROL	AW0510A	-	-	-	1	-	▲
	DB93 - 00259C	ASSY - CONTROL BOX	ASSY	-	-	-	-	1	▲
33-1	DB70 - 00019A	PLATE - CONTROL	SGCC - M	1	1	1	1	1	
33-2	3406 - 001045	SWITCH - ROTARY	DYU - 3, 240V, 25A	1	1	1	1	1	
33-3	DB47 - 20074B	THERMOSTAT	BU - A213	1	1	1	1	1	
33-4	2501 - 001205	C - OIL	30/4uF, 370V	1	-	-	-	-	▲
	2501 - 001154	C - OIL	30/3.5uF, 370V	-	1	-	-	1	▲
	0501 - 001219	C - OIL	35/3.5uF, 370V	-	-	-	1	-	▲
	2501 - 001221	C - OIL	35/4uF, 270V	-	-	1	-	-	▲
33-5	DB65 - 00031A	CLIP - CAPACITOR	SGCC-M	1	1	1	1	1	
33-6	DB39 - 10032J	POWER-CORD	SPT3, 125V, 10A, GRAY	1	1	1	1	1	
34	DB64 - 00046B	CABINET - OK	SCP1	1	1	1	1	1	
35	DB64 - 20005E	SHUTTER - ANGLE-UP	SC-94445T	1	1	1	1	-	
	DB64 - 20005F	SHUTTER - ANGLE UP	SGCC-A, SC-94445T	-	-	-	-	1	
36	DB92 - 30007D	ASSY - SHUTTER-RH	ASSY, SC-94445R(GR)	1	1	1	1	-	
	DB92 - 30007F	ASSY - SHUTTER RH	PVC, SC - 94445R	-	-	-	-	1	
37	DB92 - 30005D	ASSY - SHUTTER-LF	ASSY, SC - 94445R(GR)	1	1	1	1	-	
	DB92 - 30005F	ASSY - SHUTTER LF	PVC, SC - 94445R	-	-	-	-	1	
38	44A052HW1KA	ASSY COMP	ASSY	1	-	-	-	-	
	44A052HS1KA	ASSY COMP	ASSY	-	1	-	-	-	
	DB95 - 00109A	ASSY - COMPRESSOR	2R7S126A6F	-	-	1	1	-	
39	DB97 - 90014K	ASSY SCREW	ASSY	1	1	1	1	1	
40	DB67 - 20041A	DRAIN PLUG	PP, ID10	1	1	1	1	1	
	DB67 - 20028A	DRAIN - TUBE	PP	-	-	-	-	1	
41	DB73 - 20111A	RUBBER DRAIN	NR, T0.3, BLK	1	1	1	1	-	
	DB73 - 20135A	RUNNER - DRAIN	NR, T1	-	-	-	-	1	

# MEMO


---

## 7. Block Diagram

---

### 7-1 Refrigerating Cycle Block Diagram


---





# MEMO

## 8. Wiring Diagram



# MEMO



