

OPERATING INSTRUCTIONS AND SERVICE MANUAL

8 H. P. ROTARY TILLER MODEL 1850



211-380

PENNCRAFT OUTDOOR POWER EQUIPMENT GUARANTEE

Within one year of purchase (30 days for commercial use), we will repair any Outdoor Power Equipment Product which is defective. Just contact us for service.

Naturally, the cost of routine maintenance and service (engine adjustment, cleaning and blade sharpening) is your responsibility.

CONTENTS

| <u>Section</u> | <u>Paragraph</u> | <u>Page</u> | <u>Section</u> | <u>Paragraph</u> | <u>Page</u> |
|----------------|--|-------------|----------------|---|-------------|
| 1. | <u>GENERAL INFORMATION AND ASSEMBLY</u> | | 4. | <u>MAINTENANCE</u> | |
| 1-1. | Technical Description | 1-1 | 4-1. | Crankcase Oil | 4-1 |
| 1-2. | Preliminary Preparation | 1-1 | 4-2. | Chain Case Lubricaion | 4-1 |
| 1-3. | Assembly | 1-1 | 4-3. | Chain Adjustment | 4-1 |
| 2. | <u>CONTROLS AND PRELIMINARY CHECKS</u> | | 4-4. | Air Filter | 4-1 |
| 2-1. | Controls | 2-1 | 4-5. | Cleaning Engine and Tine Area | 4-2 |
| 2-2. | Wheel Adjustment | 2-2 | 4-6. | Belts | 4-2 |
| 2-3. | Checking Oil, Gasoline, and Gear case... .. | 2-2 | 4-7. | Spark Plug | 4-2 |
| 3. | <u>OPERATING INSTRUCTIONS</u> | | 4-8. | Gasoline Filter and Shut-Off Valve | 4-2 |
| 3-1. | Starting the Engine | 3-1 | 4-9. | Belt Adjustment | 4-3 |
| 3-2. | Stopping the Engine | 3-1 | 4-10. | Belt Replacement | 4-3 |
| 3-3. | Stopping the Tines | 3-1 | 4-11. | Adjusting the Carburetor | 4-4 |
| | | | 4-12. | Adjusting the Choke | 4-4 |
| | | | 4-13. | Magneto and Spark Plug Check | 4-5 |
| | | | 4-14. | Off-Season Storage | 4-5 |
| | | | 5. | <u>EXPLODED VIEWS AND PARTS LIST</u> | 5-1 |

ILLUSTRATIONS

| <u>Figure</u> | <u>Page</u> | <u>Figure</u> | <u>Page</u> |
|---------------|-------------------------------|---------------|------------------------------------|
| 1-1. | Wheel Assembly | 4-3. | Air Cleaner |
| 1-2. | Wheel Hanger | 4-4. | Spark Plug |
| 1-3. | Handle Assembly | 4-5. | Gasoline Filter and Shut-Off |
| 1-4. | Control Assembly | 4-6. | Drive System |
| 1-5. | Ferrule Adjustment | 4-7. | Variable Speed Pulley |
| 1-6. | Control Assembly | 4-8. | Belt Removal |
| 1-7. | Throttle Assembly | 4-9. | Carburetor Adjustment |
| 2-1. | Controls | 4-10. | Choke Adjustment |
| 2-2. | Depth Bar | 5-1. | Penncraft Tiller Model 1850 |
| 2-3. | Wheel Height Adjustment | 5-2. | Penncraft Tiller Model 1850 |
| 2-4. | Oil and Gasoline Fill | 5-3. | Engine Model 190402-0689-01 |
| 3-1. | Recoil Starter | | |
| 4-1. | Oil Fill Plug | | |
| 4-2. | Oil Drain | | |

SAFETY RULES

| BEFORE TILLING | AFTER TILLING |
|---|---|
| <ol style="list-style-type: none">1. DO NOT operate the equipment when barefooted or when wearing open sandals.2. DO NOT start machine until each control and its function is understood. See Sections 2 and 3.3. DO NOT let anyone use the tiller who is unfamiliar with the controls. Keep children and pets away from the machine.4. Check tank for fuel of crankcase for oil level. See Section 2.5. Always disconnect the sparkplug wire during repairs, refueling, or adjustments except when tuning the engine.6. NEVER refuel with motor running.7. DO NOT spill gasoline on hot engine.8. NEVER try to start the engine with the clutch control in any position but NEUTRAL.9. Stand clear of tines when starting the engine.10. Never stand in front of or work on tines when the engine is running. Keep hands and feet clear of tines. | <ol style="list-style-type: none">1. Read and understand all instructions in Sections 2 and 3.2. NEVER use the tiller in the dark.3. STOP the engine and remove the spark plug wire whenever the machine is left unattended.4. Never leave an operating tiller unattended.5. If the machine begins to vibrate or produces any other than normal operating sounds, STOP the machine immediately and check the cause.6. Keep children away from the operating tiller at all times.7. Know how to stop the tiller instantly.8. Stop the machine when crossing driveways, roads, or walkways.9. If the blades strike any obstructions, STOP the engine, remove the spark plug wire, and check for damage. |

SECTION I

GENERAL INFORMATION AND ASSEMBLY

1-1. TECHNICAL DESCRIPTION

The Model 1850 Rotary Tiller is equipped with a Briggs and Stratton 8 hp, 4-cycle engine and a recoil starter. The tines are heavy duty slasher type and the wheels are 10 x 2.50 inches with a rib tread. This tiller weighs 340 pounds.

The maximum tilling width is 26 inches.

1-2. Preliminary Preparation

Maximum tilling results, equipment performance, and personal safety depend on correct operation of the equipment and on proper maintenance of its components. The operator of this Penncraft rotary tiller should, therefore, familiarize himself with the machine and its controls before attempting to operate the equipment. The two important considerations are:

- Knowing the location of each control and its function, as outlined in this manual, to ensure for most efficient operation of the equipment and for best performance.
- Observing the operating instructions and safety rules at all times to prevent possible injury to persons and to equipment.

1-3. Assembly

The Model 1850 is shipped completely assembled except for the handle, depth bar, and wheels. These parts, with the necessary hardware, are easily assembled to the machine, as outlined in this section.


NOTE

Reference to right-hand or left-hand side of machine is from the operating position.

TOOLS NEEDED

| | |
|-----|----------------|
| Two | 7/16" Wrenches |
| Two | 9/16" Wrenches |

HARDWARE SUPPLIED



a. Wheel and Wheel Hanger Assembly

Refer to figure 1-1.

- Slide the axle through the wheel hanger.
- Place the washer A, spacer C, wheel, and washer A on each side of the axle and secure each with a cotterpin B.




FIGURE 1-1. WHEEL ASSEMBLY

Refer to Figure 1-2.

Step 3. Place the wheel hanger into the tailpiece and secure with clevis pin D and locking pin E.

b. Depth Bar

Refer to Figure 1-2.

Step 1. Attach the depth bar to the tailpiece with the clevis pin.

Step 2. Secure the clevis pin F with the locking pin E.




FIGURE 1-2. WHEEL HANGER AND DEPTH BAR

c. Handle Assembly

Refer to Figure 1-3.

Assemble the handle to the handle bracket with 4 hex bolts G, lockwashers I and hex nuts H.




FIGURE 1-3 HANDLE ASSEMBLY

d. Control Assembly

Refer to Figure 1-4.

Step 1. Place the control lever through the handle assembly.

Step 2. Attach at the bottom with hex bolt J, steel washer K, rubber washer L and secure with hex nut M.




FIGURE 1-4. CONTROL ASSEMBLY

Refer to Figure 1-5.

Step 3. Screw the control rod into the ferrule until it extends through the ferrule $\frac{7}{8}$ of an inch.




FIGURE 1-5. FERRULE ADJUSTMENT

Refer to Figure 1-6.

Step 4. Place the bent end of control rod into the control lever and fasten with cotter hairpin N.




FIGURE 1-6. CONTROL ASSEMBLY

e. Throttle Control Assembly

Step 1. Push the black plastic knob on the throttle control all the way.

Step 2. Pull out the black knob until the detent clicks twice to allow the spring lockwasher and the hex nut to pass over the detent ball to the threads.

Step 3. Slide the spring lockwasher and the hex nut over the detent ball and thread the hex nut one or two turns.

Step 4. Place the conduit through the slot in the handle panel.

Step 5. Push the throttle control in until it seats.

Step 6. Tighten the hex nut.




FIGURE 1-7. THROTTLE ASSEMBLY

SECTION 2

CONTROLS AND PRELIMINARY CHECKS

2-1. CONTROLS

The controls on Model 1850 Rotary Tiller are the control lever and throttle control.

a. The Control Lever

The Control Lever is released from Neutral by moving it to the right and allowing the spring tension to pull the control lever into one of the four forward speeds. See Figure 2-1.

NOTE

Number 1 position is the slowest tine rotation speed and number 4 is the fastest.

Pulling the control lever backwards into the Reverse position reverses the direction of tine rotation.




FIGURE 2-1. CONTROLS

b. The Throttle Control

The throttle control actuates the butterfly in the carburetor and may be set at stop, slow, fast or choke to control the speed of the engine.

NOTE

Always check the throttle cable at the engine end for a tight connection.

To stop the engine, push the throttle control all the way in. To operate the choke, pull the throttle control all the way out. See Figure 2-1.

c. The Depth Bar

The depth bar is used to prevent the tiller from running on top of the ground instead of tilling. The deeper you set the depth bar, the deeper you will till. Tilling depth is from 0 to 8-inches. See Figure 2-2.




FIGURE 2-2. DEPTH BAR

2-2. WHEEL ADJUSTMENT

The wheel height can be adjusted by removing the long clevis pin on the wheel hanger and raising or lowering the setting. The higher the setting the deeper the tilling depth. See Figure 2-3.

NOTE

Pick a height that places the handles in a comfortable position for the operator.




FIGURE 2-3. WHEEL HEIGHT ADJUSTMENT

2-3. CHECKING OIL, GASOLINE, AND GEAR CASE

NOTE

When packaged for shipment the machine contains no oil or gasoline. Before starting the engine, oil must be added to the engine crankcase and gasoline to the tank. DO NOT mix oil with gasoline.

a. Oil

With the tiller on level ground, remove the oil filler plug and pour 2¾ pints of good quality, SAE 30 type MS engine oil into the crankcase. Replace the oil filler plug.

b. Gasoline

Remove the gas cap and fill the tank with FRESH REGULAR GASOLINE. If the gasoline has been in a metal can for a long period, throw it away and use fresh gasoline.




FIGURE 2-4. OIL AND GASOLINE FILL

c. Chain Case Lubricant

The chain case is sealed and requires no further lubrication unless the chain case is disassembled for repair.

SECTION 3

OPERATING INSTRUCTIONS

3-1. STARTING THE ENGINE

- Step 1. With the tiller set on level ground, set the control lever in NEUTRAL.
- Step 2. Set the throttle control to CHOKE.
- Step 3. As illustrated in figure 3-1, grasp the recoil starter handle, pull out sharply, and hold it in the out position. (Do not let cord snap back.)




FIGURE 3-1. RECOIL STARTER

NOTE

The cord should NOT be pulled out more than about two feet. If engine fails to start, allow the cord to wind back into the housing, then pull out sharply again. Refer to Step 5.

- Step 4. When the engine starts, gradually move the throttle to the FAST position. After engine warms up (about 2 or 3 minutes) set throttle at IDLE position.
- Step 5. DO NOT OVERCHOKE ENGINE. Repeated cranking with throttle at CHOKE position will cause gasoline to flood the intake tube and the engine. If, after 3 or 4 attempts, the engine fails to start, place throttle in FAST position, crank the engine several times to clear out the excess fuel; and then proceed with steps 2, 3 and 4.

3-2. STOPPING THE ENGINE

To stop the engine, push the throttle control all the way in to the STOP position. See Figure 2-1. When the throttle control is in the STOP position, a switch blade is activated to short-circuit the spark plug.

WARNING

WHENEVER THE TILLER IS LEFT UNATTENDED, DISCONNECT THE SPARK PLUG LEAD AND PLACE THE THROTTLE CONTROL IN THE STOP POSITION.

3-3. STOPPING THE TINES

Pull the control lever into the NEUTRAL position. The tines will not rotate. See Figure 2-1.

3-4. OPERATING THE TILLER

Typical operation of the tiller is as follows:

- Step 1. Set the clutch control to NEUTRAL.
- Step 2. Start the engine as outlined in paragraph 3-1.

NOTE

To move the tiller to the work area, keep the depth bar in the highest position. With the throttle in the SLOW position, slowly engage the control lever into the number 1 position and the tiller will walk to the work area without digging into the ground.

- Step 3. With the clutch control in NEUTRAL, set the depth bar in one of the lower settings.

NOTE

When several passes must be made over a certain area, lower the depth bar each time a pass is made.

- Step 4. Set the throttle control to FAST.
- Step 5. Slowly engage the clutch control to the number 1 position and the tines will begin rotating. Number 4 position will give the maximum tine speed. Tilling the ground for the first time should be done in the number 1 or 2 position. To pulverize the soil after it has been tilled, move the control lever to the number 3 or 4 position.

NOTE

The engine must be running to move the control lever into the faster speeds.

NOTE

A downward pressure on the handles will increase the working depth and reduce the forward speed. An upward pressure on the handles will reduce the working depth and increase the forward speed. The type of soil and working conditions will determine the actual setting of the depth bar and the handle pressure required.

CAUTION

If the tines stop rotating or the belt slips, stop the engine and examine the tine area for a rock or some object that may be jamming the tines and prevent them from turning. Reversing the tiller will usually free the object.

- Step 6. To reverse the direction of rotation of the tines, pull the control lever into the reverse position. The control lever must be held in reverse. See Figure 2-1.

SECTION 4 MAINTENANCE

4-1. CRANKCASE OIL

To ensure maximum engine performance, perform the following periodic maintenance:

a. Oil Check

Check the oil level in the crankcase before each use of the machine and after every two hours of operation. The oil level shall be overflowing at the oil fill plug. See figure 4-1.




FIGURE 4-1. OIL FILL PLUG

b. Oil Change

After the first two hours of operating a new engine, drain the oil (see figure 4-2) from the crankcase while engine is still hot and refill crankcase with new oil; thereafter change the oil after every 25 hours of operation. This procedure ensures for minimum wear of engine parts and provides for virtually trouble-free operation. To change the oil, proceed as follows:




FIGURE 4-2. OIL DRAIN

Step 1. With the machine on level ground, place a suitable metal container under the oil drain plug, then remove the drain plug.

Step 2. After the oil has been drained completely from the crankcase, replace the drain plug and tighten.

Step 3. Refill crankcase with 2¾ pints of SAE 30 engine oil (A.P.I. class MS). Pour the oil slowly to eliminate airlock.

4-2. CHAIN CASE LUBRICATION

The chain is permanently lubricated and requires no further lubrication unless the case is disassembled for repair.

If the case is disassembled, clean the chain with kerosene, allow it to dry and work a high temperature grease, such as Lubriplate No. 310 into the chain.

NOTE

A 4 oz container of Lubriplate No. 310 is available under part number 727-136.

4-3. CHAIN ADJUSTMENT

No chain adjustment is necessary.

4-4. AIR FILTER

Under normal operating conditions, the air cleaner, located on top of the carburetor, must be serviced after every ten hours of use. Under extremely dusty operating conditions, the air cleaner must be serviced after every hour of operation. See Figure 4-3.

Step 1. Remove the wing nut and cover.

Step 2. Lift off foam element from support base.

Step 3. Remove metal support tube assembly (screen and two metal caps) from foam element by compressing the foam element.

- Step 4. a. Wash foam element in a solvent such as kerosene or liquid detergent and water to remove dirt.
- b. Wrap foam in cloth and squeeze dry.
- c. Saturate foam in engine oil, then squeeze out excess oil.

NOTE

Use the same oil for the air cleaner that you use in the engine.

- d. Assemble parts and fasten to the carburetor.




FIGURE 4-3. AIR CLEANER

4-5. CLEANING ENGINE AND TINE AREA

Any fuel or oil spilled on the tiller should be wiped off promptly. Dirt, leaves and other debris must not be left to accumulate around the cooling fins or the engine or on any part of the tiller. Clean the under side of the tine shield after each use. The dirt washes off the tine easier if washed off immediately instead of after it dries.

4-6. BELTS

Check that belts are free of oil or dirt. Wipe the belts periodically with a clean rag.

NOTE

Belt tension is automatically maintained on the forward and reverse drive belts by idlers. No adjustment is necessary.

4-7. SPARK PLUG

The spark plug gap should be cleaned, and reset to a 0.030-inch clearance every 25 hours of engine operation (see figure 4-4). Spark plug replacement is recommended at the start of each tiller season; check engine parts list for correct plug type.




FIGURE 4-4. SPARK PLUG

4-8. GASOLINE FILTER AND SHUT-OFF VALVE.

Refer to Figure 4-5.

- Step 1. Close the shut-off valve.
- Step 2. Loosen the thumb screw below the bowl.
- Step 3. Remove and clean the screen.
- Step 4. Open the shut-off valve to see if gasoline flows freely from the gasoline tank.
- Step 5. Clean the bowl and screen. Use alcohol or acetone to clean the parts if you find a gummy, varnish-like substance in the bowl.
- Step 6. Reassemble.
- Step 7. Open the shut-off valve.




FIGURE 4-5. GASOLINE FILTER AND SHUT-OFF

4-9. BELT ADJUSTMENT

To check the belt adjustment, it is necessary to remove the belt cover so the belts are exposed as shown in Figure 4-6.




FIGURE 4-6. DRIVE SYSTEM

Start the engine and move the control lever into the number 4 position. The belt closest to the engine should move to the outside edge of the variable speed pulley so the top of the belt is almost flush with the pulley. See Figure 4-7.




FIGURE 4-7. VARIABLE SPEED PULLEY

4-10. BELT REPLACEMENT

Step 1. Remove the belt cover so the belts are exposed as shown in Figure 4-6.

Step 2. Put the depth bar on the wheel hanger and place the tip of the depth bar under the variable speed pulley bracket as shown in Figure 4-8.




FIGURE 4-8. BELT REMOVAL

- Step 3. Place your foot on the rear of the depth bar and apply pressure. The belts will go slack.
- Step 4. Remove the REAR belt first and ALLOW IT TO FORM A LOOP AROUND THE VARIABLE SPEED PULLEY.
- Step 5. Slide the center section of the variable-speed pulley towards the engine. See Figure 4-7.
- Step 6. Remove the FORWARD belt from the engine pulley and the variable-speed pulley.

NOTE

By following this order of belt removal, it is not necessary to remove the belt guard on the variable-speed pulley.

- Step 7. Remove the rear belt from the variable-speed pulley.
- Step 8. Reassemble with the new belts.




FIGURE 4-9. CARBURETOR ADJUSTMENT

4-11. ADJUSTING THE CARBURETOR

Minor carburetor adjustment may be required to compensate for differences in fuel, temperature, altitude and load.

To Adjust Carburetor:

Turn needle valve clockwise until it just closes. See Figure 4-9.

CAUTION

Valve may be damaged by turning it in too far.

Now open needle valve $1\frac{1}{2}$ turns counter-clockwise.

Close idle valve in same manner and open $\frac{1}{4}$ to $\frac{3}{4}$ turns. This initial adjustment will permit the engine to be started and warmed up prior to final adjustment.

Final Adjustment:

Turn needle valve in until engine misses (lean mixture) then turn it out past smooth operating point until engine runs unevenly (rich mixture). Now turn needle valve to the mid-point between rich and lean so the engine runs smoothly.

Hold throttle at idle position and set idle speed adjusting screw until fast idle is obtained (1750 RPM).

Hold throttle in idle position and turn idle valve in (lean) and out (rich) until engine idles smoothly. Then reset idle speed adjusting screw so that engine idles at 1750 RPM. Release throttle—engine should accelerate without hesitation or sputtering. If engine does not accelerate properly, the carburetor should be re-adjusted to a slightly richer mixture.

4-12. ADJUSTING CARBURETOR CHOKE

Proper choke and stop switch operation is dependent upon proper adjustment of remote controls on the powered equipment.

To Check The Operation Of The Choke:

- Step 1. Remove the air cleaner.
- Step 2. Pull the throttle control all the way out to the CHOKE position. See Figure 2-1. The choke should be closed.
- Step 3. The engine should shut off when the throttle control is all the way in. (STOP position.)

To Adjust:

Place remote control lever on equipment in FAST (high speed) position. Loosen control casing clamp screw "B." Move control casing "A" and wire until lever "D" touches choke operating link at "C." Tighten casing clamp screw "B." Replace air cleaner. See Figure 4-10.




FIGURE 4-10. CHOKE ADJUSTMENT

4-13. MAGNETO AND SPARK PLUG CHECK

WARNING

WHENEVER CHECKING THE MAGNETO OR THE SPARK PLUG FOR AN ELECTRICAL SPARK, USE INSULATED PLIERS TO HOLD THE SPARK PLUG WIRE OR THE SPARK PLUG.

a. Magneto Check

- Step 1. Disconnect the spark plug wire from the spark plug, and place throttle control lever in CHOKE or FAST position.
- Step 2. Using insulated pliers, hold the wire close ($\frac{1}{4}$ -inch distance) to engine block or cylinder, then crank the engine several times. A spark should jump from the wire to the block or cylinder; if a spark does not occur, check the wire and the magneto.

b. Spark Plug Check

- Step 1. Remove spark plug from cylinder but leave the wire connected, and set throttle at CHOKE or FAST position.
- Step 2. Using insulated pliers, hold the metal side of the spark plug in contact with the engine block, and crank the engine several times. The spark should jump the gap between the center and side electrode in the plug.
- Step 3. If a spark does not occur, check the electrode gap and repeat step 2. If no spark occurs, replace the plug.

4-14. OFF-SEASON STORAGE

If the machine is to be inoperative for a period longer than 30 days, the following precautions are recommended:

- Step 1. Working outdoors, drain all fuel from the fuel tank. Use a clean dry cloth to absorb the small amount of fuel remaining in the tank, then run the engine until all fuel in carburetor is exhausted.

WARNING

DO NOT DRAIN FUEL WHILE SMOKING OR IF NEAR AN OPEN FIRE.

- Step 2. Drain all the oil from the crankcase (this should be done after the engine has been operated and is still warm) and refill the crankcase with clean new oil.
- Step 3. Disconnect the spark plug wire and remove the spark plug from the cylinder. Pour about six drops of engine oil into the cylinder, and then pull the recoil starter several times to spread the oil on the cylinder wall. Replace the spark plug, but DO NOT connect the wire.
- Step 4. Clean the engine and the entire tiller thoroughly.
- Step 5. Lubricate the gear cane as indicated in paragraph 4-2.
- Step 6. Wipe tines with oiled rag to prevent rust.

MAINTENANCE LOG

After using and servicing the machine, enter the data on this log for future reference. Change oil after first 5 hours of operation; thereafter, change oil every 25 hours of operation. Clean the air cleaner every 10 hours; every hour under very dusty conditions. Lubricate all points indicated in figures 4-2, 4-3 and 4-4 every 10 hours.

[illegible]

SECTION 5

EXPLODED VIEWS

AND

PARTS LIST




FIGURE 5-1. PENNCRAFT TILLER MODEL 1850




FIGURE 5-2. PENNCRAFT TILLER MODEL 1850

PARTS LIST—ROTARY TILLER MODEL 1850

WHEN ORDERING REPAIR PARTS, ALWAYS GIVE THE FOLLOWING INFORMATION AS SHOWN IN THIS LIST:

1. The PART NUMBER
 2. The PART NAME
 3. MODEL NUMBER
- DO NOT use Reference Numbers when ordering Repair Parts, always use Part Numbers
Your lawn mower is right hand (R.H.) or left hand (L.H.) as you ride.

| REF. NO. | PART NO. | DESCRIPTION | APPROX. SELLING PRICE | REF. NO. | PART NO. | DESCRIPTION | APPROX. SELLING PRICE |
|----------|----------|---------------------------------------|-----------------------|----------|-----------|--|-----------------------|
| 1 | — | Engine | | 72 | 715-120 | Spirol Pin 3/16 Dia. x 1 Lg.—Heavy Duty | .20 |
| 2 | 710-380 | Hex Hd. Cap Scr. 5/16-18 x 1 1/4 Lg.* | .20 | 73 | 750-118 | Spacer | .50 |
| 3 | 384-4524 | Tine Shield | | 74 | | Part of Ref. No. 70 | |
| 4 | 710-376 | Hex Hd. Cap Scr. 5/16-18 x 1 Lg.* | .20 | 75 | 713-149 | Roller Chain w/Master Link #35-2 x 36 3/4 Lg. | |
| 6 | 710-216 | Hex Hd. Cap Scr. 3/8-16 x 3/4 Lg.* | .20 | 76 | 711-505 | Pulley Shaft | |
| 7 | 720-143 | Grip | .60 | 77 | 748-855 | Flange Bearing | 1.00 |
| 8 | 714-507 | Cotter Pin 3/32 x 3/4 Lg.* | .20 | 78 | 710-230 | Hex Hd. Cap Scr. 1/4-28 x 1/2 Lg.* | .20 |
| 9 | 711-422 | Control Rod | | 79 | 428-4517 | Variable Speed Bracket Assembly | |
| 10 | 710-106 | Hex Hd. Cap Scr. 1/4-20 x 1 1/4 Lg.* | .20 | 80 | 428-4501 | Housing Assembly L.H. | |
| 11 | 712-107 | Hex Center Lock Nut 1/4-20 Thd.* | .20 | 81 | 428-11021 | Eccentric Link | |
| 12 | 305-1166 | Grip | .30 | 82 | 736-161 | Rubber Washer | .20 |
| 13 | 746-122 | Throttle Control—Complete | 2.25 | 83 | 736-703 | Flat Washer | .20 |
| 14 | 384-4533 | Handle Assembly | | 84 | 741-155 | Ball Bearing 3/8 x 1 1/8 | |
| 15 | 310-4525 | Control Lever Assembly | | 85 | 310-5034 | Bearing Housing | .60 |
| 16 | 736-325 | Flat Washer* | .20 | 86 | 736-329 | Spring Lockwasher 1/4 Scr.* | .20 |
| 17 | 736-155 | Rubber Washer | .20 | 87 | 736-329 | Spring Lockwasher 1/4 Scr.* | .20 |
| 18 | 736-325 | Flat Washer* | .20 | 88 | 710-258 | Hex Hd. Cap Scr. 1/4-20 x 5/8 Lg.* | .20 |
| 19 | 736-217 | Spring Lockwasher 3/8 Screw* | .20 | 89 | 714-136 | Hi Pro Key #505 | |
| 20 | 712-798 | Hex Nut 3/8-16 Thd.* | .20 | 90 | 310-5080 | Friction Wheel Assembly | 11.50 |
| 21 | 428-4506 | Handle Mounting Bracket L.H. | | 91 | 310-4515 | Friction Disc | |
| 22 | 710-253 | Hex Hd. Cap Scr. 3/8-16 x 1 Lg.* | .20 | 92 | 754-158 | V-Belt 21/32 x 35 Lg. Special | |
| 23 | 736-217 | Spring Lockwasher 3/8 Scr.* | .20 | 93 | 712-461 | Hex Jam Nut 1/2-13 Thd. | .20 |
| 24 | 428-4505 | Handle Mounting Bracket R.H. | | 94 | 428-4520 | Variable Speed Belt Guard | |
| 25 | 428-4507 | Tail Piece | | 95 | 756-167 | 8" x 3/8" Pulley | |
| 26 | 732-194 | Spring Pin | .50 | 96 | 726-106 | Push On Pal Nut (Not Shown) | .20 |
| 27 | 736-148 | Ext. Lockwasher for 3/8 Scr.* | .20 | 97 | 712-221 | Hex Elastic Stop Nut 3/8-18 Thd. | .40 |
| 28 | 710-253 | Hex Hd. Cap Scr. 3/8-16 x 1 Lg.* | .20 | 98 | 714-115 | Cotter Pin 1/8 Dia. x 1 Lg. | .20 |
| 29 | 732-194 | Spring Pin | .20 | 99 | 736-204 | Flat Washer | .20 |
| 30 | 428-4328 | Depth Bar | 4.80 | 100 | 711-392 | Ferrule | .40 |
| 31 | 711-231 | Clevis Pin | .30 | 101 | 428-4521 | Link Bracket Assembly | |
| 32 | 428-4527 | Wheel Hanger Bracket | | 102 | 736-703 | Flat Washer | .20 |
| 33 | 711-510 | Clevis Pin | | 103 | 712-116 | Hex Elastic Stop Nut 3/8-24 Thd.* | .20 |
| 34 | 310-4451 | Rear Axle | | 104 | 712-116 | Hex Elastic Stop Nut 3/8-24 Thd.* | .20 |
| 35 | 711-313 | Spacer | .80 | 105 | 712-461 | Hex Jam Nut 1/2-13 Thd. | .20 |
| 36 | 501-8929 | Wheel Assembly | 6.00 | 106 | 710-152 | Hex Hd. Cap Scr. 3/8-24 x 1 Lg. (Heat Treated)* | .20 |
| 37 | 736-160 | Flat Washer* | .20 | | | Spring Lockwasher 3/8 Scr.* (Heavy Duty) | .20 |
| 38 | 714-115 | Cotter Pin 1/8 Dia. x 1 Lg.* | .20 | 107 | 736-217 | Spring Lockwasher 3/8 Scr.* (Heavy Duty) | .20 |
| 39 | 712-236 | Hex Elastic Stop Nut 7/16-20 Thd.* | .20 | 108 | 310-7386 | Flat Washer | .20 |
| 40 | 428-4474 | Outer Tine Adapter | | 109 | 714-118 | Square Key 1/4 Sq. x 1 1/2 Lg.* | |
| 41 | 428-4511 | Inner Tine Adapter | | 110 | 310-10843 | Variable Speed Pulley Assembly | |
| 42 | 736-220 | Dust Pad | | 111 | 750-166 | Spacer (For Item 116) Not Shown | |
| 43 | 736-224 | Dust Pad | | 112 | 748-180 | Pivot Slide (For Item 79) Not Shown | |
| 44 | 742-113 | Tine L. H. | 1.80 | 113 | 754-157 | V-Belt 21/32 x 28 Lg. Special | |
| 45 | 428-4511 | Inner Tine Adapter | | 114 | 738-138 | Shoulder Bolt Special | |
| 46 | 742-110 | Tine R.H. | 1.80 | 115 | 710-380 | Hex Hd. Cap Scr. 5/16-18 x 1 1/4 Lg.* | .20 |
| 47 | 428-4474 | Outer Tine Adapter | | 116 | 310-11002 | Spring Bracket | |
| 48 | 710-152 | Hex Hd. Cap Scr. 3/8-24 x 1 Lg.* | .20 | 117 | 711-509 | Spring Insert | |
| 49 | 736-169 | Spring Lockwasher 3/8 Scr.* | .20 | 118 | 732-232 | Variable Drive Spring | |
| 50 | 712-711 | Hex Jam Nut 3/8-24 Thd.* | .20 | 119 | 712-158 | Hex Center Lock Nut 5/16-18 Thd.* | .20 |
| 51 | 710-483 | Hex Hd. Cap Scr. 7/16-20 x 2 1/4 Lg.* | .20 | 120 | 736-119 | Spring Lockwasher 5/16 Scr.* | .20 |
| 52 | 736-119 | Spring Lockwasher 5/16 Scr.* | .20 | 121 | 428-4530 | Cast Bearing Housing Assembly | |
| 53 | 712-158 | Hex Center Lock Nut 5/16-18 Thd.* | .20 | 122 | 721-117 | Oil Seal 1 1/4 x 1 1/4 | |
| 54 | 428-4519 | Engine Mounting Bracket | | 123 | 748-194 | Flange Bearing 1 1/4 x 1 1/4 | |
| 55 | 712-158 | Hex Center Lock Nut 5/16-18 Thd.* | .20 | 124 | 712-287 | Hex Center Lock Nut 1/4-20 Thd.* | .20 |
| 56 | 736-119 | Spring Lockwasher 5/16 Scr.* | .20 | 125 | 736-329 | Spring Lockwasher 1/4 Scr.* | .20 |
| 57 | 428-4519 | Engine Mounting Bracket | | 126 | 721-119 | Gasket | |
| 58 | 710-258 | Hex Hd. Cap Scr. 1/4-20 x 5/8 Lg.* | .20 | 127 | 310-4531 | Engine Pulley | |
| 59 | 710-252 | Hex Hd. Cap Scr. 1/4-20 x 3/4 Lg.* | .20 | 128 | 710-118 | Hex Hd. Cap Scr. 5/16-18 x 3/4 Lg. | .20 |
| 60 | 312-4516 | Belt Guard | | 129 | 711-506 | Tine Shaft | |
| 61 | 736-329 | Spring Lockwasher 1/4 Scr.* | .20 | 130 | 736-119 | Spring Lockwasher 5/16 Scr.* | .20 |
| 62 | 712-287 | Hex Nut 1/4-20 Thd.* | .20 | 131 | 713-150 | Roller Chain w/Master Link #40-2 x 34 Lg. | |
| 63 | 312-4537 | Belt Trap Assembly | | 132 | 717-189 | 24-2 Tooth Sprocket 1/2" Pitch | |
| 64 | 710-121 | Hex Hd. Cap Scr. 1/2-20 x 3/4 Lg.* | .20 | 133 | 715-125 | Spirol Pin 3/8 Dia. x 2 Lg. (Heavy Duty) | .20 |
| 65 | 736-921 | Spring Lockwasher 1/2 Scr.* | .20 | 134 | 710-258 | Hex Hd. Cap Scr. 1/4-20 x 5/8 Lg.* | .20 |
| 66 | 312-4523 | Variable Speed Guide Bracket | | 135 | 428-4530 | Cast Bearing Housing Assembly | |
| 67 | 712-287 | Hex Nut 1/4-20 Thd.* | .20 | 136 | 710-118 | Hex Hd. Cap Scr. 5/16-18 x 3/4 Lg.* | .20 |
| 68 | 711-504 | Sprocket Shaft | | 137 | 736-119 | Spring Lockwasher 5/16 Scr.* | .20 |
| 69 | 748-855 | Flange Bearing | 1.00 | 138 | 736-703 | Flat Washer | .20 |
| 70 | 310-4529 | Double Sprocket Assembly | | 139 | 428-4503 | Housing Assembly R.H. Side | |
| 71 | 717-188 | 11-2 Tooth Sprocket 3/8 Pitch | | | | | |





FIGURE 5-3. ENGINE MODEL 190402-0689-01

PARTS LIST ENGINE MODEL 190402-0689-01

| REF. NO. | PART NO. | DESCRIPTION | APPROX. SELLING PRICE | REF. NO. | PART NO. | DESCRIPTION | APPROX. SELLING PRICE |
|-------------------|----------|--|-----------------------|----------|----------|---|-----------------------|
| 1 | 390399 | Cylinder Assembly | 36.95 | 36 | 26828 | Spring—Exhaust Valve | .80 |
| 2 | 295962 | Bushing—Cylinder | 1.20 | 40 | 221596 | Retainer—Intake Valve | .25 |
| | | Note: Requires special tools for installation. | | 41 | 292260 | Rotocoil—Exhaust Valve | 3.15 |
| 3 | 294606 | Seal—Oil | .55 | 42 | 93630 | Retainer—Exhaust Valve Rotocoil (2) | .20 |
| 5 | 211778 | Head—Cylinder | 4.95 | 45 | 260933 | Tappet—Valve | .55 |
| 7 | *270430 | Gasket—Cylinder Head | .45 | 46 | 210728 | Gear—Cam | 5.70 |
| 8 | 390321 | Breather Assembly | 1.20 | 50 | 211812 | Elbow—Intake | 1.60 |
| | | | | 51 | *270684 | Gasket—Intake Elbow | .20 |
| | | | | 52 | *27828 | Gasket—Intake Elbow Mtg. | .20 |
| | | | | 53 | 93128 | Screw—Carburetor Mounting Sem | .20 |
| | | | | 54 | 93208 | Screw—Intake Elbow Mounting Sem | .20 |
| | | | | 55 | 295272 | Housing—Rewind Starter | 4.10 |
| 9 | *27803 | Gasket—Valve Cover | .20 | 56 | 295871 | Pulley—Rewind Starter | 2.95 |
| 10 | 93536 | Screw—Sem | .20 | 57 | 294303 | Spring—Rewind Starter | .75 |
| 11 | 67068 | Tube Breather | .60 | 58 | 66564 | Rope—Rewind Starter (63" Long) | .80 |
| 12 | *27750 | Gasket—Crankcase Cover—1/64" Thick | .20 | 59 | 230228 | Pin—Starter Grip | .20 |
| | *27876 | Gasket—Crankcase Cover—.005" Thick | .20 | 60 | 66728 | Grip—Starter Rope | .55 |
| | *27877 | Gasket—Crankcase Cover—.009" Thick | .20 | 61 | 68848 | Bumper—Starter Pulley | .20 |
| 13 | 93210 | Screw—Cylinder Head (2-9/32" Long) | .20 | 62 | 93254 | Screw—Pulley Bumper Mounting Sem | .20 |
| | 93583 | Stud—Cylinder Head (2). Used on type Nos. 0646, 0647 | .45 | 63 | 260414 | Spring—Ratchet | .20 |
| 14 | 93211 | Screw—Cylinder Head (2-9/16" Long) | .20 | 64 | 230543 | Adapter—Ratchet Spring | .35 |
| 15 | 91084 | Plug—Oil Drain | .20 | 65 | 93106 | Screw—Rewind Starter Housing Mounting Sem | .20 |
| | 93418 | Plug—Oil Drain (Hex Socket) Used on type Nos. 0144, 0652. | .20 | 66 | 298798 | Clutch Assy.—Rewind Starter | 3.00 |
| 16 | 261149 | Crankshaft | 38.00 | 67 | 211383 | Housing—Rewind Starter Clutch | 1.35 |
| 17 | 29530 | Bearing—Ball | 6.35 | 68 | 63770 | Ball—Clutch | .20 |
| 18 | 299167 | Cover Assy.—Crankcase | 12.95 | 69 | 66718 | Washer—Starter Clutch Thrust | .20 |
| 19 | 295964 | Bushing—Crankcase Cover | 1.65 | 70 | 298799 | Ratchet—Rewind Starter Clutch | .95 |
| | | Note: Requires special tools for installation. | | 71 | 221653 | Washer—Retainer | .20 |
| 20 | 298423 | Seal—Oil | .85 | 73 | 221796 | Screen—Rewind Starter | .80 |
| 21 | 66768 | Plug—Oil Filler | .20 | 75 | 220865 | Washer—Spring | .20 |
| 22 | 93585 | Screw—Crankcase Cover Mounting Sem | .75 | 76 | 68238 | Washer—Ratchet Sealing | .20 |
| 23 | 298260 | Flywheel | 19.50 | 90 | 390727 | Carburetor Assembly (Manual Choke) | 19.50 |
| 24 | 61760 | Key—Flywheel | .20 | 91 | 390404 | Body Assembly—Upper Carburetor | 8.80 |
| 25 | 390347 | Piston Assembly—Std. | 9.60 | 92 | 390503 | Body—Upper Carburetor | 5.20 |
| | 390348 | Piston Assembly—.010" O.S. | 9.60 | 93 | 23108 | Bushing—Throttle Shaft | .25 |
| | 390349 | Piston Assembly—.020" O.S. | 9.60 | 94 | †292681 | Valve Assembly Carburetor Idle | .25 |
| | 390350 | Piston Assembly—.030" O.S. | 9.60 | 95 | 93038 | Screw—Throttle and Choke Valve Mtg. Sem | .20 |
| | | | | 96 | 62940 | Valve—Throttle | .20 |
| | | | | 97 | 298826 | Shaft and Lever—Throttle | 1.55 |
| RING SETS: | | | | 98 | 91920 | Screw—Machine, Fil. Hd.—8-32 x 5/8" | .20 |
| 26 | 299569 | Ring Set—Piston—Std. | 4.25 | 99 | 26157 | Spring—Throttle Adjustment | .20 |
| | | CONSISTS OF— | | 100 | 61967 | Stop—Throttle | .65 |
| | 211637 | Ring—Piston, Comp., Top, Std. | 1.25 | 101 | 93043 | Pin—Throttle Stop | .20 |
| | 211636 | Ring—Piston, Comp., Center, Standard | 1.25 | 102 | †27918 | Gasket—Carburetor Body | .20 |
| | 211635 | Ring—Piston, Oil, Std. | 1.25 | 103 | 99333 | Float—Carburetor | .95 |
| | 299570 | Ring Set—Piston—.010" O.S. | 4.25 | 104 | †230896 | Pin—Float Hinge | .20 |
| | | CONSISTS OF— | | 105 | 299096 | Valve—Fuel Inlet | .60 |
| | 211649 | Ring—Piston, Comp., Top, .010" O.S. | 1.25 | 107 | 390403 | Body Assembly—Lower Carburetor | 6.15 |
| | 211650 | Ring—Piston, Comp., Center, .010" O.S. | 1.25 | 108 | 62872 | Valve—Choke | .20 |
| | 211651 | Ring—Piston, Oil, .010" O.S. | 1.25 | 110 | 62899 | Washer—Choke Lever | .20 |
| | 299571 | Ring Set—Piston—.020" O.S. | 4.25 | 111 | 26155 | Spring—Choke Lever | .20 |
| | | CONSISTS OF— | | 112 | 23123 | Screw—Choke Lever | .20 |
| | 211653 | Ring—Piston, Comp., Top, .020" O.S. | 1.25 | 113 | †390395 | Nozzle—Carburetor | 2.00 |
| | 211654 | Ring—Piston, Comp., Center, .020" O.S. | 1.25 | 114 | †68667 | Gasket—Nozzle | .20 |
| | 211655 | Ring—Piston, Oil, .020" O.S. | 1.25 | 115 | †23117 | Retainer—Needle Valve | .35 |
| | 299572 | Ring Set—Piston—.030" O.S. | 4.25 | 116 | †68677 | Packing—Needle Valve | .20 |
| | | CONSISTS OF— | | 117 | †23118 | Nut—Needle Valve Pkng. | .20 |
| | 211657 | Ring—Piston, Comp., Top, .030" O.S. | 1.25 | 118 | †230009 | Valve—Needle | .40 |
| | 211658 | Ring—Piston, Comp., Center, .030" O.S. | 1.25 | 119 | 90746 | Screw—Machine, Fil. Hd.—10-32 x 5/8" | .20 |
| | 211659 | Ring—Piston, Oil, .030" O.S. | 1.25 | 120 | 92290 | Washer—Lock—No. 10 x 1/16" x 3/64" | .20 |
| 27 | 68546 | Lock—Piston Pin | .20 | 121 | 295938 | Carburetor Overhaul Kit | 4.25 |
| 28 | 295840 | Pin Assy.—Piston—Std. | 1.15 | 158 | 27590 | Filter—Carburetor Drain | .20 |
| | 295841 | Pin Assembly—Piston—.005" O.S. | 1.15 | 159 | 220521 | Retainer—Carburetor Drain Filter | .20 |
| 29 | 390401 | Rod Assy.—Connecting | 3.90 | 164 | 390311 | Pipe Assy.—Air Cleaner | 2.80 |
| | | Note: For Connecting Rod with .020" under-size Crankpin Bore—Order No. 390773. | | 165 | 93453 | Nut—Wing | .30 |
| 30 | 222113 | Dipper—Connecting Rod | .45 | 166 | 230768 | Stud—Air Cleaner | .45 |
| 31 | 222114 | Lock—Conn. Rod Screw | .20 | 167 | 66648 | Gasket—Air Cleaner Stud | .20 |
| 32 | 92659 | Screw—Connecting Rod | .20 | 168 | 222150 | Strap—Air Cleaner Pipe | .30 |
| 33 | 390419 | Valve—Exhaust | 3.25 | 171 | 92129 | Nut—Hex—1/4-28 | .20 |
| 34 | 261055 | Valve—Intake | 1.70 | 180 | 290816 | Tank Assy.—Fuel (4 quart) | 9.50 |
| 35 | 65906 | Spring—Intake Valve | .30 | 181 | 69221 | Cap—Fuel Tank | .30 |
| | | | | 182 | 221935 | Bracket—Fuel Tank | 2.15 |

PARTS LIST ENGINE MODEL 190402-0689-01

| Ref. No. | Part No. | Description | Approx. Selling Price | Ref. No. | Part No. | Description | Approx. Selling Price |
|----------|----------|---|-----------------------|----------|----------|---|-----------------------|
| 183 | 291367 | Strap Assy.—Fuel Tank | 1.00 | 345 | 222117 | Cover—Breaker Point | .45 |
| 184 | 91257 | Screw—Machine, Fil. Hd.— $\frac{1}{4}$ -20 x $1\frac{1}{2}$ " | .20 | 346 | 93014 | Screw—Sem | .20 |
| 185 | 90970 | Nut—Square— $\frac{1}{4}$ -20 | .20 | 347 | 221808 | Switch—Stop | .20 |
| 187 | 299942 | Pipe—Fuel (Flexible) $1\frac{1}{2}$ " Long | .95 | 352 | 66068 | Washer—Insulating | .20 |
| 196 | 22907 | Support—Upper Fuel Tank | .60 | 353 | 92791 | Washer—Lock—Shakeproof (3) | .20 |
| 200 | 221760 | Guide—Air | .20 | 354 | 90576 | Nut—Hex—8-32 (2) | .20 |
| 201 | 260872 | Link—Governor | .20 | 355 | 66554 | Collar—Insulating | .20 |
| 206 | 230149 | Nut—Gov. Control Rod | .40 | 356 | 299500 | Wire—Ground | .20 |
| 207 | 26855 | Spring—Gov. Control Rod | .20 | 357 | 91540 | Key—Pulley | .20 |
| 208 | 230841 | Rod—Governor Control | .30 | 358 | 299577 | Gasket Set | 1.45 |
| 209 | 260695 | Spring—Governor | .30 | 362 | 291630 | Shield—Spark Plug (With Stop Switch) | 2.70 |
| 216 | 261122 | Link—Choke | .20 | 372 | 220477 | Clamp—Condenser | .20 |
| 217 | 261119 | Spring—Choke Link | .20 | 375 | 294628 | Breaker Points and Condenser Set | 1.85 |
| 218 | 221198 | Washer—Choke Link | .20 | | 299061 | Ignition Kit | 2.20 |
| 219 | 297656 | Gear—Governor | 1.45 | | | INCLUDES— | |
| 220 | 221551 | Washer—Thrust | .20 | | 294628 | Point Set | 1.85 |
| 222 | 390670 | Plate—Governor Control | | | 65704 | Plunger | .30 |
| 227 | 299165 | Lever Assy.—Governor | .65 | | 61760 | Key—Flywheel | .20 |
| 230 | 221559 | Washer—Spacer | .20 | 521 | 298529 | Shielding—Ignition Cable | .65 |
| 231 | 93064 | Screw—Sem | .20 | 535 | 270093 | Element—Air Cleaner | 3.05 |
| 240 | 295984 | Filter Assembly—Fuel | 3.95 | 536 | 390400 | Cleaner Assy.—Air | 4.05 |
| 240A | 298090 | Filter—Fuel (In Fuel Pipe) | 2.75 | 552 | 230843 | Bushing—Governor Shaft | .65 |
| 241 | 296005 | Cover Assembly—Fuel | 2.90 | 562 | 92613 | Bolt—Governor Lever | .20 |
| 242 | 295913 | Valve—Fuel Shut-Off | .80 | 592 | 90356 | Nut—Hex—10-24 | .20 |
| 243 | 22547 | Screen—Fuel Filter | .20 | 601 | 93053 | Clamp—Fuel Pipe | .20 |
| 245 | *68477 | Gasket—Fuel Filter Bowl | .20 | 605 | 297187 | Bracket—Guard (Upper) | 1.60 |
| 246 | 298683 | Bowl—Fuel Filter | .35 | 608 | 295001 | Starter Assy.—Rewind | 10.95 |
| 247 | 99665 | Yoke—Fuel Filter | .70 | 614 | 93306 | Cotter—Hair Pin | .20 |
| 265 | 221535 | Clamp—Casing | .20 | 615 | 93307 | Retainer—E-Ring | .20 |
| 300 | 390578 | Muffler—Exhaust | 1.95 | 616 | 230842 | Crank—Governor | .95 |
| 302 | 91242 | Locknut—Muffler and Elbow | .25 | 621 | 297472 | Switch—Stop | .20 |
| 305 | 93158 | Screw—Sem | .20 | 635 | 66538 | Elbow—Spark Plug | .50 |
| 306 | 221898 | Shield—Cylinder | .45 | 642 | 221468 | Cover—Air Cleaner | .85 |
| 307 | 93163 | Screw—Cylinder Shield Mtg. Sem | .20 | 643 | 280001 | Cup—Air Cleaner | .50 |
| 308 | 221901 | Cover—Cylinder Head | .30 | 655 | 221014 | Anchor—Spring | .20 |
| 333 | 298968 | Armature Assembly | 7.20 | 657 | 93496 | Screw—Sem | .20 |
| 334 | 93381 | Screw—Armature Mtg. Sem | .20 | 682 | 211516 | Shield—Starter Clutch | .70 |
| 337 | 298809 | Plug—Spark ($1\frac{1}{2}$ " high—38 M.M.) | 1.10 | 687 | 298957 | Slide—Friction Control | .85 |
| 340 | 26018 | Spring—Breaker Arm | .20 | 688 | 221766 | Cap—Friction Spring | .20 |
| 341 | 93381 | Screw—Breaker Arm Mounting Sem | .20 | 689 | 260847 | Spring—Friction | .20 |
| 342 | 65704 | Plunger—Breaker Point | .30 | 690 | 92484 | Screw—Machine, Fil. Hd.—10-32 x $\frac{1}{2}$ " | .20 |

*Included in Gasket Set—Part No. 299577.

†Included in Carburetor Overhaul Kit—Part No. 295938.