



# INVERTER

Plug-in option

# FR-A7AY

# INSTRUCTION MANUAL

---

*Analog output function*

---

*Digital output function*

---

PRE-OPERATION INSTRUCTIONS

1

INSTALLATION AND WIRING

2

PARAMETER LIST

3

EXTENSION ANALOG OUTPUT

4

DIGITAL OUTPUT

5

Thank you for choosing this Mitsubishi Inverter plug-in option. This instruction manual gives handling information and precautions for use of this equipment. Incorrect handling might cause an unexpected fault. Before using the equipment, please read this manual carefully to use the equipment to its optimum. Please forward this manual to the end user.

## This section is specifically about safety matters

Do not attempt to install, operate, maintain or inspect this product until you have read through this instruction manual and appended documents carefully and can use the equipment correctly. Do not use this product until you have a full knowledge of the equipment, safety information and instructions.


In this instruction manual, the safety instruction levels are classified into "WARNING" and "CAUTION".



Assumes that incorrect handling may cause hazardous conditions, resulting in death or severe injury.



Assumes that incorrect handling may cause hazardous conditions, resulting in medium or slight injury, or may cause physical damage only.

Note that even the  **CAUTION** level may lead to a serious consequence according to conditions. Please follow the instructions of both levels because they are important to personnel safety.

## SAFETY INSTRUCTIONS

### 1. Electric Shock Prevention

#### **WARNING**

- While power is on or when the inverter is running, do not open the front cover. You may get an electric shock.
- Do not run the inverter with the front cover or wiring cover removed. Otherwise, you may access the exposed high-voltage terminals and charging part and get an electric shock.
- If power is off, do not remove the front cover except for wiring or periodic inspection. You may access the charged inverter circuits and get an electric shock.
- Before starting wiring or inspection, check to make sure that the inverter power indicator lamp is off, wait for at least 10 minutes after the power supply has been switched off, and check that there are no residual voltage using a tester or the like. The capacitor is charged with high voltage for some time after power off and it is dangerous.
- Any person who is involved in the wiring or inspection of this equipment should be fully competent to do the work.
- Always install the plug-in option before wiring. Otherwise, you may get an electric shock or be injured.
- Do not touch the plug-in option with wet hands. Otherwise you may get an electric shock.
- Do not subject the cables to scratches, excessive stress, heavy loads or pinching. Otherwise you may get an electric shock.

## 2. Injury Prevention

### CAUTION

- Apply only the voltage specified in the instruction manual to each terminal. Otherwise, burst, damage, etc. may occur.
- Ensure that the cables are connected to the correct terminals. Otherwise, burst, damage, etc. may occur.
- Always make sure that polarity is correct to prevent damage, etc. Otherwise, burst, damage may occur.
- While power is on or for some time after power-off, do not touch the inverter as it is hot and you may get burnt.

## 3. Additional Instructions

Also note the following points to prevent an accidental failure, injury, electric shock, etc.

### 1) Transportation and mounting

### CAUTION

- Do not install or operate the plug-in option if it is damaged or has parts missing.
- Do not stand or rest heavy objects on the product.
- Check that the mounting orientation is correct.
- Prevent other conductive bodies such as screws and metal fragments or other flammable substance such as oil from entering the inverter.

### 2) Trial run

### CAUTION

- Before starting operation, confirm and adjust the parameters. A failure to do so may cause some machines to make unexpected motions.

## 3) Usage

### WARNING

- Do not modify the equipment.
- Do not perform parts removal which is not instructed in this manual. Doing so may lead to fault or damage of the inverter.

### CAUTION

- When parameter clear or all parameter clear is performed, reset the required parameters before starting operations. Each parameter returns to the initial value.
- For prevention of damage due to static electricity, touch nearby metal before touching this product to eliminate static electricity from your body.

### 4) Maintenance, inspection and parts replacement

### CAUTION

- Do not test the equipment with a megger (measure insulation resistance).

### 5) Disposal

### CAUTION

- Treat as industrial waste.

### 6) General instruction

All illustrations given in this manual may have been drawn with covers or safety guards removed to provide in-depth description. Before starting operation of the product, always return the covers and guards into original positions as specified and operate the equipment in accordance with the manual.

# — CONTENTS —

|            |  |           |
|------------|--|-----------|
| <b>1</b>   | <b>PRE-OPERATION INSTRUCTIONS</b>                                    | <b>1</b>  |
| <b>1.1</b> | <b>Unpacking and Product Confirmation</b>                            | <b>1</b>  |
| 1.1.1      | Packing confirmation   | 1         |
| 1.1.2      | Parts  | 2         |
| 1.1.3      | Specifications   | 3         |
| <b>2</b>   | <b>INSTALLATION AND WIRING</b>                                       | <b>5</b>  |
| <b>2.1</b> | <b>Pre-Installation Instructions</b>                                 | <b>5</b>  |
| <b>2.2</b> | <b>Installation Procedure</b>  | <b>6</b>  |
| <b>2.3</b> | <b>Wiring</b>  | <b>7</b>  |
| <b>3</b>   | <b>PARAMETER LIST</b>  | <b>9</b>  |
| <b>4</b>   | <b>EXTENSION ANALOG OUTPUT</b>                                       | <b>11</b> |
| <b>4.1</b> | <b>Wiring Example</b>  | <b>11</b> |
| <b>4.2</b> | <b>Internal Block Diagram</b>  | <b>12</b> |
| <b>4.3</b> | <b>Terminals</b>   | <b>13</b> |
| <b>4.4</b> | <b>Extension Analog Output Function Parameter List</b>               | <b>14</b> |
| <b>4.5</b> | <b>Adjustment Procedure</b>  | <b>15</b> |
| 4.5.1      | Setting of analog output signal voltage/current switchover (Pr. 309) | 15        |
| 4.5.2      | Calibration of meter   | 16        |
| 4.5.3      | Output signal setting  | 18        |
| 4.5.4      | Analog signal adjustment [Pr. 307, Pr. 308, Pr. 311, Pr. 312]        | 19        |
| <b>4.6</b> | <b>Instructions</b>  | <b>20</b> |

|          |   |           |
|----------|---|-----------|
| <b>5</b> | <b>DIGITAL OUTPUT</b>                       | <b>21</b> |
| 5.1      | Internal Block Diagram.....                 | 21        |
| 5.2      | Terminals.....                              | 22        |
| 5.3      | Digital Output Function Parameter List..... | 23        |
| 5.4      | Output Signal List.....                     | 24        |

# 1 PRE-OPERATION INSTRUCTIONS




## 1.1 Unpacking and Product Confirmation

Take the plug-in option out of the package, check the unit name, and confirm that the product is as you ordered and intact.


This product is a plug-in option dedicated for the FR-F700 series.

### 1.1.1 Packing confirmation


Check the enclosed items.

|   |   |  |
|---|---|--|
| <p>Plug-in option<br/>..... 1</p>  | <p>Mounting screw (M3 × 6mm)<br/>..... 2 (Refer to page 6.)</p>  | <p>Hex-head screw for option mounting (5.5mm)<br/>..... 1 (Refer to page 6.)</p>  |
|---|---|--|

## 1.1.2 Parts



### Terminal layout



### 1.1.3 Specifications

- (1) Output signals  
Voltage output (across terminals AM0-AMC) 0 to 10VMAXDC  
Current output (across terminals AM1-AMC) 0 to 20mADC
  
- (2) Output resolution  
Voltage output 3mV  
Current output 10 $\mu$ A
  
- (3) Output accuracy (reference value)  
 $\pm 10\%$  of the full-scale output value  
Depends on the output signal type.
  
- (4) Meters used
  - Voltmeter  
DC voltmeter Full-scale 10V (internal impedance 10k $\Omega$  or more)
  - Ammeter  
DC ammeter Full-scale 20mA (internal impedance 300 $\Omega$  or less)
  - Wiring length  
Maximum 10m



# MEMO

## 2 INSTALLATION AND WIRING


### 2.1 Pre-Installation Instructions

Make sure that the input power of the inverter is off.

#### CAUTION

 **With input power on, do not install or remove the plug-in option. Otherwise, the inverter and plug-in option may be damaged.**

## 2.2 Installation Procedure



- 1) Remove the inverter front cover.
- 2) Mount the hex-head screw for option mounting into the inverter screw hole (on earth plate). (size 5.5mm, tightening torque 0.56N·m to 0.75N·m)
- 3) Securely fit the connector of the plug-in option to the inverter connector along the guides.
- 4) Securely fix the both right and left sides of the plug-in option to the inverter with the accessory mounting screws. If the screw holes do not line-up, the connector may not have been plugged snugly. Check for loose plugging.

### REMARKS


After removing two screws on the right and left places, remove the plug-in option. (The plug-in option is easily removed if the control circuit terminal block is removed before.)

### CAUTION

1. When the inverter can not recognize that the option unit is mounted due to improper installation, etc., "E. 1" (option alarm) is displayed.
2. Note that a hex-head screw for option mounting or mounting screw may drop during mounting and removal.

## 2.3 Wiring

- (1) Strip off the sheath of the cable to wire.  
Strip off the sheath about the size below. If the length of the sheath peeled is too long, a short circuit may occur among neighboring wires. If the length is too short, wires might come off.



**Wire the stripped cable after twisting it to prevent it from becoming loose. In addition, do not solder it. Use a bar type terminal as required.**

### REMARKS


Information on bar terminals

Introduced products (as of October, 2003): Phoenix Contact Co.,Ltd.

| Terminal Screw Size | Bar Terminal Model (with insulation sleeve) | Bar Terminal Model (without insulation sleeve) | Wire Size (mm <sup>2</sup> ) |
|---------------------|---|--|------------------------------|
| M2                  | AI 0.5-6WH                                  | A 0.5-6  | 0.3 to 0.5                   |

· Bar terminal crimping tool: CRIMPFOX ZA3 (Phoenix Contact Co., Ltd.)

**When using the bar terminal (without insulation sleeve), use care so that the twisted wires do not come out.**



- (2) Loosen the terminal screw and insert the cable into the terminal.

| Screw Size | Tightening Torque  | Cable Size                                | Screwdriver   |
|------------|--------------------|---|---|
| M2         | 0.22N·m to 0.25N·m | 0.3mm <sup>2</sup> to 0.75mm <sup>2</sup> | Small ⊖ flat-blade screwdriver<br>(Tip thickness: 0.4mm/tip width: 2.5mm) |


### CAUTION

**Undertightening can cause cable disconnection or malfunction. Overtightening can cause a short circuit or malfunction due to damage to the screw or unit.**


## INSTALLATION AND WIRING

- (3) For wiring of the **30K(00620 (EC Version)) or less**, route wires between the control circuit terminal block and front cover. If cables can not be routed between the control circuit terminal block and front cover due to the increased number of cables, remove a hook of the front cover and use a space become available. For wiring of the **37K(00770 (EC Version)) or more**, use the space on the left side of the control circuit terminal block.


Wiring can be also performed using a cable groove in the inverter side surface



**30K or less**



Cut off a hook on the inverter front cover side surface.  
(Cut off so that no portion is left.)



**37K or more**

### REMARKS

When wires can not be connected to the terminal block due to parallel connection or will not fit in the wiring space due to large gauge or the increased number of cables, perform wiring by using a junction terminal block, etc.

### CAUTION

- ⚠ Do not use empty terminals as junction terminals because they are used in the option unit. If they are used as the junction terminals, the option unit may be damaged.
- ⚠ When installing the inverter front cover, the cables to the inverter's control circuit terminals and option unit terminals should be routed properly in the wiring space to prevent them from being caught between the inverter and its cover.
- ⚠ After wiring, wire offcuts must not be left in the inverter. They may cause a fault, failure or malfunction.

# 3 PARAMETER LIST

When the FR-A7AY is mounted on the inverter, the following parameters are extended.

|                         | Parameter Number        | Name  | Setting Range   | Minimum Increments | Initial Value | Refer to Page |
|-------------------------|-------------------------|---|---|--------------------|---------------|---------------|
| EXTENSION ANALOG OUTPUT | 306                     | Analog output signal selection                  | 1 to 3, 5, 6, 8,(9),<br>10 to14,17, 21, 24, 50,<br>52, 53   | 1                  | 2             | 11 and later  |
|                         | 307                     | Setting for zero analog output                  | 0 to100%  | 0.1                | 0%            |               |
|                         | 308                     | Setting for maximum analog output               | 0 to100%  | 0.1                | 100%          |               |
|                         | 309                     | Analog output signal voltage/current switchover | 0, 1, 10, 11  | 1                  | 0             |               |
|                         | 310                     | Analog meter voltage output selection           | 1 to 3, 5, 6, 8, (9),<br>10 to14, 17, 21, 24, 50,<br>52, 53 | 1                  | 2             |               |
|                         | 311                     | Setting for zero analog meter voltage output    | 0 to100%  | 0.1                | 0%            |               |
|                         | 312                     | Setting for maximum analog meter voltage output | 0 to100%  | 0.1                | 100%          |               |
|                         | 323                     | AM0 0V adjustment                               | 900 to1100%   | 1                  | 1000%         |               |
|                         | 324                     | AM1 0mA adjustment                              | 900 to 1100%  | 1                  | 1000%         |               |
|                         | C0(900)                 | FM(CA) terminal calibration                     | —   | —                  | —             |               |
| C1(901)                 | AM terminal calibration | —   | —   | —                  |               |               |

**PARAMETER LIST**


|                | <b>Parameter Number</b> | <b>Name</b>          | <b>Setting Range</b>   | <b>Minimum Increments</b> | <b>Initial Value</b> | <b>Refer to Page</b> |
|----------------|-------------------------|----------------------|--|---------------------------|----------------------|----------------------|
| DIGITAL OUTPUT | 313                     | DO0 output selection | 0 to 5, (7), 8, 10 to 19, 25, 26, 45 to 47, 64, 70, (71 to 78), 86 to 96, 98, 99, 100 to 105, (107), 108, 110 to 116, 125, 126, 145 to 147, 164, 170, 186 to 196, 198, 199, 9999 | 1                         | 9999                 | 21 and later         |
|                | 314                     | DO1 output selection |  |                           |                      |                      |
|                | 315                     | DO2 output selection |  |                           |                      |                      |
|                | 316                     | DO3 output selection |  |                           |                      |                      |
|                | 317                     | DO4 output selection |  |                           |                      |                      |
|                | 318                     | DO5 output selection |  |                           |                      |                      |
|                | 319                     | DO6 output selection |  |                           |                      |                      |

# 4 EXTENSION ANALOG OUTPUT

## 4.1 Wiring Example

By setting the *Pr. 306* to *Pr. 312* values, analog signals such as the output frequency and output current can be output from the voltage output terminal (*AM0*) and current output terminal (*AM1*).

Connect the voltmeter or ammeter as shown below:




### CAUTION

The wiring length between the FR-A7AY and the voltmeter/ammeter should be 10m maximum.




## 4.2 Internal Block Diagram

The following is the internal block diagram about the FR-A7AY analog output function.



## 4.3 Terminals



| Terminal Symbol | Terminal Name           | Description  |
|-----------------|-------------------------|--|
| AM0             | Voltage output terminal | Connect a DC voltmeter (10VDC).                      |
| AM1             | Current output terminal | Connect a DC ammeter (20mADC).                       |
| AMC             | Common terminal         | Common to AM0 and AM1                                |
| Y0 to Y6        |                         | Used for analog output function. (Refer to page 21 ) |
| SE              |                         |  |
| NC (empty)      |                         | Do not use.  |

## 4.4 Extension Analog Output Function Parameter List

| Parameter Number | Name  | Setting Range  | Minimum Increments | Initial Value |
|------------------|---|--|--------------------|---------------|
| 306              | Analog output signal selection                  | 1 to 3, 5, 6, 8, (9), 10 to 14, 17, 21, 24, 50, 52, 53 | 1                  | 2             |
| 307              | Setting for zero analog output                  | 0 to 100%  | 0.1                | 0%            |
| 308              | Setting for maximum analog output               | 0 to 100%  | 0.1                | 100%          |
| 309              | Analog output signal voltage/current switchover | 0, 1, 10, 11   | 1                  | 0             |
| 310              | Analog meter voltage output                     | 1 to 3, 5, 6, 8, (9), 10 to 14, 17, 21, 24, 50, 52, 53 | 1                  | 2             |
| 311              | Setting for zero analog meter voltage output    | 0 to 100%  | 0.1                | 0%            |
| 312              | Setting for maximum analog meter voltage output | 0 to 100%  | 0.1                | 100%          |
| 323              | AM0 0V adjustment                               | 900 to 1100%   | 1                  | 1000%         |
| 324              | AM1 0mA adjustment                              | 900 to 1100%   | 1                  | 1000%         |
| C0(900)          | FM terminal calibration                         | —  | —                  | —             |
| C1(901)          | AM terminal calibration                         | —  | —                  | —             |

**REMARKS**

For Pr. 306 and Pr. 310, write is enabled even when "0" is set in Pr. 77.

## 4.5 Adjustment Procedure

### 4.5.1 Setting of analog output signal voltage/current switchover (Pr. 309)

Use *Pr. 309 Analog output signal voltage/current switchover* to select whether to output the same signal or different signals from terminal AM0 (voltage output) and terminal AM1 (current output).


| <i>Pr. 309</i><br>Setting | Description  | Terminal  | Parameters for Setting  | Parameters<br>for<br>Adjustment  |
|---------------------------|--|---|---|--|
| 0<br>(initial<br>value)   | Same select signals are output from the voltage output terminal (AM0) and current output terminal (AM1). The signal set in <i>Pr. 306 Analog output signal selection</i> is made valid. (The setting of <i>Pr. 310</i> is made invalid.) | AM0   | <i>Pr. 306</i> : Select the output signal.  | <i>Pr. 323</i><br><i>Pr. 324</i><br><i>CI (Pr. 901)</i>                            |
|                           |  | AM1   | <i>Pr. 307</i> : Output signal value for zero analog output<br><i>Pr. 308</i> : Output signal value for maximum analog output   |  |
| AM0                       |  | <i>Pr. 306</i> : Select the output signal.  |   |  |
| AM1                       |  | <i>Pr. 307</i> : Analog output value for zero output signal<br><i>Pr. 308</i> : Analog output value for maximum output signal   |   |  |
| 10                        | Different select signals are output from voltage output terminal (AM0) and current output terminal (AM1).  | AM0   | <i>Pr. 310</i> : Select the output signal.<br><i>Pr. 311</i> : Output signal value for zero analog output<br><i>Pr. 312</i> : Output signal value for maximum analog output | <i>Pr. 323</i><br><i>CO (Pr. 900)</i><br><br><i>Pr. 324</i><br><i>CI (Pr. 901)</i> |
|                           |  | AM1   | <i>Pr. 306</i> : Select the output signal.<br><i>Pr. 307</i> : Output signal value for zero analog output<br><i>Pr. 308</i> : Output signal value for maximum analog output |  |
| AM0                       |  | <i>Pr. 310</i> : Select the output signal.<br><i>Pr. 311</i> : Analog output value for zero output signal<br><i>Pr. 312</i> : Analog output value for maximum output signal |   |  |
| AM1                       |  | <i>Pr. 306</i> : Select the output signal.<br><i>Pr. 307</i> : Analog output value for zero output signal<br><i>Pr. 308</i> : Analog output value for maximum output signal |   |  |
| 11                        |  | AM0   | <i>Pr. 310</i> : Select the output signal.<br><i>Pr. 311</i> : Analog output value for zero output signal<br><i>Pr. 312</i> : Analog output value for maximum output signal | <i>Pr. 323</i><br><i>CO (Pr. 900)</i><br><br><i>Pr. 324</i><br><i>CI (Pr. 901)</i> |
|                           |  | AM1   | <i>Pr. 306</i> : Select the output signal.<br><i>Pr. 307</i> : Analog output value for zero output signal<br><i>Pr. 308</i> : Analog output value for maximum output signal |  |

#### REMARKS

Analog output means voltage (0 to 10 V) and current (0 to 20mA) output from terminal AM0 and AM1, and output signal means the monitor signal (*refer to page 18*) set in *Pr. 306* and *Pr. 310*.

### 4.5.2 Calibration of meter


(1) Outputting the same select signals from *terminals AM0* and *AMI* (*Pr. 309* = 0 or 10)



### CAUTION

1. If calibration is made without "21" (reference voltage output) set in *Pr. 306*, *Terminals FM/AM* of the inverter is calibrated. To calibrate the extension analog output, always set "21" in *Pr. 306*.
2. When the plug-in option used was remounted on other inverter, use *Pr. 323* and *Pr. 324* to calibrate again.

(2) Outputting different select signals from terminals *AM0* and *AM1* (*Pr. 309* = 1 or 11)



## CAUTION

- If calibration is made without "21" (reference voltage output) set in *Pr. 306* or *Pr. 310*, terminals *FM/AM* of the inverter is calibrated. To calibrate the extension analog output, always set "21" in *Pr. 306*.
- When the plug-in option used was remounted on other inverter, use *Pr. 323* and *Pr. 324* to calibrate again.

### 4.5.3 Output signal setting

Set the output signals to be monitored. Set *Pr. 306* to output the same signal from *terminals AM0* and *AM1* and *Pr. 306* and *Pr. 310* to output different signals. For details of signal definitions, refer to *Pr. 54* and *Pr. 158* of the inverter manual (applied).

| <i>Pr. 306/Pr. 310</i><br>Setting | Types of Monitor                              | Increments                       | Full-Scale Value  |
|-----------------------------------|---|----------------------------------|---|
| 1                                 | Output frequency                              | 0.01Hz                           | <i>Pr. 55</i>   |
| 2                                 | Output current                                | 0.01A/0.1A *2                    | <i>Pr. 56</i>   |
| 3                                 | Output voltage                                | 0.1V                             | 800V  |
| 5                                 | Frequency setting                             | 0.01Hz                           | <i>Pr. 55</i>   |
| 6                                 | Running speed                                 | 1(r/min)                         | The value converted with the <i>Pr. 37</i> value from <i>Pr. 55</i> . |
| 8                                 | Converter output voltage                      | 0.1V                             | 800V  |
| 9 *1                              | Regenerative brake duty                       | 0.1%                             | <i>Pr. 70</i>   |
| 10                                | Electronic thermal relay function load factor | 0.1%                             | Electronic thermal relay function operation level                     |
| 11                                | Output current peak value                     | 0.01A/0.1A *2                    | <i>Pr. 56</i>   |
| 12                                | Converter output voltage peak value           | 0.1V                             | 800V  |
| 13                                | Input power                                   | 0.01kW/0.1kW *2                  | Rated inverter power × 2  |
| 14                                | Output power                                  | 0.01kW/0.1kW *2                  | Rated inverter power × 2  |
| 17                                | Load meter                                    | 0.1%                             | <i>Pr. 56</i>   |
| 21                                | Reference voltage output                      | —                                | —   |
| 24                                | Motor load factor                             | 0.1%                             | 200%  |
| 50                                | Power saving effect                           | Variable according to parameters | Inverter capacity   |
| 52                                | PID set point                                 | 0.1%                             | 100%  |
| 53                                | PID process value                             | 0.1%                             | 100%  |

\*1 Setting can be made only for the 75K(01800-EC, S75K-CH) or more.

\*2 The setting depends on capacities. (55K (01160-EC, 55K-CH) or less/75K (01800-EC, S75K-CH) or more.)


## 4.5.4 Analog signal adjustment [Pr. 307, Pr. 308, Pr. 311, Pr. 312]

Use Pr. 307 or Pr. 311 to set for zero analog output (meter points 0).

In addition, use Pr. 308 or Pr. 312 to set for maximum analog output (full-scale).

Use Pr. 307 to set the value for zero analog output and Pr. 308 for maximum analog output when outputting the same signal from terminals AM0 and AM1.

Use Pr. 307(AM1) and Pr. 311(AM0) to set the value for zero analog output and Pr. 308(AM1) and Pr. 312(AM0) for maximum analog output when outputting different signals from terminals AM0 and AM1. (Refer to page 15.)






### 4.6 Instructions

---

- (1) A voltmeter having smaller internal impedance (or an ammeter having larger internal impedance) than the value indicated in the Specifications may not deflect to full-scale and may not be calibrated.
- (2) When calibrating a meter which has a small full-scale value, set the output of *terminal AM0 (or AM1)* to the minimum without the meter connected. Then, connect the meter and make calibration.

#### **CAUTION**


 **This option unit is factory-set to provide the full-scale output of 10VDC and 20mADC. Hence, a voltmeter (7VDC or less) or an ammeter (14mADC or less) with a small full-scale value may be damaged accidentally during calibration. This should be fully noted.**

- (3) Set "0%" in *Pr. 307 (Pr. 311)* and "100%" in *Pr. 308 (Pr. 312)* when calibrating *Pr. 323, Pr. 324, C0 (Pr. 900), CI (Pr. 901)* when *Pr. 309* = "10 or 11 " to prevent calibration value deviation.
- (4) When an option error occurs, all outputs are tuned off.

# 5 DIGITAL OUTPUT

## 5.1 Internal Block Diagram

The following is the internal block diagram about the FR-A7AY digital output function






## 5.2 Terminals

By setting the *Pr. 313* to *Pr. 319* values, output signals available with an inverter as standard can be output from the open collector terminals.

- (1) Open collector output specifications: Permissible load 24V, 0.1ADC
- (2) The circuit logic is the same as that of the inverter.

For details of changing the control logic, refer to *the inverter manual (basic)*.



| Terminal Symbol | Terminal Name  | Description                                      |
|-----------------|--|--|
| Y0              | Digital output terminals                                     | Use <i>Pr. 313</i> to assign functions.          |
| Y1              |  | Use <i>Pr. 314</i> to assign functions.          |
| Y2              |  | Use <i>Pr. 315</i> to assign functions.          |
| Y3              |  | Use <i>Pr. 316</i> to assign functions.          |
| Y4              |  | Use <i>Pr. 317</i> to assign functions.          |
| Y5              |  | Use <i>Pr. 318</i> to assign functions.          |
| Y6              |  | Use <i>Pr. 319</i> to assign functions.          |
| SE              | Common terminal  | This is a common terminal (for sink and source). |
| AM0             | Used for analog output function. ( <i>Refer to page 11</i> ) |  |
| AM1             |  |  |
| AMC             |  |  |
| NC (empty)      | Do not use.  |  |

## 5.3 Digital Output Function Parameter List

| Parameter Number | Name                 | Initial Value | Setting Range  |
|------------------|----------------------|---------------|--|
| 313              | DO0 output selection | 9999          | 0 to 5, (7), 8, 10 to 19, 25, 26,<br>45 to 47, 64, 70, (71 to 78), 86<br>to 96, 98, 99,<br>100 to 105, (107), 108, 110 to<br>116, 125, 126, 145 to 147, 164,<br>170, 186 to 196, 198, 199,<br>9999 |
| 314              | DO1 output selection | 9999          |  |
| 315              | DO2 output selection | 9999          |  |
| 316              | DO3 output selection | 9999          |  |
| 317              | DO4 output selection | 9999          |  |
| 318              | DO5 output selection | 9999          |  |
| 319              | DO6 output selection | 9999          |  |

### REMARKS

- For Pr. 313 to Pr. 319, write is disabled during operation even when "2" is set in Pr. 77 *Parameter write disable selection*. When changing the parameter setting, stop the operation.
- With this function, output signals can be set redundantly.



## 5.4 Output Signal List

For details of signal definitions, refer to *Pr. 190 to Pr. 196 Output terminal function selection of the inverter manual (applied)*.

| Setting        |                | Signal Name | Function                                      | Setting        |                | Signal Name | Function  |
|----------------|----------------|-------------|---|----------------|----------------|-------------|---|
| Positive Logic | Negative Logic |             |   | Positive Logic | Negative Logic |             |   |
| 0              | 100            | RUN         | Inverter running                              | 15             | 115            | FUP         | PID upper limit   |
| 1              | 101            | SU          | Up to frequency                               | 16             | 116            | RL          | PID forward/reverse rotation output   |
| 2              | 102            | IPF         | Instantaneous power failure/<br>undervoltage  | 17             | —              | MC1         | Commercial power-supply<br>switchover MC1   |
| 3              | 103            | OL          | Overload alarm                                | 18             | —              | MC2         | Commercial power-supply<br>switchover MC2   |
| 4              | 104            | FU          | Output frequency detection                    | 19             | —              | MC3         | Commercial power-supply<br>switchover MC3   |
| 5              | 105            | FU2         | Second output frequency<br>detection          | 25             | 125            | FAN         | Fan fault output  |
| 7              | 107            | RBP         | Regenerative brake prealarm *1                | 26             | 126            | FIN         | Heatsink overheat pre-alarm   |
| 8              | 108            | THP         | Electronic thermal relay function<br>prealarm | 45             | 145            | RUN3        | During inverter running and<br>start command is on                                    |
| 10             | 110            | PU          | PU operation mode                             | 46             | 146            | Y46         | During deceleration due to<br>instantaneous power failure<br>(retained until release) |
| 11             | 111            | RY          | Inverter operation ready                      | 47             | 147            | PID         | During PID control activated  |
| 12             | 112            | Y12         | Output current detection                      | 64             | 164            | Y64         | During retry  |
| 13             | 113            | Y13         | Zero current detection                        | 70             | 170            | SLEEP       | During PID output suspension  |
| 14             | 114            | FDN         | PID lower limit                               | 71             | —              | RO1         | Commercial-power supply side<br>motor 1 connection RO1 *2                             |

| Setting        |                | Signal Name | Function   |
|----------------|----------------|-------------|--|
| Positive Logic | Negative Logic |             |  |
| 72             | —              | RO2         | Commercial-power supply side motor 2 connection RO2 *2 |
| 73             | —              | RO3         | Commercial-power supply side motor 3 connection RO3 *2 |
| 74             | —              | RO4         | Commercial-power supply side motor 4 connection RO4 *2 |
| 75             | —              | RIO1        | Inverter side motor 1 connection RIO1 *2               |
| 76             | —              | RIO2        | Inverter side motor 2 connection RIO2 *2               |
| 77             | —              | RIO3        | Inverter side motor 3 connection RIO3 *2               |
| 78             | —              | RIO4        | Inverter side motor 4 connection RIO4 *2               |
| 86             | 186            | Y86         | Control circuit capacitor life *3                      |
| 87             | 187            | Y87         | Main circuit capacitor life *3                         |
| 88             | 188            | Y88         | Cooling fan life *3                                    |
| 89             | 189            | Y89         | Inrush current limit circuit life *3                   |

\*1 Setting can be made only for the 75K (01800-EC, S75K-CH) or more.

\*2 Setting can be made only for EC and CH version.

\*3 Y86 to Y89 can not be set from the inverter.

## REMARKS

When an option error occurs, all outputs are tuned off.

| Setting        |                | Signal Name | Function                                   |
|----------------|----------------|-------------|--|
| Positive Logic | Negative Logic |             |  |
| 90             | 190            | Y90         | Life alarm                                 |
| 91             | 191            | Y91         | Input MC shut off signal                   |
| 92             | 192            | Y92         | Energy saving average value updated timing |
| 93             | 193            | Y93         | Current average monitor signal             |
| 94             | 194            | ALM2        | Alarm output 2                             |
| 95             | 195            | Y95         | Maintenance timer signal                   |
| 96             | 196            | REM         | Remote output                              |
| 98             | 198            | LF          | Minor fault output                         |
| 99             | 199            | ALM         | Alarm output                               |
| 9999           |                | —           | No function                                |

## REVISIONS

\*The manual number is given on the bottom left of the back cover.

| <b>Print Date</b> | <b>*Manual Number</b> | <b>Revision</b> |
|-------------------|-----------------------|-----------------|
| May, 2004         | IB(NA)-0600165ENG-A   | First edition   |
|                   |                       |                 |