

Operator's Manual Walk-Behind Snowthrowers

MODEL 560 - 5 H.P., 24 INCH (60 cm) WIDTH
MODEL 760 - 7 H.P., 24 INCH (60 cm) WIDTH
MODEL 860 - 8 H.P., 24 INCH (60 cm) WIDTH
MODEL 870 - 8 H.P., 28 INCH (70 cm) WIDTH
MODEL 1070 - 10 H.P., 28 INCH (70 cm) WIDTH
MODEL 1080 - 10 H.P., 32 INCH (80 cm) WIDTH

Simplicity

Contents

IDENTIFICATION & ACCESSORIES	1	NORMAL CARE CHART	11
SAFETY RULES	2	CHECK AUGER GEAR CASE	
DECALS	4	LUBRICATION	11
OPERATION	6	LUBRICATE THE SNOWTHROWER	12
CONTROLS	6	CHECK TIRE PRESSURE	12
CHECKS BEFORE EACH STARTUP	7	INSPECT THE BATTERY	13
DEFLECTOR ADJUSTMENT	7	SERVICE	14
SCRAPER BAR HEIGHT ADJUSTMENT	7	TROUBLESHOOTING	14
FREEWHEELING	8	BELT REPLACEMENT	16
STARTING THE ENGINE	8	TRACTION DRIVE TENSION	18
GROUND SPEED SELECTION	8	AUGER DRIVE TENSION	18
ENGINE SPEED	9	SPEED SELECTOR ADJUST	18
STARTING & STOPPING OPERATION	9	SHEAR PIN REPLACEMENT	19
AFTER EACH USE	10	DISCHARGE CONTROL ADJUST	19
NORMAL CARE	11	SPECIFICATIONS	20
OFF SEASON STORAGE	11	COMMON REPLACEMENT PARTS	22
STARTING AFTER STORAGE	11	PARTS MANUAL AVAILABLE	23

Manufacturer's Numbers

Model 560 - 1690543, 1690775, 1691374

Model 760 - 1690544, 1690903

Model 860 - 1691023, 1691024, 1691376, 1691401, 1691403

Model 870 - 1690545, 1690678, 1690776, 1690778, 1691377

Model 1070 - 1691378

Model 1080 - 1690546, 1690679, 1690777, 1690779, 1691540

Identification & Accessories

Record your model and serial numbers here for easy reference. The snowthrower I.D. tag is located on rear of frame.

Snowthrower I.D. (Mfg. No. & Serial No.)

Engine Model

Serial Number

(See engine Owner's Manual for location of serial number.)

See your dealer to purchase any of the following accessories for your snowthrower.

Tire Chains:

Increase traction on snowy surfaces (use with caution to avoid marking surfaces). Available for all models. Standard on some models.

The PROTECTOR Snow Cab:

Provides shelter for operator from severe weather and blowing snow. Available for all models.

Electric Starter Kit (120V AC):

Offers operator the convenience of electric start. Available for all models. Standard on some models.

Drift Cutters:

Helps break through drifts. Available for all models. Standard on some models.




WARNING

This unit is a "two-stage" snowthrower. The first stage is the auger, which feeds the snow back into the impeller housing. The second stage is the impeller, which throws the snow out the discharge chute. If bodily contact is made with the auger or impeller when they are rotating, severe personal injury will occur. To avoid injury, keep others and yourself away from the auger and the discharge chute whenever the engine is running. See Safety Rules on the following pages.

Safety Rules



Read these safety rules and follow them closely. Failure to obey these rules can result in loss of control of machine, severe personal injury to yourself or bystanders, or damage to property or equipment affecting safety. The triangle  in the text signifies important cautions or warnings which must be followed.

GENERAL

- Read the Operator's Manual carefully. Be thoroughly familiar with all controls and proper equipment use.
- Never allow children to operate the machine. Do not allow adults to operate it without proper instruction.
- Keep the area of operation clear of all persons, particularly small children, and pets.
- Never discharge material toward any person or pet.
- Make sure:
 - a. snowthrower is in good operating condition,
 - b. all safety devices and shields are in place and working, and
 - c. all adjustments are correct.

PREPARATION

- Never attempt to make any adjustment while engine is running.
- Thoroughly inspect the area where the snowthrower is to be used and remove all objects such as door mats, sleds, boards, wires, and sticks.
- Disengage all clutches (release drive levers) before starting engine.
- Do not operate snowthrower without wearing proper winter clothing. Wear footwear which improves footing on slippery surfaces.
- Handle gasoline with care — it is highly flammable.
 - a. Use approved gasoline container.
 - b. Never remove the fuel tank cap or add gasoline to a running or hot engine.

- c. Never fill the fuel tank indoors.
 - d. Wipe up spilled gasoline.
- Adjust skid shoe height to clear gravel or crushed rock surface.
 - Do not run engine indoors. Exhaust fumes are deadly.

OPERATION

- Keep hands and feet away from rotating parts. Keep clear of discharge opening at all times.
- Always clear snow up and down the face of slopes, never across the face. Use extreme caution when changing direction on slopes. Do not attempt to clear slopes over 35% (19.3°).
- After striking an object, release drive levers, stop the engine, and remove spark plug wire. Inspect the snowthrower for damage before restarting.
- Use extreme caution when operating on or crossing gravel drives, walks or roads. Stay alert for hidden hazards and traffic.

- Be especially careful not to touch snowthrower parts which might be hot from operation. Allow such parts to cool before attempting to maintain, adjust, or service.
- If unit starts to vibrate abnormally, disengage drives and stop the engine. Check immediately for the cause. Vibration is generally a warning of trouble.
- Before leaving operator's position for any reason: shut off engine, remove key, and wait for all moving parts to stop.
- Before cleaning, repairing, or inspecting, make certain all moving parts have stopped. Remove key and remove spark plug wire to prevent accidental starting.
- Always use grounded 3 wire plug-in for electric starting.
- Adjust snow discharge angle for safe flow when operating near glass enclosures, automobiles, window wells, drop-offs, etc.
- Do not overload machine capacity by clearing snow at too fast a ground speed.

- Never operate machine at high transport speeds on slippery surfaces. Use care when backing.
- Disengage auger drive when transporting or not in use.
- Never operate the snowthrower without good visibility or light. Always be sure of your footing.



WARNING



To avoid serious injury do not put your hands into the auger housing or discharge spout. If auger stalls or spout plugs, use the following procedure to remove objects or clear the spout.

1. Release both drive levers.
2. Shut off the engine.
3. Wait for moving parts to stop.
4. Use a narrow board to remove foreign objects and clear the spout. Never put your hands into the auger or discharge spout, because tension buildup due to plugging could cause parts to rotate upon clearing.

- Do not change the engine governor settings or overspeed the engine.

MAINTENANCE & STORAGE

- Keep all nuts, bolts, and screws tight to be sure the equipment is in safe working condition.
- Never store equipment with gasoline in the tank in a building where fumes may reach an open flame or spark. Allow the engine to cool before storing in any enclosure.
- Always refer to the Operator's Manual for important details if snowthrower is to be stored for an extended period.
- Run auger drive a few seconds after each completion of throwing snow to help clear out snow and prevent freeze up.



WARNING

MUFFLER & ADJACENT AREAS MAY EXCEED 150°F.

CAUTION

TO AVOID POSSIBLE INJURY

- READ OWNER'S MANUAL BEFORE OPERATING UNIT. NEVER ALLOW CHILDREN TO OPERATE SNOWTHROWER.
- ALWAYS DIRECT DISCHARGE SO AS TO AVOID INJURY OR DAMAGE TO PERSONS OR PROPERTY.
- STOP ENGINE AND DISCONNECT SPARK PLUG WIRE BEFORE SERVICING OR REMOVING DEBRIS. KEEP ALL SHIELDS AND GUARDS IN PLACE WHILE RUNNING.

TRACTION
ENGAGE

RIGHT LEFT
DISCHARGE CONTROL

AUGER AND FREE HAND CONTROL
ENGAGE

TECUMSEH ENGINE INSTRUCTIONS

CAUTION:
FOR YOUR PERSONAL PROTECTION, READ ALL SAFETY NOTES IN ENGINE OWNER'S MANUAL.


OPERATION:
FOR DETAILED LUBRICATION, STARTING, AND OPERATING INSTRUCTIONS, SEE ENGINE OWNER'S MANUAL AND EQUIPMENT MFR'S INSTRUCTIONS.

LUBRICATION:
SUMMER SAE 30 OIL
WINTER SAE 5W-30 OIL

TECUMSEH PRODUCTS COMPANY
900 NORTH STREET
GRAFTON, WI 53024, U.S.A.

Decals - Cont'd.

**PRIMER
PUSH TO PRIME**



DANGER

Avoid injury from rotating auger; Keep hands, feet and clothing away.

DANGER

Avoid injury from rotating blower; Shut off engine before unclogging discharge chute.

<p>SPEED CONTROL PULL UP FOR FAST PUSH DOWN FOR SLOW</p>	<p>IGNITION KEY INSERT TO RUN REMOVE TO STOP</p>	<p>CAUTION ALLOW ENGINE TO COOL FOR 2 MINUTES BEFORE REFUELING</p>
<p>PUSH BUTTON TO CRANK</p>	<p>TO CHOKE ↓</p>	
<p>8 H.P. Briggs & Stratton</p>		

Safety Decals

Safety warning signs are placed at strategic locations on the snowthrower as a constant reminder to the operator of the most important safety precautions. All Warning, Caution, and instructional messages on your snowthrower should be carefully read and obeyed.

If any of these signs are lost or damaged, replace them at once. They can be purchased from your dealer.

Operation




Figure 1. Controls (Location of controls may not match your unit.) Tecumseh shown (see figure 2 for Briggs & Stratton).

ITEM	NAME	FUNCTION	ITEM	NAME	FUNCTION	ITEM	NAME	FUNCTION
A	Traction Drive Lock	Disengage for freewheeling.	E	Discharge Control	Controls direction snow is thrown.	I	Ignition Switch	Allows starting & stopping of engine.
B	Deflector	Controls discharge angle.	F	Traction Control	See "Operation" for explanation.	J	Primer Bulb	Primes carburetor.
C	Light Switch	Turns light on and off. (Only certain models have light)	G	Ground Speed Selector	Controls ground speed. Also shifts to reverse.	K	Throttle Lever	Controls engine speed.
D	Auger & Free-Hand™ Control	See "Operation" for explanation.	H	Skid Shoes	Control height of scraper bar.	L	Rewind Starter	Allows manual start.
						M	Choke	Enriches fuel supply.




Figure 2. Engine Controls.
Briggs & Stratton

CHECKS BEFORE EACH STARTUP

1. Make sure all safety guards are in place and all nuts, bolts and clips are secure.
2. Check the engine oil level. See your engine Owner's Manual for procedure and quantity.
3. Check the fuel supply. Fill the tank to within 1/4 to 1/2 inch of top of tank to provide space for expansion. See your engine Owner's Manual for fuel recommendations.

WARNING

Gasoline is highly flammable and must be handled with care. Never fill the tank when the engine is hot or running. Always move the unit outdoors to fill the tank. Keep snowthrower and gasoline away from open flame or spark.

4. Position the deflector at the desired angle and the scraper bar at the desired height. Engage or disengage the traction drive lock. These procedures are explained in the following paragraphs.

DEFLECTOR ADJUSTMENT

The angle and distance of the discharged snow is controlled by the position of the deflector (B, figure 1). (Engine speed also affects distance of discharge.) The more the deflector is tilted back, the farther snow will be thrown. Loosen the knob to tilt the deflector back or forward then retighten the knob.

SCRAPER BAR HEIGHT ADJUSTMENT

On smooth surfaces such as concrete or asphalt, the scraper bar should scrape the surface. On surfaces such as gravel, the scraper bar should be high enough so that it will not pick up gravel or debris.

The height of the scraper bar is controlled by raising or lowering the skid shoes (H, figure 1).

To raise the scraper bar, rest the scraper bar on a piece of wood of thickness equal to desired height of the scraper bar. Make sure the scraper bar is parallel to the surface. Loosen the skid shoe nuts and let the skid shoes drop to the surface. Tighten the nuts, making sure the skid shoes are adjusted equally and are parallel to the surface.

To lower the scraper bar, raise the skid shoes.

If the scraper bar becomes worn, it can be moved down. Rest the skid shoes on pieces of wood. Loosen the nuts which secure the scraper bar to the housing, and slide the scraper bar down (holes in housing are slotted). Tighten the nuts securely.

FREEWHEELING/TRACTION DRIVE LOCK

For easy turning when pushing the snowthrower (engine off), disengage the traction drive locks (see figure 3 and 4). You can disengage one wheel, or both, for easier turning.

To disengage a drive lock, insert the pin thru the outer hole in the axle as shown in figure 3.

To engage the lock, insert the pin thru the hub and axle as shown in figure 4. If the hole in the hub is not aligned with the inner hole in the axle, push the snowthrower until the




Figure 3. Traction Drive Lock - Disengaged




Figure 4. Traction Drive Lock - Engaged

holes align. Be sure to install spring clip to secure pin.

When snowthrowing, engage both wheels for best performance. You can, however, only engage one wheel to make turning easier, if you are not using full width of auger. Engage the wheel on the side of the snowthrower that contacts the snow.

STARTING THE ENGINE

To start the engine with the rewind starter or with the 120 volt electric start, follow the instructions in the engine Owner's Manual. If the snowthrower is equipped with battery

start (Tecumseh engine) follow this procedure to start the engine.

1. Move the throttle lever to FAST position.
2. To crank the engine, turn the key switch to START. If the engine is cold, move the choke to FULL while cranking. If the engine is warm, try starting without the choke. If engine doesn't start, move the choke to FULL while cranking.
3. When the engine starts, release the key switch. If the engine falters, move the choke to FULL and then gradually to OFF.

GROUND SPEED SELECTION

Use the ground speed selector (G, figure 1) to control the drive speed of the snowthrower. There are five forward speeds and two reverse speeds. Use the lower speeds to blow deep or wet snow. Use the higher speeds to blow light snow or to drive the snowthrower without blowing snow. To change speed, first release the traction drive lever. Then move the selector to the desired speed.



WARNING

OPERATION ON SLOPES

For your safety, operation on slopes should be in an up and down direction only. If it becomes necessary to move across the face of a slope, use caution and do not blow snow. Be very careful when changing direction on a slope.

For added traction, tire chains are recommended. For the operator, proper winter footwear is recommended to help prevent slipping.

Never attempt to clean snow from excessively steep slopes. The maximum slope for any operation is 35 percent (19.3°) which is a rise of 3-1/2 feet vertically in 10 feet horizontally.



WARNING

Before leaving the operator's area for any reason, stop the engine and remove the key. Disconnect spark plug wire and secure away from plug to prevent accidental starting.



WARNING

To avoid serious injury, do not put your hands into the auger housing or discharge spout. If auger stalls or spout plugs, use the following procedure to remove objects or clear the spout.

1. Release both drive levers.
2. Shut off the engine.
3. Wait for moving parts to stop.
4. Use a narrow board to remove foreign objects and clear the spout. Never put your hands into the auger or discharge spout, because tension buildup due to plugging could cause parts to rotate upon clearing.



WARNING

When both levers are depressed, Free-Hand™ control is activated on Mfg. No. 1691374 and higher. Release lever on right-hand handle to stop auger and traction drive after Free-Hand™ control has been activated.

ENGINE SPEED

Set the engine speed lever to full speed.

OPERATION - Mfg. No. 1691374 & Higher

1. For operation on slopes, see the "Operation on Slopes" warning box.
2. Start the engine.
3. Select desired ground speed and set engine speed to full.
4. To start snowthrower into motion, depress the Traction Drive Lever. Releasing the lever will stop traction drive, unless Free-Hand™ control has been activated.
5. The lever on right-hand side is the Auger and Free-Hand™ control lever. Depress this lever to engage the auger. Releasing the lever will stop the auger and also Free-Hand™ control. See step 6 for explanation of Free-Hand™ control.
6. Depressing both levers (figure 5) activates Free-Hand™ control. The operator can now release the Traction Drive Lever, and the wheels will continue to drive. This allows the operator to rotate the chute (figure 6)

without stopping the snowthrower. When the Auger and Free-Hand™ control lever is released, both the auger and traction drive stop.



Figure 5.




Figure 6.

OPERATION - Mfg. No. Lower Than 1691374

1. For operation on slopes, see the "Operation on Slopes" warning box.
2. Start the engine.
3. Select desired ground speed and set engine speed to full.
4. To transport the snowthrower, engage only the Traction Drive Lever. To throw snow, engage the Auger Drive first and then the Traction Drive. If snow stops flowing freely from the spout, stop or back up to allow snowthrower to clear itself.
5. To stop auger drive, release the Auger Drive Lever. To stop traction drive, release the Traction Drive Lever. To stop engine, reduce throttle to slow and turn ignition off.

AFTER EACH USE



WARNING

Never store the snowthrower in a building where gasoline fumes may reach an open flame, spark or pilot light such as on a furnace or water heater.

1. Before stopping engine (Tecumseh models), pull the starter rope twice and allow to rewind slowly. Then, stop the engine. This will help prevent freeze-up.
2. See the "To Stop Engine" section in your engine Owner's Manual. It describes how to prevent engine freeze-up.
3. Always remove the key to prevent unauthorized use.
4. Clean snow and ice from the snowthrower.
5. If the snowthrower is kept in a cold shelter, fill the fuel tank to prevent condensation. Do not store near sparks or flame.

Normal Care

OFF-SEASON STORAGE

Before you store your snowthrower for the off-season, take the following precautions:

NOTE

Fuel may be stored in the tank or in a container for long periods if a gasoline stabilizer is used. This additive, available from your dealer, prevents formations of gum and varnish for up to one year.

1. Prepare your snowthrower engine for storage according to your engine Owner's Manual.
2. Lubricate the snowthrower as described in the Normal Care section.
3. If equipped with a battery, disconnect the cables or remove the battery from the snowthrower. The battery should be kept fully charged during storage.
4. Clean the snowthrower thoroughly. Coat all exposed bare metal parts with a good quality paint (available from your dealer) or a light film of grease, oil or automotive wax.

Normal Care Chart

Care Required	See Page	Every 25 Hours**	Yearly
Check auger gear case lubrication	11	•	
Lubricate snowthrower.	12	•	
Check tire pressure.	12	•	
Inspect battery (if equipped).	13	•	
Change engine oil.*	Eng. Manual	•	
Clean or replace spark plug.	Eng. Manual		••

*Change original engine oil after first two hours of operation.
**At least once a year.

STARTING AFTER STORAGE

1. Remove the spark plug and wipe dry. Crank engine a few times to blow excess oil out of plug hole. Then reinstall plug.
2. Fill fuel tank with fresh gasoline (unless a fuel stabilizer was used).
3. Check to be sure engine fins are clean and air flow is unobstructed.
4. Start the engine outdoors. Do not run engine at high speeds immediately after starting.

5. Check the operation of the controls. If necessary lubricate the snowthrower to improve operation of the spout control.

CHECK AUGER GEAR CASE LUBRICATION

Place the snowthrower on a level surface. Remove the pipe plug (A, figure 4). The lubricant should be level with the hole. If not, add Worm Gear Oil (available from your dealer).




Figure 4. Check Auger Gear Case Lubrication

A. Pipe Plug B. Shear Pins C. Shaft

LUBRICATE THE SNOWTHROWER

With an oil can, apply medium weight (10W) oil to points shown in figure 5, 6, 7 and 7A. There are two grease fittings in the auger shaft (figure 4). Wipe fittings clean and apply two, or three shots of grease. Also, use grease on points shown in figure 8.

Generally, all moving metal parts should be oiled where contact is made with other parts. Keep oil off belts and pulleys.

CHECK TIRE PRESSURE.

The air pressure in each tire should be 20 psi. Be sure to keep caps on valves to prevent entry of moisture. Tire pressure should be equal for best performance.




Figure 5. Lubricate Points Where Control Rods Pass Thru Brackets




Figure 6. Lubricate Points Where Chute Contacts Flange




Figure 7. Lubricate Control Levers




Figure 7A. Lubricate Points Where Free-Hand™ Control Linkage Pivots.





Figure 8. Lubricate Ring Gear And Pinion Gear While Rotating Spout.

**INSPECT THE BATTERY
(If Equipped)**

WARNING

When removing or installing battery cables, always disconnect the negative cable first and reconnect it last to avoid electrical shock and to avoid causing sparks.

Battery cables and terminals should be kept clean and free of corrosion. Baking soda and water can be used to clean the battery, compartment, and cables. The terminals and clamps can be cleaned with a wire brush and coated with petroleum jelly to inhibit corrosion. If water can be added to the battery, the fluid should be kept above the plates. If the battery loses its charge, see your dealer to recharge or replace it.



**Figure 9. Typical Battery Installation
(Shown with cover removed)**

WARNING

Battery acid causes severe burns and is flammable. Keep flames and sparks away from battery. Avoid contact with skin.

WARNING

Before performing any adjustment or service to snowthrower, stop the engine and wait for moving parts to stop. To prevent accidental starting, disconnect the spark plug wire and fasten away from the plug. Remove the key.

This section provides troubleshooting and service instructions. For problems not covered here, contact your dealer.

TROUBLESHOOTING

Locate the problem in the Troubleshooting Chart. Check the possible causes in the order they are listed. Also refer to the engine Owner's Manual for starting procedure, maintenance, etc.

Problem	Cause/Remedy
1. Engine fails to start.	A. Key off. Turn key to "ON" or "START" (Tecumseh). For Briggs & Stratton insert key.
	B. Out of fuel. Fill fuel tank.
	C. Choke not on. Move choke to full and set throttle to fast.
	D. Engine flooded. Move choke to off and try starting engine again.
	E. Spark plug faulty, fouled or poorly gapped. See your dealer for service of points.
	F. Water in fuel. Drain tank and refill with fresh fuel.
	G. Old stale gas. Drain tank and refill with fresh fuel.
	H. Battery discharged (if equipped). See your dealer.
2. Engine starts hard or runs poorly.	A. Fuel mixture too rich. Move choke to off.
	B. Carburetor adjusted incorrectly. See your dealer.
	C. Spark plug faulty, fouled or poorly gapped. Clean and gap or replace. See your dealer for points service.
	D. Fuel cap vent blocked. Clear vent.
3. Auger does not rotate.	A. Auger drive lever not engaged. Engage auger drive lever.
	B. Foreign matter blocking auger. STOP engine. REMOVE key. DISCONNECT spark plug wire. Unplug auger.
	C. Auger drive belt slipping. Check auger drive tension adjustment.
	D. Broken belt. Replace belt.
	E. Shear pin broken. Replace.

Troubleshooting Chart

4. Auger rotates, but snow not thrown far enough.	<ul style="list-style-type: none"> A. Spout deflector too low. Adjust deflector as necessary. B. Engine speed too slow. Set to full throttle. C. Ground speed too fast. Use slower speed. D. Snowthrower discharge spout clogged. STOP engine. REMOVE key. REMOVE spark plug wire. Unplug discharge spout.
5. Scraper bar does not clean hard surface.	Scraper bar improperly adjusted. Adjust.
6. Snowthrower picks up and throws stones on gravel drive.	Scraper bar improperly adjusted. Adjust.
7. Poor traction.	<ul style="list-style-type: none"> A. Traction drive lock not engaged. Engage lock. B. Transmission drive slipping. Check traction drive tension. C. Tires slipping. Use tire chains. D. Friction disc worn, see your dealer.
8. Auger does not stop when drive lever is released.	Auger drive belt out of adjustment. Adjust auger drive belt tension.
9. Snowthrower does not stop when traction drive lever is released.	Traction drive out of adjustment. Adjust traction drive tension.
10. Snowthrower does not drive when drive lever is engaged.	<ul style="list-style-type: none"> A. Traction drive out of adjustment. Adjust. B. Drive belt broken or stretched. Replace belt. C. Transmission drive slipping. Check traction drive tension. D. Friction disc requires replacement. See your dealer.
11. Discharge control difficult to operate.	<ul style="list-style-type: none"> A. Gears need lubrication. Lubricate as required. See page 12. B. Pinion gear requires adjustment. See Discharge Control Adjustment.
12. Cannot shift into all speeds.	See Speed Selector Adjustment.
13. Snowthrower veers.	Tire pressure not equal; should be 20 p.s.i. in each tire.
14. Snowthrower difficult to turn.	Disengage drive locks on one or both wheels. See page 8.

BELT REPLACEMENT

1. Rotate the spout full right. Loosen the two screws which secure the belt cover (A, figure 10). Tilt the cover toward the front and work it off the snowthrower.
2. Remove the belt guide (B, figure 11) by removing the two capscrews, lock-washers and plain washers.




Figure 10. Belt Cover
A. Belt Cover




Figure 11. Belts & Pulleys

- | | | |
|------------------------|---------------------|---------------------------|
| A. Screws | D. Auger Drive Belt | G. Idler Pulley, Auger |
| B. Belt Guide | E. Engine Pulley | H. Traction Pulley |
| C. Traction Drive Belt | F. Auger Pulley | I. Idler Pulley, Traction |

3. Remove the auger drive belt as follows.
 - a. Slip the auger drive belt (D) from the idler pulley by pushing it away from the pulley and then toward the rear.
 - b. Remove the belt from the engine pulley. Slip the belt from under the brake pad and then off the auger pulley (F).
 - c. Pull the belt out between the auger pulley and the traction pulley (H). For more clearance to get the belt out, engage the traction drive lever to move the traction pulley back.
4. Remove the traction drive belt as follows.
 - a. Pull the idler pulley (I) away from the belt and slip the belt from the pulley.
 - b. Slip the belt off the traction pulley and then the engine pulley. The arm for the front idler pulley (G) may have to be pivoted to provide clearance for slipping the belt off the traction pulley.
 - c. Pull the belt out between the auger pulley (F) and traction pulley (H).




Figure 12. Belt Pattern (as viewed from front of snowthrower)

- | | |
|------------------|------------------|
| A. Engine Pulley | C. Idler Pulley |
| B. Drive Belt | D. Driven Pulley |

5. Reverse the procedure to install the belts. Be sure there are no twists and the belts are properly seated in the grooves. The pattern for both belts is shown in Figure 12.
6. Check the Traction Drive Tension and Auger Drive Tension (page 18).
7. Make sure the auger stops when the auger drive lever is released. Make sure traction drive stops when the traction drive lever is released. If not, recheck drive tension. If problem still exists, see your dealer.



WARNING

Do not go near the discharge chute or auger when the engine is running. Do not run the engine with any cover or guard removed.

TRACTION DRIVE TENSION

With the drive lever engaged, the bottom end of the lower rod (D, figure 13) should be flush with the bottom of the spring (E). To adjust, loosen the two nuts. Hold the lower rod to keep from turning and turn the turnbuckle toward the right to lower the rod or toward the left to raise the rod. Engage the drive lever to check the adjustment.




Figure 13. Drive Tension Adjustment

- | | |
|---------------|--------------|
| A. Upper Rod | D. Lower Rod |
| B. Nuts | E. Spring |
| C. Turnbuckle | |

When correct, tighten the two nuts against the turnbuckle. (Hold turnbuckle with pliers while tightening nuts).

AUGER DRIVE TENSION

With the drive lever released, the hook (B, figure 14) should barely touch the lever (C) without raising it. (There can be a maximum of 1/32" clearance as shown.) To adjust, loosen the two nuts (G). Hold the lower rod to keep from turning and turn the turnbuckle toward the right to lower the spring or toward left to raise the spring. When correct, tighten the two nuts against the turnbuckle.

SPEED SELECTOR ADJUSTMENT

1. Loosen the two nuts (F, figure 14).
2. Place the shift lever in 5th gear. The lower link (E) will properly locate itself due to an internal spring.
3. Tighten the two nuts. Do not lift up or down on rods while tightening. Make sure the shoulders of the carriage bolts are in the slots.
4. Always check traction drive tension and auger drive tension after adjusting speed selector.




Figure 14. Auger Drive Linkage

- | |
|-----------------------------|
| A. Turnbuckle |
| B. Spring Hook |
| C. Lever |
| D. Carriage Bolts |
| E. Lower Speed Selector Rod |
| F. Nuts |
| G. Nuts |

SHEAR PIN REPLACEMENT

If the auger strikes an object which could cause damage, the shear pins will break. This protects the gear box and other parts from damage. The shear pins are shown in figure 4. To replace, install a new shear and cotter pin. Spread the legs of the new cotter pin fully.

DISCHARGE CONTROL ADJUSTMENT

If the discharge control is difficult to operate, first lubricate the pinion gear (A, figure 15) and ring gear (F). The pinion gear can be adjusted by loosening the nut (G) which holds the pinion gear bracket in the slotted hole. If the pinion gear is too tight against the ring gear, move it away slightly and then retighten the nut.

If chute turns by itself during operation, the pinion gear should be moved tightly against ring gear.




Figure 15. Discharge Control

- | | |
|------------------|---------------------|
| A. Pinion Gear | D. Slotted Bracket |
| B. Control Rod | E. U-Shaped Bracket |
| C. Carriage Bolt | F. Ring Gear |

Specifications

ENGINE

Make: Tecumseh (Except 860).
Model 860 - Briggs & Stratton

Cylinders: 1

Cycles: 4

Crankshaft: Horizontal

5 H.P. (3.73 kW)*

Model No.: See engine I.D. plate

Type: See engine I.D. plate

Bore & Stroke: 2-13/16 In. (71.44 mm) x 1-15/16 In.
(49.23 mm)

Displacement: 12.04 Cu. In. (197.34 cc)

7 H.P. (5.22 kW)*

Model No.: See engine I.D. plate

Type: See engine I.D. plate

Bore & Stroke: 2-15/16 In. (74.63 mm) x 2-17/32 (64.31 mm)

Displacement: 17.16 Cu. In. (281.32 cc)

8 H.P. (5.97 kW)* (Model 860)

Model No. 190403

Bore & Stroke: 3 in. (76.2 mm) x 2-3/4 in. (69.8 mm)

Displacement: 19.44 cu. in. (319 cc)

8 H.P. (5.97 kW)* (Model 870)

Model No.: See engine I.D. plate

Type (not equipped with battery start): See engine I.D. plate

Type (equipped for 12 V. battery start): See engine I.D. plate

Bore & Stroke: 3-1/8 In. (79.38 mm) x 2-17/32 (64.31 mm)

Displacement: 19.41 Cu. In. (318.27 cc)

10 H.P. (7.46 kW)*

Model No.: See engine I.D. plate

Type (not equipped for battery start): See engine I.D. plate

Type (equipped for 12 V. battery start): See engine I.D. plate

Bore & Stroke: 3-3/16 In. (89.96 mm) x 2-17/32 (64.31 mm)

Displacement: 20.20 Cu. In. (331.06 cc)

***Engine Manufacturer's Rating**

Ignition: Magneto

Governor: Mechanical

Choke: Manual

Lubrication: Splash system

Oil Capacity: See engine manual

Fuel Capacity: See engine manual

Traction Drive

Type: Friction drive transmission w/chain, gear drive and speed selection.

Speeds: Five forward, two reverse

Axle: Solid w/klik-pin lock for two-wheel drive

Tires: 4.80/4.00-8 turf saver pneumatic tire

Blower Housing

Construction: Welded Steel Stampings

Effective Width: **Model 560 & 760:** 24 In. (60 cm)

Model 860: 24 In. (60 cm)

Model 870: 28 In. (70 cm)

Model 1070: 28 In. (70 cm)

Model 1080: 32 In. (80 cm)

Auger Opening Height: 19 In. (47.5 cm)

Spout: 210° rotation

Scraper Bar: High carbon, wear resistant steel

Skid Shoes: Adjustable, heat treated steel

Auger

Construction: Ribbon flite welded steel

Bearings: Self-lubricating bearing

Impeller

Construction: 4 steel blades

Diameter: 12 In. (30 cm)

Bearings: Prelubricated and sealed ball bearing

Auger & Impeller Drive

Type: Cushion V-belt and worm gear housing

Overall Dimensions & Weight

Length: 56-7/8 In. (142.18 cm)

Width: **Model 560 & 760:** 26 In. (65 cm)

Model 860: 26 In. (65 cm)

Model 870: 30 In. (75 cm)

Model 1070: 30 In. (75 cm)

Model 1080: 34 In. (85 cm)

Height: 37-3/8 In. (93.44 cm)

Weight: **Model 560:** 226 lbs. (100 kg)

Model 760: 243 lbs. (110 kg)

Model 860: 240 lbs. (109 kg)

Model 870: 255 lbs. (115 kg)

Model 1070: 265 lbs. (120 kg)

Model 1080: 265 lbs. (120 kg)

Common Replacement Parts

Listed below are part numbers for the more common replacement parts. Use the order form at the back of the manual to order a complete, illustrated parts manual. Use only genuine replacement parts to assure optimum performance and safety.

<u>DESCRIPTION</u>	<u>PART NUMBER</u>
Worm Gear Oil - For Auger Gear Case (one quart)	118065
<i>Simplicity</i> Brand SAE 5W30-Cold Weather Engine Oil (case of 12 qts)	1685518
Knob - Discharge Control	8021050
Spring Clip - For Tire Pin	1960074
Keys - Ignition	122203
Klik-Pin (see figure 3 or 4)	1666969

<u>DESCRIPTION</u>	<u>PART NUMBER</u>
Handle Grip	1671041
Grease Gun Kit	1685510
8 Oz. Grease Tube for above	103077
Touch-Up Paint Orange Spray Paint	103262
Touch-Up Paint White Spray Paint	103049
Service Manual	1672610

Pneumatic Tire Seal - Stops Leaks Available in following amounts:	
11 Oz. Tube	1685523
Case of 12 - 11 Oz. Tubes	1685537
Case of 24 - 11 Oz. Tubes	1685525

USE ONLY GENUINE *SIMPLICITY* REPLACEMENT PARTS
- Available through your local authorized *Simplicity* dealer.

PARTS MANUAL AVAILABLE

Simplicity parts manuals are fully illustrated. All of the assemblies are shown in exploded views which show the relationship of the parts and how they go together. Important assembly notes and special torque values are included in the illustrations. For standard hardware, a torque specification chart is included.

To order a Parts Manual for your Snowthrower, fill out the form and enclose it in an envelope with a check or money order made out to SIMPLICITY.

Simplicity Manufacturing, Inc.
Attn: Cashier
500 N. Spring Steet
P.O. Box 210
Port Washington, WI 53074

SERVICE MANUAL AVAILABLE


A Do-It-Yourself Service Manual is available from your dealer. Order Part Number 1672610. This manual contains fully illustrated step-by-step instructions for complete maintenance, troubleshooting, and repair.


**Extend Equipment Life -
Use Only Genuine Simplicity Repair Parts**

- I would like a Do-It-Yourself Service Manual (Part Number 1672610) for my snowthrower. I am enclosing a check or money order for \$7.00.
- I would like a Parts Manual (TP-1122) for my snowthrower. I am enclosing a check or money order for \$5.00.

(Print clearly, this will be your mailing label)

NAME _____
STREET OR RFD _____
CITY _____ STATE _____ ZIP _____





Simplicity Manufacturing, Inc.
500 N. Spring Street
P.O. Box 997
Port Washington, WI 53074-0997

Copyright © 1987 Simplicity Manufacturing, Inc.

PRINTED IN U.S.A.
