

PRO-CUT® 60 (Single Phase)

IM399-D


May, 1999

PLASMA CUTTING SYSTEM

For use with all code number machines thru 10394

Safety Depends on You

Lincoln arc welding and cutting equipment is designed and built with safety in mind. However, your overall safety can be increased by proper installation ... and thoughtful operation on your part. **DO NOT INSTALL, OPERATE OR REPAIR THIS EQUIPMENT WITHOUT READING THIS MANUAL AND THE SAFETY PRECAUTIONS CONTAINED THROUGHOUT.** And, most importantly, think before you act and be careful.



This manual covers equipment which is obsolete and no longer in production by The Lincoln Electric Co. Specifications and availability of optional features may have changed.



OPERATOR'S MANUAL



World's Leader in Welding and Cutting Products



Premier Manufacturer of Industrial Motors

• Sales and Service through Subsidiaries and Distributors Worldwide •

Cleveland, Ohio 44117-1199 U.S.A. TEL: 216.481.8100 FAX: 216.486.1751 WEB SITE: www.lincolnelectric.com



WARNING

PLASMA CUTTING or GOUGING can be hazardous.

PROTECT YOURSELF AND OTHERS FROM POSSIBLE SERIOUS INJURY OR DEATH. KEEP CHILDREN AWAY. PACEMAKER WEARERS SHOULD CONSULT WITH THEIR DOCTOR BEFORE OPERATING.

Read and understand the following safety highlights. For additional safety information it is strongly recommended that you purchase a copy of "Safety in Welding & Cutting - ANSI Standard Z49.1" from the American Welding Society, P.O. Box 351040, Miami, Florida 33135 or CSA Standard W117.2.

BE SURE THAT ALL INSTALLATION, OPERATION, MAINTENANCE, AND REPAIR PROCEDURES ARE PERFORMED ONLY BY QUALIFIED INDIVIDUALS.



ELECTRIC SHOCK can kill.

- 1.a. The electrode and work (or ground) circuits are electrically "hot" when the power source is on. Do not touch these "hot" parts with your bare skin or wet clothing. Wear dry, hole-free gloves to insulate hands.
- 1.b. When the power source is operating voltages in excess of 250 volts are produced. This creates the potential for serious electrical shock - potentially even fatal.
- 1.c. Insulate yourself from work and ground using dry insulation. When cutting or gouging in damp locations, on metal framework such as floors, gratings or scaffolds and when in positions such as sitting or lying, make certain the insulation is large enough to cover your full area of physical contact with work and ground.
- 1.d. Always be sure the work cable makes a good electrical connection with the metal being cut or gouged. The connection should be as close as possible to the area being cut or gouged.
- 1.e. Ground the work or metal to be cut or gouged to a good electrical (earth) ground.
- 1.f. Maintain the plasma torch, cable and work clamp in good, safe operating condition. Replace damaged insulation.
- 1.g. Never dip the torch in water for cooling or plasma cut or gouge in or under water.
- 1.h. When working above floor level, protect yourself from a fall should you get a shock.
- 1.i. Operate the pilot arc with caution. The pilot arc is capable of burning the operator, others or even piercing safety clothing.
- 1.j. Also see Items 4c and 6.



ARC RAYS can burn.

- 2.a. Use safety glasses and a shield with the proper filter and cover plates to protect your eyes from sparks and the rays of the arc when performing or observing plasma arc cutting or gouging. Glasses, headshield and filter lens should conform to ANSI Z87.1 standards.
- 2.b. Use suitable clothing including gloves made from durable flame-resistant material to protect your skin and that of your helpers from the arc rays.
- 2.c. Protect other nearby personnel with suitable non-flammable screening and/or warn them not to watch the arc nor expose themselves to the arc rays or to hot spatter or metal.



FUMES AND GASES can be dangerous.

- 3.a. Plasma cutting or gouging may produce fumes and gases hazardous to health. Avoid breathing these fumes and gases. When cutting or gouging, keep your head out of the fumes. Use enough ventilation and/or exhaust at the arc to keep fumes and gases away from the breathing zone. **When cutting or gouging on lead or cadmium plated steel and other metals or coatings which produce highly toxic fumes keep exposure as low as possible and below Threshold Limit Values (TLV) using local exhaust or mechanical ventilation. In confined spaces or in some circumstances, outdoors, a respirator may be required. Additional precautions are also required when welding on galvanized steel.**
- 3.b. Do not use plasma arc cutting or gouging in locations near chlorinated hydrocarbon vapors coming from degreasing, cleaning or spraying operations. The heat and rays of the arc can react with solvent vapors to form phosgene, a highly toxic gas, and other irritating products.
- 3.c. Gases used for plasma cutting and gouging can displace air and cause injury or death. Always use enough ventilation, especially in confined areas, to insure breathing air is safe.
- 3.d. Read and understand the manufacturer's instructions for this equipment and the consumables to be used, including the material safety data sheet (MSDS) and follow your employer's safety practices.



CUTTING SPARKS can cause fire or explosion.

- 4.a. Remove fire hazards from the plasma cutting or gouging area. If this is not possible, cover them to prevent the cutting or gouging sparks from starting a fire. Remember that welding sparks and hot materials from plasma cutting or gouging can easily go through small cracks and openings to adjacent areas. Avoid cutting or gouging near hydraulic lines. Have a fire extinguisher readily available.
- 4.b. Where compressed gases are to be used at the job site, special precautions should be used to prevent hazardous situations. Refer to "Safety in Welding and Cutting" (ANSI Standard Z49.1) and the operating information for the equipment being used.
- 4.c. When not cutting or gouging, make certain no part of the electrode circuit is touching the work or ground. Accidental contact can cause overheating and create a fire hazard.
- 4.d. Do not cut or gouge tanks, drums or containers until the proper steps have been taken to insure that such procedures will not cause flammable or toxic vapors from substances inside. They can cause an explosion even though they have been "cleaned." For information purchase "Recommended Safe Practices for the Preparation for Welding and Cutting of Containers and Piping That Have Held Hazardous Substances", AWS F4.1 from the American Welding Society (see address above).
- 4.e. Vent hollow castings or containers before heating, cutting or gouging. They may explode.
- 4.f. Do not fuel engine driven equipment near area where plasma cutting or gouging.

4.g. Sparks and spatter are thrown from the plasma arc. Wear safety glasses, ear protection and oil free protective garments such as leather gloves, heavy shirt, cuffless trousers, high shoes and a cap over your hair. Wear ear plugs when cutting or gouging out of position or in confined places. Always wear safety glasses with side shields when in a cutting or gouging area.

4.h. Connect the work cable to the work as close to the cutting or gouging area as practical. Work cables connected to the building framework or other locations away from the cutting or gouging area increase the possibility of the current passing through lifting chains, crane cables or other alternate circuits. This can create fire hazards or overheat lifting chains or cables until they fail.



CYLINDER may explode if damaged.

5.a. Use only compressed gas cylinders containing the correct gas for the process used and properly operating regulators designed for the gas and pressure used. All hoses, fittings, etc. should be suitable for the application and maintained in good condition.

5.b. Always keep cylinders in an upright position securely chained to an undercarriage or fixed support.

5.c. Cylinders should be located:

- Away from areas where they may be struck or subjected to physical damage.
- A safe distance from plasma cutting or gouging, arc welding operations and any other source of heat, sparks, or flame.

5.d. Never allow any part of the electrode, torch or any other electrically "hot" parts to touch a cylinder.

5.e. Keep your head and face away from the cylinder valve outlet when opening the cylinder valve.

5.f. Valve protection caps should always be in place and hand tight except when the cylinder is in use or connected for use.

5.g. Read and follow the instructions on compressed gas cylinders, associated equipment, and CGA publication P-1, "Precautions for Safe Handling of Compressed Gases in Cylinders," available from the Compressed Gas Association 1235 Jefferson Davis Highway, Arlington, VA 22202.



FOR ELECTRICALLY powered equipment.

6.a. Turn off input power using the disconnect switch at the fuse box before working on the equipment.

6.b. Install equipment in accordance with the U.S. National Electrical Code, all local codes and the manufacturer's recommendations.

6.c. Ground the equipment in accordance with the U.S. National Electrical Code and the manufacturer's recommendations.



PLASMA ARC can injure.

7.a. Keep your body away from nozzle and plasma arc.

7.b. Operate the pilot arc with caution. The pilot arc is capable of burning the operator, others or even piercing safety clothing.



ELECTRIC AND MAGNETIC FIELDS may be dangerous

8.a. Electric current flowing through any conductor causes localized Electric and Magnetic Fields (EMF). Cutting or gouging current creates EMF fields around torch cables and cutting machines.

8.b. EMF fields may interfere with some pacemakers, so operators having a pacemaker should consult their physician before cutting or gouging.

8.c. Exposure to EMF fields during cutting or gouging may have other health effects which are now not known.

8.d. All operators should use the following procedures in order to minimize exposure to EMF fields from the cutting or gouging circuit:

8.d.1. Route the torch and work cables together - Secure them with tape when possible.

8.d.2. Never coil the torch cable around your body.

8.d.3. Do not place your body between the torch and work cables. If the torch cable is on your right side, the work cable should also be on your right side.

8.d.4. Connect the work cable to the workpiece as close as possible to the area being cut or gouged.

8.d.5. Do not work next to cutting power source.

PRÉCAUTIONS DE SÛRETÉ

Pour votre propre protection lire et observer toutes les instructions et les précautions de sûreté spécifiques qui paraissent dans ce manuel aussi bien que les précautions de sûreté générales suivantes:

Sûreté Pour Soudage A L'Arc

1. Protégez-vous contre la secousse électrique:
 - a. Les circuits à l'électrode et à la pièce sont sous tension quand la machine à souder est en marche. Eviter toujours tout contact entre les parties sous tension et la peau nue ou les vêtements mouillés. Porter des gants secs et sans trous pour isoler les mains.
 - b. Faire très attention de bien s'isoler de la masse quand on soude dans des endroits humides, ou sur un plancher métallique ou des grilles métalliques, principalement dans les positions assis ou couché pour lesquelles une grande partie du corps peut être en contact avec la masse.
 - c. Maintenir le porte-électrode, la pince de masse, le câble de soudage et la machine à souder en bon et sûr état de fonctionnement.
 - d. Ne jamais plonger le porte-électrode dans l'eau pour le refroidir.
 - e. Ne jamais toucher simultanément les parties sous tension des porte-électrodes connectés à deux machines à souder parce que la tension entre les deux pinces peut être le total de la tension à vide des deux machines.
 - f. Si on utilise la machine à souder comme une source de courant pour soudage semi-automatique, ces précautions pour le porte-électrode s'appliquent aussi au pistolet de soudage.
2. Dans le cas de travail au dessus du niveau du sol, se protéger contre les chutes dans le cas où on recoit un choc. Ne jamais enrouler le câble-électrode autour de n'importe quelle partie du corps.
3. Un coup d'arc peut être plus sévère qu'un coup de soleil, donc:
 - a. Utiliser un bon masque avec un verre filtrant approprié ainsi qu'un verre blanc afin de se protéger les yeux du rayonnement de l'arc et des projections quand on soude ou quand on regarde l'arc.
 - b. Porter des vêtements convenables afin de protéger la peau de soudeur et des aides contre le rayonnement de l'arc.
 - c. Protéger l'autre personnel travaillant à proximité au soudage à l'aide d'écrans appropriés et non-inflammables.
4. Des gouttes de laitier en fusion sont émises de l'arc de soudage. Se protéger avec des vêtements de protection libres de l'huile, tels que les gants en cuir, chemise épaisse, pantalons sans revers, et chaussures montantes.
5. Toujours porter des lunettes de sécurité dans la zone de soudage. Utiliser des lunettes avec écrans latéraux dans les

zones où l'on pique le laitier.

6. Eloigner les matériaux inflammables ou les recouvrir afin de prévenir tout risque d'incendie dû aux étincelles.
7. Quand on ne soude pas, poser la pince à un endroit isolé de la masse. Un court-circuit accidentel peut provoquer un échauffement et un risque d'incendie.
8. S'assurer que la masse est connectée le plus près possible de la zone de travail qu'il est pratique de le faire. Si on place la masse sur la charpente de la construction ou d'autres endroits éloignés de la zone de travail, on augmente le risque de voir passer le courant de soudage par les chaînes de levage, câbles de grue, ou autres circuits. Cela peut provoquer des risques d'incendie ou d'échauffement des chaînes et des câbles jusqu'à ce qu'ils se rompent.
9. Assurer une ventilation suffisante dans la zone de soudage. Ceci est particulièrement important pour le soudage de tôles galvanisées plombées, ou cadmiées ou tout autre métal qui produit des fumées toxiques.
10. Ne pas souder en présence de vapeurs de chlore provenant d'opérations de dégraissage, nettoyage ou pistolage. La chaleur ou les rayons de l'arc peuvent réagir avec les vapeurs du solvant pour produire du phosgène (gas fortement toxique) ou autres produits irritants.
11. Pour obtenir de plus amples renseignements sur la sûreté, voir le code "Code for safety in welding and cutting" CSA Standard W 117.2-1974.

PRÉCAUTIONS DE SÛRETÉ POUR LES MACHINES À SOUDER À TRANSFORMATEUR ET À REDRESSEUR

1. Relier à la terre le chassis du poste conformément au code de l'électricité et aux recommandations du fabricant. Le dispositif de montage ou la pièce à souder doit être branché à une bonne mise à la terre.
2. Autant que possible, l'installation et l'entretien du poste seront effectués par un électricien qualifié.
3. Avant de faire des travaux à l'intérieur de poste, la débrancher à l'interrupteur à la boîte de fusibles.
4. Garder tous les couvercles et dispositifs de sûreté à leur place.

TABLE OF CONTENTS

	Page
Safety Precautions	2-4
Introductory Information	6
Specifications	7
Product Description	8
Preheat Temperature for Plasma Cutting	8
User Responsibility	8
Installation	9-11
Safety Precautions	9
Location	9
High Frequency Interference Protection	9
Electrical Input Connection	10
Air Input Connections	11
Output Connections	11
Torch Connection	11
Work Cable and Clamp Installation	11
Operating Instructions	11-14
Sequence of events	11
Pilot Arc Discussion	12
Procedure Recommendations	12
General	12
Thin Gauge Sheet Metal	12
Expanded Metal	13
Thick Sections of Metal	13
Gouging	13
In All Cases	14
Suggestions for Extra Utility from the PRO-CUT System	14
Maintenance Procedures	15
Routine Maintenance	15
Troubleshooting Procedures	15-21
Troubleshooting Guide	15-18
PRO-CUT 60 Status Lights Operating Modes	19-20
Procedure for Replacing P.C. Boards	21
Wiring Diagram PRO-CUT 60	22
Input Supply Connection Diagrams	23
Cutting Torch Connection Diagram	24
Parts Lists	Appendix

Thank You

for selecting a **QUALITY** product by Lincoln Electric. We want you to take pride in operating this Lincoln Electric Company product
•• as much pride as we have in bringing this product to you!

Please Examine Carton and Equipment For Damage Immediately

When this equipment is shipped, title passes to the purchaser upon receipt by the carrier. Consequently, Claims for material damaged in shipment must be made by the purchaser against the transportation company at the time the shipment is received.

Please record your equipment identification information below for future reference. This information can be found on your machine nameplate.

Model Name & Number _____

Code & Serial Number _____

Date of Purchase _____

Whenever you request replacement parts for or information on this equipment always supply the information you have recorded above.

Read this Operators Manual completely before attempting to use this equipment. Save this manual and keep it handy for quick reference. Pay particular attention to the safety instructions we have provided for your protection. The level of seriousness to be applied to each is explained below:

WARNING

This statement appears where the information **must** be followed **exactly** to avoid **serious personal injury** or **loss of life**.

CAUTION

This statement appears where the information **must** be followed to avoid **minor personal injury** or **damage to this equipment**.

SPECIFICATIONS

Type	208/230/460/1/60	K1362-1 Handheld Torch with 25 ft. (7.6m) Cable K1362-2 Handheld Torch with 50 ft. (15.2m) Cable
	230/460/1/60	K1361-1 Handheld Torch with 25 ft. (7.6m) Cable K1361-2 Handheld Torch with 50 ft. (15.2m) Cable
	460/575/1/60	K1362-3 Handheld Torch with 25 ft. (7.6m) Cable K1362-4 Handheld Torch with 50 ft. (15.2m) Cable K1362-5 Robotic Torch with 50 ft. (15.2m) Cable K1362-6 Machine Torch with 50 ft. (15.2m) Cable K1362-7 Robotic Torch with 50 ft. (15.2m) Cable K1362-8 Machine Torch with 50 ft. (15.2m) Cable
Input Frequency		K871-1 [25Ft.(7.6m)Cable] & K871-2 [50Ft.(15.2m)Cable] Magnum PCT 60 Air Cooled Torch 60 Hz
Output Rating		60 Amps, 115 volts, 60% Duty Cycle 60 Amps, 115 volts, Maximum Output 45 Amps, 115 volts, 100% Duty Cycle
Pilot Current		22.5 amps
Pilot Duty Cycle		25% (20 seconds out of 80 seconds)
Current Range		25-60 Amps
Maximum OCV		282 Volts
Normal OCV		250 Volts
Input Power		
Standard Voltages	208/230/460/1/60	K1362-1, -2, -5, -6
Current	50/45/23 Amps	
Other Voltages	230/460/1/60	460/575/1/60
Current	K1361-1, -2 45/23 Amps	K1362-3, -4, -7, -8 23/18 Amps
Idle Current		4.5 amps @ 230V Maximum
Idle Power		0.7 kW Maximum
Power Factor @ Rated Load		0.65
Net Weight		
w/25 ft. (7.6 m) Cable		322 lbs/146 kg
w/50 ft. (15.2 m) Cable		329 lbs/149 kg
Dimensions, H x W x D (includes lift bail and undercarriage)		34" x 19" x 22" (864mm x 483mm x 559mm)

PRODUCT DESCRIPTION

The PRO-CUT® 60 is a constant current, single range, continuous control plasma cutting system. It provides excellent starting characteristics, cutting visibility and arc stability. The torch has a patented safety mechanism which insures that the consumables are in place before cutting or gouging. This is extremely important due to the high voltages involved.

The PRO-CUT 60 comes standard with air regulator, coarse air filter, oil coalescing filter, and pressure gauge. The Pro-Cut 60 comes ready to use with the torch attached. Machines equipped with handheld torches are available with either 25 ft. (7.6m) or 50 ft. (15.2m) torch cable. The undercarriage is standard and is shipped assembled except for the handle. The machine is capable of cutting with nitrogen or air. Nitrogen is used to cut aluminum and other nonferrous metals.

The PRO-CUT is controlled by a microprocessor-based system. The machine performs rudimentary self troubleshooting when powered up, which aids in field servicing.

PREHEAT TEMPERATURE FOR PLASMA CUTTING

Preheat temperature control is recommended for optimum mechanical properties, crack resistance and hardness control. This is particularly important on high alloy steels and heat treated aluminum. Job conditions, prevailing codes, alloy level, and other considerations may also require preheat temperature control. The following minimum preheat temperature is recommended as a starting point. Higher temperatures may be used as required by the job conditions and/or prevailing codes. If cracking or excessive hardness occurs on the cut face, higher preheat temperature may be required. The recommended minimum preheat temperature for plate thickness up to 1/2 inch (12.7m) is 70 (°F) (21.1°C).

USER RESPONSIBILITY

Because design, fabrication, erection and cutting variables affect the results obtained in applying this type of information, the serviceability of a product or structure is the responsibility of the user. Variation such as plate chemistry, plate surface condition (oil, scale), plate thickness, preheat, quench, gas type, gas flow rate and equipment may produce results different than those expected. Some adjustments to procedures may be necessary to compensate for unique individual conditions. Test all procedures duplicating actual field conditions.

INSTALLATION

SAFETY PRECAUTIONS

- Read the safety precautions at the beginning of this Operator's Manual before proceeding.
- Only personnel that have read and understood this Operator's Manual should install and operate this equipment.
- Machine must be connected to system ground per any national, local or other applicable electrical codes.
- The power switch is to be in the "OFF" position when connecting power cord to input power.

WARNING

TURN THE INPUT POWER OFF USING THE DISCONNECT SWITCH AT THE FUSE BOX BEFORE ATTEMPTING TO CONNECT THE INPUT POWER LINES.

- Only qualified personnel should perform this installation.
- Turn the power switch on the PRO-CUT "off" before connecting or disconnecting output cables.
- Connect the PRO-CUT grounding terminal located on the side of the case back to a good electrical earth ground.

LOCATION

Place the PRO-CUT where clean cooling air can freely circulate in through the front intake and out through the rear louvers. Dirt, dust or any foreign material that can be drawn into the machine should be kept at a minimum. Failure to observe these precautions can result in excessive operating temperatures and nuisance shutdown of the machine. Before planning the installation, read the section entitled "High Frequency Interference Protection".

A source of clean, dry, compressed air or nitrogen must be supplied to the PRO-CUT. Oil in the air is a severe problem and must be avoided. The supply pressure must be between 70 and 120 psi (482 and 827 kPa). The flow rate is approximately 4.7 cfm (133 l/min.). Failure to observe these precautions could result in excessive operating temperatures or damage to the torch.

HIGH FREQUENCY INTERFERENCE PROTECTION

Since the spark gap oscillator in the high frequency generator in the machine is similar to a radio transmitter, improper machine installation can result in radio and TV interference or problems with nearby electronic equipment.

Radiated interference can develop in the following four ways:

- (1) Direct interference radiated from the machine.
- (2) Direct interference radiated from the cutting leads.
- (3) Direct interference radiated from feedback into the power lines.
- (4) Interference from reradiation of "pickup" by ungrounded metallic objects.

Keeping these contributing factors in mind, installing equipment per the following instructions should minimize problems.

- (1) Keep the machine power supply lines as short as possible.
- (2) Keep the work and torch leads as short as possible and as close together as possible. Lengths should not exceed 50 ft. (15.2 m). Tape the leads together when practical.
- (3) Be sure the torch and work cable rubber coverings are free of cuts and cracks that allow high frequency leakage.
- (4) Keep the torch in good repair and all connections tight to reduce high frequency leakage.
- (5) Keep all access panels and covers securely in place

NOTE: The machine frame MUST also be grounded - see CAUTION under "Input Connection", section. The work terminal ground does not ground the machine frame.

- (6) When the machine is enclosed in a metal building, several good earth driven electrical grounds around the periphery of the building are recommended.

Failure to observe these recommended installation procedures may cause radio or TV interference problems and result in unsatisfactory cutting or gouging performance resulting from lost high frequency power.

INPUT CONNECTIONS

⚠ WARNING



ELECTRIC SHOCK can kill.

- Disconnect input power before proceeding.
- Have a qualified electrician make

the input connections.

- Be sure the voltage, phase and frequency of the input power is as specified on the machine nameplate.

Before starting the installation, check with the local power company if there is any question about whether your power supply is adequate for the voltage, amperes, phase, and frequency specified on the machine nameplate. Also be sure the planned installation will meet the any National Electrical Code and local code requirements. This machine may be operated from a single phase line or from one phase of a two or three phase line.

Models that have multiple input voltages specified on the nameplate (e.g. 208/230/460) are shipped connected for the highest voltage. If the machine is to be operated on the lower voltage, it must be reconnected according to the instructions on the inside of the removable panel in the center of the rear panel. Machine supply line entry provision is next to the removable panel.


⚠ WARNING




ELECTRIC SHOCK can kill.

- Make certain that the input power is electrically disconnected before removing the screws that hold the removable rear panel in place.

Have a qualified electrician connect the input leads to L1 and L2 of the terminal block in accordance with any National Electrical Code, all local codes and the connection diagram located on the inside of the cover. Use ferrules provided (S19117-1) for #10 wire. No ferrule is required for #8 wire. Tighten screws to 16 in/lbs. (1.8 N.M.). See below.



Strip Required for #10 (5.3mm²) Wire




Place Ferrule (S19117-1) Over Wire as Shown Before Insertion into Machine Terminal Block. For #10 (5.3mm²) AWG Wire Only

RECOMMENDED WIRE SIZE FOR PRO-CUT INPUT CONNECTIONS Based on U.S. National Electrical Code Ambient Temperature 30°C or Less

Rated Input Voltage	Wire Size (Copper, 75°C)		Fuse Size
	2 Input Wires	1 Grounding Wire	
Less than 230	#8 (8.4mm ²)	#10 (5.3mm ²)	50Amp
230	#8 (8.4mm ²)	#10 (5.3mm ²)	50Amp
460	#10 (5.3mm ²)	#10 (5.3mm ²)	25Amp
Greater than 460	#10 (5.3mm ²)	#10 (5.3mm ²)	25Amp

⚠ CAUTION

The frame of the machine must be grounded. A ground terminal marked with the symbol  located at the left side of the input box is provided for this purpose. See the U.S. National Electrical Code for details on proper grounding methods. Follow other grounding instructions per the paragraph under “High Frequency Interference Protection”.

On multiple voltage input machines, be **sure** the reconnect panel is connected per the following instructions for the voltage being supplied to the machine. See Figure 1 in the back of this manual.

- Failure to follow these instructions can cause immediate failure of machine components.

The PRO-CUT is shipped connected for the highest nameplate input voltage. To change this connector for a different input voltage, reconnect the power straps to their respective terminals corresponding to the input voltage used.

Fuse the input circuit with the recommended super lag fuses. Choose an input and grounding wire size according to local codes or use the Input Connection table. “Delay type”⁽¹⁾ circuit breakers may be used in place of fuses. Using fuses or circuit breakers smaller than recommended may result in “nuisance” tripping from machine inrush currents even if not cutting or gouging at high currents.

⁽¹⁾ Also called “inverse time” or “thermal/magnetic” circuit breakers; circuit breakers which have a delay in tripping action that decreases as the magnitude of the current increases.

⚠ WARNING

CYLINDER may explode if damaged



- Keep cylinder upright and chained to a fixed support.
- Keep cylinder away from areas where it may be damaged.
- Never lift equipment with cylinder attached.
- Never allow the cutting torch to touch cylinder.
- Keep cylinder away from live electrical circuits.
- Maximum inlet pressure 120 psig (827 kPa).

AIR INPUT CONNECTIONS

A source of clean compressed air or nitrogen must be supplied to the PRO-CUT. The supply pressure must be between 70 and 120 psi (482 and 827 kPa). The flow rate is approximately 4.7 cfm (133 l/min). Oil in the air is a very severe problem and must be avoided.

Remove the plastic thread protector from the regulator input port (located on the back of the machine). Use a suitable gas connection fitting to make the connection to the available air supply. The input port is a 1/4”

(6.3 mm) NPT thread. Tighten the air fitting to prevent leakage but do not overtighten. The use of Teflon tape to seal the connection is recommended.

Nitrogen from cylinders may be used with this machine. The cylinder of nitrogen gas must be equipped with a pressure regulator. No more than 120 psi (827 kPa) may be supplied to the regulator on the machine. Install a hose between the regulator on the gas cylinder and the gas inlet on the machine.

OUTPUT CONNECTIONS

⚠ WARNING



HIGH FREQUENCY SHOCK CAN CAUSE INJURY OR FALL.


- Keep the cutting torch and cables in good condition.
- Secure yourself in position to avoid a fall.

Torch Connection

The PRO-CUT comes factory equipped with a cutting torch.

Pictures of the torch along with the required replacement parts are shown in the parts lists in the back of this manual. The ends of the cable to be connected to the power source are unique. Follow the applicable instructions as given in Figure 2 in the back of this manual.

Work Cable and Clamp Installation



Attach the work clamp to the work cable (which extends from the front of the machine) as shown. Tighten nut and bolt securely.

OPERATING INSTRUCTIONS

Sequence of events:

- A. Turn on the line power.
- B. Connect the air supply to the machine.
- C. Turn the power switch on.

-The green “Power On” LED should begin to glow.

-The fan should start.

-If the “Safety” LED is glowing, push the “Safety Reset” button. If there is no problem, the LED will go off. If there is a problem, refer to Step F and the Troubleshooting Guide.

D. Set the Purge/Run switch to Purge.

-The air should start.

-The “Air Pressure” LED should be lit.

-Adjust the air regulator for 60 psi (413 kPa), minimum while air is flowing.

E. Set the Purge/Run switch to Run.

-The air will continue to run for 20 seconds of postflow. If the trigger is activated within this time period, the pilot arc will immediately start.

F. When ready to cut, place the work lead on the piece to be cut, place the torch near the work, make certain all safety precautions have been taken and pull the trigger.

-The air will flow for a preflow time of 2 seconds and the pilot arc will start. (This is true unless the machine is in postflow, then the preflow time is skipped.)

-The “Output ON” LED will light.

-The pilot arc will run for 2.5 seconds and shut off unless it is brought in contact with the work and the arc is transferred.

-When the arc is transferred, cutting begins. Finish the cut to be made and release the trigger.

G. When the trigger is released, the arc will stop.

-The air will continue to run for 20 seconds of postflow. If the trigger is activated within this time period, the pilot arc will immediately restart.

H. If the “Safety” LED lights at any time, check the following:

WARNING

ELECTRIC SHOCK CAN KILL.

- Turn off machine at the disconnect switch on the front of the machine before tightening, cleaning or replacing consumables.



- Check the assembly of the torch consumables. If they are not properly in place then the machine will not start.

- After the problem is found, reset the machine by pressing the “Safety Reset” button. (It is possible for electrical noise to trip the safety circuit on rare occasions. This should not be a regular occurrence.)

- If the machine does not reset or continues to trip, consult the Troubleshooting Section.

Pilot Arc Discussion:

The PRO-CUT has a smooth, continuous pilot arc. The pilot arc is only a means of transferring the arc to the workpiece for cutting. Repeated pilot arc starts, in rapid succession, is not recommended as these starts will generally reduce consumable life. Occasionally, the pilot arc may sputter or start intermittently. This is aggravated when the consumables are worn or the air pressure is too high. Always keep in mind that the pilot arc is designed to transfer the arc to the workpiece and not for numerous starts without cutting.

Procedure Recommendations

When properly used, plasma arc cutting or gouging is a very economical process.. Improper use will result in a very high operating cost.

General

- Follow safety precautions as printed inside the operating manual and on the machine.
- Use the drag cup when hand cutting at medium or high output.
- Use the proper cutting or gouging procedures referred to in procedures guideline.
- Use the shield cup with mechanized torches or when hand cutting at low output.

Thin Gauge Sheet Metal:

Output set below mid-range.

- The torch should be dragged on the metal surface, touching the nozzle lightly to the surface after piercing a hole. Current control should be set in the yellow range only.
- The S24114 Drag Cup should not be used at very low outputs. It may cause erratic arc action.

- The .035" (0.8mm) nozzle may be used for a fine cut. Larger nozzles will work and provide longer life at the expense of a larger cut.
- Do not allow the torch cable or body to contact hot surface.
- The best quality cut is obtained by reducing the current to a level that is adequate for the maximum travel speed.
- Aluminum, copper and other nonferrous metals typically require more current than the same thickness of steel. Treat these as a thicker section of steel if good results are not obtained.

Expanded Metal:

Output set near mid-range.

- Cut it as you would light gauge sheet metal.
- Expanded metal is pilot arc intensive. After about 30 seconds of cutting, the pilot arc will change from a bright continuous arc to a discontinuous one which will sputter slightly. It will stay in this mode as long as metal has been cut in the previous 5 seconds. If metal is not cut in the previous 5 seconds, the arc will shut off and the machine will go into postflow.
- If the trigger is continuously pressed and released to obtain the bright pilot arc for long periods of time, the machine will go into pilot arc duty cycle limit. This is a 20 seconds out of 80 seconds pilot duty cycle. The pilot arc is disabled in the limit period. Pilot arc duty cycle limit is indicated by alternately flashing "OUT-PUT ON" and "FAULT" LED's.
- Placing a thin piece of scrap sheet metal above the area to be cut and cutting through both can make the job easier.
- Do not allow the torch cable or body to contact hot surfaces.

Thick Sections of Metal

Output set above mid-range.

- The best quality and consumable life will be obtained by holding the torch nozzle off the surface about 1/8" (3.2mm). Output control should be sent in the red range only. Do not touch the nozzle to the work or carry a long arc.
- Use the S24114 Drag Cup to protect the torch. The only reason not to use the Drag Cup when

the output control is in the blue or red regions is in special tight corners. Always hold at least a 1/8" (3.2mm) standoff in those situations and use the S18817 shield cup.

- Set the current to the minimum necessary to make the cut.
- Use the .052" or .042" (1.2 or 1.0mm) nozzle size. **DO NOT** use the .035" (0.8mm) nozzle.
- Pierce the plate by slowly lowering the torch onto it at an angle of about 30° to blow the dross away from the torch tip and slowly rotate the torch to a vertical position as the arc becomes deeper.
- Where possible, start the cut from the edge of the workpiece.
- **Keep moving!** A steady speed is necessary. Do not pause.
- Do not allow the torch cable or body to contact hot surfaces.

Gouging:

Output set to maximum.

- Use the gouging nozzle S18497-4
- Use the Shield Cup.
- Bring the torch slowly towards the work at about a 30° angle as if piercing the plate. Blow the molten metal away from the torch.
- Do not touch the nozzle to the work.
- The air pressure may be raised to about 75 psi (517 kPa) to aid in metal removal.
- This process will blow a lot of molten metal and dross. **BE CAREFUL!** Blow the dross away from the torch, away from the operator and away from flammable objects.
- Do not allow the torch cable or body to contact hot surfaces.
- Performance is similar to air carbon arc gouging with a 1/8" (3.2mm) carbon electrode.

In All Cases:

- Do not pause when cutting or gouging the metal. This is not necessary and causes operational difficulty. Pausing at the edge of the workpiece causes poor consumable life and erratic operation.
- Always position the torch in the best way to keep dross and hot air from burning back into it.
- Do not carry a long arc. This may trip the safety or fault circuits and wears consumables rapidly.
- Do not drag the nozzle above the mid-range setting. Always hold a standoff of 1/8" above mid-range.
- Use a Drag Cup where possible but only when the current is in the blue or red ranges. Drag the nozzle in the yellow range. The use of the Drag Cup at low currents (in the yellow range) may cause problems. Proper use of the Drag Cup is the best way to get maximum nozzle and consumable life.
- Use the proper machine setting. Running the system at maximum output will not produce the best cutting performance in most situations.
- Use the proper cutting or gouging procedures referred to in procedures guideline.
- Use the nozzle with the largest orifice size that gives an acceptable cut. This will improve parts life. Never use the .035" (0.8mm) nozzle at outputs above the yellow range.

Suggestions for Extra Utility from the PRO-CUT System:

- In some cases where moderate or thin sections are being cut, higher air pressure may give better consumable life. At pressures about 80 psi (551 kPa), the pilot arc may sputter. This may be an annoyance but it will not damage the torch or power source. 60 psi (413 kPa) minimum while air is flowing is the recommended pressure because it is the minimum necessary to provide proper cooling in all situations. Feel free to experiment with higher pressures (not to exceed 120 psi (827 kPa) at the regulator input).

WARNING

ELECTRIC SHOCK CAN KILL.

- Turn off machine at the disconnect switch on the front of the machine before tightening, cleaning or replacing consumables.

- The PRO-CUT will cut with consumables that are worn considerably. Many competitive systems require replacement consumables long before a PRO-CUT system does. This is because of the solid state current regulation that the PRO-CUT has. Also, the safety reset circuit provides a means of extending nozzle life. Sometimes a small piece of material breaks off the electrode and bridges the gap between the nozzle and the electrode. In a competitive unit, this would often result in the destruction of the electrode and nozzle due to overheating. This will result in the tripping of the PRO-CUT safety circuit. When this happens, turn the power off, remove the nozzle and scrape any debris from its inside cavity with a piece of sturdy wire or a suitable drill bit. Replace the nozzle, turn on the power and continue cutting.
- The electrode has a hafnium insert at the tip which greatly prolongs the life of the consumable. When that insert has been consumed, the machine will automatically turn off output and lock up in "FAULT". At this point, replace the electrode and the nozzle; it is not recommended to continue cutting with an electrode that has consumed all of its hafnium.
- Use of the nozzle with the largest orifice size that produces acceptable cutting results will maximize consumable life. Procedures given are all based on a .042" (1.0mm) orifice size. Smaller orifice sizes constrict the arc more, raising the energy density and therefore the temperature. Larger orifice sizes have an opposite effect. Small orifice nozzles run hotter and wear faster than large orifice nozzles but produce a finer cut with less kerf width. There is a certain current where each orifice size becomes unstable because it runs too hot. Never use the smallest .035" (0.9mm) orifice size at outputs above the yellow range because it will be quickly destroyed.
- The PRO-CUT 60 is capable of operation with a 50 ft. (15.2m) plasma torch. Pilot arc operation may be slightly degraded with this torch installed. Sputtering may occur after the pilot arc is established and occasionally the pilot arc may not light after the trigger is depressed*. Keep in mind that the condition of the consumables and air pressure level have a large impact on pilot arc ignition.

* Neither cutting performance nor machine reliability will be lessened by this condition.

MAINTENANCE PROCEDURE

ROUTINE MAINTENANCE

WARNING



ELECTRIC SHOCK CAN KILL. BEFORE PERFORMING ANY MAINTENANCE THAT REQUIRES OPENING THE CASE OF THE POWER SOURCE:

- Disconnect input power to this machine at the Disconnect switch.
- Do not touch electrically live parts or internal wiring.
- Only qualified personnel should service this machine.

1. Keep the cutting or gouging area and the area around the machine clean and free of combustible materials. No debris should be allowed to collect which could obstruct air flow to the machine.
2. Every few months, blow the dust off the air intakes and louvers with compressed air. Also, blow off the components in the upper compartment with compressed air.
3. Check the air regulator filters to be sure they do not become clogged. The first stage of the air filter on the machine is self draining and will stop most of the water in the air line. The second stage of the filter is also self draining and will stop almost all of the oil in the line as well as particulate matter. Both stages will drain automatically when the flow rate changes rapidly.
4. Check the filter elements every several months to see if they are clogged (weekly in very dirty environments). Replace if necessary.
5. Inspect the cable periodically for any slits or puncture marks in the cable jacket. Replace if necessary. Check to make sure that nothing is crushing the cable and blocking the flow of air through the air tube inside. Also, check for kinks in the cable periodically and relieve any so as not to restrict the flow of air to the torch.

WARNING

ELECTRICAL SHOCK CAN KILL.

- Turn off machine at the disconnect switch at the back of the machine before tightening, cleaning or replacing consumables.

Change consumables as required.

TROUBLESHOOTING PROCEDURES

WARNING



ELECTRIC SHOCK CAN KILL. BEFORE PERFORMING ANY MAINTENANCE THAT REQUIRES OPENING THE CASE OF THE POWER SOURCE:

- Disconnect input power to this machine at the Disconnect switch.
- Do not touch electrically live parts or internal wiring.
- Only qualified personnel should service this machine.

HOW TO USE THIS GUIDE: Carefully read through each applicable section listed on the following pages. Remember that most problems are caused by improper setup, such as switch settings, control settings, etc.

If you believe the set up is correct and the trouble still exists, first check for the obvious: input power, blown fuses, loose PC board connectors, broken wires and the like. The sections listed on the following pages are intended to help you find the less obvious sources of trouble.

SYMPTOM	CHECK
<p>No LED's light when the power switch is turned on.</p>	<ol style="list-style-type: none"> 1. Check the input power to be sure it is on. 2. Check the power line fuses and machine connection. 3. Replace line switch.
<p>TORCH WILL NOT LIGHT The "MACHINE ON" LED is lit, but there is no response when the trigger is pulled.</p>	<ol style="list-style-type: none"> 1. Low air pressure results in a "no start" condition. "Air Pressure" LED must be lit when air is flowing. Set the machine in purge mode. The air will turn on. Set the regulator on the back of the machine for 60 psi minimum. If the "AIR PRESSURE" LED does not light, raise the pressure slightly. If the inlet pressure is greater than 75 psi and the LED is not lit when air is flowing, there is a leak or the air filters in the regulator assembly are clogged. 2. Check the "SAFETY" LED. If it is lit, check the torch consumables and press the "SAFETY RESET" button. 3. Check the air supply to the machine. If the air does not flow, the machine will not start. 4. Check the operation of the air solenoid by switching the machine to "PURGE". The air should begin to flow and if the pressure is sufficient, the "AIR PRESSURE" LED will light. Return to "RUN" mode. If air does not flow, check the solenoid by applying 115 VAC to its input leads. If it is bad, replace the solenoid, or else replace the control board.
<p>The air begins to flow, the "OUTPUT ON" LED lights for a brief period, but no arc is established.</p>	<ol style="list-style-type: none"> 1. Check the torch consumables to be sure they are in tight, not dirty or greasy, and in good shape. Replace the consumables if necessary. 2. Check that CR2 engages. 3. Check for high frequency at the spark gap. 4. Check the high frequency spark gap located inside the right panel of the machine. It should be set at .060" (1.52mm) DISCONNECT ALL POWER BEFORE ADJUSTING THE HIGH FREQUENCY CIRCUIT. 5. Blow off the components in the upper compartment with compressed air. 6. Check pilot to 391 for 2 ohm resistance. 7. Check 2 ohm 300 watt resistor. 8. Replace Control PC Board.

SYMPTOM	CHECK
The arc starts but sputters badly.	<ol style="list-style-type: none"> 1. Check the torch consumables to be sure they are tight, not dirty or greasy and in good shape. Replace if necessary. 2. Check air supply for oil or a great deal of water. If there is oil or a great deal of water, the air must be filtered or the machine switched to nitrogen or bottled air. 3. Check the air pressure. The pressure must be 60 psi (413 kPa) minimum while air is flowing. The "Air Pressure" LED must be lit.
The "THERMAL" LED is lit. The "FAULT" LED is blinking.	<ol style="list-style-type: none"> 1. The machine is overheated. Allow it to cool and reset. The air intakes of the machine must not be blocked, or this will become a nuisance.
The "FAULT" LED is lit	<ol style="list-style-type: none"> 1. The Fault circuit monitors the torch to see if it is shorted as well as internal machine failures. 2. Check the torch consumables to see if they are melted together or are simply touching each other. Tighten, clean or replace. See "Suggestion for Extra Utility from the PRO-CUT System". 3. Check the torch cable to see if it is cut or punctured. Replace. 4. Turn off the machine and turn it back on. If the "FAULT" LED will not stay off when you try to cut again and there is no problem with the torch, then something has failed in the machine and the machine should not be left on. <ol style="list-style-type: none"> 4a) Check electrode to pilot for short. 4b) Check air flow. 4c) Check the power board. During preflow, there should be no voltage between work and electrode and at end of preflow open circuit voltage should be present. Replace if bad. 5. Replace control PC board.
Alternating "AIR/FAULT" LED lights.	<ol style="list-style-type: none"> 1. Replace control PC board.
The "OUTPUT ON" and "FAULT" LED's blink in alternating order.	<ol style="list-style-type: none"> 1. The pilot arc duty cycle has been exceeded. The machine will cool down and the lights will quit blinking in about 20 seconds. The pilot arc is limited to 20 out of 80 seconds except in special circumstances such as cutting expanded metal. (See the section on expanded metal in the Operating Section.)
Airflow will not shut off.	<ol style="list-style-type: none"> 1. Check harness 1J7 (C2) and 3J7 (H6).

SYMPTOM	CHECK
The "SAFETY" LED is lit.	<ol style="list-style-type: none"> 1. The machine will not operate. The machine senses that the nozzle is not in place, or the operator could be exposed to dangerous volt ages if the machine were allowed to operate. 2. Check the nozzle to be sure it is tightly in place. 3. Check the torch consumables to see if they are melted together or are simply touching each other. Tighten, clean or replace. See "Suggestion for Extra Utility from the Pro-Cut System". 4. Check the torch cable to see if it is cut or punctured. Replace. 5. Check to see that the torch is hooked to the machine properly. 6. Push the "SAFETY RESET" button, the LED should go out. If the LED does not go out, the thermal sensor in the torch head has actuated. Note that the thermal sensor exists in the hand held torches but not the machine or robotic torches. This sensor prevents the torch from melting, and should not trip in normal operation. Wait several minutes until the torch head is cool, and press the reset button. If the LED does not go out, check step 2 again before proceeding. Read the procedures section of this manual for instruction in proper cutting technique. 7. This circuit rarely trips on power up or because of noise. If the circuit can be reset, it is Ok to continue operation. 8. Check the continuity between pins 1 & 3 in the plastic amp connector on the torch assembly. This is the 4-pin connector that plugs into the power source. If the safety circuit is working properly, there will be continuity when the nozzle is in place and no continuity when the nozzle is removed. When the nozzle is in place, there must be continuity between pins 1 & 3 and the torch pilot lead. Replace the torch if the continuity measurements are not as described, or else replace the control board.
No OCV when 2 and 4 are closed.	<ol style="list-style-type: none"> 1. 190 VAC across H1 and H2. 2. 250V SCR PC board positive/negative 3. Check across 31/32 for 110 VAC. 4. Replace Control PC board.

PRO-CUT 60 STATUS LIGHTS OPERATING MODES

STATUS LIGHTS	CONDITION	SUGGESTIONS
MACHINE ON	Should always be on when machine is on.	Normal
OUTPUT ON	<p>On when there is voltage potential at the torch (cutting or pilot).</p> <p>OUTPUT ON is blinking alternately with AIR PRESSURE when power is first applied to machine.</p> <p>If OUTPUT ON is blinking alternately with FAULT, the pilot arc duty cycle is exceeded.</p>	<p>Normal</p> <p>There is a problem with the microprocessor, replace the Control PC board.</p> <p>Wait for machine lights to stop blinking.</p>
AIR PRESSURE	On whenever the air pressure is above 60 psi (413 kPa), there is an error condition mentioned above where air will turn on. The air will turn on for a brief time when power is first applied to machine.	Normal conditions are purge, preflow, postflow and cutting.
THERMAL	Should normally be off.	If on, wait for machine to cool down.
FAULT	<p>Light on. At end of preflow, machine checks to see if the torch is shorted and if it can fire the transistors.</p> <p>Light blinking. If cutting tried with air pressure less than 60 psi (413 kPa) while air is flowing, the machine will wait for air pressure to become greater than 60 psi (413 kPa).</p> <p>Light blinking alternately with OUTPUT ON.</p> <p>Light started blinking during cutting or gouging. There is an overcurrent condition caused by a surge of current the machine was not designed to handle. Release the trigger and resume cutting or gouging.</p> <p>Light blinking with THERMAL light on.</p>	<p>Check consumables, replace as needed. Check torch cable to see if it is punctured or cut.</p> <p>No air connected to machine, air pressure set too low, or air leak in system.</p> <p>Pilot arc duty cycle has been exceeded. Wait for machine lights to stop blinking.</p> <p>If cutting or gouging with standoff more than 1/8" (3.2mm) at high range of machine and nozzle is accidentally touched to work, shorten stickout, or use Drag Cup. Check consumables to see if electrode melted to nozzle.</p> <p>Wait for machine to cool.</p>

STATUS LIGHTS	CONDITION	SUGGESTIONS
SAFETY	<p>It is possible that this light could turn on when power is first applied to machine.</p> <p>The nozzle is not in place.</p> <p>While cutting or gouging if the voltage between the nozzle and the work is too high, it will put the machine into SAFETY.</p> <p>If the cable is punctured or cut, it can trip the SAFETY</p> <p>The torch may be overheated. There is a thermal sensor in the hand-held torch heads to protect it during abusive use. It will not trip in normal use - even if it is abused heavily.</p>	<p>If machine can be reset, it is OK to continue operation.</p> <p>Securely fasten nozzle in place.</p> <p>By pressing reset, the machine will be functional. This occurs most often when the consumables are wearing out. By removing the hafnium that builds up on the inside of the nozzle, it is possible to extend the life of the consumables.</p> <p>By pressing reset, it will clear the SAFETY. When cutting is tried again, the machine will either go into FAULT or SAFETY; until that time, the machine will not indicate a malfunction condition.</p> <p>Wait for the torch to cool down, and reset the safety circuit. Read the procedures section of this manual for instruction in proper cutting technique.</p>

PROCEDURE FOR REPLACING PC BOARDS

WARNING



**ELECTRIC SHOCK CAN KILL.
BEFORE PERFORMING ANY MAINTENANCE THAT REQUIRES OPENING THE CASE OF THE POWER SOURCE:**

- Disconnect input power to this machine at the Disconnect switch.
 - Do not touch electrically live parts or internal wiring.
 - Only qualified personnel should service this machine.
-

Before replacing a PC board which is suspected of being defective, visually inspect the PC board in question for any damage to any of its components and conductors on the back of the board.

If there is **no** visible damage to the PC board, install a new one and see if this remedies the problem. If the problem is remedied, reinstall the **old** PC board to see if the problem still exists. If it **does** no longer exist with the old PC board:

1. Check the PC board harness conductor pins for corrosion, contamination or looseness.
2. Check leads in the plug harness for loose or intermittent connection.


If PC board is visibly damaged **electrically** (components burned, copper traces opened or damaged), before possibly subjecting the new PC board to the same cause of failure, check for possible shorts, opens or grounds caused by:

1. Frayed or pinched lead insulation.
2. Poor lead termination, such as a poor contact or a short to adjacent connection or surface.
3. Two or more leads shorted together.
4. Foreign matter or interference behind the PC boards.

If PC board is visibly damaged **mechanically** (such as a part vibrated off or was crushed), inspect for cause, then remedy before installing a replacement PC board.

If there is damage to the PC board if replacing PC board corrects problem, return it to the local Lincoln Electric Field Service Shop.

WIRING DIAGRAM - PRO-CUT 60 (SINGLE PHASE)



GENERAL INFORMATION
 ELECTRICAL SYMBOLS PER E1537
 RESISTORS = OHM/WATT (1/2 WATT UNLESS OTHERWISE SPECIFIED)
 CAPACITORS = MFD/VOLTS

NOTES
 N.A. NUMBER 3 IS CONNECTED TO THE NOZZLE (PILOT LEAD AT THE TORCH).
 N.B. 6, 7, & 8 APPEAR ON TRIPLE VOLTAGE & 208V SINGLE MACHINES ONLY

AUXILIARY COILS	N.A. NUMBER 3 IS CONNECTED TO THE NOZZLE (PILOT LEAD AT THE TORCH).
H3-H4	12 VAC
H6-C2	24 VAC
31-32	115 VAC
CL-32	24 VAC

L10294

NOTE: This diagram is for reference only. It may not be accurate for all machines covered by this manual. The specific diagram for a particular code is pasted inside the machine on one of the enclosure panels. If the diagram is illegible, write to the Service Department for a replacement. Give the equipment code number..




FIGURE 1- Dual Voltage





FIGURE 1- Triple Voltage

CUTTING TORCH CONNECTION DIAGRAM
FOR MAGNUM™ PCT 60
PLASMA TORCH



- Do not operate with covers removed
- Disconnect input power before servicing
- Do not touch electrically live parts
- Only qualified persons should install, use or service this equipment



PRO-CUT 60 POWER SOURCE

1. DISCONNECT INPUT POWER TO THE PRO-CUT AND TURN MACHINE POWER SWITCH OFF.
2. INSERT TORCH CABLE THROUGH CABLE BOOT. TURN AND LOCK STRAIN RELIEF CLAMP ONTO BOLT.
3. CONNECT PILOT LEAD.
4. PLACE GAS LINE FITTING ON ADAPTER AND SCREW TIGHT.
5. ATTACH AMPHENOL CONNECTOR.

THE LINCOLN ELECTRIC CO. CLEVELAND, OHIO U.S.A.

7-26-91C

S19941

FIGURE 2

NOTES



Now Available ...The following Service Manuals

These are comprehensive single sources of information relative to Installation, Operation, Maintenance, Accessories, Theory of Operation, Replacement Parts, Electrical Diagrams and Extensive Troubleshooting.

**ORDER FROM: Technical Service Group-Customer Service Dept.
Lincoln Electric Company
22801 St. Clair Ave.
Cleveland, Ohio 44117-1199**

All orders must be pre-paid (US Funds Only): Please allow up to 4 weeks for delivery.

Make checks or Money Orders payable to the Lincoln Electric Company

Qty.	Titles	Machine Codes	Manual #	Unit Price	Total Price
	Square Wave Tig 255	(Codes 10022-10134)	SVM100-A	\$45.00	
	V300I	(Codes 9826-10133)	SVM101-A	\$45.00	
	SP100	(Codes 9284-10050)	SVM102-A	\$45.00	
	Power Arc 4000	(Codes 10083)	SVM103-A	\$45.00	
	Power Arc 4000	(Codes 10200-10244)	SVM103-B	\$45.00	
	ProCut 60 Single Phase	(Codes 9819-10118)	SVM104-A	\$45.00	
	V300 PRO	(Codes 9934-10131)	SVM105-A	\$45.00	
	LN 7 GMA	(Codes 9168-9931)	SVM106-A	\$45.00	
	RANGER 8	(Codes 9972-10110)	SVM107-A	\$45.00	
	DC600	(Codes 9773-9910)	SVM108-A	\$45.00	
	POWER WAVE 350/500	(Codes 10104-10155)	SVM109-A	\$65.00	
	RANGER 9	(Codes 9975-9976)	SVM110-A	\$45.00	
	SP250	(Codes 9402-10002)	SVM111-A	\$45.00	
	POWER WAVE 450	(Codes 10105-10195)	SVM112-A	\$65.00	
	WELDAN POWER 125	(Codes 10158-10160)	SVM113-A	\$45.00	
	LN25	(Codes 9218-10150)	SVM114-A	\$45.00	
	SP255	(Codes 10164-10165)	SVM115-A	\$45.00	
	Idealarc CV-300	(Codes 9456-10181)	SVM116-A	\$45.00	
	Wire-matic 250	(Codes 9799-10004)	SVM117-A	\$45.00	
	Square Wave TIG 355	(Codes 9951-9955)	SVM118-A	\$45.00	
	Wire-matic 255	(Codes 10166,10167)	SVM119-A	\$45.00	
	Ranger 10-LX	(Codes 9975, 9976)	SVM120-A	\$45.00	
				TOTAL	

SHIP MANUALS TO:

Name: _____

Address: _____

Phone: _____

			
WARNING	<ul style="list-style-type: none"> Do not touch electrically live parts or electrode with skin or wet clothing. Insulate yourself from work and ground. 	<ul style="list-style-type: none"> Keep flammable materials away. 	<ul style="list-style-type: none"> Wear eye, ear and body protection.
Spanish AVISO DE PRECAUCION	<ul style="list-style-type: none"> No toque las partes o los electrodos bajo carga con la piel o ropa mojada. Aislese del trabajo y de la tierra. 	<ul style="list-style-type: none"> Mantenga el material combustible fuera del área de trabajo. 	<ul style="list-style-type: none"> Protéjase los ojos, los oídos y el cuerpo.
French ATTENTION	<ul style="list-style-type: none"> Ne laissez ni la peau ni des vêtements mouillés entrer en contact avec des pièces sous tension. Isolez-vous du travail et de la terre. 	<ul style="list-style-type: none"> Gardez à l'écart de tout matériel inflammable. 	<ul style="list-style-type: none"> Protégez vos yeux, vos oreilles et votre corps.
German WARNUNG	<ul style="list-style-type: none"> Berühren Sie keine stromführenden Teile oder Elektroden mit Ihrem Körper oder feuchter Kleidung! Isolieren Sie sich von den Elektroden und dem Erdboden! 	<ul style="list-style-type: none"> Entfernen Sie brennbares Material! 	<ul style="list-style-type: none"> Tragen Sie Augen-, Ohren- und Körperschutz!
Portuguese ATENÇÃO	<ul style="list-style-type: none"> Não toque partes elétricas e electrodos com a pele ou roupa molhada. Isole-se da peça e terra. 	<ul style="list-style-type: none"> Mantenha inflamáveis bem guardados. 	<ul style="list-style-type: none"> Use proteção para a vista, ouvido e corpo.
Japanese 注意事項	<ul style="list-style-type: none"> 通電中の電気部品、又は溶材にヒフやぬれた布で触れないこと。 施工物やアースから身体が絶縁されている様にして下さい。 	<ul style="list-style-type: none"> 燃えやすいものの側での溶接作業は絶対にしてはなりません。 	<ul style="list-style-type: none"> 目、耳及び身体に保護具をして下さい。
Chinese 警告	<ul style="list-style-type: none"> 皮肤或湿衣物切勿接触带电部件及焊条。 使你自已与地面和工作件绝缘。 	<ul style="list-style-type: none"> 把一切易燃物品移离工作场所。 	<ul style="list-style-type: none"> 佩戴眼、耳及身体劳动保护用具。
Korean 위험	<ul style="list-style-type: none"> 전도체나 용접봉을 젖은 형갑 또는 피부로 절대 접촉치 마십시오. 모재와 접지를 접촉치 마십시오. 	<ul style="list-style-type: none"> 인화성 물질을 접근시키지 마십시오. 	<ul style="list-style-type: none"> 눈, 귀와 몸에 보호장구를 착용하십시오.
Arabic تحذير	<ul style="list-style-type: none"> لا تلمس الاجزاء التي يسري فيها التيار الكهربائي أو الألكترود بجسدك أو بالملابس المبللة بالماء. ضع عازلا على جسمك خلال العمل. 	<ul style="list-style-type: none"> ضع المواد القابلة للاشتعال في مكان بعيد. 	<ul style="list-style-type: none"> ضع أدوات وملابس واقية على عينيك وأذنيك وجسمك.

READ AND UNDERSTAND THE MANUFACTURER'S INSTRUCTION FOR THIS EQUIPMENT AND THE CONSUMABLES TO BE USED AND FOLLOW YOUR EMPLOYER'S SAFETY PRACTICES.

SE RECOMIENDA LEER Y ENTENDER LAS INSTRUCCIONES DEL FABRICANTE PARA EL USO DE ESTE EQUIPO Y LOS CONSUMIBLES QUE VA A UTILIZAR, SIGA LAS MEDIDAS DE SEGURIDAD DE SU SUPERVISOR.

LISEZ ET COMPRENEZ LES INSTRUCTIONS DU FABRICANT EN CE QUI REGARDE CET EQUIPMENT ET LES PRODUITS A ETRE EMPLOYES ET SUIVEZ LES PROCEDURES DE SECURITE DE VOTRE EMPLOYEUR.

LESEN SIE UND BEFOLGEN SIE DIE BETRIEBSANLEITUNG DER ANLAGE UND DEN ELEKTRODENEINSATZ DES HERSTELLERS. DIE UNFALLVERHÜTUNGSVORSCHRIFTEN DES ARBEITGEBERS SIND EBENFALLS ZU BEACHTEN.

			
<ul style="list-style-type: none"> ● Keep your head out of fumes. ● Use ventilation or exhaust to remove fumes from breathing zone. 	<ul style="list-style-type: none"> ● Turn power off before servicing. 	<ul style="list-style-type: none"> ● Do not operate with panel open or guards off. 	WARNING
<ul style="list-style-type: none"> ● Los humos fuera de la zona de respiración. ● Mantenga la cabeza fuera de los humos. Utilice ventilación o aspiración para gases. 	<ul style="list-style-type: none"> ● Desconectar el cable de alimentación de poder de la máquina antes de iniciar cualquier servicio. 	<ul style="list-style-type: none"> ● No operar con panel abierto o guardas quitadas. 	Spanish AVISO DE PRECAUCION
<ul style="list-style-type: none"> ● Gardez la tête à l'écart des fumées. ● Utilisez un ventilateur ou un aspirateur pour ôter les fumées des zones de travail. 	<ul style="list-style-type: none"> ● Débranchez le courant avant l'entretien. 	<ul style="list-style-type: none"> ● N'opérez pas avec les panneaux ouverts ou avec les dispositifs de protection enlevés. 	French ATTENTION
<ul style="list-style-type: none"> ● Vermeiden Sie das Einatmen von Schweißrauch! ● Sorgen Sie für gute Be- und Entlüftung des Arbeitsplatzes! 	<ul style="list-style-type: none"> ● Strom vor Wartungsarbeiten abschalten! (Netzstrom völlig offen; Maschine anhalten!) 	<ul style="list-style-type: none"> ● Anlage nie ohne Schutzgehäuse oder Innenschutzkleidung in Betrieb setzen! 	German WARNUNG
<ul style="list-style-type: none"> ● Mantenha seu rosto da fumaça. ● Use ventilação e exaustão para remover fumo da zona respiratória. 	<ul style="list-style-type: none"> ● Não opere com as tampas removidas. ● Desligue a corrente antes de fazer serviço. ● Não toque as partes elétricas nuas. 	<ul style="list-style-type: none"> ● Mantenha-se afastado das partes móveis. ● Não opere com os painéis abertos ou guardas removidas. 	Portuguese ATENÇÃO
<ul style="list-style-type: none"> ● ヒュームから頭を離すようにして下さい。 ● 換気や排煙に十分留意して下さい。 	<ul style="list-style-type: none"> ● インデント・サービスに取りかかる際には、まず電源スイッチを必ず切ってください。 	<ul style="list-style-type: none"> ● パネルやカバーを取り外したままで機械操作をしないで下さい。 	Japanese 注意事項
<ul style="list-style-type: none"> ● 頭部遠離煙霧。 ● 在呼吸區使用通風或排風設備除煙。 	<ul style="list-style-type: none"> ● 維修前切斷電源。 	<ul style="list-style-type: none"> ● 儀表板打開或沒有安全罩時不準作業。 	Chinese 警告
<ul style="list-style-type: none"> ● 얼굴로부터 용접가스를 멀리하십시오. ● 호흡지역으로부터 용접가스를 제거하기 위해 가스제거기나 통풍기를 사용하십시오. 	<ul style="list-style-type: none"> ● 보수전에 전원을 차단하십시오. 	<ul style="list-style-type: none"> ● 판넬이 열린 상태로 작동치 마십시오. 	Korean 위험
<ul style="list-style-type: none"> ● ابعد رأسك بعيداً عن الدخان. ● استعمل التهوية أو جهاز ضغط الدخان للخارج لكي تبعد الدخان عن المنطقة التي تتنفس فيها. 	<ul style="list-style-type: none"> ● أقطع التيار الكهربائي قبل القيام بأية صيانة. 	<ul style="list-style-type: none"> ● لا تشغيل هذا الجهاز اذا كانت الاغطية الحديدية الواقية ليست عليه. 	Arabic تحذير

LEIA E COMPREENDA AS INSTRUÇÕES DO FABRICANTE PARA ESTE EQUIPAMENTO E AS PARTES DE USO, E SIGA AS PRÁTICAS DE SEGURANÇA DO EMPREGADOR.

使う機械や溶材のメーカーの指示書をよく読み、まず理解して下さい。そして貴社の安全規定に従って下さい。

請詳細閱讀並理解製造廠提供的說明以及應該使用的銀焊材料，並請遵守貴方的有關於勞動保護規定。

이 제품에 동봉된 작업지침서를 숙지하시고 귀사의 작업자 안전수칙을 준수하시기 바랍니다.

اقرأ بتمعن وافهم تعليمات المصنع المنتج لهذه المعدات والمواد قبل استعمالها واتبع تعليمات الوقاية لصاحب العمل.