

OPERATION AND PARTS MANUAL



MODEL MQ-D206H DIAPHRAGM PUMP

© COPYRIGHT 2003, MULTIQUIP INC.

Revision #0 (12/15/03)



MULTIQUIP INC.

18910 WILMINGTON AVE.
CARSON, CALIFORNIA 90746
310-537-3700
800-421-1244
FAX: 310-537-3927

PARTS DEPARTMENT:

800-427-1244
FAX: 800-672-7877

SERVICE DEPARTMENT/TECHNICAL ASSISTANCE:


800-478-1244
FAX: 310-631-5032

E-mail: mq@multiquip.com • www.multiquip.com

Atlanta • Boise • Dallas • Houston • Newark
Montreal, Canada • Manchester, UK
Rio De Janeiro, Brazil • Guadalajara, Mexico



WARNING



CALIFORNIA — Proposition 65 Warning

Engine exhaust and some of its constituents are known to the State of California to cause cancer, birth defects and other reproductive harm.

HERE'S HOW TO GET HELP

PLEASE HAVE THE MODEL AND SERIAL
NUMBER *ON-HAND* WHEN CALLING

MULTIQUIP'S MAIN PHONE NUMBERS

800-421-1244 FAX: 310-537-3927
310-537-3700

PARTS DEPARTMENT

800-427-1244 FAX: 800-672-7877
310-537-3700 FAX: 310-637-3284

MAYCO PARTS

800-306-2926 FAX: 800-672-7877
310-537-3700 FAX: 310-637-3284

SERVICE DEPARTMENT

800-478-1244 FAX: 310-537-4259
310-537-3700

MQ POWER SERVICE DEPARTMENT

800-835-2551 FAX: 310-638-8046
310-537-3700

TECHNICAL ASSISTANCE

800-478-1244 FAX: 310-631-5032

WARRANTY DEPARTMENT


800-421-1244, EXT. 279 FAX: 310-537-1173
310-537-3700, EXT. 279

MQ-D206H Gasoline Powered Diaphragm Pump

| | |
|---|-------|
| Here's How To Get Help | 2 |
| Table of Contents | 3 |
| Parts Ordering Procedures | 4-5 |
| Specifications (Pump/Engine) | 6 |
| Pump Dimensions | 7 |
| Safety Message Alert Symbols | 8-9 |
| Rules For Safe Operation | 10-11 |
| General Information | 12 |
| Pump Components | 13 |
| Basic Engine | 14 |
| Pre-Inspection (Engine) | 15 |
| Pre-Set-up (Pump) | 16-17 |
| Initial Start-up (Engine) | 18-19 |
| Maintenance (Pump) | 20-22 |
| Maintenance (Engine) | 23-24 |
| Preparation for Long-Term Storage | 25 |
| Troubleshooting (Pump) | 26 |
| Troubleshooting (Pump/Engine) | 27 |
| Explanation Of Code In Remarks Column | 28 |
| Suggested Spare Parts | 29 |

HONDA GX120K1QX2 Engine


| | |
|---|-------|
| Air Cleaner Assembly | 36-37 |
| Camshaft Assembly | 38-39 |
| Carburetor Assembly | 40-41 |
| Control Assembly | 42-42 |
| Crankcase Cover Assembly | 43-44 |
| Crankshaft Assembly | 45-46 |
| Cylinder Barrel Assembly | 47-48 |
| Cylinder Head Assembly | 50-51 |
| Fan Cover Assembly | 52-53 |
| Flywheel Assembly | 54-55 |
| Fuel Tank Assembly | 56-57 |
| Ignition Coil Assembly | 58-59 |
| Muffler Assembly | 60-61 |
| Piston Assembly | 62-63 |
| Recoil Starter Assembly | 64-65 |
| Gasket Kit Assembly | 66-67 |
| Terms and Condition Of Sale — Parts | 68 |



*As a continuing effort to update our parts book, contact the **MULTIQUIP** literature department for the latest revision of your "Operation and Parts Manual"*

Component Drawings

| | |
|--|-------|
| Water Box and Groove Assembly | 30-31 |
| MQ-D206H Pump Assembly | 32-33 |
| Axle, Handle, Engine Mtg. and Bumper Assy. ... | 34-35 |



Specification and part number are subject to change without notice.

PARTS ORDERING PROCEDURES

When ordering parts, please supply the following information:

- Dealer account number
- Dealer name and address
- Shipping address (if different than billing address)
- Return fax number
- Applicable model number
- Quantity, part number and description of each part
- Specify preferred method of shipment:
 - ✓ FedEx or UPS Ground
 - ✓ FedEx or UPS Second Day or Third Day
 - ✓ FedEx or UPS Next Day
 - ✓ Federal Express Priority One
 - ✓ DHL
 - ✓ Truck

Note: Unless otherwise indicated by customer, all orders are treated as "Standard Orders", and will ship within 24 hours. We will make every effort to ship "Air Shipments" the same day that the order is received, if prior to 2PM west coast time. "Stock Orders" must be so noted on fax or web forms.



Here's how to get help...

Please have the model and serial number on hand when calling.

Parts Department

800-427-1244 Fax: 800-672-7877
310-537-3700 Fax: 310-637-3284

Mayco Parts

800-306-2926 Fax: 800-672-7877
310-537-3700 Fax: 310-637-3284

Service Department

800-478-1244 Fax: 310-537-4259
310-537-3700

MQ Power Service Department

800-835-2551 Fax: 310-638-8046
310-537-3700

Technical Assistance

800-478-1244 Fax: 310-631-5032

Warranty Department

800-421-1244, Ext. 279 Fax: 310-537-1173
310-537-3700, Ext. 279

Multiquip's Main Phone Numbers

800-421-1244 Fax: 310-537-3927
310-537-3700



MULTIQUIP INC.
18910 WILMINGTON AVENUE
POST OFFICE BOX 6254
CARSON, CALIFORNIA 90749
310-537-3700 • 800-421-1244
FAX: 310-537-3927
E-MAIL: mq@multiquip.com
WWW: multiquip.com

Place Your Parts Order Via Web or Fax For Even More Savings!

Extra Discounts!

All parts orders which include complete part numbers and are received by our automated web parts order system, or by fax qualify for the following extra discounts:

| Ordered via | Standard orders | Stock orders (\$750 list and above) |
|-------------|-----------------|-------------------------------------|
| Fax | 3% | 10% |
| Web | 5% | 10% |

Special freight allowances when you order 10 or more line items via Web or Fax! **

FedEx Ground Service *at no charge for freight*
No other allowances on freight shipped by any other carrier.

NOTE: DISCOUNTS ARE SUBJECT TO CHANGE

Direct TOLL-FREE access to our Parts Department:

Toll-free nationwide — 800-427-1244

MQ-D206H— SPECIFICATIONS (PUMP/ENGINE)

Table 1. Specifications (Pump)

| | Type | MQ-206H Diaphragm Pump |
|-------------|--------------------------|--|
| Pump | Suction & Discharge Size | 2.00 in. (50.8 mm.) |
| | Maximum Pumping Capacity | 3,000 gallons/hour (11,340 liters/hour) |
| | Max. Solids Diameter | 1 in. (25.4 mm) |
| | Max Lift | 26 ft. (7.92 meters) |
| | Max. Head | 51 ft. (15.54 meters) |
| | Dry Net Weight | |

Table 2. Specifications (Engine)

| | Model | HONDA GX120K1QX2 |
|-----------------------|------------------------------|---|
| Engine | Type | Air-cooled 4 stroke, Single Cylinder, OHV, Horizontal Shaft Gasoline Engine |
| | Bore X Stroke | 2.4 in. x 1.7 in. (60 mm x 42 mm) |
| | Displacement | 119 cc (7.2 cu-in) |
| | Max Output | 4.0 H.P./3600 R.P.M. |
| | Fuel Tank Capacity | 0.66 US gal. (2.5 liters) |
| | Fuel | Unleaded Automobile Gasoline |
| | Lube Oil Capacity | 0.63 qts. (60 liters) |
| | Speed Control Method | Centrifugal Fly-weight Type |
| | Starting Method | Recoil Start |
| | Dimension (L x W x H) | 11.7 x 13.4 x 12.5 in. (297 x 341 x 318 mm) |
| Dry Net Weight | 28.7 lbs (13 Kg.) | |

MQ-D206H— DIMENSIONS (PUMP)




Figure 1. MQ-D206HPump Dimensions


Table 3. Dimensions

| MODEL | A LENGTH | B HEIGHT | C WIDTH | D DISCHARGE | E SUCTION |
|---------|--------------------------|--------------------------|--------------------------|-------------------------|-------------------------|
| MQ-206H | 39.87 in. (101.1 cm.) | 24.75 in. (62.86 cm.) | 24.75 in. (62.86 cm.) | 4.93 in. (12.52 cm.) | 4.25 in. (10.80 cm.) |

MQ-D206H — SAFETY MESSAGE ALERT SYMBOLS

FOR YOUR SAFETY AND THE SAFETY OF OTHERS!

Safety precautions should be followed at all times when operating this equipment. Failure to read and understand the Safety Messages and Operating Instructions could result in injury to yourself and others.



This Owner's Manual has been developed to provide complete instructions for the safe and efficient operation of the **MQ Model D-206H Diaphragm Pump**. Refer to the engine manufacturer's instructions for data relative to its safe operation.

Before using this pump, ensure that the operating individual has read and understands all instructions in this manual.

SAFETY MESSAGE ALERT SYMBOLS

The three (3) Safety Messages shown below will inform you about potential hazards that could injure you or others. The Safety Messages specifically address the level of exposure to the operator, and are preceded by one of three words: **DANGER**, **WARNING**, or **CAUTION**.



DANGER: You **WILL** be **KILLED** or **SERIOUSLY** injured if you do not follow directions.



WARNING: You **CAN** be **KILLED** or **SERIOUSLY** injured if you do not follow directions.



CAUTION: You **CAN** be injured if you do not follow directions.

Potential hazards associated with the MQ-D206H diaphragm pumps operation will be referenced with Hazard Symbols which appear throughout this manual, and will be referenced in conjunction with Safety Message Alert Symbols.

HAZARD SYMBOLS




Lethal Exhaust Gases



Engine exhaust gases contain poisonous carbon monoxide. This gas is colorless and odorless, and can cause death if inhaled. **NEVER** operate this equipment in a confined area or enclosed structure that does not provide ample free flow air.



Explosive Fuel



GASOLINE is extremely flammable, and its vapors can cause an explosion if ignited. **DO NOT** start the engine near spilled fuel or combustible fluids. **DO NOT** fill the fuel tank while the engine is running or hot. **DO NOT** overfill tank, since spilled fuel could ignite if it comes into contact with hot engine parts or sparks from the ignition system. Store fuel in approved containers, in well-ventilated areas and away from sparks and flames. **NEVER**



Burn Hazards



Engine components can generate extreme heat. To prevent burns, **DO NOT** touch these areas while the engine is running or immediately after operations. Never operate the engine with heat shields or heat guards removed.



Rotating Parts



NEVER operate equipment with covers, or guards removed. Keep fingers, hands, hair and clothing away from all moving parts to prevent injury.

MQ-D206H — SAFETY MESSAGE ALERT SYMBOLS



Accidental Starting



OFF

ALWAYS place the engine ON/OFF switch in the **OFF** position when the pump is not in use.




Respiratory Hazard



ALWAYS wear approved respiratory protection.



Sight and Hearing hazard



ALWAYS wear approved eye and hearing protection.

WARNING




To avoid injuries and damage to the equipment, **ALWAYS** read and understand contents of operation manual before operating equipment.



Equipment Damage Messages

Other important messages are provided throughout this manual to help prevent damage to your pump, other property, or the surrounding environment.



This pump, other property, or the surrounding environment could be damaged if you do not follow instructions.

| | |
|--|---|
| | WARNING |
| | To avoid injury, you MUST read and understand operator's manual before using this machine. |
| | This machine to be operated by qualified personnel only. Ask for training as needed. |

MQ-D206H— RULES FOR SAFE OPERATION

DANGER:



Failure to follow instructions in this manual may lead to serious injury or even death! This equipment is to be operated by trained and qualified personnel only! This equipment is for industrial use only.

The following safety guidelines should always be used when operating the **Diaphragm Pump**:

GENERAL SAFETY

- **DO NOT** operate or service this equipment before reading this entire manual.



- This equipment should not be operated by persons under 18 years of age.

- **NEVER** operate this equipment without proper protective clothing, shatterproof glasses, steel-toed boots and other protective devices required by the job.



- **NEVER** operate this equipment when not feeling well due to fatigue, illness or taking medicine.



- **NEVER** operate this equipment under the influence of drugs or alcohol.



- Whenever necessary, replace nameplate, operation and safety decals when they become difficult read.

- **ALWAYS** check the machine for loosened threads or bolts before starting.

- **ALWAYS** wear proper respiratory (mask) hearing and eye protection equipment when operating the pump.




- **NEVER** touch the hot exhaust manifold, muffler or cylinder. Allow these parts to



- **High Temperatures** – Allow the engine to cool before adding fuel or performing service and maintenance functions. Contact with *hot* components can cause serious burns.


- The engine of this pump requires an adequate free flow of cooling air. **NEVER!** operate the pump in any enclosed or narrow area where free flow of the air is restricted. If the air flow is restricted it will cause serious damage to the pump or engine and may cause injury to people and property. Remember the pump's engine gives off **DEADLY** gases.



- **ALWAYS** refuel in a well-ventilated area, away from sparks and open flames.

- **ALWAYS** use extreme caution when working with **flammable** liquids. When refueling, **stop the engine** and allow it to cool. **DO NOT** smoke around or near the machine. Fire or explosion could result from fuel vapors, or if fuel is spilled on a hot engine.

- **NEVER** operate the pump in an **explosive atmosphere** or near combustible materials. An explosion or fire could result causing severe **bodily harm or even death**.



- Topping-off to filler port is dangerous, as it tends to spill fuel.

- Refer to the **Engine Owner's Manual** for engine technical questions or information.

- **NEVER** use accessories or attachments, which are not recommended by Multiquip for this equipment. Damage to the equipment and/or injury to user may result.

- Manufacturer does not assume responsibility for any accident due to equipment modifications.

MQ-D206H— RULES FOR SAFE OPERATION

- **NEVER** Run engine without air cleaner. Severe engine damage may occur.
- **ALWAYS** read, understand, and follow procedures in Operator's Manual before attempting to operate equipment.
- **ALWAYS** be sure the operator is familiar with proper safety precautions and operation techniques before using pump.
- **ALWAYS** store equipment properly when it is not being used. Equipment should be stored in a clean, dry location out of the reach of children.
- **NEVER** leave the pump unattended, turn off engine when unattended.
- Unauthorized equipment modifications will void all warranties.
- **NEVER** pump volatile, explosive, flammable or low flash point fluids. These fluids could ignite or explode.
- **NEVER** operate the pump in an **explosive** atmosphere.
- Before starting the pump, check that the clean-out cover is securely fasten.
- **ALWAYS** ensure pump is on level ground before use.
- Become familiar with the components of the pump before operating.
- **ALWAYS** replace any worn or damaged warning decals.
- **NEVER** pump corrosive chemicals or water containing toxic substances. These fluids could create serious health and environmental hazards. Contact local authorities for assistance.
- **NEVER** open the priming plug when pump is hot. Hot water inside could be pressurized much like the radiator of an automobile. Allow pump to cool to the touch before loosening plug.
- **NEVER** open the pump housing during operation or start the pump with the clean-out cover removed. The rotating impeller inside the pump can cut or sever objects caught in it.
- **NEVER** block or restrict flow from discharge hose. Remove kinks from discharge line before starting pump. Operation with a blocked discharge line can cause water inside pump to overheat.
- **ALWAYS** fill the pump casing with water before starting the engine. Failure to maintain water inside the pump housing will cause severe damage to the pump.
- In winter drain water from pump housing to prevent freezing.

■ **High Temperatures** – Always stop engine and allow the engine to cool before adding fuel, oil or performing service and maintenance functions. Contact with *hot* components can cause serious burns.

■ **NEVER** disconnect any "**emergency or safety devices**". These devices are intended for operator safety. Disconnection of these devices can cause severe injury, bodily harm or even death! Disconnection of any of these devices will void all warranties.

Maintenance Safety

- **NEVER** lubricate components or attempt service on a running machine.
- **ALWAYS** allow the machine a proper amount of time to cool before servicing.
- Keep the machinery in proper running condition.
- Fix damage to the machine immediately and always replace broken parts, or missing decals.
- Dispose of hazardous waste properly. Examples of potentially hazardous waste are used motor oil, fuel and fuel filters.
- **DO NOT** use food or plastic containers to dispose of hazardous waste.
- **DO NOT** pour waste, oil or fuel directly onto the ground, down a drain or into any water source.

Emergencies

■ **ALWAYS** know the location of the nearest **fire extinguisher**.



■ **ALWAYS** know the location of the nearest **first aid kit**.



■ In emergencies **always** know the location of the nearest phone or **keep a phone on the job site**. Also know the phone numbers of the nearest **ambulance, doctor** and **fire department**. This information will be invaluable in the case of an emergency.



MQ-D206H— GENERAL INFORMATION

APPLICATION

The **MQ Model D206H diaphragm** pump is designed to be used for de-watering applications. The suction and discharge ports on the **D206H** use a 2-inch diameter opening, which allows the pump to pump at rate of approximately 3,000 gallons/hour (gph) or 11,340 liters/hour (lph).

Diaphragm pumps use a positive displacement design rather than centrifugal force to move water through the casing. This means the pump will deliver a specific amount of flow per stroke, revolution or cycle. These pumps are commonly referred to as mud hogs, mud hens and mud suckers. Their names reflect their popularity for use in applications where shallow depths and slurry water render centrifugal pumps ineffective

Power Plant

These diaphragm pumps are powered by an 5.5 horsepower air cooled, 4-stroke, single cylinder **HONDA GX-120** gasoline engine that incorporates a low "**Oil Alert Feature**". The drive shaft of the engine is coupled to an offset connecting rod that is coupled to a flexible diaphragm. The connecting rod alternately raises (expands) and lowers (contracts) the diaphragm at a rate between 40 and 65 strokes per minute depending on engine speed.

Oil Alert Feature

In the event of **low oil** or **no oil**, the HONDA GX-120 engine has a built-in oil alarm engine shut-down feature. In the event the oil level is low the engine will automatically shut-down.

Suction Lift

This pump is intended to be used for dewatering applications and is capable of suction lifts up to 25 feet at sea level. For optimal suction lift performance keep the suction hose or line as short as possible. In general always place the pump as close to the water as possible.

Pump Support

The pump should always be placed on **solid stationary ground** in a level position.

NEVER place the pump on **soft soil**. The suction hose or pipe connection should always be checked for tightness and leaks. A small suction leak in the hose or fittings could prevent the pump from priming.

Elevation

Higher elevations will effect the performance of the pump. Due to less atmospheric pressure at higher altitudes, pumps **DO NOT** have the priming ability that they have at sea level. This is due to the "thinner air" or lack of oxygen at higher altitudes.

A general rule of thumb is that for every 1,000 feet of elevation above sea level a pump will lose one foot of priming ability.

For example, in Flagstaff, Arizona where the elevation is approximately 7,000 feet, the pump would have a suction lift of only 18 feet rather than the 25 feet at sea level. Table 3 shows suction lift at various elevations.

Table 3. Suction Lift at Various Elevations

| Altitude Feet (Meters) | Suction Lift in Feet (Meters) | | | |
|------------------------|-------------------------------|--------------|--------------|--------------|
| | 10.0 (3.048) | 15.0 (4.572) | 20.0 (6.096) | 25.0 (7.620) |
| Sea Level | 10.0 (3.048) | 15.0 (4.572) | 20.0 (6.096) | 25.0 (7.620) |
| 2,000 (610) | 8.80 (2.680) | 13.2 (4.023) | 17.6 (5.364) | 22.0 (6.705) |
| 4,000 (1,219) | 7.80 (2.377) | 11.7 (3.566) | 15.6 (4.754) | 19.5 (5.943) |
| 6,000 (1,829) | 6.90 (2.103) | 10.4 (3.169) | 13.8 (4.206) | 17.3 (5.273) |
| 8,000 (2,438) | 6.20 (1.889) | 9.30 (2.834) | 12.4 (3.779) | 15.5 (4.724) |
| 10,000 (3,048) | 5.70 (1.737) | 8.60 (2.621) | 11.4 (3.474) | 14.3 (4.358) |


Table 4 shows percentage drops in performance as elevation increases.

Table 4. Performance Loss at Various Elevations

| Altitude Feet (Meters) | Performance Loss | |
|------------------------|------------------|----------------|
| | Discharge Flow | Discharge Head |
| Sea Level | 100% | 100% |
| 2,000 (610) | 97% | 95% |
| 4,000 (1,219) | 95% | 91% |
| 6,000 (1,829) | 93% | 87% |
| 8,000 (2,438) | 91% | 83% |
| 10,000 (3,048) | 88% | 78% |

MQ-D206H— PUMP COMPONENTS

Figure 2 shows a typical application using the MQ-D206H diaphragm pump. Please note that this pump is intended for the removal of clean water and water containing some debris and solids. Maximum size of solids should not exceed 1 inch (25 mm) in diameter. **DO NOT** set strainer on bottom of water bed. Placing the strainer above the water bed will prevent the pump from drawing in excessive amounts of sand and foreign debris.



Contact your nearest Multiquip dealer for quick disconnect hoses and fittings.




Figure 2. MQ-D206HPump Application

1. **Pump** – The **MQ-D206H** is a 2-inch diaphragm pump and is used in general de-watering applications. Typical dewatering applications consist of cleaning out cesspools and septic tanks, draining slow seepage from small excavations, trenches and construction sites, or pumping out industrial waste.
2. **Fill Cap** – Prior to operation, the pump casing should be filled with water. Remove this cap to add water to the pump. After the initial prime, a sufficient amount of water will be retained in the casing so that the operator will not need to re-prime later.
If the casing is dry or has insufficient water, the pump will have difficulty in priming which could lead to premature mechanical seal wear thus causing damage to the pump.
3. **Discharge Port** – Connect a 2-inch discharge hose to this port. Use two worm clamps to secure the hose.
4. **Worm Clamp** – Used to secure the hose to the inlet and outlet ports on the pump. Use two clamps to secure the hose on the inlet side of the pump.
5. **Discharge Hose** – Connect a flexible rubber hose to the discharge port on the pump. Make sure that the hose lays flat and is not kinked. Use only recommended type discharge hose. Contact Multiquip parts department for ordering information.
6. **Suction Port** – Connect a 2-inch inlet hose to this port. Use two worm clamps to secure the hose.
7. **Suction Hose** – Connect a flexible rubber hose to the suction port on the pump. Make sure that the hose lays flat and is not kinked. Use only recommended type suction hose. Contact Multiquip parts department for ordering information
8. **Strainer** – Always attach a strainer to bottom side of the suction hose to prevent large objects and debris from entering the pump. Strainer should be positioned so that it will remain completely under water. Running the pump with the strainer above water for long periods can damage pump.
9. **Transmission Oil Fill Plug** – Remove this plug to add SAE 80/90 EP gear oil to the transmission. Transmission oil capacity is 1-1/4 pints (550 ml.).
10. **Connecting Rod Grease Access Hole** – Grease connecting rod bearing through this access hole. Grease connecting rod bearing every 25 hours of operation.




Figure 3. Engine Controls and Components

INITIAL SERVICING

The engine (Figure 3) must be checked for proper lubrication and filled with fuel prior to operation. Refer to the manufacturer's engine manual for instructions & details of operation and servicing. The engine shown above is a **HONDA** engine, operation for other types of engines may vary somewhat.

1. **Fuel Filler Cap** – Remove this cap to add unleaded gasoline to the fuel tank. Make sure cap is tightened securely. **DO NOT** over fill.





! DANGER

Adding fuel to the tank should be done only when the engine is stopped and has had an opportunity to cool down. In the event of a fuel spill, **DO NOT** attempt to start the engine until the fuel residue has been completely wiped up, and the area surrounding the engine is dry.

2. **Throttle Lever** – Used to adjust engine RPM speed (lever advanced forward **SLOW**, lever back toward operator **FAST**).
3. **Engine ON/OFF Switch** – ON position permits engine starting, OFF position stops engine operations.
4. **Recoil Starter (pull rope)** – Manual-starting method. Pull the starter grip until resistance is felt, then pull briskly and smoothly.
5. **Fuel Valve Lever** – **OPEN** to let fuel flow, **CLOSE** to stop the flow of fuel.

6. **Choke Lever** – Used in the starting of a cold engine, or in cold weather conditions. The choke enriches the fuel mixture.
7. **Air Cleaner** – Prevents dirt and other debris from entering the fuel system. Remove wing-nut on top of air filter canister to gain access to filter element.



Operating the engine without an air filter, with a damaged air filter, or a filter in need of replacement will allow dirt to enter the engine, causing rapid engine wear.

8. **Spark Plug** – Provides spark to the ignition system. Set spark plug gap to 0.6 - 0.7 mm (0.028 - 0.031 inch) Clean spark plug once a week.
9. **Muffler** – Used to reduce noise and emissions.



! WARNING

Engine components can generate extreme heat. To prevent burns, **DO NOT** touch these areas while the engine is running or immediately after operating. **NEVER** operate the engine with the muffler removed.

10. **Fuel Tank** – Holds unleaded gasoline. For additional information refer to engine owner's manual.

MQ-D206H— PRE-INSPECTION (ENGINE)


CAUTION



NEVER operate the pump in a confined area or enclosed area structure that does not provide ample *free flow of air*.



ALWAYS wear approved eye and hearing protection before operating the pump.



Before Starting

1. Read safety instructions at the beginning of manual.
2. Clean the pump, removing dirt and dust, particularly the engine cooling air inlet, carburetor and air cleaner.
3. Check the air filter for dirt and dust. If air filter is dirty, replace air filter with a new one as required.
4. Check carburetor for external dirt and dust. Clean with dry compressed air.
5. Check fastening nuts and bolts for tightness.



Engine Oil Check

1. To check the engine oil level, place the pump on secure level ground with the engine stopped.
2. Remove the filler dipstick from the engine oil filler hole (Figure 4) and wipe clean.




Figure 4. Engine Oil Dipstick (Removal)

3. Insert and remove the dipstick without screwing it into the filler neck. Check the oil level shown on the dipstick.
4. If the oil level is low (Figure 5), fill to the edge of the oil filler hole with the recommended oil type (Table 5). Maximum oil capacity is .63 quarts (.60 liters)




Figure 5. Engine Oil Dipstick (Oil Level)

Table 5. Oil Type

| Season | Temperature | Oil Type |
|-------------|----------------|---------------|
| Summer | 25°C or Higher | SAE 10W-30 |
| Spring/Fall | 25°C~10°C | SAE 10W-30/20 |
| Winter | 0°C or Lower | SAE 10W-10 |

Explosive Fuel

DANGER



Motor fuels are highly flammable and can be dangerous if mishandled. **DO NOT** smoke while refueling. **DO NOT** attempt to refuel the pump if the engine is *hot!* or *running*.




Fuel Check

1. Remove the gasoline cap located on top of fuel tank.
2. Visually inspect to see if the fuel level is low. If fuel is low, replenish with unleaded fuel.
3. When refueling, be sure to use a strainer for filtration. **DO NOT** top-off fuel. Wipe up any spilled fuel *immediately!*

Before Starting

1. Read safety instructions at the beginning of manual.
2. Place pump as near to water as possible, on a firm flat, level surface.
3. To prime pump, remove fill cap (Figure 2) and fill pump casing with water. If the pump casing is not filled with water before starting, it will not begin pumping.



Suction and discharge hoses are available from Multiquip. Contact your nearest dealer for more information.

5. The discharge hose is usually a **collapsible** (thin-walled) hose, however if a thin-walled discharge hose is not available, a rigid suction hose can be substituted in its place.
6. Make sure the **suction strainer** (Figure 2) is clean and securely attached to the water end of the suction hose. The strainer is designed to protect the pump by preventing large objects from being pulled into the pump.

CAUTION :



Pump casing **must** be filled with water before using pump. Otherwise pump will not be able to begin pumping.

WARNING :



DO NOT open **fill cap** if pump is **hot!** Water inside may be under pressure.

4. Check for **leaks** between pump and engine. If water is leaking between the pump and engine housing, the seal inside the pump may be worn or damaged. Continued operation of the pump is not recommended. Further usage of the pump under these conditions may cause severe water damage to engine.

Hoses and Clamps

1. Check that all hoses are **securely** attached to the pump. Make certain suction hose (Figure 2) does not have any air leakage. Tighten hose clamps and couplings as required.
2. It is recommended that 2 clamps be used when securing the suction hose to the inlet side (suction) of the pump.
3. Remember suction hoses must be **rigid** enough not to collapse when the pump is in operation.
4. Check that the **discharge** hose (Figure 2) is not restricted. Place hose so that it lays as straight as it is possible on the ground. Remove any twists or sharp bends from hose which may block the flow of water.

CAUTION :



The strainer should be positioned so it will remain completely **under water**. Running the pump with the strainer above water for long periods can damage the pump.

CAUTION :



DO NOT pump flammable fluids, corrosive chemicals or fluids containing toxic substances. These fluids can create potentially dangerous health and environmental hazards. Contact local authorities for assistance.

CAUTION :



This pump uses a water-cooled **mechanical seal** to prevent water from seeping into the engine. The passage of water through the pump casing lubricates the seal and prevents it from overheating. **NEVER!** operate the pump without water in the casing as this will cause damage to the mechanical seal.

Gear Reduction Oil (Transmission)

1. Remove the **transmission oil level plug** (Figure 6). If oil begins to seep out as the plug is being removed, then it can be assumed that the transmission oil is at the proper operating level.
2. If oil does not seep out as the oil level plug is being removed, then remove the **transmission oil fill plug** and fill with **SAE 80/90 EP gear oil** to the proper operating level. Transmission oil capacity is capacity is 1-1/4 pints (590 ml.).





Figure 6. Transmission Oil Level



Diaphragm pumps will handle fluids containing considerable solids (not to exceed 1.00 inch/25 mm), however, if the mixture is too heavy to be pumped, water must be added until the mixture becomes sufficiently fluid for pumping.

Connecting Rod Bearing Lubrication

1. Grease **connecting rod bearing** thru the access hole (Figure 7) every 25 hours of operation.
2. Use only **premium lithium based grease**, conforming to NLG1 Grade #2 consistency.

APPLY 2 OR 3 SHOTS OF PREMIUM LITHIUM BASE GREASE EVERY 25 HOURS OF OPERATION





Figure 7. Connecting Rod Bearing Lubrication

Helpful Hints

The capacity of this diaphragm pump will vary greatly depending on the height of the suction lift and length of the discharge hose. A discharge hose which is too small, long or high will cause the following:

- Excessive bulging of diaphragm on the down stroke.
- Valves closing with a loud snap.
- Rough operation.
- Engine overloads and slow downs.
- Reduced efficiency

CAUTION :



DO NOT attempt to operate the pump until the Safety, General Information and Inspection sections of this manual have been **read and thoroughly understood**.

This section is intended to assist the operator with the **initial start-up** of the trash pump. It is extremely important that this section be read carefully before attempting to use the pump in the field.

Starting the Engine (HONDA engine)

1. Place the engine **fuel valve lever** (Figure 8) to the "ON" position.




Figure 8. Engine Fuel Valve Lever (ON Position)

2. Move the **throttle lever** (Figure 9) away from the slow position, about 1/3 of the way toward the fast position.




Figure 9. Throttle Lever (1/3 Start Position)

3. Place the **choke lever** (Figure 10) in the "OPEN" position if starting a **cold** engine.




Figure 10. Engine Choke Lever (Open)

4. Place the **choke lever** (Figure 9) in the "CLOSED" position if starting a **warm engine** or the **temperature is warm**.




Figure 11. Engine Choke Lever (Closed)

5. Place the **engine ON/OFF switch** (Figure 12) in the "ON" position.




Figure 12. Engine ON/OFF Switch (ON Position)

6. Grasp the starter grip (Figure 13) and slowly pull it out. The resistance becomes the hardest at a certain position, corresponding to the compression point. Pull the starter grip briskly and smoothly for starting.




Figure 13. Starter Grip

- If the engine has started, slowly return the choke lever (Figure 14) to the “CLOSED” position. If the engine has not started repeat steps 1 through 6.




Figure 14. Choke Lever (Closed)

- Before the pump is placed into operation, run the engine for several minutes. Check for fuel leaks, and noises that would associate with a loose component.
- To begin pumping, place the throttle lever (Figure 15) in the "RUN" position.





Figure 15. Throttle Lever (Run)



Pump speed can be **regulated** with the engine throttle control from full volume, 65 strokes per minute, to about 40 strokes per minute for lesser volume seepage. Smoothest operation can be determined by trying to pump at several speeds. Limit maximum speed to 65 strokes per minute of the diaphragm (2,800 RPM engine speed).

Stopping The Engine

Normal Shutdown

- Move the throttle lever to the **IDLE** position (Figure 16) and run the engine for three minutes at low speed.




Figure 16. Throttle Lever (Idle)

- After the engine **cools**, turn the engine ON/OFF switch to the “OFF” position (Figure 17).




Figure 17. Engine ON/OFF Switch (OFF)

- Place the **fuel shut-off lever** (Figure 18) in the “OFF” position.




Figure 18. Fuel Valve Lever (OFF)

Emergency Showdown

- Move the throttle lever quickly to the “**IDLE**” position, and place the engine ON/OFF switch in the “**OFF**” position.

Pump Vacuum Test

CAUTION:



DO NOT attempt to start the engine unless the pump has previously been **primed** with water. Severe pump damage will occur if pump has not been primed.

To perform the pump vacuum test do the following:

1. Remove the pump fill cap (Figure 2), and fill the pump with water.
2. Start the engine as outlined in the initial start-up section, and wait for the pump to begin pumping.
3. As shown in Figure 19 (next page), place a water hose inside the discharge opening of the pump, and turn on the water. This flow of water into the discharge opening will **prevent** the pump from running dry.
4. Place the **Pump Vacuum Tester** (P/N 7000030) over the pump suction (inlet) opening (Figure 19) with the vacuum gauge facing upwards. It may be necessary to apply a small amount of water around the rubber seal of the vacuum tester to make a good suction fit.
5. Check and make sure that there are no air leaks between the vacuum tester and the inlet port on the pump. If air leaks are present reseal vacuum tester.
6. Run the pump for a few minutes while monitoring the vacuum gauge. If the gauge indicates a reading between -25 and -20 in. Hg. (inches of mercury) then it can be assumed that the pump is working correctly.



25 in. Hg (inches of mercury) translates into 25 feet of lift at **sea level**.

7. If the vacuum tester gauge indicates a reading **below** -20 in. Hg, it can then be assumed that the pump is not functioning correctly, and corrective action needs to be taken.
6. To test the **flapper valve**, shut down the engine. The vacuum tester should remain attached to the pump suction inlet port by vacuum. This indicates the pump's flapper valve is seating properly to hold water in the suction hose when the engine is stopped. This prevents backflow and allows for faster priming when the engine is restarted.

Pump Cleaning

After pumping water containing large amounts of dirt and debris, perform the following:

1. Remove the drain plug from the pump housing (Figure 2) and drain any water left in the pump.
3. Clean and remove dirt, debris from pump casing. Inspect impeller and volute for wear. Replace any damaged or worn parts.

Gear Reduction Oil (Transmission)

1. Change transmission oil after the first **40 hours** of operation. Use **SAE 80/90 EP gear oil**. Transmission oil capacity is 1-1/4 pints (590 ml.). Check oil level periodically and change oil after every **400 hours** of operation.

Connecting Rod Bearing Lubrication

1. Grease **connecting rod bearing** thru the access hole (Figure 7) every 25 hours of operation.
2. Use only **premium lithium based grease**, conforming to NLG1 Grade #2 consistency.

Connecting Rod Bearing Lubrication

1. Keep interior of pump and valves clean. Flush out pump with clear water after operation.
2. Remove connecting rod guard occasionally and wipe up excess grease from connecting rod bearing.

CAUTION

DO NOT RUN PUMP
WITHOUT WATER.




Figure 19. Pump Vacuum Tester

Engine Maintenance



Perform engine maintenance procedures as referenced by Table 6 below:

| Table 6. Engine Maintenance Schedule | | | | | | | |
|--------------------------------------|-------------------------|--|------------------------|---------------------------|---------------------------|------------------------|---------------------------|
| DESCRIPTION (3) | OPERATION | BEFORE | FIRST MONTH OR 10 HRS. | EVERY 3 MONTHS OR 25 HRS. | EVERY 6 MONTHS OR 50 HRS. | EVERY YEAR OR 100 HRS. | EVERY 2 YEARS OR 200 HRS. |
| Engine Oil | CHECK | X | | | | | |
| | CHANGE | | X | | | | |
| Air Cleaner | CHECK | X | | | | | |
| | CHANGE | | | X (1) | | | |
| All Nuts & Bolts | Re-tighten If Necessary | X | | | | | |
| Spark Plug | CHECK-CLEAN | | | | X | | |
| | REPLACE | | | | | | X |
| Cooling Fins | CHECK | | | | X | | |
| Spark Arrester | CLEAN | | | | | X | |
| Fuel Tank | CLEAN | | | | | X | |
| Fuel Filter | CHECK | | | | | X | |
| Idle Speed | CHECK-ADJUST | | | | | X (2) | |
| Valve Clearance | CHECK-ADJUST | | | | | | X (2) |
| Fuel lines | CHECK | Every 2 years (replace if necessary) (2) | | | | | |

(1) Service more frequently when used in **DUSTY** areas.

(2) These items should be serviced by your servic dealer, unless you have the proper tools and are mechanically proficient. Refer to the HONDA shop Manual for service procedures

(3) For commercial use, log hours of operation to determine proper maintenance intervals.



Reference manufacturer engine manual for specific servicing instructions.

Maintenance

Perform the engine maintenance procedures as indicated below:

DAILY

- Thoroughly remove dirt and oil from the engine and control area. Clean or replace the air cleaner elements as necessary. Check and retighten all fasteners as necessary. Check the spring box and bellows for oil leaks. Repair or replace as needed.

WEEKLY

- Remove the fuel filter cap and clean the inside of the fuel tank.
- Remove or clean the filter at the bottom of the tank.
- Remove and clean the spark plug (Figure 20), then adjust the spark gap to 0.028 ~0.031 inch (0.6~0.7 mm). This unit has electronic ignition, which requires no adjustments.




Figure 20. Spark Plug Gap

ENGINE OIL

1. Drain the engine oil when the oil is **warm** as shown in Figure 21.
2. Remove the oil drain bolt and sealing washer and allow the oil to drain into a suitable container.
3. Replace engine oil with recommended type oil as listed in Table 5. Engine oil capacity is 1.16 quarts (1.1 liters). **DO NOT** overfill.
4. Install drain bolt with sealing washer and tighten securely.




Figure 21. Engine Oil (Draining)

DANGER :



DO NOT use gasoline as a cleaning solvent, because that would create a risk of fire or explosion.

ENGINE AIR CLEANER

1. Remove the air cleaner cover and foam filter element as shown in Figure 22.
2. Tap the paper filter element (Figure 22) several times on a hard surface to remove dirt, or blow compressed air [not exceeding 30 psi (207 kPa, 2.1 kgf/cm²)] through the filter element from the air cleaner case side. **NEVER** brush off dirt. Brushing will force dirt into the fibers. Replace the paper filter element if it is excessively dirty.
3. Clean foam element in warm, soapy water or nonflammable solvent. Rinse and dry thoroughly. Dip the element in clean engine oil and completely squeeze out the excess oil from the element before installing.




Figure 22. Engine Air Cleaner

Pump Storage

For storage of the pump for over 30 days, the following is required:

- Drain the fuel tank completely.
- Run the engine until the fuel is completely consumed.
- Completely drain used oil from the engine crankcase and fill with fresh clean oil, then follow the procedures described in the engine manual for engine storage.
- Remove the pump cover and clean inside of pump housing. Coat inside of pump housing with a light film of oil to reduce corrosion. A spray can of oil works well for this application.
- Cover suction and discharge ports with duct tape to prevent any foreign matter from falling into pump.
- Cover pump and engine with plastic covering or equivalent and store in a clean, dry place.
- To protect the water cooled-seals, place one-half pint of lubricating oil (new or used) through the discharge opening on the pump and crank the engine several times. This will prevent excessive corrosion and also keep the mechanical seal lubricated.

MQ-D206H — TROUBLESHOOTING (ENGINE)

TABLE 7. ENGINE TROUBLESHOOTING

| SYMPTOM | POSSIBLE PROBLEM | SOLUTION |
|---|---|--|
| Difficult to start | | |
| Fuel is available but spark plug will not ignite. (Power available at high tension cable). | Ignition plug being bridge? | Check ignition system. |
| | Carbon deposit at ignition? | Clean or replace ignition. |
| | Short circuit due to defective insulators? | Replace insulators. |
| | Improper spark gap? | Set spark plug gap to the correct gap. |
| Fuel is available but spark plug will not ignite. (Power NOT available at high tension cable). | Short circuit at stop switch? | Check stop switch circuit. Replace stop switch if defective. |
| | Ignition coil defective? | Replace ignition coil. |
| Fuel is available and spark plug ignites (compression normal). | Muffler clogged with carbon deposits? | Clean or replace muffler. |
| | Mixed fuel quality is inadequate? | Check fuel to oil mixture. |
| | Fuel in use inadequate (water, dust)? | Flush fuel sytem and replace with fresh fuel. |
| | Air Cleaner clogged? | Clean or replace air cleaner. |
| Fuel is available and spark plug ignites (compression low). | Defective cylinder head gasket? | Tighten cylinder head bolts or replace head gasket. |
| | Cylinder worn? | Replace cylinder. |
| | Spark plug loose? | Tighen spark plug. |
| Operation not satisfactory | | |
| Not enough power available (compression normal, no miss-firing). | Air cleaner clogged? | Clean or replace air cleaner. |
| | Air in fuel line? | Bleed (remove air) from fuel line. |
| | Fuel level in carbureator float chamber improper? | Adjust carbureator float |
| | Carbon deposits in cylinder? | Clean or replace cylinder |
| Not enough power available (compression normal, miss-firing). | Ignition coil defective? | Flush fuel sytem and replace with fresh fuel. |
| | Ignition plug often shorts? | Replace ignition wires, clean ignition. |
| | Fuel in use inadequate (water, dust)? | Flush fuel sytem and replace with fresh fuel. |
| Engine overheats. | Excessive carbon depostion in combustion chamber? | Clean or replace crankcase. |
| | Exhaust or muffler clogged with carbon. | Clean or replace muffler. |
| | Spark plug heat value incorrect? | Replace spark plug with correct type spark plug. |

MQ-D206H — TROUBLESHOOTING (ENGINE/PUMP)

TABLE 7. ENGINE TROUBLESHOOTING (Continued)

| SYMPTOM | POSSIBLE PROBLEM | SOLUTION |
|--------------------------------------|------------------------------------|-----------------------------------|
| Operation not satisfactory | | |
| Rotational speed fluctuates. | Governor adjustment improper? | Adjust governor to correct lever. |
| | Governor spring defective? | Clean or replace ignition. |
| | Fuel flow erratic? | Check fuel line. |
| | Air taken in through suction line? | Check suction line. |
| Recoil starter not working properly. | Dust in rotating part? | Clean recoil starter assembly. |
| | Spring spring failure? | Replace sprial spring. |

TABLE 8. PUMP TROUBLESHOOTING

| SYMPTOM | POSSIBLE PROBLEM | SOLUTION |
|--|--|---|
| Pump does not take on water. | Not enough priming water in the housing? | Add water. |
| | Engine speed too low? | Increase throttle. |
| | Strainer plugged? | Clean strainer. |
| | Suction hose damaged? | Replace or repair hose, and clamps |
| | Air leak at suction port? | Check that fittings are tight and properly sealed. |
| | Pump is located too high above water line? | Move pump closer to water. |
| | Debris collecting in pump housing? | Clean pump housing. |
| | Water leaking out weep hole between pump and engine? | Check condition of mechanical seal and gaskets, between pump end and engine housing. |
| | Valves not seated correctly? | Check that valves are seated correctly. Pour water in in suction chamber to help seal valves. |
| | Pump does not prime correctly? | Check diaphragm for breaks or leaks. |
| Pump takes in water, little or no discharge. | Engine speed too low? | Increase throttle speed. |
| | Suction strainer partially plugged? | Clean strainer. |
| Suction hose leaks at inlet. | Fittings/clamps are not sealed properly? | Tighten, replace or add clamp. (Keep extra seals on pump) |
| | Hose diameter is too large? | Use smaller diameter hose or replace hose. |
| Discharge hose does not stay on coupling. | Pressure too high? | Check pressure, add additional clamp. |
| | Hose kinked or end blocked? | Check hose. |


MQ-D206H — EXPLANATION OF CODE IN REMARKS COLUMN

How to read the marks and remarks used in this parts book.

Items Found In the “Remarks” Column

Serial Numbers-Where indicated, this indicates a serial number range (inclusive) where a particular part is used.


Model Number-Where indicated, this shows that the corresponding part is utilized only with this specific model number or model number variant.



The contents of this catalog are subject to change without notice.

Items Found In the “Items Number” Column


All parts with same symbol in the number column, *, #, +, %, or <, belong to the same assembly or kit.



If more than one of the same reference number is listed, the last one listed indicates newest (or latest) part available.

**MQ-D206H DIAPHRAGM PUMP
1 TO 3 UNITS WITH
HONDA GX120K1QX2 ENGINE**


| Qty. | P/N | Description |
|---------|-------------------|--------------------------|
| 3 | 17210ZE0505 | ELEMENT AIR CLEANER DUAL |
| 3 | 9807955846 | SPARK PLUG |
| 1 | 17620ZH7023 | CAP, FUEL WITH GASKET |
| 1 | 28462ZH8003 | ROPE STARTER |
| 1 | 2022331 | DIAPHRAGM 2-INCH |
| 2 | 2023356 | FLAP VALVE 2-INCH |
| 1 | 2023322 | PLUG, 2-INCH FILL |
| 1 | 2023323 | GASKET, 2-INCH PLUG |
| 1 | 0742304050 | STRAINER |



Part number on this Suggested Spare Parts List may super cede/replace the P/N shown in the text pages of this book.

MQ-D206H — WATERBOX AND GROOVE ASSY.

WATERBOX AND GROOVE ASSY.



NOTES:

 TORQUE TO 16-20 FT. LBS.

MQ-D206H — WATERBOX AND GROOVE ASSY.

WATERBOX AND GROOVE ASSY.


| <u>NO.</u> | <u>PART NO.</u> | <u>PART NAME</u> | <u>QTY.</u> | <u>REMARKS</u> |
|------------|-----------------|---------------------------------|-------------|----------------|
| 1 | 2023354 | SUCTION CONN & GROOVE PIN ASSY. | 1 | |
| 2 | 2023322 | 2" FILL PLUG | 1 | |
| 3 | 2023323 | 2" PLUG GASKET | 1 | |
| 4 | 2023015 | EXTRA HEAVY NIPPLE | 2 | |
| 5 | 2023812 | 3/8"X1-1/2" HX SCREW | 4 | |
| 5A | 2023800 | 3/8" LOCKWASHER | 4 | |
| 6 | 2021838 | 1/8"X3/8" SPRING PIN | 2 | |
| 7 | 2023358 | VALVE WEIGHT | 2 | |
| 8 | 2023356 | FLAP VALVE | 2 | |
| 9 | 2023357 | VALVE BINDER | 2 | |
| 10 | 2021032 | RD. HD. MACH. SCREW #10-32X1/2" | 4 | |
| 11 | 2023351 | WATERBOX & GROOVE PIN ASSY. | 1 | |
| 12 | 2023355 | DISCHARGE CONNECTION | 1 | |
| 13 | 2023458 | STUD, 3/8"-16 X 2 UNC | 3 | |
| 13A | 2061213 | HEX NUT, 3/8"-16 | 3 | |
| 14 | 2023353 | DIAPHRAGM BOTTOM | 1 | |
| 15 | 2022331 | DIAPHRAGM | 1 | |
| 16 | 0742304050 | STRAINER | 1 | |
| 17 | 2023816 | NUT, HEX 3/8"-16 UNC | 3 | |

PUMP ASSY.

| <u>NO.</u> | <u>PART NO.</u> | <u>PART NAME</u> | <u>QTY.</u> | <u>REMARKS</u> |
|------------|-----------------|---------------------------------------|-------------|----------------|
| 16 | 2021214 | SCREW, 1/2"X2-1/4" HEX, HN | 2 | |
| 16A | 2061213 | HEX NUT, 1/2" -13 UNC | 2 | |
| 17 | 2023350 | PUMP FRAME | 1 | |
| 18 | 2025818 | JAM NUT, 5/8-18 UNF | 1 | |
| 19 | 3051213 | HEX SCREW 1/2"-13 UNC X 1-3/4" | 4 | |
| 19A | 2021200 | WASHER, LOCK 1/2" | 4 | |
| 20 | 2023212 | SCREW, #10-32X3/8" FT. HD. MACH | 6 | |
| 21 | 2023360 | RETAINING WASHER | 2 | |
| 22 | 2023352 | CONNECTING ROD | 1 | |
| 23 | 2020316 | GREASE FITTING, 3/16" DRIVE TYPE STR. | 1 | |
| 24 | 2025582 | BEARING, CONNECTING ROD | 1 | |
| 25 | 2020807 | WOODRUFF KEY | 2 | |
| 26 | 2025584 | CRANK ARM | 1 | |
| 27 | 2021232 | OIL SEAL | 1 | |
| 28 | 2021211 | SCREW, HEX 1/2"X1-1/2"-13 UNC | 1 | |
| 29 | 2025656 | SCREW, SOCKET SET 5/16"X5/16" -18 UNC | 1 | |
| 30 | 2024540 | PLUG, 3/8" VENTED PIPE, PLASTIC | 1 | |
| 31 | 2024850 | GEAR CASE | 1 | |
| 32 | 2024858 | GASKET, GEAR CASE | 1 | |
| 33 | 2063070 | BEARING, BALL | 1 | |
| 34 | 2024853 | GEAR SHAFT | 1 | |
| 35 | 2025058 | GEAR, 79 TOOTH | 1 | |
| 36 | 2063040 | BEARING, BALL | 2 | |
| 37 | 2024852 | PINION, 11 TOOTH | 1 | |
| 38 | 2023417 | GEAR, 85 TOOTH INTERNAL | 1 | |
| 39 | 2023020 | BEARING, BALL | 1 | |
| 40 | 2021434 | PIN, 1/4"X3/4" DOWEL | 2 | |
| 41 | 2064851 | COVER, GEAR CASE | 1 | |
| 42 | 2024945 | LIFTING HOOK | 1 | |
| 43 | 2021420 | SCREW, HEX 1/4"-20 UNC X1-1/4" | 2 | |
| 43A | 2021421 | WASHER, LOCK 1/4" | 2 | |
| 44 | 2061880 | NEEDLE BEARING | 1 | |
| 45 | 2024854 | 14T PINION (3/4" BORE) | 1 | |
| 46 | 2025100 | RETAINING RING | 1 | |
| 47 | 2029106 | BEARING, BALL | 1 | |
| 48 | 3051421 | SCREW, 1/4-20" UNC X1" | 9 | |
| 48A | 2021421 | WASHER, LOCK 1/4" | 9 | |
| 49 | 2021827 | PLUG, 1/8" NPT SQ. HD. PIPE | 2 | |
| 50 | 2024859 | O-RING | 1 | |
| 51 | 2025162 | SCREW, HEX 5/16"-24 UNF X1" | 4 | |
| 51A | 2025167 | WASHER, LOCK 5/16" | 4 | |
| 52 | 2024856 | ENGINE ADAPTER | 1 | |
| 53 | 2025160 | SCREW, SOCKET HD. 5/16"-18 UNC X1" | 4 | |
| 53A | 2025165 | LOCK WASHER CS W/INTERNAL TOOTH | 4 | |
| 54 | 2025601 | KEY 3/16" SQ. X 1" LG | 1 | |
| 63 | 2023691 | GUARD | 1 | |
| 64 | 2021012 | SELF TAPPING MACH. SCREWS | 2 | |
| 65 | 2021402 | WASHER, FLAT 1/4" | 2 | |

MQ-D206H — AXLE, HANDLE, ENGINE MTG. AND BUMPER ASSY.

AXLE, HANDLE, ENGINE MOUNTING AND BUMPER ASSY.




MQ-D206H — AXLE, HANDLE, ENGINE MTG. AND BUMPER ASSY.

AXLE, HANDLE, ENGINE MOUNTING AND BUMPER ASSY.

| <u>NO.</u> | <u>PART NO.</u> | <u>PART NAME</u> | <u>QTY.</u> | <u>REMARKS</u> |
|------------|-----------------|---------------------------------|-------------|----------------|
| 1 | 2020274A | WHEELS SEMI-PNEUMATIC | 2 | |
| 2 | 2023400 | WASHER, FLAT 3/4" SAE | 2 | |
| 3 | 2023161 | COTTER PIN, 3/16" X 1-1/4" LG | 2 | |
| 4 | 2023816 | SCREW, HEX 3/8"-16 UNC X 1-1/4" | 2 | |
| 5 | 2023039 | AXLE CLAMP | 2 | |
| 6 | 2023800 | WASHER LOCK | 2 | |
| 7 | 2063816 | NUT HEX 3/8"-16 UNC | 2 | |
| 8 | 2023320A | HANDLE | 1 | |
| 9 | 2021213 | SCREW HEX 1/2"-13 UNC X 2-1/2" | 2 | |
| 10 | 2021200 | WASHER, LOCK | 4 | |
| 11 | 2025111 | NUT HEX 5/16"-18 UNC | 4 | |
| 12 | 2025167 | WASHER, LOCK 5/16" | 4 | |
| 13 | 3055160 | WASHER, FLAT 5/16" | 8 | |
| 14 | 2022676 | WASHER, SLOTTED HOLE 1/32" THK | 4 | |
| 15 | 2023327 | BUMPER | 1 | |
| 16 | 2025169 | SCREW, HEX 5/16"-18 UNC X 2" | 2 | |
| 17 | GX160K1QX2 | HONDA ENGINE 4.0 HP | 1 | |

HONDA GX120K1QX2 ENGINE — AIR CLEANER ASSY.

AIR CLEANER ASSY.




HONDA GX120K1QX2 ENGINE — AIR CLEANER ASSY.

AIR CLEANER ASSY.

| <u>NO.</u> | <u>PART NO.</u> | <u>PART NAME</u> | <u>QTY.</u> | <u>REMARKS</u> |
|------------|-----------------|-----------------------------------|-------------|--------------------|
| 1 | 16271ZE1000 | GASKET, ELBOW | 1 | |
| 2 | 17210ZE0505 | ELEMENT, AIR CLEANER (DUAL) | 1 | INCLUDES ITEMS W/* |
| 3* | 17218ZE0505 | FILTER, OUTER | 1 | |
| 4 | 17230ZE0820 | COVER, AIR CLEANER (DUAL) | 1 | |
| 5* | 17232891000 | GROMMET, AIR CLEANER | 1 | |
| 7# | 17238ZE0010 | COLLAR, AIR CLEANER | 2 | |
| 8# | 17239ZE1000 | COLLAR B, AIR CLEANER | 1 | |
| 9 | 17410ZE0030 | ELBOW, AIR CLEANER | 1 | INCLUDES ITEMS W/# |
| 12 | 90325044000 | WINGNUT, TOOL BOX SETTING | 2 | |
| 13 | 957010602000 | BOLT, FLANGE 6X20 | 1 | |
| 14 | 9405006000 | NUT, FLANGE 6MM | 2 | |

HONDA GX120K1QX2 ENGINE — CAMSHAFT ASSY.

CAMSHAFT ASSY.




HONDA GX120K1QX2 ENGINE — CAMSHAFT ASSY.

CAMSHAFT ASSY.

| <u>NO.</u> | <u>PART NO.</u> | <u>PART NAME</u> | <u>QTY.</u> | <u>REMARKS</u> |
|------------|-----------------|----------------------------|-------------|--------------------|
| 1 | 14100ZE0812 | CAMSHAFT ASSEMBLY | 1 | INCLUDES ITEMS W/* |
| 2 | 14410ZE0010 | ROD, PUSH | 2 | |
| 3 | 14431ZE1000 | ARM, VALVE ROCKER | 2 | |
| 4 | 14441ZE1010 | LIFTER, VALVE | 2 | |
| 5 | 14451ZE1013 | PIVOT, ROCKER ARM | 2 | |
| 6* | 14568ZE1000 | SPRING, WEIGHT RETURN | 1 | |
| 7 | 14711ZF0010 | VALVE, IN. | 1 | |
| 8 | 14721ZF0000 | VALVE, EX. | 1 | |
| 9 | 14751ZF1000 | SPRING, VALVE | 2 | |
| 10 | 14771ZE1000 | RETAINER, IN. VALVE SPRING | 1 | |
| 11 | 14773ZE1000 | RETAINER, EX. VALVE SPRING | 1 | |
| 12 | 14781ZE1000 | ROTATOR, VALVE | 1 | |
| 13 | 14791ZE0010 | PLATE, PUSH ROD GUIDE | 1 | |
| 14 | 90012ZE0010 | BOLT, PIVOT 8MM | 2 | |
| 15 | 90206ZE1000 | NUT, PIVOT ADJ. | 2 | |

HONDA GX120K1QX2 ENGINE — CARBURETOR ASSY.

CARBURETOR ASSY.




HONDA GX120K1QX2 ENGINE — CARBURETOR ASSY.

CARBURETOR ASSY.

| <u>NO.</u> | <u>PART NO.</u> | <u>PART NAME</u> | <u>QTY.</u> | <u>REMARKS</u> |
|------------|-----------------|-----------------------------------|-------------|--------------------|
| 1* | 16010ZE1812 | GASKET SET | 1 | |
| 2* | 16011ZE0005 | VALVE SET, FLOAT | 1 | |
| 3* | 16013ZE0005 | FLOAT SET | 1 | |
| 4* | 16015ZE1811 | CHAMBER SET, FLOAT | 1 | |
| 5* | 16016ZH7W01 | SCREW SET | 1 | |
| 6* | 16024ZE1811 | SCREW SET, DRAIN | 1 | |
| 7* | 16028ZE0005 | SCREW SET B | 1 | |
| 8* | 16044ZE0005 | CHOKE SET | 1 | |
| 9 | 16100ZH7W51 | CARBURETOR ASSEMBLY, BE60B B..... | 1 | INCLUDES ITEMS W/* |
| 10* | 16124ZE0005 | SCREW, THROTTLE STOP | 1 | |
| 11* | 16166ZH7W50 | NOZZLE, MAIN | 1 | |
| 12* | 16173001004 | GASKET, FUEL STRAINER CUP | 1 | |
| 13 | 16211ZE0000 | INSULATOR, CARBURETOR | 1 | |
| 14 | 16212ZH7800 | GASKET, INSULATOR | 1 | |
| 15 | 16220ZE1020 | SPACER, CARBURETOR | 1 | |
| 16 | 16221ZH8801 | GASKET, CARBURETOR | 1 | |
| 17 | 16610ZE1000 | LEVER, CHOKE (STANDARD) | 1 | INCLUDES ITEMS W/+ |
| 18* | 16953ZE1812 | LEVER, VALVE | 1 | |
| 19* | 16954ZE1811 | PLATE, LEVER SETTING | 1 | |
| 20* | 16956ZE1811 | SPRING, VALVE LEVER | 1 | |
| 21* | 16957ZE1812 | GASKET, VALVE | 1 | |
| 22* | 16967ZE0811 | CUP, FUEL STRAINER | 1 | |
| 23* | 93500030080G | SCREW, PAN (3 X 6) | 2 | |
| 24# | 9430520122 | PIN, SPRING (2 X 12) | 1 | |
| 25 | 99101ZH80550 | JET, MAIN (#55) (OPTIONAL) | 1 | |
| 25 | 99101ZH80580 | JET, MAIN (#58) (OPTIONAL) | 1 | |
| 25* | 99101ZH80600 | JET, MAIN (#60) | 1 | |
| 26* | 99204ZE00350 | JET, SET, PILOT (#35) | 1 | |

HONDA GX120K1QX2 ENGINE — CONTROL ASSY.

CONTROL ASSY.




HONDA GX120K1QX2 ENGINE — CONTROL ASSY.

CONTROL ASSY.

| <u>NO.</u> | <u>PART NO.</u> | <u>PART NAME</u> | <u>QTY.</u> | <u>REMARKS</u> |
|------------|-----------------|---------------------------------|-------------|--------------------|
| 3 | 16500ZH7820 | CONTROL ASSEMBLY (REMOTE) | 1 | INCLUDES ITEMS W/# |
| 4 | 16551ZE0010 | ARM, GOVERNOR | 1 | |
| 5 | 16555ZE0000 | ROD, GOVERNOR | 1 | |
| 6 | 16561ZE0020 | SPRING, GOVERNOR | 1 | |
| 7 | 16562ZE0020 | SPRING, THROTTLE RETURN | 1 | |
| 8# | 16571ZH7000 | LEVER, CONTROL | 1 | |
| 9# | 16574ZE1000 | SPRING, LEVER | 1 | |
| 10# | 16575ZH8000 | WASHER, CONTROL LEVER | 1 | |
| 11# | 16576891000 | HOLDER, CABLE | | |
| 12# | 16578ZE1000 | SPACER, CONTROL LEVER | 1 | |
| 14# | 16580ZH7810 | BASE CONTROL | 1 | |
| 15# | 16584883300 | SPRING, CONTROL ADJUSTING | 1 | |
| 16# | 16592ZE1810 | SPRING, CABLE RETURN | | |
| 18 | 90013883000 | BOLT, FLANGE 6X12 (CT200) | 1 | |
| 19 | 90015ZE5010 | BOLT, GOVERNOR ARM | 1 | |
| 20 | 90022888010 | BOLT, FLANGE 6X20 (CT200) | 1 | |
| 21# | 90114SA0000 | NUT, SELF- LOCK 6MM | 1 | |
| 24# | 93500050250H | SCREW, PAN 5X25 | 1 | |
| 25# | 93500050160A | SCREW, PAN | 1 | |
| 26 | 9405006000 | NUT, FLANGE 6MM | 1 | |

HONDA GX120K1QX2 ENGINE — CRANKCASE COVER ASSY.

CRANKCASE COVER ASSY.




HONDA GX120K1QX2 ENGINE — CRANKCASE COVER ASSY.

CRANKCASE COVER ASSY.

| <u>NO.</u> | <u>PART NO.</u> | <u>PART NAME</u> | <u>QTY.</u> | <u>REMARKS</u> |
|------------|-----------------|--|-------------|--------------------|
| 1 | 11300ZE0640 | COVER ASSEMBLY, CRANKCASE (W- TYPE)..... | 1 | INCLUDES ITEMS W/* |
| 2 | 11381ZH7800 | GASKET, CASE COVER | 1 | |
| 3 | 15600ZE1003 | CAP ASSEMBLY, OIL FILLER | 1 | INCLUDES ITEMS W/# |
| 4 | 15600ZG4003 | CAP ASSEMBLY, OIL FILLER | 1 | INCLUDES ITEMS W/+ |
| 7# | 15625ZE1003 | GASKET, OIL FILLER CAP | 1 | |
| 8+ | 15625ZE1003 | GASKET, OIL FILLER CAP | 1 | |
| 9 | 90015883000 | BOLT, FLANGE 6X28 | 7 | |
| 10* | 91001878003 | BEARING, RADIAL BALL | 1 | |
| 11* | 91203ZE0003 | OIL SEAL 22X41X6 | 1 | |
| 12 | 9430108140 | PIN A, DOWEL 8X14 | 2 | |

HONDA GX120K1QX2 ENGINE — CRANKSHAFT ASSY.

CRANKSHAFT ASSY.



HONDA GX120K1QX2 ENGINE — CRANKSHAFT ASSY.

CRANKSHAFT ASSY.

| <u>NO.</u> | <u>PART NO.</u> | <u>PART NAME</u> | <u>QTY.</u> | <u>REMARKS</u> |
|------------|-----------------|--------------------|-------------|----------------|
| 1 | 13310ZE0601 | CRANKSHAFT, H-TYPE | 1 | |
| 2 | 90745ZE1600 | KEY 4.78 X4.78X38 | 1 | |


HONDA GX120K1QX2 ENGINE — CYLINDER BARREL ASSY.

CYLINDER BARREL ASSY.

| <u>NO.</u> | <u>PART NO.</u> | <u>PART NAME</u> | <u>QTY.</u> | <u>REMARKS</u> |
|------------|-----------------|-------------------------------------|-------------|--------------------|
| 2 | 120A0ZH7810 | CYLINDER ASSEMBLY (OIL ALERT) | 1 | INCLUDES ITEMS W/* |
| 3 | 15510ZE1033 | SWITCH ASSEMBLY, OIL LEVEL | 1 | |
| 4 | 16510ZE1000 | GOVERNOR ASSEMBLY | 1 | INCLUDES ITEMS W/# |
| 5# | 16511ZE1000 | WEIGHT, GOVERNOR | 2 | |
| 6# | 16512ZE1000 | HOLDER, GOVERNOR WEIGHT | 1 | |
| 7# | 16513ZE1000 | PIN, GOVERNOR WEIGHT | 2 | |
| 8 | 16531ZE1000 | SLIDER, GOVERNOR | 1 | |
| 9 | 16541ZE1000 | SHAFT, GOVERNOR ARM | 1 | |
| 10 | 90131ZE1000 | BOLT, DRAIN PLUG | 2 | |
| 11 | 90451ZE1000 | WASHER, THRUST 6mm | 1 | |
| 12 | 90601ZE1000 | WASHER, DRAIN PLUG 10.2mm | 2 | |
| 13 | 90602ZE1000 | CLIP, GOVERNOR HOLDER | 1 | |
| 14* | 91001878003 | BEARING, RADIAL BALL 62/22 | 1 | |
| 15* | 91202ZE6003 | OIL SEAL 22X35X6 | 1 | |
| 16 | 91353671003 | O- RING 13.5X1.5 (ARAI) | 1 | |
| 17 | 9405010000 | NUT, FLANGE 10mm | 1 | |
| 18 | 9410106800 | WASHER, PLAIN 6mm | 2 | |
| 19 | 9425108000 | PIN, LOCK 8mm | 1 | |
| 20 | 957010601200 | BOLT, FLANGE 6X12 | 2 | |

HONDA GX120K1QX2 ENGINE — CYLINDER HEAD ASSY.

CYLINDER HEAD ASSY.




HONDA GX120K1QX2 ENGINE — CYLINDER HEAD ASSY.

CYLINDER HEAD ASSY.

| <u>NO.</u> | <u>PART NO.</u> | <u>PART NAME</u> | <u>QTY.</u> | <u>REMARKS</u> |
|------------|-----------------|--------------------------------------|-------------|--------------------|
| 1 | 12210ZH7000 | CYLINDER HEAD | 1 | INCLUDES ITEMS W/* |
| 2* | 12204ZE1306 | GUIDE, VALVE (OS) OPTIONAL | 1 | |
| 3* | 12205ZE1315 | GUIDE, EX. VALVE (OS) OPTIONAL | 1 | INCLUDES ITEMS W/+ |
| 4*+ | 12216ZE5300 | CLIP, VALVE GUIDE | 1 | |
| 5 | 12251ZH7800 | GASKET, CYLINDER HEAD | 1 | |
| 6 | 12310ZE1000 | COVER, HEAD | 1 | |
| 6 | 12310ZE1010 | COVER, HEAD | 1 | |
| 7 | 12391ZE1000 | GASKET, CYLINDER HEAD COVER | 1 | |
| 8 | 15721ZH8000 | TUBE, BREATHER | 1 | |
| 9 | 90013883000 | BOLT, FLANGE 6X12 (CT200) | 4 | |
| 10 | 90043ZE1020 | BOLT, STUD 6X109 | 2 | |
| 11 | 90047ZE1000 | BOLT, STUD 8X32 | 2 | |
| 12 | 9430110160 | PIN, A, DOWEL 10X16 | 2 | |
| 14 | 957230805500 | BOLT, FLANGE 8X55 | 4 | |
| 15 | 9807955846 | SPARK PLUG BPR6ES (NGK) | 1 | |

HONDA GX120K1QX2 ENGINE — FAN COVER ASSY.

FAN COVER ASSY.




HONDA GX120K1QX2 ENGINE — FAN COVER ASSY.

FAN COVER ASSY.

| <u>NO.</u> | <u>PART NO.</u> | <u>PART NAME</u> | <u>QTY.</u> | <u>REMARKS</u> |
|------------|-----------------|------------------------------|-------------|----------------|
| 1 | 11347371300 | GROMMET, ADJUSTING COVER | 1 | |
| 2 | 19610ZE0000ZE | COVER, FAN *NH1* BLACK | 1 | |
| 3 | 19611ZH7810 | PLATE, SIDE (OIL ALERT) | 1 | |
| 4 | 90601ZH7013 | CLIP, HARNESS | 1 | |
| 5 | 19630ZH7000 | SHROUD | 1 | |
| 6 | 32197ZH8003 | SUB- HARNESS | 1 | |
| 7 | 36100ZE1015 | SWITCH ASSEMBLY, ENGINE STOP | 1 | |
| 7 | 36100ZH7003 | SWITCH ASSEMBLY, ENGINE STOP | 1 | |
| 8 | 36101ZE1010 | WIRE, STOP SWITCH 370MM | 1 | |
| 9 | 90013883000 | BOLT, FLANGE 6X12 (CT200) | 6 | |
| 10 | 90022888010 | BOLT, FLANGE 6X12 (CT200) | 1 | |
| 11 | 34150ZH7003 | ALERT UNIT, OIL | 1 | |
| 13 | 957010600800 | BOLT, FLANGE 6X8 | 1 | |

HONDA GX120K1QX2 ENGINE — FLYWHEEL ASSY.

FLYWHEEL ASSY.




HONDA GX120K1QX2 ENGINE — FLYWHEEL ASSY.

FLYWHEEL ASSY.

| <u>NO.</u> | <u>PART NO.</u> | <u>PART NAME</u> | <u>QTY.</u> | <u>REMARKS</u> |
|------------|-----------------|-----------------------------|-------------|----------------|
| 1 | 13331357000 | KEY, SPECIAL WOODRUFF 25X18 | 1 | |
| 2 | 19511ZE0000 | FAN, COOLING | 1 | |
| 4 | 28451ZH8003 | PULLEY, STARTER | 1 | |
| 5 | 31100ZE0010 | FLYWHEEL | 1 | |
| 7 | 90201878003 | NUT, SPECIAL 14MM | 1 | |

HONDA GX120K1QX2 ENGINE — FUEL TANK ASSY.

FUEL TANK ASSY.




HONDA GX120K1QX2 ENGINE — FUEL TANK ASSY.

FUEL TANK ASSY.

| <u>NO.</u> | <u>PART NO.</u> | <u>PART NAME</u> | <u>QTY.</u> | <u>REMARKS</u> |
|------------|-----------------|--------------------------------------|-------------|--------------------|
| 1 | 16854ZH8000 | RUBBER, SUPPORTER 107MM | 1 | |
| 2 | 16955ZE1000 | JOINT, FUEL TANK | 1 | |
| 3 | 17510ZE0020ZD | TANK, FUEL *NH1* (BLACK) | 1 | |
| 5 | 17620ZH7023 | CAP, FUEL FILLER | 1 | INCLUDES ITEMS W/* |
| 6* | 17631ZH7003 | GASKET, FUEL FILLER CAP | 1 | |
| 11 | 91353671003 | O- RING 13.5X1.5 (ARAI) | 1 | |
| 12 | 9405006000 | NUT, FLANGE 6MM | 2 | |
| 13 | 950014500360M | BULK HOSE, FUEL (4.5X3000) (4.5X140) | 1 | |
| 14 | 9500202080 | CLIP, TUBE (B8) | 2 | |
| 15 | 90004ZH7003 | BOLT, FLANGE 6X29 | 1 | |

HONDA GX120K1QX2 ENGINE — IGNITION COIL ASSY.

IGNITION COIL ASSY.




HONDA GX120K1QX2 ENGINE — IGNITION COIL ASSY.

IGNITION COIL ASSY.

| <u>NO.</u> | <u>PART NO.</u> | <u>PART NAME</u> | <u>QTY.</u> | <u>REMARKS</u> |
|------------|-----------------|--------------------------------|-------------|----------------|
| 1 | 30500ZE1033 | COIL ASSEMBLY, IGNITION | 1 | |
| 2 | 30700ZE1013 | CAP ASSEMBLY, NOISE SUPPRESSOR | 1 | |
| 8 | 90121952000 | BOLT, FLANGE 6X25 | 2 | |

HONDA GX120K1QX2 ENGINE — MUFFLER ASSY.

MUFFLER ASSY.




HONDA GX120K1QX2 ENGINE — MUFFLER ASSY.

MUFFLER ASSY.

| <u>NO.</u> | <u>PART NO.</u> | <u>PART NAME</u> | <u>QTY.</u> | <u>REMARKS</u> |
|------------|-----------------|--------------------|-------------|----------------|
| 1 | 18310ZF1000 | MUFFLER | 1 | |
| 3 | 18320ZF1H01 | PROTECTOR, MUFFLER | 1 | |
| 7 | 18381ZH8800 | GASKET, MUFFLER | 1 | |
| 10 | 90050ZE1000 | SCREW, TAPPING 5X8 | 4 | |
| 13 | 94001080000S | NUT, HEX. 8MM | 2 | |

HONDA GX120K1QX2 ENGINE — PISTON ASSY.

PISTON ASSY.




HONDA GX120K1QX2 ENGINE — PISTON ASSY.

PISTON ASSY.

| <u>NO.</u> | <u>PART NO.</u> | <u>PART NAME</u> | <u>QTY.</u> | <u>REMARKS</u> |
|------------|-----------------|--|-------------|--------------------|
| 1 | 13010ZK7V01 | RING SET, PISTON (STANDARD) | 1 | |
| 1 | 13011ZE6013 | RING SET, PISTON (OS 0.25), OPTIONAL | 1 | |
| 1 | 13012ZK7V01 | RING SET, PISTON (OS 0.50) , OPTIONAL | 1 | |
| 1 | 13013ZK7V01 | RING SET, PISTON (OS 0.75), OPTIONAL | 1 | |
| 2 | 13101ZH7000 | PISTON, STANDARD | 1 | |
| 2 | 13102ZH7000 | PISTON, OS 0.25 | 1 | |
| 2 | 13103ZH7000 | PISTON, OS 0.50 | 1 | |
| 2 | 13104ZH7000 | PISTON, 0.75 | 1 | |
| 3 | 13111ZE0000 | PIN, PISTON | 1 | |
| 4 | 132A0ZE0000 | ROD ASSY, CONNECTING (UNDER SIZE) | 1 | INCLUDES ITEMS W/* |
| 4 | 13200ZE0000 | ROD ASSEMBLY, CONNECTING | 1 | INCLUDES ITEMS W/* |
| 5* | 90001ZE1000 | BOLT, CONNECTING ROD | 2 | |
| 6 | 90551ZE0000 | CLIP, PISTON PIN 13MM | 2 | |

HONDA GX120K1QX2 ENGINE — RECOIL STARTER ASSY.

RECOIL STARTER ASSY.



HONDA GX120K1QX2 ENGINE — RECOIL STARTER ASSY.

RECOIL STARTER ASSY.

| <u>NO.</u> | <u>PART NO.</u> | <u>PART NAME</u> | <u>QTY.</u> | <u>REMARKS</u> |
|------------|-----------------|-------------------------------------|-------------|--------------------|
| 1 | 28400ZH8013ZB | STARTER ASSY., RECOIL *NH1* (BLACK) | 1 | INCLUDES ITEMS W/* |
| 2* | 28410ZH8003ZB | CASE, RECOIL STARTER *NH1* (BLACK) | 1 | |
| 3* | 28420ZH8013 | REEL, RECOIL STARTER | 1 | |
| 4* | 28422ZH8013 | RATCHET, STARTER | 2 | |
| 5* | 28433ZH8003 | GUIDE, RATCHET | 1 | |
| 6* | 28441ZH8003 | SPRING, FRICTION | 1 | |
| 7* | 28442ZH8003 | SPRING, RECOIL STARTER | 1 | |
| 8* | 28443ZH8003 | SPRING, RETURN | 2 | |
| 9* | 28461ZH8003 | KNOB, RECOIL STARTER | 1 | |
| 10* | 28462ZH8003 | ROPE, RECOIL STARTER | 1 | |
| 11* | 90003ZH8003 | SCREW, SETTING | 1 | |
| 12 | 9008ZE2003 | BOLT, FLANGE 6X10 | 3 | |

NO ARTWORK AVAILABLE

HONDA GX120K1QX2 ENGINE — GASKET KIT ASSY.

GASKET KIT ASSY.

| <u>NO.</u> | <u>PART NO.</u> | <u>PART NAME</u> | <u>QTY.</u> | <u>REMARKS</u> |
|------------|-----------------|-----------------------------|-------------|--------------------|
| 2 | 06111ZH7405 | GASKET KIT | 1 | INCLUDES ITEMS W/* |
| 3* | 11381ZH7800 | GASKET, CASE COVER | 1 | |
| 4* | 12251ZH7800 | GASKET, CYLINDER HEAD | 1 | |
| 5* | 12391ZE1000 | GASKET, CYLINDER HEAD COVER | 1 | |
| 6* | 16212ZH7800 | GASKET, INSULATOR | 1 | |
| 7* | 16221ZH8801 | GASKET, CARBURETOR | 1 | |
| 8* | 18381ZH8800 | GASKET, MUFFLER | 1 | |

PAYMENT TERMS

Terms of payment for parts are net 10 days.

FREIGHT POLICY

All parts orders will be shipped collect or prepaid with the charges added to the invoice. All shipments are F.O.B. point of origin. Multiquip's responsibility ceases when a signed manifest has been obtained from the carrier, and any claim for shortage or damage must be settled between the consignee and the carrier.

MINIMUM ORDER

The minimum charge for orders from Multiquip is \$15.00 net. Customers will be asked for instructions regarding handling of orders not meeting this requirement.

RETURNED GOODS POLICY

Return shipments will be accepted and credit will be allowed, subject to the following provisions:

1. A Returned Material Authorization must be approved by Multiquip prior to shipment.
2. To obtain a Return Material Authorization, a list must be provided to Multiquip Parts Sales that defines item numbers, quantities, and descriptions of the items to be returned.
 - a. The parts numbers and descriptions must match the current parts price list.
 - b. The list must be typed or computer generated.
 - c. The list must state the reason(s) for the return.
 - d. The list must reference the sales order(s) or invoice(s) under which the items were originally purchased.
 - e. The list must include the name and phone number of the person requesting the RMA.
3. A copy of the Return Material Authorization must accompany the return shipment.
4. Freight is at the sender's expense. All parts must be returned freight prepaid to Multiquip's designated receiving point.

5. Parts must be in new and resalable condition, in the original Multiquip package (if any), and with Multiquip part numbers clearly marked.
6. The following items are not returnable:
 - a. Obsolete parts. (If an item is in the price book and shows as being replaced by another item, it is obsolete.)
 - b. Any parts with a limited shelf life (such as gaskets, seals, "O" rings, and other rubber parts) that were purchased more than six months prior to the return date.
 - c. Any line item with an extended dealer net price of less than \$5.00.
 - d. Special order items.
 - e. Electrical components.
 - f. Paint, chemicals, and lubricants.
 - g. Decals and paper products.
 - h. Items purchased in kits.
7. The sender will be notified of any material received that is not acceptable.
8. Such material will be held for five working days from notification, pending instructions. If a reply is not received within five days, the material will be returned to the sender at his expense.
9. Credit on returned parts will be issued at dealer net price at time of the original purchase, less a 15% restocking charge.
10. In cases where an item is accepted, for which the original purchase document can not be determined, the price will be based on the list price that was effective twelve months prior to the RMA date.
11. Credit issued will be applied to future purchases only.

PRICING AND REBATES

Prices are subject to change without prior notice. Price changes are effective on a specific date and all orders received on or after that date will be billed at the revised price. Rebates for price declines and added charges for price increases will not be made for stock on hand at the time of any price change.

Multiquip reserves the right to quote and sell direct to Government agencies, and to Original Equipment Manufacturer accounts who use our products as integral parts of their own products.

SPECIAL EXPEDITING SERVICE

A \$35.00 surcharge will be added to the invoice for special handling including bus shipments, insured parcel post or in cases where Multiquip must personally deliver the parts to the carrier.

LIMITATIONS OF SELLER'S LIABILITY

Multiquip shall not be liable hereunder for damages in excess of the purchase price of the item with respect to which damages are claimed, and in no event shall Multiquip be liable for loss of profit or good will or for any other special, consequential or incidental damages.

LIMITATION OF WARRANTIES

No warranties, express or implied, are made in connection with the sale of parts or trade accessories nor as to any engine not manufactured by Multiquip. Such warranties made in connection with the sale of new, complete units are made exclusively by a statement of warranty packaged with such units, and Multiquip neither assumes nor authorizes any person to assume for it any other obligation or liability whatever in connection with the sale of its products. Apart from such written statement of warranty, there are no warranties, express, implied or statutory, which extend beyond the description of the products on the face hereof.

OPERATION AND PARTS MANUAL

HERE'S HOW TO GET HELP

PLEASE HAVE THE MODEL AND SERIAL
NUMBER *ON-HAND* WHEN CALLING

MULTIQUIP'S MAIN PHONE NUMBERS

800-421-1244 FAX: 310-537-3927
310-537-3700

PARTS DEPARTMENT

800-427-1244 FAX: 800-672-7877
310-537-3700 FAX: 310-637-3284

MAYCO PARTS

800-306-2926 FAX: 800-672-7877
310-537-3700 FAX: 310-637-3284

SERVICE DEPARTMENT

800-478-1244 FAX: 310-537-4259
310-537-3700

MQ POWER SERVICE DEPARTMENT

800-835-2551 FAX: 310-638-8046
310-537-3700

TECHNICAL ASSISTANCE

800-478-1244 FAX: 310-631-5032

WARRANTY DEPARTMENT

800-421-1244, EXT. 279 FAX: 310-537-1173
310-537-3700, EXT. 279



MULTIQUIP INC.
POST OFFICE BOX 6254
CARSON, CA 90749
310-537-3700 • 800-421-1244
FAX: 310-537-3927
E-MAIL: mq@multiquip.com
WWW: multiquip.com

Atlanta • Boise • Dallas • Houston • Newark
Quebec, Canada • Manchester, UK • Rio De Janeiro, BR • Guadalajara, MX