

Creda

M152E

Installation & User Instructions

You must read these instructions prior to using the appliance and retain them for future reference.



For more information on our exciting product range ring
Creda Answer Centre 08701 54 64 74

OR



Visit us on the **NET** at
<http://www.creda.co.uk>

Our site invites you to make use of our **interactive cookbook** and **product selector**. Feel free to **browse our product range** to see what's **bubbling away** at the moment or to **ask for help** on our products and services

Creda

General Domestic Appliances Ltd. Morley Way Peterborough PE2 9JB
Creda Answer Centre 08701 54 64 74
Web <http://www.creda.co.uk>

It may be necessary from time to time to change the specification outlined in this booklet without notice. Any change which is made will not affect your statutory rights.

Contents

Control Panel _____	4
Oven Timer Operation _____	5
Using The Hob _____	12
Using The Grill _____	13
Using the Main Oven (See also General Information Book) _____	15
Something Wrong? _____	17
Service _____	19


To the Installer

Before installation fill in the product details on the back cover of this booklet. The information can be found on the rating plate.

To the User

You must read the instructions prior to using the appliance and then retain them for future reference.

Control Panel



Oven Interior Lights

The oven lights are operated when their respective oven control is used. **(N.B.** Not all models have a top oven interior light.)

Slow Cooking

The main oven has a "Slow Cook Setting" this can be used for slow cooking, keeping food warm and warming plates for a short period (see page 16).

Hob On Light

The Hob On light will illuminate when one or more hotplates are switched on. This light remains illuminated until all the hotplate controls have been turned off.

Note: Ensure that all controls have been switched off when you have finished using the appliance.

Oven Timer Operation

Note: Timer must be set to 'Time of Day' and 'Manual' before the ovens can be used.

AUTOMATIC COOKING

The Main Oven can be controlled by the automatic timer.

NEVER operate the grill when the oven is set to cook automatically because the oven cavity can become warm and this may cause bacterial growth in food.

HINTS ON AUTOMATIC COOKING

1. Select foods which will require the same cooking time and temperature.
2. To ensure food does not cool down and require reheating, set the end time so the food is ready when you require it.
3. Always ensure that meat and poultry is defrosted before placing in the oven.
4. Whenever possible, keep food as cool as possible before placing in the oven, ideally straight from a refrigerator.
5. If cooking food that requires frying before placing in the oven for auto cooking, keep the delay start time to a minimum.
6. Never place hot or warm food in the oven for delay start cooking as it could cause the oven to be warm and produce harmful bacteria in the food.
7. We advise that dishes containing left-over cooked poultry or meat, e.g. Shepherd's Pie, should not be cooked automatically if there is to be a delay period.
8. Ensure that delay start times are kept to a minimum to prevent bacterial growth in food.
9. Wine or beer may ferment and cream may curdle during the delay period so it is best to add these ingredients just before serving.
10. Foods which discolour should be protected by coating in fat or tossing in water to which lemon juice has been added, prior to placing food in the oven.
11. Dishes containing liquid should not be filled too full to prevent boiling over.
12. Food should be well sealed (but not airtight) in a container to prevent the loss of liquid during cooking. Aluminium foil gives a good seal.
13. Always ensure that food is piping hot and cooked thoroughly before serving.
14. Only reheat food once.


Know Your Timer

CLOCKFACE




The timer incorporates a 24 hour clock.
Ensure the correct time of day is always set, before using your cooker.


SYMBOLS



 Will light up when you select a Minute Minder Period and will remain lit for the period set.



 This "Cookpot" symbol will light up either:-
 - When the cooker is in "Manual Mode"
 - When you press the Cook Period Button and set a length of time for an Auto Cooking Programme. ( symbol will light up during Auto Cooking)



"A" will light up:-
 - When the timer is first turned on it will flash. (It will go out when a time of day is set).
 - When an Auto Cooking Programme has been set.
 The Auto symbol "A" will flash at the end of an Auto Cooking programme to indicate that the programme has finished.
(When the "A" symbol is flashing, to return the oven to Manual operation, turn the oven controls off, ensure that the correct time of day is set, and press the "Cook Period & Stop Time" buttons together- The "A" symbol will go out.)

TIMER FUNCTION BUTTONS

Minute Minder Button

Here you can set a time period of up to 23 hours 59 minutes, that will count down. When it reaches zero, the timer will emit an audible tone.
For Example: If you set 20 minutes, the audible tone will occur 20 minutes later.

AUTO COOKING PROGRAMME

Cook Period Button

Cook Period is the actual length of time for which, the timer will switch the oven(s) on as part of an "Auto Cooking" programme.
 (e.g. If you set 2 hours, the food will be cooked for 2 hours).

Stop Time Button

The time of day at which you want an "Auto Cooking" programme to **stop**.
For Example: If you set a "Cook Period" for 2 hours, and "Stop Time" of 11:00. The timer will switch the oven(s) on at 9:00 and turn the oven(s) off at 11:00. You will hear an audible tone at 11:00, to indicate that the Auto Cooking Programme has finished.

Notes:


- When setting an Auto Cooking programme you will need to set the oven control(s) to the required temperature(s) when you set the timer.
- If an Auto Cooking programme has been set the oven(s) will only operate during the pre-programmed time.

"+" and "-" Buttons

Used to adjust the various timer function settings.
 Used to adjust pitch of audible tone (see other notes on timer operation).

Oven Timer Operation


SETTING THE TIME OF DAY



Step 1 Make sure all oven controls are turned Off.

Step 2 Check the electricity supply to the cooker is turned on.

When switched on the display will show 0.00 and "A" symbol, both will be flashing intermittently.



Step 3 Press & hold in both the "Cook Period & Stop Time" buttons together.

Step 4 With the "Cook Period & Stop Time" buttons still held in, press either the "+" or "-" buttons to set the correct time of day.

Step 5 Release all the buttons simultaneously.

The time of day is now set and the  symbol will light up to show that the timer is in "Manual Mode"

To change the time of day repeat Steps 3, 4 & 5 above.


Note: You cannot adjust the time of day if the timer has been set for an Auto Cooking Programme.

SETTING THE MINUTE MINDER



Step 1 Ensure the time of day is set correctly.


Step 2 Press and hold the Minute Minder Button.



Step 3 With the "Minute Minder" button held in, set the required Minute Minder time using the "+" and "-" buttons, a  symbol will light up.

Release all buttons and the timer display will revert back to the time of day. Bell symbol will remain lit to signify that a Minute Minder period has been set. At the end of the set time a bleeping sound will be heard, and the  symbol will go out.

The bleeping sound will continue for several minutes unless cancelled (see step 4)



Step 4 To cancel the bleeping sound press the Minute Minder button, timer display will revert back to the time of day after the buttons are released.

To cancel Minute Minder before the Minute Minder period has finished.

Step 1 Press the minute minder button.

Step 2 Press the "-" button until 0.00 and the  symbol appear in the display window.

Step 3 To cancel the bleeping sound press Minute Minder button.

When the Minute Minder has been set, the time remaining can be checked at any time by simply pressing the Minute Minder button

Oven Timer Operation

There are two Auto Cooking programmes that can be selected using your timer:-


a) To set the timer to switch the oven(s) On and Off automatically.

b) To set the timer to switch On immediately and OFF automatically after a set cook period.

a) TO SET TIMER TO SWITCH THE OVEN(S) ON AND OFF AUTOMATICALLY.

Step 1 Check that the correct time of day is set, if not follow instructions for setting the time of day.

Step 2 Place food onto the correct shelf position in the oven and close the oven door(s).




Step 3 Press & hold in the "Cook Period" button, the display will read 0.00 with the cookpot symbol lit up.

Step 4 With the Cook Period button still held set the required Cook Period using the "+" and "-" buttons.




Release the buttons and the timer display will revert to the time of day with the Auto symbol "A" & Cookpot symbol remaining lit.



Step 5 Press and hold the "Stop Time" button. The display will read the earliest possible stop time for the cook period that you have set above.


Step 6 With the Stop Time button still held in, use the "+" and "-" buttons to set the "Stop Time". i.e. The time you require the oven to switch off.



Release all the buttons and the timer will revert back to the time of day. The "A" symbol will remain lit to signify that an Auto Cooking Programme has been set. The cookpot symbol will go out. When the Auto Cook Programme starts the cookpot symbol will then light up again.

Step 7 Turn the oven control(s) to the required temperature, and if necessary select the appropriate oven.

Oven Timer Operation



At the end of the Automatic Cook Period the Auto Symbol "A" will flash and an intermittent beeping sound will be heard. The  symbol will go out. The beeping sound will continue for several minutes unless cancelled. (see step 8) The "A" symbol will continue to flash until the timer is returned to Manual operation (see below).

Step 8


Press the Cook Period button to cancel the beeping sound.

Step 9

Turn the oven control(s) to the OFF position.

Step 10

Press the Cook Period and Stop Time buttons together to return the oven(s) to Manual Operation. The "A" symbol will go out and the  Cookpot symbol will light up



Note 1 When cooking automatically the Cook Period can be checked at any time by simply pressing the Cook Period button.

Note 2 When cooking automatically the Stop Time can be checked at any time by simply pressing the Stop Time button.

Oven Timer Operation

b) TO SET TIMER TO SWITCH ON IMMEDIATELY AND OFF AUTOMATICALLY AFTER A SET COOK PERIOD

- Step 1** Check that the correct time of day is set, if not follow instructions for setting the time of day.
- Step 2** Place food onto the correct shelf position in the oven and close the oven door(s).
- Step 3** Turn the oven control(s) to the required temperature, and if necessary select the appropriate oven function.

Step 4 Press & hold in the "Cook Period" button, the display will read 0.00 and the cookpot  symbol will light up.

With the Cook Period button still held set the required Cook Period using the "+" and "-" buttons, the "A" symbol will light up. (Example: 1hr 30 minutes).

Note: Cook Period is the length of time the food requires to cook.

Step 5 Release all buttons.

The timer display will revert to the time of day with the Auto symbol "A" lit & Cookpot symbol  remaining lit.

At the end of the Cook Period the "A" symbol will flash and an intermittent bleeping sound will be heard. The cookpot symbol  will go out. The bleeping sound will continue for several minutes unless cancelled. (see step 6) The "A" symbol will continue to flash until the timer is returned to Manual operation (see below).

Step 6 Press the "Cook Period" button to cancel the bleeping.

Step 7 Turn the oven control(s) to the OFF position.

Step 8 Press the "Cook Period" and "Stop Time" buttons together to return the cooker to Manual operation. (The "A" symbol will go out, and the  Cookpot symbol will light up).

Note 1 When cooking automatically the Cook Period can be checked at any time by simply pressing the Cook Period button.


Note 2 When cooking automatically the Stop Time can be checked at any time by simply pressing the Stop Time button.

Oven Timer Operation

OTHER NOTES ON TIMER OPERATION

1. To cancel the Auto Cooking programme before or after auto cooking starts, press the "Cook Period" and "Stop Time" buttons together, this will return the cooker to the manual operation.
2. When cooking Automatically the "Cook Period" can be checked at any time by simply pressing the "Cook Period" button.
3. When cooking Automatically the "Stop Time" can be checked at any time by simply pressing the "Stop Time" button
4. Having set a Cook Period and Stop Time an electronic device stores the information. The device within the timer will switch the oven(s) on and off at the required time.
5. When setting an Auto Cooking Programme and a mistake is made, to clear:-
 - (a) Press and hold in the "Cook Period" and "Stop Time" buttons together to return the cooker to manual operation.
 - (b) Start the sequence again.
6. If at any time the display shows three flashing zero's 0.00. It is likely that the electricity supply to the oven has been interrupted. Reset the timer to the correct time of day.
Food in the oven may, therefore, not have been cooked, before serving check food is thoroughly heated and completely cooked.
7. To set each function always press and hold the required function button and at the same time press "+" or "-" buttons.
8. To adjust the pitch of the Bleeping sound, simply press the "-" button while the audible tone is sounding. For example:-
 - (a) Press and hold the minute minder button.
 - (b) With the minute minder button still held in, press the "+" button and set one minute.
 - (c) When the Bleeper sounds after one minute, press and release the "-" button, until preferred pitch is set.
 - (d) Press and release the Minute Minder button to cancel the bleeping.

Using The Hob



In the unlikely event of a crack (no matter what size) appearing in the ceramic surface, switch off the electricity supply to your appliance IMMEDIATELY and contact your service centre.

DO NOT USE THE APPLIANCE UNTIL IT IS REPAIRED

NEVER allow aluminium foil to be in contact with the hob surface when in use.

SETTING THE HOTPLATE

Step 1 Place the saucepan centrally on the required hotplate.

Step 2 Turn the associated hotplate control (A, B, C or D) to the required setting.

Step 3 When you have finished, turn the hotplate control knob to the OFF position **O**.

DO NOT allow young children near to the cooker when it is in use as the surfaces get extremely hot!


Guide To Using The Hotplates.

Bringing water to boil,
Deep fat frying,
Dissolve sugar for preserve making.

To seal meat and
fry fish.

Low temperature frying
(sausages etc.)

To maintain a 'Rolling Boil' for preserve making.



These settings are a guide & will vary depending on the type of saucepans used.

To melt butter,
chocolate etc.

To simmer foods, milk
puddings


To keep water boiling.

DEEP FAT FRYING SAFELY

1. Use a deep pan, large enough to completely cover the appropriate heating area.
2. Never fill the pan more than one third full of oil.
3. Never leave oil or fat unattended during the heating or cooking period.
4. Never try to fry too much food at a time, especially frozen food. This lowers the fat temperature too much resulting in greasy food.
5. Always dry food thoroughly before frying, then lower it slowly into the hot oil or fat. Frozen foods in particular will cause the fat to froth and spit if added to quickly.
6. Never heat fat or fry with a lid on the pan.
7. Keep the outside of the pan clean and free of streaks of oil or fat.

When cooking food that contains sugar (most food) or syrup, use a utensil which is large enough to prevent boil over or spillage. **Sugar spillage will permanently damage the hob and therefore should be cleaned off with care immediately.** If sugar spillage has occurred, remove it as long as it is still hot with a metal safety razor scraper. This will avoid any damage. **NEVER LET IT COOL BEFORE REMOVING.**

Using The Grill



GRILLING SHOULD NOT BE UNDERTAKEN WITH THE GRILL DOOR CLOSED.


Never line the grill pan with aluminium foil.

DO NOT allow young children near to the cooker when it is in use as the surfaces get extremely hot!


SETTING THE GRILL

- STEP 1** Place the grill pan on runners in the correct position (see guide to grilling). Leave the grill door fully open.
- STEP 2** Set the grill control (E) to its maximum setting, the pilot light will come on to show that the grill is switched on. Pre heat for 5 minutes.
- STEP 3** Turn the control to the required setting (see guide to grilling). Place the grill pan on the shelf and position centrally under the grill element.
- STEP 4** When you have finished turn the grill control knob to the OFF position (O), the pilot light will go out.

DOOR POSITION FOR GRILLING



REMOVING THE GRILL PAN HANDLE



The grill pan handle is detachable to allow easier cleaning and storage.

- Step 1** Remove screw & washer from the grill pan handle.
- Step 2** Tilt the handle over the recess
- Step 3** Slide it towards the end of the pan and remove handle.

Guide To Grilling

Pre - heat the grill for 5 minutes on maximum control setting before grilling

GRILL CHART

Food	Grill Setting	Approximate Cooking time
Toasting of Bread products	H	3 - 5 mins.
Small cuts of meat, sausages, bacon, etc.	M - H	8 - 15 mins.
Chops etc. Gammon steaks Chicken pieces	M	20 - 25 mins. Wire food support used in upturned position for chicken.
Fish: fingers Whole Fillets	M	10 - 20 mins. Whole fish and fillets placed in the base of the grill pan.
Fish in breadcrumbs	M	15 - 20 mins.
Pre - Cooked potato products	M	10 - 12 mins.
Pizzas	M	12 - 15 mins. in the base of the grill pan.
Browning of food	H	8 - 10 mins. Dish placed directly on base of the grill pan and pan placed on the base of the grill compartment.

The settings in the above guide have been developed to cook food successfully without excessive fat spitting and splashing.

Always position the grill pan centrally under the grill element to ensure even cooking.

Using The Main Oven

Since a circulaire fan oven heats up more quickly, and generally cooks food at a lower temperature than a convection oven, pre-heating is often unnecessary. For guides on “pre-heating”, “cooking temperatures” and “cooking times”, see “Oven Temperature Charts” in General Information book.

NOTE: Charts are a guide only, to suit personal taste and requirements, it may be necessary to increase or decrease temperatures by 10°C. It may also be necessary to increase or decrease cooking times.

POINTS TO REMEMBER ABOUT FAN OVENS

Fan ovens heat up quicker than convection ovens, so pre - heating is often unnecessary. Cooking can be carried out at slightly lower temperatures.

Identical cooking results can be achieved no matter what shelf is used.

MAIN OVEN SHELF POSITIONING FOR FAN OVEN

Most foods will cook satisfactorily on any shelf position, due to even distribution of heat in the main oven, but the shelves must be evenly spaced. The top oven rod shelf can be used in the main oven when cooking large quantities of food. (N.B. Maximum 3 shelves in the main oven).

Food or utensils must never be placed directly on the floor of the oven for cooking.


DO NOT allow young children near to the appliance when the oven is in use as the surfaces get extremely hot.

MAIN OVEN UTENSILS

Do not use: Meat pans larger than 375mm x 300mm (15" x 12")
Baking Trays larger than 325mm x 250mm (13" x 10")

TEMPERATURE & TIME

When all three shelves are in use to cook large quantities of food, it may be necessary to increase the cooking times given in the temperature charts by a few minutes to allow for the loss of heat due to extra time taken to load the oven, and the larger mass of food. Baking trays should have an even gap around the oven.



SETTING THE MAIN OVEN

Step 1 Check that the timer (G) is in manual.

Place the shelf in the correct position (see Main Oven Temperature Charts in General Information book)

Step 2 Select the required cooking temperature using control (F) clockwise (see Main Oven Temperature Charts in General Information book). The pilot light (●) will immediately come on, and stay on until the oven reaches the required temperature.. The light will then automatically go off and on during cooking as the oven thermostat maintains the correct temperature.

Step 3 When the oven has reached the required temperature, place the food on the shelf (positioned as shown in the Main Oven Temperature Charts in General Information book) and close the oven door.

Step 4 When you have finished, turn the control knob to the OFF position (O).

When you open the oven door during cooking a momentary puff of steam may appear, this is NOT a fault. It is perfectly normal and is the sign of a good door seal.

Using The Main Oven For Other Functions

“SLOW” SETTING

This is used for slow cooking, keeping food warm and warming plates for short periods. Extra care must be taken when warming bone china. Do not place food or plates on the floor of the oven.

DO NOT place food or plates directly on the oven floor as this could damage both the oven lining and the plates which are being warmed

Some advantages of slow cooking are:

The oven stays cleaner because there is less splashing.

Timing of food is not as critical, so there is less fear of overcooking.

Inexpensive cuts of meat are tenderised.

Fully loading the oven can be very economical.

Cooking times can be extended in some cases by up to 2hrs. for late-comers.

The kitchen stays cooler.

OPERATION:

- 1) Place the prepared food in the main oven and ensure the door is fully closed.
- 2) Select Slow Cooking temperature by turning main oven temperature control (F) clockwise ensuring the oven door is fully closed.

STORAGE AND RE-HEATING OF FOOD

- 1) If food is to be frozen or not served immediately, cool it in a clean container as quickly as possible.
- 2) Thaw frozen food completely in the refrigerator before re-heating.
- 3) Re-heat food thoroughly and ensure it is piping hot before serving.
- 4) Only re-heat food once.

POINTS TO BEAR IN MIND WHEN PREPARING FOOD:

- 1) Make sure all dishes will fit into the oven before preparing the food.
- 2) All dishes cooked by the 'Slow' setting should be cooked for a minimum of 6 hours. They will 'hold' at this setting for a further hour but marked deterioration in appearance will be noticed in some cases.
- 3) Joints of meat and poultry should be cooked at fan oven 170°C for 30 mins before turning to the Slow setting.
- 4) Meat over 2.7 Kg. (6 lbs) and poultry over 2 Kg. (4 lbs 8oz) are unsuitable for the Slow setting.
- 5) Always stand covered joints on a rack over the meat tin, to allow good air circulation.
- 6) Pork joints can only be cooked, if by testing with a meat thermometer and internal temperature of at least 88°C is reached.
- 7) This method is unsuitable for stuffed meat and poultry.
- 8) Always bring soups, casseroles and liquids to the boil before putting in the oven.
- 9) When casseroles are used, cover the food first with foil and then the lid to prevent loss of moisture.
- 10) Always thaw frozen food completely before cooking.
- 11) Root vegetables will cook better if cut into small even sized pieces.
- 12) Always adjust the seasoning and thickenings at the end of the cooking time.
- 13) Egg and fish dishes need only 1-5 hours cooking and should be observed from time to time.
- 14) Dried red kidney beans must be boiled for a minimum of ten minutes after soaking, before inclusion in any dish.

Something Wrong?

Before calling a Service Engineer, please check through the following lists.
THERE MAY BE NOTHING WRONG.

Problem	Check
Slight odour or small amount of smoke when grill / oven used first time	This is normal and should cease after a short period.
Nothing Works	If you find that the timer display is blank, then it is likely that there is no electricity supply to your oven. Check: (i) That the main cooker wall is switched on (ii) Other appliances, to see if you have had a power cut. (iii) The main circuit breaker for the property
Timer Display shows "0:00" with "A" Flashing	The power supply to your oven has possibly been interrupted, but has now come back on again. Reset the timer to the correct day and "Manual" operation using the instructions given in the timer section of the book.
Marks appearing on hob / Can not clean hob	(a) It is imperative that Ceramic Hobs are cleaned and conditioned regularly - Please refer to the Care and Cleaning section of your General Notes book for further information. Please note that replacement Hob Cleaning and Conditioning kits are available from our Spare Parts Department under Part number 6224842 (b) With any Ceramic Hob, using the correct pans is essential. Not all pans are suitable - Please refer to the Pan section of your General Notes book for further information.
Main oven does not work, but the grill works	Your timer may be set for an Auto Cooking programme: Check the timer to see whether "A" is lit or flashing. If it is then please follow the instructions given in the Timer section of this book to return the timer to Manual operation.
Grill does not work, but Main oven works.	Operating the cooker under the following conditions may cause a safety device to operate: (a) Grilling with the door closed - Always grill with the door fully open (b) Grilling for an excessively long period at maximum setting - see Grilling guide. Switch off appliance and allow to cool for approx 30 mins. Switch the cooker back on and check that the Grill / Top oven is now operating.

Something Wrong?

Problem	Check
Can not set an "Auto Cook" programme / Can not get the timer to turn the oven on and off at the required times	Remember "Cook Period" is the actual length of time for which the timer will switch the oven(s) on as part of an "Auto Cooking" programme.
Grill keeps turning on and off	When the Grill control is operating at less than its maximum setting, the Grill will cycle on and off, this is normal and not a fault.
Draught from beneath control panel	A gentle flow of air will be blown from beneath the control panel when the appliance is used. If the appliance is still warm, this cooling fan may run on, or restart itself when all controls have been turned off. The fan will stop once the appliance has been cooled. This is normal and not a fault.
Timer buzzer / bleeper operates continually	The bleeper will stop automatically after several minutes. To cancel, press the minute minder button to silence.
Oven temperatures too high or low	Check temperature and shelf positions are as recommended in the Oven Temperature Charts. It may be necessary to increase or decrease the recommended temperature slightly to suit your taste.
Oven does not cook evenly	Check: (a) Temperature and shelf positions are as recommended in the Oven Temperature Charts. (b) Oven utensils being used allow sufficient air flow around them.
Oven lamp does not work	The oven lamp is not covered by the guarantee. The part is easily changed (see the section on oven lamp replacement) A new lamp may be obtained from our Spare Parts department by calling: 0541 530530
Condensation on the wall at the rear of the cooker.	Steam and / or condensation may appear from the vent at the rear of the appliance when using an oven particularly for foods with a high water content e.g. frozen chips, roast chicken etc. This is normal, and any excess should be wiped off.
Steam / Condensation in the oven after use.	Steam is a by-product of cooking any food with a high water content. To help minimise always: a) Try to avoid leaving food in the oven to cool after being cooked especially with the control knob turned off. b) Use a covered container, wherever possible.

If you have been through the above list and there is still a problem; you should identify your service agent using the list on the back page and contact your local service office.

Key Contacts

Service

Creda has the largest appliance manufacturer's service team in Europe, trained specialists directly employed by us to ensure your complete confidence.

Repair Service

UK: 08709 066 066

Republic of Ireland: 1850 302 200

You will be asked for the following information:-

Name, address and postcode.

Telephone number

Model / Serial number of the appliance

Clear and concise details of the query or fault

Place and Date of purchase

(Please keep the receipt as evidence will be required when the engineer calls).

Extended Warranty

To join: UK 08709 088 088

Republic of Ireland: 1850 502 200

Genuine Parts & Accessories Mail Order Hotline

UK: 08709 077 077

Republic of Ireland: (01) 842 6836

For further product information 08701 54 64 74

All Creda Services are offered as an extra benefit and do not affect your statutory rights.

Creda

General Domestic Appliances Limited, Morley Way, Peterborough, PE2 9JB