

TECHNICAL & SERVICE MANUAL

SAP-K77RAX + SAP-C77RAX
SAP-K97RAX + SAP-C97RAX
SAP-K127RAX + SAP-C127RAX

FILE NO.


Destination: Russia (50Hz)

SPLIT SYSTEM AIR CONDITIONER

Indoor Model No.	Product Code No.
SAP-K77RAX	1 852 350 01
SAP-K97RAX	1 852 350 02
SAP-K127RAX	1 852 350 03


Outdoor Model No.	Product Code No.
SAP-C77RAX	1 852 350 04
SAP-C97RAX	1 852 350 05
SAP-C127RAX	1 852 350 06

Indoor Unit




SAP-K77RAX
SAP-K97RAX
SAP-K127RAX

Outdoor Unit



SAP-C77RAX
SAP-C97RAX



SAP-C127RAX

Important! Please Read Before Starting

This air conditioning system meets strict safety and operating standards. As the installer or service person, it is an important part of your job to install or service the system so it operates safely and efficiently.

For safe installation and trouble-free operation, you must:

- Carefully read this instruction booklet before beginning.
- Follow each installation or repair step exactly as shown.
- Observe all local, state, and national electrical codes.
- Pay close attention to all warning and caution notices given in this manual.



WARNING

This symbol refers to a hazard or unsafe practice which can result in severe personal injury or death.



CAUTION

This symbol refers to a hazard or unsafe practice which can result in personal injury or product or property damage.

If Necessary, Get Help

These instructions are all you need for most installation sites and maintenance conditions. If you require help for a special problem, contact our sales/service outlet or your certified dealer for additional instructions.

In Case of Improper Installation

The manufacturer shall in no way be responsible for improper installation or maintenance service, including failure to follow the instructions in this document.

SPECIAL PRECAUTIONS

WARNING When Wiring



ELECTRICAL SHOCK CAN CAUSE SEVERE PERSONAL INJURY OR DEATH. ONLY A QUALIFIED, EXPERIENCED ELECTRICIAN SHOULD ATTEMPT TO WIRE THIS SYSTEM.

- Do not supply power to the unit until all wiring and tubing are completed or reconnected and checked.
- Highly dangerous electrical voltages are used in this system. Carefully refer to the wiring diagram and these instructions when wiring. Improper connections and inadequate grounding can cause accidental injury or death.
- Ground the unit following local electrical codes.
- Connect all wiring tightly. Loose wiring may cause overheating at connection points and a possible fire hazard.
- Install a protective leakage breaker depending on the installation location (especially a damp or humid location). If a leakage breaker is not installed, electric shock can occur.

When Transporting

Be careful when picking up and moving the indoor and outdoor units. Get a partner to help, and bend your knees when lifting to reduce strain on your back. Sharp edges or thin aluminum fins on the air conditioner can cut your fingers.

When Installing

In a Ceiling or Wall

Make sure the ceiling/wall is strong enough to hold the unit's weight. It may be necessary to construct a strong wood or metal frame to provide added support.

In a Room

Properly insulate any tubing run inside a room to prevent "sweating" that can cause dripping and water damage to walls and floors.

In Moist or Uneven Locations

Use a raised concrete pad or concrete blocks to provide a solid, level foundation for the outdoor unit. This prevents water damage and abnormal vibration.

In an Area with High Winds

Securely anchor the outdoor unit down with bolts and a metal frame. Provide a suitable air baffle.

In a Snowy Area (for Heat Pump-type Systems)

Install the outdoor unit on a raised platform that is higher than drifting snow. Provide snow vents.

When Connecting Refrigerant Tubing

- Use the flare method for connecting tubing.
- Apply refrigerant lubricant to the matching surfaces of the flare and union tubes before connecting them, then tighten the nut with a torque wrench for a leak-free connection.
- Check carefully for leaks before starting the test run.

When Servicing

- Turn the power off at the main power box (mains) before opening the unit to check or repair electrical parts and wiring.
- Keep your fingers and clothing away from any moving parts.
- Clean up the site after you finish, remembering to check that no metal scraps or bits of wiring have been left inside the unit being serviced.

Others



CAUTION

- Ventilate any enclosed areas when installing or testing the refrigeration system. Escaped refrigerant gas, on contact with fire or heat, can produce dangerously toxic gas.
- Confirm upon completing installation that no refrigerant gas is leaking. If escaped gas comes in contact with a stove, gas water heater, electric room heater or other heat source, it can produce dangerously toxic gas.

Table of Contents

	Page
1. OPERATING RANGE	5
2. SPECIFICATIONS	
2-1. Unit Specifications	6
2-2. Major Component Specifications	9
2-3. Other Component Specifications	15
3. DIMENSIONAL DATA	16
4. REFRIGERANT FLOW DIAGRAM	
4-1. Refrigerant Flow Diagram	19
5. PERFORMANCE DATA	
5-1. Performance charts	20
5-2. Air Throw Distance Charts	23
5-3. Cooling Capacity	26
6. ELECTRICAL DATA	
6-1. Electrical Characteristics	29
6-2. Electric Wiring Diagrams	30
7. INSTALLATION INSTRUCTIONS	
7-1. Installation Site Selection	32
7-2. Recommended Wire Length and Diameter	34
7-3. Remote Control Unit Installation Position	35
7-4. How to Test Run the Air Conditioner	36
7-5. Removing and Installing the Grille	37
7-6. Address Setting of the Remote Control Unit	38
8. FUNCTIONS	
8-1. Room Temperature Control	39
8-2. Dry Operation (Dehumidification)	40
8-3. Freeze Prevention (Cooling and Dry)	41
8-4. Automatic Fan Speed (Cooling and Dry)	42

	Page
9. TROUBLESHOOTING	
9-1. Check before and after troubleshooting	43
9-2. Air conditioner does not operate.	44
9-3. Some part of air conditioner does not operate.	48
9-4. Air conditioner operates, but abnormalities are observed.	50
10. CHECKING ELECTRICAL COMPONENTS	
10-1. Measurement of Insulation Resistance	51
10-2. Checking Continuity of Fuse on PCB Ass'y	52
10-3. Checking Motor Capacitor	52
APPENDIX INSTRUCTION MANUAL	53

1. OPERATING RANGE

	Temperature	Indoor Air Intake Temp.	Outdoor Air Intake Temp.
Cooling	Maximum	32 °C D.B. / 23 °C W.B.	43 °C D.B.
	Minimum	19 °C D.B. / 14 °C W.B.	19 °C D.B.

2. SPECIFICATIONS

2-1. Unit Specifications

Indoor Unit **SAP-K77RAX**

Outdoor Unit **SAP-C77RAX**

Power Source		220 to 240V Single-Phase 50Hz	
Voltage Rating		220-240 V	
Performance		Cooling	
Capacity	kW	2.10 / 2.10 / 2.10	
	BTU/h	7,200 / 7,200 / 7,200	
Air Circulation (High)	m ³ /h	430	
Moisture Removal (High)	Liters/h	1.1	
Electrical Rating		Cooling	
Available Voltage Range	V	198 to 264	
Running Amperes	A	3.5 / 3.6 / 3.6	
Power Input	W	750 / 770 / 790	
Power Factor	%	97 / 93 / 91	
E.E.R.	W/W	2.80 / 2.73 / 2.66	
C.O.P.	W/W	-	
Compressor Locked Rotor Amperes	A	16.5	
Features			
Controls / Temperature Control		Microprocessor / I.C. Thermister	
Control Unit		Wireless Remote Control Unit	
Timer		12-Hour ON or OFF Timer, 1Hour OFF Timer	
Fan Speeds	Indoor / Outdoor	Auto and 3 steps / 1 (Hi)	
Airflow Direction (Indoor)	Horizontal	Manual	
	Vertical	Auto	
Air Filter		Washable, Anti-Mold	
Compressor		Single Rotary	
Refrigerant / Amount charged at shipment	kg	R22 / 0.48	
Refrigerant Control		Capillary tube	
Operation Sound	Indoor : Hi/Me/Lo	dB-A	38 / 33 / 30
	Outdoor : Hi	dB-A	49
Refrigerant Tubing Connections		Flare Type	
Max. allowable tubing length at shipment	m	5	
Refrigerant	Narrow tube	mm (in.)	6.35 (1/4)
Tube Diameter	Wide tube	mm (in.)	9.52 (3/8)
Refrigerant Tube Kit / Accessories		Optional / Air Clean Filter	
Dimensions & Weight		Indoor Unit	Outdoor Unit
Unit Dimensions	Height	mm	250
	Width	mm	799
	Depth	mm	205
Package Dimensions	Height	mm	270
	Width	mm	870
	Depth	mm	295
Weight	Net	kg	7.5
	Shipping	kg	9.0
Shipping Volume	m ³	0.06	0.13

DATA SUBJECT TO CHANGE WITHOUT NOTICE.

Remarks: Rating conditions are:

Cooling: Indoor air temperature 27°C D.B. / 19°C W.B.

Outdoor air temperature 35°C D.B. / 24°C W.B.

Indoor Unit **SAP-K97RAX**
 Outdoor Unit **SAP-C97RAX**

Power Source		220 to 240V Single-Phase 50Hz	
Voltage Rating		220-240 V	
Performance		Cooling	
Capacity	kW	2.55 / 2.55 / 2.55	
	BTU/h	8,700	
Air Circulation (High)	m ³ /h	440	
Moisture Removal (High)	Liters/h	1.8	
Electrical Rating		Cooling	
Available Voltage Range	V	198 to 264	
Running Amperes	A	4.5 / 4.5 / 4.6	
Power Input	W	930 / 960 / 1,000	
Power Factor	%	94 / 93 / 91	
E.E.R.	W/W	2.74 / 2.66 / 2.55	
C.O.P.	W/W	-	
Compressor Locked Rotor Amperes	A	22.5	
Features			
Controls / Temperature Control		Microprocessor / I.C. Thermister	
Control Unit		Wireless Remote Control Unit	
Timer		12-Hour ON or OFF Timer, 1Hour OFF Timer	
Fan Speeds	Indoor / Outdoor	Auto and 3 steps / 1 (Hi)	
Airflow Direction (Indoor)	Horizontal	Manual	
	Vertical	Auto	
Air Filter		Washable, Anti-Mold	
Compressor		Single Rotary	
Refrigerant / Amount charged at shipment	kg	R22 / 0.53	
Refrigerant Control		Capillary tube	
Operation Sound	Indoor : Hi/Me/Lo	dB-A	39 / 34 / 31
	Outdoor : Hi	dB-A	50
Refrigerant Tubing Connections		Flare Type	
Max. allowable tubing length at shipment	m	5	
Refrigerant	Narrow tube	mm (in.)	6.35 (1/4)
Tube Diameter	Wide tube	mm (in.)	9.52 (3/8)
Refrigerant Tube Kit / Accessories		Optional / Air Clean Filter	
Dimensions & Weight		Indoor Unit	Outdoor Unit
Unit Dimensions	Height	mm	250
	Width	mm	799
	Depth	mm	205
Package Dimensions	Height	mm	270
	Width	mm	870
	Depth	mm	295
Weight	Net	kg	7.5
	Shipping	kg	9.0
Shipping Volume	m ³	0.06	0.13

DATA SUBJECT TO CHANGE WITHOUT NOTICE.

Remarks: Rating conditions are:

Cooling: Indoor air temperature 27°C D.B. / 19°C W.B.

Outdoor air temperature 35°C D.B. / 24°C W.B.

Indoor Unit **SAP-K127RAX**
 Outdoor Unit **SAP-C127RAX**

Power Source		220 to 240V Single-Phase 50Hz	
Voltage Rating		220-240 V	
Performance		Cooling	
Capacity	kW	3.55 / 3.55 / 3.55	
	BTU/h	12,100 / 12,100 / 12,100	
Air Circulation (High)	m ³ /h	460	
Moisture Removal (High)	Liters/h	2.5	
Electrical Rating		Cooling	
Available Voltage Range	V	198 to 264	
Running Amperes	A	6.1 / 6.1 / 6.2	
Power Input	W	1,265 / 1,305 / 1,345	
Power Factor	%	94 / 93 / 90	
E.E.R.	W/W	2.81 / 2.72 / 2.64	
C.O.P.	W/W	-	
Compressor Locked Rotor Amperes	A	33.5	
Features			
Controls / Temperature Control		Microprocessor / I.C. Thermister	
Control Unit		Wireless Remote Control Unit	
Timer		12-Hour ON or OFF Timer, 1Hour OFF Timer	
Fan Speeds	Indoor / Outdoor	Auto and 3 steps / 1 (Hi)	
Airflow Direction (Indoor)	Horizontal	Manual	
	Vertical	Auto	
Air Filter		Washable, Anti-Mold	
Compressor		Single Rotary	
Refrigerant / Amount charged at shipment	kg	R22 / 0.72	
Refrigerant Control		Capillary tube	
Operation Sound	Indoor : Hi/Me/Lo	dB-A	
	(*Qt = Quiet mode) Outdoor : Hi	dB-A	
Refrigerant Tubing Connections		Flare Type	
Max. allowable tubing length at shipment	m	5	
Refrigerant	Narrow tube	mm (in.)	6.35 (1/4)
Tube Diameter	Wide tube	mm (in.)	12.70 (1/2)
Refrigerant Tube Kit / Accessories		Optional / Air Clean Filter	
Dimensions & Weight		Indoor Unit	Outdoor Unit
Unit Dimensions	Height	mm	250
	Width	mm	799
	Depth	mm	205
Package Dimensions	Height	mm	270
	Width	mm	870
	Depth	mm	295
Weight	Net	kg	7.5
	Shipping	kg	9.0
Shipping Volume	m ³	0.06	0.14

DATA SUBJECT TO CHANGE WITHOUT NOTICE.

Remarks: Rating conditions are:

Cooling: Indoor air temperature 27°C D.B. / 19°C W.B.

Outdoor air temperature 35°C D.B. / 24°C W.B.

2-2. Major Component Specifications

2-2-1. Indoor Unit

Indoor Unit **SAP-K77RAX**

Control PCB		
Part No.		CR-K77GAX
Controls		Microprocessor
Control Circuit Fuse		250V 3.15A
Remote Control Unit		RCS-7S2E-G
Fan		
Type		Cross-Flow
Q'ty ... Dia. and Length	mm	1 ... D102 / L637
Fan Motor		
Type		AC Motor
Model ... Q'ty		IBH-884-066B ... 1
No. of Poles		4
Rough Measure RPM (Cool)		1,280
Nominal Output	W	12.5
Coil Resistance	Ohm	BRN-WHT : 234 PNK (RED)-WHT : 209
Safety Device	Type	Thermal fuse
	Operating Temp. Open °C	130
	Close	-
Run Capacitor (on controller PCB)	Micro F	1.5
	VAC	450
Flap Motor		
Type		Stepping Motor
Model		24BYJ48-916
Rating		DC 12V
Coil Resistance	Ohm	Each Pair of Terminal : 200 +/- 7%
	(Ambient Temp. 25 °C)	
Heat Exchanger Coil		
Coil		Aluminum Plate Fin / Copper Tube
Rows		2
Fin Pitch	mm	1.3
Face Area	m ²	0.108

DATA SUBJECT TO CHANGE WITHOUT NOTICE.

Indoor Unit **SAP-K97RAX**

Control PCB	
Part No.	CR-K97GAX
Controls	Microprocessor
Control Circuit Fuse	250V 3.15A
Remote Control Unit	
RCS-7S2E-G	
Fan	
Type	Cross-Flow
Q'ty ... Dia. and Length	mm 1 ... D102 / L637
Fan Motor	
Type	AC Motor
Model ... Q'ty	IBH-884-066B ... 1
No. of Poles	4
Rough Measure RPM (Cool)	1,290
Nominal Output	W 12.5
Coil Resistance	Ohm BRN-WHT : 234 PNK (RED)-WHT : 209
Safety Device	Type Thermal fuse
Operating Temp.	Open °C 130
	Close -
Run Capacitor (on controller PCB)	Micro F 1.5
	VAC 450
Flap Motor	
Type	Stepping Motor
Model	24BYJ48-916
Rating	DC 12V
Coil Resistance	Ohm Each Pair of Terminal : 200 +/- 7%
(Ambient Temp. 25 °C)	
Heat Exchanger Coil	
Coil	Aluminum Plate Fin / Copper Tube
Rows	2
Fin Pitch	mm 1.3
Face Area	m ² 0.108

DATA SUBJECT TO CHANGE WITHOUT NOTICE.

Indoor Unit **SAP-K127RAX**

Control PCB	
Part No.	CR-K127GAX
Controls	Microprocessor
Control Circuit Fuse	250V 3.15A
Remote Control Unit	
RCS-7S2E-G	
Fan	
Type	Cross-Flow
Q'ty ... Dia. and Length	mm 1 ... D102 / L637
Fan Motor	
Type	AC Motor
Model ... Q'ty	IBH-884-066B ... 1
No. of Poles	4
Rough Measure RPM (Cool)	1,300
Nominal Output	W 12.5
Coil Resistance	Ohm BRN-WHT : 234 PNK (RED)-WHT : 209
Safety Device	Type Thermal fuse
Operating Temp.	Open °C 130
	Close -
Run Capacitor (on controller PCB)	Micro F 1.5
	VAC 450
Flap Motor	
Type	Stepping Motor
Model	24BYJ48-916
Rating	DC 12V
Coil Resistance	Ohm Each Pair of Terminal : 200 +/- 7%
(Ambient Temp. 25 °C)	
Heat Exchanger Coil	
Coil	Aluminum Plate Fin / Copper Tube
Rows	2
Fin Pitch	mm 1.1
Face Area	m ² 0.162

DATA SUBJECT TO CHANGE WITHOUT NOTICE.

2-2-2. Outdoor Unit

Outdoor Unit **SAP-C77RAX**

Control PCB		
Compressor		
Type		Single Rotary
Compressor Model / Nominal Output		C-1R65H5S / 650W
Compressor Oil ... Amount	CC	SAY-56T ... 350
Coil Resistance (Ambient Temp. 25 °C)	Ohm	C - R : 4.68 C - S : 6.77
Safety Device	Type	External (OLR)
	Overload Relay	MRA99094-9201
Operating Temp.	Open °C	150 +/-5
	Close °C	69 +/-11
Operating Amp. (Ambient Temp. 25 °C)		Trip in 6 to 16 sec. at 15A
Run Capacitor	Micro F	20
	VAC	400
Crankcase Heater		-
Fan		
Type		Propeller
Q'ty ... Dia.	mm	1 ... D320
Fan Motor		
Type		AC Motor
Model ... Q'ty		IB-976-501E ... 1
No. of Poles		6
Rough Measure RPM (Cool)		890
Nominal Output	W	25
Coil Resistance (Ambient Temp. 20 °C)	Ohm	BRN - WHT : 213 RED (PNK) - WHT : 168
Safety Device	Type	Thermal protector
Operating Temp.	Open °C	110
	Close °C	75
Run Capacitor	Micro F	2.0
	VAC	450
Heat Exchanger Coil		
Coil		Aluminum Plate Fin / Copper Tube
Rows		1
Fin Pitch	mm	1.4
Face Area	m ²	0.227
External Finish		Acrylic baked-on enamel finish

DATA SUBJECT TO CHANGE WITHOUT NOTICE.

Outdoor Unit **SAP-C97RAX**

Control PCB	
Compressor	
Type	Single Rotary
Compressor Model / Nominal Output	C-1RV162H91AA / 800W
Compressor Oil ... Amount	CC SAY-56T ... 280
Coil Resistance (Ambient Temp. 25 °C)	Ohm C - R : 3.65 C - S : 5.38
Safety Device	Type External (OLR)
Overload Relay	MRA99134-9201
Operating Temp.	Open °C 145 +/- 5
	Close °C 69 +/- 11
Operating Amp. (Ambient Temp. 25 °C)	Trip in 6 to 16 sec. at 16.5A
Run Capacitor	Micro F 25
	VAC 400
Crankcase Heater	-
Fan	
Type	Propeller
Q'ty ... Dia.	mm 1 ... D320
Fan Motor	
Type	AC Motor
Model ... Q'ty	IB-976-501E ... 1
No. of Poles	6
Rough Measure RPM (Cool)	900
Nominal Output	W 25
Coil Resistance (Ambient Temp. 20 °C)	Ohm BRN - WHT : 213 RED (PNK) - WHT : 168
Safety Device	Type Thermal protector
Operating Temp.	Open °C 110
	Close °C 75
Run Capacitor	Micro F 2.5
	VAC 450
Heat Exchanger Coil	
Coil	Aluminum Plate Fin / Copper Tube
Rows	1
Fin Pitch	mm 1.3
Face Area	m ² 0.301
External Finish	Acrylic baked-on enamel finish

DATA SUBJECT TO CHANGE WITHOUT NOTICE.

Outdoor Unit **SAP-C127RAX**

Control PCB	
Compressor	
Type	Single Rotary
Compressor Model / Nominal Output	C-R115H5A / 1,100W
Compressor Oil ... Amount	CC SAY-56T ... 520
Coil Resistance (Ambient Temp. 25 °C)	Ohm C - R : 1.962 C - S : 5.38
Safety Device	Type External (OLR)
	Overload Relay MRA98619-9200
Operating Temp.	Open °C 150 +/- 5
	Close °C 69 +/- 11
Operating Amp. (Ambient Temp. 25 °C)	Trip in 6 to 16 sec. at 22.5A
Run Capacitor	Micro F 25
	VAC 400
Crankcase Heater	-
Fan	
Type	Propeller
Q'ty ... Dia.	mm 1 ... D380
Fan Motor	
Type	AC Motor
Model ... Q'ty	IB-976-501E ... 1
No. of Poles	6
Rough Measure RPM (Cool)	840
Nominal Output	W 25
Coil Resistance (Ambient Temp. 20 °C)	Ohm BRN - WHT : 213 RED (PNK) - WHT : 168
Safety Device	Type Thermal protector
Operating Temp.	Open °C 110
	Close °C 75
Run Capacitor	Micro F 2.5
	VAC 450
Heat Exchanger Coil	
Coil	Aluminum Plate Fin / Copper Tube
Rows	1
Fin Pitch	mm 1.3
Face Area	m ² 0.346
External Finish	Acrylic baked-on enamel finish

DATA SUBJECT TO CHANGE WITHOUT NOTICE.

2-3. Other Component Specifications

Indoor Unit **SAP-K77RAX**
SAP-K97RAX
SAP-K127RAX

< Thermistor (Room sensor) >

Model	PTN-41G-S6Z
Resistance	5 kohm (at 25 °C)

< Thermistor (Coil sensor) >



Model	PB2M-41E-S16-1
Resistance	15 kohm (at 0 °C) 5.4 kohm (at 25 °C)

Outdoor Unit **SAP-C77RAX**
SAP-C97RAX
SAP-C127RAX

< Power Relay >




Model	EL200/240A1-F (M)
Rating	AC277V 30A

Outdoor Unit **SAP-C77RAX**
SAP-C97RAX



Unit: mm

Outdoor Unit **SAP-C127RAX**




Unit: mm

4. REFRIGERANT FLOW DIAGRAM

4-1. Refrigerant Flow Diagram

Indoor Unit
SAP-K77RAX
SAP-K97RAX
SAP-K127RAX

Outdoor Unit
SAP-C77RAX
SAP-C97RAX
SAP-C127RAX



Insulation of Refrigerant Tubing


IMPORTANT

Because capillary tubing is used in the outdoor unit, both the wide and narrow tubes of this air conditioner become cold. To prevent heat loss and wet floors due to dripping of condensation, **both tubes must be well insulated** with a proper insulation material. The thickness of the insulation should be a min. 8 mm.



CAUTION

After a tube has been insulated, never try to bend it into a narrow curve because it can cause the tube to break or crack.





5. PERFORMANCE DATA

5-1. Performance charts

Indoor Unit **SAP-K77RAX**

Outdoor Unit **SAP-C77RAX**

< Cooling Characteristics >





NOTE

●:Points of rating condition
 Black dots in above charts indicate the following rating conditions.
 Cooling: Indoor air temperature 27 °C D.B. / 19 °C W.B.
 Outdoor air temperature 35 °C D.B. / 24 °C W.B.

Indoor Unit **SAP-K97RAX**
 Outdoor Unit **SAP-C97RAX**

< Cooling Characteristics >





NOTE

●:Points of rating condition
 Black dots in above charts indicate the following rating conditions.
 Cooling: Indoor air temperature 27 °C D.B. / 19 °C W.B.
 Outdoor air temperature 35 °C D.B. / 24 °C W.B.

Indoor Unit **SAP-K127RAX**
 Outdoor Unit **SAP-C127RAX**

< Cooling Characteristics >



NOTE

●:Points of rating condition
 Black dots in above charts indicate the following rating conditions.
 Cooling: Indoor air temperature 27 °C D.B. / 19 °C W.B.
 Outdoor air temperature 35 °C D.B. / 24 °C W.B.


5-2. Air Throw Distance Charts

Indoor Unit SAP-K77RAX

Cooling

Room air temp. : 27°C


Fan speed : High



Cooling

Room air temp. : 27°C


Fan speed : High



Cooling

Room air temp. : 27°C

Fan speed : High



5-3. Cooling Capacity

Indoor Unit **SAP-K77RAX**

Outdoor Unit **SAP-C77RAX**

230 V Single Phase 50 Hz

RATING CAPACITY		2.10 kW						
AIR FLOW RATE		430 m ³ /h						
EVAPORATOR		CONDENSER						
ENT. TEMP. °C		OUTDOOR AMBIENT TEMP. °C						
W.B.	D.B.		20	25	30	35	40	43
15		TC	2.12	2.02	1.93	1.84	1.73	1.59
		CM	0.53	0.57	0.61	0.66	0.70	0.74
	21	SHC	1.51	1.46	1.42	1.38	1.32	1.26
	23	SHC	1.72	1.67	1.63	1.58	1.53	1.47
	25	SHC	1.93	1.88	1.84	1.79	1.73	1.59
	27	SHC	2.12	2.02	1.93	1.84	1.73	1.59
	29	SHC	2.12	2.02	1.93	1.84	1.73	1.59
17		TC	2.27	2.17	2.07	1.97	1.86	1.71
		CM	0.54	0.59	0.63	0.68	0.72	0.76
	21	SHC	1.29	1.25	1.20	1.16	1.11	1.05
	23	SHC	1.50	1.46	1.41	1.37	1.32	1.25
	25	SHC	1.71	1.67	1.62	1.58	1.53	1.46
	27	SHC	1.92	1.87	1.83	1.79	1.74	1.67
	29	SHC	2.13	2.08	2.04	1.97	1.86	1.71
19		TC	2.42	2.31	2.21	# 2.10	1.97	1.82
		CM	0.56	0.61	0.65	0.70	0.74	0.78
	21	SHC	1.07	1.02	0.98	0.94	0.89	0.82
	23	SHC	1.28	1.23	1.19	1.15	1.10	1.03
	25	SHC	1.49	1.44	1.40	1.36	1.31	1.24
	27	SHC	1.70	1.65	1.61	1.56	1.51	1.45
	29	SHC	1.90	1.86	1.82	1.77	1.72	1.66
21		TC	2.56	2.45	2.34	2.23	2.09	1.93
		CM	0.58	0.62	0.67	0.72	0.76	0.81
	23	SHC	1.05	1.01	0.97	0.92	0.87	0.81
	25	SHC	1.26	1.22	1.17	1.13	1.08	1.02
	27	SHC	1.47	1.43	1.38	1.34	1.29	1.23
	29	SHC	1.68	1.64	1.59	1.55	1.50	1.44
23		TC	2.72	2.60	2.48	2.34	2.19	2.03
		CM	0.59	0.64	0.69	0.74	0.78	0.83
	25	SHC	1.02	0.98	0.94	0.89	0.84	0.79
	27	SHC	1.23	1.19	1.15	1.10	1.05	1.00
	29	SHC	1.44	1.40	1.36	1.31	1.26	1.21
	31	SHC	1.65	1.61	1.57	1.52	1.47	1.41

TC : Total Cooling Capacity (kW)

SHC : Sensible Heat Capacity (kW)

CM : Compressor Input (kW)

Rating conditions (#Mark) are

Outdoor Ambient Temp. 35 °C D.B.

Indoor Unit Entering Air Temp. 27 °C D.B. / 19 °C W.B.

Indoor Unit **SAP-K97RAX**

Outdoor Unit **SAP-C97RAX**

230 V Single Phase 50 Hz

RATING CAPACITY		2.55 kW						
AIR FLOW RATE		440 m ³ /h						
EVAPORATOR		CONDENSER						
ENT. TEMP. °C		OUTDOOR AMBIENT TEMP. °C						
W.B.	D.B.		20	25	30	35	40	43
15		TC	2.57	2.46	2.35	2.23	2.10	1.93
		CM	0.67	0.73	0.78	0.84	0.95	1.07
	21	SHC	1.74	1.69	1.63	1.57	1.51	1.43
	23	SHC	1.96	1.90	1.84	1.79	1.72	1.64
	25	SHC	2.17	2.11	2.06	2.00	1.93	1.85
	27	SHC	2.38	2.33	2.27	2.21	2.10	1.93
	29	SHC	2.57	2.46	2.35	2.23	2.10	1.93
17		TC	2.76	2.64	2.52	2.40	2.25	2.07
		CM	0.69	0.75	0.80	0.86	0.98	1.09
	21	SHC	1.53	1.47	1.41	1.36	1.29	1.21
	23	SHC	1.74	1.68	1.62	1.57	1.50	1.42
	25	SHC	1.95	1.89	1.84	1.78	1.72	1.64
	27	SHC	2.17	2.11	2.05	1.99	1.93	1.85
	29	SHC	2.38	2.32	2.26	2.21	2.14	2.06
19		TC	2.93	2.81	2.68	# 2.55	2.40	2.21
		CM	0.71	0.77	0.83	0.89	1.00	1.12
	21	SHC	1.30	1.24	1.18	1.13	1.06	0.98
	23	SHC	1.51	1.45	1.40	1.34	1.28	1.20
	25	SHC	1.72	1.67	1.61	1.55	1.49	1.41
	27	SHC	1.94	1.88	1.82	1.77	1.70	1.62
	29	SHC	2.15	2.09	2.03	1.98	1.91	1.83
21		TC	3.11	2.97	2.84	2.70	2.54	2.34
		CM	0.73	0.79	0.85	0.91	1.03	1.15
	23	SHC	1.28	1.22	1.16	1.11	1.05	0.97
	25	SHC	1.49	1.43	1.38	1.32	1.26	1.18
	27	SHC	1.70	1.65	1.59	1.54	1.47	1.39
	29	SHC	1.92	1.86	1.80	1.75	1.68	1.61
23		TC	3.30	3.16	3.01	2.84	2.66	2.47
		CM	0.75	0.81	0.87	0.94	1.06	1.18
	25	SHC	1.24	1.19	1.13	1.07	1.00	0.94
	27	SHC	1.46	1.40	1.34	1.28	1.22	1.15
	29	SHC	1.67	1.61	1.56	1.50	1.43	1.36
	31	SHC	1.88	1.83	1.77	1.71	1.64	1.58

TC : Total Cooling Capacity (kW)

SHC : Sensible Heat Capacity (kW)

CM : Compressor Input (kW)

Rating conditions (#Mark) are

Outdoor Ambient Temp. 35 °C D.B.

Indoor Unit Entering Air Temp. 27 °C D.B. / 19 °C W.B.

Indoor Unit **SAP-K127RAX**
 Outdoor Unit **SAP-C127RAX**

230 V Single Phase 50 Hz

RATING CAPACITY		3.55 kW						
AIR FLOW RATE		460 m ³ /h						
EVAPORATOR		CONDENSER						
ENT. TEMP. °C		OUTDOOR AMBIENT TEMP. °C						
W.B.	D.B.		20	25	30	35	40	43
15		TC	3.58	3.42	3.27	3.11	2.92	2.69
		CM	0.92	1.00	1.07	1.15	1.33	1.51
	21	SHC	2.34	2.25	2.16	2.08	1.98	1.86
	23	SHC	2.57	2.49	2.40	2.31	2.21	2.10
	25	SHC	2.81	2.72	2.64	2.55	2.45	2.33
	27	SHC	3.05	2.96	2.87	2.79	2.69	2.57
	29	SHC	3.29	3.20	3.11	3.03	2.92	2.69
17		TC	3.84	3.67	3.50	3.34	3.14	2.89
		CM	0.95	1.03	1.10	1.18	1.36	1.54
	21	SHC	2.10	2.01	1.92	1.83	1.74	1.61
	23	SHC	2.33	2.24	2.16	2.07	1.97	1.85
	25	SHC	2.57	2.48	2.40	2.31	2.21	2.09
	27	SHC	2.81	2.72	2.63	2.55	2.45	2.33
	29	SHC	3.05	2.96	2.87	2.79	2.69	2.57
19		TC	4.08	3.91	3.73	# 3.55	3.34	3.07
		CM	0.98	1.06	1.13	1.22	1.40	1.58
	21	SHC	1.84	1.75	1.66	1.58	1.48	1.36
	23	SHC	2.07	1.99	1.90	1.81	1.72	1.60
	25	SHC	2.31	2.22	2.14	2.05	1.95	1.83
	27	SHC	2.55	2.46	2.37	2.29	2.19	2.07
	29	SHC	2.79	2.70	2.61	2.53	2.43	2.31
21		TC	4.33	4.14	3.95	3.76	3.54	3.25
		CM	1.01	1.09	1.16	1.25	1.44	1.62
	23	SHC	1.81	1.72	1.64	1.55	1.46	1.34
	25	SHC	2.05	1.96	1.87	1.79	1.69	1.58
	27	SHC	2.28	2.20	2.11	2.03	1.93	1.81
	29	SHC	2.52	2.43	2.35	2.27	2.17	2.05
23		TC	4.59	4.39	4.19	3.95	3.70	3.44
		CM	1.03	1.12	1.19	1.28	1.47	1.66
	25	SHC	1.76	1.68	1.59	1.50	1.40	1.30
	27	SHC	2.00	1.92	1.83	1.73	1.63	1.53
	29	SHC	2.24	2.15	2.07	1.97	1.87	1.77
		SHC	2.48	2.39	2.30	2.21	2.11	2.01

TC : Total Cooling Capacity (kW)

SHC : Sensible Heat Capacity (kW)

CM : Compressor Input (kW)

Rating conditions (#Mark) are

Outdoor Ambient Temp. 35 °C D.B.

Indoor Unit Entering Air Temp. 27 °C D.B. / 19 °C W.B.

6. ELECTRICAL DATA

6-1. Electrical Characteristics

Indoor Unit **SAP-K77RAX**

Outdoor Unit **SAP-C77RAX**

Cooling

			Indoor Unit	Outdoor Unit		Complete Unit
			Fan Motor	Fan Motor	Compressor	
Performance at			230V Single-phase 50Hz			
Rating Conditions	Running amp.	A	0.17	0.22	3.21	3.60
	Power input	kW	0.028	0.045	0.697	0.770
Full Load Conditions	Running amp.	A	0.17	0.22	3.71	4.10
	Power input	kW	0.028	0.045	0.827	0.900

Rating conditions: Indoor air temperature: 27 °C D.B. / 19 °C W.B.

Outdoor air temperature: 35 °C D.B.

Full Load conditions: Indoor air temperature: 32 °C D.B. / 23 °C W.B.

Outdoor air temperature: 43 °C D.B.

Indoor Unit **SAP-K97RAX**

Outdoor Unit **SAP-C97RAX**

Cooling

			Indoor Unit	Outdoor Unit		Complete Unit
			Fan Motor	Fan Motor	Compressor	
Performance at			230V Single-phase 50Hz			
Rating Conditions	Running amp.	A	0.17	0.27	4.11	4.55
	Power input	kW	0.028	0.057	0.887	0.972
Full Load Conditions	Running amp.	A	0.17	0.27	5.41	5.85
	Power input	kW	0.028	0.057	1.177	1.262

Rating conditions: Indoor air temperature: 27 °C D.B. / 19 °C W.B.

Outdoor air temperature: 35 °C D.B.

Full Load conditions: Indoor air temperature: 32 °C D.B. / 23 °C W.B.

Outdoor air temperature: 43 °C D.B.

Indoor Unit **SAP-K127RAX**

Outdoor Unit **SAP-C127RAX**

Cooling

			Indoor Unit	Outdoor Unit		Complete Unit
			Fan Motor	Fan Motor	Compressor	
Performance at			230V Single-phase 50Hz			
Rating Conditions	Running amp.	A	0.17	0.27	5.66	6.10
	Power input	kW	0.028	0.062	1.215	1.305
Full Load Conditions	Running amp.	A	0.17	0.27	7.56	8.00
	Power input	kW	0.028	0.062	1.660	1.750

Rating conditions: Indoor air temperature: 27 °C D.B. / 19 °C W.B.

Outdoor air temperature: 35 °C D.B.

Full Load conditions: Indoor air temperature: 32 °C D.B. / 23 °C W.B.

Outdoor air temperature: 43 °C D.B.


6-2. Electric Wiring Diagrams

Indoor Unit **SAP-K77RAX**
 SAP-K97RAX
 SAP-K127RAX



WARNING

To avoid electrical shock hazard, be sure to disconnect power before checking, servicing and/or cleaning any electrical parts.




8FA2-5250-29500-1

Outdoor Unit **SAP-C77RAX**
SAP-C97RAX
SAP-C127RAX



WARNING

To avoid electrical shock hazard, be sure to disconnect power before checking, servicing and/or cleaning any electrical parts.



8FA2-5250-29800-0

7. INSTALLATION INSTRUCTIONS

7-1. Installation Site Selection

7-1-1. Indoor Unit



WARNING


To prevent abnormal heat generation and the possibility of fire, do not place obstacles, enclosures and grilles in front of or surrounding the air conditioner in a way that may block air flow.

AVOID:

- direct sunlight.
- nearby heat sources that may affect performance of the unit.
- areas where leakage of flammable gas may be expected.
- places where large amounts of oil mist exist.

DO:

- select an appropriate position from which every corner of the room can be uniformly cooled. (High on a wall is best.)
- select a location that will hold the weight of the unit.
- select a location where tubing and drain hose have the shortest run to the outside.
- allow room for operation and maintenance as well as unrestricted air flow around the unit. (Fig. 1)
- install the unit within the maximum elevation difference (H) above or below the outdoor unit and within a total tubing length (L) from the outdoor unit as detailed in Table 1 and Fig. 2.



Front View

Fig. 1




Fig. 2



CAUTION

For stable operation of the air conditioner, do not install wall-mounted type indoor units less than 1.5 m from floor level.




Fig. 3

Table 1

Model	Max. Allowable Tubing Length at Shipment (m)	Limit of Tubing Length (L) (m)	Limit of Elevation Difference (H) (m)	Required Amount of Additional Refrigerant (g/m)*
K77 / 97	5	15	5	15
K127	5	20	5	20

* If total tubing length becomes a) 5 to 15 m (Max.), b) 5 to 20 m (Max.), charge additional refrigerant (R22) by a) 15 g/m, b) 20 g/m. No additional charge of compressor oil is necessary.

7-1-2. Outdoor Unit

AVOID:

- heat sources, exhaust fans, etc. (Fig. 4)
- damp, humid or uneven locations.

DO:

- choose a place as cool as possible.
- choose a place that is well ventilated.
- allow enough room around the unit for air intake/exhaust and possible maintenance. (Fig. 5a)
- provide a solid base (level concrete pad, concrete block, 10 × 40 cm beams or equal), a minimum of 10 cm above ground level to reduce humidity and protect the unit against possible water damage and decreased service life. (Fig. 5b)
- Install cushion rubber under unit's feet to reduce vibration and noise. (Fig. 5c)
- use lug bolts or equal to bolt down unit, reducing vibration and noise.
- Install in a location where no antenna of a television or radio exists within 3 meters.




Fig. 4




Fig. 5a




Fig. 5b




Fig. 5c

7-2. Recommended Wire Length and Diameter

Regulations on wiring diameter differ from locality to locality. For field wiring requirements, please refer to your local electrical codes. Carefully observe these regulations when carrying out the installation.

Table 2 lists recommended wire lengths and diameters for power supply systems.

NOTE

Refer to the wiring system diagram (Fig. 6) for the meaning of (A) and (B) in Table 2.

Table 2

Model	Cross-Sectional Area (mm ²)	(A) Power Supply Wiring Length (m)	(B) Power Line Length (m)	Fuse or Circuit Breaker Capacity
	(A) + (B)	(A)	(B)	
C77 / 97	2	3.5	51	10A
C127	33	41	27	



WARNING

- Be sure to comply with local codes on running the wire from the indoor unit to the outdoor unit (size of wire and wiring method, etc.).
- Each wire must be firmly connected.
- No wire should be allowed to touch refrigerant tubing, the compressor, or any moving part.



WARNING

- To avoid the risk of electrical shock, each air conditioner unit must be grounded.



CAUTION

- Be sure to connect the power supply line to the outdoor unit as shown in the wiring diagram. The indoor unit draws its power from the outdoor unit.

WIRING SYSTEM DIAGRAM




Fig. 6

7-3. Remote Control Unit Installation Position

The remote control unit can be operated from either a non-fixed position or a wall-mounted position.

To ensure that the air conditioner operates correctly, do not install the remote control unit in the following places:

- In direct sunlight
- Behind a curtain or other place where it is covered
- More than 8 m away from the air conditioner
- In the path of the air conditioner's airstream
- Where it may become extremely hot or cold
- Where it may be subject to electrical or magnetic interference
- Where there is an obstacle between the remote control unit and the air conditioner (since a check signal is sent from the remote control unit every 5 minutes)

7-3-1. Mounting on a Wall

Before mounting the remote control unit, press the ON/OFF operation button at the mounting location to make sure that the air conditioner operates from that location. The indoor unit should make a beeping sound to indicate that it has received the signal.




Fig. 7

7-4. How to Test Run the Air Conditioner

After turning on the power of the air conditioner, use the remote controller and follow the steps below to conduct the test run.

- (1) Set the remote controller in Test Run mode. (Fig. 8a)
 - a) Press and hold the ECONOMY button and the 1HR. TIMER button.
 - b) Then press and hold the ACL (Reset) button with a pointed object such as the tip of a pen. After 5 seconds, release the ACL button first.
 - c) Then release the ECONOMY and 1HR. TIMER buttons.
 - d) "◀" for ⌘ appears and "P1" blinking in the remote controller display area. (Fig. 8b)
- (2) Start Cooling mode test run by pressing the ON/OFF operation button of the remote controller. (Fig. 8a)
 - This starts the fan producing uncooled forced air with the 2 indicator lamps (OPERATION lamp and TIMER lamp) on the main unit blinking. (Fig. 8c)
 - After 3 minutes, the system shifts into cooling operation, and cool air will start to be felt. Cooling mode test run is unaffected by the room temperature.
- (3) Press the ON/OFF operation button of the remote controller again to stop the test run. (Fig. 8a)
- (4) Finally press the ACL (Reset) button of the remote controller to release it from Test Run mode to return to normal mode. (Fig. 8a)
 - "◀" for ⌘ and "P1" will disappear from the remote controller display area.

IMPORTANT

After the test run is completed, be sure to press the ACL (Reset) button to return to normal mode. The air conditioner will not operate correctly if this is not done.




Fig. 8a



Fig. 8b




Fig. 8c

7-5. Removing and Installing the Grille

Basically, these models can be installed and wired without removing the grille. If access to any internal part is needed, follow the steps as given below.

How to remove the grille

- (1) Open the front panel until it is nearly horizontal, grasp the sections near the front panel arms on both sides, and then remove the panel by pushing the arms towards the outside while pulling the panel towards you. (Fig. 9)
- (2) Lift the anti-mold filter up slightly to disengage the protrusions from the hooks on the unit, and then pull downward to remove the filter from the unit. (Fig. 9)
- (3) Remove the 4 screws. Grasp the grille on both bottom sides, and pull it towards you slightly. (Fig. 10)
- (4) Press the 2 tabs on the top of the grille to disengage them. (Fig. 10)
- (5) Pull the grille towards you to remove it. (Fig. 10)




Fig. 9




Fig. 10

How to replace the grille

- (1) Insert the bottom of the grille into the frame.
- (2) While aligning both edges of the grille with the frame, move the grille horizontally and insert the top and bottom into the frame.
- (3) Press the grille firmly with your hand to ensure no gap exists between the frame and grille.
- (4) Tighten the 4 screws.
- (5) Grasp the sections near the front panel arms on both sides, and hold the front panel so that it is nearly horizontal. Push the arm shafts towards the outside so that they come into contact with the top of the indentations on the right and left sides of the air conditioner. Then push firmly until the arm shafts click into place. (Fig. 11)
- (6) Insert the top of the anti-mold filter, and then fit the protrusions on the bottom of the filter all the way into the hooks on the unit.
- (7) After closing the front panel, press firmly on the parts indicated by the arrows to securely fasten the panel in place. (Fig. 12)




Fig. 11




Fig. 12

NOTE

Check that no gap exists between the frame and the grille.


7-6. Address Setting of the Remote Control Unit

The address can be set in order to prevent interference between remote controllers when 2 indoor units are installed near each other. To set a different address, it is necessary to change the address on the second remote controller.

NOTE

Once changed, you cannot restore the original address setting of the air conditioner.


- (1) Switch on the power source.
- (2) Slide the rear cover of the remote control unit, and cut the jumper wire for address switching using a nipper then draw away the cut wires to prevent short circuit. Slide back the rear cover. When the wire is cut, the address is automatically set to a different address (Fig. 13).
- (3) Press and hold the remote controller ECONOMY button and 1HR. TIMER button. Then, press and hold the ACL (Reset) button with a pointed object such as the tip of a pen. After 5 seconds, release the ACL button first, then release the ECONOMY and 1HR. TIMER buttons. "P1" (Test Run) appears, blinking in the remote controller display area.
- (4) Each time the 1HR. TIMER button is pressed, the display changes as shown below. Press this button 2 times to change the display to "P7" (Address Setting).



- (5) "P7" has now been selected for address setting.
- (6) Press the ON/OFF operation button on the remote controller. (Fig. 14) Check that the "beep" signal-received sound is heard from the second indoor unit (approximately 5 times). The sound you hear is the signal that the remote controller address has been changed.
- (7) Finally press the remote controller ACL (Reset) button to cancel the blinking "P7" display. (Fig. 14)

Changing of the second remote controller address is now completed.

Jumper wire for address switching



Slide the cover

Fig. 13




Fig. 14


8. FUNCTIONS

8-1. Room Temperature Control

(1) Cooling

- Room temperature control is obtained by cycling the compressor ON and OFF under control of the room temperature sensor in the indoor unit.


NOTE Some informations except for the room temperature are transmitted every 5 minutes by the remote control unit to the controller in the indoor unit.



- Once the compressor starts, it keeps running for 5 minutes.
- Once the compressor stops, it will not start running again for 3 minutes.
- Thermo. ON : When room temperature rises 1°C above the set temperature $T^{\circ}\text{C}$, the compressor turns ON.
- Thermo. OFF : When the room temperature falls below the set temperature $T^{\circ}\text{C}$, the compressor turns OFF.

8-2. Dry Operation (Dehumidification)

- Dry operation uses the ability of the cooling cycle to remove moisture from the air, but by running at low level to dehumidify without greatly reducing the room temperature. The air conditioner repeats the cycle of turning ON and OFF automatically as shown in the chart below according to the room temperature.




NOTE

- Intermittent ventilation occurs by switching the indoor fan speed between L and LL.
- DRY operation does not occur when the room temperature is 15°C or less, which is the monitor zone.
- When the compressor stops, the indoor fan stops as well.

8-3. Freeze Prevention (Cooling and Dry)


- This function prevents freezing of the indoor heat exchange coil.
- When the temperature of the indoor heat exchange coil falls below 2 °C for 2 minutes, the control circuit stops the outdoor fan and compressor (The compressor stops 3 seconds after the outdoor fan stopped). During this period, Indoor fan operates in LL. The outdoor fan does not start again until the temperature rises above 6°C. (The compressor starts 2 seconds after the outdoor fan started.)



8-4. Automatic Fan Speed (Cooling and Dry)


- This automatically adjust the indoor fan speed by the difference between the room temperature and set temperature.

< Cooling >



9. TROUBLESHOOTING

9-1. Check before and after troubleshooting




WARNING

Hazardous voltage can cause **ELECTRIC SHOCK** or **DEATH**. Disconnect power or turn off circuit breaker before you start checking or servicing.

9-1-1. Check power supply wiring.

- Check that power supply wires are correctly connected to terminals **L** and **N** on the terminal plate in the outdoor unit.



9-1-2. Check inter-unit wiring.

- Check that inter-unit wiring is correctly connected between indoor unit and outdoor unit.

9-1-3. Check power supply.

- Check that voltage is in specified range ($\pm 10\%$ of the rating).
- Check that power is being supplied.

9-1-4. Check lead wires and connectors in indoor and outdoor units.

- Check that coating of lead wires is not damaged.
- Check that lead wires and connectors are firmly connected.
- Check that wiring is correct.

9-2. Air conditioner does not operate.

9-2-1. Circuit breaker trips (or fuse blows).

(1) When the circuit breaker is set to ON, it is tripped soon. (Resetting is not possible.)

< Failure Cause >

- There is a possibility of ground fault.
- There is a possibility of insulation fault.

< Identification Method of the Failure Cause >

Identify the failure cause using the following procedure.



WARNING

Turn off the circuit breaker and disconnect the power supply wiring to prevent the electric shock or damage to any measuring instrument.

< Check outdoor unit >

1. Turn off the circuit breaker and disconnect the power supply wiring. Fig. 1
2. Disconnect the inter-unit wiring from the outdoor unit terminal plate. Fig. 1
3. Measure insulation resistance of outdoor unit.

Does the insulation resistance read 2M ohm or more ?

No

1. Insulation of outdoor unit is defective.
2. And measure insulation resistance of electrical parts in outdoor unit to specify the insulation fault.

< Check indoor unit >

1. Turn off the circuit breaker and disconnect the power supply wiring. Fig. 1
2. Disconnect the inter-unit wiring from the indoor unit terminal plate. Fig. 1
3. Measure insulation resistance of indoor unit.

Does the insulation resistance read 2M ohm or more ?

No

1. Insulation of indoor unit is defective.
2. And measure insulation resistance of electrical parts in indoor unit to specify the insulation fault.








Fig.1

(2) Circuit breaker trips in several minutes after turning the air conditioner on.

- There is a possibility of short circuit.




In case of Heating operation :




9-2-2. Neither indoor nor outdoor unit runs.

- (1) Power is not supplied.**




(2) Check remote control unit.



In the case that the remote control transmission section is dirty, clean it.

In the case that the remote control reception section in front of indoor unit is dirty, clean it.

(3) Check fuse on the indoor P.C.Board.




(4) Check TIMER on the remote control unit.



9-2-3. Only outdoor unit does not run.


(1) Check setting temperature.

COOL




9-3. Some part of air conditioner does not operate.


9-3-1. Only indoor fan does not run.




9-3-2. Only flap motor does not run.



9-3-3. Only outdoor fan does not run.




9-3-4. Only compressor does not run.




9-4. Air conditioner operates, but abnormalities are observed.

9-4-1. Poor cooling.



9-4-2. Excessive cooling.



10. CHECKING ELECTRICAL COMPONENTS

10-1. Measurement of Insulation Resistance

- The insulation is in good condition if the resistance exceeds 2M ohm.

10-1-1. Power Supply Cord

Clamp the grounding wire of power cord with the lead clip of the insulation resistance tester and measure the resistance by placing a probe on either of the two power wires. (Fig. 1)

Then also measure the resistance between the grounding and other power wire. (Fig. 1)




Fig. 1

10-1-2. Indoor Unit

Clamp an aluminum plate fin or copper tube with the lead clip of the insulation resistance tester and measure the resistance by placing a probe on each terminal screw on the terminal plate. (Fig. 2)

Note that the ground line terminal should be skipped for the check.




Fig. 2

10-1-3. Outdoor Unit

Clamp a metallic part of the unit with the lead clip of the insulation resistance tester and measure the resistance by placing a probe on each terminal screw where power supply lines are connected on the terminal plate. (Fig. 2)

10-1-4. Measurement of Insulation Resistance for Electrical Parts

Disconnect the lead wires of the desired electric part from terminal plate, capacitor, etc. Similarly disconnect the connector. Then measure the insulation resistance. (Figs. 3 and 4)

NOTE

Refer to Electric Wiring Diagram.

If the probe cannot enter the poles because the hole is too narrow then use a probe with a thinner pin.




Fig. 3




Fig. 4

10-2. Checking Continuity of Fuse on PCB Ass'y

- Remove the PCB Ass'y from the electrical component box. Then pull out the fuse from the PCB Ass'y. (Fig. 5)
- Check for continuity using a multimeter as shown in Fig. 6.




Fig. 5

10-3. Checking Motor Capacitor

Remove the lead wires from the capacitor terminals, and then place a probe on the capacitor terminals as shown in Fig. 7. Observe the deflection of the pointer, setting the resistance measuring range of the multimeter to the maximum value.

The capacitor is “good” if the pointer bounces to a great extent and then gradually returns to its original position.

The range of deflection and deflection time differ according to the capacity of the capacitor.




Fig. 6




Fig. 7

APPENDIX INSTRUCTION MANUAL

SAP-K77GAX + SAP-C77GAX
SAP-K97GAX + SAP-C97GAX
SAP-K127GAX + SAP-C127GAX

(OI-852-6-4181-018-00-1)

FEATURES

This air conditioner is equipped with cooling, and drying functions. Details on these functions are provided below; refer to these descriptions when using the air conditioner.

- **Microprocessor Controlled Operation**
The interior compartment of the remote control unit contains several features to facilitate automatic operation, easy logically displayed for easy use.
- **Simple One-touch Wireless Remote Control**
The remote control unit has several features to facilitate automatic operation.
- **12-Hour ON or OFF Timer**
This timer can be set to automatically turn the unit on or off at any time within a 12 hour period.
- **1-Hour OFF Timer**
This timer can be set to automatically turn off the unit at any time after one hour.
- **Economy**
This function saves energy by controlling operation to provide a quieter operating sound than normal.
- **Automatic and 3-step Fan Speed**
Auto/High/Medium/Low
- **Air Sweep Control**
This function moves a flap up and down in the air outlet, directing air in a sweeping motion around the room and providing comfort in every corner.
- **Auto. Flap Control**
This automatically sets the flap to the optimum position during cooling and drying operation.
- **Automatic Restart Function for Power Failure**
Even when power failure occurs, preset programmed operation can be reactivated once power resumes.
- **Anti-Mold Filter**
This unit is equipped with an anti-mold filter that inhibits the growth of mold and bacteria.
- **Air Clean Filter**
An air filter that eliminates unpleasant odors and cleans the air is available.
Purchase a replacement filter at your local dealer.
(model **STK-FWWB**)

CONTENTS

	Page
FEATURES	2
PRODUCT INFORMATION	3
ALERT SYMBOLS	3
INSTALLATION LOCATION	3
ELECTRICAL REQUIREMENTS.....	3
SAFETY INSTRUCTIONS	3
NAMES OF PARTS.....	4
USING THE REMOTE CONTROL UNIT	8
OPERATION WITH THE REMOTE CONTROL UNIT	9
1. Operation.....	9
2. Adjusting the Fan Speed	9
3. Fan Only	9
4. ECONOMY Mode.....	10
SPECIAL REMARKS.....	10
USING THE 12-HOUR ON AND OFF TIMER	11
USING THE 1-HOUR OFF TIMER	12
TIPS FOR ENERGY SAVING.....	12
ADJUSTING THE AIRFLOW DIRECTION	13
OPERATION WITHOUT THE REMOTE CONTROL UNIT	13
CARE AND CLEANING.....	14
TROUBLESHOOTING	15
OPERATING RANGE	15

PRODUCT INFORMATION

If you have problems or questions concerning your Air Conditioner, you will need the following information. Model and serial numbers are on the nameplate on the bottom of the cabinet.

Model No. _____

Serial No. _____

Date of purchase _____

Dealer's address _____

Phone number _____

ALERT SYMBOLS

The following symbols used in this manual, alert you to potentially dangerous conditions to users, service personnel or the appliance:



WARNING

This symbol refers to a hazard or unsafe practice which can result in severe personal injury or death.



CAUTION

This symbol refers to a hazard or unsafe practice which can result in personal injury or product or property damage.

INSTALLATION LOCATION

- We recommend that this air conditioner be installed properly by qualified installation technicians in accordance with the Installation Instructions provided with the unit.
- Before installation, check that the voltage of the electric supply in your home or office is the same as the voltage shown on the nameplate.



WARNING

- Do not install this air conditioner where there are fumes or flammable gases, or in an extremely humid space such as a greenhouse.
- Do not install the air conditioner where excessively high heat-generating objects are placed.

Avoid:

To protect the air conditioner from heavy corrosion, avoid installing the outdoor unit where salty sea water can splash directly onto it or in sulphurous air near a spa.

ELECTRICAL REQUIREMENTS

1. All wiring must conform to the local electrical codes. Consult your dealer or a qualified electrician for details.
2. Each unit must be properly grounded with a ground (or earth) wire or through the supply wiring.
3. Wiring must be done by a qualified electrician.

SAFETY INSTRUCTIONS

- Read this Instruction Manual carefully before using this air conditioner. If you still have any difficulties or problems, consult your dealer for help.
- This air conditioner is designed to give you comfortable room conditions. Use this only for its intended purpose as described in this Instruction Manual.



WARNING


- Never use or store gasoline or other flammable vapor or liquid near the air conditioner — it is very dangerous.
- This air conditioner has no ventilator for intaking fresh air from outdoors. You must open doors or windows frequently when you use gas or oil heating appliances in the same room, which consume a lot of oxygen from the air. Otherwise there is a risk of suffocation in an extreme case.



CAUTION

- Do not turn the air conditioner on and off from the power mains switch. Use the ON/OFF operation button.
- Do not stick anything into the air outlet of the outdoor unit. This is dangerous because the fan is rotating at high speed.
- Do not let children play with the air conditioner.
- Do not cool the room too much if babies or invalids are present.

NAMES OF PARTS




NOTE

This illustration is based on the external view of a standard model. Consequently, the shape may differ from that of the air conditioner which you have selected.

This air conditioner consists of an indoor unit and an outdoor unit. You can control the air conditioner with the remote control unit.

Air Intake	Air from the room is drawn into this section and passes through air filters which remove dust.
Air Outlet	Conditioned air is blown out of the air conditioner through the air outlet.
Remote Control Unit	The wireless remote control unit controls power ON/OFF, operation mode selection, temperature, fan speed, timer setting, and air sweeping.
Refrigerant Tubes	The indoor and outdoor units are connected by copper tubes through which refrigerant gas flows.
Drain Hose	Moisture in the room condenses and drains off through this hose.
Outdoor (Condensing) Unit	The outdoor unit contains the compressor, fan motor, heat exchanger coil, and other electrical components.

UNIT DISPLAY AND OPERATION BUTTON



IMPORTANT

Avoid using radio equipment such as mobile phone near (within 1 m) the remote control receiver. Some radio equipment may cause malfunction of the unit.


If the trouble happens, disconnect power and restart the air conditioner after a few minutes.

REMOTE CONTROL receiver	This section picks up infrared signals from the remote control unit (transmitter).
OPERATION button	When the remote control cannot be used, pressing this button enables cooling operation. Each time this button is pressed, the operation mode changes cyclically. Cooling operation → Stop ↑
OPERATION lamp	This lamp lights when the system is in the continuous COOL, DRY and FAN mode.
TIMER lamp	This lamp lights when the system is being controlled by the timer.

NOTE







The unit's display lamps are dimmed during operation in the ECONOMY mode.

REMOTE CONTROL UNIT (DISPLAY)







Symbols

(1) Operation mode


COOL.....		
MILD DRY		
FAN		

(2) Fan speed




Automatic operation	
HIGH	
MEDIUM.....	
LOW	

(3) Temperature setting

16 – 30 °C
When set to 28 °C
temperature indication.....

SET TEMP.	
------------------	---

(4) Timer

12-hour ON Timer.....	
12-hour OFF Timer.....	
1-hour OFF Timer.....	


(5) ECONOMY



(6) Confirmation of transmission.....



(7) Auto. flap indication.....



Flap angle indication.....




Sweep indication.....



REMOTE CONTROL UNIT


Transmitter

When you press the buttons on the remote control unit, the  mark appears in the display to transmit the setting changes to the receiver in the air conditioner.

Display




Information on the operating conditions is displayed while the remote control unit is switched on. If the unit is turned off, FLAP setting and FAN SPEED setting are not displayed.

1 HR. TIMER button (1-HOUR OFF TIMER)


: When you press this button, regardless of whether the unit is operating or stopping, the unit operates for one hour and then shuts down.

MODE selector button





Use this button to select COOL, DRY or FAN mode.

- (COOL)  ◀: The air conditioner makes the room cooler.
- (DRY)  ◀: The air conditioner reduces the humidity in the room.
- (FAN)  ◀: The air conditioner works only as a circulation fan.

ECONOMY button



For details, see "4. ECONOMY Mode". When you press this button in the COOL or DRY mode, the  mark appears in the display, and the remote control unit will automatically adjust the set temperature to save energy.

FAN SPEED selector button

- : The air conditioner automatically decides the fan speeds.
- : High fan speed
- : Medium fan speed
- : Low fan speed


ON TIME/OFF TIME setting buttons

No display: The timer does not operate.

- : The air conditioner starts at the set time.
- : The air conditioner stops at the set time.

ACL button (ALL CLEAR)


Puts the remote control unit into pre-operation status. Always press this button after replacing the batteries.




ON/OFF operation button

This button is for turning the air conditioner on and off.

Temperature setting buttons (TEMP.)

Press the  button to increase the set temperature.


Press the  button to reduce the set temperature.


The temperature setting changes by 1 °C each time one of the TEMP. buttons is pressed.


The set temperature appears in the display for only 3 seconds.

FLAP button

Press this button either to select the setting of the airflow direction to the auto. flap in each mode or one of the six possible positions manually or to select the sweep function which moves the flap up and down automatically.


 : Auto flap setting: If selected in a cooling or dry operation, the flap is set at position (7) in the following chart.

 : The airflow direction can be set manually. (six positions)

 : The flap moves up and down automatically.

NOTE

When you press the FLAP button, the air flow direction will be changed one by one as follows.




CANCEL button

After using the TIMER ON button or TIMER OFF button to set the timer, press this button to cancel the setting.

Jumper wire for address switching


- The address switch changes to prevent mixing of signals from remote control units when two air conditioners are installed next to each other. For more information, please contact the dealer where you made the purchase.



Back side of remote control unit
(Cover removed)

USING THE REMOTE CONTROL UNIT

HOW TO INSTALL BATTERIES



ACL button


1. Slide the cover in the direction indicated by the arrow and remove it.
2. Install two AAA alkaline batteries. Make sure the batteries point in the direction marked in the battery compartment.
3. Use a thin object such as the tip of a pen to press the ACL button.

NOTE

- The batteries last about six months, depending on how much you use the remote control unit. Replace the batteries when the remote control unit's display fails to light, or when the remote control cannot be used to change the air conditioner's settings.
- Use two fresh leak-proof type-AAA alkaline batteries.
- In replacing batteries, follow the instructions as mentioned in the sub-section "HOW TO INSTALL BATTERIES".
- If you do not use the remote control unit more than 1 month, take out the batteries.

HOW TO USE THE REMOTE CONTROL UNIT

When using the remote control unit, always point the unit's transmitter head directly at the air conditioner's receiver.



REMOTE CONTROL UNIT INSTALLATION POSITION


The remote control unit may be operated either from a non-fixed position or from a wall-mounted position. To ensure that the air conditioner operates correctly, DO NOT install the remote control unit in the following places:

DO NOT

- In direct sunlight
- Behind a curtain or other places where it is covered
- More than 8 m away from the air conditioner
- In the path of the air conditioner's airstream
- Where it may become extremely hot or cold
- Where it may be subject to electrical or magnetic noise
- Where there is an obstacle between the remote control unit and air conditioner (since a check signal is sent from the remote control unit every 5 minutes)

MOUNTING THE REMOTE CONTROL UNIT

Before mounting the remote control unit, press the ON/OFF operation button at the mounting location to make sure that the air conditioner operates from that location. The indoor unit should make a beeping sound to indicate that it has received the signal.




- To prevent loss of the remote control unit, you can connect the remote control unit to the mount by passing a string through the remote control unit and attachment hole.

WHEN HOLDING THE REMOTE CONTROL UNIT

- When using the remote control unit and during air conditioner operation, the transmitter on the remote control unit should be pointed towards the receiver on the indoor unit.
- Make sure that there are no objects between the remote control unit and receiver which could block the signal.

OPERATION WITH THE REMOTE CONTROL UNIT

1. Operation



NOTE Check that the circuit breaker on the power panel is turned on.

Press the setting buttons as described below and change the settings as desired.

STEP 1	Press the MODE selector button and select the desired mode. For cooling operation → ☼ ◀ For dehumidifying operation → 💧 ◀ For fan only operation → 🌀 ◀
STEP 2	To start the air conditioner, press the ON/OFF operation button.
STEP 3	Press the TEMP. setting buttons to change the temperature setting to the desired temperature. The set temperature appears in the display for only 3 seconds. Adjustable temperature range: 30 °C max. 16 °C min.
STEP 4	Set the FAN SPEED selector button to the setting you want.
STEP 5	Press the FLAP button and set the airflow direction as desired. (Refer to "ADJUSTING THE AIRFLOW DIRECTION" on page 13.)

To stop the air conditioner, press the ON/OFF operation button again.

- NOTE**
- Choose the best position in the room for the remote control unit, which also transmits the operating instructions. Once you've found this best position, always keep the remote control unit there.
 - This appliance has a built-in 5-minute time delay circuit to ensure reliable operation. When the operation button is pressed, the compressor will start running within three minutes. In the event of power failure, the unit will stop.

2. Adjusting the Fan Speed

A. Automatic fan speed


Simply set the FAN SPEED selector button to the ☼ 🌀 position.

This automatically sets the best fan speed for the room temperature.

B. Manual fan speed

If you want to adjust fan speed manually during operation, just set the FAN SPEED selector button as desired. [🌀, 🌀, or ☼]


3. Fan Only



If you want to circulate air without any temperature control, follow these steps:

STEP 1	Press the MODE selector button to switch to the fan mode 🌀 ◀.
STEP 2	Press the ON/OFF operation button.
STEP 3	Press the FAN SPEED selector button to select the fan speed of your choice (🌀, 🌀, or ☼).

4. ECONOMY Mode



ECONOMY Mode is used for saving energy.


Press the ECONOMY button while operation.

The  mark appears in the display.

To release the economy function, press the ECONOMY button again.

In Cooling and DRY Mode: (and)

When the ECONOMY mode is selected, the air conditioner automatically raises the temperature setting 1 °C when 30 minutes have passed after the selection was made, and then another 1 °C after another 30 minutes have passed, regardless of the indoor temperature when economy was selected. This enables you to save energy without sacrificing comfort. This function is convenient when gentle cooling is needed.



SPECIAL REMARKS

“DRY” () Operation

How it works?

- Once the room temperature reaches the level that was set, the unit repeats the cycle of turning on and off automatically.
- During DRY operation, the fan speed is automatically set to Low speed for providing a comfortable breeze.
- “DRY” operation is not possible if the indoor temperature is 15 °C or less.

Power failure during operation

- In the event of power failure, the unit will stop. When the power is resumed, the unit will restart automatically within five minutes by the remote control unit.

Clicking Sound

Clicking sound is heard from the air conditioner


- In cooling operation, any plastic parts may shrink due to a sudden temperature change. In this event, a clicking sound may occur. This is normal, and the sound will soon disappear.

Remote Control Unit

- The remote control unit sends the setting condition to the air conditioner regularly at five minute intervals.

USING THE 12-HOUR ON AND OFF TIMER

1. TIMER ON mode (Example)



The timer times appear in the display for only 3 seconds.

After the length of time set for TIMER ON elapses, the unit begins operating.

The display depicted above indicates that the air conditioner will begin operating in three hours.

Setting procedure:

STEP 1	Press the MODE button and set the desired operation mode. (See "Operation with the Remote Control Unit," page 9.)
STEP 2	Press the TIMER ON button.
STEP 3	Press the TIMER ON button (which advances the time displayed) to set the time at which you want operation to begin. The time can be set for one to twelve hours, in one hour steps.


- The display changes immediately to its status previous to timer setting, but the **ON** indicator remains.
- To check the status of the timer while it is counting down, press the TIMER ON button again.

Cancellation procedure: Press the CANCEL button.

NOTE

If you do not operate the remote control unit for 25 hours or more after the start of ON timer operation, the unit will stop operating automatically as a safety measure in case you forget to turn off the air conditioner.

2. TIMER OFF mode (Example)




The timer times appear in the display for only 3 seconds.

After the length of time set for TIMER OFF elapses, the unit stops operating.

The display depicted at left indicates that the air conditioner will stop operating in five hours.

Setting procedure:

STEP 1	Press the TIMER OFF button.
STEP 2	Press the TIMER OFF button (which advances the time displayed) to set the time at which you want operation to stop. The time can be set for one to twelve hours, in one hour steps.




- The display changes immediately to its status previous to timer setting, but the **OFF** indication remains.
- To check the status of the timer while it is counting down, press the TIMER OFF button again.

Cancellation procedure: Press the CANCEL button.

3. ON/OFF Program Timer

A combination of the TIMER ON and TIMER OFF modes, this function allows you to specify the time that the unit turns on and the time when it turns off.

(Example) The unit will turn on three hours from now, and turn off five hours from now.



Setting procedure:


STEP 1	Use the procedure described in the "1. TIMER ON mode" section on the preceding page to set the timer to turn the unit on three hours from now.
STEP 2	Use the procedure described in the "2. TIMER OFF mode" section on the preceding page to set the timer to turn the unit off five hours from now.

- The display changes immediately to its status previous to timer setting, but the **ON** or **OFF** indication remains.
- Press the TIMER ON button or the TIMER OFF button to display the time remaining on the timer in seconds.
- Note that it is not possible to check both the ON and OFF timer settings. The timer setting that will occur first is given preference and displayed.

Cancellation procedure: Press the CANCEL button.

USING THE 1-HOUR OFF TIMER

1. 1-Hour OFF Timer



This function causes the unit to operate for one hour and then stop, regardless of whether the unit is on or off when this button is pressed.

The **1H.** indicator in the display indicates that this function is operating.

Setting procedure:

Regardless of whether the unit is operating or stopped, press the 1 HR. TIMER button.

1H. appears in the display.

Cancellation procedure:

Press the ON/OFF operation button to turn the unit off, wait for the unit to stop operating, and then press the ON/OFF operation button again.

The 1-Hour Timer function is now cancelled and the unit operates normally.

NOTE


- If, while the 1-Hour Timer function is operating, the 1HR. TIMER button is pressed once to cancel the function and then again, the unit continues to operate for one hour from that point in time and then stops.
- It is not possible to use the OFF Timer and 1-Hour OFF Timer together. Whichever function is set last takes precedence. If the 1 HR. TIMER button is pressed while the TIMER OFF function operates, the OFF Timer is cancelled and the unit will stop operating one hour later.
- **Do not use the 1-Hour OFF Timer when both TIMER ON and TIMER OFF are set simultaneously. If the 1-Hour OFF Timer has been set, press the TIMER OFF button, then the CANCEL button to operate both the 1-Hour OFF Timer and ON Timer simultaneously.**

2. Combining the 1-Hour OFF Timer and 12-Hour ON Timer

By combining the 1-Hour OFF Timer and 12-Hour ON Timer, it is possible to have the unit operate for just one hour from the present time, and then have it switch on again later at a time specified by you.

(Example) Having the unit operate for just one hour from the present time, and then switch on again three hours from the present time.

Timer setting



Setting procedure:

STEP 1	Press the 1 HR. TIMER button.
STEP 2	Press the TIMER ON button. Then press it again to set the unit to turn on three hours later.

NOTE

- **Set the 1-Hour OFF Timer and the 12-Hour ON Timer simultaneously.** Unless you set the 1-Hour OFF Timer and the 12-Hour ON Timer at the same time, the 1-Hour OFF Timer may operate for one hour or more.

TIPS FOR ENERGY SAVING

Do not

- **Block the air intake and outlet of the unit. If they are obstructed, the unit will not work well, and may be damaged.**
- Let direct sunlight into the room. Use sunshades, blinds or curtains. If the walls and ceiling of the room are warmed by the sun, it will take longer to cool the room.


Do

- Always try to keep the air filter clean. (Refer to "CARE AND CLEANING".) A clogged filter will impair the performance of the unit.
- To prevent conditioned air from escaping, keep windows, doors and any other openings closed.

ADJUSTING THE AIRFLOW DIRECTION

1. Horizontal

The horizontal airflow can be adjusted by moving the vertical vanes with your hands to the left or right. Always use the knobs located at the top of the center vanes on the left and right sides to adjust the airflow direction.




CAUTION

When the humidity is high, the vertical vanes should be in the front position during the cooling or dehumidifying operation. If the vertical vanes are positioned all of the way to the right or left, condensation may begin to form around the air vent and drip down.

2. Vertical

The vertical airflow can be adjusted by moving the flap with the remote control unit. Do not move the flap with your hands. Confirm that the remote control unit has been turned on. Use the FLAP button to set either the sweep function or one of the six airflow direction settings.



A. Sweep function



The flap starts moving up and down to deliver air over the sweep range.

B. Setting the airflow manually



Referring to the above illustration, use the FLAP button to set the airflow direction within the range used during the cooling or dehumidifying operation.

C. Auto flap function



The flap is set to the recommended position.

NOTE

- The flap automatically closes when the unit is off.




CAUTION

- Use the FLAP button on the remote control to adjust the position of the flap. If you move the flap by hand, the flap position according to the remote control and the actual flap position may no longer match. If this should happen, shut off the unit, wait for the flap to close, and then turn on the unit again; the flap position will now be normal again.
- Do not have the flap pointed down during cooling operation. Condensation may begin to form around the air vent and drip down.

OPERATION WITHOUT THE REMOTE CONTROL UNIT

INDOOR UNIT



If you have lost the remote control unit or it has trouble, follow the steps below.

When the air conditioner is not running

Each time the OPERATION button is pressed, the operation mode changes cyclically.



CARE AND CLEANING



WARNING

1. For safety, be sure to turn the air conditioner off and also to disconnect the power before cleaning.
2. Do not pour water on the indoor unit to clean it. This will damage the internal components and cause an electric shock hazard.

Casing and Grille (Indoor Unit)

Clean the casing and grille of the indoor unit with a vacuum cleaner brush, or wipe them with a clean, soft cloth.

If these parts are stained, use a clean cloth moistened with a mild liquid detergent. When cleaning the grille, be careful not to force the vanes out of place.



CAUTION


1. Never use solvents, or harsh chemicals when cleaning the indoor unit. Do not wipe the plastic casing using very hot water.
2. Some metal edges and the fins are sharp and may cause injury if handled improperly; be especially careful when you clean these parts.
3. The internal coil and other components of the outdoor unit must be cleaned every year. Consult your dealer or service center.

Anti-Mold Filter

The anti-mold filter behind the front panel should be checked and cleaned at least once every two weeks.

How to remove the anti-mold filter

Grasp both ends of the front panel and pull forward and up to open the front panel. Lift the anti-mold filter up slightly to disengage the protrusions from the hooks on the unit, and then pull downward to remove the filter from the unit.




Cleaning

Use a vacuum cleaner to remove light dust. If there is sticky dust on the filter, wash the filter in lukewarm, soapy water, rinse it in clean water, and dry it.

How to replace the anti-mold filter

Insert the top of the anti-mold filter, and then fit the protrusions on the bottom of the filter all the way into the hooks on the unit. Press the locations marked by the arrows and close the front panel.



Air Clean Filter

The air clean filter removes dust and dirt from the air, and reduces odors and smoke from tobacco.




WARNING

This air clean filter cannot remove harmful gases or vapors nor ventilate air in the room. You must open doors or windows frequently when you use gas or oil heating appliances. Otherwise there is a risk of suffocation in extreme cases.

How to install the air clean filter

The air clean filter needs to be installed behind the anti-mold filter. Open the front panel and remove the anti-mold filters, then install the air clean filter in the position shown in the figure. After that, remount the anti-mold filters and close the front panel.



NOTE


- Do not bend nor give excessive force onto the air clean filter.
- If the filter surface is heavily blocked with dirt or damaged, replace it with new one. Purchase a replacement filter at your local dealer. (model **STK-FWWB**)

Cleaning the main unit and remote control unit

- Wipe clean using a soft, dry cloth.
- To remove stubborn dirt, moisten a cloth in warm water no hotter than 40 °C, wring thoroughly, and then wipe.
- The front panel can be removed in order to wash it with water.

Removing and remounting the front panel

1. Open the front panel until it is nearly horizontal, grasp the sections near the front panel arms on both sides, and then remove the panel by pushing the arms towards the outside while pulling the panel towards you.



2. Grasp the sections near the front panel arms on both sides, and hold the front panel so that it is nearly horizontal. Push the arm shafts towards the outside so that they come into contact with the top of the indentations on the right and left sides of the air conditioner. Then push firmly until the arm shafts click into place. After closing the front panel, press firmly on the parts indicated by the arrows to securely fasten the panel in place. Also refer to the figure that shows "How to replace the anti-mold filter".



CAUTION

When using a footstool or the like, be careful not to let it tip over.

Washing the front panel with water

- Clean the front panel gently using a soft sponge, or the like. Then wipe away any remaining moisture.
- Neutral detergent may be used to remove stubborn dirt. Then rinse thoroughly with water and wipe away any remaining moisture.

TROUBLESHOOTING

If your air conditioner does not work properly, first check the following points before requesting service. If it still does not work properly, contact your dealer or service center.

Trouble	Possible Cause	Remedy
Air conditioner does not run at all.	<ol style="list-style-type: none"> 1. Power failure. 2. Leakage circuit breaker tripped. 3. Line voltage is too low. 4. Batteries in remote control unit have run down. 	<ol style="list-style-type: none"> 1. Restore power. 2. Contact service center. 3. Consult your electrician or dealer. 4. Replace batteries.
OPERATION lamp blinks and air conditioner does not operate.	Trouble in system.	Contact service center.
Compressor runs but soon stops.	Obstruction in front of condenser coil.	Remove obstruction.
Poor cooling performance.	<ol style="list-style-type: none"> 1. Dirty or clogged air filter. 2. Heat source or many people in room. 3. Doors and/or windows are open. 4. Obstacle near air intake or air discharge port. 5. Thermostat is set too high for cooling. 	<ol style="list-style-type: none"> 1. Clean air filter to improve airflow. 2. Eliminate heat source if possible. 3. Shut them to keep the heat out. 4. Remove it to ensure good airflow. 5. Set the temperature lower.
Clicking sound is heard from the air conditioner.	In cooling operation, any plastic parts may shrink due to a sudden temperature change. In this event, a clicking sound may occur.	This is normal, and the sound will soon disappear.
OPERATION lamp lights but outdoor unit will not run.	The use of cellular phones near the air conditioner may cause disturbance to its normal operation.	<ol style="list-style-type: none"> 1. Turn off the power then restart the air conditioner after a while. 2. Consult your dealer.

OPERATING RANGE

The air conditioner is operable within the temperature ranges as listed below:

	Temperature	Indoor air temperature	Outdoor air temperature
COOLING	Max.	32 °C DB / 23 °C WB	43 °C DB
	Min.	19 °C DB / 14 °C WB	19 °C DB



SANYO Electric co., Ltd.

Apr. / 2008

R&D center manual