


OWNER'S INSTRUCTIONS

AC340B AC340BR AC340BG

Air Cleaner




Safety Precautions

The following safety precautions must be taken into account when using this product.



- Do not install this product in places where it will come into contact with combustible gases such as sulfuric gas, hydrogen gas, methane gas, etc.
- Do not install this product in places that are exposed to direct sunlight, near heating equipments and wet places.
- When installing the electric wires, do not bend the wire excessively or place a heavy object on it. The wires may be disconnected or damaged.
- Avoid using inflammable spray gases such as insecticides near this product.
- Prevent children from inserting their fingers or objects into the air inlet and outlet.
- Do not attempt to install or repair this product by yourself. If the product needs repairing, consult an authorized service personnel.
- Do not install this product on surfaces that are not even or slant. This may cause the product to malfunction or make a strange noise due to vibration.
- Make sure that the product is installed in a location that ensures enough space(at least 5 cm) in front of the air inlet.
- Make sure that there are no obstacles near the air inlet and outlet of the product.
- If a strange noise, burning smell or smoke come from the product, immediately disconnect the power supply and consult an authorized service personnel.
- Do not use this product for other purposes.
- Do not spill any kind of liquids into the product.
- Do not place containers containing liquid substances on top of the product.
- Do not apply excessive impact on the product.
- When using this product in a closed area that combustible fuels are fired, make sure to ventilate the air occasionally.
- Do not use the product in places that have a high temperature and humidity level, such as a bathroom or a sauna.
- Before attempting to clean or repair the product, make sure that the power supply is disconnected and the fan has stopped rotating.
- Do not use substances such as benzene, thinner or alcohol to clean the surface of the product.
- Do not open the filter box when the product is in operation.
- When drying the washable filters, do not expose it to direct sunshine. The powerful sunshine may affect the transformation of the filter case.
- Do not touch the filter section with wet hands because the user may be electrocuted. This is especially true for the Washable Filter section where a high voltage current flows.




Contents


•	 PREPARING THE AIR CLEANER Safety Precautions View of the Unit Getting Started 	2 4 6
•	OPERATING THE AIR CLEANER Selecting the Automatic Mode Selecting the Pollen Mode Selecting the Sleep Mode Selecting the Odor Mode	7 8 9 10
•	Отнек Functions Generating Anions Adjusting the Clean Level (Fan Speed)	11 12
•	Recommendations For Use Operating Recommendations Cleaning the Air Cleaner Solving Common Problems	13 14 17

♦ TECHNICAL SPECIFICATIONS


View of the Unit



Ionizer Electrostatic Metal Nano TiO₂ Anti-bacterial Anion filter filter silver photocatalyst fan generator formula filter



Pre-filter



Operating Mode Selection Button

Mota Contamination Level Indicator

- Classifies the various contaminants in the indoor air, as Odor, Mote and Dust, and up to 5 levels can be displayed.
- Green indicates that the indoor air is clean. Red means that the indoor air is contaminated.
- During the first two minutes after the air cleaner is turned on, the contamination level will move up and down because the sensor will be in the process of analyzing the contamination level of the indoor air. So it is recommended that you check the contamination level in 2 minutes.



Getting Started

You have just purchased an air cleaner and it has to be installed according to the safety precautions of page 2.


This manual contains important information concerning the use of your air cleaner. Please take some time to read this booklet as it will help you take full advantage of the product's features.

The booklet is organized as follows.

 The following figures are shown from page 4 to 5 :
 View of the Unit They will help you find the buttons and understand the symbols that are displayed.

 In the manual, you will find a series of step-by-step procedures for each function available.

Three types of symbols are used to help you understand the illustrations in the step-by-step procedures :



Selecting the Automatic Mode

In the Automatic Mode, the air cleaner automatically adjusts the clean level according to the signal of the more contaminated level after comparing the dusts and motes contamination level with the odor contamination level in the indoor air. Anions are generated into an air automatically and the air flow blade does not move.

1 If necessary, press the (1) (Power) button.


- Result:
- The Power indicator on the display comes on.
 The air cleaner runs in the Auto Mode.
- The air cleaner makes a ringing sound.
- 2 If the Auto is not displayed on the display, select the Auto mode by pressing the Mote button until it is displayed on the display of the air cleaner.
 - The air cleaner beeps.
 - The air cleaner operates in the Auto mode.



Result:

You can change modes at any time.

3 To adjust the clean level, refer to page 12.To adjust the generating anions, refer to page 11.



Selecting the Pollen Mode

The Pollen Mode can eliminate pollen and dust particles effectively in the indoor air. In this operating mode, the air cleaner automatically adjusts the clean level according to the dusts or motes contamination level without the odor contamination level in the indoor air. Anions are generated automatically and the air flow blade moves automatically.

1 If necessary, press the (b) (Power) button.

Result:


- The Power indicator on the display comes on.
 - The air cleaner runs in the Auto Mode.
 - The air cleaner makes a ringing sound.

2 If the 谷 is not displayed on the display, select the Pollen mode by pressing the button until it is displayed on the display. Result:

- The air cleaner beeps.
 - The air cleaner operates in the Pollen mode.

Note You can change modes at any time.

3 To adjust the clean level, refer to page 12. To adjust the generating anions, refer to page 11.



Power

Selecting the Sleep Mode

If you wish the air cleaner to clean the air in your room quietly, select the Sleep Mode. In this operating mode, the air cleaner runs in "Low Speed" which is the quietest clean level setting. Anions are generated into an air automatically and the air flow blade does not move.

1 If necessary, press the () (Power) button.

Result:

- The Power indicator on the display comes on.
 - The air cleaner runs in the Auto Mode.
 - The air cleaner makes a ringing sound.



Mode

Anior

- 2 If the .★ is not displayed on the display, select the Sleep mode by pressing the or button until it is displayed on the display.
 - Result:

 The air cleaner beeps.
 - The air cleaner operates in the Sleep mode.
 - *Mote* You can change modes at any time.
- 3 To adjust the clean level, refer to page 12.To adjust the generating anions, refer to page 11.
- Notə

The brightness of the display during the Sleep Mode

 In the Sleep Mode, the brightness of the display decreases so that it may not disturb your sleep.



Clean Level

Selecting the Odor Mode

If you select the Odor Mode, the air cleaner can eliminate airborne contaminants and harmful smells effectively in the indoor air. In this operating mode, the air cleaner automatically adjusts the clean level according to the signal of the odor contamination level without the dusts and motes contamination level in the indoor air. Anions are generated automatically and the air flow blade moves automatically.

If necessary, press the 🕐 (Power) button. 1

Result:

- The Power indicator on the display comes on.
- The air cleaner runs in the Auto Mode.
 - The air cleaner makes a ringing sound.

Clean Level Anion Mode \bigcirc

Power

- Result:
 - The air cleaner beeps.
 - The air cleaner operates in the Odor mode.

Note You can change modes at any time.

3 To adjust the clean level, refer to page 12. To adjust the generating anions, refer to page 11.

E-10

Generating Anions

The Anion Generator generates anions, which are beneficial to the human body. Use this function if you want to feel refreshed both physically and mentally, just as if you were in the midst of a forest. If the air cleaner is turned on, anions are generated automatically.

1 If necessary, press the (b) (Power) button.

Result:

Result:

- The Power indicator on the display comes on.
- The air cleaner runs in the Auto Mode.
- The air cleaner makes a ringing sound.

Certe Auto Certe Certe

Power

- 2 If the Anion Indicator is not displayed on the display, select the Anion Generation function by pressing the obtained button.
 - Result:

 The air cleaner beeps.
 - The Anion Indicator lights up on the display.
 - The air cleaner generates anions into the indoor air.
- 3 If you wish to turn off the Anion Generation function, press the 🔘 button again.
 - The Anion Indicator disappears on the display.
 - The air cleaner stops generating anions into the indoor air.
- N@text Anions are ultra-fine particles charged negatively in the air. There are vast quantities of them in nature, for example near waterfalls or in the midst of a forest. When inhaled in sufficient quantities, anions can enhance the metabolism of your blood cells, help you recover from fatigue faster, and calm your nerves. Thus anions are beneficial to you both physically and mentally.

Adjusting the Clean Level (Fan Speed)


Result:

Result:

The air cleaner automatically adjusts the clean level according to the contamination levels of the indoor air. It is also possible for you to manually select the clean level.

- 1 If necessary, press the () (Power) button.
 - The Power indicator on the display comes on.
 - The air cleaner runs in the Auto Mode.
 - The air cleaner makes a ringing sound.
- 2 If you wish to manually select the clean level, press the Other button one or more times until the desired clean level is selected.
 - Result:

 The air cleaner beeps.
 - The air cleaner operates in the clean level that was selected.
 - ஸ்லீ HH (Turbo) ஒயி H (High) ஒபி M (Medium) இ L (Low)
- 3 If you wish the air cleaner to automatically adjust the clean level for you,
 - press the button until the Auto mode is selected.
 - The clean level that was selected is canceled.
 - The air cleaner operates in the Auto mode.
 - The air cleaner automatically chooses the appropriate clean level according to the levels of contamination in the indoor air.




Power

Operating Recommendations

Here are a few recommendations that you should follow when using your air cleaner.

Торіс	Recommendation
Wash indicator	If the light on the "Wash" indicator comes on, the washable filters must be cleaned. The washable filters must be cleaned more often in environments that include large amounts of dust in the air.
Closing the air flow blade	If you want to close the air flow blade, use the Power button on the control panel. Do not close the air flow blade with your hands.

Cleaning the Air Cleaner



Cleaning the Lens of the Dust Sensor

To get the best possible result from your air cleaner, you must clean the lens of the dust sensor regularly. The dust sensor is responsible for sensing the accumulation level of small and big dust particles in the air in your room.

1 Open the front panel.

Moto Slightly pull out the bottom part of the front panel(1), lift it up(2) and then separate it from the unit.

2 Clean the lens of the Dust Sensor thoroughly with a cotton stick.

N⊚te If the lens of the Dust Sensor is cleaned with a sharp or rough object, the lens is damaged, so the Dust Sensor may not work properly.

3 After you have cleaned the lens of the Dust Sensor, put the front panel back into the place.

N@text You must clean the lens of the Dust Sensor every six months. However, this may vary according to the time and place that the air cleaner was operated. So the air cleaner must be cleaned more often in environments that have a high level of dust accumulation.


> The Odor Sensor does not have a lens. So you do not need to clean the Odor Sensor.

Cleaning the Washable Filters

Washable Filters are responsible for eliminating fine particles of dust, molds and mites in the air that are as small as 0.5 microns. It also has the function of sterilizing virus or bacteria in the air in your room. You must clean the Washable Filters every 3 months or whenever the Wash Indicator comes on. The cleaning frequency of the Washable Filters may vary according to the time and place that the air cleaner is operated.

- 1 Open the Filter Box and pull out the Washable Filter Section towards the direction of the arrow.
- 2 Wash the Washable Filter Section under lukewarm tap water.
 - Mote
 ♦ If the filter is too contaminated, leave it in warm water mixed with neutral detergent for 30 minutes, and brush the contaminants off with a soft brush.
 - The Pre-Filter is easy to clean because it can be taken out of the Washable Filter Section and washed separately.
- 3 Leave the Washable Filter Section in the shade to dry for over 12 hours.
 - N @ t = During this process, make sure that the filter is not exposed to direct sunlight because the sun's rays may affect the transformation of the filter case.
- 4 Put the Washable Filter Section back into the place and close the Filter Box.
- 5 Press the control panel's Wash () button for 2 seconds.
 - Result:
 The Wash Indicator on the control panel turns off. It will light up again when the time for the next filter washing comes.
 - The air cleaner beeps.
- PORTANT Even though the Wash Indicator does not light up, always press the Wash
 button after washing the Washable Filter Section.









Cleaning the Air Cleaner (cont.)




The phototcatalyst filter eliminates various odors in the indoor air.

1 Open the filter box and pull out the Recovery Filter Section towards in the direction of the arrow.

- 2 Dry the Recovery Filter Section under the sunlight at least for 8 hours. • The more frequently you dry the photocatalyst filter under the Notə
 - sunlight, the higher the filter efficiency would be.
 - You can purchase new photocatalyst filters in the authorized service center.

MPORTANT

- Don't wash the photocatalyst filter. It must be dried only under the sunlight every six months.
- 3 After pushing the Recovery Filter Section back into the place, close the Filter Box.



Recovery Filter Section



Before contacting the after-sales service, perform the following simple checks. This may prevent you from making an unnecessary call and wasting your time and money.

Problem	Explanation/Solution
The air cleaner does not operate.	 Check for a power failure. Check that the power plug is plugged in tightly. Check that the power outlet is not of a poor quality. Check that the Filter Box is closed properly.
The air cleaner stops its operation abruptly	 Check whether the Filter Box was opened during operation. Press the Power button if you wish to restart the air cleaner.
The air flow blade does not move.	 Check that the air cleaner is in the Auto or Sleep Mode. In the Auto or Sleep Mode, the air cleaner automatically does not move the air flow blade.
Unpleasant odors can be detected coming from the air cleaner.	 Make sure that the air cleaner is used in places that have a high level of odor permeating contaminants in the air. The air cleaner cannot fully function in an environment where the level of contamination is too high. Check whether the source of the unpleasant odor is the unclean filters in the Filter Box.
The Display Brightness is too dim.	 Check whether the air cleaner is operating in the Sleep Mode. In the Sleep Mode, the display automatically diminishes its brightness to ensure a comfortable sleeping setting.
The air in the room still feels unclean.	 Check whether the lens of the Dust Sensor is unclean. Check whether the filters in the Washable and Recovery Filter Section have been cleaned and recovered regularly. Check that there are no additional contaminants entering the room through open windows and doors.
The Wash Indicator stays on.	 Make sure that you have pressed the Filter Reset button after you have cleaned the Washable Filter Section.
The air flow blade does not close.	 Close the air flow blade by using the Power button on the control panel. Do not close the air flow blade with your hands.

Technical Specifications

Model	Power Supply
AC340B	
AC340BR	220-240V~, 50/60Hz
AC340BG	

Memo

THIS AIR CLEANER IS MANUFACTURED BY:

