


**SAMSUNG**

**! Please read Instruction & Safety Precaution carefully before use**

# MICROWAVE OVEN

## Owner's Instructions and Cooking Guide

**PG838**




Quick Look-up Guide .....	2
Oven .....	3
Accessories .....	3
Control Panel .....	4
Using this Instruction Booklet .....	4
Installing Your Microwave oven .....	6
Setting the Time .....	6
What to Do if You are in Doubt or Have a Problem .....	7
Choosing the Heating Element Position(Lower Heater) .....	7
Cooking / Reheating .....	8
Power Levels .....	8
Stopping the Cooking .....	9
Adjusting the Cooking Time .....	9
Using the Steam Cleaning .....	9
Using the Auto Reheat Feature .....	10
Using the Auto Defrost Feature .....	11
Auto Defrost Settings .....	11
Choosing the Accessories .....	12
Top Grilling .....	12
Super Grilling .....	13
Combining Microwaves and the Top Grill .....	14
Combining Microwaves and the Super Grill .....	15
Using the Super Grill Auto Cook Features .....	16
Using the Super Grill Auto Reheat Features .....	17
Switching the Beeper Off .....	18
Safety-Locking Your Microwave Oven .....	18
Cookware Guide .....	19
Cooking Guide .....	20
Cleaning Your Microwave Oven .....	29
Storing and Repairing Your Microwave Oven .....	30
Technical Specifications .....	30


## Quick Look-up Guide

EN

### If you want to cook some food



1. Place the food in the oven.  
Select the power level by pressing the **Microwave** (微波) button once or more times.



2. Select the cooking time by pressing the **Down** (▽) and **Up** (△) button as required.




3. Press the **Start/Pause** (▶) button.  
Result : Cooking starts.  
The oven beeps four times when cooking is over.

### If you want to defrost some food



1. Place the frozen food in the oven.  
Press the **Auto Defrost** (自动解冻) button once or more times according to the type of food to be defrosted.



2. Select the weight by pressing the **Down** (▽) and **Up** (△) buttons as required.




3. Press the **Start/Pause** (▶) button.

### If you want to add an extra minute



- Leave the food in the oven.  
Press **Start/Pause** (▶) once or more times for each extra 30 seconds that you wish to add.


### If you want to top grill some food



1. Preheat the grill to the required temperature, by pressing the **Grill / Combi** (烧烤 + 烧烤) button and set the preheat time by pressing the **Down** (▽) and **Up** (△) button and **Start/Pause** (▶) button.




2. Place the food on the rack in the oven.  
Press the **Grill / Combi** (烧烤 + 烧烤) button. Select the cooking time by pressing the **Down** (▽) and **Up** (△) buttons.



3. Press the **Start/Pause** (▶) button.




### If you want to super grill some food



1. Preheat the grill to the required temperature, by pressing the **Grill / Combi** (烧烤 + 烧烤) button and set the preheat time by pressing the **Down** (▽) and **Up** (△) button and **Start/Pause** (▶) button.



2. Place the food on the rack in the oven.  
Press the **Grill / Combi** (烧烤 + 烧烤) button. Select the cooking time by pressing the **Down** (▽) and **Up** (△) buttons.




3. Press the **Super Grill** (超级烧烤) button.



4. Press the **Start/Pause** (▶) button.




## Oven



## Accessories


Depending on the model that you have purchased, you are supplied with several accessories that can be used in a variety of ways.

EN




- Coupler**, already placed over the motor shaft in the base of the oven.

Purpose The coupler rotates the turntable.




- Roller ring**, to be placed in the centre of the oven.

Purpose The roller ring supports the turntable.




- Turntable**, to be placed on the roller ring with the centre fitting to the coupler.

Purpose The turntable serves as the main cooking surface; it can be easily removed for cleaning.




- Metal rack**, to be placed on the turntable.

Purpose The metal rack can be used in grill and combination and super grill cooking.




- Heat-resistant gloves for burn injury prevention.**

Purpose Use the safety gloves when moving heating elements or taking out metal rack, turntable or dishes from the oven after cooking.



- Equipments to move heating element.**

Purpose Use this equipment when moving heating elements.




- Clean Water Bowl**, see page 9.

Purpose : The water bowl can be used to clean.



**DO NOT** operate the microwave oven without the roller ring and turntable.



1. AUTO COOK(Super Grill) BUTTON
2. AUTO DEFROST FEATURE SELECTION
3. AUTO REHEAT BUTTON
4. MW BUTTON
5. GRILL/COMBI BUTTON
6. UP (▲) / DOWN (▼) BUTTON (Cook time, Weight and serving size)
7. STOP/CANCEL BUTTON
8. TOAST/PIZZA BUTTON
9. SUPER GRILL SELECTION
10. STEAM CLEAN BUTTON
11. START/+30s BUTTON

## Using this Instruction Booklet

You have just purchased a SAMSUNG microwave oven. Your Owner's Instructions contain much valuable information on cooking with your microwave oven:

- Safety precautions
- Suitable accessories and cookware
- Useful cooking tips

Inside the cover you will find a quick look-up guide explaining three basic cooking operations:

- Cooking food
- Defrosting food
- Grilling food
- Adding extra cooking time

At the front of the booklet you will find illustrations of the oven, and more importantly the control panel, so that you can find the buttons more easily.

The step-by-step procedures use three different symbols.



Important



Note



Caution

## PRECAUTIONS TO AVOID POSSIBLE EXPOSURE TO EXCESSIVE MICROWAVE ENERGY

Failure to observe the following safety precautions may result in harmful exposure to microwave energy.

- (a) Under no circumstances should any attempt be made to operate the oven with the door open or to tamper with the safety interlocks (door latches) or to insert anything into the safety interlock holes.
- (b) Do not place any object between the oven door and front face or allow food or cleaner residues to accumulate on sealing surfaces. Ensure that the door and door sealing surfaces are kept clean by wiping after use first with a damp cloth and then with a soft dry cloth.
- (c) Do not operate the oven if it is damaged until it has been repaired by a qualified microwave service technician trained by the manufacturer. It is particularly important that the oven door closes properly and that there is no damage to the:
  - (1) Door (bent)
  - (2) Door hinges (broken or loose)
  - (3) door seals and sealing surfaces
- (d) The oven should not be adjusted or repaired by anyone other than a properly qualified microwave service technician trained by the manufacturer.

## Safety Precautions

### IMPORTANT SAFETY INSTRUCTIONS.

#### READ CAREFULLY AND KEEP FOR FUTURE REFERENCE.

*Before cooking food or liquids in your microwave oven, please check that the following safety precautions are taken.*

- Only use utensils that are suitable for use in microwave ovens;  
**DO NOT** use any metallic containers, Dinnerware with gold or silver trimmings, Skewers, forks, etc.  
Remove wire twist ties from paper or plastic bags.  
Reason: Electric arcing or sparking may occur and may damage the oven.
- When heating food in plastic or paper containers, keep an eye on the oven due to the possibility of ignition;  
Do not use your microwave oven to dry papers or clothes.
- Small amounts of food require shorter cooking or heating time.  
If normal times are allowed they may overheat and burn.
- If smoke is observed, switch off or unplug the appliance and keep the door closed in order to stifle any flames;
- Microwave heating of beverages can result in delayed eruptive boiling, therefore care must be taken when handling the container; To prevent this situation  
**ALWAYS** allow a standing time of at least 20 seconds after the oven has been switched off so that the temperature can equalize.  
Stir during heating, if necessary, and **ALWAYS** stir after heating.  
In the event of scalding, follow these FIRST AID instructions:
  - \* Immerse the scalded area in cold water for at least 10 minutes.
  - \* Cover with a clean, dry dressing.
  - \* Do not apply any creams, oils or lotions.
- **NEVER** fill the container to the top and choose a container that is wider at the top than at the bottom to prevent the liquid from boiling over. Bottles with narrow necks may also explode if overheated.  
**NEVER** heat a baby's bottle with the teat on, as the bottle may explode if overheated.
- The contents of feeding bottles and baby food jars shall be stirred or shaken and the temperature checked before consumption, in order to avoid burns;
- Eggs in their shell and whole hard-boiled eggs should not be heated in microwave ovens since they may explode, even after microwave heating has ended;  
Also do not heat airtight or vacuum-sealed bottles, jars, containers, nuts in shells, tomatoes etc.
- The oven should be cleaned regularly and any food deposits removed;
- Failure to maintain the oven in a clean condition could lead to deterioration of the surface that could adversely affect the life of the appliance and possibly result in a hazardous situation;
- **DO NOT** cover the ventilation slots with cloths or paper. They may catch fire as hot air is evacuated from the oven.  
The oven may overheat and automatically switch itself off. It will remain inoperable until it has cooled sufficiently.
- **ALWAYS** use oven gloves when removing a dish from the oven to avoid unintentional burn.

- **DO NOT** touch heating elements or interior oven walls until the oven be cooled down.
- Do not immerse the power cable or plug in water and keep the power cable away from heated surfaces.  
Do not operate this appliance if it has a damaged power cable or plug.
- Stand at arms length from the oven when opening the door.  
Reason: The hot air or steam released may cause scalding.
- You may notice a Clicking sound during operation (especially when the oven is defrosting).  
Reason: This sound is normal when the electrical power output is changing.
- **DO NOT** operate the microwave oven when it is empty. The power will be cut off automatically for safety. You can operate normally after letting it stand for over 30 minutes.  
It is best to leave a glass of water inside the oven at all times. The water will absorb the microwaves energy if the oven accidentally started.
- The microwave oven shall not be placed in a cabinet.

### IMPORTANT

- Young children should **NEVER** be allowed to use or play with the microwave oven. Nor should they be left unattended near the microwave oven when it is in use. Items of interest to children should not be stored or hidden just above the oven.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- Children should be supervised to ensure that they do not play with the appliance.
- During use the appliance becomes hot. Care should be taken to avoid touching heating elements inside the oven.
- **DO NOT** use harsh abrasive cleaners or sharp metal scrapers to clean the oven door glass since they can scratch the surface, which may result in shattering of the glass. (If provided)

### WARNING:

If the door or door seals are damaged, the oven must not be operated until it has been repaired by a competent person.

### WARNING:

It is hazardous for anyone other than a competent person to carry out any service or repair operation which involves the removal of a cover which gives protection against exposure to microwave energy.

### WARNING:

Liquids and other foods must not be heated in sealed containers since they are liable to explode.

### WARNING:

Only allow children to use the oven without supervision when adequate instructions have been given so that the child is able to use the oven in a safe way and understands the hazards of improper use.

### WARNING:

When the appliance is operated in the combination mode, children should only use the oven under adult supervision due to the temperatures generated.

### WARNING:


Accessible parts may become hot during use. Young children should be kept away.

- For safety reasons do not clean the appliance with a steam jet or high pressure cleaner.

## Installing Your Microwave oven

EN

*Place the oven on a flat level surface 85cm above the floor. The surface should be strong enough to safely bear the weight of the oven.*



1. When you install your oven, make sure there is adequate ventilation for your oven by leaving at least 10 cm (4 inches) of space behind and, on the sides of the oven and 20 cm (8 inches) of space above.
2. Remove all packing materials inside the oven. Install the roller ring and turntable. Check that the turntable rotates freely.
3. This microwave oven has to be positioned so that plug is accessible.



If the supply cord is damaged, it must be replaced by a special cord or assembly available from the manufacturer or its service agent.


For your personal safety, plug the cable into a 3-pin, 240 Volt, 50Hz, AC earthed socket. If the power cable of this appliance is damaged, it must be replaced by a special cable.




Do not install the microwave oven in hot or damp surroundings like next to a traditional oven or radiator. The power supply specifications of the oven must be respected and any extension cable used must be of the same standard as the power cable supplied with the oven. Wipe the interior and the door seal with a damp cloth before using your microwave oven for the first time.


## Setting the Time


1. Plug your oven into a standard household socket.  
Result: The following indication is displayed :  
(12: will flash)




2. Press the **Down** (▽) and **Up** (△) buttons to set hour.




3. Press the  button.  
Result: The following indication is displayed :  
( 12: will flash)



4. Press the **Down** (▽) and **Up** (△) buttons to set minute.




5. Press the  button.  
Clock set is finished.






If you don't want to setting the time, press the **Stop** (⊙) button before starting your cooking.



If you want to change or reset the time setting when the cooking is finished and in the **Stop** status, press and hold the  and **Up** (△) buttons simultaneously for more than 2 seconds.

## What to Do if You are in Doubt or Have a Problem

If you have any of the problems listed below try the solutions given.

- ◆ This is normal.
    - Condensation inside the oven
    - Air flow around the door and outer casing
    - Light reflection around the door and outer casing
    - Steam escaping from around the door or vents
  - ◆ The oven does not start when you press the  button.
    - Is the door completely closed?
  - ◆ The food is not cooked at all
    - Have you set the timer correctly and/or pressed the  button?
    - Is the door closed?
    - Have you overloaded the electric circuit and caused a fuse to blow or a breaker to be triggered?
  - ◆ The food is either overcooked or undercooked
    - Was the appropriate cooking length set for the type of food?
    - Was an appropriate power level chosen?
  - ◆ Sparking and cracking occur inside the oven (arcing)
    - Have you used a dish with metal trimmings?
    - Have you left a fork or other metal utensil inside the oven?
    - Is aluminium foil too close to the inside walls?
  - ◆ The oven causes interference with radios or televisions
    - Slight interference may be observed on televisions or radios when the oven is operating. This is normal. To solve this problem, install the oven away from televisions, radios and aerials.
    - If interference is detected by the oven's microprocessor, the display may be reset. To solve this problem, disconnect the power plug and reconnect it. Reset the time.
-  If the above guidelines do not enable you to solve the problem, contact your local dealer or SAMSUNG after-sales service.

## Choosing the Heating Element Position(Lower Heater)

The heating element is used when Super grilling. It can be placed in one of two positions:

- **Horizontal position for Super grilling or combined microwave +super grill cooking**
- **Vertical position for microwave cooking.**





When moving heating elements, make sure to use the equipment designed to move heating element while wearing safety gloves provided with the product, and see if temperature drops sufficiently (at least 10 minutes after grill or combination cooking operation) after operation.





DO NOT apply excessive force when moving heating elements.



Proper cooking result cannot be obtained if Lower Heater is carried out using the super grill function from the vertical position. Therefore, make sure to put this product on a level surface in time of grill or combination-cooking using the super grill function.




To set the heating element to the...	Then...
Lower Heater Horizontal position (supper grill or combined microwave + super grill cooking)	◆ Pull out in the oven until it is horizontal (180 degrees) 
Lower Heater Vertical position (top grill or combined microwave + top grill cooking, microwave cooking, instant reheat, defrost)	◆ Push back in the oven until it is vertical (90 degrees) 

## Cooking / Reheating


EN

The following procedure explains how to cook or reheat food. **ALWAYS** check your cooking settings before leaving the oven unattended.


First, select the position of heating elements and place the food in the center of the turntable. Then, close the door.



1. Make sure that heating element(lower heater) is in the vertical position; refer to page 7 for further details.



2. Press the **Microwave** (微波) button.  
**Result :** The 800W (maximum cooking power) indications are displayed:  
Select the appropriate power level by pressing the **Microwave** button again until the corresponding wattage is displayed.  
Refer to the power level table on the next page.



3. Set the cooking time by pressing the **Down** (▽) and **Up** (△) button.



4. Press the **Start/Pause** (Start/暂停) button.  
**Result :** The oven light comes on and the turntable starts rotating.
  - 1) Cooking starts and when it has finished the oven beeps four times.
  - 2) The end reminder signal will beep 3 times (once every minute).
  - 3) The current time is displayed again.



**Never** switch the microwave oven on when it is empty.



The oven must be plugged into an appropriate wall socket. The turntable must be in position in the oven. If a power level other than the maximum is used, the water takes longer to boil.



If you wish to heat a dish for a short period of time at maximum power (800W), simply press the **Start/Pause** button once for each 30 seconds of cooking time. The oven starts immediately.



When moving heating elements, make sure to use the equipment designed to move heating element while wearing safety gloves provided with the product, and see if temperature drops sufficiently (at least 10 minutes grill or combination after cooking operation) after operation.

## Power Levels

You can choose among the power levels below.

Power Level	Output		
	MWO	TOP GRILL (Upper Heater)	SUPER GRILL (Upper + Lower Heater)
HIGH	800 W		
MEDIUM HIGH	600 W		
MEDIUM	450 W		
MEDIUM LOW	300 W		
DEFROST (解冻)	180 W		
LOW/KEEP WARM	100 W		
GRILL	-	1300 W	2080 W
COMBI I	600 W	1300 W	2080 W
COMBI II	450 W	1300 W	2080 W
COMBI III	300 W	1300 W	2080 W




If you select higher power level, the cooking time must be decreased.  
If you select lower power level, the cooking time must be increased.




## Stopping the Cooking


*You can stop cooking at any time to check the food.*



1. To stop temporarily;  
Open the door.  
**Result :** Cooking stops. To resume cooking, close the door and press  $\diamond$  again.



2. To stop Completely;  
Press the **Stop** (⏻) button.  
**Result :** The cooking stops.  
If you wish to cancel the cooking settings, press the **Stop** (⏻) button again.


 You can cancel any setting before starting cooking by simply pressing **Stop** (⏻).

## Adjusting the Cooking Time

*You can increase the cooking time by pressing the  $\diamond$  button once for each 30 seconds to be added.*






Press the  $\diamond$  button once for each 30 seconds to be added.

 You can not adjust the time during cooking when Auto modes are selected.

## Using the Steam Cleaning

*The steam provided by steam clean system will soak the cavity surface. After using steam clean function, you can easily clean the cavity of oven.*


-  use this function only after the oven has completely cooled. (Room temperature)
-  Use normal water only, and no distilled water.



1. Open the Door.



2. Fill with water following guide line (water level) outside the water bowl.  
(The line is about 50ml.)




3. Insert water bowl into upper water bowl holder on the right wall of cooking chamber.


4. Close the door.



5. Press the **Steam clean** (⊙) button.  
It can be seen **MISTY** during steam cleaning, but it is not a defect **BUT STEAM SHIELDS THE light INSIDE.**



6. Open the Door.



7. Please clean cavity of oven with dried dishtowel. Remove the turntable and only under rack with kitchen paper.



### Warning!

- Water Bowl only can be use during **Steam clean** (⊙) mode.
- When cooking non-liquid items, remove water bowl because it will damage and cause fire to the microwave oven.

# Using the Auto Reheat Feature

With the Auto Reheat feature, the cooking time is set automatically. You can adjust the number of servings by pressing the appropriate Auto Reheat button the required number of times.

First, select the position of heating elements and place the food in the center of the turntable. Then, close the door.



1. Make sure that the heating element(upper heater) is in the horizontal position and heating element(lower heater) is in the vertical position; refer to page 7 for further details.
2. Press the **Auto Reheat** (🔥) button which you want the required number of times.
3. Select the food serving by pressing **Down**(▽) and **Up**(△) button
4. Press **Start/Stop** (◇) button  
**Result :** When it has finished:
  - 1) The oven beeps four times.
  - 2) The end reminder signal will beep 3 times. (once every minute)
  - 3) The current time is displayed again.

☒ Use only recipients that are microwave-safe.


🧤 When moving heating elements, make sure to use the equipment designed to move heating element while wearing safety gloves provided with the product, and see if temperature drops sufficiently (at least 10 minutes after grill or combination cooking operation) after operation.

The following table presents 3 Auto Reheat Programmes and the quantities, standing times and appropriate recommendations.


Code/Food	Serving Size	Standing Time	Recommendations
1. 🍽️ <b>Ready Meal (chilled)</b>	300-350 g 400-450 g	3 min	Put on a ceramic plate and cover with microwave cling film. This programme is suitable for meals consisting of 3 components (e.g. meat with sauce, vegetables and a side dish like potatoes, rice or pasta).
2. 🍲 <b>Soup/Stew (chilled)</b>	300-350 ml 400-450 ml	3 min	Pour the soup or stew into a deep ceramic soup plate or bowl. Cover during heating and standing time. Stir before and after standing time.
3. ☕ <b>Drinks (coffee, milk, tea, water with room temperature)</b>	150 ml (1 cup) 250 ml (1 mug)	1-2 min	Pour into a ceramic cup (150 ml) or mug (250 ml) and place in the centre of turntable. Reheat uncovered. Stir carefully before and after standing time.

## Using the Auto Defrost Feature


The Auto Defrost feature enables you to defrost meat, poultry or fish. The defrost time and power level are set automatically. You simply select the programme and the weight.

 Use only dishes that are microwave-safe.


First, select the position of heating elements and place the food in the center of the turntable. Then, close the door..



1. Make sure that the heating element(upper heater) is in the horizontal position and heating element(lower heater) is in the vertical position; refer to page 7 for further details.






2. Press the **Auto Defrost** (解冻) button.  
Press the **Auto Defrost** (解冻) button one or more times according to the type of food to be defrosted. Refer to the table for further details.




3. Select the food weight by pressing the **Down** (▽) and **Up** (△) button.



4. Press  button.  
**Result :**
  - ◆ Defrosting begins.
  - ◆ The oven beeps halfway through defrosting to remind you to turn the food over.
  - ◆ Press  again to finish defrosting. When it has finished.
    - 1) The oven beeps four times.
    - 2) The end reminder will beep 3 times (once every minute).
    - 3) The current time is displayed again.





 You can also defrost food manually. To do so, select the microwave cooking/reheating function with a power level of 180W. Refer to the section entitled “Cooking/Reheating” on page 8 for further details.

 When moving heating elements, make sure to use the equipment designed to move heating element while wearing safety gloves provided with the product, and see if temperature drops sufficiently (at least 10 minutes after grill or combination cooking operation) after operation.

## Auto Defrost Settings

The following table presents the various Auto Defrost programmes, quantities, standing times and appropriate recommendations.


Remove all kinds of package material before defrosting. Place meat, poultry and fish on a ceramic plate.

Code/ Food	Serving Size	Standing Time	Recommendations
<b>1.Meat</b> 	200-2000 g	20-60 min	Shield the edges with aluminium foil. Turn the meat over, when the oven beeps. This programme is suitable for beef, lamb, pork, steaks, chops, minced meat.
<b>2.Poultry</b> 	200-2000 g	20-60 min	Shield the leg and wing tips with aluminium foil. Turn the poultry over, when the oven beeps. This programme is suitable for whole chicken as well as for chicken portions.
<b>3.Fish</b> 	200-2000 g	20-50 min	Shield the tail of a whole fish with aluminium foil. Turn the fish over, when the oven beeps. This programme is suitable for whole fishes as well as for fish fillets.
<b>4.Fruit</b> 	100-600 g	5-20 min	Spread fruits evenly into a flat glass dish or use a flat glass plate. This programme is suitable for all kinds of fruit.

## Choosing the Accessories

EN

*Use microwave-safe recipients; do not use plastic containers, dishes, paper cups, towels, etc.*



If you wish to select the combined cooking mode (grill and microwave), use only dishes that are microwave-safe and oven-proof. Metallic cookware or utensils may damage your oven.



For further details on suitable cookware and utensils, refer to the Cookware Guide on page 19 .

## Top Grilling


*The top grill enables you to heat and brown food quickly, without using microwaves. To this aim, a grill rack(metal rack) is supplied with your microwave oven.*




The upper heater can be used without lower heater if you want to brown top side of food only (see Grill Guide for Top Grill on page 28). Whenever the top grill mode is used, make sure that the lower grill-heating element in vertical position on back-wall.




Preheating the grill elements for 3 minutes will make the food brown more quickly.




1. Make sure that the heating element(lower heater) is in the vertical position; refer to page 7 for further details.



2. Preheat the grill to the required temperature, by pressing the **Grill / Combi** (烧烤) button and set the preheat time by pressing the **Down** (▽) and **Up** (△) button and ◇ button.



3. Open the door and place the food on the rack.



4. Press the **Grill / Combi** (烧烤) button. Select the cooking time by pressing the **Down** (▽) and **Up** (△) buttons. (The maximum grilling time is 60 minute.)



5. Press the ◇ button.

Result : The oven light comes on and the turntable starts rotating.

- 1) Cooking starts and when it has finished the oven beeps four times.
- 2) The end reminder signal will beep 3 times (once every minute).
- 3) The current time is displayed again.



Always use oven gloves when touching the dishes in the oven, as they will be very hot.



When moving heating elements, make sure to use the equipment designed to move heating element while wearing safety gloves provided with the product, and see if temperature drops sufficiently (at least 10 minutes grill or combination after cooking operation) after operation.

## Super Grilling

The super grill enables you to heat and brown food very quickly, without using microwaves. To this aim, a grill rack(metal rack) is supplied with your microwave oven.


- ☒ The grill-heating elements are located underneath the ceiling and at the back of the cavity.

They operate while the door is closed and the turntable is rotating. The turntable's rotation makes the food brown more evenly. Before using super grill modes make sure that lower heating element is in horizontal position.


When using super grill function both elements will heat up and the food will be browned from top side and bottom side.

The advantage of super grill function is that you do not have to turnover food (see super Grill Guide on page 26 to 28).


- ☒ Preheating the grill elements for 3 minutes will make the food brown more quickly.




1. Make sure that the heating element(lower heater) is in the horizontal position; refer to page 7 for further details.



2. Preheat the grill to the required temperature, by pressing the **Grill / Combi** (烧烤+微波) button and set the preheat time by pressing the **Down** (▽) and **Up** (△) button and ◇ button.




3. Open the door and place the food on the rack.



4. Press the **Grill / Combi** (烧烤+微波) button. Select the cooking time by pressing the **Down** (▽) and **Up** (△) buttons. (The maximum grilling time is 60 minute.)



5. Press the **Super Grill** (超烧烤) button.  
**Result :** The following indication is displayed:



- ☒ If you press the **Super Grill** button one more time, and the display will be disappeared.
- ☒ The super grill function can be performed only in time of grill or combined microwave plus grill operation.



6. Press the ◇ button.  
**Result :** The oven light comes on and the turntable starts rotating.
  - 1) Cooking starts and when it has finished the oven beeps four times.
  - 2) The end reminder signal will beep 3 times (once every minute).
  - 3) The current time is displayed again.



Always use oven gloves when touching the dishes in the oven, as they will be very hot.




When moving heating elements, make sure to use the equipment designed to move heating element while wearing safety gloves provided with the product, and see if temperature drops sufficiently (at least 10 minutes after grill or combination cooking operation) after operation.


## Combining Microwaves and the Top Grill


EN

*This cooking mode combines the radiant heat that is coming from the grill with the speed of microwave cooking. It operates only while the door is closed and the turntable is rotating. Due to the rotation of the turntable, the food browns evenly on top side.*


**Three combination modes with Top Grill are available with this model: 600 W + Top Grill, 450 W + Top Grill and 300 W + Top Grill.**

 **ALWAYS** use microwave-safe and oven-proof cookware. Glass or ceramic dishes are ideal as they allow the microwaves to penetrate the food evenly.

 **ALWAYS** use oven gloves when touching the recipients in the oven, as they will be very hot.



1. Make sure that the heating element(lower heater) is in the vertical position; refer to page 7 for further details.




2. Place the food on the rack and the rack on the turntable. Close the door.




3. Press the **Grill / Combi** (烧烤+微波) button twice.  
Result : Select the appropriate power level by pressing the **Grill / Combi** (烧烤+微波) button again until the corresponding power level is displayed:  
Twice : 600 W  
Third : 450 W  
Fourth: 300 W

 You cannot set the temperature of the grill.



4. Set the cooking time by pressing the **Down** (▽) and **Up** (△) buttons. The maximum cooking time is 60 minutes.



5. Press the  button.  
Result : Combination cooking starts. When it has finished.  
1) The oven beeps four times.  
2) The end reminder signal will beep 3 times (once every minute).  
3) The current time is displayed again.



The maximum microwave power for the combined microwave and grill mode is 600W.





When moving heating elements, make sure to use the equipment designed to move heating element while wearing safety gloves provided with the product, and see if temperature drops sufficiently (at least 10 minutes after grill or combination cooking operation) after operation.


## Combining Microwaves and the Super Grill

*This cooking mode combines the radiant heat that is coming from the grill with the speed of microwave cooking. It operates only while the door is closed and the turntable is rotating. Due to the rotation of the turntable, the food browns on top side and bottom side. You do not need to turnover the food. Three combination modes with Super Grill are available with this model:*


**600 W + Super Grill, 450 W + Super Grill and 300 W + Super Grill.**

 **ALWAYS** use microwave-safe and oven-proof cookware. Glass or ceramic dishes are ideal as they allow the microwaves to penetrate the food evenly.

 **ALWAYS** use oven gloves when touching the recipients in the oven, as they will be very hot.




1. Make sure that the heating element(lower heater) is in the horizontal position; refer to page 7 for further details.



2. Open the oven door.  
Place the food on the rack and the rack on the turntable.  
Close the door.






3. Press the **Grill / Combi** (烧烤) button twice.  
Result : Select the appropriate power level by pressing the **Grill / Combi** (烧烤) button again until the corresponding power level is displayed:  
Twice : 600 W  
Third : 450 W  
Fourth: 300 W


 You cannot set the temperature of the grill.



4. Press the **Super Grill** (超烤) button.  
Result : The following indication is displayed:




-  Press the **Super Grill** (超烤) button again. Then, display will be cleared
-  The super grill function can be performed only in time of grill or combined microwave plus grill operation.



5. Set the cooking time by pressing the **Down** (▽) and **Up** (△) buttons. The maximum cooking time is 60 minutes.



6. Press the  button.  
Result : Combination cooking starts. When it has finished.  
1) The oven beeps four times.  
2) The end reminder signal will beep 3 times (once every minute).  
3) The current time is displayed again.



The maximum microwave power for the combined microwave and grill mode is 600W.




When moving heating elements, make sure to use the equipment designed to move heating element while wearing safety gloves provided with the product, and see if temperature drops sufficiently (at least 10 minutes after grill or combination cooking operation) after operation.


## Using the Super Grill Auto Cook Features

With the super grill auto cook feature, the cooking time is set automatically. You can adjust the number of serving by pressing the appropriate super grill auto cook button the required number of times.


First, select the position of heating elements and place the food in the center of the turntable. Then, close the door.



1. Make sure that the heating element(lower heater) is in the horizontal position; refer to page 7 for further details.



2. Press the **Auto Cook** ( ) button one or more times according to type of food. Refer to the table for further details.



3. Select the food serving size by pressing **Down** (▽) and **Up** (△) button



4. Press button.  
**Result:** When it has finished.  
1) The oven beeps four times.  
2) The end reminder will beep 3 times (once every minute).  
3) The current time is displayed again.



Use only recipients that are microwave-safe.



When moving heating elements, make sure to use the equipment designed to move heating element while wearing safety gloves provided with the product, and see if temperature drops sufficiently (at least 10 minutes after grill or combination cooking operation) after operation.

The following table presents the various Super Grill Auto Programmes for Roast Meat, Roast Poultry and Roast Fish and the quantities, standing times and appropriate recommendations. The steaks programme is running with Super Grill only. The following programmes are running with a combination of microwaves and super grill.


Code/Food	Serving Size	Standing Time	Recommendations
<b>1. Steaks</b> 	350-400 g (2 pcs) 450-500 g (2-3 pcs)	-	We recommend to preheat the grill with the Super Grill setting for 3 minutes. Brush the beef steaks or lamb steaks with oil and spices. Put them in a circle on the metal rack.
<b>2. Kebab Spits/ Shashlik Spits</b> 	400 g (2-4 spits) 600 g (4-6 spits)	1-2 min.	We recommend to preheat the grill with the Super Grill setting for 3 minutes. Prepare fresh meat cubes of pork, beef or lamb with pieces of vegetables on skewer and spice it. (Do not marinate meat in vinegar.) Put the ready prepared kebab spits side by side on the rack.
<b>1. Chicken Pieces</b> 	200-300 g (1 pc) 400-500 g (2 pcs) 600-700 g (3 pcs)	2 min	We recommend to preheat the grill with the Super Grill setting for 3 minutes. Brush the chicken pieces with oil and spice them with pepper, salt and paprika. Put them in a circle on the high rack with the skin-side down.
<b>2. Chicken Breast</b> 	300 g (1-2 pcs) 400 g (2 pcs) 500 g (2-3 pcs)	-	We recommend to preheat the grill with the Super Grill setting for 3 minutes. Marinate chicken breast. Put breasts in a circle on the rack. This programme can be used for chicken breast as well as turkey breast in slices.
<b>1. Roast Fish</b> 	300 g (1pc) 600 g (2pcs)	3-4 min.	We recommend to preheat the grill with the Super Grill setting for 3 minutes. Brush skin of whole fish with oil and salt Add herbs and spices inside fish. Put one fish beside the centre, put two fish side by side, head to tail on the rack. This programme is suitable for whole fish like trout, carp, dorade or zander.
<b>2. Fish Fillets</b> 	200-300 g (1 pc) 400-500 g (2 pcs)	3-4 min.	We recommend to preheat the grill with the Super Grill setting for 3 minutes. Put fish fillets side by side on the rack, leave centre of rack clear. This programme is suitable for fish fillets like salmon, pollack or rose-fish fillets.



## Using the Super Grill Auto Reheat Features

With the super grill auto reheat feature, the cooking time is set automatically. You can adjust the number of serving by pressing the appropriate super grill auto reheat button the required number of times.


First, select the position of heating elements and place the food in the center of the turntable. Then, close the door.



1. Make sure that the heating element(lower heater) is in the horizontal position; refer to page 7 for further details.



2. Press the **Toast / Pizza** (吐司/比萨) button which you want the required number of times. Refer to the table on the next page for further details.



3. Select the food serving size by pressing **Down** (下调) and **Up** (上调) button



4. Press ◆ button.  
**Result :** When it has finished.
  - 1) The oven beeps four times.
  - 2) The end reminder will beep 3 times (once every minute).
  - 3) The current time is displayed again.



Use only recipients that are microwave-safe.





When moving heating elements, make sure to use the equipment designed to move heating element while wearing safety gloves provided with the product, and see if temperature drops sufficiently (at least 10 minutes after grill or combination cooking operation) after operation.

## Using the Super Grill Auto Reheat Features (continued)

The following table presents the Super Grill Auto Programmes for Toast Hawaii and Frozen Pizza and the quantities, standing times and appropriate recommendations.


These programmes are running with a combination of microwaves and super grill.

Code/ Food	Serving Size	Standing Time	Recommendations
<b>1. Toast Hawaii</b> 	250-300 g (2 pcs) 450-500 g (4 pcs)	1-2 min.	Take 2 or 4 slices of toast and put e.g. slice of ham, pineapple and cheese on top of each toast slice. Put the prepared cheese toasts side by side on rack.
<b>2. Frozen Pizza</b> 	200 g 300 g 400 g	-	Put the frozen pizza on the rack.

## Switching the Beeper Off


EN

You can switch the beeper off whenever you want.



1. Press the **Stop** (⏏) and **Stop/Pop** (⬠) buttons at the same time.  
**Result :** The oven will not beep each time you press a button.

OFF




2. To switch the beeper back on, press the **Stop** (⏏) and **Stop/Pop** (⬠) buttons again at the same time.  
**Result :** The oven operates with the beeper on again.

ON

## Safety-Locking Your Microwave Oven

Your microwave oven is fitted with a special **Child Safety** programme, which enables the oven to be “locked” so that children or anyone unfamiliar with it cannot operate it accidentally.


The oven can be locked at any time.



1. Press the **Stop** (⏏) and **Down** (▼) buttons at the same time.

**Result :** The oven is locked (no functions can be selected).

L



2. To unlock the oven, press the **Stop** (⏏) and **Down** (▼) buttons again at the same time.  
**Result :** The oven can be used normally.

## Cookware Guide

*To cook food in the microwave oven, the microwaves must be able to penetrate the food, without being reflected or absorbed by the dish used.*

*Care must therefore be taken when choosing the cookware. If the cookware is marked microwave-safe, you do not need to worry.*

*The following table lists various types of cookware and indicates whether and how they should be used in a microwave oven.*

Cookware	Microwave-Safe	Comments
Aluminium foil	✓ X	Can be used in small quantities to protect areas against overcooking. Arcing can occur if the foil is too close to the oven wall or if too much foil is used.
Browning plate	✓	Do not preheat for more than eight minutes.
China and earthenware	✓	Porcelain, pottery, glazed earthenware and bone china are usually suitable, unless decorated with a metal trim.
Disposable polyester cardboard dishes	✓	Some frozen foods are packaged in these dishes.
Fast-food packaging		
• Polystyrene cups containers	✓	Can be used to warm food. Overheating may cause the polystyrene to melt.
• Paper bags or newspaper	X	May catch fire.
• Recycled paper or metal trims	X	May cause arcing.
Glassware		
• Oven-to-table ware	✓	Can be used, unless decorated with a metal trim.
• Fine glassware	✓	Can be used to warm foods or liquids. Delicate glass may break or crack if heated suddenly.
• Glass jars	✓	Must remove the lid. Suitable for warming only.
Metal		
• Dishes	X	May cause arcing or fire.
• Freezer bag twist ties	X	

### Paper

- Plates, cups, napkins and Kitchen paper ✓ For short cooking times and warming. Also to absorb excess moisture.
- Recycled paper X May cause arcing.

### Plastic

- Containers ✓ Particularly if heat-resistant thermoplastic. Some other plastics may warp or discolour at high temperatures. Do not use Melamine plastic.
- Cling film ✓ Can be used to retain moisture. Should not touch the food. Take care when removing the film as hot steam will escape.
- Freezer bags ✓ X Only if boilable or oven-proof. Should not be airtight. Prick with a fork, if necessary.

### Wax or grease-proof paper ✓

Can be used to retain moisture and prevent spattering.

- ✓ :Recommended
- ✓X :Use Caution
- X :Unsafe

# Cooking Guide

## MICROWAVES

Microwave energy actually penetrates food, attracted and absorbed by its water, fat and sugar content.

The microwaves cause the molecules in the food to move rapidly. The rapid movement of these molecules creates friction and the resulting heat cooks the food.

## COOKING

### Cookware for microwave cooking:

Cookware must allow microwave energy to pass through it for maximum efficiency. Microwaves are reflected by metal, such as stainless steel, aluminium and copper, but they can penetrate through ceramic, glass, porcelain and plastic as well as paper and wood. So food must never be cooked in metal containers.

### Food suitable for microwave cooking:

Many kinds of food are suitable for microwave cooking, including fresh or frozen vegetables, fruit, pasta, rice, grains, beans, fish, and meat. Sauces, custard, soups, steamed puddings, preserves, and chutneys can also be cooked in a microwave oven. Generally speaking, microwave cooking is ideal for any food that would normally be prepared on a hob. Melting butter or chocolate, for example (see the chapter with tips, techniques and hints).

### Covering during cooking

To cover the food during cooking is very important, as the evaporated water rises as steam and contributes to cooking process. Food can be covered in different ways: e.g. with a ceramic plate, plastic cover or microwave suitable cling film.

### Standing times

After cooking is over, standing time for the food is important to allow the temperature to even out within the food.

### Cooking Guide for frozen vegetables

Use a suitable glass pyrex bowl with lid. Cook covered for the minimum time - see table. Continue cooking to get the result you prefer.

Stir twice during cooking and once after cooking. Add salt, herbs or butter after cooking. Cover during standing time.

Food	Portion	Power	Time (min.)	Standing Time(min.)	Instructions
Spinach	150g	600W	4½-5½	2-3	Add 15 ml (1 tablespoon) cold water.
Broccoli	300g	600W	9-10	2-3	Add 30 ml (2 tbsp.) cold water.
Peas	300g	600W	7½-8½	2-3	Add 15 ml (1 tbsp.) cold water.

Food	Portion	Power	Time (min.)	Standing Time(min.)	Instructions
Green Beans	300g	600W	8-9	2-3	Add 30 ml (2 tbsp.) cold water.
Mixed Vegetables (carrots/peas/corn)	300g	600W	7½-8½	2-3	Add 15 ml (1 tbsp.) cold water.
Mixed Vegetables (Chinese style)	300g	600W	8-9	2-3	Add 15 ml (1 tbsp.) cold water.

### Cooking Guide for rice and pasta

**Rice:** Use a large glass pyrex bowl with lid - rice doubles in volume during cooking. Cook covered. After the cooking time is over, stir before standing time and add salt or add herbs and butter. Remark: the rice may not have absorbed all water after the cooking time is finished.

**Pasta:** Use a large glass pyrex bowl. Add boiling water, a pinch of salt and stir well. Cook uncovered. Stir occasionally during and after cooking. Cover during standing time and drain thoroughly afterwards.

Food	Portion	Power	Time (min.)	Standing Time(min.)	Instructions
White Rice (parboiled)	250g	800W	16-17	5	Add 500 ml cold water.
Brown Rice (parboiled)	250g	800W	21-22	5	Add 500 ml cold water.
Mixed Rice (rice + wild rice)	250g	800W	17-18	5	Add 500 ml cold water.
Mixed Corn (rice + grain)	250g	800W	18-19	5	Add 400 ml cold water.
Pasta	250g	800W	11-12	5	Add 1000 ml hot water.

## Cooking Guide (continued)

### Cooking Cooking Guide for fresh vegetables

Use a suitable glass pyrex bowl with lid. Add 30-45 ml cold water (2-3 tbsp.) for every 250 g unless another water quantity is recommended - see table. Cook covered for the minimum time - see table. Continue cooking to get the result you prefer. Stir once during and once after cooking. Add salt, herbs or butter after cooking. Cover during a standing time of 3 minutes.

Hint: Cut the fresh vegetables into even sized pieces. The smaller they are cut, the quicker they will cook.

**All fresh vegetables should be cooked using full microwave power (800 W).**

Food	Portion	Time (min.)	Standing Time (min.)	Instructions
Broccoli	250g 500g	4-4½ 8-8½	3	Prepare even sized florets. Arrange the stems to the centre.
Brussels Sprouts	250g	5½-6½	3	Add 60-75 ml (5-6 tbsp.) water.
Carrots	250g	4½-5	3	Cut carrots into even sized slices.
Cauliflower	250g 500g	5-5½ 8½-9	3	Prepare even sized florets. Cut big florets into halves. Arrange stems to the centre.
Courgettes	250g	3½-4	3	Cut courgettes into slices. Add 30 ml (2 tbsp.) water or a knob of butter. Cook until just tender.
Egg Plants	250g	3½-4	3	Cut egg plants into small slices and sprinkle with 1 tablespoon lemon juice.
Leeks	250g	4½-5	3	Cut leeks into thick slices.
Mushrooms	125g 250g	1½-2 3-3½	3	Prepare small whole or sliced mushrooms. Do not add any water. Sprinkle with lemon juice. Spice with salt and pepper. Drain before serving.

Food	Portion	Time (min.)	Standing Time (min.)	Instructions
Onions	250g	5½-6	3	Cut onions into slices or halves. Add only 15 ml (1 tbsp.) water.
Pepper	250g	4½-5	3	Cut pepper into small slices.
Potatoes	250g 500g	4-5 7½-8½	3	Weigh the peeled potatoes and cut them into similar sized halves or quarters.
Turnip Cabbage	250g	5-5½	3	Cut turnip cabbage into small cubes.

EN

### REHEATING

Your microwave oven will reheat food in a fraction of the time that conventional ovens hobs normally take.

Use the power levels and reheating times in the following chart as a guide. The times in the chart consider liquids with a room temperature of about +18 to +20°C or a chilled food with a temperature of about +5 to +7°C.

#### Arranging and covering

Avoid reheating large items such as joint of meat - they tend to overcook and dry out before the centre is piping hot. Reheating small pieces will be more successful.

#### Power levels and stirring

Some foods can be reheated using 800 W power while others should be reheated using 600 W, 450 W or even 300 W.

Check the tables for guidance. In general, it is better to reheat food using a lower power level, if the food is delicate, in large quantities, or if it is likely to heat up very quickly (mince pies, for example).

Stir well or turn food over during reheating for best results. When possible, stir again before serving.

Take particular care when heating liquids and baby foods. To prevent eruptive boiling of liquids and possible scalding, stir before, during and after heating. Keep them in the microwave oven during standing time. We recommend putting a plastic spoon or glass stick into the liquids. Avoid overheating (and therefore spoiling) the food.

It is preferable to underestimate cooking time and add extra heating time, if necessary.

#### Heating and standing times

When reheating food for the first time, it is helpful to make a note of the time taken - for future reference.

Always make sure that the reheated food is piping hot throughout.

Allow food to stand for a short time after reheating - to let the temperature even out.

The recommended standing time after reheating is 2-4 minutes, unless another time is recommended in the chart.

Take particular care when heating liquids and baby food. See also the chapter with the safety precautions.

### REHEATING LIQUIDS

Always allow a standing time of at least 20 seconds after the oven has been switched off to allow the temperature to even out. Stir during heating, if necessary, and **ALWAYS** stir after heating. To prevent eruptive boiling and possible scalding, you should put a spoon or glass stick into the beverages and stir before, during and after heating.

### REHEATING BABY FOOD

#### BABY FOOD:

Empty into a deep ceramic plate. Cover with plastic lid. Stir well after reheating!

- Let stand for 2-3 minutes before serving. Stir again and check the temperature. Recommended serving temperature: between 30-40°C.

#### BABY MILK:

Pour milk into a sterilised glass bottle. Reheat uncovered. Never heat a baby's bottle with teat on, as the bottle may explode if overheated. Shake well before standing time and again before serving ! Always carefully check the temperature of baby milk or food before giving it to the baby. Recommended serving temperature: about 37°C.

#### REMARK:

Baby food particularly needs to be checked carefully before serving to prevent burns.

- Use the power levels and times in the next table as a guide lines for reheating.

## Cooking Guide (continued)

### Reheating Baby Food and Milk

Use the power levels and times in this table as guide lines for reheating.

Food	Portion	Power	Time	Standing Time (min.)	Instructions
Baby food (vegetables + meat)	190g	600W	30sec.	2-3	Empty into ceramic deep plate. Cook covered. Stir after cooking time. Stand for 2-3 minutes. Before serving, stir well and check the temperature carefully.
Baby porridge (grain + milk + fruit)	190g	600W	20sec.	2-3	Empty into ceramic deep plate. Cook covered. Stir after cooking time. Stand for 2-3 minutes. Before serving, stir well and check the temperature carefully.
Baby milk	100ml	300W	30-40sec.	2-3	Stir or shake well and pour into a sterilised glass bottle. Place into the centre of turn-table. Cook uncovered. Shake well and stand for at least 3 minutes. Before serving, shake well and check the temperature carefully.
	200ml		50 sec to 1min.		

### Reheating Liquids and Food

Use the power levels and times in this table as a guide lines for reheating.

Food	Portion	Power	Time (min.)	Standing Time (min.)	Instructions
Drinks (coffee, tea, water with room temperature)	150ml (1 cup) 250ml (1 mug)	800W	1-1 ½ 1 ½ -2	1-2	Pour in to a ceramic cup and reheat uncovered. Place cup (150ml) or mug (250ml) in the centre of turntable, Stir carefully before and after standing time.
Soup (chilled)	250g	800W	3-3½	2-3	Pour into a deep ceramic plate. Cover with plastic lid. Stir well after reheating. Stir again before serving.
Stew (chilled)	350g	600W	5 ½ -6 ½	2-3	Put stew in a deep ceramic plate. Cover with plastic lid. Stir occasionally during reheating and again before standing and serving.
Pasta with sauce (chilled)	350g	600W	4 ½ -5 ½	3	Put pasta (e.g. spaghetti or egg noodles) on a flat ceramic plate. Cover with microwave cling film. Stir before serving.
Filled pasta with sauce (chilled)	350g	600W	5-6	3	Put filled pasta (e.g. ravioli, tortellini) in a deep ceramic plate. Cover with plastic lid. Stir occasionally during reheating and again before standing and serving.
Plated Meal (chilled)	350g	600W	5-5 ½	3	Plate a meal of 2-3 chilled components on a ceramic dish. Cover with microwave cling-film.

EN

## Cooking Guide (continued)

EN

### DEFROSTING

Microwaves are an excellent way of defrosting frozen food. Microwaves gently defrost frozen food in a short period of time. This can be of great advantage, if unexpected guests suddenly show up.

Frozen poultry must be thoroughly thawed before cooking. Remove any metal ties and take it out of any wrapping to allow thawed liquid to drain away.

Put the frozen food on a dish without cover. Turn over half way, drain off any liquid and remove any giblets as soon as possible.  
Check the food occasionally to make sure that it does not feel warm.  
If smaller and thinner parts of the frozen food start to warm up, they can be shield by wrapping very small strips of aluminium foil around them during defrosting.

Should poultry start to warm up on the outer surface, stop thawing and allow it to stand for 20 minutes before continuing.  
Leave the fish, meat and poultry to stand in order to complete defrosting. The standing time for complete defrosting will vary depending on the quantity defrosted. Please refer to the table below.

**Hint:** Flat food defrosts better than thick and smaller quantities need less time than bigger ones. Remember this hint while freezing and defrosting food.

For defrosting of frozen food with a temperature of about -18 to -20 °C, use the following table as a guide.

**All frozen food should be defrosted using defrosting power level (180 W, ).**

Food	Portion	Time (min.)	Standing Time (min.)	Instructions
Meat				
Minced beef	250g 500g	6½ -7½ 10-12	5-25	Place the meat on a flat ceramic plate. Shield thinner edges with aluminium foil. Turn over after half of defrosting time!
Pork steaks	250g	6½ -7½		
Poultry				
Chicken pieces	500g (2 pcs)	13½-15½	15-40	First, put chicken pieces first skin-side down, whole chicken first breast-side-down on a flat ceramic plate. Shield the thinner parts like wings and ends with aluminium foil. Turn over after half of defrosting time!
Whole chicken	900g	28-30		
Fish				
Fish fillets	200g (2 pcs) 400g (4 pcs)	5-7 11-13	5-15	Put frozen fish in the middle of a flat ceramic plate. Arrange the thinner parts under the thicker parts. Shield narrow ends with aluminium foil. Turn over after half of defrosting time!
Fruits				
Berries	250g	5-7	5 - 10	Distribute fruits on a flat, round glass dish (with a large diameter).
Bread				
Bread rolls (each ca. 50 g)	2 pcs 4 pcs	½-1 2-2½	5 - 20	Arrange rolls in a circle or bread horizontally on kitchen paper in the middle of turntable. Turn over after half of defrosting time!
Toast/ Sandwich	250g	4½-5		
German bread (wheat+ rye flour)	500g	7-9		



### ***SUPER GRILL***

The grill-heating elements are located underneath the ceiling and at the back of the cavity.

They operate while the door is closed and the turntable is rotating. The turntable's rotation makes the food brown more evenly.

Before using super grill modes make sure that lower heating element is in horizontal position.

When using super grill setting three elements will heat up and the food will be browned from top side and bottom side.

The advantage of super grill setting is that you do not have to turnover food (see Super Grill Guide).

Preheating the grill elements for 2-3 minutes will make the food brown more quickly.

#### **Cookware for grilling:**

Should be flameproof and may include metal. Do not use any type of plastic cookware, as it can melt.

#### **Food suitable for grilling:**

Chicken pieces, chops, sausages, steaks, hamburgers, bacon and gammon rashers, thin fish portions, sandwiches and all kinds of toast with toppings.

#### **Important remark:**

Whenever the super grill function is used, make sure that the lower grill heating element is in the horizontal position and not on the back-wall in the vertical position.

Please remember that food must be placed on the rack, unless another instruction is recommended.

### ***MICROWAVE + SUPER GRILL***

This cooking mode combines the radiant heat that is coming from the grill with the speed of microwave cooking. It operates only while the door is closed and the turntable is rotating. Due to the rotation of the turntable, the food browns on top side and bottom side. You do not need to turnover the food. Three combination modes with Super Grill are available with this model:

600 W + Super Grill, 450 W + Super Grill and 300 W + Super Grill.

#### **Important remark:**

Whenever the combination mode (microwave + super grill) is used, make sure that lower grill heating element is in the horizontal position and not on the back-wall or in the vertical position. The food should be placed on the rack, unless another instruction is recommended. Please refer to the instructions in the following chart.

### ***TOP GRILL***

The upper heater can be used without lower heater if you want to brown top side of food only (see Grill Guide for Top Grill).

Whenever the top grill mode is used, make sure that the lower grill-heating element is in vertical position on back-wall.

The food should be placed on the rack, unless another instruction is recommended.

### ***MICROWAVE + TOP GRILL***

This cooking mode combines the radiant heat that is coming from the grill with the speed of microwave cooking. It operates only while the door is closed and the turntable is rotating. Due to the rotation of the turntable, the food browns evenly on top side.

Three combination modes with Top Grill are available with this model:  
600 W + Top Grill, 450 W + Top Grill and 300 W + Top Grill.

#### **Important remark:**

Whenever the combination mode (microwave + top grill) is used, make sure that the lower grill-heating element is in vertical position on back-wall.

The food should be placed on the rack, unless another instruction is recommended.

#### **Cookware for cooking with microwave + grill**

Please use cookware that microwaves can pass through. Cookware should be flameproof. Do not use metal cookware with combination mode. Do not use any type of plastic cookware, as it can melt.

#### **Food suitable for microwave + grill cooking:**

Food suitable for combination mode cooking include all kinds of cooked food which need heating and browning (e.g. pasta gratin), as well as foods which require a short cooking time to brown the top of the food. Also, the grill modes can be used for food portions that benefit from a browned and crispy top side. Please refer to the grill charts for further details.

## Cooking Guide (continued)

EN

### Super Grill Guide for toasts, pastries and vegetables

Before using the Super Grill modes make sure that lower heater is in horizontal position.

Use the super levels and times in this table as guide lines for grilling.

Use oven gloves while taking out food. Do not touch the hot heaters directly after grilling.

Food	Portion	Preheating Time(min.) Super Grill	Power	Time (min.)	Instructions
Toast Slices	4 pcs	3	Super Grill only	2-4	Put toast slices on rack.
Tomato-Cheese-Toast	2pcs (250 g)	3	300 W + Super Grill	3-4	Take a slice of toast bread and put a slice of ham, tomato, cheese on top of each toast slice.
Toast Hawaii (ham, pineapple, cheese slices)	2pcs (250 g)	3	300 W + Super Grill	3½-4½	Toast the bread slices first. Put the toasts with topping side by side on the high rack. Stand for 2-3 minutes.
Puff Pastry (fruit filling)	200 g (2pcs)	3	Super Grill only	8-10	Fill fresh puff pastry with e.g. apricots. Put 2 filled pastries opposite to each other on baking paper on rack. Brush with stirred egg.
Omelette	150 g	3	300 W + Super Grill	5-6	Stir 2 eggs, 2 tbsp. milk and add spices. Fill into a greased, flat glass pyrex dish and put some cheese on top. Put dish on rack.
Vegetable Spits	200 g (2 spits)	3	Super Grill only	11-13	Cut vegetables e.g. courgettes, pepper, mushrooms into pieces and put on a skewer. Put oil and spice on top and set spits side by side on rack.

Food	Portion	Preheating Time(min.) Super Grill	Power	Time (min.)	Instructions
Baked Potatoes	500 g	3	600W + Super Grill	8-10	Put the potatoes (4-5 pcs) in a circle on the rack .
Pasta Gratin/ Lasagne	400 g	3	450W + Super Grill	8-10	Put the fresh pasta gratin, e.g. lasagne into a suitable glass dish. Put the dish on the rack. After cooking stand for 2-3 minutes.

## Cooking Guide (continued)

### Super Grill Guide for meat, poultry and fish

Before using the Super Grill modes make sure that lower heater is in horizontal position.

Use the super levels and times in this table as guide lines for grilling.

Use oven gloves while taking out food. Do not touch the hot heaters directly after grilling.

Fresh Food	Portion	Preheating Time(min.) Super Grill	Power	Time (min.)	Instructions
Beef Steaks (medium)	300-400 g (4 pcs)	3	Super Grill only	11-13	Brush beef steaks or lamb steaks with oil and spices. Put them in a circle on the metal rack.
Kebab Spits/ Shashlik Spits	400 g (4 pcs)	3	300 W + Super Grill	10-12	Put fresh meat cubes of pork, beef, or lamb with pieces of vegetables and spices on skewer. Do not marinate meat in vinegar. Put the ready prepared kebab spits side by side on rack. Stand for 1-2 minutes.
Chicken Pieces	400-500 g	3	300 W + Super Grill	13-15	Brush chicken pieces with oil and spices. Put them opposite to each other on the rack. Stand for 2-3 minutes.
Chicken Breast Fillets	300-400 g (2 pcs)	3	300 W + Super Grill	9-11	Marinate fillets of chicken breast or turkey breast and put on opposite to each other on rack.
Roast Fish	600 g (2 pcs)	3	300 W + Super Grill	13-15	Brush skin of e.g. trout or dorade with oil and salt. Add herbs and spices inside of fish. Put fishes side by side, head to tail on rack. Stand for 2-3 minutes after grilling.

Fresh Food	Portion	Preheating Time(min.) Super Grill	Power	Time (min.)	Instructions
Salmon Fillet	200-300 g (1 pc)	3	300 W + Super Grill	7-9	Put fish fillet beside centre on rack. Stand for 2-3 min. after grilling.

EN

## Cooking Guide (continued)

EN

### Super Grill Guide for Frozen Food

Before using the Super Grill modes make sure that lower heater is in horizontal position.

Use the super levels and times in this table as guide lines for grilling.

Use oven gloves while taking out food. Do not touch the hot heaters directly after grilling.

Frozen Food	Portion	Preheating Time (min) Super Grill	Power	Time (min)	Instructions
Garlic Bread, (pre-baked)	175 g	-	300 W + Super Grill	3-5	Put the baguette, filled with garlic butter on the rack.
Baguettes with Topping	250 g (2 pcs)	-	300 W + Super Grill	8-10	Put the baguettes (e.g. with ham, cheese, tomato topping) sides by side on the rack. Stand for 1-2 min after grilling.
Pizza	300-400 g	-	450 W + Super Grill	7-9	Put the pizza on rack.
Fish Gratin	400 g	-	450 W + Super Grill	15-17	Put the frozen fish fillet into a suitable sized oven proof glass dish. Put dish on the rack. Stand for 2-3 min after cooking.

### Grill Guide for Top Grill

Preheat the grill with the grill-function for 3 minutes.

Use the power levels and times in this table as guide lines for grilling.

Food	Portion	Power	1. Side Time (min.)	2. Side Time (min.)	Instructions
Toast Slices	4pcs (each 25 g)	Top Grill only	3-4	2-3	Put the toast slices side by side on the rack.
Frozen Baguettes/ Bread Rolls	2-4 pieces	Mw + Top Grill	300 W + Grill 2-2 ½	Grill only 1-2	Arrange rolls in a circle on turntable. Grill the second side of the rolls up to the crisp you prefer. Stand for 2-5 minutes.
Grilled Tomatoes	200 g (2pcs)	300 W + Top Grill	3-4	---	Cut tomatoes into halves. Put some cheese on top. Arrange in a circle in a flat glass pyrex dish. Place it on the rack.
Baked Apples	2 apples (400g)	300 W + Top Grill	6-7	----	Core the apples and fill them with raisins and jam. Put some almond slices on top. Put apples on a flat glass pyrex dish. Place the dish directly on the turntable.
Frozen Pasta Gratin	400 g	600 W + Top Grill	10-12	---	Put frozen pasta (lasagne, macaroni or caneloni) into a small flat rectangular glass pyrex dish. Put the dish directly on the turntable. After cooking stand for 2-3 minutes.
Frozen Oven Chips	250 g	300 W + Top Grill	9-10	4-5	Use a flat glass pyrex dish. Insert baking paper in bottom of dish. Put oven chips in dish, set dish on rack.

## Cooking Guide (continued)

### SPECIAL HINTS

#### MELTING BUTTER

Put 50 g butter into a small deep glass dish. Cover with plastic lid. Heat for 30-40 seconds using 800 W, until butter is melted.

#### MELTING CHOCOLATE

Put 100 g chocolate into a small deep glass dish. Heat for 3-5 minutes, using 450 W until chocolate is melted. Stir once or twice during melting. Use oven gloves while taking out!

#### MELTING CRYSTALLIZED HONEY

Put 20 g crystallized honey into a small deep glass dish. Heat for 20-30 seconds using 300 W, until honey is melted.

#### MELTING GELATINE

Lay dry gelatine sheets (10 g) for 5 minutes into cold water. Put drained gelatine into a small glass pyrex bowl. Heat for 1 minute using 300 W. Stir after melting.

#### COOKING GLAZE/ICING (FOR CAKE AND GATEAUX)

Mix instant glaze (approximately 14 g) with 40 g sugar and 250 ml cold water. Cook uncovered in a glass pyrex bowl for 3 ½ to 4 ½ minutes using 800 W, until glaze/icing is transparent. Stir twice during cooking.

#### COOKING JAM

Put 600 g fruits (for example mixed berries) in a suitable sized glass pyrex bowl with lid. Add 300 g preserving sugar and stir well. Cook covered for 10-12 minutes using 800 W. Stir several times during cooking. Empty directly into small jam glasses with twist-off lids. Stand on lid for 5 minutes.

#### COOKING PUDDING

Mix pudding powder with sugar and milk (500 ml) by following the manufacturers instructions and stir well. Use a suitable sized glass pyrex bowl with lid. Cook covered for 6 ½ to 7 ½ minutes using 800 W. Stir several times well during cooking.

#### BROWNING ALMOND SLICES

Spread 30 g sliced almonds evenly on a medium sized ceramic plate. Stir several times during browning for 3 ½ to 4 ½ minutes using 600 W. Let it stand for 2-3 minutes in the oven. Use oven gloves while taking out!

## Cleaning Your Microwave Oven

*The following parts of your microwave oven should be cleaned regularly to prevent grease and food particles from building up:*

- *Inside and outside surfaces*
- *Door and door seals*
- *Turntable and Roller rings*



**ALWAYS** ensure that the door seals are clean and the door closes properly.



Failure to maintain the oven in a clean condition could lead to deterioration of the surface that could adversely affect the of the appliance and possibly result in a hazardous situation.

1. Clean the outside surfaces with a soft cloth and warm, soapy water. Rinse and dry.
2. Remove any splashes or stains on the inside surfaces or on the roller ring with a soapy cloth. Rinse and dry.
3. To loosen hardened food particles and remove smells, place a cup of diluted lemon juice on the turntable and heat for ten minutes at maximum power.
4. Wash the dishwasher-safe plate whenever necessary.



**DO NOT** spill water in the vents. **NEVER** use any abrasive products or chemical solvents. Take particular care when cleaning the door seals to ensure that no particles:

- Accumulate
- Prevent the door from closing correctly



Clean the microwave oven cavity right after each use with a mild detergent solution, but let the microwave oven cool down before cleaning in order to avoid injury.

## Storing and Repairing Your Microwave Oven

A few simple precautions should be taken when storing or having your microwave oven serviced.

The oven must not be used if the door or door seals are damaged:

- Broken hinge
- Deteriorated seals
- Distorted or bent oven casing

Only a qualified microwave service technician should perform repair.

- ✎ **NEVER** remove the outer casing from the oven. If the oven is faulty and needs servicing or you are in doubt about its condition:
  - Unplug it from the wall socket
  - Contact the nearest after-sales service centre

- ☒ If you wish to store your oven away temporarily, choose a dry, dust-free place.  
Reason: Dust and damp may adversely affect the working parts in the oven.

- ☒ This microwave oven is not intended for commercial use.

## Technical Specifications

SAMSUNG strives to improve its products at all times. Both the design specifications and these user instructions are thus subject to change without notice.

Model	PG838
Power source	240V ~ 50 Hz
Power consumption	
Maximum power	3400 W
Microwave	1250 W
Top Grill	1300 W
Super Grill	2080 W
Output power	100 W / 800 W (IEC-705)
Operating frequency	2450 MHz
Magnetron	OM75P(31)
Cooling method	Cooling fan motor
Dimensions (W x H x D)	
Outside	489 x 275 x 401 mm
Oven cavity	330 x 211 x 329 mm
Volume	23 liter
Weight	
Net	15 kg approx





ELECTRONICS

**If you have any questions or comments relating to Samsung products,  
please contact the SAMSUNG customer care center.**

Tel : 0845 SAMSUNG (7267864) (United Kingdom)

Tel : 0818 717 100 (EIRE)

[www.samsung.com](http://www.samsung.com)  
[www.samsung.com/ie](http://www.samsung.com/ie)