


**SAMSUNG**

# MICROWAVE OVEN


## Owner's Instructions

**M197DL**




Oven .....	2
Accessories .....	2
Control Panel .....	2
Using this Instruction Booklet .....	3
Safety Precautions .....	3
Installing Your Microwave Oven .....	4
Setting the Time .....	5
What to Do if You are in Doubt or Have a Problem .....	5
Cooking / Reheating .....	6
Power Levels .....	6
Stopping the Cooking .....	6
Adjusting the Cooking Time .....	7
Setting a Standing Time .....	7
Using the Auto Reheat Feature .....	7
Auto Reheat Settings .....	8
Using the Indian Recipe Feature .....	8
Indian Recipe Setting .....	9
Using the Auto Power Defrost Feature .....	10
Auto Power Defrost Settings .....	10
Using the Good Morning Cook Function .....	11
Using the Deodorization Feature .....	12
Manual Stop Turntable Function .....	12
Switching the Beeper Off .....	12
Safety-Locking Your Microwave Oven .....	12
Cookware Guide .....	13
Cleaning Your Microwave Oven .....	14
Storing and Repairing Your Microwave Oven .....	14
Technical Specifications .....	15

## Oven




## Accessories


Depending on the model that you have purchased, you are supplied with several accessories that can be used in a variety of ways.



- Coupler**, already placed over the motor shaft in the base of the oven.  
Purpose : The coupler rotates the turntable.



- Roller ring**, to be placed in the centre of the oven.  
Purpose : The roller ring supports the turntable.



- Turntable**, to be placed on the roller ring with the centre fitting on to the coupler.  
Purpose : The turntable serves as the main cooking surface; it can be easily removed for cleaning.




- Good Morning Kit**, see page 11.  
Purpose : The toast kit when using toast, toast & fride egg, grillde sand witch function.



**DO NOT** operate the microwave oven without the roller ring and turntable.

## Control Panel



- |                                |  |
|--------------------------------|--|
| 1. DISPLAY                     | 8. AUTO POWER DEFROST BUTTON                                     |
| 2. STANDING TIME SETTING       | 9. AUTO REHEAT SELECTION   |
| 3. DEODORIZATION BUTTON        | 10. POWER LEVEL SETTING  |
| 4. GOOD MORNING COOK SELECTION | 11. TURNTABLE ON/OFF BUTTON                                      |
| 5. STOP/CANCEL BUTTON          | 12. START BUTTON/ DIAL KNOB (cook time, weight and serving size) |
| 6. CLOCK SETTING               |  |
| 7. INDIAN RECIPE BUTTON        |  |

## Using this Instruction Booklet

You have just purchased a SAMSUNG microwave oven. Your Owner's Instructions contain much valuable information on cooking with your microwave oven:

- Safety precautions
- Suitable accessories and cookware
- Useful cooking tips

At the front of the booklet you will find illustrations of the oven, and more importantly the control panel, so that you can find the buttons more easily.


The step-by-step procedures use three different symbols.



Important



Note



Turn

### PRECAUTIONS TO AVOID POSSIBLE EXPOSURE TO EXCESSIVE MICROWAVE ENERGY

Failure to observe the following safety precautions may result in harmful exposure to microwave energy.

- Under no circumstances should any attempt be made to operate the oven with the door open or to tamper with the safety interlocks (door latches) or to insert anything into the safety interlock holes.
- Do not place any object between the oven door and front face or allow food or cleaner residues to accumulate on sealing surfaces. Ensure that the door and door sealing surfaces are kept clean by wiping after use first with a damp cloth and then with a soft dry cloth.
- Do not operate the oven if it is damaged until it has been repaired by a qualified microwave service technician trained by the manufacturer. It is particularly important that the oven door closes properly and that there is no damage to the:
  - Door, door seals and sealing surfaces
  - Door hinges (broken or loose)
  - Power cable
- The oven should not be adjusted or repaired by anyone other than a properly qualified microwave service technician trained by the manufacturer.

## Safety Precautions

### IMPORTANT SAFETY INSTRUCTIONS.

#### READ CAREFULLY AND KEEP FOR FUTURE REFERENCE.

Before cooking food or liquids in your microwave oven, please check that the following safety precautions are taken.

- DO NOT** use any metallic cookware in the microwave oven:
  - Metallic containers
  - Dinnerware with gold or silver trimmings
  - Skewers, forks, etc.

Reason: Electric arcing or sparking may occur and may damage the oven.
- DO NOT** heat:
  - Airtight or vacuum-sealed bottles, jars, containers. Ex) Baby food jars
  - Airtight food. Ex) Eggs, nuts in shells, tomatoes

Reason: The increase in pressure may cause them to explode.

Tip: Remove lids and pierce skins, bags, etc.
- DO NOT** operate the microwave oven when it is empty.

Reason: The oven walls may be damaged.

Tip: Leave a glass of water inside the oven at all times.

The water will absorb the microwaves if you accidentally set the oven going when it is empty.
- DO NOT** cover the rear ventilation slots with cloths or paper.

Reason: The cloths or paper may catch fire as hot air is evacuated from the oven.
- ALWAYS** use oven gloves when removing a dish from the oven.

Reason: Some dishes absorb microwaves and heat is always transferred from the food to the dish. The dishes are therefore hot.
- DO NOT** touch heating elements or interior oven walls.

Reason: These walls may be hot enough to burn even after cooking has finished, even though they do not appear to be so. Do not allow inflammable materials to come into contact with any interior area of the oven. Let the oven cool down first.
- To reduce the risk of fire in the oven cavity:
  - Do not store flammable materials in the oven
  - Remove wire twist ties from paper or plastic bags
  - Do not use your microwave oven to dry newspapers
  - If smoke is observed, keep the oven door closed and switch off or disconnect the oven from the power supply
- Take particular care when heating liquids and baby foods.
  - **ALWAYS** allow a standing time of at least 20 seconds after the oven has been switched off so that the temperature can equalize.
  - Stir during heating, if necessary, and ALWAYS stir after heating.
  - Take care when handling the container after heating. You may burn yourself, if the container is too hot.
  - A risk of delayed eruptive boiling exists.
  - To prevent delayed boiling and possible scalding, you should put a plastic spoon or glass stick into the beverages and stir before, during and after heating.

Reason: During the heating of liquids the boiling point can be delayed; this means that eruptive boiling can start after the container is removed from the oven. You may scald yourself.

## Safety Precautions (continued)

- In the event of scalding, follow these FIRST AID instructions:
    - \* Immerse the scalded area in cold water for at least 10 minutes.
    - \* Cover with a clean, dry dressing.
    - \* Do not apply any creams, oils or lotions.
  - **NEVER** fill the container to the top and choose a container that is wider at the top than at the bottom to prevent the liquid from boiling over. Bottles with narrow necks may also explode if overheated.
  - **ALWAYS** check the temperature of baby food or milk before giving it to the baby.
  - **NEVER** heat a baby's bottle with the teat on, as the bottle may explode if overheated.
9. Be careful not to damage the power cable.
- Do not immerse the power cable or plug in water and keep the power cable away from heated surfaces.
  - Do not operate this appliance if it has a damaged power cable or plug.
10. Stand at arm's length from the oven when opening the door.  
**Reason:** The hot air or steam released may cause scalding.
11. Keep the inside of the oven clean.  
**Reason:** Food particles or spattered oils stuck to oven walls or floor can cause paint damage and reduce the efficiency of the oven.
12. You may notice a "Clicking" sound during operation (especially when the oven is defrosting).  
**Reason:** This sound is normal when the electrical power output is changing.
13. When the microwave oven is operating without any load, the power will be cut off automatically for safety. You can operate normally after letting it stand for over 30 minutes.

### IMPORTANT SAFETY INSTRUCTIONS

During cooking, you should look into the oven from time to time when food is being heated or cooked in disposable containers of plastic, paper or other combustible materials.

### IMPORTANT

Young children should **NEVER** be allowed to use or play with the microwave oven. Nor should they be left unattended near the microwave oven when it is in use. Items of interest to children should not be stored or hidden just above the oven.

### WARNING:

If the door or door seals are damaged, the oven must not be operated until it has been repaired by a competent person.

### WARNING:

It is hazardous for anyone other than a competent person to carry out any service or repair operation which involves the removal of a cover which gives protection against exposure to microwave energy.

### WARNING:



Liquids and other foods must not be heated in sealed containers since they are liable to explode.

### WARNING:

Only allow children to use the oven without supervision when adequate instructions have been given so that the child is able to use the oven in a safe way and understands the hazards of improper use.

## Installing Your Microwave Oven

**Place the oven on a flat, level surface that is strong enough to safely bear the weight of the oven.**



1. When you install your oven, Make sure there is adequate ventilation for your oven by leaving at least 10 cm (4 inches) of space behind, and on the sides of the oven, at least 20 cm (8 inches) of space above the oven.
2. Remove all packing materials inside the oven. Install the roller ring and turntable. Check that the turntable rotates freely.
3. This microwave oven has to be positioned so that plug is accessible.



**Never** block the air vents as the oven may overheat and automatically switch itself off. It will remain inoperable until it has cooled sufficiently.



For your personal safety, plug the cable into a 3-pin, 230 Volt, 50Hz, AC earthed socket. If the power cable of this appliance is damaged, it must be replaced by the manufacturer or its service agent or a similarly qualified person in order to avoid a hazard.




**Do not** install the microwave oven in hot or damp surroundings like next to a traditional oven or radiator. The power supply specifications of the oven must be respected and any extension cable used must be of the same standard as the power cable supplied with the oven. Wipe the interior and the door seal with a damp cloth before using your microwave oven for the first time.

## Setting the Time

Your microwave oven has an inbuilt clock. The time can be displayed in either the 24-hour or 12-hour notation. You must set the clock:

- When you first install your microwave oven
- After a power failure

☒ Do not forget to reset the clock when you switch to and from summer or winter time.




1. To display the time in the...


24-hour notation  
12-hour notation

Then press the button...


Once  
Twice




2. Turn the **dial knob** to set the hour.



3. Press the button.



4. Turn the **dial knob** to set the minute.



5. Press the button.

## What to Do if You are in Doubt or Have a Problem


If you have any of the problems listed below try the solutions given.



- ◆ This is normal.
    - Condensation inside the oven.
    - Air flow around the door and outer casing.
    - Light reflection around the door and outer casing.
    - Steam escaping from around the door or vents.
  - ◆ The oven does not start when you press the button.
    - Is the door completely closed?
  - ◆ The food is not cooked at all
    - Have you set the timer correctly and/or pressed the button?
    - Is the door closed?
    - Have you overloaded the electric circuit and caused a fuse to blow or a breaker to be triggered?
  - ◆ The food is either overcooked or undercooked
    - Was the appropriate cooking length set for the type of food?
    - Was an appropriate power level chosen?
  - ◆ Sparking and cracking occur inside the oven (arcing)
    - Have you used a dish with metal trimmings?
    - Have you left a fork or other metal utensil inside the oven?
    - Is aluminium foil too close to the inside walls?
  - ◆ The oven causes interference with radios or televisions
    - Slight interference may be observed on televisions or radios when the oven is operating. This is normal. To solve this problem, install the oven away from televisions, radios and aerials.
    - If interference is detected by the oven's microprocessor, the display may be reset. To solve this problem, disconnect the power plug and reconnect it. Reset the time.
- ☒ If the above guidelines do not enable you to solve the problem, contact your local dealer or SAMSUNG after-sales service.


## Cooking / Reheating

The following procedure explains how to cook or reheat food. **ALWAYS** check your cooking settings before leaving the oven unattended.


First, place the food in the centre of the turntable. Then, close the door.




1. Press the  button.  
**Result:** The 1000W (maximum cooking power) indications are displayed:  
Select the appropriate power level by pressing the  button again until the corresponding wattage is displayed. Refer to the power level table.






2. Set the cooking time by turning the **dial knob** as required.




3. Press the  button.  
**Result:** The oven light comes on and the turntable starts rotating. Cooking starts. When it has finished:  
  - 1) The oven beeps four times.
  - 2) The end reminder signal will beep 3 times (once every minutes).
  - 3) The current time is displayed again.



 **Never** switch the microwave oven on when it is empty.

-  If you wish to heat a dish for a short period of time at maximum power (1000W), simply press the **+30s** button once for each 30 seconds of cooking time. The oven starts immediately.
-  You can change the power level during cooking by pressing the  button.

## Power Levels

You can choose from among the power levels below.

Power Level	Output
FULL	1000 W
HIGH	850 W
MEDIUM HIGH	600 W
MEDIUM	450 W
MEDIUM LOW	300 W
DEFROST (  )	180 W
LOW / KEEP WARM	100 W


-  If you select the higher power level, the cooking time must be decreased.
-  If you select the lower power level, the cooking time must be increased.


If you want to add the cooking time by turning dial knob.


Time	Increasing Time
Up to 1 min	5 sec. unit
1 - 3 min	10 sec. unit
3 - 10 min	30 sec. unit
10 - 20 min	1 min unit
20 - 40 min	2 min unit
40 - 99 min	5 min unit



## Stopping the Cooking



You can stop cooking at any time to check the food.



1. To stop temporarily:  
Open the door.  
**Result:** Cooking stops. To resume cooking, close the door and press  again.




2. To stop Completely:  
Press the  button.  
**Result:** The cooking stops.  
If you wish to cancel the cooking setting, press the Cancel (  ) button again.

 You can cancel any setting before you start cooking by simply pressing **Cancel** (  ).

## Adjusting the Cooking Time


You can increase the cooking time by pressing the +30s button once for each 30 seconds to be added.



Press the **+30s** button once for each 30 seconds to be added.




You can only adjust the time during cooking when the Microwave, Auto Reheat, Snack, Deodorization and Power Steam modes are selected.





During the cooking, to increase or decrease the cooking time of your food, turn the **dial knob** right or left.

## Setting a Standing Time


The Hold Time can be used to set a standing time automatically (without microwave cooking).




1. Press the  button.



2. Select the standing time by turning the **dial knob**.



3. Press the  button.


**Result:** Standing time starts. When it has finished:


- 1) The oven beeps four times.
- 2) The end reminder signal will beep 3 times (once every minute)
- 3) The current time is displayed again.

## Using the Auto Reheat Feature


The Auto Reheat feature has four pre-programmed cooking times. You do not need to set either the cooking times or the power level. You can adjust the number of servings by turning the dial knob. First, place the food in the centre of the turntable and close the door.




1. Select the type of food that you are cooking by pressing the **Auto Reheat** () button once or more times.



2. Select the size of the serving by turning the **dial knob**. (Refer to the table on the side.)



3. Press the  button

**Result:** Cooking starts. When it has finished:





- 1) The oven beeps four times.
- 2) The end reminder signal will beep 3 times (once every minutes)
- 3) The current time is displayed again.



Use only recipients that are microwave-safe.

## Auto Reheat Settings

The following table presents the various Auto Reheat Programmes, quantities, standing times and appropriate recommendations.

Code/ Food	Serving Size	Standing Time	Recommendations
<b>1</b>  <b>Ready Meal</b> (Chilled)	300-350 g 400-450 g	3 min.	Put on a ceramic plate and cover with microwave cling film. This programme is suitable for meals consisting of 3 components (e.g. meat with sauce, vegetables and a side dishes like potatoes, rice or pasta).
<b>2</b>  <b>Ready Meal</b> (frozen)	300 - 350 g 400 - 450 g	4 min.	Take frozen ready meal and check if dish is suitable for microwave. Pierce film of ready meal. Put the frozen ready meal in the centre. This programme is suitable for frozen ready meals consisting of 3 components (e.g. meat with sauce, vegetables and a side dish like potatoes, rice or pasta).
<b>3</b>  <b>Drinks</b> Coffee, milk, tea, water (room- temperature)	150 ml (1 cup) 300 ml (2 cups) 450 ml (3 cups) 600 ml (4 cups)	1-2 min.	Pour into a ceramic cup and reheat uncovered. Place 1 cup in the centre, 2 opposite of each other and 3 or 4 in a circle. Stir carefully before and after standing time, be careful while taking them out of oven.
<b>4</b>  <b>Soup/            Sauce</b> (Chilled)	200 - 250 ml 300 - 350 ml 400 - 450 ml 500 - 550 ml 600 - 650 ml	2-3 min.	Pour into a deep ceramic soup plate or bowl and cover during heating and standing. Stir carefully before and after standing time.


## Using the Indian Recipe Feature


The Indian Recipe feature has six pre-programmed cooking time, you do not need to set either the cooking time or power level.

First, place the food in the centre of the turntable and close the door.



1. Select the type of food that you are cooking by pressing the **Indian Recipe** button once or more times. Refer to the table on the following page for a description of the various pre-programmed settings.



2. Press the  button.  
**Result :**
  - 1) The oven beeps four times.
  - 2) The end reminder signal will beep 3 times (once every minute)
  - 3) The current time is displayed again.









Use only recipients that are microwave-safe.



## Indian Recipe Setting

The following table presents six Auto Programmes for types of food. It contains its quantities, standing times and appropriate recommendations.

Code/ Symbol	Recipe	Serving Size	Standing Time	Ingredients	Recommendations
1. 	Instant Dhokla	8 pcs	3 min.	Sooji (1/4 cup), Baisan ( 3/4 cup), Curd (1 cup), Salt (1 tsp),Sugar (2 Tsp), Lemon juice(1Tsp), Haldi(1/2 Tsp), Oil (1 Tsp), Eno salt (3/4 Tsp)	Mix basin, sooji, curd, salt,sugar,lemon juice, Haldi,oil & Eno salt in the last. Pour into microwave safe greased bowls ( Katories) or idli maker with cover or lid.
2. 	Instant Idli	8 pcs	3 min.	Rawa Sooji(1 cup), Curd (1 cup),Heeng (1 pinch), Eno salt (3/4 Tsp), Lemon juice (1 Tsp), Roasted/Fried Moongfali (optional), Roasted Channa Dal (optional), Green chillies (1no)	Mix sooji, curd, salt, heeng ,lemon juice, Green chilli, Nut or dal(roasted). Add Eno salt last of all & pour into microwave safe bowls (katories) or idli maker.
3. 	Kadai Paneer	200-250 gms	3 min.	Paneer(250g), Capsicum (1 cut julliens), Fresh Tomato (1 Chopped- medium), Tomato puree (3-4 Tsp),Salt (1 Tsp) , Sugar (1*1/2 Tsp), Red Chille wole (2-3), Red chilli powder (1/2 Tsp), Ginger (1 Shredded), Garlic (1 Tsp paste), Garam Masala (1 Tsp),Dhaniya Powder(1*1/2 Tsp), Kastoori Methi (Dry fenugreek-2 Tsp), Green Dhaniya (For garnishing), Oil (1 Tsp)	Mix all the ingredients in a microwave safe bowl.

4. 	Veg. Pulao	50gm/ 1/2cup	5 min.	Rice(1/2 cup-washed & soaked in 1 cup of water for 1 hrs), Veg ( 1/4cup peas,beans,tomato,e tc),Oil(1/2 Tsp), Salt(1/2 Tsp), Red chilli powder(1/2 Tsp- Optional),Clove(2-3), Cinnamom ( 1/2"), Bayleaf(1), Black peeper Corn(2-3)	Add rice, water, oil, salt, all vegetables & whole spices in a microwave safe bowl with lid or cover with clingfilm.
5. 	Lemon Chichen stick	2 drum- stick	3 min.	Chicken(2pcs preferably drumsticks),Lemon juice(2),Dalchini(1), Long(Clove 2-3), Black Pepper Corn (5-6), Moti illachi dana (Black Cardamon -1),Salt ( 3/4- 1 Tsp), Butter (2 Tsp, optional)	Make a couple of cuts into each drumsticks (legs) & mix with butter , lemon juice, dalchini, Clove, Black peeper corns,moti illachi dana, salt. Pour into a microwave safe bowl with lid or cover it with clingfilm.
6. 	Chocola te Cake	400 gms	5 min.	Eggs(2), Flour (100g/1cup),Butter (100g / 1/2 cup), Coster Sugar ( 15g / 2 Tsp), Coco powder (15g / 2 Tsp), Baking powder (1/2 Tsp), Milk(1/4 Cup -To make batter pouring), Vanilla Essence (1 tsp)	Shift the flour with baking powder & mix with coco powder. Keep aside. Beat eggs till fluffy & light with hands or electric beater. Beat together softened butter & sugar till creamy. Add egg & continue to beat.. Add flour mixture gradually into egg mixture & continue mixing clockwise only. Add milk to make the batter of pouring consistency. Line the base of microwave safe baking dish walls with butter/ grease paper or oil & pour in the batter. ( Note :- Add Walnut to make Walnut Chocolate Cake)


GB

## Using the Auto Power Defrost Feature

The Auto Power Defrost feature enables you to defrost meat, poultry, fish and bread/cake. The defrost time and power level are set automatically.


- ✉ Use only dishes that are microwave-safe.

First, place the frozen food in the centre of the turntable and close the door.




1. Press the **Power Defrost** (❄️) button which you want the required number of time.

**Example:** Press the Power Defrost (❄️) button three times to defrost fish.



2. Select the food weight by turning the **dial knob**. It is possible to set up to a maximum of 2000g. (Bread/Cake is possible to set up to a maximum of 1000g.)



3. Press **⏏** button.

**Result :**





- ◆ Defrosting begins.
- ◆ The oven beeps halfway through defrosting to remind you to turn the food over.
- ◆ Press **⏏** button again to finish defrosting

- ✉ You can also defrost food manually. To do so, select the microwave cooking/reheating function with a power level of 180W. Refer to the section entitled "Cooking/Reheating" on page 6 for further details.

## Auto Power Defrost Settings

The following table presents the various Auto Power Defrost programmes, quantities, standing times and appropriate recommendations.

Remove all kinds of package material before defrosting. Place meat, poultry, fish and bread/cake on a turntable.

Food	Serving Size	Standing Time	Recommendations
 Meat	200-2000 g	20-60 mins	Shield the edges with aluminium foil. Turn the meat over, when the oven beeps. This programme is suitable for meat, lamb, pork, steaks, chops, minced meat.
 Poultry	200-2000 g	20-60 mins	Shield the leg and wing tips with aluminium foil. Turn the poultry over, when the oven beeps. This programme is suitable for whole chicken as well as for chicken portions.
 Fish	200-2000 g	20-50 mins	Shield the tail of a whole fish with aluminium foil. Turn the fish over, when the oven beeps. This programme is suitable for whole fishes as well as for fish fillets.
 Bread/ Cake	125-1000 g	5-30 mins	Put bread on a piece of kitchen paper and turn over, as soon as the oven beeps. Place cake on a ceramic plate and if possible, turn over, as soon as the oven beeps. (Oven keeps operating and is stopped, when you open the door.) This programme is suitable for all kinds of bread, sliced or whole, as well as for bread rolls and baguettes. Arrange bread rolls in a circle. This programme is suitable for all kinds of yeast cake, biscuit, cheese cake and puff pastry. It is not suitable for short/crust pastry, fruit and cream cakes as well as for cake with chocolate topping.

## Using the Good Morning Cook Function

With the Good Morning Cook feature, the cooking time is set automatically.


You can adjust the number of cook by pressing the Good Morning button.

Use the plastic Good Morning kit when using toast, toast & fried egg, grilled sand witch function.

**Example. To cook toast and fried egg**




1. Put slices of bread and egg in the Good Morning kit.
  - ☞ Mind that the egg in the Good Morning kit does not overflow when heating the egg.
  - ☞ Break the yolk of the egg with a chopstick or fork. (The yolk might explode while heating it.)
  - ☞ Before put in the egg, spread the Good Morning kit with cooking oil to prevent burning.
  - ☞ If basic cooking requires 2 slices of bread, you cannot put in a single slice of bread.




2. Close the cover of the Good Morning kit, and place the Good Morning kit on the center of the turntable.
  - Make sure that the cover of the Good Morning kit is closed completely, and then start cooking.
3. Press the Good Morning kit button 2 times to select toast & fried egg function.
  - Press the button until the number 2 appears.




4. Press the  button.  
**Result:** Cooking starts. When it has finished:
  - 1) The oven beeps four times.
  - 2) The end reminder signal will beep 3 times (once every minute)
  - 3) The current time is displayed again.

- ☞ Do not heat the empty Good Morning kit.
- ☞ Be careful when you take the Good Morning kit out, because it may be hot.
- ☞ Be careful not to injure your hand when you close the cover of the Good Morning kit.
- ☞ Since the Good Morning kit is heavy, hold the Good Morning kit with both of your hands while moving it to prevent dropping it.
- ☞ Place the Good Morning kit on a flat and solid place so as to prevent unintentional falling or closing.
- ☞ Before successive cooking, wait until the Good Morning kit cools.

## Good Morning kit Clean Guide



1. Open the Good Morning kit cover.
  - Pull and lift the lever on the front



2. Lift the upper tray with a hand until it is separated.
  - Be careful not to injure your hand because the dropping of the upper tray may injure your hand.



3. Separate the lower tray.
  - You can easily separate the lower tray by lifting it or turning it over.


4. Clean the Good Morning kit with neutral detergent.

- ☞ Before separating and cleaning the Good Morning kit, wait until the Good Morning kit cools completely.
- ☞ Be careful not to injure your hand when you close the cover of the Good Morning kit.

## Using the Deodorization Feature

**Use this feature after cooking odorous food or when there is a lot of smoke in the oven interior.**

**First clean the oven interior.**



Press the **Deodorization** (☼) button after you have finished cleaning, you will hear four beeps.

- ☒ The deodorization time has been specified as 5 minutes. It increases by 30 seconds whenever the **+30s** button is pressed.
- ☒ You can also adjust deodorization time by turning the dial knob right or left.
- ☒ The maximum deodorization time is 15 minutes.

## Manual Stop Turntable Function

**The turntable on/off (⊞) button enables you to use large dishes which fill the whole oven by stopping the turntable from rotating.**

☞ The results will be less satisfactory in this case as the cooking is less even. We recommend that you turn the dish by hand halfway through the cooking process.

☞ **Warning!** Never operate the turntable without food in the oven.

**Reason:** This may cause fire or damage to the unit.



1. Press the **Turntable on/off** (⊞) button.  
**Result:** Turntable on/off (⊞) symbol appears on the display, the turntable will not rotate.




2. To switch the turntable rotating back on, Press the **Turntable on/off** (⊞) button again.  
**Result:** Turntable on/off (⊞) symbol disappears on the display, the turntable will rotate.

- ☒ Don't press **Turntable on/off** (⊞) button during cooking process.

## Switching the Beeper Off

**You can switch the beeper off whenever you want.**




1. Press the ⊞ and ⊞ buttons at the same time.

**Result:**

- ◆ The following indication is displayed.

OFF

- ◆ The oven will not beep each time you press a button.



2. To switch the beeper back on, press the ⊞ and ⊞ buttons again at the same time.

**Result:**

- ◆ The following indication is displayed.


On

- ◆ The oven operates with the beeper on again.

## Safety-Locking Your Microwave Oven

**Your microwave oven is fitted with a special Child Safety programme, which enables the oven to be "locked" so that children or anyone unfamiliar with it cannot operate it accidentally.**

**The oven can be locked at any time.**




1. Press the ⊞ and ⬇ buttons at the same time.

**Result:**

- ◆ The oven is locked (no functions can be selected).

- ◆ The display shows "L".

L



2. To unlock the oven, press the ⊞ and ⬇ buttons again at the same time.

**Result:** The oven can be used normally.

## Cookware Guide

To cook food in the microwave oven, the microwaves must be able to penetrate the food, without being reflected or absorbed by the dish used.

Care must therefore be taken when choosing the cookware. If the cookware is marked microwave-safe, you do not need to worry.

The following table lists various types of cookware and indicates whether and how they should be used in a microwave oven.

Cookware	Microwave-Safe	Comments
Aluminium foil	✓ X	Can be used in small quantities to protect areas against overcooking. Arcing can occur if the foil is too close to the oven wall or if too much foil is used.
Browning plate	✓	Do not preheat for more than eight minutes.
China and earthenware	✓	Porcelain, pottery, glazed earthenware and bone china are usually suitable, unless decorated with a metal trim.
Disposable polyester cardboard dishes	✓	Some frozen foods are packaged in these dishes.
<b>Fast-food packaging</b>		
• Polystyrene cups	✓	Can be used to warm food. Overheating may cause the polystyrene to melt. May catch fire.
• Paper bags or newspaper	X	
• Recycled paper or metal trims	X	
<b>Glassware</b>		
• Oven-to-table ware	✓	Can be used, unless decorated with a metal trim.
• Fine glassware	✓	Can be used to warm foods or liquids. Delicate glass may break or crack if heated suddenly.
• Glass jars	✓	Must remove the lid. Suitable for warming only.
<b>Metal</b>		
• Dishes	X	May cause arcing or fire.
• Freezer bag twist ties	X	

<b>Paper</b>		
• Plates, cups, napkins and Kitchen paper	✓	For short cooking times and warming. Also to absorb excess moisture. May cause arcing.
• Recycled paper	X	
<b>Plastic</b>		
• Containers	✓	Particularly if heat-resistant thermoplastic. Some other plastics may warp or discolour at high temperatures. Do not use Melamine plastic. Can be used to retain moisture. Should not touch the food. Take care when removing the film as hot steam will escape. Only if boilable or oven-proof. Should not be airtight. Prick with a fork, if necessary.
• Cling film	✓	
• Freezer bags	✓ X	
<b>Wax or grease-proof paper</b>	✓	Can be used to retain moisture and prevent spattering.

✓ :Recommended

✓X :Use Caution

X :Unsafe


---


## Cleaning Your Microwave Oven

---


**GB** *The following parts of your microwave oven should be cleaned regularly to prevent grease and food particles from building up:*

- *Inside and outside surfaces*
- *Door and door seals*
- *Turntable and Roller rings*

 **ALWAYS** ensure that the door seals are clean and the door closes properly.

 Failure to maintain the oven in a clean condition could lead to deterioration of the surface that could adversely affect the of the appliance and possibly result in a hazardous situation.

1. Clean the outside surfaces with a soft cloth and warm, soapy water. Rinse and dry.
2. Remove any splashes or stains on the inside surfaces or on the roller ring with a soapy cloth. Rinse and dry.
3. To loosen hardened food particles and remove smells, place a cup of diluted lemon juice on the turntable and heat for ten minutes at maximum power.
4. Wash the dishwasher-safe plate whenever necessary.

 **DO NOT** spill water in the vents. NEVER use any abrasive products or chemical solvents. Take particular care when cleaning the door seals to ensure that no particles:

- Accumulate
- Prevent the door from closing correctly

---

## Storing and Repairing Your Microwave Oven


---

*A few simple precautions should be taken when storing or having your microwave oven serviced.*


*The oven must not be used if the door or door seals are damaged:*

- *Broken hinge*
- *Deteriorated seals*
- *Distorted or bent oven casing*


*Only a qualified microwave service technician should perform repair*

 **NEVER** remove the outer casing from the oven. If the oven is faulty and needs servicing or you are in doubt about its condition:

- Unplug it from the wall socket
- Contact the nearest after-sales service centre

 If you wish to store your oven away temporarily, choose a dry, dust-free place.

**Reason:** Dust and damp may adversely affect the working parts in the oven.

 This microwave oven is not intended for commercial use.

## Technical Specifications

*SAMSUNG strives to improve its products at all times. Both the design specifications and these user instructions are thus subject to change without notice.*

<b>Model</b>	<b>M197DL</b>
<b>Power source</b>	230V ~ 50 Hz
<b>Power consumption</b> Microwave	1400 W
<b>Output power</b>	100 W / 1000 W (IEC-705)
<b>Operating frequency</b>	2450 MHz
<b>Magnetron</b>	OM75P(31)
<b>Cooling method</b>	Cooling fan motor
<b>Dimensions (W x H x D)</b> Outside Oven cavity	517 x 297 x 420 mm 336 x 241 x 349 mm
<b>Volume</b>	28 liter
<b>Weight</b> Net	16.5 kg approx

## Note

