


VR348

USER'S GUIDE



VIDEO CASSETTE

RECORDER

TRUST

Important Information


WARNING

To reduce the risk of fire or shock hazard, do not expose this VCR to rain or moisture.


WARNING

RISK OF ELECTRIC SHOCK DO NOT OPEN

TO REDUCE THE RISK OF ELECTRIC SHOCK, DO NOT REMOVE COVER (OR BACK). NO USER SERVICEABLE PARTS INSIDE. REFER SERVICING TO QUALIFIED SERVICE PERSONNEL.




This symbol indicates "dangerous voltage" inside the product that presents a risk of electric shock or personal injury.



This symbol indicates important instructions accompanying the product.

Cautions



CAUTION: To reduce the risk of electric shock, match wide blade of plug to wide slot, fully insert.

ATTENTION: Pour éviter les chocs électriques, introduire la lame la plus large de la fiche dans la borne correspondante de la prise et pousser jusqu'au fond.

For Refer to the identification/rating label on the back of the product for the proper operating voltage.

FCC Regulations state that unauthorized changes or modifications to this equipment may void the user's authority to operate it.

Note To Cable TV Installer

This reminder is provided to call your attention to Article 820-40 of the National Electrical Code (Section 54 of the Canadian Electrical Code, Part 1) which provides guidelines for proper grounding and, in particular, specifies that the cable ground shall be connected to the grounding system of the building as close to the point of cable entry as practical.

Product Registration

Please fill out the product registration card and return it immediately. Returning this card allows us to contact you if needed.

Keep your sales receipt to obtain warranty parts and service and for proof of purchase. Attach it here and record the serial and model numbers in case you need them. The numbers are located on the back of the VCR.

Model No. **VR348** _____

Serial No. _____

Purchase Date: _____

Dealer / Address / Phone: _____

Table of Contents

Important Information

Warnings _____	i
Cautions _____	i
Note to Cable TV Installer _____	i
Product Registration _____	i

Hooking Up the VCR

Choosing a Hookup _____	2
Antenna or Cable System Without a Cable Box _____	3
Cable System With Cable Box to Unscramble All Channels _____	4
Cable System With Cable Box to Unscramble Pay Channels Only _____	5
Connecting Two VCRs for Copying Tapes _____	6

Setting Up the VCR

Startup	
Check Accessories With VCR _____	7
Insert Batteries in Remote _____	7
Turn on the TV _____	8
Turn on the VCR _____	8
Place Channels in VCR's Memory _____	8
Add or Remove Channels from VCR's Memory _____	9
Select a Language/ Choisissez une Langue _____	9
Set the Time and Date _____	9
Use TV•VCR Button _____	10
Set Auto TV/VCR Feature _____	10

Using the Remote Control

VCR Function Buttons _____	11
----------------------------	----

Playing a Tape

Operating Instructions _____	12
Auto Play Feature _____	12
Using the Playback Features	
Pause for Stop-Action _____	13

Picture Search _____	13
Automatic Tracking _____	13
Manual Tracking _____	13
DISPLAY Button _____	14
Time Counter _____	14
Commercial Scan _____	15
Index Search _____	15
Zero Search _____	16

Recording a Program

Types of Recordings _____	17
Recording Speeds _____	17
Recording Pause _____	17
Basic Recording –	
Operating Instructions _____	18
Watch a TV Channel While VCR is Recording a Different Channel _____	18
Express Recording (XPR) _____	19
Recording While You're Away	
VCR Plus+ Recording _____	20-22
Timer Recording _____	23
Checking or Clearing VCR Plus+ or Timer Recordings _____	24
Timer Recording From the VCR's Line Input _____	24
Using Two VCRs for Copying and Editing Tapes _____	25

References

Location of Controls	
Front Panel _____	26
Back Panel _____	27
Display Panel _____	28
Specifications _____	29
Cleaning the VCR _____	29
Trouble Checks _____	30-31
Limited Warranty _____	32
Index _____	33

Choosing a Hookup

The hookups on pages 3 through 5 are divided into two hookup types: Basic (A) and Advanced (B).

The basic hookups show the backs of TVs that have only an antenna/cable connection. It is the easier of the two and additional accessories may not be needed.

The advanced hookups show the VCR hooked up to a monitor/receiver (TV with audio and video jacks). This connection may improve the picture quality as well as convenience of operation.

Answer the questions to choose the hookup for your VCR.

1. How do you receive your TV signals?

Choose one answer from below.

- A. Outside antenna – Turn to page 3.
- B. Rabbit ears (set-top) and/or bow tie antenna – Turn to page 3.
- C. Cable System – Go to question 2.

2. What type of cable-TV system* do you have?

Choose one answer from below.

- A. Cable without a box – Turn to page 3.
- B. Cable box to unscramble all the channels – Turn to page 4.
- C. Cable box to unscramble only pay channels, such as HBO, Showtime, Cinemax, etc. – Turn to page 5.

*You may need to contact your local cable company for assistance.

Optional Hookups

How to hook up two VCRs for copying tapes?

- A. Select a hookup by answering the questions above.
- B. Then modify the connections as shown on page 6.

Antenna or Cable System Without a Cable Box

A. Basic hookup.

Use this hookup for a simple connection which requires fewer accessories.

1. Set the **CH3 CH4** switch on back of VCR to either channel 3 or 4.


You will tune the TV to this channel and use the TV•VCR button to watch the VCR.

2. Connect as shown.

This connection may require additional accessories not provided.

3. Plug in power cords of VCR and TV.

4. **Continue to page 7.**



B. Advanced hookup.

Use this hookup for slightly improved picture quality and more convenient operation — use of TV•VCR button not required.

1. Connect as shown.

This connection requires additional accessories not provided.


If your TV is stereo, you may need a Y-adaptor to hear sound from both left and right channels.

2. Plug in power cords of VCR and TV.

3. **Continue to page 7.**

You will tune the TV to its video input to watch the VCR.

Set the Auto TV/VCR feature to OFF. See page 10.




Cable System With Cable Box to Unscramble All Channels

A. Basic hookup.

Use this hookup for a simple connection which requires fewer accessories.

1. Set the CH3 CH4 switch on back of VCR to either channel 3 or 4.
You will tune the TV to this channel and use the TV•VCR button to watch the VCR.
2. Connect as shown.
This connection may require additional accessories not provided.
3. Plug in power cords of VCR, TV, and cable box.
4. **Continue to page 7.**




B. Advanced hookup.

Use this hookup for slightly improved picture quality and more convenient operation — use of TV•VCR button not required.

1. Connect as shown.
This connection requires additional accessories not provided.
If your TV is stereo, you may need a Y-adaptor to hear sound from both left and right channels.
2. Plug in power cords of VCR, TV, and cable box.
3. **Continue to page 7.**

You will tune the TV to its video input to watch the VCR.
Set the Auto TV/VCR feature to OFF. See page 10.

Caution: The unauthorized recording of satellite broadcasts, television programs, or other materials may infringe the rights of others.




Cable System With Cable Box to Unscramble Pay Channels Only

(such as HBO, Showtime, Pay-Per-View, etc.)

A. Basic hookup.

Use this hookup for a simple connection which requires fewer accessories.


1. Set the **CH3 CH4** switch on back of VCR to either channel 3 or 4.
You will tune the TV to this channel and use the TV•VCR button to watch the VCR.
2. **Connect as shown.**
This connection may require additional accessories not provided.
3. **Plug in power cords of VCR, TV, and cable box.**
4. **Continue to page 7.**



B. Advanced hookup.

Use this hookup for slightly improved picture quality and more convenient operation — use of TV•VCR button not required.

1. **Connect as shown.**
This connection requires additional accessories not provided.
If your TV is stereo, you may need a Y-adaptor to hear sound from both left and right channels.
 2. **Plug in power cords of VCR, TV, and cable box.**
 3. **Continue to page 7.**
- You will tune the TV to its video input to watch the VCR. All pay channels are viewed through the VCR.




Connecting Two VCRs for Copying Tapes

Option A hookup.

Use this hookup for a simple connection which requires fewer accessories.

1. Select a hookup from pages 2 through 5 and then modify with this connection.
2. Set the CH3 CH4 switch on the playback VCR to either channel 3 or 4.
You will tune the recording VCR to this channel to receive the signal from the playback VCR.
3. Connect as shown.
This connection may require additional accessories not provided.
4. Plug in power cords of VCRs and TV.
5. **Continue to page 7.**




Option B hookup.

Use this hookup for slightly improved copy quality and more convenient operation — use of TV•VCR button not required.

1. Select a hookup from pages 2 through 5 and then modify with this connection.
2. Connect as shown.
This connection requires additional accessories not provided.
If your other VCR is stereo, you may need a Y-adaptor to hear sound from both left and right channels.
3. Plug in power cords of VCRs and TV.
4. **Continue to page 7.**

You will select the line (audio/video) input on the recording VCR to receive the signal from the playback VCR.


Caution: The unauthorized recording of satellite broadcasts, television programs, or other materials may infringe the rights of others.




Startup

1. Check accessories with VCR.

Contact your dealer if any items are missing.



Remote
(Stock No. 233456)




2 "AA" Batteries



RF Coaxial Cable
(Stock No. 221396)

2. Insert batteries in remote.



Startup

3. Turn on the TV.

- A. Turn on the TV.
- B. If you used one of the basic hookups, tune the TV to the channel selected with the CH3 CH4 switch on back of VCR.

If you used one of the advanced hookups, tune the TV to the TV's video input. (See TV owner's manual for details.)

4. Turn on the VCR.

- A. Press POWER on the remote.

5. Place channels in the VCR's memory.

The first time you turn on the VCR or after a power interruption, perform the AUTO CHANNEL SEARCH so that your VCR can locate the channels available through your signal type—cable or antenna. The signal type is automatically selected when you perform the AUTO CHANNEL SEARCH function. Also, if you change the signal type, you will need to perform AUTO CHANNEL SEARCH again.



- A. Press MENU to display the VCR MAIN MENU on the TV screen. If this menu does not appear:
 - Make sure TV is tuned to same channel as the CH3 CH4 switch on the back of the VCR or the TV's video input (refer to TV's manual).
 - Press MENU again.
 - If you use a basic hookup, check VCR indicator in display panel – it should be on. Press TV•VCR to turn it on.
 - Check the connections.

- B. Press 4 to display the CHANNELS menu.

- C. Press 1 to begin AUTO CHANNEL SEARCH.

The VCR automatically selects CABLE (cable TV) or ANTENNA. If you need to change the setting manually, press 3.

Wait until the channel numbers stop changing. This takes about one to two minutes. The TV will then tune to the lowest channel found. Pressing CHANNEL up or down will select only the active channels.




Startup

6. Add or remove channels from the VCR's memory.

You may want to add or remove channels if some of them are not active, have weak signals, or you do not want to watch them.

We recommend channels be placed in memory using the AUTO CHANNEL SEARCH feature *described on the previous page* before adding or removing channels. Channels 2-13 and VID1 were placed in memory at the factory.


- Press MENU on the remote to see the VCR MAIN MENU on the TV screen.
- Press 4 to display the CHANNELS menu.
- Press 2 to display the ADD/REMOVE CHANNELS menu.
- Follow the directions on the screen.
- Add or remove more channels by entering channel numbers or using CHANNEL up or down.



7. Select a language./Choisissez une langue.


You can select the language for the displays on the VCR.

- Press MENU on the remote to see the VCR MAIN MENU on the TV screen.
- Press 6 to display the LANGUAGE menu.
- Select English or French.
 - Press 1 to select English.
 - Press 2 to select Français (French).




8. Set the time and date.

When you first turn on the VCR, --:-- appears in the clock area of the VCR's display panel.



- Press MENU on remote to display the VCR MAIN MENU on the TV screen.
- Press 3 to display SET TIME AND DATE.
- Enter the time and date with the number buttons on the remote.
 - Press 0 before single-digit numbers.
Example: press 0, then 5, then 0, then 7 for a time of 5:07. Press 1 for AM or 2 for PM.
 - Press CLEAR on the remote to change incorrect entries.
- Press MENU on remote to remove SET TIME AND DATE from the TV screen and start the clock. The time will appear in the VCR's display panel and the time and date will appear on the TV screen when you press DISPLAY.



continued on next page

Startup

9. Use TV•VCR button.

Skip this step if you used one of the advanced hookups.

When using one of the basic hookups, the TV•VCR button lets you switch between the picture coming from the VCR or the picture from the TV channel. This button lets you record a program on the VCR while watching another channel on the TV. *Details are on page 18.*


- A. Press TV•VCR to see the picture from the VCR.
The VCR indicator lights in the display panel.
- B. Press CHANNEL up or down to change channels on the VCR.
The channel number changes in the display panel.
- C. Press TV•VCR to see the TV channels.
The VCR indicator does not light in the display panel. Change channels using the TV's remote.
- D. Return the TV to the VCR viewing channel — CH3 or CH4.
- E. Press TV•VCR to switch back to the picture from the VCR.

10. Set Auto TV/VCR feature.

If you used one of the basic hookups and did not connect the audio/video jacks of the VCR to the TV, leave the Auto TV/VCR feature set to ON.


If you have connected your VCR using the audio/video input of your TV, you can prevent the VCR indicator from turning on automatically and interrupting the cable or antenna signal to your TV.

- A. Press MENU on the remote to see VCR MAIN MENU on the TV screen.
- B. Press 5 to display PREFERENCES.
- C. Press 2 to select Auto TV/VCR: ON or OFF.
 - Select ON if you used one of the basic hookups and watch the VCR on channel 3 or 4 of your TV. The VCR will automatically switch the TV•VCR setting to VCR every time the VCR is turned on, a tape with the safety tab removed is inserted, or you press PLAY.
 - Select OFF if you used one of the advanced hookups and watch your VCR on the video input channel of your TV. The VCR indicator will not turn on automatically and the signal from your antenna or cable to your TV will not be interrupted. Pressing TV•VCR on the remote will still turn the VCR indicator on or off and switch the antenna signal.



VCR Function Buttons

VCR Function Buttons



CHANNEL Up or Down
Selects next higher or lower channel in the VCR's channel memory.

CLEAR
Resets time counter to 0:00:00.
Allows you to change entries when setting the clock or VCR for a VCR Plus+ or timer recording.

DISPLAY
Shows VCR operating displays on the TV screen.
Displays the time counter.

FF (Fast Forward)
Fast forwards the tape when the VCR is stopped.

Searches the picture in forward motion during playback.

INPUT
Turns the line input on or off. VID1 appears in VCR's display panel and VIDEO appears on TV screen.

Line input refers to the signal coming from the component connected to the AUDIO/VIDEO IN jacks on the back of the VCR.

MENU
Displays the VCR MAIN MENU on the TV screen.

Removes a menu from the screen.

Numbers (0 through 9)
Select a channel up to 99 by pressing two numbers.

Select a cable channel over 99 by pressing and holding 1 until 1-- appears on the screen. Then press the other two numbers.

PAUSE
Pauses action for viewing during playback.

Pauses recording to prevent recording of unwanted scenes.

PLAY
Plays a tape.

POWER
Turns the VCR on and off.

PREV CH (Previous Channel)
Switches between two channels.

Select one channel and then use the number buttons to select another. Press PREV CH to switch between the two channels.

REC
Starts VCR recording.

Used for express recording (XPR). See page 19.

REW (Rewind)
Rewinds the tape when the VCR is stopped.

Searches the picture in reverse motion during playback.

SEARCH
Displays INDEX and ZERO SEARCH menus on TV.

Lets you advance tape 60 or 120 seconds during playback.

SPEED (Tape Speed)
Selects a recording speed (SP or SLP).

STOP
Stops the normal functions such as record, playback, rewind, fast forward, and pause.


TRACKING - and +
Lets you manually reduce the streaks that may appear on the picture during play or pause.


TV•VCR
Switches the picture signal so that it either comes from the VCR or the TV channel. See page 10.

Operating Instructions

To Play a Tape

1. Turn on the TV and tune it to channel 3, 4, or TV's video input to see the picture from the VCR.
2. Insert a tape in the VCR.

VCR automatically turns on. The cassette-in  indicator lights, and the VCR indicator lights if the Auto TV/VCR feature is set to ON. The tape automatically begins playback if the safety tab on the cassette has been removed and the Auto Play feature is turned on.




3. Press PLAY on the remote or PLAY•PAUSE on the VCR, if necessary. PLAY appears in the VCR's display panel.
4. Press TRACKING up or down to remove any streaks from the picture, if necessary. *Details are on page 13.*
5. Press STOP on the remote or STOP•EJECT on the VCR.
6. Press REW. REW will appear in the VCR's display panel.
The VCR will automatically rewind the tape if it reaches the end of the tape during playback. While rewinding, you can press POWER and the VCR will turn off after rewinding.
7. Press STOP•EJECT on the VCR to eject the tape once it is completely rewound.

Auto Play Feature

This feature lets you tell the VCR whether you want it to automatically start playing a tape that is inserted with the safety tab removed.

1. Press MENU on the remote to see the VCR MAIN MENU on the TV screen.
2. Press 5 to display the PREFERENCES menu.
3. Press 1 to select Auto Play: ON or OFF.
 - Select ON to have a tape with its safety tab removed start playing automatically.
 - Select OFF if you do not want a tape with its safety tab removed to start playing automatically.



Using the Playback Features

Pause for Stop Action

This feature stops the tape in action and allows you to examine the details of the scene. Stop action works best for tapes recorded in SLP speed.

1. Press PAUSE on the remote or PLAY•PAUSE on the VCR during playback to stop the action.

PAUS appears in the VCR's display panel.

2. Press PLAY•PAUSE on the VCR or PLAY on the remote to return to playback.

The VCR will automatically switch from stop-action playback to stop after a few minutes.

Picture Search

You can search a picture during playback by fast forwarding or rewinding the tape. Sound is turned off during picture search. Picture search works best for tapes recorded in SLP speed.

Fast Forward Search

1. During playback, press FF on the remote or FWD on the VCR to search forward at a faster-than-normal speed.

SRCH+ appears in the VCR's display panel.

2. To return to playback, press FF on the remote, FWD on the VCR, PLAY on the remote, or PLAY•PAUSE on the VCR.

Rewind Search

1. During playback, press REW to search in reverse at a faster-than-normal speed.

SRCH- appears in the VCR's display panel.

2. To return to playback, press REW, PLAY on the remote, or PLAY•PAUSE on the VCR.

Automatic Tracking

The VCR has automatic tracking which adjusts the picture when playing back a tape recorded on another VCR. Automatic tracking is turned on whenever a tape is inserted or the VCR's power is turned on.

Manual Tracking

Occasionally, you may need to manually adjust tracking on a tape recorded on a different VCR or camcorder. The TRACKING buttons on the remote or VCR are used when playing a tape. They have no effect during recording.

- When streaks or snow appear, press TRACKING up or down for the best possible picture.

Using the Playback Features

DISPLAY Button


1. Press DISPLAY to display the status of the VCR, channel number, time counter, date, time, and tape speed on the TV screen. The VCR status will appear in the display panel.

The time and date must be set before they are displayed. If you do not press DISPLAY again, these displays will time out.
2. Press DISPLAY again to have only the time counter remain on the TV screen. The time counter will appear instead of the time in the VCR's display panel.
3. Press DISPLAY again to remove the time counter from the TV screen.

The time counter will remain in the VCR's display panel.
4. Press DISPLAY again to return to the normal status displays.

The time will appear in the VCR's display panel.

Turning off the VCR automatically returns the displays to normal.




Time Counter

The time counter shows the elapsed time it takes to record a program or play back a segment of a prerecorded tape. It helps locate the beginning or end of programs you taped. The time counter resets to 0:00:00 whenever the tape is ejected from the VCR.

For example, if a 30-minute program was recorded at the beginning of the tape, you would:

1. Insert the prerecorded tape. Make sure the tape is rewound. Press STOP on the remote or STOP•EJECT on the VCR.
2. Press DISPLAY twice to display only the time counter on the TV screen.
3. Press CLEAR to reset the time counter to 0:00:00.
4. Press FF on remote or FWD on the VCR to fast forward the tape until the time counter reads 0:30:00. Press STOP on the remote or STOP•EJECT on the VCR.

This is the approximate end of the program and you can begin recording at this spot.
5. Press DISPLAY to remove the time counter from the screen and return to the normal displays.



Using the Playback Features

Commercial Scan (SEARCH Button)

This is useful for scanning commercials or short program segments.

1. Press SEARCH once during playback to advance the tape approximately 60 seconds.
2. Press SEARCH twice during playback to advance the tape approximately 120 seconds.

SRCH+ appears in the VCR's display panel.

Index Search

The VCR has a "VHS Index Search System" that automatically records an index mark on the tape every time you begin recording a program. During playback you can locate the program you want to play by the number of index marks.

The VCR will automatically locate the index number you select. The VCR will search forward or reverse from the location you are on the tape.



1. Insert the prerecorded tape and press STOP.
2. Press SEARCH on the remote to display the INDEX SEARCH menu on the TV screen.
3. Press FF or REW to search for the next index mark or press two number buttons to enter the specific index mark you want the VCR to search for.

Press CLEAR to correct an entry.

4. Press FF to search forward or press REW to search in reverse.
5. Press STOP to stop index searching.

Some index marks may be missed by the VCR.

- A mark too close to your location on the tape.
- The mark at the beginning of a recorded segment of five minutes or less.
- The first index mark on the tape when you start at the beginning of the tape.



Using the Playback Features

Zero Search

The zero search feature allows you to quickly return to a counter reading of 0:00:00 at any spot on the tape. This is convenient when you want to watch a segment of the tape several times.

1. Insert the prerecorded tape and press STOP.
2. Press DISPLAY twice to display only the time counter on the TV screen.
3. Locate the point on the tape that you want to return to quickly.
4. Press CLEAR to reset the time counter to 0:00:00.
5. You can continue to play the tape or perform other functions. When you are finished, press STOP.
6. Press SEARCH twice to display the ZERO SEARCH menu. The current tape counter is displayed.
7. Press REW to return to 0:00:00. When the VCR reaches 0:00:00 it will begin playback.
If the time counter reading has a minus (-) in front of it, press FF to return to a reading of 0:00:00.
8. Press STOP to stop zero search.

```
ZERO SEARCH  
Current tape counter is  
2:17:25  
Press REW to go to  
0:00:00  
Press SEARCH to exit
```

-OR-

```
ZERO SEARCH  
Current tape counter is  
-2:17:25  
Press FF to go to  
0:00:00  
Press SEARCH to exit
```

Types of Recordings

Your VCR provides different types of recording. These types are explained in the following sections:

Basic Recording – Operating Instructions

Express (XPR) Recording

Recording While You're Away

VCR Plus+ Recording

Timer Recording

Using Two VCRs for Copying Tapes

Using the Recording Features

Recording Speeds

Press **SPEED** on the remote to select a recording speed (SP or SLP). The speed you select appears on the TV screen and in the VCR's display panel. The VCR automatically selects the playback speed (SP, LP, or SLP).

Cassette Type	Recording Time	
	SP	SLP
T120	2Hr	6Hr
T160	2Hr 40Min	8Hr

SP (Standard Play) gives the best quality recording. That is why most prerecorded, rental tapes are recorded in SP. Fewer programs can be recorded on the tape.

SLP (Super Long Play) gives three times the recording time of tapes recorded in SP. Special effects, such as pause and picture search, work well.

Recording Pause

This feature allows you to prevent recording short passages of unwanted material.

Press **PAUSE** during recording to stop and start recording. **REC.P** appears in the VCR's display panel.


The VCR will automatically switch from pause to stop after a few minutes.

Types of Recordings

Basic Recording – Operating Instructions

To Make a Recording

Turn on the TV and tune it to the VCR viewing channel, either 3, 4, or TV's video input channel.


1. Insert a tape with safety tab in place.
The cassette-in indicator  lights in the VCR's display panel.
2. If using one of the basic hookups, make sure the VCR indicator appears in the VCR's display panel. If not, press TV•VCR to turn it on.
3. Select recording speed using SPEED on the remote.
The tape speed indicator appears in the VCR's display panel and on the TV screen.
4. Select the channel to be recorded.
The channel number appears in the VCR's display panel and on the TV screen.
5. Press REC on the remote or RECORD on the VCR to begin recording. REC appears in the VCR's display panel while the VCR is recording.

Watch a TV Channel While VCR is Recording a Different Channel

1. Follow steps 1 through 5 above.
2. If using one of the basic hookups, press TV•VCR to switch to the TV channel. The VCR indicator will turn off in the display panel.
3. Select the channel you want to watch with the TV's channel buttons.
4. Press STOP on the remote or STOP•EJECT on the VCR when recording is finished.

Express Recording (XPR)

Express recording lets you record up to four hours without using the timer program feature. The VCR will turn off automatically at the end of the recording.



Operating Instructions

1. Turn on the VCR.
2. Insert a tape with safety tab in place.
3. Select the channel you want to record.
4. Select the desired recording speed using SPEED on the remote.
5. Press REC on the remote or RECORD on the VCR twice to activate XPR recording.
6. Press REC on the remote or RECORD on the VCR repeatedly until the amount of recording time for the program is displayed in the VCR's display panel or on the TV screen.

	Press RECORD	Recording Time
<div style="border: 1px solid black; padding: 5px; width: fit-content;"> <p>REC Ch 11 Record Length 0:30</p> <p>Press REC to set length</p> </div> <p style="text-align: center;">Express Display on TV Screen</p>	0:30	(30 Min)
	1:00	(1 Hr)
	1:30	(1 Hr, 30 Min)
	2:00	(2 Hrs)
	3:00	(3 Hrs)
	4:00	(4 Hrs)
		(Normal Recording)

Each press increases the time — 30 minutes up to four hours.

The amount of time the VCR will record and REC will appear in the VCR's display panel.

You can increase the amount of recording time by pressing REC on the remote or RECORD on the VCR.

Stopping a Recording in Progress

Press and hold STOP on the remote or STOP•EJECT on the VCR for approximately three seconds.

Recording While You're Away (VCR Plus+* Recording)

VCR Plus+ Setup for Antenna or Unscrambled Cable Systems (Not Requiring a Cable Box)

A VCR Plus+ channel number is assigned for each broadcast or cable channel. These numbers are listed in most publications that list PlusCode* numbers.

1. Prepare the worksheet on the opposing page for the VCR Plus+ channels that are different than the channels you receive them on. Refer to the chart below for standardized VCR Plus+ channel numbers.

Broadcast or Cable-TV Station Name	VCR Plus+ Channel Number	Channel Number You Receive This Station On
HBO	33	See Note 1
ESPN	34	See Note 1
ABC	See Note 2	See Note 1
FOX	See Note 2	See Note 1

Note 1: Check your local or cable listing for the channel number you receive this station on.
Note 2: Check your local listing for the broadcast or VCR Plus+ channel number assigned to this station.


2. Press MENU on the remote to display the VCR MAIN MENU on the TV screen.
3. Press 4 to display CHANNELS menu.
4. Press 4 to display VCR Plus+ Channel List menu.
5. Using your worksheet, press two numbers to enter each channel number you receive on a different channel than the assigned VCR Plus+ channel number.

Press CHANNEL up or down to move the numbers up or down on the menu.

Press CLEAR on the remote to erase a number.

6. Press MENU when you are finished.

Auto channel search must be performed before setting the VCR Plus+ channel list.



Standardized VCR Plus+ Channel Numbers for Cable-TV

U.S.A. List		Canadian List	
35 American Movie Classics	58 The Movie Channel	67 Allarcom Pay Television/Superchannel	65 MeteoMedia/The Weather Network
39 Arts & Entertainment	48 Music Television	44 Arts & Entertainment	48 MuchMusic Network
57 Black Entertainment	49 The Nashville Network	72 Cable News Network-Headline News	55 MusiquePlus
54 Bravo	38 Nickelodeon	61 Cable News Network	52 Nashville Network
42 Cable News Network	64 Nostalgia Television	70 Canadian Home Shopping Network	73 Newsworld/CBC
45 Cinemax	99 Quality Value Cable	56 Canal Famille	53 Le Reseau des Sports
98 Cinemax 2	41 Showtime	69 Cathay International Television Inc	43 The Sports Network
37 The Discovery Channel	97 Showtime 2	68 Chinavision Canada Corp	64 Super Ecran
53 The Disney Channel	59 Sports Channel	60 Country Music Television	37 Super Ecran B
63 Entertainment Television	52 Turner Network Television	63 Family Channel	98 Super Ecran C
34 ESPN Sports Network	44 USA Network	62 First Choice	66 Telatino Network
47 The Family Channel	62 Video Hits 1	96 First Choice Two	46 TV5 Montreal
33 Home Box Office	93 Viewer's Choice 1	97 First Choice Three	92 Viewer's Choice 1
95 Home Box Office 2	94 Viewer's Choice 2	99 First Choice Four	93 Viewer's Choice 2
96 Home Box Office 3	55 WGN Chicago	90 House of Commons	94 Viewer's Choice 3
51 The Learning Channel	43 WTBS Atlanta	91 La Chaîne Francaise	95 Viewer's Choice 4
46 Lifetime	60 WWOR New York	51 The Learning Channel	71 Vision TV: Canada's Faith Network
			38 Youth TV, Canada Inc

*VCR Plus+ and PlusCode are trademarks of Gemstar Development Corporation.

Recording While You're Away (VCR Plus+ Recording)

The VCR Plus+ and timer program features let you program the VCR to record up to eight different programs within a one year period. Before using VCR Plus+ to record a program, make sure that:

- The clock is set correctly.
- A tape with safety tab has been inserted with enough tape to record the programs.
- The VCR is setup for VCR Plus+ programming.
 - If you do not use a cable box for all channels, complete VCR Plus+ setup *on pages 20-21*.

Setting a VCR Plus+ Recording

1. Press MENU on the remote to display the VCR MAIN MENU on the TV screen.
2. Press 1 to display the VCR PLUS+ menu.
3. Press numbers on the remote to enter the PlusCode number for the program you want to record. PlusCode numbers are found in most local TV listings.

Press CLEAR on the remote to correct an entry.

4. Press MENU to enter the program.

If the VCR does not recognize the PlusCode number, Unrecognized number... Please re-enter appears on the TV screen. Check the number and enter it again.

5. Press 1, 2, 3, or 4 to select type of program.
 - 1 One time – single program recorded once.
 - 2 Daily – program recorded at same time every day.
 - 3 Weekdays – program recorded at same time Monday through Friday.
 - 4 Weekly – program recorded at same time once a week.

6. Press SPEED on the remote to change recording speed.

7. Press CLEAR if you want to change the program end time. This feature allows you to extend the recording time on VCR Plus+ programs. This option may be useful when recording programs such as sporting events that could go past scheduled broadcast times.

8. Press MENU to enter your program. A reminder appears which will time out.


PROGRAMS OVERLAP may appear on the screen if you entered two programs where the times overlap.

9. The TIMER RECORDINGS menu appears. Press 3 to enter an additional VCR Plus+ program, or press 0 to exit.

10. **Turn off the VCR** before recording time.

TIMER appears in the VCR's display panel when the timer has been programmed.

11. **If using a cable box, leave it turned on and tuned to the channel you want to record.**



Stopping a Recording in Progress

Press and hold STOP on the remote or STOP•EJECT on the VCR for approximately three seconds.

Recording While You're Away (Timer Recording)

The VCR Plus+ and timer program features let you program the VCR to record up to eight different programs within a one year period. Before setting the timer, make sure that:


- The clock is set correctly.
- A tape with safety tab has been inserted with enough tape to record the programs.

Setting a Timer Recording

1. Press MENU on remote to display VCR MAIN MENU.
2. Press 2 to display TIMER RECORDINGS menu.
3. Press 1 to display Create a New Program menu.
4. Press 1, 2, 3, or 4 to select type of program.
 - 1 One time — single program recorded once.
 - 2 Daily — program recorded at same time every day.
 - 3 Weekdays — program recorded at same time Monday through Friday.
 - 4 Weekly — program recorded at same time once a week.
5. Press number buttons on the remote to enter the channel number (use INPUT or 0, 0 to select video input), start time including AM or PM, end time, and start date of the recording. Just follow the on-screen prompts. Press CLEAR to correct an entry.
6. Press SPEED on the remote to change recording speed.
7. Press MENU to enter your program. A reminder appears which will time out or you can press MENU to return to the VCR MAIN MENU. PROGRAMS OVERLAP may appear on the screen if you have entered two programs where the times overlap.
8. The TIMER RECORDINGS menu appears. Press 1 to enter an additional timer program, or press 0 to exit.
9. **Turn off the VCR** before recording begins. TIMER appears in the VCR's display panel when the timer has been programmed.
10. **If using a cable box, leave it turned on and tuned to the channel you want to record.**

Stopping a Recording in Progress


Press and hold STOP on the remote or STOP•EJECT on the VCR for approximately three seconds.



Recording While You're Away

Checking or Clearing VCR Plus+ or Timer Recordings


1. Press MENU on remote to display VCR MAIN MENU on TV screen.
2. Press 2 to display the TIMER RECORDINGS menu.
3. Press 2 for Review Existing Progs. feature.
4. Press MENU to display information for the next program.
5. Press CLEAR when the program you want to erase appears on the screen.



Timer Recording From the VCR's Line Input

The line input refers to the signal coming from the AUDIO and VIDEO IN jacks of the VCR. Recording from the line input is convenient if you have a satellite receiver or similar component attached to these jacks. To timer record from the component connected to the VCR's line input:

Press INPUT (or 0,0) to select VIDEO in place of the channel number on the TV screen during timer programming.



Using Two VCRs for Copying and Editing Tapes

Operating Instructions (Refer to hookup on page 6.)

Use this VCR as the playback VCR and the other as the recording VCR.

Caution: The unauthorized recording of television programs and other materials may infringe the rights of others.

1. Turn on the TV and VCRs.
2. Tune TV to the VCR viewing channel, either 3, 4, or TV's video input.
3. If you have connected your VCR using Option A (page 6), tune recording VCR to channel 3 or 4 — the one selected on the back of the playback VCR.


If you have connected your VCR using Option B (page 6), press INPUT on recording VCR's remote to select the line input (VID1).

4. Insert the tape you want to copy into playback VCR. Insert a blank tape with safety tab in place into recording VCR.
5. Press PLAY, then PAUSE on playback VCR when you reach the point on the tape or program where you want to begin copying. If the tape was not recorded on the playback VCR, streaks may appear and you may need to adjust tracking.
6. Press RECORD, then PAUSE, on recording VCR.
7. Press PAUSE buttons on both VCRs at the same time to begin copying the tape.*
8. Edit out segments that you do not want to copy by pressing PAUSE on recording VCR to stop copying the tape. Then locate the next segment you want to copy on the playback VCR by using FWD, REW, and PLAY. Press PAUSE on the playback VCR. Press PAUSE at the same time on both VCRs to resume copying.
9. Press STOP on both VCRs when you are finished.

* You may turn off the TV after the recording has started as it does not have to be on to copy a tape.

Location of Controls

Front Panel



CHANNEL or TRACKING Up or Down

Selects next higher or lower channel in the VCR's channel memory.

Adjusts tracking during playback or pause.

FWD (Fast Forward)

Fast forwards the tape when the VCR is stopped.

Searches the picture forward during playback.

PLAY•PAUSE

Plays a tape.

Pauses the tape for stop-action viewing during playback.

Pauses the tape during recording to prevent recording unwanted material.

POWER

Turns the VCR on or off.

RECORD

Start the VCR recording.

Used for express recording.

Remote Sensor

Receives signals from the remote control. Aim the remote at this sensor with no objects between them.

REW

Rewinds the tape when the VCR is stopped.

Searches the picture in reverse during playback.


STOP•EJECT

Stops the normal functions such as record, playback, rewind, fast-forward, or pause.

Press when the VCR is stopped to eject the cassette.

Location of Controls

Back Panel



CH3 CH4 Switch

Selects the channel to which you will tune the TV to see the VCR picture if you connect the VCR using one of the basic hookups.

ANT. (Antenna) IN Connector

Receives the signal from an antenna or cable system that is attached to this connector.

RF OUT Connector

Passes signal to TV using the cable supplied.


VIDEO and AUDIO IN Jacks

Receives signals from another component, like a VCR or camcorder, when it is connected to these jacks. Use INPUT or channel number 0,0 to select VID1 in the VCR's display panel.

VIDEO and AUDIO OUT Jacks

Sends signals from VCR to another component, like a TV monitor or VCR, when it is connected to these jacks.

Display Panel



Cassette-in Indicator ()

Lights when a tape is in the VCR. Flashes while tape is ejecting.

Channel Number, Line Indicator (VID1), Time, Time Counter, or Status Indicator

The current time, time counter, channel number, or line indicator (VID1) appears here.

Status indicators show what the VCR is doing.

BYE	Turned off
F.FWD	Fast forward
HI	Turned on
PLAY	Playback
PAUS	Play pause
REC	Record
REC.P	Record pause
REW	Rewind
SRCH+	Forward search

SRCH-	Reverse search
STOP	VCR stopped
T.REC	Timer recording

REC Indicator

Lights when the VCR is recording.

Tape Speed Indicators (SP, LP, or SLP)

Press SPEED to change.

TIMER Indicator

Lights when a timer recording is set.

VCR Indicator (Applies Only to Basic Hookups)

Press TV•VCR to turn on or off.

VCR indicator on: Picture from VCR.

VCR indicator off: Picture from TV channel.

Specifications

Format:	VHS
Record/Playback System:	Video: 2-Head Audio: Mono record/playback system
Video Signal System:	EIA standard: NTSC color
Antenna:	75-ohm external VHF/UHF combined antenna terminal
Tuner:	USA: 181 channels capability* (125 cable channels) Canada: 178 channels capability* (122 cable channels)
Type:	AutoProgramming frequency synthesis
Power Requirement:	120V AC, 60 Hz
Power Consumption:	17 watts
Dimensions:	3.5 inches high (90 mm) 15.5 inches wide (393 mm) 12.5 inches deep (318 mm)
Weight:	9.5 pounds (4.3 kg)
Storage Temperature Range:	- 22°F (- 30°C) to +149°F (+65°C)
Operating Temperature Range:	+41°F (+5°C) to +104°F (+40°C)

*Check your cable company's compatibility requirements.

Cleaning the VCR

Use a soft cloth or dusting attachment of your vacuum cleaner to dust your VCR. Remove dust from the ventilation holes on the top, back, sides, and bottom of the cabinet.

Plastic surfaces are easily scratched and can be marred by alcohol and various solvents. Avoid excessive use of oil-based furniture polishes since the materials used in the cabinet will accumulate more dust. We recommend using a non-abrasive, anti-static cleaner and polisher.

Trouble Checks

Sometimes problems can be easily solved by checking a few basic things. Check below before you call for help or take your VCR to an Authorized RCA VCR Servicenter.

Trouble	Here's what to try:
No power	<ul style="list-style-type: none"> • Plug VCR into an operating outlet. • Check connections.
VCR does not respond to remote	<ul style="list-style-type: none"> • Remove batteries and hold down one or more buttons for several seconds to drain the microprocessor inside the remote to reset it. Reinstall the batteries and try remote again. • Aim remote at VCR with no objects between them. • Change batteries.
No picture when VCR turned on – using a basic hookup	<ul style="list-style-type: none"> • Press TV•VCR to turn VCR indicator on. <i>See page 10.</i> • Check to see if Auto TV/VCR feature is set to OFF. <i>See page 10.</i>
Poor or no picture for normal TV viewing	<ul style="list-style-type: none"> • Press TV•VCR to turn VCR indicator off. • Switch TV to an active channel. • Check antenna connections.
Snowy or no picture during playback	<ul style="list-style-type: none"> • Press TV•VCR to turn VCR indicator on. • Check TV channel selected (3 or 4) to make sure it matches the channel selected with CH3 CH4 switch on back of VCR. • Check TV's fine tuning. • Check video cable connections between VCR and TV monitor. • Set TV monitor to video input channel. • Try another tape. • Some snow / streaks are normal during search or stop-action playback.
Time counter not working	<ul style="list-style-type: none"> • The time counter does not advance during unrecorded portions of tape. When an unrecorded segment of tape is encountered, the time counter will hold its count until recorded material is detected again. • A minus (-) will appear in front of the time if you rewind the tape farther back than a counter reading of 0:00:00.
Will not record or play	<ul style="list-style-type: none"> • No cassette in VCR. • Eject and re-insert cassette. • Broken tape — try another cassette.

Trouble Checks

Trouble	Here's what to try:
Streaks in picture during normal playback	<ul style="list-style-type: none"> • Some snow/streaks are normal during search or stop-action playback.
Will not record	<ul style="list-style-type: none"> • VCR is in pause mode. Press PAUSE. • Safety tab removed from cassette. • Make sure the line indicator (VID1) is turned off in VCR's display panel for normal recording from the VCR's tuner. Press INPUT to turn off the line indicator.
Rewind does not operate	<ul style="list-style-type: none"> • Tape already rewound.
VCR Plus+ or timer recording not made or wrong program recorded	<ul style="list-style-type: none"> • Wrong PlusCode number entered. • Cable box was not turned on or was tuned to the wrong channel at time recording was to begin. • Program entered incorrectly (wrong channel or times). • Power interruption. Clock area in display panel will show - -: -. • Check to see if time and date are correct — including AM/PM. • Check Signal Type: CABLE/ANTENNA feature. <i>See page 8.</i> • Program exceeded tape's length or tape was not rewound beforehand. • VCR was not turned off at the time recording was to start. • No tape in VCR or cassette's safety tab broken off.
Clock shows incorrect time or date	<ul style="list-style-type: none"> • Power interruption. Clock on the front panel will show --:--. • Clock was not set accurately (check AM/PM and date). • Time counter display appears in VCR's display panel. Press DISPLAY on remote.
VCR makes noise when stopped	<ul style="list-style-type: none"> • VCR is removing tape from heads. This is normal. The head cylinder inside the VCR will continue to rotate for a few minutes after you put the VCR in the stop mode.
Will not auto channel search active channels correctly	<ul style="list-style-type: none"> • Check antenna connections. • Check Signal Type: CABLE/ANTENNA feature. <i>See page 8.</i>
Cannot select channels over 69	<ul style="list-style-type: none"> • Cable channels over 69 can only be selected if Signal Type: CABLE/ANTENNA feature is set to CABLE. <i>Details are on page 8.</i>
Cassette with safety tab removed does not start to play automatically	<ul style="list-style-type: none"> • Set Auto Play ON/OFF feature to ON. <i>Details are on page 12.</i>
Displays appear in wrong language	<ul style="list-style-type: none"> • Language feature set incorrectly. <i>Details are on page 9.</i>

Limited Warranty

What your warranty covers:

- Any defect in material or workmanship.

For how long after your purchase:

- Ninety days for labor charges.
- One year for parts.

The warranty period for rental units begins with the first rental or 45 days from the date of shipment to the rental firm, whichever comes first.

What we will do:

- Pay any Authorized RCA VCR Servicenter the labor charges to repair your VCR.
- Pay any Authorized RCA VCR Servicenter for the new or, at our option, refurbished replacement parts required to repair your VCR.

How you get service:

- Take your VCR to any Authorized RCA VCR Servicenter. To identify your nearest Authorized RCA VCR Servicenter, ask your dealer, look in the Yellow Pages, or call 1-800-336-1900.
- Show the service technician your evidence of purchase date.
- Pick up your VCR when repairs are completed.

What your warranty does not cover:

- Customer instruction. (Your Owner's Manual clearly describes how to install, adjust, and operate your VCR. Any additional information should be obtained from your Dealer.)
- Installation and related adjustments.
- Signal reception problems not caused by your VCR.
- Damage from misuse or neglect.
- Cleaning of video/audio heads.
- Remote control batteries.
- A VCR that has been modified or incorporated into other products or is used for institutional or other commercial purposes.
- A VCR purchased or serviced outside the USA.
- Acts of God, such as but not limited to lightning damage.

Product Registration:

- Please complete and mail the Product Registration Card packed with your VCR. It will make it easier to contact you should it ever be necessary. The return of the card is not required for warranty coverage.

How state law relates to this warranty:

- This warranty gives you specific legal rights, and you also may have other rights that vary from state to state.

If you purchased your VCR outside the United States:

- This warranty does not apply. Contact your dealer for warranty information.

Index

- Accessories, Included 7
- Add or Remove Channels from Memory9
- ADD/REMOVE CHANNEL Menu 9
- ANT. (Antenna) IN Connector 3-8,27
- Antenna Connections 2,3
- AUDIO and VIDEO Jacks 3-6,24,27
- Auto Channel Search Feature 8
- Auto Play Feature 12
- Auto TV/VCR Feature 10
- Automatic Tracking 13
- Back Panel 27
- Basic Recording 18
- Batteries, Inserting in Remote 7
- Cable System With Cable Box 2,3-5
- Cable System Without Cable Box .. 2,3
- Card, Registration i
- Cassette-In Indicator 12,18,28
- CH3 CH4 Switch 3-6,8,27
- CHANNEL Buttons 8,9,10,11,20
- Channel Number Indicator 28
- CHANNELS Menu 8,20
- CHANNEL•TRACKING Button 13,26
- Checking Timer and VCR Plus+
 - Programs 24
- Checks, Trouble 30-31
- Choisissez une Langue 9
- Choosing a Hookup 2
- Cleaning the VCR 29
- CLEAR Button . 9,11,14,15,16,20,22,23,24
- Clearing Timer and VCR Plus+
 - Programs 24
- Commercial Scan 15
- Connections
 - Antenna 2-3
 - Cable With a Cable Box 2,4-5
 - Cable Without a Cable Box 2,3
 - Two VCRs for Copying Tapes 6
- Contents 1
- Copying and Editing Tapes 25
- Copying Tape, Connections 6
- Date, Set 9
- Design Specifications 29
- DISPLAY Button 9,11,14
- Display Panel 28
- Displays, Status 14
- Editing and Copying Tapes 25
- Express Recording 19
- Express recording, Stopping 19
- FF (Fast Forward) Button 11,13-16
- First-Time Operation 7-10
- Front Panel 26
- Hookups
 - Antenna 2-3
 - Cable With a Cable Box 2,4-5
 - Cable Without a Cable Box 2,3
 - Choosing 2
 - Two VCRs for Copying Tapes 6
- INDEX Feature 15
- INDEX SEARCH Menu 15
- INPUT Button 11,22,23,24,27
- LANGUAGE Menu 9
- Limited Warranty 32
- Line Input, Recording From 24
- Manual Tracking 13
- MENU Button .. 8,9,10,11,12,20,22,23,24
- Number Buttons 11
- On-Screen Displays 14
- Operation
 - Basic Recording 18
 - Copying Tapes 25
 - Express Recording 19
 - First Time 7-10
 - Playback 12
 - Timer Recording 18
 - VCR Plus+ Recording 20-22
- PAUSE Button 11,13,17,25
- Pause for Stop Action 13
- Pause, Recording 17
- Picture Search, 13
- PLAY Button 11,12,13,14,25
- PLAY•PAUSE Button 12,13,25,26
- POWER Button 8,11
- PREFERENCES Menu 10,25
- PREV CH (Previous Channel) Button .11
- Problems, Solving 30-31
- Product Registration i
- REC and RECORD
 - Buttons 11,18,19,25,26
- REC Indicator 18,19,25,26
- REC.P (Record Pause) Indicator 17
- Recording
 - Basic 18
 - Express 19
 - Pause 17
 - Speeds 17
 - Timer 23
 - Types of 18
 - VCR Plus+ 20-22
- Registration Card i
- Remote Sensor 26
- Remove or Add Channels from
 - Memory 9
- REMOVE/ADD Channel Menu 9
- REW (Rewind) Button 11,12,13,15,16
- RF OUT Connector 3-8,27
- Safety Precautions i
- SEARCH Button 11,15,16
- Select a Language 9
- Sensor, Remote 26
- Set Clock Feature 9
- Set the Time and Date 9
- SET TIME AND DATE Menu 9
- Setting a Timer Recording 23
- Setting a VCR Plus+ Recording 22
- Setting Up the VCR 7-10
- Signal Type: CABLE/ANTENNA
 - Feature 8
- SLP Speed 17
- Solving Problems 30-31
- SP Speed 17
- Specifications 29
- SPEED Button 11,17,18
- Speeds, Recording 17
- Standardized VCR Plus+ Channel
 - Number Chart 20
- Startup 7-10
- Status Displays 14
- Status Indicators 28
- Stop Action Pause 13
- STOP Button . 11,12,14-16,18,19,22,23,25
- Stopping a Timer Recording 23
- Stopping a VCR Plus+ Recording ... 22
- Stopping an Express Recording 19
- STOP•EJECT Button .. 12,18,19,22,23,26
- Table of Contents 1
- Tape Speed Indicators 28
- Tape, Playing 12
- Time and Date, Set 9
- Time Counter 14,28
- Time Display 28
- Time, Set 9
- TIMER Indicator 19,22,23,28
- Timer Recording
 - Checking or Clearing 24
 - Setting 23
 - Stopping 23
- TIMER RECORDINGS Menu .22,23,24,25
- TRACKING Buttons 11,12,13
- Tracking, Automatic and Manual ... 13
- Trouble Checks 30-31
- Turn On TV 8
- Turn on VCR 8
- TV, Turn On 8
- TV•VCR Button 10
- TV•VCR Button 11,18
- Types of Recordings 18
- Using TV•VCR Button 10
- VCR Controls 26-28
- VCR Indicator 12,18,28
- VCR MAIN MENU . 8,10,12,20,22,23,24
- VCR Plus+ Recording
 - Checking or Clearing 23
 - Channel Worksheet 21
 - Stopping 22
 - VCR PLUS+ Menu 22
 - VCR Plus+ Setup Channels 20
 - VCR PlusCodes 22
 - Worksheet 21
- VCR, Cleaning 29
- VCR, Turn On 8
- VCRs Memory, Placing Channels In .. 8
- VCRs, Connecting for Tape Copying .. 6
- VID1 Indicator 28
- Warranty, Limited 32
- Watch One Channel While
 - Recording Another 18
- XPR Recording 19
- Zero Search Feature 16
- ZERO SEARCH Menu 16

For your nearest Authorized Servicenter
call toll-free in the U.S.A.

1-800-336-1900

Canadian Consumers –
Your toll free numbers are:

English: 1-800-522-0338

French: 1-800-522-0445

If you would like a copy of this manual in French, please follow the
instructions below:

Si un livret d'instructions en français n'est pas inclus avec votre appareil, vous
pouvez en obtenir un (indiquer le numéro de modèle, votre nom, et votre
adresse) en vous adressant à:

Thomson Consumer Electronics
Attention: Canadian Operations
P.O. Box 0944
Indianapolis, IN 46206-0944

If your VCR needs service, please contact your dealer
or the nearest Servicenter from the yellow pages.
Please do not send any products to the Indianapolis
address listed in this manual or on the carton. This
will only add delays in service for your product.

 **THOMSON CONSUMER ELECTRONICS**

10330 North Meridian Street
Indianapolis, IN 46290-1024

©1996 Thomson Consumer Electronics, Inc.
Trademark(s)® Registered
Marca(s) Registrada(s)
Printed in Korea
Part Number 96-VR348-1