


SAMSUNG

MICROWAVE OVEN

Owner's Instructions and Cooking Guide

**CE117A / CE117AE/
CE117AT**




| | |
|---|----|
| "Quick" Look-up Guide | 2 |
| Using the Steam Cleaning (CE117AE) | 2 |
| Control Panel | 3 |
| Oven | 4 |
| Accessories | 4 |
| Using this Instruction Booklet | 5 |
| Safety Precautions | 6 |
| Installing Your Microwave Oven | 7 |
| Setting the Time | 7 |
| Checking that Your Oven is Operating Correctly | 8 |
| How a Microwave Oven Works | 8 |
| What to Do if You are in Doubt or You have a Problem | 8 |
| Cooking/Reheating | 9 |
| Power Levels and Time Variations | 9 |
| Stopping the Cooking | 10 |
| Adjusting the Cooking Time | 10 |
| Using the Auto Cook Feature | 11 |
| Using the Auto Reheat Feature | 12 |
| Using the Power Defrost Feature | 13 |
| Using the Snack Cook Feature | 14 |
| Using the Auto Steam / Crusty Cook Feature (CE117AE) | 15 |
| Using the Manual Steam Cook Function (CE117AE) | 17 |
| Using the Manual Crusty Cook Function (CE117AE / CE117AT) | 19 |
| Multistage Cooking | 21 |
| Fast Preheating the Oven | 21 |
| Cooking by Convection | 22 |
| Grilling | 22 |
| Choosing the Accessories | 23 |
| Combining Microwaves and the Grill | 23 |
| Combining Microwaves and Convection | 24 |
| Using the Deodorize Feature (CE117A / CE117AT) | 24 |
| Safety-locking Your Microwave Oven | 24 |
| Switching the Beeper Off | 24 |
| Using the Memory Cook Feature (CE117A / CE117AT) | 25 |
| Manual Stop Turntable Function | 25 |
| Cookware Guide | 26 |
| Cooking Guide | 27 |
| Cleaning Your Microwave Oven | 35 |
| Storing and Repairing Your Microwave Oven | 36 |
| Installation & Wiring Instructions | 36 |
| Wiring Instructions | 37 |
| Cooking Instructions On Food Packaging | 37 |
| Cooking Instructions | 38 |
| Technical Specifications | 38 |




“Quick” Look-up Guide

EN


I want to cook some food




1. Place the food in the oven.
Press the **Microwave** () button.



2. Press the **Microwave** () button until the appropriate power level is displayed.




3. Select the cooking time by turning the **dial knob** as required.




4. Press **Start** () button.
Result: Cooking starts
◆ When cooking has finished, the oven will beep and flash “0” four times. The oven will then beep one time per minute.

I want to add an extra 30 seconds




- Leave the food in the oven.
Press **+30s** button one or more times for each extra 30 seconds that you wish to add.


I want to Power defrost some food




1. Place the frozen food in the oven.
Press the **Power Defrost** () button.



2. Select the food category by pressing the **Power Defrost** () button, until the desired food category is selected.



3. Select the weight by turning the **dial knob** as required.




4. Press **Start** () button.
Result: Defrosting starts
◆ When cooking has finished, the oven will beep and flash “0” four times. The oven will then beep one time per minute.


Using the Steam Cleaning (CE117AE)

*The steam provided by steam clean system will soak the cavity surface.
After using steam clean function, you can easily clean the cavity of oven.*


- ☞ Use this function only after the oven has completely cooled. (Room temperature)
- ☞ Use normal water only, and no distilled water.
- ☞ It will be more better if you do a deodorization function after using Steam cleaning.
- ☞ If the door is opened during this operation “E - 47” will be displayed. (The water in the oven will be very hot due to the steam cleaning function.)



1. Open the Door.



2. Fill with water following guide line inside the water bowl. (The line is about 30ml.)




3. Please attach the water bowl in right side of the oven


4. Close the door.



5. Press the **Steam clean** () button. (Bulb does work during Steam cleaning time.)



6. Open the Door.




7. Please clean cavity of oven with dried dishtowel. Remove the turntable and only under rack with kitchen paper.

Warning!

- Water Bowl only can be use during “**Steam Clean**” mode.
- When cooking non-liquid items, remove water bowl because It will damage and cause fire to the microwave oven.

Control Panel


Model : CE117A, CE117AT



1. DISPLAY
2. MEMORY BUTTON
3. AUTO COOK FEATURE BUTTON
4. MICROWAVE BUTTON
5. GRILL BUTTON
6. DEODORIZE BUTTON
7. MICROWAVE+GRILL BUTTON
8. TURNTABLE ON/OFF BUTTON
9. STOP / CANCEL BUTTON
10. POWER DEFROST FEATURE BUTTON
11. AUTO REHEAT FEATURE BUTTON
12. AUTO FAST PREHEAT SELECTION BUTTON
13. CONVECTION BUTTON
14. SNACK MODE
15. MICROWAVE+CONVECTION BUTTON
16. DIAL KNOB (Cook time, Weight and serving size)
17. CLOCK SETTING BUTTON
18. START / +30S BUTTON

Model : CE117AE


EN



1. DISPLAY
2. AUTO STEAM & CRUSTY COOK FEATURE BUTTON
3. AUTO COOK FEATURE BUTTON
4. MICROWAVE BUTTON
5. GRILL BUTTON
6. STEAM CLEAN BUTTON
7. MICROWAVE+GRILL BUTTON
8. TURNTABLE ON/OFF BUTTON
9. STOP / CANCEL BUTTON
10. POWER DEFROST FEATURE BUTTON
11. AUTO REHEAT FEATURE BUTTON
12. AUTO FAST PREHEAT SELECTION BUTTON
13. CONVECTION BUTTON
14. SNACK MODE
15. MICROWAVE+CONVECTION BUTTON
16. DIAL KNOB (Cook time, Weight and serving size)
17. CLOCK SETTING BUTTON
18. START / +30S BUTTON


Oven

EN




Accessories

Depending on the model that you have purchased, you are supplied with several accessories that can be used in a variety of ways.




- 1. Coupler**, to be placed correctly over the motor shaft in the base of the oven.

Purpose: The coupler rotates the turntable.




- 2. Roller ring**, to be placed in the center of the oven.

Purpose: The roller ring supports the turntable.




- 3. turntable**, to be placed on the roller ring with the center fitting on to the coupler.

Purpose: The turntable serves as the main cooking surface; it can be easily removed for cleaning.




- 4. Metal racks** (High rack, Low rack), to be placed on the turntable.

Purpose: The metal racks can be used to cook two dishes at the same time. A small dish may be placed on the turntable and a second dish on the rack. **The metal racks can be used in grill, convection and combination cooking.**




- 5. Clean water bowl**, to be placed in the right side of the oven. (only CE117AE)

Purpose: The water bowl can be used to clean.



- 6. Pro Steamer / Crusty plate** to be placed on the turntable. (only CE117AE)

Purpose: The Pro Steamer can be used to steam crusty cook. The Crusty plate is used to brown food better in the microwave or grill combination cooking modes and to keep pastry and pizza dough crisp.




Stainless Steel Lid



Steam Tray




Steam Plate / Crusty Plate



- 7. Crusty plate**, to be placed on the turntable (only CE117AT)

Purpose: The Crusty plate is used to brown food better in the microwave or grill combination cooking modes and to keep pastry and pizza dough crisp.



Accessories (continued)

Caution!!

- Never use this Pro Steamer with a different product or model. It may cause a fire or fatal damage to the product.
- Do not use the Pro Steamer without water or food inside. When you use this Pro Steamer, pour at least 500ml of water before use. If the amount of water is less than 500ml, it may cause incomplete cooking, or may cause a fire or fatal damage to the product.
- Caution must be taken when removing the container from inside the Pro Steamer after cooking, as it will be very hot.
- The Pro Steamer should be used only in the mode of "Auto steam / Crusty cook (찜) : S-1 to S-5".
- The crusty plate should be used only in the mode of "Auto steam / Crusty cook (찜) : C-1 to C-5".
- Make sure you install the cover onto the Pro Steamer so that it fits into the Steam plate / Crusty plate.
The eggs or the chestnuts would be explode without setting the steam cover and steam plate as instructed on the Instruction book.

Using this Instruction Booklet

Thank you for purchasing a SAMSUNG microwave oven. Your Owner's Instructions contains much valuable information on cooking with your new microwave oven:

- *Safety precautions*
- *Accessories and cookware*
- *Useful cooking tips*

Inside the cover you will find a quick look-up guide explaining three basic cooking operations:

- *Cooking (microwave mode)*
- *Defrosting*
- *Adding an extra 30 seconds, if the dish is inadequately cooked or requires additional reheating*

At the end of the booklet you will find illustrations of the oven, and more importantly the control panel, so that you can find the buttons more easily. The illustrations in the step-by-step procedures use two different symbols.



Important



Note

PRECAUTIONS TO AVOID POSSIBLE EXPOSURE TO EXCESSIVE MICROWAVE ENERGY

Failure to observe the following safety precautions may result in harmful exposure to microwave energy.

- Under no circumstances should any attempt be made to operate the oven with the door open or to tamper with the safety interlocks (door latches) or to insert anything into the safety interlock holes.
- Do not place any object between the oven door and front face or allow food or cleaner residues to accumulate on sealing surfaces. Ensure that the door and door sealing surfaces are kept clean by wiping after use first with a damp cloth and then with a soft dry cloth.
- Do not operate the oven if it is damaged until it has been repaired by a qualified microwave service technician trained by the manufacturer. It is particularly important that the oven door closes properly and that there is no damage to the:
 - Door (bent)
 - Door hinges (broken or loose)
 - door seals and sealing surfaces
- The oven should not be adjusted or repaired by anyone other than a properly qualified microwave service technician trained by the manufacturer.

Safety Precautions

IMPORTANT SAFETY INSTRUCTIONS.

READ CAREFULLY AND KEEP FOR FUTURE REFERENCE.

Before cooking food or liquids in your microwave oven, please check that the following safety precautions are taken.

- Only use utensils that are suitable for use in microwave ovens;
DO NOT use any metallic containers, Dinnerware with gold or silver trimmings, Skewers, forks, etc.
Remove wire twist ties from paper or plastic bags.
Reason: Electric arcing or sparking may occur and may damage the oven.
- When heating food in plastic or paper containers, keep an eye on the oven due to the possibility of ignition;
Do not use your microwave oven to dry papers or clothes.
- Small amounts of food require shorter cooking or heating time.
If normal times are allowed they may overheat and burn.
- If smoke is observed, switch off or unplug the appliance and keep the door closed in order to stifle any flames;
- Microwave heating of beverages can result in delayed eruptive boiling, therefore care must be taken when handling the container; To prevent this situation
ALWAYS allow a standing time of at least 20 seconds after the oven has been switched off so that the temperature can equalize.
Stir during heating, if necessary, and **ALWAYS** stir after heating.
In the event of scalding, follow these FIRST AID instructions:
 - * Immerse the scalded area in cold water for at least 10 minutes.
 - * Cover with a clean, dry dressing.
 - * Do not apply any creams, oils or lotions.
- NEVER** fill the container to the top and choose a container that is wider at the top than at the bottom to prevent the liquid from boiling over. Bottles with narrow necks may also explode if overheated.
NEVER heat a baby's bottle with the teat on, as the bottle may explode if overheated.
- The contents of feeding bottles and baby food jars shall be stirred or shaken and the temperature checked before consumption, in order to avoid burns;
- Eggs in their shell and whole hard-boiled eggs should not be heated in microwave ovens since they may explode, even after microwave heating has ended;
Also do not heat airtight or vacuum-sealed bottles, jars, containers, nuts in shells, tomatoes etc.
- The oven should be cleaned regularly and any food deposits removed;
- Failure to maintain the oven in a clean condition could lead to deterioration of the surface that could adversely affect the life of the appliance and possibly result in a hazardous situation;
- DO NOT** cover the ventilation slots with cloths or paper. They may catch fire as hot air is evacuated from the oven.
The oven may overheat and automatically switch itself off. It will remain inoperable until it has cooled sufficiently.
- ALWAYS** use oven gloves when removing a dish from the oven to avoid unintentional burn.
- DO NOT** touch heating elements or interior oven walls until the oven be cooled down.
- Do not immerse the power cable or plug in water and keep the power cable away from heated surfaces.
Do not operate this appliance if it has a damaged power cable or plug.

- Stand at arms length from the oven when opening the door.

Reason: The hot air or steam released may cause scalding.

- You may notice a Clicking sound during operation (especially when the oven is defrosting).

Reason: This sound is normal when the electrical power output is changing.

- DO NOT** operate the microwave oven when it is empty. The power will be cut off automatically for safety. You can operate normally after letting it stand for over 30 minutes.
It is best to leave a glass of water inside the oven at all times. The water will absorb the microwaves energy if the oven accidentally started.
- The microwave oven shall not be placed in a cabinet

IMPORTANT

- Young children should **NEVER** be allowed to use or play with the microwave oven. Nor should they be left unattended near the microwave oven when it is in use. Items of interest to children should not be stored or hidden just above the oven.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- Children should be supervised to ensure that they do not play with the appliance.
- During use the appliance becomes hot. Care should be taken to avoid touching heating elements inside the oven.
- DO NOT** use harsh abrasive cleaners or sharp metal scrapers to clean the oven door glass since they can scratch the surface, which may result in shattering of the glass. (If provided)

WARNING:

If the door or door seals are damaged, the oven must not be operated until it has been repaired by a competent person.

WARNING:

It is hazardous for anyone other than a competent person to carry out any service or repair operation which involves the removal of a cover which gives protection against exposure to microwave energy.

WARNING:

Liquids and other foods must not be heated in sealed containers since they are liable to explode.

WARNING:

Only allow children to use the oven without supervision when adequate instructions have been given so that the child is able to use the oven in a safe way and understands the hazards of improper use.

WARNING:

When the appliance is operated in the combination mode, children should only use the oven under adult supervision due to the temperatures generated.



WARNING:

Accessible parts may become hot during use. Young children should be kept away.

- For safety reasons do not clean the appliance with a steam jet or high pressure cleaner.

Installing Your Microwave Oven

Place the oven on a flat level surface 85cm above the floor. The surface should be strong enough to safely bear the weight of the oven.



1. When you install your oven, make sure there is adequate ventilation for your oven by leaving at least 10 cm (4 inches) of space behind and, on the sides of the oven and 20 cm (8 inches) of space above.
2. Remove all packing materials inside the oven. Install the roller ring and turntable. Check that the turntable rotates freely.
3. This microwave oven has to be positioned so that plug is accessible.

⚠ If the supply cord is damaged, it must be replaced by a special cord or assembly available from the manufacturer or its service agent.

For your personal safety, plug the cable into a 3-pin, 230 Volt, 50Hz, AC earthed socket. If the power cable of this appliance is damaged, it must be replaced by a special cable.

⚠ Do not install the microwave oven in hot or damp surroundings like next to a traditional oven or radiator. The power supply specifications of the oven must be respected and any extension cable used must be of the same standard as the power cable supplied with the oven. Wipe the interior and the door seal with a damp cloth before using your microwave oven for the first time.


Setting the Time

Your microwave oven has an inbuilt clock. The time can be displayed in either the 12-hour or 24-hour notation. You must set the clock:

- When you first install your microwave oven
- After a power failure




Do not forget to reset the clock when you switch to and from summer or winter time.




1. To display the time in the... 12-hour notation 24-hour notation


Then press the Clock(⌚) button...
Once
Twice




2. Turn the **dial knob** to set the hour.



3. Press the **Clock**(⌚) button.



4. Turn the **dial knob** to set the minute.



5. When the right time is displayed, press the **Clock**(⌚) button to start the clock.


Result: The time is displayed whenever you are not using the microwave oven.



Checking that Your Oven is Operating Correctly

The following simple procedure enables you to check that your oven is working correctly at all times. If you are in doubt, refer to the section entitled "What to Do if You are in Doubt or Have a Problem" on the page.

- ☒ The oven must be plugged into an appropriate wall socket. The turntable must be in position in the oven. If a power level other than the maximum (100% - 900 W) is used, the water takes longer to boil.

Open the oven door by pulling the handle on the right side of the door. Place a glass of water on the turntable. Close the door.



Press the **Start**() button and set the time to 4 or 5 minutes, by pressing the **Start**() button the appropriate number of times.

Result: The oven heats the water for 4 or 5 minutes. The water should then be boiling.


How a Microwave Oven Works

Microwaves are high-frequency electromagnetic waves; the energy released enables food to be cooked or reheated without changing either the form or the colour.

You can use your microwave oven to:

- Defrost
- Reheat
- Cook

Cooking Principle



1. The microwaves generated by the magnetron reflected at cavity and are distributed uniformly as the food rotates on the turntable. The food is thus cooked evenly.
2. The microwaves are absorbed by the food up to a depth of about 1 inch (2.5 cm). Cooking then continues as the heat is dissipated within the food.
3. Cooking times vary according to the container used and the properties of the food:
 - Quantity and density
 - Water content
 - Initial temperature (refrigerated or not)




As the centre of the food is cooked by heat dissipation, cooking continues even when you have taken the food out of the oven. Standing times specified in recipes and in this booklet must therefore be respected to ensure:

- Even cooking of the food right to the centre
- The same temperature throughout the food

What to Do if You are in Doubt or You have a Problem

Becoming familiar with a new appliance always takes a little time. If you have any of the problems listed below, try the solutions given. They may save you the time and inconvenience of an unnecessary service call.

- ◆ The following are normal occurrences.
 - Condensation inside the oven
 - Air flow around the door and outer casing
 - Light reflection around the door and outer casing
 - Steam escaping from around the door or vents
- ◆ The food is not cooked at all
 - Have you set the timer correctly and pressed the **Start**() button?
 - Is the door closed?
 - Have you overloaded the electric circuit and caused a fuse to blow or a breaker to be triggered.
- ◆ The food is either overcooked or undercooked
 - Was the appropriate cooking length set for the type of food?
 - Was an appropriate power level chosen?
- ◆ Sparking and cracking occur inside the oven (arcing)
 - Have you used a dish with metal trimmings?
 - Have you left a fork or other metal utensil inside the oven?
 - Is aluminium foil too close to the inside walls?
- ◆ The oven causes interference with radios or televisions
 - Slight interference may be observed on televisions or radios when the oven is operating. This is normal.
 - * Solution: Install the oven away from televisions, radios and aerials.
 - If interference is detected by the oven's microprocessor, the display may be reset.
 - * Solution: Disconnect the power plug and reconnect it. Reset the time.
- ◆ "E - 24" message indicates
 - The "E - 24" message is automatically activated prior to the microwave oven overheating. Should the "E - 24" message be activated, then depress the "Stop/Cancel" key to utilize the initialization mode.

If the above guidelines do not enable you to solve the problem, then contact your local Samsung customer service centre.


Please have the following information read;

- The model and serial numbers, normally printed on the rear of the oven
- Your warranty details
- A clear description of the problem


Then contact your local dealer or SAMSUNG aftersales service.



Cooking/Reheating


The following procedure explains how to cook or reheat food.


-  ALWAYS check your cooking settings before leaving the oven unattended.


Open the door. Place the food in the centre of the turntable. Close the door. Never switch the microwave oven on when it is empty.




1. Press the **Microwave**() button.
Result: The following indications are displayed:
 (microwave mode)







2. Select the appropriate power level by pressing the **Microwave**() button again until the corresponding output power is displayed. Refer to the power level table below for further details.





3. Set the cooking time by turning the **dial knob**.
Result: The cooking time is displayed.



4. Press the **Start**() button.
Result: The oven light comes on and the turntable starts rotating. Cooking starts and when it has finished:
◆ The oven will beep and flash "0" four times.
The oven will then beep one time per minute.

-  If you would like to know the current Power Level of the oven cavity, press **Microwave**() button once. If you would like to change the power level during cooking, press the **Microwave**() button twice or more times to select the desired power level.

Quick Start:

-  If you wish to heat a dish for a short period of time at maximum power (900W), you can also simply press the **Start**() button once for each 30 seconds of cooking time. The oven starts immediately.

Power Levels and Time Variations

The power level function enables you to adapt the amount of energy dissipated and thus the time required to cook or reheat your food, according to its type and quantity. You can choose between six power levels.

| Power Level | Percentage | Output |
|-------------|------------|--------|
| HIGH | 100 % | 900 W |
| MEDIUM HIGH | 67 % | 600 W |
| MEDIUM | 50 % | 450 W |
| MEDIUM LOW | 33 % | 300 W |
| DEFROST | 20 % | 180 W |
| LOW | 11 % | 100 W |

The cooking times given in recipes and in this booklet correspond to the specific power level indicated.

| If you select a... | Then the cooking time must be... |
|--------------------|----------------------------------|
| Higher power level | Decreased |
| Lower power level | Increased |

Stopping the Cooking

You can stop cooking at any time so that you can:


- Check the food
- Turn the food over or stir it
- Leave it to stand

| To stop the cooking... | Then... |
|------------------------|---|
| Temporarily | Open the door. Result: Cooking stops. To resume cooking, close the door again and press the Start (◊) button. |
| Completely | Press the Stop button. Result: Cooking stops. If you wish to cancel the cooking settings, press the Stop button again. |

Adjusting the Cooking Time

You can increase the cooking time by pressing +30s button once for each 30seconds to be added.

- Check how cooking is progressing at any time simply by opening the door
- Increase the remaining cooking time



To increase the cooking time of your food, press the **Start**(◊) button once for each 30 seconds that you wish to add.


- Example: To add three minutes, press the **Start**(◊) button six times.

Using the Auto Cook Feature


The five Auto Cook (☺) features include/provide pre-programmed cooking times. You do not need to set either the cooking times or the power level. You can adjust the size of the serving by turning the dial knob.

 Use only recipients that are microwave-safe.


Open the door. Place the food in the centre of the turntable. Close the door.




1. Press the **Auto Cook** (☺) button.



2. Select the type of food that you are cooking by pressing the **Auto Cook** (☺) button. Refer to the table on the following page for a description of the various pre-programmed settings.








3. Select the size of the serving by turning the **dial knob**.



4. Press the **Start** (◊) button.
Result: The food is cooked according to the pre-programmed setting selected.
◆ When cooking has finished, the oven will beep and flash "0" four times. The oven will then beep one time per minute.


The following table presents the various Auto Cook Programmes, quantities, standing times and appropriate recommendations. Programmes no 1 and 2 are running with microwave energy only. Programmes no 3 and 4 are running with a combination of microwaves and grill.

Programme no 5 is running with a combination of microwaves and convection.

| Code | Food | Serving Size | Standing Time | Recommendations |
|------|---|--|---------------|---|
| 1. | Fresh Vegetables  | 200-250 g 300-350 g 400-450 g 500-550 g 600-650 g 700-750 g | 3 min. | Weigh the vegetables after washing, cleaning and cutting into similar size. Put them into a glass bowl with lid. Add 30 ml (2 tablespoons) water when cooking for 200-250 g, add 45 ml (3 tablespoons) for 300-450 g and add 60-75 ml (4-5 tablespoons) for 500-750 g. Stir after cooking. When cooking higher quantities stir once during cooking. |
| 2. | Peeled Potatoes  | 300-350 g 400-450 g 500-550 g 600-650 g 700-750 g | 3 min. | Weigh the potatoes after peeling, washing and cutting into a similar size. Put them into a glass bowl with lid. Add 45 ml (3 tablespoons) water when cooking 300-450g, add 60ml (4 tablespoons) for cooking 500-750 g. |
| 3. | Roast Fish  | 200-300 g (1 pc) 400-500 g (1-2 pcs) 600-700 g (2 pcs) | 3 min. | Brush skin of whole fish with oil and add herbs and spices. Put fish side by side, head to tail on the high metal rack. Turn over, as soon as the beep sounds. |
| 4. | Chicken Pieces  | 200-300 g (1pc) 400-500 g (2pcs) 600-700 g (3pcs) | 3min. | Brush the chicken pieces with oil and spice them with pepper, salt and paprika. Put them in a circle on the high rack with the skin-side down. Turn over, as soon as the beep sounds. |
| 5. | Roast Beef / Roast Lamb  | 900-1000 g 1200-1300 g 1400-1500 g | 10-15min. | Brush the beef/lamb with oil and spices (pepper only, salt should be added after roasting). Put it on the low rack with the fat-side down. Turn over, when the oven beeps. After roasting and during standing time it should be wrapped in aluminium foil. |


Using the Auto Reheat Feature

EN


The four Auto Reheat() features provide four pre-programmed cooking times. You do not need to set either the cooking times or the power level. You can adjust the size of the serving by turning the dial knob.


 Use only recipients that are microwave-safe.


Open the door. Place the food in the centre of the turntable. Close the door.




1. Press the **Auto Reheat** () button.




2. Select the type of food that you are cooking by pressing the **Auto Reheat** () button. Refer to the table on the following page for a description of the various pre-programmed settings.







3. Select the size of the serving by turning the **dial knob**.




4. Press the **Start**() button.
Result: The food is cooked according to the pre-programmed setting selected.
◆ When cooking has finished, the oven will beep and flash "0" four times. The oven will then beep one time per minute.

The following table presents the various Auto Reheat & Cook Programmes, quantities, standing times and appropriate recommendations. Programmes no 1 and 2 are running with microwave energy only.

Programmes no 3 and 4 are running with a combination of microwaves and convection.


| Code | Food | Serving Size | Standing Time | Recommendations |
|------|---|--|---------------|---|
| 1. | Ready Meal (chilled)  | 300 - 350 g 400 - 450 g 500 - 550 g | 3min. | Put on a ceramic plate and cover with microwave cling film. This programme is suitable for meals consisting of 3 components (e.g. meat with sauce, vegetables and a side dish like potatoes, rice or pasta). |
| 2. | Soup/Sauce (chilled)  | 200 - 250 ml 300 - 350 ml 400 - 450 ml 500 - 550 ml 600 - 650 ml 700 - 750 ml | 2-3min. | Pour into a deep ceramic soup plate or bowl and cover with plastic lid during heating. Stir the soup, as soon as the oven beeps (oven keeps operating and is stopped, when you open the door). Stir carefully before and after standing time. |
| 3. | Frozen Pizza  | 300 - 400 g 450 - 550 g 600 - 700 g | - | We recommend to pre-heat the oven to 220°C for 5 minutes using the convection function. Place one frozen pizza (-18°C) on the high rack, place two frozen pizzas on the low and high rack. |
| 4. | Frozen Bread Rolls  | 100-150 g (2pcs) 200-250 g (4pcs) 300-350 g (6pcs) 400-450 g (8pcs) | 3-5min. | We recommend to pre-heat the oven to 180°C for 5 minutes using the convection function. Put 2 to 6 frozen bread rolls (-18°C) in a circle on the low rack. Put 8 frozen bread rolls equally on the low and high rack. This program is suitable for small frozen bakery products as bread rolls, ciabatta rolls and small baguettes. |

Using the Power Defrost Feature


The Power Defrost () feature enables you to defrost meat, poultry, fish, bread, cake and fruit. The defrost time and power level are set automatically. You simply select the programme and the weight.


 Use only containers that are microwave-safe.


Open the door. Place the frozen food on a ceramic in the centre of the turntable. Close the door.




1. Press the **Power Defrost** () button.



2. Select the type of food that you are cooking by pressing the **Power Defrost** () button. Refer to the table on the following page for a description of the various pre-programmed settings.




3. Select the food weight by turning the **dial knob**.




4. Press **Start** () button.


Result:

- ◆ Defrosting begins.
- ◆ The oven beeps through defrosting to remind you to turn the food over.








5. Press the **Start** () again to finish defrosting.

Result: When cooking has finished, the oven will beep and flash "0" four times. The oven will then beep one time per minute.

 You can also defrost food manually. To do so, select the microwave function with a power level of 180 W. Refer to the section entitled "Defrosting" on page 31 for further details.

The following table presents the various Power Defrost programmes, quantities, standing times and appropriate recommendations. Remove all kind of package material before defrosting.


Place meat, poultry and fish on a flat glass plate or on a ceramic plate, arrange bread and cake on kitchen paper.

| Code | Food | Serving Size | Standing Time | Recommendations |
|------|--|--------------|---------------|---|
| 1. | Meat  | 200-2000g | 20-90 min. | Shield the edges with aluminium foil. Turn the meat over, when the oven beeps. This programme is suitable for beef, lamb, pork, steaks, chops, minced meat. |
| 2. | Poultry  | 200-2000g | 20-90 min. | Shield the leg and wing tips with aluminium foil. Turn the poultry over, when the oven beeps. This programme is suitable for whole chicken as well as for chicken portions. |
| 3. | Fish  | 200-2000g | 20-60 min. | Shield the tail of a whole fish with aluminium foil. Turn the fish over, when the oven beeps. This programme is suitable for whole fishes as well as for fish fillets. |
| 4. | Bread / Cake  | 125-1000g | 10-60 min. | Put bread horizontally on a piece of kitchen paper and turn over, as soon as the oven beeps. Place cake on a ceramic plate and if possible, turn over, as soon as the oven beeps. (Oven keeps operating and is stopped, when you open the door.) This programme is suitable for all kinds of bread, sliced or whole, as well as for bread rolls and baguettes. Arrange bread rolls in a circle. This programme is suitable for all kinds of yeast cake, biscuit, cheese cake and puff pastry. It is not suitable for short/crust pastry, fruit and cream cakes as well as for cake with chocolate topping. |
| 5. | Fruit  | 100-600g | 5-20 min. | Spread fruits evenly into a flat glass dish. This programme is suitable for all kind of fruits. |

Using the Snack Cook Feature

The Junior/Snacks feature provides six auto programmed for hamburger, ravioli and popcorn, frozen chicken wings, frozen snacks, nachos. You do not need to set either the cooking time or power level. You can adjust the number of servings by turning the Jog Dial.


First, place the food in the centre of the turntable and close the door.




1. Press the **Snack** button.




2. Select the type of food that you are cooking by pressing the **Snack** button. Refer to the table on the following page for a description of the various pre-programmed settings.



3. Select the size of the serving by turning the **dial knob**.









4. Press **Start** () button.
Result: The food is cooked according to the pre-programmed setting selected.
◆ When cooking has finished, the oven will beep and flash "0" four times. The oven will then beep one time per minute.

The following table presents Auto Programmes for types of food and snacks which are favoured by children and for trendy finger food. It contains its quantities, standing times and appropriate recommendations.

Programmes no 1, 2, 5 and 6 are running with microwave energy only.

Programme no 3 is running with a combination of microwaves and grill.


Programme no 4 is running with a combination of grill and convection.

| Code | Food | Serving Size | Standing Time | Recommendations |
|------|---|--|---------------|--|
| 1 | Hamburger (chilled)  | 150 g (1pc) 300 g (2pcs) | 1-2 min | Put hamburger (bread roll with slice of beef) or cheeseburger on kitchen paper. Put one hamburger in the centre of turntable, put two hamburgers opposite to each other on turntable. After reheating garnish with lettuce, tomato slice, dressing and spices. |
| 2 | Mini Ravioli (chilled)  | 200-250 g 300-350 g | 3 min | Put chilled ready mini ravioli in a microwave proof plastic dish in the centre of turntable. Pierce film of ready product or cover plastic dish with microwave cling film. Stir carefully before and after standing time. This programme is suitable for ravioli, as well as for noodles in sauce. |
| 3 | Frozen Chicken Wings  | 250 g 500 g | 2 min | Put the frozen ready chicken wings or small drumsticks (pre-cooked and spiced) on the high metal rack with the skin-side down. Put them in a circle and leave the centre clear. Turn over, as soon as the oven beeps. |
| 4 | Frozen Pizza Snacks  | 200 g (5-6pcs) 300 g (8-9pcs) | - | Put the frozen pizza snacks or mini quiches evenly on the high metal rack. |
| 5 | Popcorn  | 100 g | - | Use special popcorn product for preparing in microwave oven. Follow the instructions of food manufacturer and put the bag in the centre of turntable. During this programme corn will pop and the bag will increase in volume. Be careful when taking out and opening the hot bag. |
| 6 | Nachos  | 125 g | - | Put nachos (tortilla chips) on a flat ceramic plate. Put 50g grated cheddar cheese and spices on top. Place on turntable. |

Using the Auto Steam / Crusty Cook Feature (CE117AE)

The Auto Steam & Crusty Cook (🍲) feature provide pre-programmed cooking time. You do not need to set either the cooking time or power level. You can adjust the size of the serving by turning the dial knob.



First, place the food in the centre of the turntable and close the door.





1. Press the **Auto Steam & Crusty COOK** (🍲) button.

Using the Mode & Container

1. Auto steam cook : S-1 to S-5




2. Auto crusty cook : C-1 to C-5




2. Select the type of food that you are cooking by pressing the **Auto Steam & Crusty COOK** (🍲) button. Refer to the table on the following page for a description of the various pre-programmed settings.

- Auto steam cook : S-1 to S-5
- Auto crusty cook : C-1 to C-5



3. Select the size of the serving by turning the **dial knob**.



4. Press **Start** (◇) button.

Result: The food is cooked according to the pre-programmed setting selected.

- ◆ When cooking has finished, the oven will beep and flash "0" four times. The oven will then beep one time per minute.

Caution!!

- Never use this Pro Steamer with a different product or model. It may cause a fire or fatal damage to the product.
- Do not use the Pro Steamer without water or food inside. When you use this Pro Steamer, pour at least 500ml of water before use. If the amount of water is less than 500ml, it may cause incomplete cooking, or may cause a fire or fatal damage to the product.
- Caution must be taken when removing the container from inside the Pro Steamer after cooking, as it will be very hot.
- The Pro Steamer should be used only in the mode of "**Auto steam / Crusty cook** (🍲) : **S-1 to S-5**".
- The crusty plate should be used only in the mode of "**Auto steam / Crusty cook** (🍲) : **C-1 to C-5**".
- Make sure you install the cover onto the Pro Steamer so that it fits into the Steam plate / Crusty plate. The eggs or the chestnuts would be explode without setting the steam cover and steam plate as instructed on the Instruction book.



How to clean the Steam plate / Crusty Plate

Clean the Steam plate / crusty plate with warm water and detergent and rinse off with clean water.



Do not use a scrubbing brush or a hard sponge otherwise the top layer will be damaged.



Please Note

The Steam plate / crusty plate is not dishwasher-safe.

Using the Auto Steam / Crusty Cook Feature (CE117AE) (continued)

EN



The following table presents the various Steam & Crusty Cook Programmes, quantities, standing times and appropriate recommendations.




These programmes can only be used together with the combined steam & crusty plate accessory. Programmes number S-1 to 5 will be used with the Pro Steamer, while programme number C-1 to 5 will be used with the crusty plate (plate of Pro Steamer) only.

Regarding the Steam programmes (S 1-5) the cooking time depends on size, thickness and type of food. These programmes are suitable for medium sized food or pieces of food. When steaming thick slices or big sized pieces of food, keep covered and let stand for 2-5 minutes after cooking.

When steaming very thin sliced food, or soft cooking vegetables, we recommend, to finish the automatic cooking process 2-3 minutes before end of time, by pressing stop button.






These programmes are running with microwave energy only.

| Code | Food | Serving Size | Accessory Preparation | Recommendations |
|------|---|--------------|------------------------------------|---|
| S-1 | Sliced vegetables  | 200-500 g | Pro Steamer plus 500 ml cold water | Rinse and clean the vegetables, cut into slices or similar sized pieces. Pour ½ ℓ water into steam plate of Pro Steamer. Insert steam tray into steam plate, add vegetables and cover with stainless steel lid. Put Pro Steamer on turntable. This programme is suitable for medium sized pieces of vegetables such as broccoli florets, cauliflower florets, and sliced carrots. |
| S-2 | Whole vegetables  | 200-800g | Pro Steamer plus 500 ml cold water | Rinse and clean the vegetables. Pour ½ ℓ water into the steam plate of Pro Steamer. Insert steam tray into steam plate, add vegetables and cover with stainless steel lid. Put Pro Steamer on turntable. This programme is suitable for whole vegetables, such as corn on the cob, artichokes, whole cauliflower, small potatoes and cabbage cut into quarters. |

| | | | | |
|-----|---|-----------|------------------------------------|---|
| S-3 | Fish Fillets  | 100-600g | Pro Steamer plus 500 ml cold water | Rinse and clean the fish fillets. Pour ½ ℓ water into the steam plate of Pro Steamer. Insert steam tray into steam plate, add fish fillets side by side. You can add salt, herbs and 1-2 tbsp, lemon juice. Cover with stainless steel lid. Put Pro Steamer on turntable. This programme is suitable for fish fillets like rose fish, pollack and cod fish. |
| S-4 | Boiled Eggs  | 150-500 g | Pro Steamer plus 500 ml cold water | Pour ½ ℓ water into the steam plate of Pro Steamer. Insert steam tray into steam plate. Pierce 3-8 fresh eggs, each about 60g (medium size) and set into the small cavities of the tray. Cover with stainless steel lid and set Pro Steamer on turntable. After steaming keep standing for 2-5 minutes. |
| S-5 | Chicken breast  | 100-600 g | Pro Steamer plus 500 ml cold water | Rinse and clean the chicken breast fillets. Pour ½ ℓ water into the steam plate of Pro Steamer. You can add herbs and spices to the water. Insert steam tray into steam plate, add chicken breasts in a circle and cover with stainless steel lid. Put Pro Steamer on turntable. |

Using the Auto Steam / Crusty Cook Feature (CE117AE) (continued)

Before using the Crusty Cook programmes (C 1-C5) preheat the Crusty plate with 600W+Grill mode or 600W+250°C for 3-5 minutes on the turntable, please follow instruction. These Programmes are running with a combination of microwaves and grill, or microwave and convection. Use oven gloves while taking out!

| Code | Food | Serving Size | Accessory Preparation | Recommendations |
|------|---|----------------------------------|--|--|
| C-1 | Frozen Pizza (-18°C)  | 200g 300g 400g | Crusty plate/ 600W+Grill for 5 min. | Preheat the Crusty plate using 600W + Grill for 5 min. on turntable. Put frozen pizza on Crusty plate. Put Crusty plate on high rack. |
| C-2 | Frozen Mini Spring Rolls (-18°C)  | 125 g (5pcs) 250 g (10pcs) | Crusty plate/ preheating 600W+250°C for 5 min. | Preheat the Crusty plate on using 600W + 250°C for 5 min. on turntable. Put spring rolls on Crusty plate. Put Crusty plate on low rack. |
| C-3 | Frozen Baguettes (-18°C)  | 150 g (1pc) 250 g (2pcs) | Crusty plate/ preheating 600W+250°C for 5 min. | Preheat the Crusty plate using 600W + 250°C for 5 min. on turntable. Put one baguette off-centre on Crusty plate, put 2 baguettes side by side on the Crusty plate. Put Crusty plate on low rack. This programme is suitable for baguettes with topping, (e.g. vegetables, ham and cheese). |
| C-4 | Frozen Chicken Nuggets (-18°C)  | 125 g 250 g | Crusty plate/ preheating 600W+Grill for 3 min. | Preheat the Crusty plate using 600W + Grill for 3 min. on turntable. Brush Crusty plate with one tbsp. oil. Distribute chicken nuggets evenly on Crusty plate. Put Crusty plate on high rack. Turn over when the oven beeps. Push start button to continue cooking. |
| C-5 | Frozen Bruschetta (-18°C)  | 150 g (4-5pcs) 300 g (8-9pcs) | Crusty plate/ preheating 600W+250°C for 5 min. | Preheat the Crusty plate using 600W + 250°C for 5 min. on turntable. Put bruschetta in a circle on Crusty plate. Put Crusty plate on low rack. |



Using the Manual Steam Cook Function (CE117AE)

Using Pro Steamer, not only can you Auto Steam Cook, but you can also Manual Steam Cook referring to the Manual Steam Cooking table on the right.


The following procedure explains how to manual steam cook. ALWAYS check your cooking settings before leaving the oven unattended.


First, place the Pro Steamer(with food) in the centre of the turntable. Then, close the door.

Using the Container.




1. Press the **Microwave** () button.

Result : The 900W (maximum cooking power) indications are displayed:
Select the appropriate power level by pressing the  button again until the corresponding wattage is displayed.
Set the power level (900W) given in Manual Steam Cooking Guide on the next page.



2. Select the cooking time by turning the **dial knob** as required.
Set the cooking time referring to the cooking time in the Manual Steam Cooking Guide on the next page.



3. Press **Start** () button.

Result : The oven light comes on and the turntable starts rotating.
1) Cooking starts and when it has finished the oven beeps four times.
2) The end reminder signal will beep 3 times (once every minute).
3) The current time is displayed again.

Using the Manual Steam Cook Function (CE117AE) (continued)

Caution!!

- Never use this Pro Steamer with a different product or model. It may cause a fire or fatal damage to the product.
- Do not use the Pro Steamer without water or food inside. When you use this Pro Steamer, pour at least 500ml of water before use. If the amount of water is less than 500ml, it may cause incomplete cooking, or may cause a fire or fatal damage to the product.
- Caution must be taken when removing the container from inside the Pro Pro Steamer after cooking, as it will be very hot.
- Make sure you install the cover onto the Pro Steamer so that it fits into the Steam plate / Crusty plate. The eggs or the chestnuts would be explode without setting the steam cover and steam plate as instructed on the Instruction book.



How to clean the Steam plate / Crusty Plate

Clean the Steam plate / crusty plate with warm water and detergent and rinse off with clean water.



Do not use a scrubbing brush or a hard sponge otherwise the top layer will be damaged.



Please Note

The Steam plate / crusty plate is not dishwasher-safe.

Pour 500 ml cold water into the steam plate of Pro Steamer. Put the steam tray into the plate, add food on tray and cover with stainless steel lid. Put Pro Steamer on the turntable. The cooking time depends on size, thickness and type of food.

When steaming thin slices or small pieces we recommend to reduce the time. When steaming thick slices or big sized pieces of food you can add time.

Use the power levels and times in this table as a guide lines for steam cooking.


| Fresh Food | Portion | Cold Water (ml) | Power | Time (min.) | Instructions |
|-------------------|---------|-----------------|-------|-------------|---|
| Broccoli, florets | 400g | 500 | 900W | 12-18 | Rinse and clean broccoli. Cut into similar sized florets. Put florets evenly on steam tray. |
| Carrots | 400g | 500 | 900W | 15-20 | Rinse and clean carrots and cut into even slices. Distribute slices on steam tray. |

| Fresh Food | Portion | Cold Water (ml) | Power | Time (min.) | Instructions |
|------------------------------------|------------------|-----------------|-------|-------------|--|
| Cauliflower, whole | 600g | 500 | 900W | 20-25 | Clean whole cauliflower and set on steam tray. |
| Corn on the cob | 400g (2pcs) | 500 | 900W | 23-28 | Rinse and clean corn on the cobs. Put corn on the cobs side by side on steam tray. |
| Courgettes | 400g | 500 | 900W | 10-15 | Rinse courgettes and cut them into similar slices. Distribute evenly on steam tray. |
| Frozen Mixed Vegetables | 400g | 500 | 900W | 18-23 | Distribute frozen mixed vegetables (-18°C) e.g. broccoli, cauliflower, sliced carrots evenly on steam tray. |
| Potatoes (small) | 500g | 500 | 900W | 25-30 | Rinse and clean potatoes and pierce skin with a fork. Set whole potatoes evenly on steam tray. |
| Apples | 800g (4 apples) | 500 | 900W | 15-20 | Rinse and core apples. Put apples upright side by side on steam tray. |
| Eggs | 4-6 eggs | 500 | 900W | 15-20 | Pierce 4-6 fresh eggs (size M) and set them in the small cavities of steam tray. After steaming keep standing covered for 2-5 minutes. |
| Blue Prawns | 250g (5-6pcs) | 500 | 900W | 10-15 | Sprinkle blue prawns with 1-2 tablespoons lemon juice. Put them evenly on steam tray. |
| Fish Fillets (cod fish, rose-fish) | 500g (2-3pcs) | 500 | 900W | 12-17 | Sprinkle fish fillets with 1-2 tablespoons lemon juice and add herbs and spices (e.g. rosemary). Put fillets evenly on steam tray. |
| Chicken breast fillets | 400g (2 fillets) | 500 | 900W | 20-25 | Rinse and clean the chicken breast fillets. Put chicken breast fillets side by side on steam tray. |

Using the Manual Crusty Cook Function (CE117AE / CE117AT)

Normally when cooking in microwave oven, using grill or microwave mode in grill/convection ovens, foods like pastries and pizza become soggy from bottom side. Using the Samsung Crusty plate helps to gain a crispy cookde result of your food.

The crusty plate can also be used for bacon, eggs, sausages, etc.



1. Preheat the crusty plate, as described above.

☞ Before using the crusty plate, preheat it by selecting the combination mode for 3 to 5 minutes:

- Combination of convection (250°C) and microwaves. (600 W power level)
- Combination of grill and microwaves (600 W power level)

☞ Use oven gloves at all times as the crusty plate will become very hot.

2. Brush the plate with oil if you are cooking food, such as bacon and eggs, in order to brown the food nicely.

✳ Please note that the crusty plate has a teflon layer which is not scratch-resistant. Do not use any sharp objects like a knife to cut on the crusty plate.


✳ Use plastic accessories to avoid scratches on the surface of the crusty plate or remove the food from the plate before cutting.

3. Place the food on the crusty plate.


☞ Do not place any recipients on the crusty plate that are not heat-resistant (plastic bowls for example).

4. Place the crusty plate on the metal rack(or turntable) in the microwave.


☞ Never place the crusty plate in the oven without the turntable.




5. Press the **Combi** (or) button.



6. Select the appropriate power level by pressing the **Combi** (or) button.



7. Set the cooking time by turning the **Jog Dial** until the appropriate cooking time is displayed.



8. Press the **Start** () button.

Result: Cooking starts.

◆ When cooking has finished, the oven will beep and flash "0" four times. The oven will then beep one time per minute.



How to clean the Crusty Plate

Clean the crusty plate with warm water and detergent and rinse off with clean water.



Do not use a scrubbing brush or a hard sponge otherwise the top layer will be damaged.



Please Note

The crusty plate is not dishwasher-safe.

Using the Manual Crusty Cook Function (CE117AE / CE117AT) (continued)

EN

We recommend to preheat crusty plate directly on the turntable. Preheat crusty plate with the 600W + Grill-function or 600W + Convection(250°C)-function for 5 Min. and follow the times and instructions in the table.

| Food | QUANTITY | PREHEAT TIME (MIN) | COOKING MODE | COOKING TIME (MIN) | Recommendations |
|---------------------------|------------------|--------------------|--------------|--------------------|---|
| Bacon | 4-6 Slices (80g) | 3 | 600W+Grill | 3-4 | Preheat crusty plate. Put slices side by side on crusty plate. Put crusty plate on high rack. |
| Grilled Tomatoes | 200 g | 3 | 300W +Grill | 3-4 | Preheat crusty plate. Cut tomatoes in halves. Put some cheese on top. Arrange in a circle on crusty plate and set on high rack. |
| Omelette | 300 g | 3-4 | 450W + Grill | 3 ½ -4 ½ | Beat 3 eggs, add 2 tbsp. milk, herbs and spices. Cut one tomato in cubes. Preheat crusty plate, put tomato pieces on plate, add beaten eggs and 50g grated cheese evenly. Set plate on high rack. |
| Grilled Vegetables | 250 g | 3-4 | 450W + Grill | 7-8 | Preheat crusty plate and brush with 1 tbsp. oil. Put fresh sliced vegetables on plate e.g. pieces of pepper, onions, courgette slices and mushrooms. Set crusty plate on high rack. |

| | | | | | |
|---|-------|-----|--|--|--|
| Frozen Mini Spring Rolls with topping | 250 g | 2-3 | 1 st stage: 300W + 250°C 2 nd stage: Grill only | 1 st stage: 5-6 2 nd stage: 4-5 | Preheat crusty plate. Distribute spring rolls evenly on plate. Put plate on low rack. |
| Frozen Pizza | 350 g | 4-5 | 600W+Grill | 6-8 | Preheat crusty plate. Put the frozen pizza on crusty plate. Put crusty plate on high rack. |
| Frozen Baguettes (frozen) | 250 g | 3-4 | 300W + 220°C | 10-12 | Preheat crusty plate. Put the two frozen baguettes with topping (e.g. vegetables, ham and cheese). Put crusty plate on low rack. |
| Chicken Nuggets (frozen) | 250 g | 4 | 600W+Grill | 6-7 | Preheat crusty plate. Brush plate with 1 tbsp. oil. Put chicken nuggets on crusty plate. Put crusty plate on the high rack. Turn over after 4-5 minutes. |


Multistage Cooking

Your microwave oven can be programmed to cook food in up to three stages (the Convection, Microwave+Convection and Fast Preheat mode can not be used in Multistage cooking). Example: You wish to Power defrost food and cook it without having to reset the oven after each stage. You can thus defrost and cook a 1.8 kg chicken in three stages:


- **Defrosting**
- **Microwave cooking for 30 minutes**
- **Grill for 15 minutes**





Defrosting must be the first stage. Combination and Grill can only be used once during the remaining two stages, However microwave can be used twice(at two different power levels).




1. Press the **Power Defrost** () button.




2. Select the type of food that you are cooking by pressing the **Power Defrost** () button.





3. Set the weight by turning the **dial knob** the appropriate number of times (1800 g in the example).




4. Press the **Microwave** () button.




5. Set the microwave power level by pressing the **Microwave** () button to select the appropriate Power Level (450W in the example).




6. Set the cooking time by turning the **dial knob**. (30 minutes in the example)



7. Press the **Grill** () button.



8. Set the cooking time by turning the **dial knob**. (15 minutes in the example).




9. Press **Start** () button.

Result: Cooking starts:

- ◆ When cooking has finished, the oven will beep and flash "0" four times. The oven will then beep one time per minute.


Fast Preheating the Oven


For convection cooking, it is recommended that you preheat the oven to the appropriate temperature before placing the food in the oven. When the oven reaches the requested temperature, it is maintained for approximately 10 minutes; it is then switched off automatically. Check that the heating element is in the correct position for type of cooking that you require.




1. Press the **Fast Preheat** () button.

Result: The following indications are displayed:
250°C (temperature)



2. Press the **Fast Preheat** () button one or more times to set the temperature.



3. Press the **Start** () button.

Result: The oven is preheated to the requested temperature.


- ◆ Upon arrival at the preset temperature, the oven beeps 6 times and the temperature is kept for 10 minutes.

- ◆ After 10 minutes, the beeps 4 times and the operation stops.



In case the inner temperature has reached the preset temperature, the beeps 6 times when temperature and the preset temperature is kept for 10 minutes.



If you would like to know the current temperature of oven cavity, press **Fast Preheat** () button.

Cooking by Convection

EN


The convection mode enables you to cook food in the same way as in a traditional oven. The microwave mode is not used. You can set the temperature, as required, in a range varying from 40°C to 250°C in eight preset levels. The maximum cooking time is 60 minutes.



If you wish to Fast Preheat the oven, see page 21.


- Always use oven gloves when touching the recipients in the oven, as they will be very hot.
- You can get better cooking and browning, if you use the low rack.


Check that the heating element is in the horizontal position and that the turntable is in position. Open the door and place the recipient on the low rack and set on turntable.





1. Press the **Convection** () button.

Result: The following indications are displayed:


 (convection mode)
250°C (temperature)



2. Press the **Convection** () button once or more times to set the temperature.
(Temperature : 250, 220, 200, 180, 160, 140, 100, 40°C)



3. Set the cooking time by turning the **dial knob**.




4. Press the **Start** () button.

Result: Cooking starts:

- ◆ When cooking has finished, the oven will beep and flash "0" four times. The oven will then beep one time per minute.




If you would like to know the current temperature of oven cavity, press **Fast Preheat** () button.


Grilling

The grill enables you to heat and brown food quickly, without using microwaves.


- Always use oven gloves when touching the recipients in the oven, as they will be very hot.
- You can get better cooking and grilling results, if you use the high rack.




1. Open the door and place the food on the rack.



2. Press the **Grill** () button.


Result: The following indications are displayed:
 (grill mode)

- You cannot set the temperature of the grill.



3. Set the grilling time by turning the **dial knob**.

- The maximum grilling time is 60 minutes.




4. Press the **Start** () button.

Result: Grilling starts:

- ◆ When cooking has finished, the oven will beep and flash "0" four times. The oven will then beep one time per minute.

Choosing the Accessories



Traditional convection cooking does require cookware. You should, however, use only cookware that you would use in your normal oven.

Microwave-safe containers are not usually suitable for convection cooking; don't use plastic containers, dishes, paper cups, towels, etc.

If you wish to select a combined cooking mode (microwave and grill or convection), use only recipients that are microwave-safe and oven-proof. Metallic cookware or utensils may damage your oven.



For further details on suitable cookware and utensils, refer to the Cookware Guide on page 26.

Combining Microwaves and the Grill

You can also combine microwave cooking with the grill, to cook quickly and brown at the same time.




ALWAYS use microwave-safe and oven-proof cookware. Glass or ceramic dishes are ideal as they allow the microwaves to penetrate the food evenly.


ALWAYS use oven gloves when touching the recipients in the oven, as they will be very hot.


You can improve cooking and grilling, if you use the high rack.


Open the door. Place the food on the rack best suited to the type of food to be cooked. Place the rack on the turntable. Close the door.




1. Press the **Microwave + Grill** () button.


Result: The following indications are displayed:
 (microwave & grill combi mode)
600W (output power)



2. Select the appropriate power level by pressing the **Microwave + Grill** () button until the corresponding output power is displayed (300-600W).
 - You cannot set the temperature of the grill.



3. Set the cooking time by turning the **dial knob**.
 - The maximum cooking time is 60 minutes.



4. Press the **Start** () button.

Result:

- ◆ Combination cooking starts.
- ◆ When cooking has finished, the oven will beep and flash "0" four times. The oven will then beep one time per minute.

Combining Microwaves and Convection

Combination cooking uses both microwave energy and convection heating. No preheating is required as the microwave energy is immediately available.

Many foods can be cooked in combination mode, particularly:


- Roast meats and poultry
- Pies and cakes
- Egg and cheese dishes

ALWAYS use microwave-safe and oven-proof cookware. Glass or ceramic dishes are ideal as they allow the microwaves to penetrate the food evenly.

ALWAYS use oven gloves when touching the recipients in the oven, as they will be very hot.


You can get better cooking and browning, if you use the low rack.


Open the door. Place the food on the turntable or on the low rack which should then be placed on the turntable. Close the door. The heating element must be in the horizontal position.





1. Press the **Microwave + Convection** () button.

Result: The following indications are displayed:


 (microwave & convection combi mode)
600W (output power : Switches to the following temperature mode in 2 seconds)
250°C (temperature)





2. Select the temperature by pressing the **Microwave + Convection** () button.
(Temperature : 250, 220, 200, 180, 160, 140, 100, 40°C)



3. Set the cooking time by turning the **dial knob**.
 - The maximum cooking time is 60 minutes.



4. Set the appropriate power level by pressing the **Microwave + Convection** () button until the corresponding output power is displayed (600, 450, 300, 180, 100W).




5. Press the **Start** () button.

Result:

- ◆ Combination cooking starts.
- ◆ The oven is heated to the required temperature and then microwave cooking continues until the cooking time is over.
- ◆ When cooking has finished, the oven will beep and flash "0" four times. The oven will then beep one time per minute.




If you would like to know the current temperature of the oven cavity, press the **Fast Preheat** () button.

Using the Deodorize Feature (CE117A / CE117AT)

Use this feature after cooking odorous food or when there is a lot of smoke in the oven interior.

First clean the oven interior.



Press the **Deodorize** () button after you have finished cleaning. you will hear four beeps.



The deodorization time has been specified as 5 minutes.




You can also adjust **Deodorize** time by pressing the +30s button.





The maximum deodorization time is 60 minutes.

Safety-locking Your Microwave Oven


Your microwave oven is fitted with a special Child Safety programme, which enables the oven to be "locked" so that children or anyone unfamiliar with it cannot operate it accidentally. The oven can be locked at any time.





1. Press the **Clock** () and **Fast Preheat** () buttons at the same time (about three second).

Result:

- ◆ The oven is locked.
- ◆ The follow indication is display "L".




2. To unlock the oven, press the **Clock** () and **Fast Preheat** () buttons again at the same time (about three second).

Result: The oven can be used normally.


Switching the Beeper Off



You can switch the beeper off whenever you want.



1. Press the **Start** () and **Clock** () buttons at the same time (about one second).

Result: The oven does not beep to indicate the end of a function.




2. To switch the beeper back on, press the **Start** () and **Clock** () buttons again at the same time (about one second).


Result: The oven operates normally.


Using the Memory Cook Feature (CE117A / CE117AT)


If you often cook or reheat the same types of dishes, you can store the cooking times and power levels in the oven's memory, so that you do not have to reset them each other.

Storing the Settings




1. To programme the...
Setting
Resetting
Then press **MEMORY**()
button.
Once (Display is **P**)
Twice (Display is **P**)
2. Set your cooking programme as usual (MW, Grill, MW+Grill, Convection, MW+Convection)




3. Press the **Start**() button.
Result: Your settings are now stored in the oven's memory.


Using the Settings

First, place the food in the centre of the turntable




1. Press **MEMORY**() button.



2. Press the **Start**() button.
Result: The food is cooked as requested.

Manual Stop Turntable Function


The turntable on/off() button enables you to use large dishes which fill the whole oven by stopping the turntable from rotating (only manual cooking mode).




The results will be less satisfactory in this case as the cooking is less even. We recommend that you turn the dish by hand halfway through the cooking process.


Warning ! Never operate the turntable without food in the oven.

Reason: This may cause fire or damage to the unit.





1. Press the **Turntable on/off** () button.
Result: The turntable will not rotate.



2. To switch the turntable rotating back on, press the **Turntable on/off** () button again.
Result: The turntable will rotate.



Do not press the **Turntable on/off**() button during the cooking process. Cancel the cooking phase, before pressing the **turntable On/Off**() button.

Cookware Guide

EN

To cook food in the microwave oven, the microwaves must be able to penetrate the food, without being reflected or absorbed by the dish used. Care must therefore be taken when choosing the cookware. If the cookware is marked microwave-safe, you do not need to worry. The following table lists various types of cookware and indicates whether and how they should be used in a microwave oven.

| Cookware | Microwave-Safe | Comments |
|---|----------------|---|
| Aluminium foil | ✓ X | Can be used in small quantities to protect areas against overcooking. Arcing can occur if the foil is too close to the oven wall or if too much foil is used. |
| Crusty plate | ✓ | Do not preheat for more than 8minutes. |
| China and earthenware | ✓ | Porcelain, pottery, glazed earthenware and bone china are usually suitable, unless decorated with a metal trim. |
| Disposable polyester cardboard dishes | ✓ | Some frozen foods are packaged in these dishes. |
| Fast-food packaging | | |
| • Polystyrene cups | ✓ | Can be used to warm food. Overheating may cause the polystyrene to melt. May catch fire. |
| • Paper bags or newspaper | X | |
| • Recycled paper or metal trims | X | May cause arcing. |
| Glassware | | |
| • Oven-to-table ware | ✓ | Can be used, unless decorated with a metal trim. |
| • Fine glassware | ✓ | Can be used to warm foods or liquids. Delicate glass may break or crack if heated suddenly. |
| • Glass jars | ✓ | Must remove the lid. Suitable for warming only. |
| Metal | | |
| • Dishes | X | May cause arcing or fire. |
| • Freezer bag twist ties | X | |
| Paper | | |
| • Plates, cups, napkins and Kitchen paper | ✓ | For short cooking times and warming. Also to absorb excess moisture. |
| • Recycled paper | X | May cause arcing. |

Plastic

- Containers ✓ Particularly if heat-resistant thermoplastic. Some other plastics may warp or discolour at high temperatures. Do not use Melamine plastic.
- Cling film ✓ Can be used to retain moisture. Should not touch the food. Take care when removing the film as hot steam will escape.
- Freezer bags ✓ X Only if boilable or oven-proof. Should not be airtight. Prick with a fork, if necessary.

Wax or grease-proof paper

- ✓ Can be used to retain moisture and prevent spattering.

✓ :Recommended

✓ X :Use Caution

X :Unsafe

Cooking Guide

MICROWAVES

Microwave energy actually penetrates food, attracted and absorbed by its water, fat and sugar content.

The microwaves cause the molecules in the food to move rapidly. The rapid movement of these molecules creates friction and the resulting heat cooks the food.

COOKING

Cookware for microwave cooking:

Cookware must allow microwave energy to pass through it for maximum efficiency. Microwaves are reflected by metal, such as stainless steel, aluminium and copper, but they can penetrate through ceramic, glass, porcelain and plastic as well as paper and wood. So food must never be cooked in metal containers.

Food suitable for microwave cooking:

Many kinds of food are suitable for microwave cooking, including fresh or frozen vegetables, fruit, pasta, rice, grains, beans, fish, and meat. Sauces, custard, soups, steamed puddings, preserves, and chutneys can also be cooked in a microwave oven. Generally speaking, microwave cooking is ideal for any food that would normally be prepared on a hob. Melting butter or chocolate, for example (see the chapter with tips, techniques and hints).

Covering during cooking

To cover the food during cooking is very important, as the evaporated water rises as steam and contributes to cooking process. Food can be covered in different ways: e.g. with a ceramic plate, plastic cover or microwave suitable cling film.

Standing times

After cooking is over food the standing time is important to allow the temperature to even out within the food.

Cooking Guide for frozen vegetables

Use a suitable glass pyrex bowl with lid. Cook covered for the minimum time – see table. Continue cooking to get the result you prefer.

Stir twice during cooking and once after cooking. Add salt, herbs or butter after cooking. Cover during standing time.

| Food | Portion | Power | Time (min.) | Standing Time(min.) | Instructions |
|--------------------------------------|---------|-------|-------------|---------------------|--------------------------------------|
| Spinach | 150g | 600W | 5-6 | 2-3 | Add 15 ml (1 tablespoon) cold water. |
| Broccoli | 300g | 600W | 8-9 | 2-3 | Add 30 ml (2 tbsp.) cold water. |
| Peas | 300g | 600W | 7-8 | 2-3 | Add 15 ml (1 tbsp.) cold water. |
| Green Beans | 300g | 600W | 7½-8½ | 2-3 | Add 30 ml (2 tbsp.) cold water. |
| Mixed Vegetables (carrots/peas/corn) | 300g | 600W | 7-8 | 2-3 | Add 15 ml (1 tbsp.) cold water. |
| Mixed Vegetables (Chinese style) | 300g | 600W | 7½-8½ | 2-3 | Add 15 ml (1 tbsp.) cold water. |

Cooking Guide (continued)

Cooking Guide for rice and pasta

Rice: Use a large glass pyrex bowl with lid – rice doubles in volume during cooking. Cook covered.
After the cooking time is over, stir before standing time and salt or add herbs and butter.
Remark: the rice may not have absorbed all water after the cooking time is finished.

Pasta: Use a large glass pyrex bowl. Add boiling water, a pinch of salt and stir well. Cook uncovered.
Stir occasionally during and after cooking. Cover during standing time and drain thoroughly afterwards.

| Food | Portion | Power | Time (min.) | Standing Time(min.) | Instructions |
|-------------------------------|--------------|-------|------------------|---------------------|--|
| White Rice (parboiled) | 250g 375g | 900W | 15-16 17½-18½ | 5 | Add 500 ml cold water. Add 750 ml cold water. |
| Brown Rice (parboiled) | 250g 375g | 900W | 20-21 22-23 | 5 | Add 500 ml cold water. Add 750 ml cold water. |
| Mixed Rice (rice + wild rice) | 250g | 900W | 16-17 | 5 | Add 500 ml cold water. |
| Mixed Corn (rice + grain) | 250g | 900W | 17-18 | 5 | Add 400 ml cold water. |
| Pasta | 250g | 900W | 10-11 | 5 | Add 1000 ml hot water. |

Cooking Guide for fresh vegetables

Use a suitable glass pyrex bowl with lid. Add 30-45 ml cold water (2-3 tbsp.) for every 250 g unless another water quantity is recommended – see table. Cook covered for the minimum time – see table. Continue cooking to get the result you prefer. Stir once during and once after cooking. Add salt, herbs or butter after cooking.
Cover during a standing time of 3 minutes.

Hint: Cut the fresh vegetables into even sized pieces. The smaller they are cut, the quicker they will cook.

All fresh vegetables should be cooked using full microwave power (900W).

| Food | Portion | Time (min.) | Standing Time (min.) | Instructions |
|------------------|--------------|---------------|----------------------|---|
| Broccoli | 250g 500g | 4½-5 7-8 | 3 | Prepare even sized florets. Arrange the stems to the centre. |
| Brussels Sprouts | 250g | 6-6½ | 3 | Add 60-75 ml (5-6 tbsp.) water. |
| Carrots | 250g | 4½-5 | 3 | Cut carrots into even sized slices. |
| Cauliflower | 250g 500g | 5-5½ 7½-8½ | 3 | Prepare even sized florets. Cut big florets into halves. Arrange stems to the centre. |
| Courgettes | 250g | 4-4½ | 3 | Cut courgettes into slices. Add 30 ml (2 tbsp.) water or a knob of butter. Cook until just tender. |
| Egg Plants | 250g | 3½-4 | 3 | Cut egg plants into small slices and sprinkle with 1 tablespoon lemon juice. |
| Leeks | 250g | 4-4½ | 3 | Cut leeks into thick slices. |
| Mushrooms | 125g 250g | 1½-2 2½-3 | 3 | Prepare small whole or sliced mushrooms. Do not add any water. Sprinkle with lemon juice. Spice with salt and pepper. Drain before serving. |
| Onions | 250g | 5-5½ | 3 | Cut onions into slices or halves. Add only 15 ml (1 tbsp.) water. |
| Pepper | 250g | 4½-5 | 3 | Cut pepper into small slices. |
| Potatoes | 250g 500g | 4-5 7-8 | 3 | Weigh the peeled potatoes and cut them into similar sized halves or quarters. |
| Turnip Cabbage | 250g | 5½-6 | 3 | Cut turnip cabbage into small cubes. |

REHEATING

Your microwave oven will reheat food in a fraction of the time that conventional ovens hobs normally take.

Use the power levels and reheating times in the following chart as a guide. The times in the chart consider liquids with a room temperature of about +18 to +20°C or a chilled food with a temperature of about +5 to +7°C.

Arranging and covering

Avoid reheating large items such as joint of meat – they tend to overcook and dry out before the centre is piping hot. Reheating small pieces will be more successful.

Power levels and stirring

Some foods can be reheated using 900 W power while others should be reheated using 600 W, 450 W or even 300 W.

Check the tables for guidance. In general, it is better to reheat food using a lower power level, if the food is delicate, in large quantities, or if it is likely to heat up very quickly (mince pies, for example).

Stir well or turn food over during reheating for best results. When possible, stir again before serving.

Take particular care when heating liquids and baby foods. To prevent eruptive boiling of liquids and possible scalding, stir before, during and after heating. Keep them in the microwave oven during standing time. We recommend putting a plastic spoon or glass stick into the liquids. Avoid overheating (and therefore spoiling) the food.

It is preferable to underestimate cooking time and add extra heating time, if necessary.

Heating and standing times

When reheating food for the first time, it is helpful to make a note of the time taken – for future reference.

Always make sure that the reheated food is piping hot throughout.

Allow food to stand for a short time after reheating - to let the temperature even out.

The recommended standing time after reheating is 2-4 minutes, unless another time is recommended in the chart..

Take particular care when heating liquids and baby food. See also the chapter with the safety precautions.

REHEATING LIQUIDS

Always allow a standing time of at least 20 seconds after the oven has been switched off to allow the temperature to even out. Stir during heating, if necessary, and ALWAYS stir after heating. To prevent eruptive boiling and possible scalding, you should put a spoon or glass stick into the beverages and stir before, during and after heating.

REHEATING BABY FOOD

BABY FOOD:

Empty into a deep ceramic plate. Cover with plastic lid. Stir well after reheating! Let stand for 2-3 minutes before serving. Stir again and check the temperature.

Recommended serving temperature: between 30–40°C.

BABY MILK:

Pour milk into a sterilised glass bottle. Reheat uncovered. Never heat a baby's bottle with teat on, as the bottle may explode if overheated. Shake well before standing time and again before serving ! Always carefully check the temperature of baby milk or food before giving it to the baby. Recommended serving temperature: ca. 37°C.

REMARK:

Baby food particularly needs to be checked carefully before serving to prevent burns. Use the power levels and times in the next table as a guide lines for reheating.

Cooking Guide (continued)

EN

Reheating Baby Food and Milk

Use the power levels and times in this table as guide lines for reheating.

| Food | Portion | Power | Time | Standing Time(min.) | Instructions |
|--------------------------------------|----------------|-------|--|---------------------|--|
| Baby food (vegetables + meat) | 190g | 600W | 30sec. | 2-3 | Empty into ceramic deep plate. Cook covered. Stir after cooking time. Stand for 2-3 minutes. Before serving, stir well and check the temperature carefully. |
| Baby porridge (grain + milk + fruit) | 190g | 600W | 20sec. | 2-3 | Empty into ceramic deep plate. Cook covered. Stir after cooking time. Stand for 2-3 minutes. Before serving, stir well and check the temperature carefully. |
| Baby milk | 100ml 200ml | 300W | 30-40sec. 1min. to 1min. 10sec. | 2-3 | Stir or shake well and pour into a sterilised glass bottle. Place into the centre of turntable. Cook uncovered. Shake well and stand for at least 3 minutes. Before serving, shake well and check the temperature carefully. |

Reheating Liquids and Food

Use the power levels and times in this table as a guide lines for reheating.

| Food | Portion | Power | Time (min.) | Standing Time (min.) | Instructions |
|-----------------------------------|---|-------|------------------------------|----------------------|---|
| Drinks (coffee, tea and water) | 150ml (1 cup) 300ml (2 cups) 450ml (3 cups) 600ml (4 cups) | 900W | 1-1½ 2-2½ 3-3½ 3½-4 | 1-2 | Pour into cups and reheat uncovered: 1 cup in the centre, 2 cups opposite of each other, 3 cups in a circle. Keep in microwave oven during standing time and stir well. |
| Soup (chilled) | 250 g 350 g 450 g 550 g | 900W | 2½-3 3-3½ 3½-4 4½-5 | 2-3 | Pour into a deep ceramic plate or deep ceramic bowl. Cover with plastic lid. Stir well after reheating. Stir again before serving. |
| Stew (chilled) | 350g | 600W | 4½-5½ | 2-3 | Put stew in a deep ceramic plate. Cover with plastic lid. Stir occasionally during reheating and again before standing and serving. |
| Pasta with sauce (chilled) | 350g | 600W | 3½-4½ | 3 | Put pasta (e.g. spaghetti or egg noodles) on a flat ceramic plate. Cover with microwave cling film. Stir before serving. |
| Filled pasta with sauce (chilled) | 350g | 600W | 4-5 | 3 | Put filled pasta (e.g. ravioli, tortellini) in a deep ceramic plate. Cover with plastic lid. Stir occasionally during reheating and again before standing and serving. |
| Plated Meal (chilled) | 350g 450g 550g | 600W | 4½-5½ 5½-6½ 6½-7½ | 3 | Plate a meal of 2-3 chilled components on a ceramic dish. Cover with microwave cling-film. |

Cooking Guide (continued)

DEFROSTING

Microwaves are an excellent way of defrosting frozen food. Microwaves gently defrost frozen food in a short period of time. This can be of great advantage, if unexpected guests suddenly show up.

Frozen poultry must be thoroughly thawed before cooking. Remove any metal ties and take it out of any wrapping to allow thawed liquid to drain away.

Put the frozen food on a dish without cover. Turn over half way, drain off any liquid and remove any giblets as soon as possible.

Check the food occasionally to make sure that it does not feel warm.

If smaller and thinner parts of the frozen food start to warm up, they can be shield by wrapping very small strips of aluminium foil around them during defrosting.

Should poultry start to warm up on the outer surface, stop thawing and allow it to stand for 20 minutes before continuing.

Leave the fish, meat and poultry to stand in order to complete defrosting. The standing time for complete defrosting will vary depending on the quantity defrosted. Please refer to the table below.

Hint: Flat food defrosts better than thick and smaller quantities need less time than bigger ones. Remember this hint while freezing and defrosting food.

For defrosting of frozen food with a temperature of about -18 to -20 °C, use the following table as a guide.

All frozen food should be defrosted using defrosting power level (180 W).

| Food | Portion | Time (min.) | Standing Time (min.) | Instructions |
|----------------------------------|----------------|--------------|----------------------|--|
| Meat | | | | |
| Minced beef | 250g 500g | 6-7 10-12 | 15-30 | Place the meat on a flat ceramic plate. Shield thinner edges with aluminium foil. Turn over after half of defrosting time! |
| Pork steaks | 250g | 7-8 | | |
| Poultry | | | | |
| Chicken pieces | 500g (2pcs) | 14-15 | 15-60 | First, put chicken pieces first skin-side down, whole chicken first breast-side-down on a flat ceramic plate. Shield the thinner parts like wings and ends with aluminium foil. Turn over after half of defrosting time! |
| Whole chicken | 1200g | 32-34 | | |
| Fish | | | | |
| Fish fillets | 200g | 6-7 | 10-25 | Put frozen fish in the middle of a flat ceramic plate. Arrange the thinner parts under the thicker parts. Shield narrow ends of fillets and tail of whole fish with aluminium foil. Turn over after half of defrosting time! |
| Whole fish | 400g | 11-13 | | |
| Fruits | | | | |
| Berries | 300g | 6-7 | 5-10 | Spread fruit on a flat, round glass dish (with a large diameter). |
| Bread | | | | |
| Bread rolls (each ca. 50 g) | 2pc 4pc | 1-1½ 2½-3 | 5-20 | Arrange rolls in a circle or bread horizontally on kitchen paper in the middle of turntable. Turn over after half of defrosting time! |
| Toast/ Sandwich | 250g | 4-4½ | | |
| German bread (wheat + rye flour) | 500g | 7-9 | | |

Cooking Guide (continued)

EN

GRILL

The grill-heating elements are located underneath the ceiling of the cavity. They operate while the door is closed and the turntable is rotating. The turntable's rotation makes the food brown more evenly. Preheating the grill for 2-3 minutes will make the food brown more quickly.

Cookware for grilling:

Should be flameproof and may include metal. Do not use any type of plastic cookware, as it can melt.

Food suitable for grilling:

Chops, sausages, steaks, hamburgers, bacon and gammon rashers, thin fish portions, sandwiches and all kinds of toast with toppings.

IMPORTANT REMARK:

Whenever the grill only mode is used, please remember that food must be placed on the high rack, unless another instruction is recommended.

MICROWAVE + GRILL

This cooking mode combines the radiant heat that is coming from the grill with the speed of microwave cooking. It operates only while the door is closed and the turntable is rotating. Due to the rotation of the turntable, the food browns evenly. Three combination modes are available with this model: 600 W + Grill, 450 W + Grill and 300 W + Grill.

Cookware for cooking with microwaves + grill

Please use cookware that microwaves can pass through. Cookware should be flameproof. Do not use metal cookware with combination mode. Do not use any type of plastic cookware, as it can melt.

Food suitable for microwaves + grill cooking:

Food suitable for combination mode cooking include all kinds of cooked food which need reheating and browning (e.g. baked pasta), as well as foods which require a short cooking time to brown the top of the food. Also, this mode can be used for thick food portions that benefit from a browned and crispy top (e.g. chicken pieces, turning them over half way through cooking). Please refer to the grill table for further details.

IMPORTANT REMARK:

Whenever the combination mode (microwave + grill) is used, the food should be placed on the high rack, unless another instruction is recommended. Please refer to the instructions in the following chart.

The food must be turned over, if it is to be browned on both sides.

Grill Guide for fresh food

Preheat the grill with the grill-function for 2-3 minutes.

Use the power levels and times in this table as guide lines for grilling.

| Fresh Food | Portion | Power | 1. Side Time (min.) | 2. Side Time (min.) | Instructions |
|--|--------------------|-------------|---------------------|---------------------|--|
| Toast Slices | 4 pc (each 25g) | Grill only | 3-4 | 2-3 | Put toast slices side by side on the high rack. |
| Cocktail-Tomatoes | 400 g | 300W+ Grill | 5-6 | - | Use small tomatoes. Arrange in a circle in a flat glass pyrex dish. Place it on the high rack. Stand for 2-3 minutes. |
| Tomato-Cheese Toast | 4 pcs (300 g) | 300W+ Grill | 4½-5½ | - | Toast the bread slices first. Put the toast with topping on the high rack. Stand for 2-3 minutes |
| Toast Hawaii (ham, pineapple, cheese slices) | 4 pcs (500 g) | 300W+ Grill | 6½-7½ | - | Toast the bread slices first. Put the toast with topping on the high rack. Stand for 2-3 minutes. |
| Baked Potatoes | 500g | 600W+ Grill | 7-8 | - | Cut potatoes into halves. Put them in a circle on the high rack with the cut side to the grill. |
| Gratin Potatoes / vegetables (chilled) | 450g | 450W+ Grill | 9-11 | - | Put the fresh gratin into a small glass pyrex dish. Put the dish on the high rack. After cooking stand for 2-3 minutes. |
| Baked Apples | 2 apples (ca.400g) | 300W+ Grill | 6½-7½ | - | Core the apples and fill them with raisins and jam. Put some almond slices on top. Put apples on a flat glass pyrex dish. Place the dish directly on the low rack. |
| Chicken Pieces | 500g (2pcs) | 300W+ Grill | 9-10 | 7-8 | Brush chicken pieces with oil and spices. Put them in a circle on the high rack. After grilling stand for 2-3 minutes. |

| Fresh Food | Portion | Power | 1. Side Time (min.) | 2. Side Time (min.) | Instructions |
|----------------------|-------------|-------------|---------------------|---------------------|---|
| Beef Steaks (medium) | 400g (2pcs) | Grill only | 12-13 | 11-12 | Brush the beef steaks with oil. Lay them in a circle on the high rack. After grilling stand for 2-3 minutes. |
| Roast Fish | 400-500g | 300W+ Grill | 5½-6½ | 5-6 | Brush skin of whole fish with oil and add herbs and spices. Put two fish side by side (head to tail) on the high rack. After grilling stand for 2-3 minutes. |

CONVECTION

Cooking with convection is the traditional and well known method of cooking food in a traditional oven with hot air.

The heating element and the fan position is at the back-wall, so that the hot air is circulating.

Cookware for convection cooking:

All conventional ovenproof cookware, baking tins and sheets – anything you would normally use in a traditional convection oven – can be used.

Food suitable for convection cooking:

All biscuits, individual scones, rolls and cakes should be made by this mode as well as rich fruit cakes, choux pastry and soufflés.

MICROWAVES + CONVECTION

This mode combines the microwave energy with the hot air and is therefore reducing the cooking time while giving the food a brown and crispy surface.

Cooking with convection is the traditional and well known method of cooking food in an oven with hot air circulated by a fan on the back-wall.

Cookware for cooking with microwaves + convection:

Should be able to let the microwaves pass through. Should be ovenproof (like glass, pottery or china without metal trims); similar to the cookware described under MW + Grill.

Food suitable for microwave + convection cooking:

All kinds of meats and poultry as well as casseroles and gratin dishes, sponge cakes and light fruit cakes, pies and crumbles, roast vegetables, scones and breads.

Cooking Guide (continued)

EN

Convection Guide for fresh and frozen food

Preheat the convection with the fast pre-heat function to the desired temperature. Use the power levels and times in this table as guide lines for convection cooking.

| Fresh Food | Portion | Power | 1. Side Time (min.) | 2. Side Time (min.) | Instructions |
|---|---------------|--------------|---------------------|---------------------|--|
| PIZZA Frozen Pizza (ready baked) | 300-400 g | 600W + 220°C | 9-11 | - | Place the pizza on the high rack. After baking stand for 2-3 minutes |
| PASTA Frozen Lasagne | 400 g | 450W + 200°C | 20-23 | - | Put into a suitable sized glass pyrex dish or leave in the original packaging (take care that this is suitable for microwaves and oven heat). Put frozen lasagne on the low rack. After cooking stand for 2-3 minutes. |
| MEAT Roast beef/ Roast Lamb (medium) | 1200-1300g | 600W + 180°C | 19-21 | 11-13 | Brush beef/ lamb with oil and spice it with pepper, salt and paprika. Put it on the low rack, first with the fat side down. After cooking wrap in aluminium foil and stand for 10–15minutes. |
| Roast Chicken | 900-1000g | 450W + 220°C | 16-18 | 12-15 | Brush chicken with oil and spices. Put chicken first breast side down, second side breast side up on the low rack. Stand for 5 minutes. |
| BREAD Fresh Bread Rolls (fresh dough) | 4 pcs (200 g) | Only 200°C | 13-15 | - | Put bread rolls in a circle on the low rack. Use oven gloves while taking out! Stand 2-3 minutes. |
| Garlic Bread (chilled, pre-baked) | 200 g (1pc) | 180W + 220°C | 10-12 | - | Put the chilled baguette on baking paper on the low rack. After baking stand for 2-3 minutes. |

| Fresh Food | Portion | Power | 1. Side Time (min.) | 2. Side Time (min.) | Instructions |
|---|-----------------------|--------------|---------------------|---------------------|---|
| CAKE Apple Cake (fresh dough) | 500 g | Only 180°C | 40-45 | - | Put the fresh dough (300g) in a small round black metal baking dish (diameter 18 cm). Add sliced apples (200g) on top. Put the cake on the low rack. After baking stand for 5-10 minutes. |
| Mini Muffins (fresh dough) | 12 x 30 g (350-400 g) | Only 200°C | 15-18 | - | Fill the fresh dough evenly in paper muffin dishes. Put the dishes on the low rack. After baking stand for 5 minutes. |
| Cookies (fresh dough) | 100-150 g | Only 200°C | 9-12 | - | Preheat oven including a round metal baking plate or use Crusty plate. Put cookies on the plate. Put plate on low rack. |
| Frozen Cake | 1000 g | 180W + 180°C | 18-20 | - | Put the frozen cake directly on the low rack. After defrost and warming stand for 15-20 minutes. |

Cooking Guide (continued)

SPECIAL HINTS

MELTING BUTTER

Put 50 g butter into a small deep glass dish. Cover with plastic lid. Heat for 30-40 seconds using 900 W, until butter is melted.

MELTING CHOCOLATE

Put 100 g chocolate into a small deep glass dish. Heat for 3-5 minutes, using 450 W until chocolate is melted. Stir once or twice during melting. Use oven gloves while taking out!

MELTING CRYSTALLIZED HONEY

Put 20 g crystallized honey into a small deep glass dish. Heat for 20-30 seconds using 300 W, until honey is melted.

MELTING GELATINE

Lay dry gelatine sheets (10 g) for 5 minutes into cold water. Put drained gelatine into a small glass pyrex bowl. Heat for 1 minute using 300 W. Stir after melting.

COOKING GLAZE/ICING (FOR CAKE AND GATEAUX)

Mix instant glaze (approximately 14 g) with 40 g sugar and 250 ml cold water. Cook uncovered in a glass pyrex bowl for 3 ½ to 4 ½ minutes using 900 W, until glaze/icing is transparent. Stir twice during cooking.

COOKING JAM

Put 600 g fruits (for example mixed berries) in a suitable sized glass pyrex bowl with lid. Add 300 g preserving sugar and stir well. Cook covered for 10-12 minutes using 900 W. Stir several times during cooking. Empty directly into small jam glasses with twist-off lids. Stand on lid for 5 minutes.

COOKING PUDDING/ CUSTARD

Mix pudding powder with sugar and milk (500 ml) by following the manufacturers instructions and stir well. Use a suitable sized glass pyrex bowl with lid. Cook covered for 6 ½ to 7 ½ minutes using 900 W. Stir several times well during cooking.

BROWNING ALMOND SLICES

Spread 30 g sliced almonds evenly on a medium sized ceramic plate. Stir several times during browning for 3 ½ to 4 ½ minutes using 600 W. Let it stand for 2-3 minutes in the oven. Use oven gloves while taking out!

Cleaning Your Microwave Oven

The following parts of your microwave oven should be cleaned regularly to prevent grease and food particles from building up:

- **Inside and outside surfaces**
- **Door and door seals**
- **Turntable and Roller rings**



ALWAYS ensure that the door seals are clean and the door closes properly.



Failure to maintain the oven in a clean condition could lead to deterioration of the surface that could adversely affect the of the appliance and possibly result in a hazardous situation.

1. Clean the outside surfaces with a soft cloth and warm, soapy water. Rinse and dry.
2. Remove any splashes or stains on the inside surfaces or on the roller ring with a soapy cloth. Rinse and dry.
3. To loosen hardened food particles and remove smells, place a cup of diluted lemon juice on the turntable and heat for ten minutes at maximum power.
4. Wash the dishwasher-safe plate whenever necessary.



DO NOT spill water in the vents. **NEVER** use any abrasive products or chemical solvents. Take particular care when cleaning the door seals to ensure that no particles:

- Accumulate
- Prevent the door from closing correctly



Clean the microwave oven cavity right after each use with a mild detergent solution, but let the microwave oven cool down before cleaning in order to avoid injury.



The instructions for cooking ranges, hobs and ovens shall state that a steam cleaner is not to be used.

Storing and Repairing Your Microwave Oven

EN

A few simple precautions should be taken when storing or having your microwave oven serviced.

The oven must not be used if the door or door seals are damaged:

- **Broken hinge**
- **Deteriorated seals**
- **Distorted or bent oven casing**

Only a qualified microwave service technician should perform repairs.



NEVER remove the outer casing from the oven. If the oven is faulty and needs servicing or you are in doubt about its condition:

- Unplug it from the wall socket
- Contact the nearest after-sales service centre



If you wish to store your oven away temporarily, choose a dry, dust-free place.

- **Reason:** Dust and damp may adversely affect the working parts in the oven.

Installation & Wiring Instructions

IMPORTANT NOTE :

The mains lead on this equipment is supplied with a moulded plug incorporating a fuse. The value of the fuse is indicated on the pin face of the plug and, if it requires replacing, a fuse approved to BS1363 of the same rating must be used.

Never use the plug with the fuse cover omitted if the cover is detachable. If a replacement fuse cover is required, it must be of the same colour as the pin face of the plug.



Replacement covers are available from your Dealer. If the fitted plug is not suitable for the power points in your house or the cable is not long enough to reach a power point, you should obtain a suitable safety approved extension lead or consult your Dealer for assistance. However, if there is no alternative to cutting off the plug, remove the fuse and then safely dispose of the plug. Do not connect the plug to a mains socket, as there is a risk of shock hazard from the bared flexible cord.

Wiring Instructions

WARNING THIS APPLIANCE MUST BE EARTHED.

This appliance must be earthed. In the event of an electrical short circuit, earthing reduces the risk of electric shock providing an escape wire for the electric current. The appliance is equipped with a mains lead which includes an earth wire for connecting to the earth terminal of your mains plug. The plug must be plugged into a socket that is properly installed and earthed.

🔌 The wires in this mains lead are coloured in accordance with the following code:


- Green-and yellow : Earth
- Blue : Neutral
- Brown : Live

- ◆ As the colours of the wires in the mains lead of this appliance may not correspond with the coloured markings identifying the terminals in your plug, proceed as follows.
- ◆ Connect the green-and yellow wire to the terminal in the plug marked with the letter E or the earth symbol (\perp) or coloured green or green-and-yellow.
- ◆ Connect the blue wire to the terminal marked with the letter N or coloured black.

🔌 Consult a qualified electrician or service technician if in doubt about any of these instructions.

The manufacturer of this oven will not accept any liability for damage to persons or material for non observance of these requirements.

There are no user+serviceable parts inside the oven and if the mains lead of this appliance is damaged, it must only be replaced by qualified service personnel approved by the manufacturer because special tools are required.



WARNING

Ensure that the plug and power cord are not damaged before use.

If you have any reason to remove the moulded plug from this appliance, immediately remove the fuse and dispose of the plug.

Do not connect the plug to a mains socket under any circumstances as there is a danger of electric shock.

CIRCUITS

Your microwave oven should be operated on a separate circuit from other appliances. Failure to do this may cause the circuit breaker to trip, the fuse to blow, or the food to cook more slowly.

Cooking Instructions On Food Packaging

Microwave Symbols

On the front of your oven there is a microwave oven symbol, as shown below.

This symbol has been introduced for your benefit when cooking or reheating packaged food.



Packaged food is also, increasingly, using a microwave symbol similar to the one below.

When you see this



Symbol on food packaging, the cooking instructions are based on either the IEC Power Output Rating, or the Reheating Categories A, B, C, D or E.

EN

Cooking Instructions

EN

The IEC Power Output rating is an internationally standardised rating, so all microwave manufacturers now use the same method of measuring power output.

If food packaging gives cooking instructions based on IEC Power ratings, set cooking times according to the IEC Power of your oven.

For example :

If the cooking instructions are based on a 650W oven, then you will need to reduce some cooking time for the CE117A (900W)

Ready meals are now very convenient and popular. These are meals which are already prepared and cooked by the food manufacturer, and then frozen, chilled or vacuum sealed for long life.

Increasingly, heating times for such ready meals are being based on the Heating Categories A, B, C, D and E.

On this instance, simply match the heating category of your oven to the instructions on the food package, and set your timer accordingly.

For example :

If the heating instructions are 3 minutes on HIGH for a D category oven, then you will need to set your timer for less than 3 minutes on HIGH for the CE117A (E category).



Always remember that cooking instructions are intended only as a guide. If you have followed the instructions and the food is still not piping hot throughout, simply return it to the oven and cook it until it is.

Technical Specifications

SAMSUNG strives to improve its products at all times. Both the design specifications and these user instructions are thus subject to change without notice.

| | |
|-------------------------------|------------------------------------|
| Power source | 230 V ~ 50 Hz AC |
| Power consumption | |
| Maximum power | 2700 W |
| Microwave | 1400 W |
| Grill (heating element) | 1250 W |
| Convection (heating element) | Max. 2050 W |
| Output power | 100 W / 900 W - 6 levels (IEC-705) |
| Operating frequency | 2450 MHz |
| Dimensions (W x D x H) | |
| Outside | 522 x 539 x 312 mm |
| Oven cavity | 355 x 380.6 x 234 mm |
| Volume | 1.1 Cubic feet |
| Weight | |
| Net | 21 kg approx. |

English



Correct Disposal of This Product (Waste Electrical & Electronic Equipment)



(Applicable in the European Union and other European countries with separate collection systems)

This marking on the product, accessories or literature indicates that the product and its electronic accessories (e.g. charger, headset, USB cable) should not be disposed of with other household waste at the end of their working life. To prevent possible harm to the environment or human health from uncontrolled waste disposal, please separate these items from other types of waste and recycle them responsibly to promote the sustainable reuse of material resources.

Household users should contact either the retailer where they purchased this product, or their local government office, for details of where and how they can take these items for environmentally safe recycling.

Business users should contact their supplier and check the terms and conditions of the purchase contract. This product and its electronic accessories should not be mixed with other commercial wastes for disposal.



ELECTRONICS

QUESTIONS OR COMMENTS

| COUNTRY | CALL | OR VISIT US ONLINE AT |
|----------------|---|---|
| BELGIUM | 02 201 24 18 | www.samsung.com/be (Dutch) www.samsung.com/be_fr (French) |
| CZECH REPUBLIC | 800 - SAMSUNG (800-726-786) | www.samsung.com/cz |
| DENMARK | 8 - SAMSUNG (7267864) | www.samsung.com/dk |
| FINLAND | 30-6227 515 | www.samsung.com/fi |
| FRANCE | 01 48 63 00 00 | www.samsung.com/fr |
| GERMANY | 01805 - SAMSUNG(726-7864, € 0.14/Min) | www.samsung.com/de |
| HUNGARY | 06 - 80 - SAMSUNG (726-7864) | www.samsung.com/hu |
| ITALIA | 800 - SAMSUNG (726-7864) | www.samsung.com/it |
| LUXEMBURG | 02 261 03 710 | www.samsung.com/lu |
| NETHERLANDS | 0900 - SAMSUNG (0900-726-7864, € 0.10/Min) | www.samsung.com/nl |
| NORWAY | 3 - SAMSUNG (726-7864) | www.samsung.com/no |
| POLAND | 0 - 801 - 1 SAMSUNG (172678) 022-607-93-33 | www.samsung.com/pl |
| PORTUGAL | 808 20 - SAMSUNG (726-7864) | www.samsung.com/pt |
| SLOVAKIA | 0800 - SAMSUNG (726-7864) | www.samsung.com/sk |
| SPAIN | 902 - 1 - SAMSUNG (902 172 678) | www.samsung.com/es |
| SWEDEN | 075 - SAMSUNG (726-7864) | www.samsung.com/se |
| U.K | 0845 SAMSUNG (726-7864) | www.samsung.com/uk |
| EIRE | 0818 717 100 | www.samsung.com/ie |
| AUSTRIA | 0810 - SAMSUNG (726-7864, € 0.07/Min) | www.samsung.com/at |
| Switzerland | 0848 - SAMSUNG (726-7864, CHF 0.08/Min) | www.samsung.com/ch |