



GE81KR*-1 GE81KR*-2 GE81KR*-3 GE81MR** GE81AR*


Microwave Oven

Owner's Instructions & Cooking Guide

imagine the possibilities

Thank you for purchasing this Samsung product.

Please be advised that the Samsung warranty does NOT cover service calls to explain product operation, correct improper installation, or perform normal cleaning or maintenance.



This manual is made with 100 % recycled paper.







contents

| Safety information | | | |
|---------------------------------------------------|--|--|--|
| Oven features11 | | | |
| Oven (GE81KR*-1, GE81KR*-2, GE81KR*-3)11 | | | |
| Oven (GE81MR**)12 | | | |
| Oven (GE81AR*)12 | | | |
| Control panel (GE81KR*-1, GE81KR*-2, GE81KR*-3)13 | | | |
| Control panel (GE81MR**)13 | | | |
| Control panel (GE81AR*)14 | | | |
| Accessories14 | | | |
| Oven use15 | | | |
| Cooking/Reheating15 | | | |
| Power levels15 | | | |
| Adjusting the cooking time15 | | | |
| Stopping the cooking16 | | | |
| Manual defrosting food16 | | | |
| Using the instant reheat/cook feature16 | | | |
| Instant reheat/cook settings16 | | | |
| Grilling16 | | | |
| Combining microwaves and the grill17 | | | |
| Choosing the accessories17 | | | |
| Cookware guide17 | | | |
| Cooking guide18 | | | |
| Troubleshooting26 | | | |
| Technical specifications27 | | | |

safety information

USING THIS INSTRUCTION BOOKLET

You have just purchased a SAMSUNG microwave oven. Your Owner's Instructions contain valuable information on cooking with your microwave oven:

- Safety precautions
- Suitable accessories and cookware
- Useful cooking tips
- Cooking tips

LEGEND FOR SYMBOLS AND ICONS



Hazards or unsafe practices that may result in severe personal injury or death.



Hazards or unsafe practices that may result in minor personal injury or property damage.



Warning; Fire hazard



Warning; Hot surface



Warning; Electricity



Warning; Explosive material



Do NOT attempt.



Do NOT touch.



Do NOT disassemble.



Follow directions explicitly.



Unplug the power plug from the wall socket.



Make sure the machine is grounded to prevent electric shock.



Call the service center for help.



Note



Important











IMPORTANT SAFETY INSTRUCTIONS READ CAREFULLY AND KEEP FOR FUTURE REFERENCE.

Make sure that these safety precautions are obeyed at all times.

Before using the oven, confirm that the following instructions are followed.

▲ WARNING (Microwave function only)

- WARNING: If the door or door seals are damaged, the oven must not be operated until it has been repaired by a competent person.
- warning: It is hazardous for anyone other than a competent person to carry out any service or repair operation that involves the removal of a cover which gives protection against exposure to microwave energy.
- This appliance is intended to be used in household only.

- warning: Only allow children to use the oven without supervision when adequate instructions have been given so that the child is able to use the oven in a safe way and understands the hazards of improper use.
- warning: This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved. Children shall not play with the appliance. Cleaning and user maintenance shall not be made by children unless they are aged from 8 years and above and supervised.
- Only use utensils that are suitable for use in microwave ovens.
- When heating food in plasitic or paper containers, keep an eye on the oven due to the possibility of ignitions.







- The microwave oven is intended for heating food and beverages. Drying of food or clothing and heating of warming pads, slippers, sponges, damp cloth and similar may lead to risk of injury, ignition or fire.
- If smoke is emitted, switch off or unplug the appliance and keep the door closed in order to stifle any flames.
- warning: Microwave heating of beverages can result in delayed eruptive boiling, therefore care must be taken when handling the container.
- warning: The contents of feeding bottles and baby food jars shall be stirred or shaken and the temperature checked before consumption, in order to avoid burns.
- Eggs in their shell and whole hard-boiled eggs should not be heated in microwave ovens since they may explode, even after microwave heating has ended.
- The oven should be cleaned regularly and any food deposites removed.

- Failure to maintain the oven in a clean conditioin could lead to deterioration of the surface that could adversely affect the life of the appliance and possibly result in a hazardous situation.
- The appliance is not intended for installing in road vehicles, caravans and similar vehicles etc.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- Children should be supervised to ensure that they do not play with the appliance.
- If the supply cord is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard.
- WARNING: Liquids and other foods must not be heated in sealed containers since they are liable to explode;

English - 4

- •
- The appliance should not be cleaned with a water jet.
- This oven should be positioned proper direction and height permitting easy access to cavity and control area.
- Before using the your oven first time, oven should be operated with the water during 10 minute and then used.
- If the oven generates a strange noise, a burning smell, or smoke is emitted, unplug the power plug immediately and contact your nearest service center.
- The microwave oven has to be positioned so that plug is accessible.
- The microwave oven is intended to be used on the counter or counter top use only, the microwave oven shall not be placed in a cabinet.

▲ WARNING (Oven function only) - Optional

warning: When the appliance is operated in the combination mode, children should only use the oven under adult supervision due to the temperatures generated.

- During use the appliance becomes hot. Care should be taken to avoid touching heating elements inside the oven.
- WARNING: Accessible parts may become hot during use. Young children should be kept away.
- A steam cleaner is not to be used.
- WARNING: Ensure that the appliance is switched off before replacing the lamp to avoid the possibility of electric shock.
- warning: The appliance and its accessible parts become hot during use. Care should be taken to avoid touching heating elements.
 Children less than 8 years of age shall be kept away unless continuously
- The temperature of accessible surfaces may be high when the appliance is operating.

supervised.

- The door or the outer surface may get hot when the appliance is operating.
- Keep the appliance and its cord out of reach of children less than 8 years.





- This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved. Children shall not play with the appliance. Cleaning and user maintenance shall not be made by children without supervision.
- Do not use harsh abrasive cleaners or sharp metal scrapers to clean the oven door glass since they can scratch the surface, which may result in shattering of the glass.
- Appliances are not intended to be operated by means of an external timer or separate remote-control system.


This product is a Group 2 Class B ISM equipment. The definition of group 2 which contains all ISM equipment in which radiofrequency energy is intentionally generated and/or used in the form of electromagnetic radiation for the treatment of material, and

EDM and arc welding equipment. For Class B equipment is equipment suitable for use in domestic establishments and in establishments directly connected to a low voltage power supply network which supplies buildings used for domestic purposes.

INSTALLING YOUR MICROWAVE OVEN

Place the oven on a flat level surface 85 cm above the floor. The surface should be strong enough to safety bear the weight of the oven.

1.When you install your oven, make sure there is adequate ventilation for your oven by leaving at least 10 cm (4 inches) of space behind and, on the sides of the



2.Remove all packing materials inside the oven.

oven and 20 cm (8 inches) of space above.

- **3.**Install the roller ring and turntable. Check that the turntable rotates freely. (Turntable type model only)
- **4.**This microwave oven has to be positioned so that plug is accessible.

English - 6

- ${\color{red} \bigoplus}$
- If the supply cord is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard. For your personal safety, plug the cable into a proper AC earthed socket.
- Do not install the microwave oven in hot or damp surroundings like next to a traditional oven or radiator. The power supply specifications of the oven must be respected and any extension cable used must be of the same standard as the power cable supplied with the oven. Wipe the interior and the door seal with a damp cloth before using your microwave oven for the first time.

CLEANING YOUR MICROWAVE OVEN

The following parts of your microwave oven should be cleaned regularly to prevent grease and food particles from building up:

- Inside and outside surfaces
- Door and door seals
- Turntable and Roller rings (Turntable type model only)
- ALWAYS ensure that the door seals are clean and the door closes properly.

- Failure to maintain the oven in a clean condition could lead to deterioration of the surface that could adversely affect the life of the appliance and possibly result in a hazardous situation.
- **1.**Clean the outside surfaces with a soft cloth and warm, soapy water. Rinse and dry.
- 2. Remove any splashes or stains on the inside surfaces of oven with a soapy cloth. Rinse and dry.
- **3.**To loosen hardened food particles and remove smells, place a cup of diluted lemon juice in the oven and heat for ten minutes at maximum power.
- **4.** Wash the dishwasher-safe plate whenever necessary.
- **DO NOT** spill water in the vents. **NEVER** use any abrasive products or chemical solvents. Take particular care when cleaning the door seals to ensure that no particles:
 - Accumulate
 - Prevent the door from closing correctly









Clean the microwave oven cavity right after each use with a mild detergent solution, but let the microwave oven cool down before cleaning in order to avoid injury.

When cleaning the upper part inside the cavity, it will be convenient to turn heater downward by 45 ° and clean it. (Swing heater model only)



STORING AND REPAIRING YOUR MICROWAVE OVEN

A few simple precautions should be taken when storing or having your microwave oven serviced.

The oven must not be used if the door or door seals are damaged:

- Broken hinge
- Deteriorated seals
- Distorted or bent oven casing

Only a qualified microwave service technician should perform repair.

■ NEVER remove the outer casing from the oven. If the oven is faulty and needs servicing or you are in doubt about its condition:

- Unplug it from the wall socket
- Contact the nearest after-sales service centre
- If you wish to store your oven away temporarily, choose a dry, dustfree place.
 Reason: Dust and damp may adversely affect the working parts in the oven.
- This microwave oven is not intended for commercial use.
- The Light bulb should not be replaced in person for safety reasons. Please contact nearest authorised Samsung customer care, to arrange for a qualified engineer to replace the bulb.

| A | WARNING | Δ | À | ▲ | <u>k</u> |
|---|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|----------|----------|----------|----------|
| X | Only qualified staff should be allowed to modify or repair the appliance. | ~ | ~ | ~ | ✓ |
| | Do not heat liquids and other food in sealed containers for microwave function. | ~ | ~ | ~ | ~ |
| | For your safety, do not use high-pressure water cleaners or steam jet cleaners. | ~ | ~ | ~ | ~ |
| | Do not install this appliance; near heater, inflammable material; in a humid, oily or dusty location, in a location exposed to direct sunlight and water or where gas may leak; on un level ground. | ~ | ✓ | ✓ | ✓ |
| | This appliance must be properly grounded in accordance with local and national codes. | ~ | ~ | ~ | ~ |

English - 8



| * | Remove all foreign substances such as dust or water from the power plug terminals and contact points using a dry cloth on a regular basis. | ✓ | ✓ | ✓ | ✓ |
|----------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|----------|----------|----------|----------|
| | Do not pull or excessively bend or place heavy objecton the power cord. | ✓ | ~ | ~ | ~ |
| * | In the event of a gas leak (such as propane gas, LP gas, etc.), ventilate immediately without touching the power plug. | ✓ | ✓ | ✓ | ✓ |
| 8 | Do not touch the power plug with wet hands. | ~ | ~ | ~ | ~ |
| | Do not turn the appliance off by unplugging the power plug while an operation is in progress. | ~ | ✓ | ✓ | ✓ |
| | Do not insert fingers or foreign substances, If any foreign substance such as water has entered the appliance, unplug the power plug and contact your nearest service centre. | ~ | ✓ | ✓ | ✓ |
| | Do not apply excessive pressure or impact to the appliance. | ~ | ~ | ✓ | ✓ |
| | Do not place the oven over a fragile object such as a sink or glass object. | ~ | ~ | | |
| | Do not use benzene, thinner, alcohol, steam cleaner or high pressure cleaner to clean the appliance. | ~ | ~ | ~ | ✓ |
| | Ensure that the power voltage, frequency and current are the same as those of the product specifications. | ✓ | ✓ | | ~ |
| | Plug the power plug into the wall socket firmly. Do not use a multiple plug adapter, an extension cord or an electric transformer. | ✓ | ✓ | ✓ | |
| | Do not hook the power cord on a metal object, insert the power cord between the objects or behind the oven. | ~ | ✓ | ✓ | |

| | Do not use a damaged power plug, damaged power cord or loose wall socket. When the power plug or power cord is damaged, contact your nearest service centre. | ~ | ~ | ~ | ~ |
|---|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|----------|----------|----------|----------|
| | Do not pour or directly spray water onto the oven. | ~ | ~ | | |
| | Do not place objects on the oven, inside or on the door of the oven. | ~ | ✓ | ✓ | |
| | Do not spray volatile material such as insecticide onto the surface of the oven. | ~ | ~ | | |
| | Do not store flammable materials in the oven. Take special care when heating dishes or drinks that contain alcohol as alcohol vapours may contact a hot part of the oven. | ~ | | ✓ | ~ |
| * | Keep children away from the door when opening or closing it as they may bump themselves on the door or catch their fingers in the door. | ✓ | √ | ~ | ~ |
| * | warning: Microwave heating of beverages can result in delayed eruptive boiling, therefore care must be taken when handling the container; To prevent this situation ALWAYS allow a standing time of at least 20 seconds after the oven has been switched off so that the temperature can equalize. Stir during heating, if necessary, and ALWAYS stir after heating. In the event of scalding, follow these FIRST AID instructions: • Immerse the scalded area in cold water for at least 10 minutes. • Cover with a clean, dry dressing. • Do not apply any creams, oils or lotions. | | | | |
| | Do not put the tray or rack in water shortly after cooking because it may cause breakage or damage | | | | ~ |

English - 9







| 5 | Do not operate the microwave oven for deep fat frying because the oil temperature cannot be controlled. This could result in a sudden boil over of the hot liquid. | ~ | | | ~ |
|---|--------------------------------------------------------------------------------------------------------------------------------------------------------------------|---|---|---|----------|
| | | | | | |
| 4 | A CAUTION | Δ | À | | Æ |
| 7 | Only use utensils that are suitable for use in microwave ovens; DO NOT use any metallic containers, Dinnerware with gold or silver trimmings, | ~ | | ~ | ~ |

| A | CAUTION | | A | | K |
|----------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|----------|----------|----------|----------|
| * | Only use utensils that are suitable for use in microwave ovens; DO NOT use any metallic containers, Dinnerware with gold or silver trimmings, Skewers, forks, etc. Remove wire twist ties from paper or plastic bags. Reason: Electric arcing or sparking may occur and may damage the oven. | ✓ | | ✓ | ✓ |
| | Do not use your microwave oven to dry papers or clothes. | ~ | | ~ | ✓ |
| * | Use shorter times for smaller amounts of food to prevent overheating and burning food. | ✓ | | ✓ | ✓ |
| | Do not immerse the power cable or power plug in water and keep the power cable away from heat. | ✓ | ~ | | |
| | Eggs in their shell and whole hard-boiled eggs should not be heated in microwave ovens since they may explode, even after microwave heating has ended; Also do not heat airtight or vacuum-sealed bottles, jars, containers, nuts inshells, tomatoes etc. | | | ✓ | ✓ |
| | Do not cover the ventilation slots with cloth or paper. They may catch fire as hot air escapes from the oven. The oven may also overheat and switch itself off automatically, and will remain off until it cools sufficiently. | ~ | | ~ | |
| 8 | Always use oven mitts when removing a dish from the oven to avoid unintentional burns. | | | √ | |
| * | Stir liquids halfway during heating or after heating ends and allow the liquid stand at least 20 seconds after heating to prevent eruptive boiling. | | | √ | |

| * | Stand at arms length from the oven when opening the door to avoid getting scalded by escaping hot air or steam. | | | ✓ | |
|---|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|----------|----------|----------|----------|
| | Do not operate the microwave oven when it is empty. The microwave oven will automatically shut down for 30 minutes for safety purposes. We recommend placing a glass of water inside the oven at all times to absorb microwave energy in case the microwave oven is started accidentally. | ✓ | | | ✓ |
| * | Install the oven in compliance with the clearances stated in this manual. (See installing your microwave oven.) | ~ | | ✓ | |
| * | Take care when connecting other electrical appliances to sockets near the oven. | ~ | ~ | ✓ | |

PRECAUTIONS TO AVOID POSSIBLE EXPOSURE TO EXCESSIVE **MICROWAVE ENERGY. (MICROWAVE FUNCTION ONLY)**

Failure to observe the following safety precautions may result in harmful exposure to microwave energy.

- (a) Under no circumstances should any attempt be made to operate the oven with the door open or to tamper with the safety interlocks (door latches) or to insert anything into the safety interlock holes.
- (b) Do NOT place any object between the oven door and front face or allow food or cleaner residues to accumulate on sealing surfaces. Ensure that the door and door sealing surfaces are kept clean by wiping after use first with a damp cloth and then with a soft dry cloth.
- (c) Do NOT operate the oven if it is damaged until it has been repaired by a qualified microwave service technician trained by the manufacturer. It is particularly important that the oven door closes properly and that there is no damage to the:
 - (1) door (bent)
 - (2) door hinges (broken or loose)
 - (3) door seals and sealing surfaces
- (d) The oven should not be adjusted or repaired by anyone other than a properly qualified microwave service technician trained by the manufacturer.

English - 10







Samsung will charge a repair fee for replacing an accessory or repairing a cosmetic defect if the damage to the unit and/or damage to or loss of the accessory was caused by the customer. Items this stipulation covers include:

- (a) A Dented. Scratched. or Broken Door, Handle, Out-Panel, or Control Panel.
- (b) A Broken or missing Tray, Guide Roller, Coupler, or Wire Rack.
- Use this appliance only for its intended purpose as described in this
 instruction manual. Warnings and Important Safety Instructions in this
 manual do not cover all possible conditions and situations that may occur.
 It is your responsibility to use common sense, caution, and care when
 installing, maintaining, and operating your appliance.
- Because these following operating instructions cover various models, the characteristics of your microwave oven may differ slightly from those described in this manual and not all warning signs may be applicable. If you have any questions or concerns, contact your nearest service centre or find help and information online at www.samsung.com.
- This microwave oven is supposed for heating food. It is intended for domestic home-use only. Do not heat any type of textiles or cushions filled with grains, which could cause burns and fire. The manufacturer cannot be held liable for damage caused by improper or incorrect use of the appliance.
- Failure to maintain the oven in a clean condition could lead to deterioration of the surface that could adversely affect the life of the appliance and possible result in a hazardous situation.



(WASTE ELECTRICAL & ELECTRONIC EQUIPMENT)

CORRECT DISPOSAL OF THIS PRODUCT

(Applicable in countries with separate collection systems)


This marking on the product, accessories or literature indicates that the product and its electronic accessories (e.g. charger, headset, USB cable) should not be disposed of with other household waste at the end of their working life. To prevent possible harm to the environment or human health from uncontrolled waste disposal, please separate these items from other types of waste and recycle them responsibly to promote the sustainable reuse of material resources.

Household users should contact either the retailer where they purchased this product, or their local government office, for details of where and how they can take these items for environmentally safe recycling.

Business users should contact their supplier and check the terms and conditions of the purchase contract. This product and its electronic accessories should not be mixed with other commercial wastes for disposal.

oven features

OVEN (GE81KR*-1, GE81KR*-2, GE81KR*-3)



- **1.** DOOR
- 2. VENTILATION HOLES
- 3. GRILL
- 4. LIGHT
- 5. VARIABLE COOKING POWER CONTROL KNOB
- 6. TIMER KNOB

- 7. DOOR LATCHES
- 8. TURNTABLE
- 9. COUPLER
- 10. ROLLER RING
- 11. SAFETY INTERLOCK HOLES
- 12. OPEN DOOR PUSH BUTTON











OVEN (GE81MR**)



- 1. DOOR
- 2. VENTILATION HOLES
- 3. GRILL
- 4. LIGHT
- 5. VARIABLE COOKING POWER CONTROL KNOB
- 6. TIMER KNOB

- 7. DOOR LATCHES
- 8. TURNTABLE
- 9. COUPLER
- 10. ROLLER RING
- 11. SAFETY INTERLOCK HOLES
- 12. OPEN DOOR PUSH BUTTON

OVEN (GE81AR*)




- **1.** DOOR
- 2. VENTILATION HOLES
- 3. GRILL
- 4. LIGHT
- **5.** VARIABLE COOKING POWER CONTROL KNOB
- 6. TIMER KNOB

- 7. DOOR LATCHES
- 8. TURNTABLE
- 9. COUPLER
- 10. ROLLER RING
- 11. SAFETY INTERLOCK HOLES






CONTROL PANEL (GE81KR*-1, GE81KR*-2, GE81KR*-3)



- 1. DEFROST
- 2. COOKING POWER CONTROL KNOB
- 3. TIMER KNOB

- 4. GRILL
- 5. COMBI
- 6. INSTANT REHEAT

CONTROL PANEL (GE81MR)**



1. DEFROST

- 4. GRILL
- 2. COOKING POWER CONTROL KNOB 5. COMBI

3. TIMER KNOB

6. INSTANT REHEAT










CONTROL PANEL (GE81AR*)



1. DEFROST

- 4. GRILL
- 2. COOKING POWER CONTROL KNOB 5. COMBI

3. TIMER KNOB

6. INSTANT REHEAT

ACCESSORIES

Depending on the model that you have purchased, you are supplied with several accessories that can be used in a variety of ways.

| | Roller ring, to be placed in the centre of the oven. Purpose: The roller ring supports the turntable. | |
|---------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|--|
| (\$0) | 2. Turntable, to be placed on the roller ring with the centre fitting to the coupler. Purpose: The turntable serves as the main cooking surface; it can be easily removed for cleaning. | |
| | 3. Grill rack, to be placed on the turntable. Purpose: The metal rack can be used in grill and combination cooking. | |

DO NOT operate the microwave oven without the roller ring and turntable.





oven use


COOKING/REHEATING

The following procedure explains how to cook or reheat food.

Always check your cooking settings before leaving the oven unattended.

First, place the food in the centre of the turntable. Then, close the door.

| A) 4500 900 100 100 100 100 100 100 100 100 1 | | he power level to maximum by turning COOKING VER CONTROL knob. (MAXIMUM POWER: 800 W) |
|-----------------------------------------------|----------|------------------------------------------------------------------------------------------|
| 0 ,,0 | 2. Set 1 | he time by turning TIMER knob. |
| 50 40 30 10 9 8 9 9 | Res | ult: The oven light comes on and the turntable starts rotating. |





POWER LEVELS

You can choose among the power levels below.

| Power level | Out | tput |
|-----------------|-------|--------|
| Power level | MWO | GRILL |
| HIGH | 800 W | - |
| MEDIUM HIGH | 600 W | - |
| MEDIUM | 450 W | - |
| MEDIUM LOW | 300 W | - |
| DEFROST | 180 W | - |
| LOW / KEEP WARM | 100 W | - |
| GRILL | - | 1100 W |
| COMBII | 300 W | 1100 W |
| COMBI II | 450 W | 1100 W |
| COMBI III | 600 W | 1100 W |

If you select higher power level, the cooking time must be decreased.

If you select lower power level, the cooking time must be increased.

ADJUSTING THE COOKING TIME



Adjust the remaining cooking time by rotating the **TIMER** knob.









STOPPING THE COOKING

You can stop cooking at any time to check the food.

| | 1. | To stop temporarily; Open the door. Result: Cooking stops. To resume cooking, close the door. |
|------------------------------------------|----|------------------------------------------------------------------------------------------------|
| 00 1 2 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 | 2. | To stop completely; Turn the TIMER knob to "0". |

MANUAL DEFROSTING FOOD

The defrost feature enables you to defrost meat, poultry, fish or bread/cake. First, place the frozen food in the centre of the turntable and close the door.

| 200 45000 000 200 000 000 200 000 000 | 1. | Turn the COOKING POWER CONTROL knob to ($\mathring{\delta}\mathring{\delta}$). |
|---------------------------------------------|----|------------------------------------------------------------------------------------------------|
| 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 | 2. | Turn the TIMER knob to select the appropriate weight. Result: Defrosting begins. |

Use only recipients that are microwave-safe.

USING THE INSTANT REHEAT/COOK FEATURE

First, place the food in the center of the turntable and close the door.

| A 455W 600 101 101 101 101 101 101 101 101 101 | 1. | Turn the COOKING POWER CONTROL knob to max power. |
|------------------------------------------------|----|-----------------------------------------------------------------------------------------------|
| 0 1 2 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 | 2. | Turn the TIMER knob to select instant reheat. (Drinks or Soup/Sauce, Fresh Vegetables) |

Use only recipients that are microwave-safe.

INSTANT REHEAT/COOK SETTINGS

Here are a few tips and recommendations to be followed when cooking or reheating food with whe instant reheat and cooking feature.

| Food | Power | Serving Size | Cooking Time | Standing Time |
|-------------------------|-------|--------------|--------------|---------------|
| Drinks | 800 W | 150 ml | 1 min 10 sec | 1-2 min. |
| Soup/Sauce (Chilled) | 800 W | 200-250 ml | 2 min 50 sec | 2-3 min. |
| Fresh Vegetables | 800 W | 300-350 g | 5 min | 3 min. |


GRILLING

The grill enables you to heat and brown food quickly, without using microwaves. To this aim, a grill rack is supplied with your microwave oven.

| AD 0500 050 050 050 050 050 050 050 050 0 | 1. | Preheat the grill to the required temperature, by turning the COOKING POWER CONTROL knob to Grill ($\mathbb{U}\mathbb{U}$) and turning the TIMER knob to the appropriate. |
|-------------------------------------------|----|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| | 2. | Open the door and place the food on the rack. |
| © 1 2 5 5 5 5 5 5 5 5 5 5 5 5 5 5 5 5 5 5 | 3. | Select the appropriate cooking time by the turning the TIMER knob. (Example : 60 minutes) Result: Cooking start. |

- Do not worry if the heater turns off and on while grilling. This system is designed to prevent overheating of the oven.
- Always use oven gloves when touching the dishes in the oven, as they will be very hot.









COMBINING MICROWAVES AND THE GRILL

You can also combine microwave cooking with the grill, to cook quickly and brown at the same time.

- **ALWAYS** use microwave-safe and oven-proof cookware. Glass or ceramic dishes are ideal as they allow the microwaves to penetrate the food evenly.
- **ALWAYS** use oven gloves when touching the recipients in the oven, as they will be very hot.

| | 1. | Open the oven door by pushing the large button in the bottom right-hand corner of the control panel. Place the food on the rack and the rack on the turntable. Close the door. |
|-------------------------------------------|----|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| 40 45000 000 000 000 000 000 000 000 000 | 2. | Turn the COOKING POWER CONTROL knob to the appropriate power Level (恐帆, 蛩帆, 蛩帆). |
| 0 1 2 5 5 5 5 5 5 5 5 5 5 5 5 5 5 5 5 5 5 | 3. | Turn the TIMER knob to select the appropriate time. (Example : 60 minutes) Result: Cooking start. |

The maximum microwave power for the combined microwave and grill mode is 600 W.

CHOOSING THE ACCESSORIES



Use microwave-safe recipients; do not use plastic containers, dishes, paper cups, towels, etc.

If you wish to select the combined cooking mode (grill and microwave), use only dishes that are microwave-safe and oven-proof.

For further details on suitable cookware and utensils, refer to the cookware guide on page 17-18.

cookware guide

To cook food in the microwave oven, the microwaves must be able to penetrate the food, without being reflected or absorbed by the dish used.

Care must therefore be taken when choosing the cookware. If the cookware is marked microwave-safe, you do not need to worry.

The following table lists various types of cookware and indicates whether and how they should be used in a microwave oven.

| Cookware | Microwave- safe | Comments |
|-----------------------------------------------------|--------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Aluminum foil | √ X | Can be used in small quantities to protect areas against overcooking. Arcing can occur if the foil is too close to the oven wall or if too much foil is used. |
| Browning plate | 1 | Do not preheat for more than eight minutes. |
| China and earthenware | 1 | Porcelain, pottery, glazed earthenware and bone china are usually suitable, unless decorated with a metal trim. |
| Disposable polyester cardboard dishes | 1 | Some frozen foods are packaged in these dishes. |
| Fast-food | | |
| packaging | | |
| Polystyrene cups containers | 1 | Can be used to warm food. Overheating may cause the polystyrene to melt. |
| Paper bags or newspaper | Х | May catch fire. |
| Recycled paper or metal trims | Х | May cause arcing. |

(continued)









| Cookware | Microwave- safe | Comments |
|-------------------------------------------------|--------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------|
| Glassware | | |
| Oven-to-table ware | 1 | Can be used, unless decorated with a metal trim. |
| Fine glassware | ✓ | Can be used to warm foods or liquids. Delicate glass may break or crack if heated suddenly. |
| Glass jars | 1 | Must remove the lid. Suitable for warming only. |
| Metal | | |
| Dishes | × | May cause arcing or fire. |
| Freezer bag twist ties | × | |
| Paper | | |
| Plates, cups, napkins and Kitchen paper | ✓ | For short cooking times and warming. Also to absorb excess moisture. |
| Recycled paper | × | May cause arcing. |
| Plastic | | |
| Containers | ✓ | Particularly if heat-resistant thermoplastic. Some other plastics may warp or discolour at high temperatures. Do not use Melamine plastic. |
| Cling film | ✓ | Can be used to retain moisture. Should not touch the food. Take care when removing the film as hot steam will escape. |
| Freezer bags | √ X | Only if boilable or oven-proof. Should not be airtight. Prick with a fork, if necessary. |
| Wax or grease- proof paper | 1 | Can be used to retain moisture and prevent spattering. |

: Recommended

: Use Caution

x: Unsafe

cooking guide

MICROWAVES

Microwave energy actually penetrates food, attracted and absorbed by its water, fat and sugar content.

The microwaves cause the molecules in the food to move rapidly. The rapid movement of these molecules creates friction and the resulting heat cooks the food.

COOKING

Cookware for microwave cooking:

Cookware must allow microwave energy to pass through it for maximum efficiency. • Microwaves are reflected by metal, such as stainless steel, aluminium and copper, but they can penetrate through ceramic, glass, porcelain and plastic as well as paper and wood. So food must never be cooked in metal containers.

Food suitable for microwave cooking:

Many kinds of food are suitable for microwave cooking, including fresh or frozen vegetables, fruit, pasta, rice, grains, beans, fish, and meat. Sauces, custard, soups, steamed puddings, preserves, and chutneys can also be cooked in a microwave oven. Generally speaking, microwave cooking is ideal for any food that would normally be prepared on a hob. Melting butter or chocolate, for example (see the chapter with tips, techniques and hints).

Covering during cooking

To cover the food during cooking is very important, as the evaporated water rises as steam and contributes to cooking process. Food can be covered in different ways: e.g. with a ceramic plate, plastic cover or microwave suitable cling film.

Standing times

After cooking is over food the standing time is important to allow the temperature to even out within the food.









Cooking guide for frozen vegetables

Use a suitable glass pyrex bowl with lid. Cook covered for the minimum time - see table. Continue cooking to get the result you prefer.

Stir twice during cooking and once after cooking. Add salt, herbs or butter after cooking. Cover during standing time.

| Food | Serving Size | Power | Time (min.) | | |
|---------------------------------------|--------------------------------------|--------------------------------------------------------------------|-------------------|--|--|
| Spinach | 150 g | 600 W | 4½-5½ | | |
| | Instructions Add 15 ml (1 tbsp) c | old water. Stand for 2- | 3 minutes. | | |
| Broccoli | 300 g | 600 W | 9-10 | | |
| | Instructions Add 30 ml (2 tbsp) o | old water. Stand for 2- | 3 minutes. | | |
| Peas | 300 g | 600 W | 71/2-81/2 | | |
| Green Beans | Add 15 ml (1 tbsp) c | old water. Stand for 2-3 | 3 minutes. 8-9 | | |
| | Instructions Add 30 ml (2 tbsp) c | Instructions Add 30 ml (2 tbsp) cold water. Stand for 2-3 minutes. | | | |
| Mixed | 300 g | 600 W | 71/2-81/2 | | |
| Vegetables (Carrots/Peas/ Corn) | Instructions Add 15 ml (1 tbsp) c | Instructions Add 15 ml (1 tbsp) cold water. Stand for 2-3 minutes. | | | |
| Mixed | 300 g | 600 W | 8-9 | | |
| Vegetables (Chinese Style) | Instructions Add 15 ml (1 tbsp) c | old water. Stand for 2- | 3 minutes. | | |

Cooking Guide for rice and pasta

Rice: Use a large glass pyrex bowl with lid - rice doubles in volume during

cooking. Cook covered.

After the cooking time is over, stir before standing time and salt or add

herbs and butter.

Remark: the rice may not have absorbed all water after the cooking time

is finished.

Pasta: Use a large glass pyrex bowl. Add boiling water, a pinch of salt and stir

well. Cook uncovered.

Stir occasionally during and after cooking. Cover during standing time

and drain thoroughly afterwards.

| Food | Serving Size | Power | Time (min.) |
|--------------------|---------------------|-------------------------|-------------|
| White Rice | 250 g | 800 W | 16-17 |
| (Parboiled) | Instructions | | |
| | Add 500 ml cold wat | er. Stand for 5 minutes | S. |
| Brown Rice | 250 g | 800 W | 21-22 |
| (Parboiled) | Instructions | | |
| | Add 500 ml cold wat | er. Stand for 5 minutes | S. |
| Mixed Rice | 250 g | 800 W | 17-18 |
| (Rice + Wild Rice) | Instructions | | |
| | Add 500 ml cold wat | er. Stand for 5 minutes | S. |
| Mixed Corn | 250 g | 800 W | 18-19 |
| (Rice + Grain) | Instructions | | |
| | Add 400 ml cold wat | er. Stand for 5 minutes | S. |
| Pasta | 250 g | 800 W | 11-12 |
| | Instructions | | |
| | Add 1000 ml hot wa | ter. Stand for 5 minute | S. |









Cooking Guide for fresh vegetables

Use a suitable glass pyrex bowl with lid. Add 30-45 ml cold water (2-3 tbsp) for every 250 g unless another water quantity is recommended – see table. Cook covered for the minimum time – see table. Continue cooking to get the result you prefer. Stir once during and once after cooking. Add salt, herbs or butter after cooking. Cover during a standing time of 3 minutes.

<u>Hint:</u> Cut the fresh vegetables into even sized pieces. The smaller they are cut, the quicker they will cook.

| | - | | | | | |
|------------------|-------------------------|---------------------------|-----------------------|--|--|--|
| Food | Serving Size | Power | Time (min.) | | | |
| Broccoli | 250 g | 800 W | 4-41/2 | | | |
| | 500 g | | 7-71/2 | | | |
| | Instructions | | | | | |
| | Prepare even sized flo | orets. Arrange the sten | ns to the centre. | | | |
| | Stand for 3 minutes. | | | | | |
| Brussels Sprouts | 250 g | 800 W | 51/2-61/2 | | | |
| | Instructions | | | | | |
| | Add 60-75 ml (4-5 tb | sp) water. Stand for 3 | minutes. | | | |
| Carrots | 250 g | 800 W | 4½-5 | | | |
| | Instructions | | | | | |
| | Cut carrots into even | sized slices. Stand for | 3 minutes. | | | |
| Cauliflower | 250 g | 800 W | 5-51/2 | | | |
| | 500 g | | 81/2-9 | | | |
| | Instructions | Instructions | | | | |
| | Prepare even sized fle | orets. Cut big florets in | to halves. Arrange | | | |
| | stems to the centre. | Stand for 3 minutes. | | | | |
| Courgettes | 250 g | 800 W | 3½-4 | | | |
| | Instructions | | | | | |
| | Cut courgettes into s | lices. Add 30 ml (2 tbs | p) water or a knob of | | | |
| | butter. Cook until just | tender. Stand for 3 m | inutes. | | | |
| Egg Plants | 250 g | 800 W | 3½-4 | | | |
| | Instructions | | | | | |
| | Cut egg plants into s | mall slices and sprinkle | e with 1 tbsp lemon | | | |
| | juice. Stand for 3 min | utes. | | | | |

| Food | Serving Size | Power | Time (min.) | |
|----------------|-----------------------------------------------------------|------------------------------------------------|----------------------|--|
| Leeks | 250 g | 800 W | 4½-5 | |
| | Instructions | | | |
| | Cut leeks into thick s | lices. Stand for 3 minu | tes. | |
| Mushrooms | 125 g | 800 W | 1½-2 | |
| | 250 g | | 3-3½ | |
| | Instructions | | | |
| | Prepare small whole | or sliced mushrooms. | Do not add any | |
| | water. Sprinkle with leading before serving. | emon juice. Spice with Stand for 3 minutes. | salt and pepper. | |
| Onions | 250 g | 800 W | 5½-6 | |
| | Instructions | | | |
| | Cut onions into slices | or halves. Add only 1 | 5 ml (1 tbsp) water. | |
| | Stand for 3 minutes. | | | |
| Pepper | 250 g | 800 W | 4½-5 | |
| | Instructions | | | |
| | Cut pepper into small | I slices. Stand for 3 mi | nutes. | |
| Potatoes | 250 g | 800 W | 4-5 | |
| | 500 g | | 71/2-81/2 | |
| | Instructions | | | |
| | Weigh the peeled potatoes and cut them into similar sized | | | |
| | halves or quarters. S | tand for 3 minutes. | | |
| Turnip Cabbage | 250 g | 800 W | 5-5½ | |
| | Instructions | | | |
| | Cut turnip cabbage into small cubes. Stand for 3 minutes. | | | |









REHEATING

Your microwave oven will reheat food in a fraction of the time that conventional ovens hobs normally take.

Use the power levels and reheating times in the following chart as a guide. The times in the chart consider liquids with a room temperature of about +18 to +20 °C or a chilled food with a temperature of about +5 to +7 °C.

Arranging and covering

Avoid reheating large items such as joint of meat - they tend to overcook and dry out before the centre is piping hot. Reheating small pieces will be more successful.

Power levels and stirring

Some foods can be reheated using 800 W power while others should be reheated using 600 W. 450 W or even 300 W.

Check the tables for guidance. In general, it is better to reheat food using a lower power level, if the food is delicate, in large quantities, or if it is likely to heat up very quickly (mince pies, for example).

Stir well or turn food over during reheating for best results. When possible, stir again before serving

Take particular care when heating liquids and baby foods. To prevent eruptive boiling of liquids and possible scalding, stir before, during and after heating. Keep them in the microwave oven during standing time. We recommend putting a plastic spoon or glass stick into the liquids. Avoid overheating (and therefore spoiling) the food

It is preferable to underestimate cooking time and add extra heating time, if necessary.

Heating and standing times

When reheating food for the first time, it is helpful to make a note of the time taken – for future reference.

Always make sure that the reheated food is piping hot throughout.

Allow food to stand for a short time after reheating - to let the temperature even out. The recommended standing time after reheating is 2-4 minutes, unless another time is recommended in the chart.

Take particular care when heating liquids and baby food. See also the chapter with the safety precautions.

REHEATING LIQUIDS

Always allow a standing time of at least 20 seconds after the oven has been switched off to allow the temperature to even out. Stir during heating, if necessary, and ALWAYS stir after heating. To prevent eruptive boiling and possible scalding, you should put a spoon or glass stick into the beverages and stir before, during and after heating.

Reheating Liquids and Food

Use the power levels and times in this table as a guide lines for reheating.

| Food | Serving Size | Power | Time (min.) |
|-----------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|------------------------|--------------|
| Drinks (Coffee, Tea and Water) | 150 ml (1 cup) 250 ml (1 mug) | 800 W | 1-1½ 1½-2 |
| · | Instructions Pour into cup and reheat uncovered. Put cup/ mug in the centre of turntable. Keep in microwave oven during standing time and stir well. Stand for 1-2 minutes. | | |
| Soup (Chilled) | 250 g | 800 W | 3-31/2 |
| | Instructions Pour into a deep ceramic plate. Cover with pierced cling film. Stir well after reheating. Stir again before serving. Stand for 2-3 minutes. | | |
| Stew (Chilled) | 350 g | 600 W | 51/2-61/2 |
| Pasta with Sauce (Chilled) | Instructions Put stew in a deep ceramic plate. Cover with pierced cling film. Stir occasionally during reheating and again before standing and serving. Stand for 2-3 minutes. 350 g 600 W 4½-5½ Instructions Put pasta (e.g. spaghetti or egg noodles) on a flat ceramic plate. Cover with microwave cling film. Stir before serving. Stand for 3 minutes. | | |
| | | | |
| Filled Pasta with | 350 g | 600 W | 5-6 |
| Sauce (Chilled) | Instructions Put filled pasta (e.g. ravioli, tortellini) in a deep ceramic plate. Cover with plastic lid. Stir occasionally during reheating and again before standing and serving. Stand for 3 minutes. | | |
| Plated Meal | 350 g | 600 W | 51/2-61/2 |
| (Chilled) | | hilled components on a | |









REHEATING BABY FOOD

BABY FOOD: Empty into a deep ceramic plate. Cover with plastic lid. Stir well after reheating!

Let stand for 2-3 minutes before serving. Stir again and check the temperature. Recommended serving temperature: between 30-40 °C.

BABY MILK: Pour milk into a sterilised glass bottle. Reheat uncovered. Never heat a baby's bottle with teat on, as the bottle may explode if overheated. Shake well before standing time and again before serving! Always carefully check the temperature of baby milk or food before giving it to the baby. Recommended serving temperature: ca. 37 °C.

REMARK:

Baby food particularly needs to be checked carefully before serving to prevent burns. Use the power levels and times in the next table as a guide lines for reheating.

Reheating baby food and milk

Use the power levels and times in this table as guide lines for reheating.

| Food | Serving Size | Power | Time | | | |
|-----------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-------------------------|-------------------|--|--|--|
| Baby Food | 190 g | 190 g 600 W | | | | |
| (Vegetables + | Instructions | | | | | |
| Meat) | | leep plate. Cook cover | | | | |
| | 0. | stir well and check the | temperature | | | |
| | carefully. Stand for 2- | ·3 minutes. | | | | |
| Baby Porridge | 190 g 600 W 20 sec. | | | | | |
| (Grain + Milk + | Instructions Empty into ceramic deep plate. Cook covered. Stir after cooking | | | | | |
| Fruit) | | | | | | |
| | time. Before serving, stir well and check the temperature | | | | | |
| | carefully. Stand for 2- | 3 minutes. | | | | |
| Baby Milk | 100 ml | 300 W | 30-40 sec. | | | |
| | 200 ml | | 50 sec. to 1 min. | | | |
| | Instructions | | | | | |
| | Stir or shake well and pour into a sterilized glass bottle. Place into the centre of turn-table. Cook uncovered. Shake well and stand for at least 3 minutes. Before serving, shake well and check the temperature carefully. Stand for 2-3 minutes. | | | | | |
| | | | | | | |
| | | | | | | |
| | | | | | | |

MANUAL DEFROSTING

Microwaves are an excellent way of defrosting frozen food. Microwaves gently defrost frozen food in a short period of time. This can be of great advantage, if unexpected quests suddenly show up.

Frozen poultry must be thoroughly thawed before cooking. Remove any metal ties and take it out of any wrapping to allow thawed liquid to drain away.

Put the frozen food on a dish without cover. Turn over half way, drain off any liquid and remove any giblets as soon as possible.

Check the food occasionally to make sure that it does not feel warm.

If smaller and thinner parts of the frozen food start to warm up, they can be shield by wrapping very small strips of aluminium foil around them during defrosting.

Should poultry start to warm up on the outer surface, stop thawing and allow it to stand for 20 minutes before continuing.

Leave the fish, meat and poultry to stand in order to complete defrosting. The standing time for complete defrosting will vary depending on the quantity defrosted. Please refer to the table below.

Hint: Flat food defrosts better than thick and smaller quantities need less time than bigger ones. Remember this hint while freezing and defrosting food.

For defrosting of frozen food with a temperature of about -18 to -20 °C, use the following table as a guide.

| Food | Serving Size | Power | Time (min.) | |
|-------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------|-------|----------------|--|
| Meat | | | | |
| Minced Beef | 250 g 500 g | 180 W | 6½-7½ 10-12 | |
| Pork Steaks | 250 g | 180 W | 7½-8½ | |
| | Instructions Place the meat on a flat ceramic plate. Shield thinner edges with aluminium foil. Turn over after half of defrosting time! Stand for 5-25 minutes. | | | |







| | | _ | |
|-------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-------|--------------|
| Food | Serving Size | Power | Time (min.) |
| Poultry | | | |
| Chicken Pieces | 500 g (2 pcs) | 180 W | 14½-15½ |
| Whole Chicken | 900 g | 180 W | 28-30 |
| | Instructions First, put chicken pieces first skin-side down, whole chicken first breast-side-down on a flat ceramic plate. Shield the thinner parts like wings and ends with aluminium foil. Turn over after half of defrosting time! Stand for 15-40 minutes. | | |
| Fish | | | |
| Fish Fillets | 250 g (2 pcs) 400 g (4 pcs) | 180 W | 6-7 12-13 |
| | Instructions | | |
| | Put frozen fish in the middle of a flat ceramic plate. Arrange the thinner parts under the thicker parts. Shield narrow ends with aluminium foil. Turn over after half of defrosting time! Stand for 5-15 minutes. | | |
| Fruits | | | |
| Berries | 250 g | 180 W | 6-7 |
| | Instructions Distribute fruits on a flat, round glass dish (with a large diameter). Stand for 5-10 minutes. | | |
| Bread | | | |
| Bread Rolls (Each about 50 g) | 2 pcs 4 pcs | 180 W | ½-1 2-2½ |
| Toast/Sandwich | 250 g | 180 W | 4½-5 |
| German Bread 500 g 180 v | | | 8-10 |
| (Wheat + Rye Flour) | Flour) Instructions Arrange rolls in a circle or bread horizontally on kitchen paper in the middle of turntable. Turn over after half of defrosting time! Stand for 5-20 minutes. | | |

GRILL

The grill-heating element is located underneath the ceiling of the cavity. It operates while the door is closed and the turntable is rotating. The turntable's rotation makes the food brown more evenly. Preheating the grill for 3-4 minutes will make the food brown more quickly.

Cookware for grilling:

Should be flameproof and may include metal. Do not use any type of plastic cookware, as it can melt.

Food suitable for grilling:

Chops, sausages, steaks, hamburgers, bacon and gammon rashers, thin fish portions, sandwiches and all kinds of toast with toppings.

Important remark:

Whenever the grill only mode is used, make sure that the grill-heating element is under the ceiling in the horizontal position and not on the back-wall in the vertical position. Please remember that food must be placed on the high rack, unless another instruction is recommended.

MICROWAVE + GRILL

This cooking mode combines the radiant heat that is coming from the grill with the speed of microwave cooking. It operates only while the door is closed and the turntable is rotating. Due to the rotation of the turntable, the food browns evenly. Three combination modes are available with this model: 600 W + Grill, 450 W + Grill and 300 W + Grill.

Cookware for cooking with microwave + grill

Please use cookware that microwaves can pass through. Cookware should be flameproof. Do not use metal cookware with combination mode. Do not use any type of plastic cookware, as it can melt.

Food suitable for microwave + grill cooking:

Food suitable for combination mode cooking include all kinds of cooked food which need reheating and browning (e.g. baked pasta), as well as foods which require a short cooking time to brown the top of the food. Also, this mode can be used for thick food portions that benefit from a browned and crispy top (e.g. chicken pieces, turning them over half way through cooking). Please refer to the grill table for further details.

Important remark:

Whenever the combination mode (microwave + grill) is used, make sure that the grill heating element is under the ceiling in the horizontal position and not on the back-wall in the vertical position. The food should be placed on the high rack, unless another instruction is recommended. Otherwise it has to be placed directly on the turntable. Please refer to the instructions in the following chart.

The food must be turned over, if it is to be browned on both sides.

English - 23







Grill Guide for frozen food

Use the power levels and times in this table as guide lines for grilling.

| Frozen Food | Serving | Power | 1 step (min.) | 2 step (min.) |
|-----------------------|-------------------------------------------------------------------------------------------------------------------------------------|---------------|--------------------|---------------|
| 11020111000 | Size | 1 OWCI | 1 Step (IIIII.) | 2 Stop (min.) |
| Bread Rolls | | MW + Grill | 300 W + Grill | Grill only |
| (Each ca. 50 g) | 2 pcs | | 1-1½ | 1-2 |
| | 4 pcs | | 2-21/2 | 1-2 |
| | Instructions | | | |
| | | | Grill the second s | |
| D | · · | | d for 2-5 minutes. | |
| Baguettes + | 250-300 g (2 pcs) | 450 W + Grill | 8-9 | - |
| Topping (Tomatoes, | Instructions | | | |
| Cheese, Ham, | Put 2 frozen baguettes side by side on the rack. After grilling. | | | |
| Mushrooms) | Stand for 2-3 minutes. | | | |
| Gratin | 400 g | 450 W + Grill | 13-14 | - |
| (Vegetables or | Instructions | | | |
| Potatoes) | Put frozen gratin into a small, round glass pyrex dish. Put the dish on the rack. After grilling. Stand for 2-3 minutes. | | | |
| | | | | |
| Pasta | 400 g | MW + Grill | 300 W + Grill | Grill only |
| (Cannelloni, | | | 18-19 | 1-2 |
| Macaroni, Lasagne) | Instructions | | | |
| Lasagne | Put frozen pasta into a small flat rectangular glass pyrex dish. Put the dish directly on the turntable. After grilling. Stand for | | | |
| | 2-3 minutes. | | | |
| Chicken | 250 g | 450 W + Grill | 5-5½ | 3-31/2 |
| Nuggets | Instructions | I. | | |
| | Put chicken nuggets on the rack. Turn over after first time. | | | |
| Oven Chips | 250 g | 450 W + Grill | 9-11 | 4-5 |
| | Instructions | | | |
| | Put oven chips evenly on baking paper on the rack. | | | |

Grill Guide for fresh food

Preheat the grill with the grill-function for 3-4 minutes.

Use the power levels and times in this table as guide lines for grilling.

| Fresh Food | Serving Size | Power | 1 step (min.) | 2 step (min.) |
|------------------------------|------------------------------------------------------------------------------------------------------------------------------------------|---------------|---------------|---------------|
| Toast Slices | 4 pcs (each 25 g) | Grill only | 6-8 | 4-51/2 |
| | Instructions Put the toast slices side by side on the rack. | | | |
| Bread Rolls | 2-4 pieces | Grill only | 2-3 | 2-3 |
| (Already Baked) | Instructions Put bread rolls first with the bottom side up in a circle directly on the turntable. | | | |
| Grilled | | MW + Grill | 300 W + Grill | Grill only |
| Tomatoes | 200 g (2 pcs) | | 4½-5½ | 2-3 |
| | 400 g (4 pcs) | | 7-8 | |
| | Instructions | | | |
| | Cut tomatoes into halves. Put some cheese on top. Arrange in a circle in a flat glass pyrex dish. Place it on the rack. | | | |
| Toast Hawaii | 2 pcs (300 g) | 450 W + Grill | 31/2-4 | - |
| (Ham, | Instructions | | | |
| Pineapple, Cheese Slices) | Toast the bread slices first. Put the toast with topping on the rack. Put 2 toasts opposite directly on the rack. Stand for 2-3 minutes. | | | |
| Baked Potatoes | 250 g | 600 W + Grill | 41/2-51/2 | - |
| | 500 g | | 8-9 | |
| | Instructions Cut potatoes into halves. Put them in a circle on the rack with the cut side to the grill. | | | |

English - 24







| Fresh Food | Serving Size | Power | 1 step (min.) | 2 step (min.) |
|-------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|---------------|---------------|---------------|
| Chicken Pieces | 450-500 g (2 pcs) | 300 W + Grill | 10-12 | 12-13 |
| | Instructions Prepare chicken pieces with oil and spices. Put them in a circle with the bones to the middle. Put 1 chicken piece not into the centre of the rack. Stand for 2-3 minutes. | | | |
| Lamb Chops/ | 400 g (4 pcs) | Grill only | 12-15 | 9-12 |
| Beef Steaks (Medium) | Instructions Brush the lamb chops with oil and spices. Lay them in a circle on the rack. After grilling. Stand for 2-3 minutes. | | | |
| Pork Steaks | | MW + Grill | 300 W + Grill | Grill only |
| | 250 g (2 pcs) | | 7-8 | 6-7 |
| | Instructions Brush the pork steaks with oil and spices. Lay them in a circle of the rack. After grilling. Stand for 2-3 minutes. | | | |
| Baked Apples | 1 apple (ca. 200 g) 2 apples (ca. 400 g) | 300 W + Grill | 4-4½ 6-7 | - |
| | Instructions Core the apples and fill them with raisins and jam. Put some almond slices on top. Put apples on a flat glass pyrex dish. Plac the dish directly on the turntable. | | | |
| Roast Chicken | | MW + Grill | 450 W + Grill | 300 W + Grill |
| | 1200 g | | 22-24 | 23-25 |
| | Instructions Brush chicken with oil and spices. Put chicken first breast side down, second breast side up on pyrex dish. Stand for 5 minutes after grilling. | | | |

TIPS AND TRICKS

MELTING BUTTER

Put 50 g butter into a small deep glass dish. Cover with plastic lid. Heat for 30-40 seconds using 800 W, until butter is melted.

MELTING CHOCOLATE

Put 100 g chocolate into a small deep glass dish.

Heat for 3-5 minutes, using 450 W until chocolate is melted.

Stir once or twice during melting. Use oven gloves while taking out!

MELTING CRYSTALLIZED HONEY

Put 20 g crystallized honey into a small deep glass dish.

Heat for 20-30 seconds using 300 W until honey is melted.

MELTING GELATINE

Lay dry gelatine sheets (10 g) for 5 minutes into cold water.

Put drained gelatine into a small glass pyrex bowl.

Heat for 1 minute using 300 W.

Stir after melting.

COOKING GLAZE/ICING (FOR CAKE AND GATEAUX)

Mix instant glaze (approximately 14 g) with 40 g sugar and 250 ml cold water.

Cook uncovered in a glass pyrex bowl for 3½ to 4½ minutes using 800 W, until glaze/ icing is transparent. Stir twice during cooking.

COOKING JAM

Put 600 g fruits (for example mixed berries) in a suitable sized glass pyrex bowl with lid. Add 300 g preserving sugar and stir well.

Cook covered for 10-12 minutes using 800 W.

Stir several times during cooking. Empty directly into small jam glasses with twist-off lids. Stand on lid for 5 minutes.

COOKING PUDDING

Mix pudding powder with sugar and milk (500 ml) by following the manufacturers instructions and stir well. Use a suitable sized glass pyrex bowl with lid. Cook covered for 61/2 to 71/2 minutes using 800 W.

Stir several times well during cooking.

BROWNING ALMOND SLICES

Spread 30 g sliced almonds evenly on a medium sized ceramic plate.

Stir several times during browning for 3½ to 4½ minutes using 600 W.

Let it stand for 2-3 minutes in the oven. Use oven gloves while taking out!

English - 25







troubleshooting

If you have any of the problems listed below try the solutions given.

This is normal.

- Condensation inside the oven.
- Air flow around the door and outer casing.
- Light reflection around the door and outer casing.
- Steam escaping from around the door or vents.

The oven does not start when you turn the TIMER knob.

Is the door completely closed?

The food is not cooked at all.

- Have you set the timer correctly?
- Is the door closed?
- Have you overloaded the electric circuit and caused a fuse to blow or a breaker to be triggered?

The food is either overcooked or undercooked.

- Was the appropriate cooking length set for the type of food?
- Was an appropriate power level chosen?

The oven causes interference with radios or televisions.

• Slight interference may be observed on televisions or radios when the oven is operating. This is normal. To solve this problem, install the oven away from televisions, radios and aerials.

The light bulb is not working.

• The Light bulb should not be replaced in person for safety reasons. Please contact nearest authorised Samsung customer care, to arrange for a qualified engineer to replace the bulb.

Sparking and cracking occur inside the oven (arcing).

- Have you used a dish with metal trimmings?
- Have you left a fork or other metal utensil inside the oven?
- Is aluminum foil too close to the inside walls?

Smoke and bad smell when initial operating.

• It's a temporary condition by new component heating. Smoke and smell will disappear completely after 10 minutes operation. To remove smell more quickly, please operate microwave oven with putting lemon formation or lemon juice in the cabinet.



If the above guidelines do not enable you to solve the problem, then contact your local SAMSUNG customer service centre.

Please have the following information read:

- The model and serial numbers, normally printed on the rear of the oven
- · Your warranty details
- A clear description of the problem

Then contact your local dealer or SAMSUNG aftersales service.

Подлежит использованию по назначению в нормальных условиях

Срок службы: 7 лет



Символ «не для пищевой продукции» применяется в соответствие с техническим регламентом Таможенного союза «О безопасности упаковки» 005/2011 и указывает на то, что упаковка данного продукта не предназначена для повторного использования и подлежит утилизации. Упаковку данного продукта запрещается использовать для хранения пищевой продукции.



Символ «петля Мебиуса» указывает на возможность утилизации упаковки. Символ может быть дополнен обозначением материала упаковки в виде цифрового и/или буквенного обозначения.









technical specifications

SAMSUNG strives to improve its products at all times. Both the design specifications and these user instructions are thus subject to change without notice.

| Model | GE81KR*-1, GE81KR*-2, GE81KR*-3, GE81MR**, GE81AR* | | |
|-------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------|--|--|
| Power source | 230 V ~ 50 Hz | | |
| Power consumption Microwave Grill Combined mode | 1200 W 1100 W 2300 W | | |
| Output power | 100 W / 800 W (IEC-705) | | |
| Operating frequency | 2450 MHz | | |
| Magnetron | OM75P (31) | | |
| Cooling method | Cooling fan motor | | |
| Dimensions (W x H x D) Outside | 489 x 275 x 380 mm (GE81KR*-1, GE81AR*) 489 x 275 x 376 mm (GE81KR*-2) 489 x 275 x 385 mm (GE81KR*-3) 489 x 275 x 375 mm (GE81MR**) | | |
| Oven cavity | 330 x 211 x 324 mm | | |
| Volume | 23 liter | | |
| Weight Net | 12.5 kg approx (GE81KR*-1, GE81KR*-2, GE81KR*-3, GE81AR*) 13.0 kg approx (GE81MR**) | | |

[※] оборудование класса I













Производитель: Samsung Electronics Co., Ltd / Самсунг Электроникс Ко., Лтд

Адрес производителя:

(Мэтан-донг) 129, Самсунг-ро, Йонгтонг-гу, Сувон-си, Гйонгги-до, Корея, 443-742

Адрес мощностей производства : ЛОТ 2, ЛЕБУХ 2, НОРС КЛАНГ СТРЕЙТС, ЭРИА 21, ИНДАСТРИАЛ ПАРК, 42000 ПОРТ КЛАНГ, СЕЛАНГОР ДАРУЛ ЭСАН, МАЛАЙЗИЯ

Страна производства: Малайзия

Импортер в России:

ООО «Самсунг Электроникс Рус Компани»

Адрес: 125009, г. Москва, Россия, ул. Воздвиженка 10, 4 этаж

В СЛУЧАЕ ВОЗНИКНОВЕНИЯ ВОПРОСОВ ИЛИ КОММЕНТАРИЕВ

| СТРАНА | ТЕЛЕФОН | ВЕБ-УЗЕЛ | |
|-------------|-----------------------------------------------|-----------------------------------------------------------------------------------|--|
| RUSSIA | 8-800-555-55-55 | www.samsung.com/ru/support | |
| GEORGIA | 0-800-555-555 | | |
| ARMENIA | 0-800-05-555 | | |
| AZERBAIJAN | 0-88-555-55-55 | www.samsung.com/support | |
| KAZAKHSTAN | 8-10-800-500-55-500(GSM: 7799, VIP care 7700) | | |
| UZBEKISTAN | 8-10-800-500-55-500 | | |
| KYRGYZSTAN | 8-10-800-500-55-500 | www.samsung.com/kz_ru/support | |
| TADJIKISTAN | 8-10-800-500-55-500 | | |
| MONGOLIA | 7-495-363-17-00 | , , | |
| BELARUS | 810-800-500-55-500 | www.samsung.com/support | |
| MOLDOVA | 0-800-614-40 | | |
| UKRAINE | 0-800-502-000 | www.samsung.com/ua/support (Ukrainian) www.samsung.com/ua_ru/support (Russian) | |

DE68-04284A-01



