

PCAN-USB Hub

All-in-one USB adapter for communication via CAN, RS-232, and USB

User Manual



Products taken into account

Product Name	Model	Item Number
PCAN-USB Hub		IPEH-002004

CANopen® and CiA® are registered community trade marks of CAN in Automation e.V.

All other product names mentioned in this document may be the trademarks or registered trademarks of their respective companies. They are not explicitly marked by "™" and "®".

© 2010 PEAK-System Technik GmbH

PEAK-System Technik GmbH
Otto-Roehm-Strasse 69
64293 Darmstadt
Germany

Phone: +49 (0)6151 8173-20
Fax: +49 (0)6151 8173-29

www.peak-system.com
info@peak-system.com

Issued 2010-04-14

Contents

1	Introduction	4
1.1	Properties at a Glance	4
1.2	Prerequisites for the operation	5
1.3	Scope of Supply	5
2	Installing the Software and the PCAN-USB Hub	6
3	Connectors on the PCAN-USB Hub	9
3.1	Upstream Port (USB Cable)	9
3.2	Power (Voltage Supply)	9
3.3	CAN	10
3.3.1	Supplying External Devices via the CAN Connector	11
3.4	RS-232	13
3.5	USB Ports (Downstream)	13
4	Operation	14
4.1	Status LEDs	14
4.2	Removing the Hub Safely	15
5	CAN Software	17
5.1	CAN Monitor PCAN-View for Windows	17
5.2	Linking Own Programs with PCAN-Light	19
6	Technical Specifications	20
Appendix A	CE Certificate	22
Appendix B	Quick Reference	23

1 Introduction

The PCAN-USB Hub provides several hardware interfaces via a USB connection. The device has connection facilities for one CAN bus, two serial RS-232 connections and two additional USB devices. Software interfaces exist for different operating systems, so programs can easily access a connected CAN bus.




Tip: At the end of this manual (Appendix B) you can find a [Quick Reference](#) with brief information about the installation and operation of the PCAN-USB Hub.

1.1 Properties at a Glance

- └ Aluminum casing
- └ USB 2.0 connection with a computer (upstream)
- └ Voltage supply via USB connector or via separate input possible (bus-/self-powered)
- └ 1 High-speed CAN channel (ISO 11898-2)
- └ CAN transfer rates up to 1 Mbit/s
- └ CAN specifications 2.0A and 2.0B
- └ CAN connection 9-pin D-Sub male, pin assignment according to specification CiA® 102
- └ 2 RS-232 interfaces via 9-pin D-Sub connectors
- └ 2 USB 2.0 downstream ports
- └ 5-Volt and external power supply at the CAN connector connectible by solder bridges, e.g. for external bus converter

- Device drivers and programming interfaces for operating systems Windows (from XP onwards) and Linux, for earlier Windows versions and other operating systems on request

 **Note:** This manual describes the use of PCAN-USB Hub with Windows. You can find CAN drivers for Linux and the corresponding application information on the provided CD in the directory branch `Develop` and on our website under www.peak-system.com/linux.

1.2 Prerequisites for the operation

- A vacant USB port at the computer (USB 2.0 recommended)
- Operating system Windows 7/Vista/XP (32-/64-bit) or Linux (32-/64-bit)

1.3 Scope of Supply

- PCAN-USB Hub incl. a fixed USB cable for the connection to the computer
- Mating connector for an external power supply
- CD with software (drivers, utilities), programming examples, and documentation

2 Installing the software and the PCAN-USB Hub

This chapter deals with the software setup for the PCAN-USB Hub under Windows and the connection of the hub to the computer. Drivers for the CAN interface as well as the RS-232 interfaces are installed. All drivers are installed from the provided Product CD.

Setup the driver for the CAN interface before connecting the PCAN-USB Hub to the computer for the first time.

▶ Do the following to setup the driver for the CAN interface:

1. Make sure that you are logged in as user with administrator privileges (not needed for normal use of the PCAN-USB Hub later on).
2. Insert the CD into the appropriate drive of the computer. Usually a navigation program appears a few moments later. If not, start the file `Intro.exe` from the root directory of the CD.
3. On the page **English > Drivers** activate the entry **PCAN-USB**.
4. Click on **Install now**. The setup program for the driver is executed.

Follow the instructions of the setup program.



Tip: If you don't want to install the CAN monitor PCAN-View for Windows onto hard disk together with the driver, you have the option to start the program later directly from CD without prior installation.

▶ Do the following to connect the PCAN-USB Hub and carry out the initialization of the CAN driver and the installation of the drivers for the RS-232 interfaces:

1. Connect the PCAN-USB Hub to a USB port at the computer. The computer can remain powered on.

Windows notifies that new hardware has been detected.

2. Only Windows XP: A Wizard dialog box appears guiding through the CAN driver initialization ("PCAN-USB device"). Follow its instructions. Deny the search for driver software at Windows Update and select the automatic software installation during this procedure.
3. Dialog boxes appear for the installation of the drivers for the RS-232 interfaces (devices "USB <-> Serial Cable" and "USB Serial Port"). Follow their instructions. Select the search for driver software on CD during this procedure.

The drivers are found on CD and installed by Windows.

Afterwards you can work as user with restricted rights again.

After the initialization process for the driver for the CAN interface is finished successfully the red LED at the CAN connector of the PCAN-USB Hub is on.

The Device Manager of Windows contains the following new entries:

- └ Ports (COM & LPT) > USB Serial Port (COMn¹) and USB Serial Port (COMn¹)
 - └ CAN-USB-Hardware > PCAN-USB Device
 - └ Universal Serial Bus controllers > Generic USB Hub
 - └ Universal Serial Bus controllers > USB Serial Converter A
 - └ Universal Serial Bus controllers > USB Serial Converter A
 - └ Universal Serial Bus controllers > USB Composite Device
-

¹ The port numbers for the COM ports may vary. If a COM port is occupied, the next vacant port number is used. Changing the port number in the Device Manager: Ports (COM & LPT) > USB Serial Port (COMn) > Properties > Port Settings > Advanced

3 Connectors on the PCAN-USB Hub

3.1 Upstream Port (USB cable)

The cable with the USB plug is used for connecting the PCAN-USB Hub to a computer.

When a high-speed USB connection (USB 2.0) is established, the LED at the upstream port is on. For a full-speed USB connection (USB 1.1) the LED stays off.

The Upstream Port can be used for voltage supply of the PCAN-USB Hub (see the following section 3.2).

3.2 Power (Voltage Supply)

The voltage supply of the PCAN-USB Hub may either be done via the Upstream Port or with an external power supply at the Power socket.

Property	For voltage supply via	
	Upstream Port	Power socket
Supply voltage	5 V DC (USB)	9 - 36 V DC
Operating mode name	Bus-powered	Self-powered
Permissible current delivery USB Port 1/2	100 mA	500 mA
Permissible total current consumption of hub (incl. additional USB devices at the hub)	500 mA	

If the permissible current delivery value is exceeded by connecting additional USB devices to the PCAN-USB Hub, Windows shows a respective warning and deactivates the related components.



Figure 1: Power socket at the rear of the PCAN-USB Hub for the external voltage supply (self-powered operation)

The connection of an external power supply at the Power socket is done with the supplied mating connector for fastening cable strands.

3.3 CAN

A High-speed CAN bus (ISO 11898-2) is connected to the 9-pin D-Sub connector. The pin assignment corresponds to the specification CiA® 102.




Figure 2: Pin assignment High-speed CAN (view onto connector of the PCAN-USB Hub)

With the pins 1 and 9 devices with low power consumption (e.g. bus converters) can be directly supplied via the CAN connector. At delivery these pins are not assigned. You can find a detailed description about the activation in the following section 3.3.1.



Tip: You can connect a can bus with a different transmission standard via a bus converter. PEAK-System offers different bus converter modules (e.g. PCAN-TJA1054 for a Low-speed CAN bus according to ISO 11898-3).

3.3.1 Supplying External Devices via the CAN Connector

By setting solder bridges on the PCB of the PCAN-USB Hub (casing opened) a 5-Volt supply can be routed to pin 1 and the external voltage supply, if available, can be routed to pin 9 of the D-Sub CAN connector.

CAN D-Sub pin	Voltage	Max. current delivery
1	+5 V	100 mA
9	external supply voltage (9 - 36 V)	2 A

If the solder bridge for pin 9 is set, the state of this pin can be switched by software (on/off). At delivery pin 9 is on referred to the software part. On request we'll provide you with additional information and a Windows program for switching ([contact information](#): see on page 2).

➡ Proceed as follows to activate the 5-Volt supply and the external voltage supply at the CAN connector:

Remove the four lower corner screws from the aluminum casing of the PCAN-USB Hub and then the bottom cover.

Set the solder bridge(s) on the PCB of the PCAN-USB Hub according to the desired function. During this procedure take especially care not to produce unwanted short circuits on the board.

The following figure shows the positions of the solder fields on the PCB of the PCAN-USB Hub; the tables below contain the possible settings.




Figure 3: Positions of the solder fields JP103 and JP104 on the PCB of the PCAN-USB Hub

5-Volt supply →	None	Pin 1
JP104		
External supply →	None	Pin 9
JP103		

⚠ Attention! Risk of short circuit! If the option described in this section is activated, you may only connect or disconnect CAN cables or peripheral systems (e.g. external bus converters) to or from the PCAN-USB Hub while it is de-energized (the hub is not connected to the computer). Consider that some computers still supply the USB ports with power even when they are turned off (standby operation).

3.4 RS-232

An RS-232 connection is done via a 9-pin D-Sub connector.




Figure 4: Pin assignment RS-232 A/B
(view onto connector of the PCAN-USB Hub)

3.5 USB Ports (Downstream)

Further USB devices can be connected to the USB ports 1 and 2.




Figure 5: USB ports at the back of the PCAN-USB Hub

When using the USB ports, we recommend the voltage supply of the PCAN-USB Hub via the Power socket (self-powered operation). See also section 3.2 *Power (Voltage Supply)* on page 9.

Supply via	Operating mode	Current delivery USB Port 1/2
Upstream Port	Bus-powered	max. 100 mA
Power socket	Self-powered	max. 500 mA

4 operation

4.1 Status LEDs

The PCAN-USB Hub has several status LEDs.




Figure 6: Arrangement of the LEDs on the back side, USB Upstream / Power socket

Power

- **Green:** Supply via Upstream port
- **Red:** external voltage supply

USB Upstream (red)

- **On:** High-speed USB connection (USB 2.0) with a computer
- **Off:** Full-speed USB connection (USB 1.1) with a computer




Figure 7: Arrangement of the LEDs on the front side,
CAN / RS-232 A/B

CAN (red)

- **On:** The CAN interface is initialized. There's a connection to a driver of the operating system.
- **Slowly flashing:** A software application is connected to the CAN interface.
- **Quickly flashing:** Data is transmitted via the connected CAN bus.

RS-232 A/B (green)

- **Flickering:** Transmission on TxD or RxD

4.2 Removing the Hub Safely

Obey the notes about removing hardware safely, if one of the following cases arises:

- You want to remove the PCAN-USB Hub from the computer during a Windows session.
 - You want to switch the voltage supply at the Power socket on or off.
- ▶ Do the following to log off the PCAN-USB Device in the hub and USB devices eventually connected to the hub from Windows:
1. Under Windows you can find the icon for safely removing hardware in the notification area of the Taskbar (on the lower right of the desktop):



Figure 8: Icon for removing hardware safely

2. After clicking on the icon select the command **Remove PCAN-USB Device**.
3. Proceed similarly with further USB devices that are connected to the PCAN-USB Hub.
4. When the CAN LED on the PCAN-USB Hub is off, you can remove it from the USB port of the computer or switch the external voltage supply.

5 CAN Software

This chapter deals with the provided software and the programming interface for the CAN interface of the PCAN-USB Hub.

5.1 CAN Monitor PCAN-View for Windows

PCAN-View for Windows is a simple CAN monitor for viewing and transmitting CAN messages.




Figure 9: The main window of PCAN-View for Windows

▶ Do the following to start and initialize PCAN-View:

1. If PCAN-View is already installed on the hard disk, open the Windows Start menu, go to **Programs > PCAN-Hardware**, and select the entry **PCAN-View USB**.

In order to start directly from the supplied CD without prior installation use the navigation program (*Intro.exe*), go to **English > Tools**, and in the entry **PCAN-View for USB** click on **Start**.

The dialog box for selecting the CAN hardware and for setting the CAN parameters appears.




Figure 10: Selection of the CAN specific hardware and parameters

2. From the list **Baud rate** select the transfer rate that is used by all nodes on the CAN bus.
3. Under **Message filter** you can limit the range of CAN IDs to be received, either for standard frames (11-bit IDs) or for extended frames (29-bit IDs).

Finally confirm the settings in the dialog box with **OK**. The main window of PCAN-View appears (see Figure 9).

You can find further information about the use of PCAN-View in the help which you can invoke in the program via the menu **Help** or the **F1** key.

5.2 Linking Own Programs with PCAN-Light

On the provided CD you can find files for software development in the directory branch `Develop`. They exclusively serve the linking of own programs to hardware by PEAK-System with the help of the installed device driver under Windows.

Further more the CD-ROM contains header files and examples for creating own applications in conjunction with the PCAN-Light drivers. Read the detailed documentation of the interface (API) in each header file.

You can find further information in the text and help files (file name extensions `.txt` and `.chm`).

Notes about the License

The CAN device driver, the CAN interface DLL, and further files needed for linking are property of the PEAK-System Technik GmbH and may be used only in connection with a hardware component purchased from PEAK-System or one of its partners. If a CAN hardware component of third party suppliers should be compatible to one of PEAK-System, then you are not allowed to use or to pass on the driver software of PEAK-System.

PEAK-System assumes no liability and no support for the PCAN-Light driver software and the necessary interface files. If third party suppliers develop software based on the PCAN-Light driver and problems occur during use of this software, consult the software provider. To obtain development support, you need to own a PCAN-Developer or PCAN-Evaluation version.

6 Technical specifications

Supply	
Supply voltage	5 V DC via USB port (bus-powered operation) 9 - 36 V DC via Power socket (self-powered operation)
Current consumption	At 5 V via USB port: max. 300 mA At 12 V via Power socket: max. 150 mA (each time without connected USB devices)
Connectors	
Computer	USB plug type A
CAN	D-Sub (m), 9 pins Pin assignment according to specification CiA® 102
RS-232	2 x D-Sub (m), 9 pins
USB	2 x USB socket type A
USB	
Upstream port	USB 2.0 (compatible to USB 1.1)
Downstream ports	USB 2.0
CAN	
Specification	ISO 11898-2 High-speed CAN (up to 1 Mbit/s) 2.0A (standard format) and 2.0B (extended format)
Controller	NXP (Philips) SJA1000T
Transceiver	NXP (Philips) PCA82C251
RS-232	
Transfer rates	0.3 - 120 kbit/s
Signal levels	EIA-232E

Continued on the next page

Environment	
Operating temperature	-30 - +85 °C (-22 - +185 °F)
Temperature for storage and transport	-40 - +105 °C (-40 - +221 °F)
Relative humidity	15 - 90 %, not condensing
EMC	EN 55024:2003-10 EN 55022:2007-04 EC directive 2004/108/EG
Ingress protection (IEC 60529)	IP50

Measures	
Size	105 x 26 x 110 mm (4 1/8 x 1 x 4 5/16 inches) (without connection cable)
Weight	300 g (10.6 oz.) (with connection cable)

Appendix A CE Certificate

PCAN-USB Hub IPEH-002004 – EC Declaration of Conformity
PEAK-System Technik GmbH



Notes on the CE Symbol

The following applies to the PCAN-USB Hub product
IPEH-002004

EC Directive

This product fulfills the requirements of EC directive
2004/108/EG on "Electromagnetic Compatibility" and is
designed for the following fields of application as per the
CE marking:

Electromagnetic Immunity

DIN EN 55024, Publication date: 2003-10
Information technology equipment, immunity characteristics – Limits and methods of
measurement (IEC/CISPR 24:1997, modified + A1:2001 + A2:2003);
German version EN 55024:1998 + A1:2001 + A2:2003

Electromagnetic Emission

DIN EN 55022, Publication date: 2007-4
Information technology equipment – Radio disturbance characteristics – Limits and methods
of measurement (IEC/CISPR 22:2005, modified);
German version EN 55022:2006

Declarations of Conformity

In accordance with the above mentioned EU directives,
the EC declarations of conformity and the associated
documentation are held at the disposal of the competent
authorities at the address below:

PEAK-System Technik GmbH

Mr. Wilhelm
Otto-Roehm-Strasse 69
64293 Darmstadt
Germany

Phone: +49 (0)6151 8173-20
Fax: +49 (0)6151 8173-29
E-mail: info@peak-system.com

A handwritten signature in black ink, appearing to read "V. Wilhelm".

Signed this 26th day of February 2009

Appendix B Quick Reference


Software/Hardware Installation under windows

Before connecting the PCAN-USB Hub to the computer set up the corresponding software package (PCAN-USB) from the supplied CD (with administrator privileges). Afterwards connect the PCAN-USB Hub to a USB port at your computer. The Hub is recognized by Windows and the drivers are initialized. After the installation process for the CAN interface is finished successfully the red CAN LED on the hub is on. The RS-232 interfaces are accessible as virtual COM ports.

CAN Access

Run the CAN monitor PCAN-View from the Windows Start menu as a sample application for accessing the CAN interface of the PCAN-USB Hub. For initialization of the CAN interface select the CAN transfer rate (Baud rate).

High-speed CAN



n/c = not connected

RS-232

